Thinking of you Electrolux

Built-In Electric Oven

We were thinking of you when we made this product

Welcome to the world of Electrolux

Thank you for choosing a first class product from Electrolux, which hopefully will provide you with lots of pleasure in the future. The Electrolux ambition is to offer a wide variety of quality products that make your life more comfortable. You will find some examples on the cover in this manual. Please take a few minutes to study this manual so that you can take advantage of the benefits of your new machine. We promise that it will provide a superior User Experience delivering Ease-of-Mind. Good luck!

4 electrolux contents

Contents

Salety instructions	5
Description of the Appliance	7
Before Using for the first time	11
Using the Oven	12
Uses, Tables and Tips	18
Cleaning and Care	34
What to do if	45
Installation Instructions	46
Disposal	51
Guarantee/Customer Service	52
Service	54

The following symbols are used in this user manual:



Important information concerning your personal safety and information on how to avoid damaging the appliance.



General information and tips



Environmental information



Safety instructions

(€

This appliance conforms with the following EU Directives:

- 73/23/EEC dated 19.02.1973 Low Voltage Directive
- 89/336/EEC dated 03.05.1989 EMC Directive inclusive of Amending Directive 92/31/EEC
- 93/68/EEC dated 22.07.1993 CE Marking Directive

Electrical safety

- This appliance must be only connected by a **registered electrician**.
- In the event of a fault or damage to the appliance: Take the fuses out or switch off.
- Repairs to the appliance must only be carried out by qualified service engineers. Considerable danger may result from improper repairs. If repairs become necessary, please contact our Customer Services or your dealer.

Child Safety

 Never leave children unsupervised when the appliance is in use.

Safety whilst Using

- This appliance is intended to be used for cooking, roasting and baking food in the home.
- Take care when connecting electric appliances to sockets nearby. Do not allow connecting leads to come into contact with or to catch beneath the hot oven door.

- Warning: Risk of burns! The interior of the oven becomes hot during use.
- Using ingredients containing alcohol in the oven may create an alcohol-air mixture that is easily ignited. In this case, open the door carefully. Do not have embers, sparks or naked flames in the vicinity when opening the door.

How to avoid damage to the appliance

- Do not line the oven with aluminium foil and do not place baking trays, pots, etc. on the oven floor, as the heat that builds up will damage the oven enamel.
- Fruit juices dripping from the baking tray will leave stains, which you will not be able to remove. For very moist cakes, use a deep tray.
- Do not put any strain on the oven door when open.
- Never pour water directly into the oven when it is hot. This could cause damage to or discoloration of the enamel.
- Rough handling, especially around the edges of the front panel, can cause the glass to break.
- Do not store any flammable materials inside the oven. These could ignite when the oven is switched on.
- Do not store any moist foods inside the oven. This could damage the oven enamel.
- After switching off the cooling fan, do not keep uncovered dishes in the oven. Moisture may condense in the oven interior or on the glass doors and may get into the units.




Note on enamel coating


Changes in the colour of the oven's enamel coating as a result of use do not affect the appliance's suitability for normal and correct use. They therefore do not constitute a defect in the sense of the warranty law.

Description of the Appliance


General Overview



Control Panel



Oven Features




10 electrolux description of the appliance

Oven accessories


Oven shelf

For cookware, cake tins, roasts and grilled foods.



Baking tray

For cakes and biscuits.



Before Using for the first time

Initial Cleaning

Before using the oven for the first time you should clean it thoroughly.



Caution: Do not use any caustic, abrasive cleaners! The surface could be damaged.




To clean metal fronts use commercially available cleaning agents.

- Turn the oven function switch to oven lighting ♥.
- 2. Remove all accessories and the shelf support rails and wash them with warm water and washing up liquid.
- Then wash out the oven with warm water and washing-up liquid, and dry.
- 4. Wipe the front of the appliance with a damp cloth.

Using the Oven

Switching the Oven On and Off



- 1. Turn the oven functions dial to the desired function.
- 2. Turn the temperature selector to the desired temperature.

The power indicator is lit as long as the oven is in operation.

The temperature pilot light is lit as long as the oven is heating up.

3. To turn the oven off, turn the oven functions dial and the temperature selector to the Off position.



Cooling fan

The fan switches on automatically in order to keep the appliance's surfaces cool. When the oven is switched off, the fan continues to run to cool the appliance down, then switches itself off automatically.

Oven Functions

The oven has the following functions:

Oven function		Application	Heating element/ fan		
ँ	Light	Using this function you can light up the oven interior, e.g. for cleaning.			
	Convection with ring heating element	For baking on up to three oven levels at the same time. Set the oven temperatures 20-40 °C lower than when using Conventional.	Rear heating element, fan		
9	Pizza setting	For baking on one oven level dishes that require more intensive browning and a crispy base . Set the oven temperatures 20-40 °C lower than when using Conventional.	Bottom heat, rear wall heating element, fan		
	Conventional	For baking and roasting on one oven level .	Top heat, bottomheat		
	Bottom heat	For baking cakes with crispy or crusty bases .	Bottom heat		
*	Defrost	For defrosting e. g. flans and gateaux, butter, bread, fruit or other frozen foods .	Fan		
""	Grill	For grilling flat foodstuffs placed in the middle of the grill and for toasting .	Grill		
	Dual grill	For grilling flat foodstuffs in large quantities and for toasting .	Grill, top heat		
₩	Convection grilling	For roasting larger joints of meat or poultry on one level. The function is also suitable for gratinating and browning .	Grill, top heat, fan		

Inserting the Oven Shelf and the Baking Tray




Shelf runner safety and anti-tip device

As a shelf runner safety device, all insertable components have a small curved indentation at the bottom on the right and left-hand edge. Always insert insertable components so that this indentation is at the back of the oven interior. This indentation is also important for preventing the insertable components from tipping.

Inserting the baking tray

Push the baking tray between the guide bars of the selected oven level.




Inserting the oven shelf:

Insert the oven shelf so that the feet point downwards.

Push the oven shelf between the guide bars of the selected oven level.




The high rim around the oven shelf is an additional device to prevent cookware from slipping.



Inserting the oven shelf and the baking tray together:

Lay the oven shelf on the baking tray. Push the baking tray **between** the guide bars of the selected oven level.



Inserting/Removing the Grease Filter


Only use the grease filter when roasting to protect the rear heating elements from fat splashes.

Inserting the grease filter

Hold the grease filter by the grip and insert the two mounts downwards into the opening on the rear wall of the oven (fan opening).

Taking out the grease filter

Hold the grease filter by the grip and unhook it.



Timer

To set a time. A signal is sounded when the time has elapsed.


This function has no effect on oven operation.

Set the timer knob to 60 minutes, then turn it to the desired length of time. (60 minutes maximum).

A signal is sounded when the time has elapsed.

To change your setting, just turn the knob to the desired value.

To stop the timer before the set time has elapsed, turn the knob to OFF.



Uses, Tables and Tips

Baking

Oven function: Convection with ring heating element ⊚ or Conventional □

Oven levels

- Baking with Conventional
 is possible on one oven level.
- With Convection with ring heating element you can bake on up to 3 baking trays at the same time:

1 baking tray:

e.g. oven level 3

1 cake tin: e.g. oven level 1


2 baking trays:


z.g., oven levels 1 and 3


3 baking trays: oven levels 1, 3 and 5


Baking tins

- For Conventional dark metal and non-stick tins are suitable.









General Instructions

- Insert the tray with the bevel at the front.
- With Conventional or Convection with ring heating element you can also bake with two tins next to one another on the oven shelf at the same time. This does not significantly increase baking time.



When frozen foods are used the trays inserted may distort during cooking. This is due to the large difference in temperature between the freezing temperature and the temperature in the oven. Once the trays have cooled the distortion will disappear again.

How to use the Baking Tables

The tables give the required temperature settings, baking times and oven shelf levels for a selection of typical dishes.

- Temperatures and baking times are for guidance only, as these will depend on the consistency of pastry, dough or mixture, the amount and the type of baking tin.
- We recommend using the lower temperature the first time and then if necessary, for example, if a deeper browning is required, or baking time is too long, selecting a higher temperature.
- If you cannot find the settings for a particular recipe, look for the one that is most similar.
- If baking cakes on baking trays or in tins on more than one level, baking time may be extended by 10-15 minutes.

- Moist recipes (for example, pizzas, fruit flans, etc.) are baked on one level.
- Cakes and pastries at different heights may brown at an uneven rate at first. If this occurs, please do not change the temperature setting. Different rates of browning even out as baking progresses.
- Your new oven may bake or roast differently to your previous appliance.
 So adapt your normal settings (temperature, cooking times) and oven shelf levels to the recommendations in the following tables.



With longer baking times, the oven can be switched off about 10 minutes before the end of baking time, to make use of the residual heat.

Unless otherwise stated, the values given in the tables assume that cooking is started with the oven cold.

Baking table Baking on one oven level

Type of baking		Oven function	Oven level	Temperature °C	Time Hr: Mins.
Baking in tins					
Ring cake or brioche	8	Convection with ring heating element	1	150-160	0:50-1:10
Madeira cake/fruit cakes	8	Convection with ring heating element	1	140-160	1:10-1:30
Sponge cake		Convection with ring heating element	1	140	0:25-0:40
Sponge cake		Conventional	1	160	0:25-0:40
Flan base - short pastry	8	Convection with ring heating element	3	170-180 ¹⁾	0:10-0:25
Flan base - sponge mixture	8	Convection with ring heating element	3	150-170	0:20-0:25
Apple pie		Conventional	1	170-190	0:50-1:00
Apple pie (2 tins Ø20cm, diagonally off set)	8	Convection with ring heating element	1	160	1:10-1:30
Apple pie (2tins Ø20cm, diagonally off set)		Conventional	1	180	1:10-1:30
Savoury flan (e. g, quiche lorraine)	8	Convection with ring heating element	1	160-180	0:30-1:10
Cheesecake		Conventional	1	170-190	1:00-1:30
Cakes/pastries/breads or	n ba	king trays			
Plaited bread/bread crown		Conventional	3	170-190	0:30-0:40
Christmas stollen		Conventional	3	160-180 ¹⁾	0:40-1:00
Bread (rye bread) -first of all -then		Conventional	1	230 ¹⁾ 160-180	0:25 0:30-1:00
Cream puffs/eclairs		Conventional	3	160-170 ¹⁾	0:15-0:30
Swiss roll		Conventional	3	180-200 ¹⁾	0:10-0:20

Type of baking	,	Oven function	Oven level	Temperature °C	Time Hr: Mins.
Cake with crumble topping (dry)	8	Convection with ring heating element	3	150-160	0:20-0:40
Buttered almond cake/sugar cakes		Conventional	3	190-210 ¹⁾	0:15-0:30
Fruit flans (made with yeast dough/ sponge mixture)	8	Convection with ring heating element	3	150	0:35-0:50
Fruit flans (made with yeast dough/ sponge mixture)		Conventional	3	170	0:35-0:50
Fruit flans made with short pastry	8	Convection with ring heating element	3	160-170	0:40-1:20
Yeast cakes with delicate toppings (e. g, quark, cream, custard)		Conventional	3	160-180 ¹⁾	0:40-1:20
Pizza (with a lot of topping)	8	Convection with ring heating element	1	180-200 ¹⁾	0:30-1:00
Pizza (thin crust)	(a)	Convection with ring heating element	1	200-220 ¹⁾	0:10-0:25
Unleavened bread	8	Convection with ring heating element	1	200-220	0:08-0:15
Tarts (CH)	8	Convection with ring heating element	1	180-200	0:35-0:50
Biscuits					
Short pastry biscuits	8	Convection with ring heating element	3	150-160	0:06-0:20
Viennese whirls	8	Convection with ring heating element	3	140	0:20-0:30
Viennese whirls		Conventional	3	160 ¹⁾	0:20-0:30
Biscuits made with sponge mixture	8	Convection with ring heating element	3	150-160	0:15-0:20

22 electrolux uses, tables and tips

Type of baking	Oven function		Oven level	Temperature °C	Time Hr: Mins.
Pastries made with egg white, meringues	8	Convection with ring heating element	3	80-100	2:00-2:30
Macaroons	8	Convection with ring heating element	3	100-120	0:30-0:60
Biscuits made with yeast dough	8	Convection with ring heating element	3	150-160	0:20-0:40
Puff pastries	8	Convection with ring heating element	3	170-180 ¹⁾	0:20-0:30
Rolls	8	Convection with ring heating element	3	160 ¹⁾	0:20-0:35
Rolls		Conventional	3	180 ¹⁾	0:20-0:35
Small cakes (20 per tray)	\text{\ti}\}\text{\ti}\}\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\tex{\tex	Convection with ring heating element	3	140 ¹⁾	0:20-0:30
Small cakes (20per tray)		Conventional	3	170 ¹⁾	0:20-0:30

¹⁾ Pre-heat the oven

Baking on more than one oven level

Type of baking	Convection with ring heating element 🗑	Convection with ring heating element 🗑		Time Hours: Mins.	
	Shelf position	s from bottom	Tempera-	IVIII15.	
	2 levels	3 levels	ture in °C		
Cakes/pastries/breads of	on baking trays				
Cream puffs/Eclairs	1/4		160-180 ¹⁾⁾	0:35-0:60	
Dry streusel cake	1/3		140-160	0:30-0:60	
Biscuits/small cakes/pa	stries/rolls				
Short pastry biscuits	1/3	1/3/5	150-160	0:15-0:35	
Viennese whirls	1/3	1/3/5	140	0:20-0:60	
Biscuits made with sponge mixture	1/3		160-170	0:25-0:40	
Biscuits made with egg white, meringues	1/3		80-100	2:10-2:50	
Macaroons	1/3		100-120	0:40-1:20	
Biscuits made with yeast dough	1/3		160-170	0:30-0:60	
Puff pastries	1/3		170-180 ¹⁾	0:30-0:50	
Rolls	1/4		160	0:30-0:55	
Small cakes (20per tray)	1 / 4		140 ¹⁾	0:25-0:40	

¹⁾ Pre-heat the oven

24 electrolux uses, tables and tips

Tips on Baking

Baking results	Possible cause	Remedy
The cake is not browned enough underneath	Wrong oven level	Place cake lower
The cake sinks (becomes	Oven temperature too high	Use a slightly lower setting
soggy, lumpy, streaky)	Baking time too short	Set a longer baking time Baking times cannot be reduced by setting higher temperatures
	Too much liquid in the mixture	Use less liquid. Pay attention to mixing times, especially if using mixing machines
Cake is too dry	Oven temperature too low	Set oven temperature higher.
	Baking time too long	Set a shorter baking time
Cake browns unevenly	Oven temperature too high and baking time too short	Set a lower oven temperature and a longer baking time
	Mixture is unevenly distributed	Spread the mixture evenly on the baking tray
	Grease filter is inserted	Take out the grease filter
Cake does not cook in	Temperature too low	Use a slightly higher oven setting
the baking time given	Grease filter is inserted	Take out the grease filter

Table Pizza setting **№**

Type of baking	Shelf position	Temperature °C	Time Hr: Mins.
Pizza (thin crust)	1	180 - 200 ¹⁾	20 - 30
Pizza (with a lot of topping)	1	180 - 200	20 - 30
Tarts	1	180 - 200	45 - 60
Spinach flan	1	160 -180	45 - 60
Quiche Lorraine	1	170 - 190	40 - 50
Quark flan, round	1	140 - 160	60 - 90
Quark flan on tray	1	140 - 160	50 - 60
Apple cake, covered	1	150 - 170	50 - 70
Vegetable pie	1	160 - 180	50 - 60
Unleavened bread	1	250 - 270 ¹⁾	10 - 20
Puff pastry flan	1	160 - 180 ¹⁾	40 - 50
Flammekuchen (Pizza-like dish from Alsace)	1	250 - 270 ¹⁾	12 - 20
Piroggen (Russian version of calzone)	1	180 - 200 ¹⁾	15 - 25

¹⁾ Pre-heat the oven

Table for Bakes and Gratins

Dish	Oven function		Shelf position	Tempera- ture °C	Time Hr: Mins.
Pasta bake		Conventional	1	180-200	0:45-1:00
Lasagne		Conventional	1	180-200	0:25-0:40
Vegetables au gratin ¹⁾	8	Convection with ring heating element	1	160-170	0:15-0:30
Baguettes topped with melted cheese ¹⁾	8	Convection with ring heating element	1	160-170	0:15-0:30
Sweet bakes		Conventional	1	180-200	0:40-0:60
Fish bakes		Conventional	1	180-200	0:30-1:00
Stuffed vegetables	8	Convection with ring heating element	1	160-170	0:30-1:00

¹⁾ Pre-heat the oven

Frozen Ready Meals Table

Food to be cooked	Oven function		1 Oven function		Shelf position	Temperature °C	Time
Frozen pizza		Conventional	3	as per manufac- turer's instruc- tions	as per manufac- turer's instruc- tions		
Chips ¹⁾ (500 g)		Convection with ring heating element	3	200-220	as per manufac- turer's instruc- tions		
Baguettes		Conventional	3	as per manufac- turer's instruc- tions	as per manufac- turer's instruc- tions		
Fruit flans		Conventional	3	as per manufac- turer's instruc- tions	as per manufac- turer's instruc- tions		

¹⁾ Comments: Turn chips 2 or 3 times during cooking

Roasting

Oven function: Conventional ☐ or Convection grilling 🗑

Ovenware for roasting

- Any heat-resistant ovenware is suitable to use for roasting. (Please read the manufacturer's instructions.)
- For all lean meats, we recommend roasting these in a roasting tin or dish with a lid. The meat will be more succulent.
- All types of meat, that can be browned or have crackling, can be roasted in a roasting tin or dish without a lid.



Tips on using the Roasting Table The information given in the following table is for guidance only.

- We recommend cooking meat and fish weighing 1kg or more in the oven.
- To prevent meat juices or fat from burning onto the ovenware, we recommend adding some liquid.
- If required, turn the roast (after 1/2 2/3 of the cooking time).
- Baste large roasts and poultry with their juices several times during roasting. This will give better roasting results.
- You can switch the oven off about 10 minutes before the end of the roasting time, in order to utilise the residual heat.

Roasting table

Type of meat	Quantity	Ov	enfunction	Shelf position	Tem- pera- ture °C	Time Hours mins.
Beef						
Pot roast	1-1.5 kg		Convention- al	1	200-250	2:00-2:30
Roast beef or fillet						per cm. of thickness
- rare	per cm. of thickness	\overline{\overline{\pi}}	Convection grilling	1	190- 200 ¹⁾	0:05-0:06
- medium	per cm. of thickness	₩	Convection grilling	1	180-190	0:06-0:08
- well done	per cm. of thickness	₹	Convection grilling	1	170-180	0:08-0:10
Pork						
Shoulder, neck, ham joint	1-1.5 kg	\overline{\overline{\pi}}	Convection grilling	1	160-180	1:30-2:00
Chop, spare rib	1-1.5 kg	₩	Convection grilling	1	170-180	1:00-1:30
Meat loaf	750 g-1 kg	₹	Convection grilling	1	160-170	0:45-1:00
Porkknuckle (pre- cooked)	750 g-1 kg	\overline{\overline{\pi}}	Convection grilling	1	150-170	1:30-2:00
Veal						
Roast veal	1 kg	\overline{\overline{\pi}}	Convection grilling	1	160-180	1:30-2:00
Knuckle of veal	1.5-2 kg	₩	Convection grilling	1	160-180	2:00-2:30
Lamb						
Leg of lamb, roast lamb	1-1.5 kg	\overline{\overline{\pi}}	Convection grilling	1	150-170	1:15-2:00
Saddle of lamb	1-1.5 kg	\overline{\overline{\pi}}	Convection grilling	1	160-180	1:00-1:30
Game						
Saddle of hare, leg of hare	up to 1 kg		Convention- al	3	220- 250 ¹⁾	0:25-0:40
Saddle of venison	1.5-2 kg		Convention- al	1	210-220	1:15-1:45

Type of meat	Quantity	Ovenfunction		Shelf position	Tem- pera- ture °C	Time Hours mins.
Haunch of venison	1.5-2 kg		Convention- al	1	200-210	1:30-2:15
Poultry						
Poultry portions	200-250g each	\overline{\pi}	Convection grilling	1	200-220	0:35-0:50
Half chicken	400-500g each	\overline{\overline{\pi}}	Convection grilling	1	190-210	0:35-0:50
Chicken, poulard	1-1.5 kg	\overline{\overline{\pi}}	Convection grilling	1	190-210	0:45-1:15
Duck	1.5-2 kg	\overline{\overline{\pi}}	Convection grilling	1	180-200	1:15-1:45
Goose	3.5-5 kg	\overline{\overline{\pi}}	Convection grilling	1	160-180	2:30-3:30
Turkey	2.5-3.5 kg	\$	Convection grilling	1	160-180	1:45-2:30
Turkey	4-6 kg	\overline{\pi}	Convection grilling	1	140-160	2:30-4:00
Fish (steamed)						
Whole fish	1-1.5 kg		Convention- al	1	210-220	0:45-1:15

¹⁾ Pre-heat the oven

Grill Sizes

Oven function: Grill or Dual grill with maximum temperature setting



Important: Always grill with the oven door closed.



The empty oven should always be pre-heated with the grill functions for 5 minutes.

- For grilling, place the **shelf** in the **recommended shelf position**.
- Always insert the tray into the first shelf position from the bottom.
- The grilling times are guidelines.
- Grilling is particularly suitable for flat pieces of meat or fish.

Grilling table

Food to be grilled	Oven level	Grilling time	
		1st side	2nd side
Burgers	4	8-10 mins.	6-8 mins.
Pork fillet	4	10-12 mins.	6-10 mins.
Sausages	4	8-10 mins.	6-8 mins.
Fillet steaks, veal steaks	4	6-7 mins.	5-6 mins.
Fillet of beef, roast beef (approx. 1 kg)	3	10-12 mins.	10-12 mins.
Toast ¹⁾	3	4-6 mins.	3-5 mins.
Toast with topping	3	6-8 mins.	

¹⁾ Do not pre-heat

Defrosting

Oven function: Defrost **()** (no temperature setting)

- Unwrap the food and place it on a plate on the oven shelf.
- Do not cover with a plate or bowl, as these can substantially lengthen the defrosting time.
- For defrosting, place the shelf in the **1st oven level from the bottom**.

Defrosting table

Dish	Defrost- ing time mins.	Further defrosting time (mins.)	Comments
Chicken, 1000 g	100-140	20-30	Place the chicken on an upturned saucer placed on a large plate Turn halfway through
Meat, 1000 g	100-140	20-30	Turn halfway through
Meat, 500 g	90-120	20-30	Turn halfway through
Trout, 150g	25-35	10-15	
Strawberries, 300g	30-40	10-20	
Butter, 250g	30-40	10-15	
Cream, 2 x 200g	80-100	10-15	Cream can also be whipped when still slightly frozen in places
Gateau, 1400g	60	60	

Drying

Oven function: Convection with ring heating element ⊚

- Use oven shelves covered with greaseproof paper or baking parchment.
- You get a better result if you switch the oven off halfway through the drying time, open the door and leave the oven to cool down overnight.
- After this finish drying the food to be dried.

Food to be dried	Temperature in °C	Oven level		Time in hours		
		1 level	2 levels	(Guideline)		
Vegetables						
Beans	60- 70	3	1/4	6-8		
Peppers (strips)	60- 70	3	1/4	5-6		
Vegetables for soup	60- 70	3	1 / 4	5-6		
Mushrooms	50- 60	3	1/4	6-8		
Herbs	40-50	3	1/4	2-3		
Fruit						
Plums	60- 70	3	1/4	8-10		
Apricots	60- 70	3	1/4	8-10		
Apple slices	60- 70	3	1/4	6-8		
Pears	60- 70	3	1/4	6-9		

Making Preserves

Oven function: Bottom heat

- For preserving, use only commercially available preserve jars of the same size.
- Jars with twist-off or bayonet type lids and metal tins are not suitable.
- When making preserves, the first shelf position from the bottom is the one most used.
- Use the shelf for making preserves. There is enough room on this for up to six 1-litre preserving jars.

- The jars should all be filled to the same level and clamped shut.
- Place the jars on the baking tray in such a way that they are not touching each other.
- Pour approx. 1/2 litre of water into the baking tray so that sufficient moisture is produced in the oven.
- As soon as the liquid starts to pearl in the first jars (after about 35-60 minutes with 1 litre jars), switch the oven off or reduce the temperature to 100°C (see table).

Preserves table

The times and temperatures for making preserves are for quidance only.

preserves are for guidance only.					
Preserve	Temperature in°C	Cooking time until simmering in mins.	Continue to cook at 100°C in mins.		
Soft fruit					
Strawberries, blueberries, rasp- berries, ripe gooseberries	160-170	35-45			
Unripe gooseberries	160-170	35-45	10-15		
Stone fruit					
Pears, quinces, plums	160-170	35-45	10-15		
Vegetables					
Carrots ¹⁾	160-170	50-60	5-10		
Mushrooms ¹⁾	160-170	40-60	10-15		
Cucumbers	160-170	50-60			
Mixed pickles	160-170	50-60	15		
Kohlrabi, peas, asparagus	160-170	50-60	15-20		
Beans	160-170	50-60			

¹⁾ Leave standing in oven when switched off

Cleaning and Care



Warning: For cleaning, the appliance must be switched off and cooled down.

Warning: For safety reasons, do not clean the appliance with steam jet or high-pressure cleaning equipment.

Attention: Do not use any scouring agents, sharp cleaning tools or scourers.

Outside of the appliance

- Wipe the front of the appliance with a soft cloth and warm water and washing up liquid.
- For metal fronts, use normal commercially available cleaning agents.

Oven interior

Clean the appliance after each use. In this way, dirt is easier to clean off and is not allowed to burn on.

- 1. For cleaning, turn the oven light on.
- After every use, wipe the oven with a solution of washing-up liquid and allow to dry.



Clean stubborn dirt with a special oven cleaner.



Important: If using an oven spray, please follow the manufacturer's instructions exactly.

Accessories

Wash all slide-in units (shelf unit, baking tray, shelf support rails etc.) after each use and dry well. Soak briefly to make them easier to clean.

Fat Filter


- Clean the fat filter in hot water and washing up liquid or in the dishwasher.
- Badly burned on soiling can be removed by boiling the filter in a little water to which 2-3 tablespoonsful of dishwasher cleaner has been added.


Shelf Support Rails

The shelf support rails on the left and right hand sides of the oven can be removed for cleaning the side walls.

Removing the shelf support rails

First pull the front of the rail away from the oven wall (1) and then unhitch at the back (2).







Fitting the shelf support rails



Important! The rounded ends of the guide rails must be pointing forwards!

To re-insert, first hook the rail into place at the back (1) and then insert the front and press into place (2).





Oven Lighting



Warning: Risk of electric shock! Prior to changing the oven light bulb:


- Switch off the oven!
- Disconnect from the electricity supply.



Place a cloth on the oven floor to protect the oven light and glass cover.

Changing the oven light bulb/cleaning the glass cover

- 1. Remove the glass cover by turning it anti-clockwise and then clean it.
- 2. If necessary: replace with 25 watt, 230 V, 300 °C heat-resistant oven lighting.
- 3. Refit the glass cover.



Oven Ceiling

The upper heating element can be folded down to make it easier to clean the oven ceiling.

Folding down the heating element




Warning: Only fold down the heating element when the oven is switched off and there is no risk of being burnt!

- 1. Remove the side shelf support rails.
- Grip the heating element at the front and pull it forwards and out over the support lug on the inner wall of the oven.
- 3. The heating element will now fold down.



Caution: Do not use force to press the heating element down! The heating element might break.

Cleaning the oven ceiling




Repositioning the heating element

- 1. Move the heating element back up towards the oven ceiling.
- 2. Pull the heating element forwards against the spring pressure and guide it over the oven support lug.
- 3. Settle it onto the support.
- 4. Insert shelf support rail.



Important: The heating element must be positioned correctly and securely on both sides above the support lug on the inner wall of the oven.




Oven door


For easier cleaning of the oven interior the oven door of your appliance can be taken off its hinges.

Removing the oven door from its hinges

1. Open the oven door as far as it will go.



2. Undo the **clamping levers** (A) on both door hinges **fully**.




3. Close the oven door as far as the first position (approx. 45°).



4. Take hold of the oven door with a hand on each side and pull it away from the oven at an upwards angle (**Take care:** It is heavy).




Lay the oven door with the outer side facing downwards on something soft and level, for example, a blanket in order to prevent scratches.




Hanging the oven door back on its hinges

 From the handle side take hold of the oven door with a hand on each side and hold at an angle of approx. 45°. Position the recesses on the bottom of the oven door on the hinges on the oven.


Let the door slide down as far as it will go.



2. Open the oven door as far as it will go.



3. Fold up the clamping levers (A) on both door hinges back into their original positions.



4. Close the oven door.

Oven door glass


The oven door is fitted with two panels of glass mounted one behind the other. The inner panel can be removed for cleaning.




Important Rough handling, especially around the edges of the front panel, can cause the glass to break.

Removing the door glass


1. Open the oven door as far as it will go.



2. Undo the **clamping levers** (A) on both door hinges **fully**.




3. Close the oven door as far as the first position (approx. 45°).




42 electrolux cleaning and care

4. Take hold of the door trim (B) on the upper edge of the door at both sides and press inwards to release the clip seal. Then remove the door trim by pulling upwards.



5. Take hold of the door glass on its upper edge and take it out of the guide by pulling it upwards.




Cleaning the door glass


Clean the door glass thoroughly with a solution of water and washing up liquid. Then dry it carefully.

Putting the door glass back

 From above insert the door glass at an angle into the door profile at the bottom edge of the door and lower it.





2. Take hold of the door trim (B) at each side, position it on the inside edge of the door and plug the door trim(B) into the upper edge of the door.






On the open side of the door trim (B) there is a guide bar (C). This must be pushed between the outer door panel and the guide corner (D). The clip seal (E) must be snapped in.






44 electrolux cleaning and care

3. Open the oven door as far as it will go.



4. Fold up the clamping levers (A) on both door hinges back into their original positions.



5. Close the oven door.

What to do if ...

Fault	Possible cause	Remedy
The oven does not heat.	The oven has not been switched on.	Switch the oven on.
	The required settings have not been made.	Check the settings.
	The domestic electrical protection device (fuse) has been tripped.	Check the fuses or protection devices. If these are tripped repeatedly, you should call a qualified electrician.
The oven light does not come on.	The bulb has blown.	Replace the bulb.

If you are unable to remedy the problem by following the above suggestions, please contact your dealer or the Customer Care Department.



Warning! Repairs to the appliance are only to be carried out by qualified service engineers. Considerable danger to the user may result from improper repairs.



If the appliance has been wrongly operated, the visit from the customer service technician or dealer may not take place free of charge, even during the warranty period.



Advice on cookers with metal fronts:

Because of the cold surface at the front of the cooker, opening the oven door during (or just after) baking or roasting may cause the glass to steam up.

Installation Instructions




Attention: The new appliance may only be installed and connected by a registered expert.


Please comply with this. If you do not, any damage resulting is not covered by the warranty.




Safety information for the installer


- The electrical installation is to be set up so that the appliance can be isolated from the mains with a minimum 3mm all-pole contact separation.
 Suitable separation devices include e.g. cut-outs, fuses (screw fuses are to be taken out of the holder), RCD's and contactors.
- Anti-shock protection must be provided by the installation.
- The built-in unit must meet the stability requirements of DIN 68930.
- Built-in ovens and built-in cooking surfaces are fitted with special connection systems. For safety reasons, they must only be combined with appliances from the same manufacturer.






48 electrolux installation instructions





50 electrolux installation instructions



Disposal



Packaging material

The packaging materials are environmentally friendly and can be recycled. The plastic components are identified by markings, e.g. >PE<, >PS<, etc. Please dispose of the packaging materials in the appropriate container at the community waste disposal facilities.



Old appliance

The symbol and on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



Warning: So that the old appliance can no longer cause any danger, make it unusable before disposing of it.

To do this, disconnect the appliance from the mains supply and remove the mains cable from the appliance.

Guarantee/Customer Service

European Guarantee

This appliance is guaranteed by Electrolux in each of the countries listed at the back of this user manual, for the period specified in the appliance guarantee or otherwise by law. If you move from one of these countries to another of the countries listed below the appliance guarantee will move with you subject to the following qualifications:

- The appliance guarantee starts from the date you first purchased the appliance which will be evidenced by production of a valid purchase document issued by the seller of the appliance.
- The appliance guarantee is for the same period and to the same extent for labour and parts as exists in your new country of residence for this particular model or range of appliances.
- The appliance guarantee is personal to the original purchaser of the appliance and cannot be transferred to another user.
- The appliance is installed and used in accordance with instructions issued by Electrolux and is only used within the home, i.e. is not used for commercial purposes.
- The appliance is installed in accordance with all relevant regulations in force within your new country of residence.

The provisions of this European Guarantee do not affect any of the rights granted to you by law.

www.electrolux.com

•	~	
Albania	+35 5 4 261 450	Rr. Pjeter Bogdani Nr. 7 Tirane
Belgique/België/ Belgien	+32 2 363 04 44	Bergensesteenweg 719, 1502 Lembeek
Česká republika	+420 2 61 12 61 12	Budějovická 3, Praha 4, 140 21
Danmark	+45 70 11 74 00	Sjællandsgade 2, 7000 Fredericia
Deutschland	+49 180 32 26 622	Muggenhofer Str. 135, 90429 Nürnberg
Eesti	+37 2 66 50 030	Mustamäe tee 24, 10621 Tallinn

③	7	\boxtimes		
España	+34 902 11 63 88	Carretera M-300, Km. 29,900 Alcalá de Henares Madrid		
France	www.electrolux.fr			
Great Britain	+44 8705 929 929	Addington Way, Luton, Bedfordshire LU4 9QQ		
Hellas	+30 23 10 56 19 70	4 Limnou Str., 54627 Thessaloniki		
Hrvatska	+385 1 63 23 338	Slavonska avenija 3, 10000 Zagreb		
Ireland	+353 1 40 90 753	Long Mile Road Dublin 12		
Italia	+39 (0) 434 558500	C.so Lino Zanussi, 26 - 33080 Porcia (PN)		
Latvija	+37 17 84 59 34	Kr. Barona iela 130/2, LV-1012, Riga		
Lietuva	+370 5 2780609	Verkių 29, LT-09108 Vilnius		
Luxembourg	+35 2 42 43 13 01	Rue de Bitbourg, 7, L-1273 Hamm		
Magyarország	+36 1 252 1773	H-1142 Budapest XIV, Erzsébet királyné útja 87		
Nederland	+31 17 24 68 300	Vennootsweg 1, 2404 CG - Alphen aan den Rijn		
Norge	+47 81 5 30 222	Risløkkvn. 2 , 0508 Oslo		
Österreich	+43 18 66 400	Herziggasse 9, 1230 Wien		
Polska	+48 22 43 47 300	ul. Kolejowa 5/7, Warsaw		
Portugal	+35 12 14 40 39 39	Quinta da Fonte - Edificio Gonçalves Zarco - Q 35 2774 - 518 Paço de Arcos		
Romania	+40 21 451 20 30	Str. Garii Progresului 2, S4, 040671 RO		
Schweiz/Suisse/ Svizzera	+41 62 88 99 111	Industriestrasse 10, CH-5506 Mägenwil		
Slovenija	+38 61 24 25 731	Electrolux Ljubljana d.o.o. Gerbiceva 98, 1000 Ljubljana		
Slovensko	+421 2 43 33 43 22	Electrolux Slovakia s.r.o., Electrolux Domáce spotrebièe SK, Seberíniho 1, 821 03 Bratislava		
Suomi	www.electrolux.fi			
Sverige	+46 (0)771 76 76 76	Electrolux Service, S:t Göransgatan 143, S-105 45 Stockholm		
Türkiye	+90 21 22 93 10 25	Tarlabaşı caddesi no : 35 Taksim Istanbul		
Россия	+7 095 937 7837	129090 Москва, Олимпийский проспект, 16, БЦ "Олимпик"		

Service


In the event of technical faults, please first check whether you can remedy the problem yourself with the help of the operating instructions (section "What to do if...").

If you were not able to remedy the problem yourself, please contact the Customer Care Department or one of our service partners.

In order to be able to assist you quickly, we require the following information:

- Model description
- Product number (PNC)
- Serial number (S No.) (for numbers see rating plate)
- Type of fault
- Any error messages displayed by the appliance

So that you have the necessary reference numbers from your appliance at hand, we recommend that you write them in here:



Model description:	
PNC:	
S No:	

www.electrolux.com