INFO



EOB 854

Built-in Oven

Instruction and Installation Manual

(GB)

Electrolux

DEJ-K/RD-SD - 970505 319 2881-01

This manual will also be printed in the ITALIAN language.
We like to send this manual, if needed to your address and ask you to give us information by mail to Electrolux-Juno Küchentechnik GmbH K/CS
Junostraße 1
D-35745 Herborn

, -	\sim	\sim 1	\sim	~ :	-
	<i>1</i> 1		\sim	11	
					_

Important hints on safety	,
---------------------------	---

User instructions

Total view and control panel 5 Safety equipment 6 Prior to the first use 7 First cleaning 7 First heating-up The oven switches 8 Function switch 8 Temperature selector 8 Control indicators 8 The oven cavity 9 Oven accessories 9 9 Oven runners Application of the oven functions 10 Top- and bottom heat 10 Infra-red grill 11 Large surface grill 11 12 Turbo grill Remarks for baking and roasting 12 Oven lighting, bulb exchange 13 **Electronic clock** 14 18 Charts for roasting 19 Charts for baking, Charts for grilling 21 Useful hints on practical problems 22 Useful hints on technical problems 22 Cleaning 23 Oven and accessories 23 Control panel and oven door 23 Heating elements on top 24 Stainless steel surface 24 Guarantee Spare parts service

After sales addresses

Installation instructions

Installation instructions	25
Unpacking and disposal	25
Built-in in kitchen furniture	25
Built-in dimensions	25
Mains connection	26
Technical data, type plate	28

Important hints on safety



Do carefully keep the manual at a safe place and, if need be, pass it on to your successor user.

The appliance is only to be used for its purpose in the household. This appliance is according to international security instructions and quality norms.

The safety measures existing as a matter of selfunderstanding would, however, not cover all of possible risks of accidents.

Electrical safety

The connection to the power supply must exclusively be carried out by expert electricians. Moreover, electrical safety has to be ensured by expert installation in standard built-in cabinets.

Damaged appliances must not be used. Fuselage to be cut off or unscrewed in case of trouble or failure.

For safety reasons repairing, in particular at live parts of the appliance, has to be carried out by expert electricians or trained service technicians only, as potential danger will result for the user. If a fault occurs, please contact our after-sales-service.

Children safety

Always keep small children away. Make sure that playing children do not operate the appliance.

To protect against burns from hot heating elements of the oven the oven door is provided with a catch lock, that can normally be opened by adults, only.

Use and operation

Prior to first use the oven must be heated up once. Take care for a sufficient space ventilation.

In case of careless handling there is **danger of burning** oneself at the heating elements in the oven.

The oven bottom must not be covered with alu-foil. The heat will accumulate and may cause damage to the material.

When taking out the hot items do absolutely make use of pot or thermo-gloves.

The opened oven door must not be burdened too heavily, do not sit or step on it.

When connecting additional electrical appliances to sockets close to the oven make sure the connecting wires do not come into contact with the hot appliance and do not get jammed with the hot oven door.

Besides the accessories supplied with the unit do exclusively make use of suitable and temperature-resistant baking tins and roasting dishes. Do please follow the manufacturers' instructions.

After use make sure that the appliance is switched off. All of the rotary knobs have to be reset into the OFF-position.

Cleaning

No heating element must be switched on during the cleaning procedure. Make sure that the oven has cooled down in a way that one may get in touch with interior parts without any danger.


Always keep the oven clean. When heating up fat splashes and spots will cause inconvenient odours.


The oven door must firmly close. Ensure clean sealing surfaces at door and door frame.


Steam and high-pressure cleaning units are not suitable for cleaning because of the requirements of electrical safety.

The built-in electric oven

Overall view







- 1 Oven function switch
- 2 Illuminated scale discs
- 3 Electronic clock
- 4 Oven temperature selector
- **5** Temperature control lamp

Safety equipment

Oven door locking / Children safety mechanism

By means of an interlocking mechanism for the oven you can prevent playing children from getting access to it.

Activating of door lock

For interlocking of the oven door pull the interlocking tongue out.

Opening and closing of the oven door with activated interlocking mechanism.

To open the door push the tongue upwards, the door can easily be opened. Make use of thermo-gloves or of a pot cloth in case the appliance will be hot.

When closing the door the interlocking tongue will automatically catch in.


Deactivating of door lock

Push the tongue in. Now the oven may always be opened.

Activation (pull out) or deactivation (push in) of the interlocking mechanism are always to be realized with the door open.




In order to avoid any burns do only activate or deactivate the oven door interlocking mechanism with the appliance in cold state.



Oven cooling fan

The appliance is fitted with a cooling fan that will automatically switch on in case of heat beeing developed and, if need be, continue to run after switch-off of the appliance.




Prior to the first use

Daytime setting

When the oven has been connected to the mains and after failure of electricity, the time display of the electronic autotimer flashes 0.00 and AUTO. The present daytime has to be set. Without this, the oven cannot be used. The time display covers the range from 0.01 to 24.00 hours.

- Push buttons 4 and simultaneously and hold it.
- At a time set the present daytime by pushing button \triangle forwards or button ∇ backwards.

To make corrections of time (summer-/winter-time, etc.) simultaneously press the two adjusting buttons and adjust the actual time with ∇ or \triangle .



In order to remove possible production remnants, clean the appliance once prior to first use.


Remove any possibly existing labels and protective foils from the front of the appliance.


Clean control panel and oven door with hot water and a washing-up liquid and dry.

Remove the accessories from the oven and wash them.

The clean-enammelled cavity has to be washedo with warm water and a washing-up liquid. Then dry it.

The oven lighting may be switched on for this purpose by setting the function switch to position \\$.






First heating up



Prior to first use the oven must be heated up once. Take care for a sufficient space ventilation.

Set function switch to top / bottom heat and temperature selector knob to 250 °C.

Holding this setting, operate the empty and closed oven for 60 minutes.




Oven switches

Oven function switch

The function switch can be turned to the left and to the right to the desired position.

The oven illumination ist switched on with position \Box and at a time with all oven functions.




- Oven illumination
- **★** Hot-air
- ▼ Pizza function
- Turbo grill
- Infrared grill
- Infrared large surface grill
- Top heat
- Bottom heat
- Top and bottom heat

Oven temperature selector

The temperature selector knob is switched on by turning to the right from 50 to 275 $^{\rm o}$ C. Do not turn it beyond the maximum setting. For switch-off turn left to 0-setting.

The oven will be heated up after setting of function switch <u>and</u> temperature selector.




Indicators

The function control

The scale discs light up, when the oven is switched on. The illumination goes out, when both switches are in the OFF-position.

The temperature control lamp

shines when the oven heating is on. It goes out, when the set temperature has been reached, and lights up again during reheating phase.





Temperature control lamp

The oven cavity


- A Oven runners, removable
- **B** Separation panel, rear element and fan behind
- C Infrared grill
- **D** Top heat element
- C+DLarge surface grill
- E oven illumination
- type plate



Runner level







Oven accessories




Besides the accessories supplied with the unit do exclusively make use of suitable and temperature-resistant baking tins and roasting dishes. Do please follow the manufacturers' instructions.

The oven has the following accessories:


- 1 drip pan
- 2 baking sheets
- 1 wire shelve
- 1 grease filter for rear element

Further baking sheets and wire shelves can be ordered with our Central Spareparts Service.



Oven runners

The oven has 4 runners. In the charts and illustrations of these instructions they are numbered from 1 = bottom to 4 = top. Please insert baking sheets, wire shelf or grill pan between the double bars: this will hold them in a secure position when inserting them and taking them out.




Application of the oven functions

Top- and bottom heat



Heating elementes installed under the oven bottom and at the oven ceiling respectiveley give off radiant heat to the food. Any temperature between 50 and 275 °C can be set.

Baking and roasting using top and bottom heat is only possible at one level.



Top heat




The radiant heat from the element at the oven ceiling is used for follow-up baking, overbaking and gratinating. 180 °C can be reached at maximum.

Bottom heat



The heating element under the oven bottom gives off radiant heat to the items to be cooked. The function can be set for follow-up baking and incrustation on the sheet. 180 °C can be reached at maximum.




Hot air



The oven is heated by circulating hot air. The fan at the oven back wall intensively moves the hot air in the oven and thus ensures even cooking. Any temperature between 50 and 275 oC can be selected.

Depending on the food you can use up to 3 runner levels.



Grilling



During grill operation the oven always has to be closed. When grilling, do not leave the appliance unsupervised.

Set the function switch to the selected grilling function. Which grilling function is to select depends on the amount and the height of the grill food.

The temperature can be adapted to the particular food, as the oven thermostat holds the temperature within the set range also during grill operations.

For special advices of function selection, temperature setting and runner level please see the grilling charts.



Infrared grill

For small amounts of flat meat as well as for chicken halves, placed in the middle part of the wire shelf. Temperature from 210 to 275 $^{\circ}$ C.



Large surface grill

For flat items to be grilled, half chickens, etc. <u>on the fully charged wire shelf</u>. This function combines the infrared grill with top heat.

Temperature from 210 to 275 °C.

Both surface-grill functions are suitable for flat meat such as steaks, chops, sausages, fish, etc.


As the radiation heat can brown only the surface of the grill food, same has to be turned over after some time.


The large-surface grill functions can, moreover be used:

- for the overbaking of toast,
- for the overflaming of marzipane or icecream
- for the crustation of soufflés.

The grill food has to be inserted on the wire shelf, depending on height, into runner **4** or **5**. The distance toward the grill heating element can be varied by inserting the wire shelf with its convexity either turned upward or downward.

Do not insert flat grill food too close beneath the heating element. Drip pan has to be inserted in runner level 1 or 2.






Turbo grill



For high roasts such as pork loin, leg or poultry it is advisable to select the function turbo grill with temperature settings of about 150 to 190 $^{\rm o}$ C.

The infra-red grill operates along with the fan. In this way, not only the surface of the grill food is browned and grilled, but the grill heat is led intensively to all sides of the grill food.

Insert the drip pan into runner level 1 or 2 and the wire shelf with the grilling food into the runner above.



Remarks for baking and roasting

Roasting with hot-air and top-/bottom heat

The length of roasting time depends on the kind of meat, weight and height of the roast. Basically yourekkon per cm height of meat:

• beef, game 14 - 17 minutes

pork, veal14 - 17 minutes

• fillet, roastbeef 10 - 12 minutes.

The higher the roast is, the lower the temperature needs to be.

The doneness can be checked by pressing the meat down with a spoon. If the roast does not give way, it is done.

After switch-off leave the roast for another 10 minutes in the oven so that no juice will be running out, when you cut the roast.

Roasting on the wire shelf

Place roast on wire shelf with its serving side turned upward. Insert baking sheet **into** runner 1 and the wire shelf directly above it **onto** the runner.

Roasting in the pan

Put lean meat, game or meat loaf directly into the drip pan or in a vessel onto the wire shelf. Put short-roasts on a sheet into the oven.

In case there is need for a roasting time of more than an hour, put the ingredients for the gravy into the pan only half an hour before the end of cooking time, have them browned and fill in a little hot water.

Using runner levels on baking and roasting

Depending on the food with the hot-air function you can use up to 3 runner levels. We recommend:

- 1 baking sheet: runner 2 or 3
- 2 baking sheets: runners 1+3 or 2+4
- 3 baking sheets: runners 1, 3 and 5
- 1-2 high moulds side by side:
 wire shelve in runner 1
- flat mould: baking sheet in runner 2 or 3
- 2flat moulds: wire shelve and/or baking sheets in runners 1 and 3 respectively.

Baking and roasting using top and bottom heat is only possible at one level.

- D flat cakes and biscuits on the baking sheet
 - in runner 1, 2 or 3
- D high cakes, ring or square moulds
 - wire shelve in runner 2 or 3.

Bake- and roastware

Use only the accessories supplied with the unit or dark enamelled baking moulds. do exclusively make use of suitable and temperature-resistant baking tins and roasting dishes.

At baking or roasting with hot-air or pizza function you can use dark and bright baking moulds, baking pottery, heat-resistant moulds and pots. Do exclusively make use of suitable and temperature-resistant baking tins and roasting dishes. Bright sheets and molds do, however, extend the baking and roasting times. Please observe manufacturer's instructions.

At function top-/bottom heat do not use bright and gleaming sheets or moulds.

In the according runner level baking moulds and roasting dishes are put onto the wire shelf. Special hints are given in the baking an roasting charts.

Temperature selection

The hot air function is faster than ordinary functions in supplying the food with heat. Therefore, set the temperature by about 25 °C lower than recommended in reciepes for top and bottom heat.

Hint: The household appliance dealer is offering baking / roasting thermometers for the indication of the state of cooking.

Grease filter

Grease filter to be hooked in with all roasting procedures with hotair and when turbogrilling; filter to be removed when baking as the baking time would otherwise be extended.

Preheating

As the set temperature is reached within a very short time, preheating of the oven before inserting the food is not necessary for most of the baking and roasting operations.

We recommend preheating with:

- D meat dishes and short-roasts, such as fillet, roastbeef, schnitzl or cutlet. The meat pores are quicker closed and the item to be roasted remains juicy.
- **D** fancy biscuits that tend to spread easily,
- D rolls, quiches, Swiss rolls.

For this purpose and before insertion of the items the oven is heated up until the temperature signal lamp goes out.

Baking with hot air and top-/ bottom heat Introduction for using the baking chart

The chart on baking operations contains in most cases temperature ranges, e.g. 160–175 oC. Select the lower temperature for the moment. In case of too high temperatures a cake overcrusts too fast, it will collapse or will not rise properly, because only an insufficient amount of water is extracted.

If the baking operation takes too long or if the cake does not brown enough as expected, you may select a higher setting.

The even browning of the cake can be improved by reducing the baking temperature (by about 10 °C). Then prolonging of the baking time is necessary.

You might also have to change the baking time even if you exactly followed the instructions given in the recipe, as the size of eggs, the binding quality of the flour and the material of which the mould is made can vary.

Oven lighting - bulb exchange



Before opening the oven lamp the oven has to be isolated from the mains. Fuselage to be switched off or removed.

You may replace defect light bulbs yourself.

For the replacement you need bulbs that are heat-resistant up to 300 °C, 25 W / 220-230 V - E 14.


You can buy these bulbs in electronic specialist shops or at the spare parts service.


Round oven lamp on the oven rear:

Unscrew the round protective cover glass, replace the oven lamp and rescrew the protective cover glass.

Rectangular oven lamp in the left oven wall:

Hang out the left oven runner. With a wide screw driver or a suitable knife unclip the protective glass carefully from the support, replace the bulb and press the protective glass into place again.





Electronic clock

Electronic clock functions

- D DaytimeThe adjustment is described on page 7
- D Short-term alarm
- D Switch-off automatism
- D Switch-on/off automatism

The clock is manipulated by 3 program buttons, two setting buttons and the changeover button.

Start-up phase

After pushing of a programming button the next setting may be made within 5 seconds. Afterwards the daytime appears on the display again. By pushing the programming buttons you can at any time check or correct the settings made.

Luminous symbols in the display

Symbol **AUTO** and "refer to set switch-on or switch-on/off automatism programs. After expiration of time goes out and **AUTO** flashes.

The bell symbol $\stackrel{\triangle}{\bullet}$ refers to short-term alarm switched-on.


Audible signal

The end of a duration of cooking or time setting is indicated by a signal tone resounding.

- short-term alarm: double signal tone
- end of cooking time: four-fold signal tone.

The signal tone is repeated for 3 minutes and can be cut off in advance by pushing a program button.





program button short-term alarm program button duration of cooking



program button end of duration of cooking changeover to manual operation



setting buttons for all of the time settings

Symbols in the display

A U T

comes on with automatic programs set, flashes after expiration of time



comes on with short-term alarm settings



comes on with automatic sequences

Switch-off automatism



= terminates the cooking duration set by automatic switch-off of the oven

- Items to be cooked to be put into the oven.
- . Set function and temperature switch
- . Push program button 445
- and set the desired duration of cooking by setting buttons riangle and riangle .

During the sequence of the duration of cooking symbols and **AUTO** are lighting up. You may check in the display the remaining duration of cooking with button and the switch-off time with button

Corrections: push button $\stackrel{\text{ss}}{\rightharpoonup}$ and the duration of cooking set can be varied with setting buttons \triangle and ∇ .

After expiration of the duration of cooking the oven is automatically swithced off. The triple signal tone resaounds, 3% goes out and **AUTO** flashes.

• Press any setting button. The sound signal is switched off, AUTO goes out.

The oven is now ready again for manual cooking operation or for new automatic setting.


As long as symbol ## flashes any further oven settings will remain ineffictive. Then push button ##.


Switch-on/-off automatism



= switches on the oven functions at a later time and automatically ends them after required duration of cooking

- . Items to be cooked to be put into the oven.
- Set function switch and temperature selector.
- . Push program button 🁑
- and set the desired duration of cooking by setting buttons $\underline{\mathbb{A}}$ and $\overline{\nabla}$
- . Then push program button to the button to
- and set the switch-off time (the expected meal-ready-time) with bottoms \triangle and ∇ .





The oven illumination and the function are switched off, symbol AUTO is on from the start to the end of the duration of cooking.

After actuation of button $\stackrel{\text{lift}}{\Box}$ the duration of cooking set and after actuation of button $\stackrel{\text{stop}}{\Box}$ a switch-off time adjusted can be checked in the display and if need varied with setting buttons $\underline{\mathbb{A}}$ and $\overline{\nabla}$.

After expiration of the duration of cooking the oven is automatically swithced off. The signal resounds, symbol if goes out and **AUTO** flashes.

• Press button [⊥], the flashing symbol AUTO and the sound signal goes out.

The oven is now ready again for manual cooking operation or for new automatic setting.

As long as **AUTO** flashes any further oven settings will remain ineffictive. Then push button $\stackrel{\text{dl}}{=}$.



Short-term alarm



The short-term alarm has no switching function for the appliance. It may be used for any sequence of time in a kitchen.


- Push button ↓
 the display shows 0.00 and Symbol ↓
- adjust the time desired with setting buttons $\underline{\mathbb{A}}$ and $\overline{\nabla}$.

The setting range covers 24 hours. The bell symbol lights up in the display.

After expiration the bell symbols goes out, the double signal resounds at the same time.

. The sound signal is at once switched off by pressing any setting button.

A correction of the short-term alarm setting can at any time be made by pressing the program button \bigcap again together with the actuation of the setting buttons ∇ and \triangle .



Roasting

	Hot-air			
Kind of roast	Temperature °C	wire shelve level	drip pan level	roasting time minutes
Roasts				
1 kg pork, per cm of height, well done	160	2	1	14 - 17
smoked pork loin per cm of height, well done	180	2	1	10 - 12
Mince meat	170	2	1	60
Beaf, per cm of height, well done	160	2	1	18
Sirloin, per cm of height	200	2	1	6 - 8 rare 8 - 10 medium
Roastbeef, per cm of height	200	2	1	8 - 10 rare 10 - 12 medium
Roast veal, per cm of height, well done	180	2	1	14 - 17
1 kg Turkey roll, per cm of height	160	2	1	11 - 13
Roast lamb (abbr. 1,8 kg)	180	2	1	90
Chicken	160	2	1	55 - 60
Duck (2 - 2,5 kg)	160	2	1	90 - 120
Goose (ca. 4,5 kg)	160	2	1	150 - 180
Short roasts	on ba	king sheet or drip p 1 abbr. 2 levels	oan in	
Sausages	*230	3		12 - 13
	*230	4 + 2		12 - 13
Schnitzel/Chops, coated	*240	3		13 - 15
	*240	4 + 2		13 - 15
Meat balls	*220	3		15 - 20
	*220	4 + 2		15 - 20
Liver	*250	3		6 - 7
	*250	4 + 2		6 - 7
Fish	on ba	king sheet or drip p	an in 1 level	•
Trouts à 200 - 250 g	200	3		20
4 Trout fillets (à 200 g)	180	3		22
Fish fillets, coated (ca. 1 kg)	200	3		30
Roasting times are approximated	times. * = Prehe	eating since the temp	erature indicator la	amp goes out

Drying up

Hot-air function	×	Temperature °C	level fro for 1	om bottom for 2	sheets for 3	approximated time / = hours
Apples		75			5. 3. 1	6 h 10 min.
Mushrooms		50			5. 3. 1	6 - 8

Baking

	★ Hot-air					o- and ttom heat		
Kind of pastry	tempera-	us	sing level	s	baking time	tempera- ture °C	using level	
	ture °C	1 level	2 levels	3 levels	minutes	ture C	ievei	
Batter in tins or on sheet	Batter in tins or on sheet							
High ring cake	160	1			70-75	175	2	
Frankfurt ring, meddle high	150	2			45-55	170	1	
Plain cake, loaf tin	150-160	3			70-85	160-170	3	
Fruit cake, on sheet	160	3			15-20	*180	3	
Apple cake, round tin	160	2			40-45	*175	2	
Batter with fruit coating	160	3			30-35	*180	3	
Blitzkuchen	160-170	3			20-30	180-190	3	
Honey cake, on sheet	150	3			20-30	*170	3	
Short pastry in tins								
Plain tart base, tin	160	3			15-20			
Tart with curd (750 g curd)					65-75 +10	170	1	
tin 26cm \varnothing					min. after switch-off			
Tart with fruit, on the sheet	170	2			45-60	180	1	
cake with curd, on the sheet					45-55	175	2	
formed cake, on the sheet	170	2			45-55	180	2	
Puff pastry								
Fench apple tart	*170	3			40-45	*190	2	
Sponge mixture								
Sponge cake (DIN)	*160	3			35-40	*170	2	
Fruit flan	*160	3	4+2		25-35	*180	3	
Omelette surprise	*250	2			3-4			
Swiss roll	*180	3			15	*190	2	
Yeast pastry				Į.	•			
High ring cake	160	2			45 - 55	170	1	
Medium high ring cake	160	2			30-35	180	2	
Yeast pastry on sheets:								
with butter /sugar coating	170-180	3	4+2		25-30	180-190	3	
with crumble topping	170-180	3	4+2		40-50	180-190	3	
with almonds (DIN)	170	3			15-20	200	3	
with curd coating					45-50	180	3 3 2	
Fruit loaf (500 g flour)	*150	2			65-70	* 175	2	
Yeast plaited loaf	170-180	3			25-35	*200	2	
Pizza	*220	1			20-30	*250	1	
Small pastries								
Meringues	*80-90	3	4+2		120 - 180	80 - 90	3	
Macaroons	140	3	4+2		21-22	*170	3	
Butter dough (DIN)	140-160	3	4+2	5,3,1	15-35	160-170	3	
Short bread					25-30	180	2	
Sponge mixture	150	3	4+2		15-20	*170	3	
Approximated times may be ch	nanged - Red	commend	ed function	ns and te	mperatures ar	e bold typed		
* = Preheating of oven since	temperature	control la	amp goes	out.				
J 1 1 J 1 J 1 T 1 T 1 T 1 T 1 T 1 T 1 T								

	★ Hot-air					o- and ttom heat	
Kind of pastry	tempera- ture °C	u	sing level	ls	baking time minutes	tempera- ture °C	using level
		1 level	2 levels	3 levels			
Small pastry							
Puff pastries Rolls with curd/caraway or	*180		4 + 2		20	*190	3
poppy seed (aperitif pastries)	*190		4 + 2	5.3.1	12-14	*210	3
Yeast dough pastries	* 170	3	4 + 2		15-20	*190	3
- with apples	160	3	4 + 2		20-25	180	3
Sponge pastries	*160		4 + 2		13	*180	3
- with fruit	160	3	4 + 2		20-30	180	3
Choux pastry							
Cream puff	190	3	4 + 2		30 - 40	*200	3
Strudel and quiches							
Apfelstrudel	160	2			55		
Swiss apple quiche					35	230	2
Quiche Lorraine					35	230	1
Cheese and onion tart					40	230	1
Tart with vegetables					30-40	210-220	1
Bread and rolls							
Rolls with raisins	*190	3	4 + 2		15 - 20	*210	3
Breakfast rolls	*220-230	3	4 + 2		15-20	*240	3
Wholemeal bread	*190	2			45-50	* 210	2
Ryemeal bread	*190	3			45-50	* 210	3
White loaf in tin	*175	2			40-45	*190	1
Flat loaf					20-25	*230	2
Brioche in tin 22 cm Ø	* 160	2			20-25	*190	1
small Brioches on sheet	*160		4 + 2		15-16		
Puddings and gratins							
Pasta au gratin	200	2			40-45		
Potatoes au gratin	200	2			60-65	200	2
Cauliflower with sauce Hollandaise	220	3			20		
Toast "Hawaii"	*250	3			5-8		
Approximated times may be ch	anged - Red	commend	ed functio	ons and te	mperatures ar	e bold typed	
* = Preheating of oven since	temperature	control la	amp goes	out.			

Infraread and large surface grilling

Kind of grilling food for all dishes the oven has to be preheated for 3 minutes	Function	Tempera- ture °C	Drip pan in level	Wire shelve	Mini side 1	utes side 2
4 - 8 pork chops	=	275	1	4	15	10
2 - 4 pork chops	-	275	1	4	12	12
pork medaillons	=	270	1	<u></u>	12	12
fillet steak	-	250	1	_ 5 _	5	4
4 fillet steaks	=	250	1	5	6	5
2 half chickens	-	250	1	_ 4	16	16
4 hals chickens	=	250	1	4	25	18
1 - 4 chicken tights	-	250	1	_ 4 _	15	15
4 - 6 chicken tights	=	250	1	_ 4 _	20	15
Grill sausages, up to 6		250	1	_ 5 _	6	4
Grill sausages, up to 12	=	250	1	_ 5 _	6	4
Frying sausages, up to 4	-	250	1	_ 5 _	10	9
Frying sausages, up to 6	=	250	1	_ 5 _	10	9
Toast without topping	=	250	1	_ 5	1 - 2	1 - 2
for all dishes insert drip pan in level 1						

Turbo-grilling

Kind of dishes	Temperature °C	Wire shelve	Minutes	turn over after minutes
Chicken (900 - 1000 g)	160	2	50	25
		drip pan in level 1		
Pork rolled meat (2 kg)	160	2	90 - 95	45
		drip pan in level 1		
Pasta au gratin	180	2	30	
Potatoes au gratin	200	3	20 - 23	
Gnocchi au gratin	180	3	20 - 23	
Cauliflower wirth sauce Hollandaise	200	3	15	

Useful hints on practical problems

practical problem	possible cause	remedy
Items to be baked or roasted would not really rise	Wrong temperature setting	Check the temperature set with the indications of the chart
Items to be baked or roasted would not become brown	Too low a temperature	Increase the temperature setting, look into the state of cooking, possibly shorten the time
	Wrong material of tins/moulds	With top and bottom heat make use of dark oven tins only.
Items to be baked or roasted would not regularly brown	Irregular height	Reduce the temperature setting, possibly extend the time
Items to be baked or roasted become too dark	Too high a temperature	Check the temperature set with the indications of the chart, reduce the temperature setting, possibly extend the time
Items to be baked or roasted become too dry	Duration of baking too long because of too low a temperature	Check the temperature set with the indications of the chart, possibly increase the temperature setting and shorten the time

Useful hints on technical problems

technical problem	possible cause	remedy
The built-under oven would not function	Trouble with the power supply	Check the fuselage
Oven lighting would not come on	The bulb is defective	Replace the bulb - see page 13



A Damaged appliances must not be used. In case of trouble or failure do please cut off or unscrew the fuselage.

Do not do anything with the oven. Inappropriate work may lead to damages with persons and material.

Not being in a position to cure a trouble or failure with the help of the hints do please contact your after-salesservice or your fitter.

Cleaning of oven, accessories and fascia



No heating element must be switched on during the cleaning procedure. Make sure that the oven has cooled down in a way that one may get in touch with interior parts without any danger. Only the function switch may be switched on for oven lighting.

Steam and high-pressure cleaning units are not suitable for cleaning because of the requirements of electrical safety.



Carefully and regularly clean the appliance in lukewarm or cold state. Avoid repeated burning-on of soiling.

The oven inside is washed with a warm washing-up liquid and a sponge or cloth. Soiling to be watered, if need be. Afterwards wipe out with clear water and dry.


Never use caustic, scouring and scratching cleaners, oven sprays, steel-wool. When nevertheless using oven spray do take into consideration that some means are damaging enamel surfaces.


Wire shelf and grill pan, baking sheets and cake moulds


Oven accessories and shelving parts to be cleaned with a warm washing-up liquid. These items are not suitable for cleaning in a dishwasher.

Grease filter

Wash the stainless steel grease filter after every use with a soft brush in a hot washing-up liquid or quite simply in a dishwasher. Have tenacious soiling soak and react, for instance, in a hot scouring agent solution.







Removal and Installation of the runners

For easier cleaning you may remove the entire shelving parts from the oven inside.

For this purpose grip the oven runners in the middle, draw off towards the oven center and remove from the oven, lift slightly, if need be.


Hang in again: Insert the clevis hook and firmly press down.




For easier cleaning the heating elements under the oven ceiling can be folded down at a slant.

Lay both your thumbs to the left and right on the outside oven frame, then grip with your fingers in the front bends of the heating elements and draw them off their fixture to the front. The heating elements can now be lowered at a slant and you can clean the oven ceiling.

After cleaning move the elements up again, draw in again with fingers and thumbs and catch into the fixture.





Appliances with stainless steel surface




During the cleaning procedure make sure that the stainless steel surface finish (the fine horizontal lines) will not be processed against the structure.

For the stainless steel front side we recommend throughout and regular cleaning and care with suitable stainless steel cleaners and preservative agents.

Please observe manufacturer's instructions. Scratching and scouring agents are not suitable.

Before wiping put the cleaner on a wet cloth and afterwards wash off with water and dry with a clean cloth.



Control panel and oven door



A Do please pay attention to clean sealing surfaces at the door and in the door frame.

The control panel and the oven door have to be cleaned with warm washing-up liquid or glass cleansing agent and to be wiped dry. For cleaning the inside of the oven door use only washing-up water.

Installation instructions



The appliance must exclusively be connected to the mains by an expert electrician.

With the installation and in case of a service failure the appliance has to be isolated from the mains. Fuselage to be switched off or removed.

The general rules for the operation of electric appliances, the provisions by the competent electricity supply board and the specifications of these instructions for installation have to be strictly adhered to.

Unpacking

Please do check whether the appliance was delivered in perfect state. Appliances with obvious transport damages must not be connected to the mains.

Disposal



All packaging parts are recyclable, wooden strips are non-treated, foils and hard foam parts marked. Packaging material and old appliances to be disposed orderly.

Do please adhere to the national and regional prescriptions (material separation, waste collection, residuary product yards).

Installation in kitchen furniture



Electrical safety is to be ensured by professional installation.


> Protection against accidental contact according to the regulations set by VDE or other local authorities must be ensured by correct installation of the appliances. The same refers to the back of the appliance which, even in case of built-in solutions away from the wall, must not be freely accessible.


> Built-in cupboards have to be located and fastened in a way that they are stable.

Built-in dimensions

The opening in the cupboard must correspond to commercial dimensions. The hints required are given in the following dimension sketch.

Built-in cupboards have to be located and fastened in a way that they are stable.





With built-in furniture the plastic coating or the veneer respectively and the glue used must be temperature-resistant up to 95°C.

Unsuitable plastic coating and non-heat-resistant glues are the reason for possible deformation and loosening of the coating. When in doubt check with the manufacturer of the built-in furniture.

With regard to the protection against overheating of surrounding furniture surfaces this appliance corresponds to type Y. This appliance or the built-in cupboard for the appliance respectively may be located with the rear wall and one side wall to whatever high walls or furniture respectively and with the other side to another appliance or furniture of the same height as this appliance.

Mains connection

Prior to connection it should be checked whether the voltage stated on the type plate – i.e. the nominal voltage of the appliance – is identical with the prevailing mains voltage. The type plate ist located on the lower oven frame at the left side and is visible after opening of the oven door.

Oven with cord and plug:

put the plug into a by an expert installed socket.

Connection to the mains terminal:

The mains connection must be carried out by an expert electrician. The VDE-regulations and the valid prescriptions by the local power supply boards have to be complied with.

According to existing mains voltage the appliances are to be connected in correspondence with the following diagram of connections.

The heating element voltage amounts to 230 V . The appliance will also perfectly perform with the former mains voltage of 220 V .


The mains connection must be carried out in a way that an all-pole isolating device is existing with a contact opening of at least 3 mm, e.g. LS-automatism, earth-leakage circuit-breaker or fuse.


A wire of type H05VV-F or of higher rating is to be used as supply cable.

The mains terminal is located at the back of the appliance behind a covering slide.

The protective conductor is to be connected to terminal The bridges of the terminal board are to be changed accordingly, if need be.

The cable connections have to be established as prescribed and the terminal screws be <u>firmly</u> tightened. Afterwards the supply cable has to be secured by strain relief device.






After completion of the mains connection the built-in or -under oven is located in the cupboard and aligned. The screws and plastic sleeves supplied in a bag are to be inserted at the right and left side of the oven frame and the appliance is to be screwed down in the cupboard.



Prior to first use remove any possibly existing labels and protective foils from the front of the appliance.

> After connection to the power supply all heating elements are to be switched on shortly at maximum setting one after another, in order to check the operability.



Technical data: :

A	ما: سم م	
Outer	aımer	ısions

 Width
 592/540 mm

 Height
 594/579 mm

 Depth
 567/547 mm

 Depth with open door
 1010 mm

Oven cavity dimensions

 Width
 422 mm

 Height
 310 mm

 Depth
 440 mm

 Volume
 57,5 l

Connected load:

Top heat1000 WBottom heat1000 WTop and bottom heat2000 WInfra-red grill1900 WLarge surface grill2900 WCavity illumination2x25 W


Type plates

Note down here the data from the type plate of your appliance. Same is to be seen after opening of the oven door on the oven frame in the bottom at the left side

Make always reference to this info:

- when filing a service call
- when ordering spare parts or accessories
- with technical queries

	TYP	MODELL		ProdNr.			Serien-Nr.		<u>r.</u>
l	BEE1 002	EOB 854	W	948 9	00 2	73			
l	☑ Electrolux	TOTAL r	nax.	3,0 kW	- <i>F</i>	AC 23	0 V	50 Hz	_
l	Made in Germany		230 V	OLT		(6	(_



TYP	MODELL	ProdN	lr.	Serien-Nr.
BEE1 002	EON 854 X	948 900	275	
☑ Electrolux	TOTAL max.	3,0 kW -	AC 230	V 50 Hz
Made in Germany	230 Y	VOLT	(€	