

**bryant**

# installation, start-up and service instructions

## SINGLE PACKAGE ROOFTOP ELECTRIC COOLING UNITS

551B

DuraPac Plus Series

Sizes 090-150

7 $\frac{1}{2}$  to 12 $\frac{1}{2}$  Tons

### CONTENTS

	Page
<b>SAFETY CONSIDERATIONS</b>	1
<b>INSTALLATION</b>	1-37
I. Step 1 — Provide Unit Support	1
II. Step 2 — Field Fabricate Ductwork	1
III. Step 3 — Install Condensate Drain Line and External Trap	2
IV. Step 4 — Rig and Place Unit	2
V. Step 5 — Make Electrical Connections	7
VI. Step 6 — Adjust Factory-Installed Options	11
VII. Step 7 — Adjust Evaporator-Fan Speed	21
<b>PRE-START-UP</b>	38
<b>START-UP</b>	38-41
<b>SERVICE</b>	41-45
<b>TROUBLESHOOTING</b>	46-49
<b>INDEX</b>	50
<b>START-UP CHECKLIST</b>	CL-1

### SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Follow all safety codes. Wear safety glasses and work gloves. Use quenching cloth for unbrazing operations. Have fire extinguisher available for all brazing operations.

**CAUTION:** Ensure voltage listed on unit data plate agrees with electrical supply provided for unit.

**WARNING:** Before performing service or maintenance operations on unit, turn off main power switch to unit and install lockout tag. Electrical shock could cause personal injury.

### INSTALLATION

Unit is shipped in the vertical configuration. To convert to horizontal configuration, remove side duct opening covers. Using the same screws, install covers on vertical duct openings with the insulation-side down. Seals around duct openings must be tight. See Fig. 1.

Cancels: II 551B-90-6

II 551B-90-7

10/15/05

### I. STEP 1 — PROVIDE UNIT SUPPORT

#### A. Roof Curb

Assemble and install accessory roof curb in accordance with instructions shipped with curb. Install insulation, cant strips, roofing felt, and counter flashing as shown. *Ductwork must be attached to curb.* If electric or control power is to be routed through the basepan, attach the accessory thru-the-bottom service connections to the basepan in accordance with the accessory installation instructions. Connections must be installed before unit is set on roof curb.

**IMPORTANT:** The gasketing of the unit to the roof curb is critical for a watertight seal. Install gasket supplied with the roof curb as shown in Fig. 2. Improperly applied gasket can also result in air leaks and poor unit performance.

Curb should be level. This is necessary for unit drain to function properly. Unit leveling tolerances are shown in Fig. 3. Refer to Accessory Roof Curb Installation Instructions for additional information as required.

#### B. Slab Mount (Horizontal Units Only)

Provide a level concrete slab that extends a minimum of 6 in. beyond unit cabinet. Install a gravel apron in front of condenser coil air inlet to prevent grass and foliage from obstructing airflow.

**NOTE:** Horizontal units may be installed on a roof curb if required.

#### C. Alternate Unit Support (Curb or Slab Mount)

A non-combustible sleeper rail can be used in the unit curb support area. If sleeper rails cannot be used, support the long sides of the unit with a minimum of 3 equally spaced 4-in. x 4-in. pads on each side.


### II. STEP 2 — FIELD FABRICATE DUCTWORK

On vertical discharge units, secure all ducts to roof curb and building structure. *Do not connect ductwork to unit.* For horizontal applications, field-supplied flanges should be attached to horizontal discharge openings and all ductwork attached to the flanges. Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through an unconditioned space must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

A minimum clearance to combustibles is not required around ductwork on vertical discharge units. On horizontal discharge units, a minimum clearance of 1 in. is required for the first 12 in. of ductwork. Cabinet return-air static pressure (a negative condition) should not exceed 0.30 in. wg with EconoMi\$er IV, or 0.45 in. wg without economizer.



**Fig. 1 — Horizontal Conversion Panels**

### III. STEP 3 — INSTALL CONDENSATE DRAIN LINE AND EXTERNAL TRAP

Condensate drain connections are located at the bottom and end of the unit. Unit discharge connections do not determine the use of drain connections; either drain connection can be used in vertical or horizontal applications.

When using the standard end drain connection, make sure the plug (red) in the alternate bottom connection is tight before installing the unit.

To use the bottom drain connection for a roof curb installation, relocate the factory-installed plug (red) from the bottom connection to the end connection. See Fig. 4. The piping for the condensate drain and external trap can be completed after the unit is in place. The center drain plug looks like a star connection, however it can be removed with a  $\frac{1}{2}$ -in. socket drive extension.

All units must have an external trap for condensate drainage. Install a trap at least 4-in. deep and protect against freeze-up. If drain line is installed downstream from the external trap, pitch the line away from the unit at 1 in. per 10 ft of run. Do not use a pipe size smaller than the unit connection ( $\frac{3}{4}$  in.). See Fig. 5.

### IV. STEP 4 — RIG AND PLACE UNIT

Inspect unit for transportation damage. File any claim with transportation agency. Keep unit upright and do not drop.

Spreader bars are not required if top crating is left on unit. Rollers may be used to move unit across a roof. Level by using unit frame as a reference. See Table 1 and Fig. 6 for additional information. Operating weight is shown in Table 1 and Fig. 6.

Lifting holes are provided in base rails as shown in Fig. 6 and 7. Refer to rigging instructions on unit.

#### A. Positioning

Maintain clearance around and above unit to provide proper airflow and service access. See Fig. 7.

Position unit on roof curb so that the following clearances are maintained:  $\frac{1}{4}$  in. clearance between the roof curb and the base rail inside the front and rear, 0.0 in. clearance between the roof curb and the base rail inside on the duct end of the unit. This will result in the distance between the roof curb and the base rail inside on the condenser end of the unit being approximately equal to Fig. 2, section C-C.

*Do not install unit in an indoor location.* Do not locate unit air inlet near exhaust vents or other sources of contaminated air.

Although unit is weatherproof, guard against water from higher level runoff and overhangs.

After unit is in position, remove polyethylene shipping wrap-  
per and rigging skid.

CONNECTOR PKG. ACCY.	B	C	D ALT DRAIN HOLE	GAS	POWER	CONTROL	ACCESSORY POWER	ROOF CURB ACCESSORY	"A"	UNIT SIZE
CRBTMPWR001A01				$\frac{3}{4}''$ [19] NPT $\frac{11}{4}''$ [31.7]				CRRFCURB003A01	1'-2" [356]	
CRBTMPWR002A01	$2' - 8\frac{7}{16}''$ [827]	$1' - 10\frac{15}{16}''$ [583]	$1\frac{3}{4}''$ [44.5]	$\frac{1}{2}''$ [12.7] NPT	$\frac{3}{4}''$ [19] NPT	$\frac{1}{2}''$ [12.7] NPT		CRRFCURB004A01	2'-0" [610]	551B090-150
CRBTMPWR003A01				$\frac{3}{4}''$ [19] NPT	$1\frac{1}{4}''$ [31.7]					
CRBTMPWR004A01										






Fig. 2 — Roof Curb Details



MAXIMUM ALLOWABLE DIFFERENCE  
(in.)


A-B	B-C	A-C
0.5	1.0	1.0

Fig. 3 — Unit Leveling Tolerances




NOTE: Trap should be deep enough to offset maximum unit static difference. A 4-in. trap is recommended.

Fig. 5 — Condensate Drain Piping Details



NOTE: Drain plug is shown in factory-installed position.

Fig. 4 — Condensate Drain Location



NOTES:

1. Place unit on curb as close as possible to the duct end.
2. Dimension in ( ) is in millimeters.
3. Hook rigging shackles through holes in base rail, as shown in detail "A." Holes in base rails are centered around the unit center of gravity. Use wooden top skid when rigging to prevent rigging straps from damaging unit.
4. Unit weights do not include economizer. See Table 1 for economizer weights.
5. Weights include base unit without the Perfect Humidity™ dehumidification system. See Table 1 for additional unit operating weights with the Perfect Humidity dehumidification system.

551B	OPERATING WEIGHT		A		B		C	
	lb	kg	in.	mm	in.	mm	in.	mm
090	755	343	77.42	1967	41.5	1054	42.12	1070
102	895	406	77.42	1967	41.5	1054	50.12	1273
120	915	415	77.42	1967	41.5	1054	50.12	1273
150	930	422	77.42	1967	41.5	1054	50.12	1273

CAUTION: All panels must be in place when rigging.

Fig. 6 — Rigging Details




Fig. 7 — Base Unit Dimensions

**Table 1 — Physical Data**

UNIT 551B	090	102	120	150
<b>NOMINAL CAPACITY (tons)</b>	7½	8½	10	12½
<b>OPERATING WEIGHT (lb)</b>				
Unit	755	895	915	930
EconoMi\$er IV	75	75	75	75
Perfect Humidity™ Dehumidification Package	44	51	51	51
Roof Curb	143	143	143	143
<b>COMPRESSOR</b>		Scroll		
Quantity	2	2	2	2
Oil (oz) (each compressor)	53	53	50	60
<b>REFRIGERANT TYPE</b>		R-22	Metering Device	
Expansion Device				
Operating Charge (lb-oz)				
Standard Unit				
Circuit 1	7-10	9- 8	9-6	9-8
Circuit 2	8- 2	8-13	10-9	9-5
Unit With Perfect Humidity Dehumidification Package				
Circuit 1	13-0	16-0	16-8	15-3
Circuit 2	13-6	16-8	17-8	16-6
<b>CONDENSER FAN</b>		Propeller Type		
Quantity...Diameter (in.)	2...22	2...22	2...22	2...22
Nominal Cfm	6500	6500	7000	7000
Motor Hp...Rpm	1/4...1100	1/4...1100	1/4...1100	1/4...1100
Watts Input (Total)	650	650	650	650
<b>CONDENSER COIL</b>		High-Efficiency Enhanced Copper Tubes, Lanced Aluminum Fins		
Rows...Fins/in.	2...17	2...17	2...17	2...17
Total Face Area (sq ft)	20.5	25.0	25.0	25.0
<b>EVAPORATOR COIL</b>		High Efficiency Enhanced Copper Tubes, Aluminum Double-Wavy Fins, Face Split		
Standard Unit				
Rows...Fins/in.	3...15	4...15	4...15	4...15
Total Face Area (sq ft)	8.9	11.1	11.1	11.1
Unit with Perfect Humidity Dehumidification Package				
Rows...Fins/in.	2...17	2...17	2...17	2...17
Total Face Area (sq ft)	6.3	8.4	8.4	8.4
<b>EVAPORATOR FAN</b>		Centrifugal Type, Belt Drive		
Size (in.)	15 x 15	15 x 15	15 x 15	15 x 15
Nominal Cfm — Standard	3000	3400	4000	5000
Maximum Continuous Bhp				
Standard	2.90	2.90	3.70	5.25
High Static	4.20	4.20	5.25	—
Motor Frame	56	56	56	56
Fan Rpm Range				
Standard	840-1085	840-1085	860-1080	830-1130
High Static	860-1080	860-1080	830-1130	—
Motor Bearing Type	Ball	Ball	Ball	Ball
Maximum Fan Rpm	2100	2100	2100	2100
Motor Pulley Pitch Diameter A/B (in.)				
Standard	3.4/4.4	3.4/4.4	4.0/5.0	2.8/3.8
High Static	4.0/5.0	4.0/5.0	2.8/3.8	—
Nominal Motor Shaft Diameter (in.)	7/8	7/8	7/8	7/8
Fan Pulley Pitch Diameter (in.)				
Standard	7.0	7.0	8.0	5.8
High Static	8.0	8.0	5.8	—
Belt — Quantity...Type...Length (in.)				
Standard	1...A...48	1...A...51	1...A...51	1...BX...46
High Static	1...A...55	1...A...55	1...BX...46	—
Pulley Center Line Distance (in.)	16.75-19.25	16.75-19.25	15.85-17.50	15.85-17.50
Speed Change per Full Turn of Movable Pulley Flange (rpm)				
Standard	50	50	45	60
High Static	60	60	60	—
Movable Pulley Maximum Full Turns From Closed Position				
Standard	5	5	5	6
High Static	5	5	6	—
Factory Setting — Full Turns Open	5	5	5	5
Factory Speed Setting (rpm)				
Standard	840	840	862	887
High Static	860	860	887	—
Fan Shaft Diameter at Pulley (in.)	1	1	1	1
<b>HIGH-PRESSURE SWITCH (psig)</b>			450 ± 50	
Standard Compressor Internal Relief (Differential)			428	
Cutout			320	
Reset (Auto.)				
<b>LOSS-OF-CHARGE/LOW-PRESSURE SWITCH (Liquid Line) (psig)</b>			7 ± 3	
Cutout			22 ± 5	
Reset (Auto.)				
<b>FREEZE-PROTECTION THERMOSTAT</b>			30 ± 5	
Opens (F)			45 ± 5	
Closes (F)				
<b>OUTDOOR-AIR INLET SCREENS</b>		Cleanable. Screen size and quantity varies by options selected.		
<b>RETURN-AIR FILTERS</b>			Throwaway	
Quantity...Size (in.)	4...16 x 20 x 2	4...16 x 20 x 2	4...20 x 20 x 2	4...20 x 20 x 2

**LEGEND**

Bhp — Brake Horsepower

## V. STEP 5 — MAKE ELECTRICAL CONNECTIONS

**⚠️ WARNING:** Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC (National Electrical Code) ANSI (American National Standards Institute) / NFPA (National Fire Protection Association) 70-latest year and local electrical codes. Failure to follow this warning could result in the installer being liable for personal injury of others.

### A. Field Power Supply

All units except 208/230-v units are factory-wired for the voltage shown on the unit nameplate. If the 208/230-v unit is to be connected to a 208-v power supply, the transformer **must** be rewired by disconnecting the black wire from the 230-v terminal wire on the transformer and connecting it to the 200-v red terminal of the transformer. The end of the orange wire must then be insulated.

Refer to unit label diagram for additional information. Pigtails are provided for field wire connections. Use factory-supplied splices or UL (Underwriters' Laboratories) approved copper/aluminum connector.

When installing units, provide a disconnect per the NEC.


All field wiring must comply with the NEC and local requirements. In Canada, electrical connections must be made in accordance with CSA (Canadian Standards Association) C22.1 Canadian Electrical Code Part One.

Install field wiring as follows:


1. Install conduit through side panel openings. For units without electric heat, install conduit between disconnect and control box.
2. Install power lines to terminal connections as shown in Fig. 8.
3. For units with electric heat, refer to Accessory Installation Instructions.

During operation, voltage to compressor terminals must be within range indicated on unit nameplate (see Table 2). On 3-phase units, voltages between phases must be balanced within 2%, and the current within 10%. Use the formula shown in Table 2, Note 2 on page 10 to determine the percentage of voltage imbalance. Operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components. Such operation would invalidate any applicable Bryant warranty.


See Table 3 for electric heater and single point box usage.



551B090-120, 208/230-3-60  
551B090-150, 460-3-60



551B150, 208/230-3-60



551B090-150, 575-3-60

LEGEND	
C	— Contactor
COMP(S)	— Compressor
IFC	— Indoor (Evaporator) Fan Contactor
NEC	— National Electrical Code
OFC	— Outdoor (Condenser) Fan Contactor
TB	— Terminal Block
⊕	— Terminal Block Connection
---	— Field Wiring
—	— Factory Wiring
—	— Splice Connection (Factory-Supplied)

Fig. 8 — Power Wiring Connections





## LEGEND AND NOTES FOR TABLE 2

### LEGEND

**FLA** — Full Load Amps  
**HACR** — Heating, Air Conditioning and Refrigeration  
**IFM** — Indoor (Evaporator) Fan Motor  
**LRA** — Locked Rotor Amps  
**MCA** — Minimum Circuit Amps  
**MOPC** — Maximum Overcurrent Protection  
**NEC** — National Electrical Code  
**OFM** — Outdoor (Condenser) Fan Motor  
**RLA** — Rated Load Amps



\*Heater capacity (kW) is based on heater voltage of 208, 240, 480, and 575-V. If power distribution voltage varies from rated heater voltage, heater kW will vary accordingly.


†Used to determine minimum disconnect per NEC.

### NOTES:

- In compliance with NEC requirements for multimotor and combination load equipment (refer to NEC Articles 430 and 440), the overcurrent protective device for the unit shall be fuse or HACR breaker.
- Unbalanced 3-Phase Supply Voltage**  
Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percent of voltage imbalance.  
% Voltage Imbalance

$$= 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

Example: Supply voltage is 460-3-60.



$$\begin{aligned} AB &= 452 \text{ v} \\ BC &= 464 \text{ v} \\ AC &= 455 \text{ v} \\ \text{Average Voltage} &= \frac{452 + 464 + 455}{3} \\ &= \frac{1371}{3} \\ &= 457 \end{aligned}$$

Determine maximum deviation from average voltage.

$$(AB) 457 - 452 = 5 \text{ v}$$

$$(BC) 464 - 457 = 7 \text{ v}$$

$$(AC) 457 - 455 = 2 \text{ v}$$

Maximum deviation is 7 v.

Determine percent of voltage imbalance.

$$\begin{aligned} \% \text{ Voltage Imbalance} &= 100 \times \frac{7}{457} \\ &= 1.53\% \end{aligned}$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

**IMPORTANT:** If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

- Non-fused disconnect switch cannot be used when rooftop unit electrical ratings exceed 80 amps.

**Table 3 — Electric Heater Usage**

UNIT 551B	VOLTAGE (60 Hz)	ACCESORY kW	ACCESSORY HEATER PART NUMBER CRHEATER---A00	ACCESSORY SINGLE POINT BOX PART NUMBER CRSINGLE---A00
090	208/230/240 (3 phase)	7.8/ 9.6/10.4 12.0/14.7/16.0 18.6/22.8/24.8 24.0/29.4/32.0 31.8/39.0/42.4	017 010 011 012 012+017	006 006 007 007 009
	460/480 (3 phase)	12.8/13.9 15.2/16.5 25.6/27.8 30.4/33.0 38.4/41.7	016 013 014 015 014+016	006 006 006 006 008
	575 (3 phase)	17.0 34.0	018 019	006 006
102	208/230/240 (3 phase)	7.8/ 9.6/10.4 12.0/14.7/16.0 18.6/22.8/24.8 24.0/29.4/32.0 31.8/39.0/42.4	017 010 011 012 012+017	011 011 012 012 015
	460/480 (3 phase)	12.8/13.9 15.2/16.5 25.6/27.8 30.4/33.0 38.4/41.7	016 013 014 015 014+016	011 011 011 011 014
	575 (3 phase)	17.0 34.0	018 019	011 011
120	208/230/240 (3 phase)	7.8/ 9.6/10.4 12.0/14.7/16.0 24.0/29.4/32.0 31.8/38.9/42.4 37.5/46.0/50.0	017 010 012 012+017 010+012	011 012 012 015 015
	460/480 (3 phase)	12.8/13.9 15.2/16.5 30.4/33.0 38.4/41.7 46.0/50.0	016 013 015 014+016 013+015	011 011 011 014 014
	575 (3 phase)	17.0 34.0 51.0	018+019	011 011 014
150	208/230/240 (3 phase)	7.8/ 9.6/10.4 12.0/14.7/16.0 24.0/29.4/32.0 31.8/38.9/42.4 37.5/46.0/50.0	017 010 012 012+017 010+012	012 012 012 015 015
	460/480 (3 phase)	12.8/13.9 15.2/16.5 30.4/33.0 38.4/41.7 46.0/50.0	016 013 015 014+016 013+015	011 011 011 014 014
	575 (3 phase)	17.0 34.0 51.0	018+019	011 014 014

### NOTES:

- The rated heater voltage is 240, 480, and 575 v. If power distribution voltage varies from rated heater voltage, heater kW vary accordingly.
- To determine heater kW at voltages other than those shown in table, use the following formula:

$$\text{Heater kW new} = \text{Heater kW rated} \times (\text{unit power distribution voltage} / \text{rated heater voltage})^2$$

As an example:

For a 16 kW heater rated at 240 v with a power distribution voltage of 215 v

$$\text{kW new} = 16 \text{ kW} (215/240)^2$$

$$\text{kW new} = 12.8 \text{ kW (rating at 215 v)}$$


## B. Field Control Wiring

Install a Bryant-approved accessory thermostat assembly according to installation instructions included with the accessory. Locate thermostat assembly on a solid wall in the conditioned space to sense average temperature in accordance with thermostat installation instructions.

Route thermostat cable or equivalent single leads of colored wire from subbase terminals to low-voltage connections on unit (shown in Fig. 9) as described in Steps 1 through 4 below.

**NOTE:** For wire runs up to 50 ft, use no. 18 AWG (American Wire Gage) insulated wire (35 C minimum). For 51 to 75 ft, use no. 16 AWG insulated wire (35 C minimum). For over 75 ft, use no. 14 AWG insulated wire (35 C minimum). All wire larger than no. 18 AWG cannot be directly connected to the thermostat and will require a junction box and splice at the thermostat.

1. If mounted on a roof curb and electrical power is to be run through the basepan, an accessory thru-the-bottom connection kit is required. This is available through the local Bryant distributor. This kit is required to ensure a reliable water-tight connection.
2. If unit is mounted on roof curb and accessory thru-the-bottom service connections are used, route wire through connections.
3. Pass control wires through the hole provided on unit (see connection D in Connection Sizes table in Fig. 7).
4. Feed wire through the raceway built into the corner post to the 24-v barrier located on the left side of the control box. See Fig. 9. The raceway provides the UL-required clearance between high-voltage and low-voltage wiring.



**NOTE:** Underlined letter indicates active thermostat output when configured for A/C operation.

Fig. 9 — Low-Voltage Connections

UL required clearance between the high-voltage and low-voltage wiring.

5. Connect thermostat wires to screw terminals of low-voltage connector (see Fig. 9).

**NOTE:** If thru-the-bottom power connections are used refer to the accessory installation instructions for information on power wiring. Refer to Fig. 7 for drilling holes in basepan.

## C. Heat Anticipator Settings

For units with electric heat, set heat anticipator settings as shown in Table 4.

## VI. STEP 6 — ADJUST FACTORY-INSTALLED OPTIONS

### A. Disconnect Switch

The optional disconnect switch is non-fused. The switch has the capability of being locked in place for safety purposes.

### B. Perfect Humidity™ Dehumidification System

Perfect Humidity system operation can be controlled by field installation of a Bryant-approved humidistat (Fig. 11), or light commercial Thermidistat™ device (Fig. 12). To install the humidistat:

1. Route humidistat cable through hole provided in unit corner post.
2. Feed wires through the raceway built into the corner post to the 24-v barrier located on the left side of the control box. See Fig. 10. The raceway provides the UL-required clearance between high-voltage and low-voltage wiring.




Fig. 10 — Field Control Wiring Raceway

Table 4 — Heat Anticipator Settings

UNIT	UNIT VOLTAGE										
	208/230				460				575		
	Heater kW*	Configuration			Heater kW	Configuration			Heater kW	Configuration	
551B		1-Stage	2-Stage			1-Stage	2-Stage			1-Stage	2-Stage
10.4, 16.0	0.3	NA	NA	13.9, 16.5	0.3	NA	NA	17.0, 34.0	0.3	NA	
24.8, 32.0	0.6	0.3	0.3	27.8, 33.0	0.6	0.3	0.3	51.0	0.6	0.3	
	42.4, 50.0	0.9	0.6	0.3	41.7, 50.0						0.3

\*Heater capacity (kW) is based on heater voltage of 208 v, 240 v, 480 v or 575 v. If power distribution voltage to unit varies from rated heater voltage, heater kW will vary accordingly.

3. Use a wire nut to connect humidistat cable into low-voltage wiring as shown in Fig. 13.

To install Thermidistat™ device:

1. Route Thermidistat cable through hole provided in unit corner post.
2. Feed the wires through the raceway built into the corner post to the 24-v barrier located on the left side of the control box. See Fig. 10. The raceway provides the UL-required clearance between high and low voltage wiring.




Fig. 11 — Accessory Field-Installed Humidistat

3. A field-supplied relay must be installed between the Thermidistat device and the Perfect Humidity™ circuit (recommended relay: HN612KK324) Fig. 14. The relay coil is connected between the DEHUM output and C (common) of the unit. The relay controls the Perfect Humidity solenoid valve and must be wired between the Perfect Humidity fuse and the low-pressure switch. Refer to the installation instructions included with the Bryant Light Commercial Thermidistat device for more information.




Fig. 12 — Light Commercial Thermidistat Device




Fig. 13 — Typical Perfect Humidity Dehumidification System Humidistat Wiring (208/230-v Unit Shown)




Fig. 14 — Typical Rooftop Unit with Perfect Humidity Dehumidification System with Thermidistat Device

### C. Convenience Outlet

An optional convenience outlet provides power for rooftop use. For maintenance personnel safety, the convenience outlet power is off when the unit disconnect is off. Adjacent unit outlets may be used for service tools. An optional "Hot Outlet" is available from the factory as a special order item.

### D. Manual Outdoor-Air Damper

The outdoor-air hood and screen are attached to the basepan at the bottom of the unit for shipping.

#### Assembly:

1. Determine quantity of ventilation required for building. Record amount for use in Step 8.
2. Remove filter access panel by raising panel and swinging panel outward. Panel is now disengaged from track and can be removed. No tools are required to remove the filter access panel. Remove outdoor-air opening panel. Save panels and screws. See Fig. 15.
3. Separate hood and screen from basepan by removing the screws and brackets securing them. Save all screws and discard brackets.
4. Replace outdoor air opening panel.
5. Place hood on front of outdoor air opening panel. See Fig. 16 for hood details. Secure top of hood with the 6 screws removed in Step 3. See Fig. 17.
6. Remove and save 8 screws (4 on each side) from sides of the manual outdoor-air damper.
7. Align screw holes on hood with screw holes on side of manual outdoor-air damper. See Fig. 16 and 17. Secure hood with 8 screws from Step 6.
8. Adjust minimum position setting of the damper blade by adjusting the manual outdoor-air adjustment screws on the front of the damper blade. See Fig. 15. Slide blade vertically until it is in the appropriate position determined by Fig. 18. Tighten screws.
9. Remove and save screws currently on sides of hood. Insert screen. Secure screen to hood using the screws. See Fig. 17.
10. Replace filter access panel. Ensure filter access panel slides along the tracks and is securely engaged.

### E. Optional EconoMi\$er IV

See Fig. 19 for EconoMi\$er IV component locations.

**NOTE:** These instructions are for installing the optional EconoMi\$er IV. Refer to the accessory EconoMi\$er IV installation instructions when field installing an EconoMi\$er IV accessory.




Fig. 15 — Damper Panel with Manual Outdoor-Air Damper Installed

1. To remove the existing unit filter access panel, raise the panel and swing the bottom outward. The panel is now disengaged from the track and can be removed. See Fig. 20.




Fig. 16 — Outdoor-Air Hood Details




Fig. 17 — Optional Manual Outdoor-Air Damper with Hood Attached




Fig. 18 — Outdoor Air Damper Position Setting

- The box with the economizer hood components is shipped in the compartment behind the economizer. The EconoMi\$er IV controller is mounted on top of the EconoMi\$er IV in the position shown in Fig. 19. To remove the component box from its shipping position, remove the screw holding the hood box bracket to the top of the economizer. Slide the hood box out of the unit. See Fig. 21.

**IMPORTANT:** If the power exhaust accessory is to be installed on the unit, the hood shipped with the unit will not be used and must be discarded. **Save the aluminum filter for use in the power exhaust hood assembly.**

- The indoor coil access panel will be used as the top of the hood. Remove the screws along the sides and bottom of the indoor coil access panel. See Fig. 22.
- Swing out indoor coil access panel and insert the hood sides under the panel (hood top). Use the screws provided to attach the hood sides to the hood top. Use screws provided to attach the hood sides to the unit. See Fig. 23.
- Remove the shipping tape holding the economizer barometric relief damper in place.
- Insert the hood divider between the hood sides. See Fig. 23 and 24. Secure hood divider with 2 screws on each hood side. The hood divider is also used as the bottom filter rack for the aluminum filter.
- Open the filter clips which are located underneath the hood top. Insert the aluminum filter into the bottom filter rack (hood divider). Push the filter into




Fig. 19 — EconoMi\$er IV Component Locations




Fig. 20 — Typical Access Panel Locations

position past the open filter clips. Close the filter clips to lock the filter into place. See Fig. 24.

- Caulk the ends of the joint between the unit top panel and the hood top. See Fig. 22.
- Replace the filter access panel.
- Install all EconoMi\$er IV accessories. EconoMi\$er IV wiring is shown in Fig. 25.

Barometric flow capacity is shown in Fig. 26. Outdoor air leakage is shown in Fig. 27. Return air pressure drop is shown in Fig. 28.

#### F. EconoMi\$er IV Standard Sensors

##### Outdoor Air Temperature (OAT) Sensor

The outdoor air temperature sensor (HH57AC074) is a 10 to 20 mA device used to measure the outdoor-air temperature. The outdoor-air temperature is used to determine when the EconoMi\$er IV can be used for free cooling. The sensor is factory-installed on the EconoMi\$er IV in the outdoor air-stream. See Fig. 19. The operating range of temperature measurement is 40 to 100 F.

##### Supply Air Temperature (SAT) Sensor

The supply air temperature sensor is a 3 K thermistor located at the inlet of the indoor fan. See Fig. 29. This sensor is factory installed. The operating range of temperature measurement is 0° to 158 F. See Table 5 for sensor temperature/resistance values.




Fig. 21 — Hood Box Removal







Fig. 22 — Indoor Coil Access Panel Relocation



**Fig. 23 — Outdoor-Air Hood Construction**



**Fig. 24 — Filter Installation**



#### LEGEND

**DCV**— Demand Controlled Ventilation  
**IAQ**— Indoor Air Quality  
**LA**— Low Ambient Lockout Device  
**OAT**— Outdoor-Air Temperature  
**POT**— Potentiometer  
**RAT**— Return-Air Temperature

#### Potentiometer Defaults Settings:

Power Exhaust	Middle
Minimum Pos.	Fully Closed
DCV Max.	Middle
DCV Set	Middle
Enthalpy	C Setting

#### NOTES:

1. 620 ohm, 1 watt 5% resistor should be removed only when using differential enthalpy or dry bulb.
2. If a separate field-supplied 24 v transformer is used for the IAQ sensor power supply, it cannot have the secondary of the transformer grounded.
3. For field-installed remote minimum position POT, remove black wire jumper between P and P1 and set control minimum position POT. to the minimum position.

**Fig. 25 — EconoMi\$er IV Wiring**




Fig. 26 — Barometric Relief Flow Capacity




Fig. 27 — Outdoor Air Damper Leakage




Fig. 28 — Return Air Pressure Drop




Fig. 29 — Supply Air Sensor Location

Table 5 — Supply Air Sensor Temperature/Resistance Values

TEMPERATURE (F)	RESISTANCE (ohms)
-58	200,250
-40	100,680
-22	53,010
-4	29,091
14	16,590
32	9,795
50	5,970
68	3,747
77	3,000
86	2,416
104	1,597
122	1,080
140	746
158	525
176	376
185	321
194	274
212	203
230	153
248	116
257	102
266	89
284	70
302	55

The temperature sensor looks like an eyelet terminal with wires running to it. The sensor is located in the "crimp end" and is sealed from moisture.

#### Outdoor Air Lockout Sensor

The EconoMi\$er IV is equipped with an ambient temperature lockout switch located in the outdoor airstream which is used to lock out the compressors below a 42 F ambient temperature. See Fig. 19.

#### G. EconoMi\$er IV Control Modes

Determine the EconoMi\$er IV control mode before set up of the control. Some modes of operation may require different sensors. Refer to Table 6. The EconoMi\$er IV is supplied from the factory with a supply air temperature sensor and an outdoor air temperature sensor. This allows for operation of the EconoMi\$er IV with outdoor air dry bulb changeover control. Additional accessories can be added to allow for different types of changeover control and operation of the EconoMi\$er IV and unit.

Table 6 — EconoMi\$er IV Sensor Usage

APPLICATION	ECONOMISER IV WITH OUTDOOR AIR DRY BULB SENSOR		
	Accessories Required		
Outdoor Air Dry Bulb	None. The outdoor air dry bulb sensor is factory installed.		
Differential Dry Bulb	CRTEMPSON002A00*		
Single Enthalpy	HH57AC078		
Differential Enthalpy	HH57AC078 and CRENTDIF004A00*		
CO <sub>2</sub> for DCV Control using a Wall-Mounted CO <sub>2</sub> Sensor	33ZCSENCO2		
CO <sub>2</sub> for DCV Control using a Duct-Mounted CO <sub>2</sub> Sensor	33ZCSENCO2† and 33ZCASPCO2**	CRCBDIOX005A00††	O

\*CRENTDIF004A00 and CRTEMPSON002A00 accessories are used on many different base units. As such, these kits may contain parts that will not be needed for installation.

†33ZCSENCO2 is an accessory CO<sub>2</sub> sensor.

\*\*33ZCASPCO2 is an accessory aspirator box required for duct-mounted applications.

††CRCBDIOX005A00 is an accessory that contains both 33ZCSENCO2 and 33ZCASPCO2 accessories.

## Outdoor Dry Bulb Changeover

The standard controller is shipped from the factory configured for outdoor dry bulb changeover control. The outdoor air and supply air temperature sensors are included as standard. For this control mode, the outdoor temperature is compared to an adjustable set point selected on the control. If the outdoor-air temperature is above the set point, the EconoMi\$er IV will adjust the outdoor-air dampers to minimum position. If the outdoor-air temperature is below the set point, the position of the outdoor-air dampers will be controlled to provide free cooling using outdoor air. When in this mode, the LED next to the free cooling set point potentiometer will be on. The changeover temperature set point is controlled by the free cooling set point potentiometer located on the control. See Fig. 30. The scale on the potentiometer is A, B, C, and D. See Fig. 31 for the corresponding temperature changeover values.

## Differential Dry Bulb Control

For differential dry bulb control the standard outdoor dry bulb sensor is used in conjunction with an additional accessory dry bulb sensor (part number CRTEMPSN002A00). The accessory sensor must be mounted in the return airstream. See Fig. 32. Wiring is provided in the EconoMi\$er IV wiring harness. See Fig. 25.

In this mode of operation, the outdoor-air temperature is compared to the return-air temperature and the lower temperature airstream is used for cooling. When using this mode of changeover control, turn the enthalpy set point potentiometer fully clockwise to the D setting. See Fig. 30.


## Outdoor Enthalpy Changeover

For enthalpy control, accessory enthalpy sensor (part number HH57AC078) is required. Replace the standard outdoor dry bulb temperature sensor with the accessory enthalpy sensor in the same mounting location. See Fig. 19. When the outdoor air enthalpy rises above the outdoor enthalpy changeover set point, the outdoor-air damper moves to its minimum position. The outdoor enthalpy changeover set point is set with the outdoor enthalpy set point potentiometer on the EconoMi\$er IV controller. The set points are A, B, C, and D. See Fig. 33. The factory-installed 620-ohm jumper must be in place across terminals SR and SR+ on the EconoMi\$er IV controller. See Fig. 19 and 34.


## Differential Enthalpy Control

For differential enthalpy control, the EconoMi\$er IV controller uses two enthalpy sensors (HH57AC078 and CRENTDIF004A00), one in the outside air and one in the return air duct. The EconoMi\$er IV controller compares the outdoor air enthalpy to the return air enthalpy to determine EconoMi\$er IV use. The controller selects the lower enthalpy air (return or outdoor) for cooling. For example, when the outdoor air has a lower enthalpy than the return air, the EconoMi\$er IV opens to bring in outdoor air for free cooling.


Replace the standard outside air dry bulb temperature sensor with the accessory enthalpy sensor in the same mounting location. See Fig. 19. Mount the return air enthalpy sensor in the return air duct. See Fig. 32. Wiring is provided in the EconoMi\$er IV wiring harness. See Fig. 25. The outdoor enthalpy changeover set point is set with the outdoor enthalpy set point potentiometer on the EconoMi\$er IV controller. When using this mode of changeover control, turn the enthalpy set-point potentiometer fully clockwise to the D setting.



**Fig. 30 — EconoMi\$er IV Controller Potentiometer and LED Locations**



**Fig. 31 — Outdoor Air Temperature Changeover Set Points**



**Fig. 32 — Return Air Temperature or Enthalpy Sensor Mounting Location**

### Indoor Air Quality (IAQ) Sensor Input

The IAQ input can be used for demand control ventilation control based on the level of CO<sub>2</sub> measured in the space or return air duct.

Mount the accessory IAQ sensor according to manufacturer specifications. The IAQ sensor should be wired to the AQ and

AQ1 terminals of the controller. Adjust the DCV potentiometers to correspond to the DCV voltage output of the indoor air quality sensor at the user-determined set point. See Fig. 35.

If a separate field-supplied transformer is used to power the IAQ sensor, the sensor must not be grounded or the EconoMi\$er IV control board will be damaged.




Fig. 33 — Enthalpy Changeover Set Points




Fig. 34 — EconoMi\$er IV Control




Fig. 35 — CO<sub>2</sub> Sensor Maximum Range Setting

### Exhaust Set Point Adjustment

The exhaust set point will determine when the exhaust fan runs based on damper position (if accessory power exhaust is installed). The set point is modified with the Exhaust Fan Set Point (EXH SET) potentiometer. See Fig. 30. The set point represents the damper position above which the exhaust fans will be turned on. When there is a call for exhaust, the EconoMi\$er IV controller provides a  $45 \pm 15$  second delay before exhaust fan activation to allow the dampers to open. This delay allows the damper to reach the appropriate position to avoid unnecessary fan overload.

### Minimum Position Control

There is a minimum damper position potentiometer on the EconoMi\$er IV controller. See Fig. 30. The minimum damper position maintains the minimum airflow into the building during the occupied period.

When using demand ventilation, the minimum damper position represents the minimum ventilation position for VOC (volatile organic compound) ventilation requirements. The maximum demand ventilation position is used for fully occupied ventilation.

When demand ventilation control is not being used, the minimum position potentiometer should be used to set the occupied ventilation position. The maximum demand ventilation position should be turned fully clockwise.

Adjust the minimum position potentiometer to allow the minimum amount of outdoor air, as required by local codes, to enter the building. Make minimum position adjustments with at least 10 F temperature difference between the outdoor and return-air temperatures.

To determine the minimum position setting, perform the following procedure:

1. Calculate the appropriate mixed-air temperature using the following formula:

$$(T_O \times \frac{OA}{100}) + (T_R \times \frac{RA}{100}) = T_M$$

$T_O$  = Outdoor-Air Temperature

$OA$  = Percent of Outdoor Air

$T_R$  = Return-Air Temperature

$RA$  = Percent of Return Air

$T_M$  = Mixed-Air Temperature

As an example, if local codes require 10% outdoor air during occupied conditions, outdoor-air temperature is 60 F, and return-air temperature is 75 F.

$$(60 \times .10) + (75 \times .90) = 73.5 F$$

2. Disconnect the supply air sensor from terminals T and T1.
3. Ensure that the factory-installed jumper is in place across terminals P and P1. If remote damper positioning is being used, make sure that the terminals are wired according to Fig. 25 and that the minimum position potentiometer is turned fully clockwise.
4. Connect 24 vac across terminals TR and TR1.
5. Carefully adjust the minimum position potentiometer until the measured mixed-air temperature matches the calculated value.
6. Reconnect the supply-air sensor to terminals T and T1.

Remote control of the EconoMi\$er IV damper is desirable when requiring additional temporary ventilation. If a field-supplied remote potentiometer (Honeywell part number S963B1128) is wired to the EconoMi\$er IV controller, the minimum position of the damper can be controlled from a remote location.

To control the minimum damper position remotely, remove the factory-installed jumper on the P and P1 terminals on the EconoMi\$er IV controller. Wire the field-supplied potentiometer to the P and P1 terminals on the EconoMi\$er IV controller. See Fig. 34.

### Damper Movement

Damper movement from full open to full closed (or vice versa) takes  $2\frac{1}{2}$  minutes.

### Thermostats

The EconoMi\$er IV control works with conventional thermostats that have a Y1 (cool stage 1), Y2 (cool stage 2), W1 (heat stage 1), W2 (heat stage 2), and G (fan). The EconoMi\$er IV control does not support space temperature sensors. Connections are made at the thermostat terminal connection board located in the main control box.

### Occupancy Control

The factory default configuration for the EconoMi\$er IV control is occupied mode. Occupied status is provided by the black jumper from terminal TR to terminal N. When unoccupied mode is desired, install a field-supplied timeclock function in place of the jumper between TR and N. See Fig. 25. When the timeclock contacts are closed, the EconoMi\$er IV control will be in occupied mode. When the timeclock contacts are open (removing the 24-v signal from terminal N), the EconoMi\$er IV will be in unoccupied mode.

### Demand Controlled Ventilation (DCV)

When using the EconoMi\$er IV for demand controlled ventilation, there are some equipment selection criteria which should be considered. When selecting the heat capacity and cool capacity of the equipment, the maximum ventilation rate must be evaluated for design conditions. The maximum damper position must be calculated to provide the desired fresh air.

Typically the maximum ventilation rate will be about 5 to 10% more than the typical cfm required per person, using normal outside air design criteria.

A proportional anticipatory strategy should be taken with the following conditions: a zone with a large area, varied occupancy, and equipment that cannot exceed the required ventilation rate at design conditions. Exceeding the required ventilation rate means the equipment can condition air at a maximum ventilation rate that is greater than the required ventilation rate for maximum occupancy. A proportional-anticipatory strategy will cause the fresh air supplied to increase as the room CO<sub>2</sub> level increases even though the CO<sub>2</sub> set point has not been reached. By the time the CO<sub>2</sub> level reaches the set point, the damper will be at maximum ventilation and should maintain the set point.

In order to have the CO<sub>2</sub> sensor control the economizer damper in this manner, first determine the damper voltage output for minimum or base ventilation. Base ventilation is the ventilation required to remove contaminants during unoccupied periods. The following equation may be used to determine the percent of outside-air entering the building for a given damper position. For best results there should be at least a 10 degree difference in outside and return-air temperatures.

$$(T_O \times \frac{OA}{100}) + (T_R \times \frac{RA}{100}) = T_M$$

$T_O$  = Outdoor-Air Temperature

$OA$  = Percent of Outdoor Air

$T_R$  = Return-Air Temperature

$RA$  = Percent of Return Air

$T_M$  = Mixed-Air Temperature

Once base ventilation has been determined, set the minimum damper position potentiometer to the correct position.

The same equation can be used to determine the occupied or maximum ventilation rate to the building. For example, an output of 3.6 volts to the actuator provides a base ventilation rate of 5% and an output of 6.7 volts provides the maximum ventilation rate of 20% (or base plus 15 cfm per person). Use Fig. 35 to determine the maximum setting of the CO<sub>2</sub> sensor. For example, a 1100 ppm set point relates to a 15 cfm per person design. Use the 1100 ppm curve on Fig. 35 to find the point when the CO<sub>2</sub> sensor output will be 6.7 volts. Line up the point on the graph with the left side of the chart to determine that the range configuration for the CO<sub>2</sub> sensor should be 1800 ppm. The EconoMiSer IV controller will output the 6.7 volts from the CO<sub>2</sub> sensor to the actuator when the CO<sub>2</sub> concentration in the space is at 1100 ppm. The DCV set point may be left at 2 volts since the CO<sub>2</sub> sensor voltage will be ignored by the EconoMiSer IV controller until it rises above the 3.6 volt setting of the minimum position potentiometer.

Once the fully occupied damper position has been determined, set the maximum damper demand control ventilation potentiometer to this position. Do not set to the maximum position as this can result in over-ventilation to the space and potential high-humidity levels.

#### CO<sub>2</sub> Sensor Configuration

The CO<sub>2</sub> sensor has preset standard voltage settings that can be selected anytime after the sensor is powered up. See Table 7.

Use setting 1 or 2 for Bryant equipment. See Table 7.

1. Press Clear and Mode buttons. Hold at least 5 seconds until the sensor enters the Edit mode.
2. Press Mode twice. The STDSET Menu will appear.

3. Use the Up/Down button to select the preset number. See Table 7.

4. Press Enter to lock in the selection.
5. Press Mode to exit and resume normal operation.

The custom settings of the CO<sub>2</sub> sensor can be changed anytime after the sensor is energized. Follow the steps below to change the non-standard settings:

1. Press Clear and Mode buttons. Hold at least 5 seconds until the sensor enters the Edit mode.
2. Press Mode twice. The STDSET Menu will appear.
3. Use the Up/Down button to toggle to the NONSTD menu and press Enter.
4. Use the Up/Down button to toggle through each of the nine variables, starting with Altitude, until the desired setting is reached.
5. Press Mode to move through the variables.
6. Press Enter to lock in the selection, then press Mode to continue to the next variable.

#### Dehumidification of Fresh Air with DCV Control

Information from ASHRAE indicates that the largest humidity load on any zone is the fresh air introduced. For some applications, an energy recovery unit is added to reduce the moisture content of the fresh air being brought into the building when the enthalpy is high. In most cases, the normal heating and cooling processes are more than adequate to remove the humidity loads for most commercial applications.

If normal rooftop heating and cooling operation is not adequate for the outdoor humidity level, an energy recovery unit and/or a dehumidification option should be considered.

**Table 7 — CO<sub>2</sub> Sensor Standard Settings**

SETTING	EQUIPMENT	OUTPUT	VENTILATION RATE (cfm/Person)	ANALOG OUTPUT	CO <sub>2</sub> CONTROL RANGE (ppm)	OPTIONAL RELAY SETPOINT (ppm)	RELAY HYSTERESIS (ppm)
1	Interface w/Standard Building Control System	Proportional	Any	0-10V 4-20 mA	0-2000	1000	50
2		Proportional	Any	2-10V 7-20 mA	0-2000	1000	50
3		Exponential	Any	0-10V 4-20 mA	0-2000	1100	50
4	Economizer	Proportional	15	0-10V 4-20 mA	0-1100	1100	50
5		Proportional	20	0-10V 4-20 mA	0- 900	900	50
6		Exponential	15	0-10V 4-20 mA	0-1100	1100	50
7		Exponential	20	0-10V 4-20 mA	0- 900	900	50
8	Health & Safety	Proportional	—	0-10V 4-20 mA	0-9999	5000	500
9	Parking/Air Intakes/ Loading Docks	Proportional	—	0-10V 4-20 mA	0-2000	700	50

#### **LEGEND**

ppm — Parts Per Million

## VII. STEP 7 — ADJUST EVAPORATOR-FAN SPEED

Adjust evaporator-fan rpm to meet jobsite conditions.

For units with electric heat, required minimum cfm is 2250 for 551B090 and 102 and 3000 for 551B120 and 150. See Table 8 for exceptions.

**Table 8 — Minimum Required Airflow Exceptions**

UNIT 551B	UNIT VOLTAGE	HEATER KW	UNIT CONFIG- URATION	REQUIRED MINIMUM CFM
120,150	208/230	42.4	Horizontal	3200
	208/230	50.0	Horizontal	3200
	460	50.0	Horizontal or Vertical	3200
090-150	575	17.0	Horizontal	2800
		34.0	Vertical	2350

Tables 9 and 10 show fan rpm at motor pulley settings for standard and high-static motors. Tables 11 and 12 show evaporator-fan motor data. See Tables 13 and 14 and Fig. 36 for accessory and option static pressure drops. Refer to Tables 15-28 to determine fan speed settings.

Fan motor pulleys are factory set for speed shown in Table 1.

To change fan speeds:

1. Shut off unit power supply and install lockout tag.
2. Loosen belt by loosening fan motor mounting nuts. See Fig. 37 and 38.
3. Loosen movable pulley flange setscrew (see Fig. 39).
4. Screw movable flange toward fixed flange to increase rpm or away from fixed flange to decrease rpm. Increasing fan rpm increases load on motor. Do not exceed maximum speed specified in Table 1.
5. Set movable flange at nearest keyway of pulley hub and tighten setscrew. (See Table 1 for speed change for each full turn of pulley flange.)

To align fan and motor pulleys:


1. Loosen fan pulley setscrews.

2. Slide fan pulley along fan shaft.


3. Make angular alignment by loosening motor from mounting plate.

To adjust belt tension:


1. Loosen fan motor mounting nuts.
2. *Size 090* — Slide motor mounting plate away from fan scroll for proper belt tension ( $\frac{1}{2}$ -in. deflection with 8 to 10 lb of force) and tighten mounting nuts (see Fig. 37).  
*Sizes 102-150* — Slide motor mounting plate downward to tighten belt tension. Secure motor mounting plate nuts. See Fig. 38. Use  $\frac{1}{2}$ -in. deflection with 10 lb of force.
3. Adjust bolt and nut on mounting plate to secure motor in fixed position.




**Fig. 37 — Typical Belt-Drive Motor Mounting for Size 090**



**Fig. 36 — Perfect Humidity™ Dehumidification System Static Pressure Drop (in. wg)**



**Fig. 38 — Typical Belt-Drive Motor Mounting for Sizes 102-150**



**Fig. 39 — Indoor-Fan Pulley Adjustment**

**Table 9 — Fan Rpm at Motor Pulley Setting\*; Standard Motor/Drive**

UNIT 551B	MOTOR PULLEY TURNS OPEN												
	0	1/2	1	1 1/2	2	2 1/2	3	3 1/2	4	4 1/2	5	5 1/2	6
090,102	1085	1060	1035	1010	985	960	935	910	890	865	840	—	—
120	1080	1060	1035	1015	990	970	950	925	905	880	860	—	—
150	1130	1112	1087	1062	1037	1212	987	962	937	912	887	862	830

\*Approximate fan rpm shown.

**Table 10 — Fan Rpm at Motor Pulley Setting\*; High-Static Motor/Drive**

UNIT 551B	MOTOR PULLEY TURNS OPEN												
	0	1/2	1	1 1/2	2	2 1/2	3	3 1/2	4	4 1/2	5	5 1/2	6
090	1080	1025	1007	988	970	952	933	915	897	878	860	—	—
102	1080	1025	1007	988	970	952	933	915	897	878	860	—	—
120	1130	1112	1087	1062	1037	1212	987	962	937	912	887	862	830

\*Approximate fan rpm shown.

**Table 11 — Evaporator-Fan Motor Data — Standard Motor**

UNIT 551B	UNIT PHASE	MAXIMUM CONTINUOUS BHP*	MAXIMUM OPERATING WATTS*	UNIT VOLTAGE	MAXIMUM AMP DRAW
090,102	Three	2.90	2615	208/230	8.6
				460	3.9
				575	3.9
120	Three	3.70	3775	208/230	12.2
				460	5.5
				575	5.5
150	Three	5.25	4400	208/230	17.3
				460	8.5
				575	8.5

#### LEGEND

**BHP** — Brake Horsepower

\*Extensive motor and electrical testing on these units ensures that the full horsepower and watts range of the motors can be utilized with confidence. Using your fan motors up to the ratings shown in this table will not result in nuisance tripping or premature motor failure. Unit warranty will not be affected.

**Table 12 — Evaporator-Fan Motor Data — High-Static Motors**

UNIT 5551B	UNIT PHASE	MAXIMUM CONTINUOUS BHP*	MAXIMUM OPERATING WATTS*	UNIT VOLTAGE	MAXIMUM AMP DRAW
090,102	Three	4.20	3775	208/230	12.2
				460	5.5
				575	5.5
120	Three	5.25	4400	208/230	17.3
				460	8.5
				575	8.5

**LEGEND**

**BHP** — Brake Horsepower

\*Extensive motor and electrical testing on these units ensures that the full horsepower and watts range of the motors can be utilized with confidence. Using your fan motors up to the ratings shown in this table will not result in nuisance tripping or premature motor failure. Unit warranty will not be affected.

**Table 13 — Accessory/FIOP EconoMi\$er IV Static Pressure\* (in. wg)**

COMPONENT	CFM													
	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	4750	5000	5250	6250
Vertical EconoMi\$er IV	0.06	0.075	0.09	0.115	0.13	0.15	0.17	0.195	0.22	0.25	0.285	0.325	0.36	—
Horizontal EconoMi\$er IV	—	0.1	0.125	0.15	0.18	0.21	0.25	0.275	0.3	0.34	0.388	—	—	—

**LEGEND**

**FIOP** — Factory-Installed Option

\*The static pressure must be added to external static pressure. The sum and the evaporator entering-air cfm should be used in conjunction with the Fan Performance tables to determine indoor blower rpm and watts.

**Table 14 — Accessory/FIOP Electric Heaters Static Pressure (in. wg)**

COMPONENT	CFM								
	2200	2500	3000	3500	4000	4500	5000	5500	6000
1 Heater Module	0.02	0.03	0.05	0.065	0.08	0.10	0.12	0.14	0.155
2 Heater Modules	0.03	0.05	0.07	0.09	0.12	0.14	0.16	0.19	0.21

**LEGEND**

**FIOP** — Factory-Installed Option

\*The static pressure must be added to external static pressure. The sum and the evaporator entering-air cfm should be used in conjunction with the Fan Performance tables to determine indoor blower rpm and watts.

### **GENERAL FAN PERFORMANCE NOTES**

1. Extensive motor and electrical testing on these units ensures that the full range of the motor can be utilized with confidence. Using fan motors up to the ratings shown will not result in nuisance tripping or premature motor failure. Unit warranty will not be affected. For additional information on motor performance refer to Evaporator-Fan Motor Data, Tables 11 and 12.
2. Values include losses for filters, unit casing, and wet coils. See Tables 13 and 14 and Fig. 36 for accessory/FIOP static pressure information.
3. Use of a field-supplied motor may affect wire sizing. Contact Bryant representative to verify.
4. Interpolation is permissible. Do not extrapolate.





























## PRE-START-UP

**⚠ WARNING:** Failure to observe the following warnings could result in serious personal injury:

1. Follow recognized safety practices and wear protective goggles when checking or servicing refrigerant system.
2. Do not operate compressor or provide any electric power to unit unless compressor terminal cover is in place and secured.
3. Do not remove compressor terminal cover until all electrical sources are disconnected and properly tagged.
4. Relieve all pressure from system before touching or disturbing anything inside terminal box if refrigerant leak is suspected around compressor terminals. Use accepted methods to recover refrigerant.
5. Never attempt to repair soldered connection while refrigerant system is under pressure.
6. Do not use torch to remove any component. System contains oil and refrigerant under pressure. To remove a component, wear protective goggles and proceed as follows:
  - a. Shut off electrical power to unit and install lockout tag.
  - b. Relieve all pressure from system using both high and low-pressure ports. Use accepted methods to recover refrigerant.
  - c. Cut component connection tubing with tubing cutter and remove component from unit.
  - d. Carefully unsweat remaining tubing stubs when necessary. Oil can ignite when exposed to torch flame.

Proceed as follows to inspect and prepare the unit for initial start-up:

1. Remove all access panels.
2. Read and follow instructions on all WARNING, CAUTION, and INFORMATION labels attached to or shipped with unit.
3. Make the following inspections:
  - a. Inspect for shipping and handling damages such as broken lines, loose parts, or disconnected wires.
  - b. Inspect for oil at all refrigerant tubing connections and on unit base. Detecting oil generally indicates a refrigerant leak. Leak-test all refrigerant tubing connections using electronic leak detector, halide torch, or liquid-soap solution.
  - c. Inspect all field-wiring and factory-wiring connections. Be sure that connections are completed and tight.
  - d. Inspect coil fins. If damaged during shipping and handling, carefully straighten fins with a fin comb.
4. Verify the following:
  - a. Make sure that condenser-fan blades are correctly positioned in fan orifice. Refer to Condenser-Fan Adjustment section on page 42 for more details.
  - b. Make sure that air filters are in place.
  - c. Make sure that condensate drain trap is filled with water to ensure proper drainage.

- d. Make sure that all tools and miscellaneous loose parts have been removed.
- e. Make sure that the start-up checklist has been performed and filled out.

**NOTE:** Ensure wiring does not contact any refrigerant tubing.

## START-UP

### I. UNIT PREPARATION

Make sure that unit has been installed in accordance with these installation instructions and applicable codes.

### II. RETURN-AIR FILTERS

Make sure correct filters are installed in unit (see Table 1). Do not operate unit without return-air filters.

### III. OUTDOOR-AIR INLET SCREENS

Outdoor-air inlet screens must be in place before operating unit.

### IV. COMPRESSOR MOUNTING

Compressors are internally spring mounted. Do not loosen or remove compressor holddown bolts.

### V. INTERNAL WIRING

Check all electrical connections in unit control boxes; tighten as required.

### VI. REFRIGERANT SERVICE PORTS

Each refrigerant system has 4 Schrader-type service gage ports: one on the suction line, one on the liquid line, and 2 on the compressor discharge line. Be sure that caps on the ports are tight.

### VII. HIGH FLOW VALVES

Two high flow refrigerant valves are located on the compressor hot gas and suction tubes. Large black plastic caps distinguish these valves with o-rings located inside the caps. These valves can not be accessed for service in the field. Ensure the plastic caps are in place and tight or the possibility of refrigerant leakage could occur.

### VIII. COMPRESSOR ROTATION

On 3-phase units, it is important to be certain the scroll compressor is rotating in the proper direction. To determine whether or not compressor is rotating in the proper direction:

1. Connect service gages to suction and discharge pressure fittings.
2. Energize the compressor.
3. The suction pressure should drop and the discharge pressure should rise, as is normal on any start-up.

If the suction pressure does not drop and the discharge pressure does not rise to normal levels:

1. Note that the evaporator fan is probably also rotating in the wrong direction.
2. Turn off power to the unit and install lockout tag.
3. Reverse any two of the unit power leads.
4. Turn on power to the unit.

The suction and discharge pressure levels should now move to their normal start-up levels.

**NOTE:** When the compressor is rotating in the wrong direction, the unit makes an elevated level of noise and does not provide heating or cooling.

**⚠ CAUTION:** Compressor damage will occur if rotation is not immediately corrected.

## **IX. COOLING**

To start unit, turn on main power supply. Set system selector switch at COOL position and fan switch at AUTO position. Adjust thermostat to a setting below room temperature. Compressor starts on closure of contactor.

Check unit charge. Refer to Refrigerant Charge section on page 42.

Reset thermostat at a position above room temperature. Compressor will shut off.

### **To Shut Off Unit**

Set system selector switch at OFF position. Resetting thermostat at a position above room temperature shuts unit off temporarily until space temperature exceeds thermostat setting. Units are equipped with Cycle-LOC™ protection device. Unit shuts down on any safety trip and remains off; an indicator light on the thermostat comes on. Check reason for safety trip.

Compressor restart is accomplished by manual reset at the thermostat by turning the selector switch to OFF position and then ON position.

## **X. HEATING (IF ACCESSORY HEATER IS INSTALLED)**

To start unit, turn on main power supply.

Set thermostat at HEAT position and a setting above room temperature, and set fan at AUTO position.

First stage of thermostat energizes the first-stage electric heater elements; second stage energizes second-stage electric heater elements. Check heating effects at air supply grille(s).

If accessory electric heaters do not energize, reset limit switch (located on evaporator-fan scroll) by pressing button located between terminals on the switch.

### **To Shut Off Unit**

Set system selector switch at OFF position. Resetting heating selector lever below room temperature temporarily shuts unit off until space temperature falls below thermostat setting.

## **XI. SAFETY RELIEF**

A soft solder joint in the suction line at the loss-of-charge/low-pressure switch fitting provides pressure relief under abnormal temperature and pressure conditions.

## **XII. VENTILATION (CONTINUOUS FAN)**

Set fan and system selector switches at ON and OFF positions, respectively. Evaporator fan operates continuously to provide constant air circulation.

## **XIII. OPERATING SEQUENCE**

### **A. Cooling, Units Without EconoMi\$er IV**

When the thermostat calls for cooling, terminals G and Y1 are energized. The indoor (evaporator) fan contactor (IFC), outdoor (condenser) fan contactor (OFC), and compressor contactor no. 1 (C1) are energized and the evaporator-fan motor, compressor no. 1, and condenser fans start. The condenser-fan motors run continuously while unit is in cooling. If the thermostat calls for a second stage of cooling by energizing Y2, compressor contactor no. 2 (C2) is energized and compressor no. 2 starts.

### **B. Heating, Units Without EconoMi\$er IV (If Accessory Heater is Installed)**

Upon a call for heating through terminal W1, IFC and heater contactor no. 1 (HC1) are energized. On units equipped for 2 stages of heat, when additional heat is needed, HC2 is energized through W2.

### **C. Cooling, Units With EconoMi\$er IV**

When free cooling is not available, the compressors will be controlled by the zone thermostat. When free cooling is available, the outdoor-air damper is modulated by the EconoMi\$er IV control to provide a 50 to 55 F supply-air temperature into the zone. As the supply-air temperature fluctuates above 55 or below 50 F, the dampers will be modulated (open or close) to bring the supply-air temperature back within the set point limits.

For EconoMi\$er IV operation, there must be a thermostat call for the fan (G). This will move the damper to its minimum position during the occupied mode.

Above 50 F supply-air temperature, the dampers will modulate from 100% open to the minimum open position. From 50 F to 45 F supply-air temperature, the dampers will maintain at the minimum open position. Below 45 F the dampers will be completely shut. As the supply-air temperature rises, the dampers will come back open to the minimum open position once the supply air temperature rises to 48 F.

If optional power exhaust is installed, as the outdoor-air damper opens and closes, the power exhaust fans will be energized and deenergized.

If field-installed accessory CO<sub>2</sub> sensors are connected to the EconoMi\$er IV control, a demand controlled ventilation strategy will begin to operate. As the CO<sub>2</sub> level in the zone increases above the CO<sub>2</sub> set point, the minimum position of the damper will be increased proportionally. As the CO<sub>2</sub> level decreases because of the increase in fresh air, the outdoor-air damper will be proportionally closed. Damper position will follow the higher demand condition from DCV mode or free cooling mode.

Damper movement from full closed to full open (or vice versa) will take between 1½ and 2½ minutes.

If free cooling can be used as determined from the appropriate changeover command (switch, dry bulb, enthalpy curve, differential dry bulb, or differential enthalpy), a call for cooling (Y1 closes at the thermostat) will cause the control to modulate the dampers open to maintain the supply air temperature set point at 50 to 55 F.

As the supply-air temperature drops below the set point range of 50 to 55 F, the control will modulate the outdoor-air dampers closed to maintain the proper supply-air temperature.

### **D. Heating, Units with EconoMi\$er IV**


Upon a call for heating through terminal W1, IFC and heater contactor no. 1 (HC1) are energized. On units equipped for 2 stages of heat, when additional heat is needed, HC2 is energized through W2. The economizer damper moves to the minimum position. When the thermostat is satisfied, the damper moves to the fully closed position.

### **E. Units With Perfect Humidity™ Dehumidification System**


#### Normal Design Cooling Operation

When the rooftop operates under the normal sequence of operation, the compressors will cycle to maintain indoor conditions. See Fig. 40.

The Perfect Humidity dehumidification system includes a factory-installed Motormaster® low ambient control to keep the head and suction pressure high, allowing normal design cooling mode operation down to 0° F.



**Fig. 40 — Perfect Humidity™ System Normal Design Cooling Operation**



**Fig. 41 — Perfect Humidity System Subcooling Mode Operation**

### Subcooling Mode

When subcooling mode is initiated, this will energize (close) the liquid line solenoid valve (LLSV) forcing the hot liquid refrigerant to enter into the subcooling coil (see Fig. 41).

As the hot liquid refrigerant passes through the subcooling/reheat dehumidification coil, it is exposed to the cold supply airflow coming through the evaporator coil. The liquid is further subcooled to a temperature approaching the evaporator leaving-air temperature. The liquid then enters a thermostatic expansion valve (TXV) where the liquid drops to a lower pressure. The TXV does not have a pressure drop great enough to change the liquid to a 2-phase fluid, so the liquid then enters the Acutrol™ device at the evaporator coil.

The liquid enters the evaporator coil at a temperature lower than in standard cooling operation. This lower temperature increases the latent capacity of the rooftop unit. The refrigerant passes through the evaporator and is turned into a vapor. The air passing over the evaporator coil will become colder than during normal operation. However, as this same air passes over the subcooling coil, it will be slightly warmed, partially reheating the air.

Subcooling mode operates only when the outside-air temperature is warmer than 40 F. A factory-installed temperature switch located in the condenser section will lock out subcooling mode when the outside temperature is cooler than 40 F.

The scroll compressors are equipped with crankcase heaters to provide protection for the compressors due to the additional refrigerant charge required by the subcooling/reheat coil.

When in subcooling mode, there is a slight decrease in system total gross capacity (5% less), a lower gross sensible capacity (20% less), and a greatly increased latent capacity (up to 40% more).

### Hot Gas Reheat Mode

When the humidity levels in the space require humidity control, a hot gas solenoid valve (specific to hot gas reheat mode only) will open to bypass a portion of hot gas refrigerant around the condenser coil (see Fig. 42).

This hot gas will mix with liquid refrigerant leaving the condenser coil and flow to the subcooling/reheat dehumidification coil. Now the conditioned air coming off the evaporator


will be cooled and dehumidified, but will be warmed to neutral conditions (72 F to 75 F) by the subcooling/reheat dehumidification coil.

**NOTE:** The 551B090-150 rooftop units can operate one circuit in subcooling mode and one circuit in hot gas reheat mode or both circuits in hot gas reheat mode, or both in normal design cooling mode.

The net effect of the rooftop when in hot gas reheat mode is to provide nearly all latent capacity removal from the space when sensible loads diminish (when outdoor temperature conditions are moderate). When in hot gas reheat mode, the unit will operate to provide mostly latent capacity and extremely low sensible heat ratio capability.

Similar to the subcooling mode of operation, hot gas reheat mode operates only when the outside air temperature is warmer than 40 F. Below this temperature, a factory-installed outside air temperature switch will lock out this mode of operation.

See Table 29 for the Perfect Humidity dehumidification system sequence of operation.



**Fig. 42 — Perfect Humidity System Hot Gas Reheat Mode Operation**

**Table 29 — Perfect Humidity™ Dehumidification System Sequence of Operation and System Response — Dual Compressor Units**

THERMOSTAT INPUT			ECONOMIZER FUNCTION		551B UNIT OPERATION							
H	Y1	Y2	OAT < Economizer Set Point	Economizer	First Stage			Second Stage				
					Compressor 1	Subcooling Mode	Hot Gas Reheat Mode	Compressor 2	Subcooling Mode	Hot Gas Reheat Mode		
Off	—	—	Unit Operates Under Normal Sequence of Operation									
On	On	On	No	Off	On	Yes	No	On	Yes	No		
On	On	Off	No	Off	On	Yes	No	On	No	Yes		
On	On	On	Yes	On	On	Yes	No	On	No	Yes		
On	On	Off	Yes	On	On	No	Yes	On	No	Yes		
On	Off	Off	No	Off	On	No	Yes	On	No	Yes		

#### LEGEND

OAT — Outdoor Air Temperature

**NOTE:** On a thermostat call for W1, all cooling and dehumidification will be off.

#### F. Units With Power Exhaust

When the outdoor-air damper is modulated open, the two end switches located in the actuator are tripped. The factory settings are: switch no. 1 will close at 30% outdoor air; switch no. 2 will close at 70% outdoor-air. Both switches are field adjustable. As the outdoor-air damper opens, switch no. 1 closes, energizing a double-pole relay that starts fan no. 1. As the outdoor-air damper continues to open, switch no. 2 will close, energizing a double-pole relay that starts fan no. 2. When the outdoor-air damper closes to a point below the fan start points (30% fan no. 1, 70% fan no. 2), the respective fan will be deenergized.

#### SERVICE

**CAUTION:** When servicing unit, shut off all electrical power to unit to avoid shock hazard or injury from rotating parts.

#### I. CLEANING

Inspect unit interior at the beginning of each heating and cooling season or as operating conditions require.

##### A. Evaporator Coil

- Turn unit power off and install lockout tag. Remove evaporator coil access panel.
- If EconoMi\$er IV or accessory two-position damper is installed, remove economizer or two-position damper by disconnecting EconoMi\$er IV plug and removing mounting screws.
- Slide filters out of unit.
- Clean coil using a commercial coil cleaner or dishwasher detergent in a pressurized spray canister. Wash both sides of coil and flush with clean water. For best results, back-flush toward return-air section to remove foreign material.
- Flush condensate pan after completion.
- Reinstall economizer or two-position damper and filters.
- Reconnect wiring.
- Replace access panels.


##### B. Condenser Coils

Inspect coils monthly. Clean condenser coils annually, and as required by location and outdoor-air conditions.


Clean 2-row coils as follows:

- Turn off unit power and install lockout tag.
- Remove top panel screws on condenser end of unit.


- Remove condenser coil corner post. See Fig. 43. To hold top panel open, place coil corner post between top panel and center post. See Fig. 44.
- Remove device holding coil sections together at return end of condenser coil. Carefully separate the outer coil section 3 to 4 in. from the inner coil section. See Fig. 45.
- Use a water hose or other suitable equipment to flush down between the 2 coil sections to remove dirt and debris. Clean the outer surfaces with a stiff brush in the normal manner.
- Secure the sections together. Reposition the coil sections, and remove the coil corner post from between the top panel and center post. Install the coil corner post and coil center post, and replace all screws.



**Fig. 43 — Cleaning Condenser Coil**



**Fig. 44 — Propping Up Top Panel**



**Fig. 45 — Separating Coil Sections**

#### C. Condensate Drain

Check and clean each year at start of cooling season. In winter, protect against freeze-up.

#### D. Filters

Clean or replace at start of each heating and cooling season, or more often if operating conditions require it. Replacement filters must be same dimensions as original filters.

#### E. Outdoor-Air Inlet Screen

Clean screen with steam or hot water and a mild detergent. Do not use throwaway filters in place of screens.

### II. LUBRICATION

#### A. Compressors


Each compressor is charged with correct amount of oil from the factory.

#### B. Fan Motor Bearings

*Fan motor bearings are permanently lubricated.* No further lubrication of condenser-fan or evaporator-fan motors is required.

### III. CONDENSER-FAN ADJUSTMENT (FIG. 46)

1. Shut off unit power supply and install lockout tag.
2. Remove condenser-fan assembly (grille, motor, motor cover, and fan) and loosen fan hub setscrews.
3. Adjust fan height as shown in Fig. 46.
4. Tighten setscrews and replace condenser-fan assembly.



UNIT VOLTAGE	FAN HEIGHT "A" (in.)
208/230 v	2.75
460 v and 575 v	3.50

**Fig. 46 — Condenser-Fan Adjustment**

### IV. BELT/PULLEY ADJUSTMENT

Inspect once each season or sooner if conditions warrant, verifying that belt tension and pulley alignment are correct. Replace belt if required.

### V. ECONOMi\$ER IV ADJUSTMENT

Refer to Optional EconoMi\$er IV section on page 13.

### VI. REFRIGERANT CHARGE

Amount of refrigerant charge is listed on unit nameplate (also refer to Table 1). Refer to Bryant Standard Service Techniques Manual, Chapter 1, Refrigerants section.

Unit panels must be in place when unit is operating during charging procedure.

#### A. No Charge

Locate and repair any refrigerant leak. Use standard evacuating techniques. After evacuating system, weigh in the specified amount of refrigerant (refer to Table 1).

#### B. Low Charge Cooling

Use Cooling Charging Charts, Fig. 47-50. Vary refrigerant until the conditions of the appropriate chart are met. Note that charging charts are different from the type normally used. Charts are based on charging the units to the correct superheat for the various operating conditions. Accurate pressure gage and temperature sensing device are required. Connect the pressure gage to the service port on the suction line. Mount the temperature sensing device on the suction line and insulate it so that outdoor ambient temperature does not affect the reading. Indoor-air cfm must be within the normal operating range of the unit.

#### C. Perfect Humidity™ System Charging

The system charge for units with the Perfect Humidity option is greater than that of the standard unit alone. The charge for units with this option is indicated on the unit nameplate drawing. Also refer to Fig. 51-53. To charge systems using the Perfect Humidity dehumidification system, fully evacuate, recover and recharge the system to the nameplate specified charge level.

To check or adjust refrigerant charge on systems using the Perfect Humidity Dehumidification system, charge per Fig. 51-53.

**NOTE:** When using the charging charts, it is important that only the subcooling/reheat dehumidification coil liquid line solenoid valve be energized. The subcooling/reheat dehumidification coil liquid line solenoid valve MUST be energized to use the charging charts and the outdoor motor speed controller jumpered to run the fan at full speed.

The charts reference a liquid pressure (psig) and temperature at a point between the condenser coil and the subcooling/reheat dehumidification coil. A tap is provided on the unit to measure liquid pressure entering the subcooling/reheat dehumidification coil.

**IMPORTANT:** The subcooling mode charging charts (Fig. 51-53) are to be used ONLY with units having the optional Perfect Humidity dehumidification system. DO NOT use standard charts (Fig. 47-50) for units with Perfect Humidity option, and DO NOT use Fig. 51-53 for standard units.

#### D. To Use Cooling Charging Charts, Standard Units

Take the outdoor ambient temperature and read the suction pressure gage. Refer to appropriate chart to determine what the suction temperature should be. If suction temperature is high, add refrigerant. If suction temperature is low, carefully recover some of the charge. Recheck the suction pressure as charge is adjusted.

**EXAMPLE (Fig. 47):**

Circuit 1

Outdoor Temperature .....	85 F
Suction Pressure .....	70 psig
Suction Temperature should be .....	46 F
(Suction Temperature may vary $\pm 5^{\circ}$ F.)	




Fig. 47 — Cooling Charging Charts, Standard 551B090 Unit




Fig. 48 — Cooling Charging Charts, Standard 551B102 Unit




Fig. 49 — Cooling Charging Charts, Standard 551B120 Unit




Fig. 50 — Cooling Charging Charts, Standard 551B150 Unit

## E. To Use Cooling Charging Charts, Units the Perfect Humidity™ Dehumidification System

Refer to the charts (Fig. 51-53) to determine the proper leaving condenser pressure and temperature.

**EXAMPLE:** (Fig. 51)


Circuit 1

Leaving Condenser Pressure ..... 300 psig  
Leaving Condenser Temperature ..... 117 F

**NOTE:** When using the charging charts, it is important that only the subcooling/reheat dehumidification coil liquid line solenoid valve be energized. The subcooling/reheat dehumidification coil liquid line solenoid valve MUST be energized to use the charging charts and the outdoor motor speed controller jumpered to run the fan at full speed.


## VII. REPLACEMENT PARTS

A complete list of replacement parts may be obtained from any Bryant distributor upon request.




**NOTE:** When using the charging charts, it is important that only the subcooling/reheat dehumidification coil liquid line solenoid valve be energized. The subcooling/reheat dehumidification coil liquid line solenoid valve MUST be energized to use the charging charts and the outdoor motor speed controller jumpered to run the fan at full speed.

**Fig. 51 — Cooling Charging Chart, 581B090 With the Perfect Humidity Dehumidification System**



**NOTE:** When using the charging charts, it is important that only the subcooling/reheat dehumidification coil liquid line solenoid valve be energized. The subcooling/reheat dehumidification coil liquid line solenoid valve MUST be energized to use the charging charts and the outdoor motor speed controller jumpered to run the fan at full speed.

**Fig. 52 — Cooling Charging Chart, 581B102 and 120 With the Perfect Humidity Dehumidification System**



**NOTE:** When using the charging charts, it is important that only the subcooling/reheat dehumidification coil liquid line solenoid valve be energized. The subcooling/reheat dehumidification coil liquid line solenoid valve MUST be energized to use the charging charts and the outdoor motor speed controller jumpered to run the fan at full speed.

**Fig. 53 — Cooling Charging Chart, 581B150 With the Perfect Humidity Dehumidification System**

## TROUBLESHOOTING

### I. UNIT TROUBLESHOOTING

Refer to Tables 30-32 for additional information.

**Table 30 — Cooling Troubleshooting**

PROBLEM	CAUSE	REMEDY
<b>Compressor(s) and Condenser Fan Will Not Start.</b>	Power failure.	Call power company.
	Fuse blown or circuit breaker tripped.	Replace fuse or reset circuit breaker.
	Defective thermostat, contactor, transformer, control relay.	Replace component.
	Insufficient line voltage.	Determine cause and correct.
	Incorrect or faulty wiring.	Check wiring diagram and rewire correctly.
	Thermostat setting too high.	Lower thermostat setting below room temperature.
	High pressure switch tripped.	See problem "Excessive Head Pressure."
	Low pressure switch tripped.	Check system for leaks, repair, and recharge.
	Freeze-up protection thermostat tripped.	See problem "Suction Pressure Too Low."
<b>Compressor(s) Will Not Start but Condenser Fan Runs.</b>	Faulty wiring or loose connections in compressor circuit.	Check wiring and repair or replace.
	Compressor motor(s) burned out, seized, or internal overload open.	Determine cause. Replace compressor(s).
	Defective overload.	Determine cause and replace.
	One leg of 3-phase power dead.	Replace fuse or reset circuit breaker. Determine cause.
<b>Compressor(s) Cycles (Other Than Normally Satisfying Thermostat).</b>	Refrigerant overcharge or undercharge.	Recover refrigerant, evacuate system, and recharge to nameplate.
	Defective compressor.	Replace and determine cause.
	Insufficient line voltage.	Determine cause and correct.
	Blocked condenser.	Determine cause and correct.
	Defective overload.	Determine cause and replace.
	Defective thermostat.	Replace thermostat.
	Faulty condenser-fan motor(s) or capacitor.	Replace.
<b>Compressor(s) Operates Continuously.</b>	Restriction in refrigerant system.	Locate restriction and remove.
	Dirty air filter.	Replace filter.
	Unit undersized for load.	Decrease load or increase unit size.
	Thermostat set too low.	Reset thermostat.
	Low refrigerant charge.	Locate leak, repair, and recharge.
	Leaking valves in compressor.	Replace compressor.
	Air in system.	Recover refrigerant, evacuate system, and recharge.
<b>Scroll Compressor(s) Makes Excessive Noise.</b>	Condenser coil dirty or restricted.	Clean coil or remove restriction.
	Compressor(s) rotating in the wrong direction.	Reverse the 3-phase power leads as described in Start-Up section, page 38.
<b>Excessive Head Pressure.</b>	Dirty air filter.	Replace filter.
	Dirty condenser coil.	Clean coil.
	Refrigerant overcharged.	Remove excess refrigerant.
	Air in system.	Recover refrigerant, evacuate system to 500 microns, and recharge.
	Condenser air restricted or air short-cycling.	Determine cause and correct.
<b>Head Pressure Too Low.</b>	Low refrigerant charge.	Check for leaks, repair, and recharge.
	Compressor valves leaking.	Replace compressor(s).
	Restriction in liquid tube.	Remove restriction.
<b>Excessive Suction Pressure.</b>	High heat load.	Check for source and eliminate.
	Compressor valves leaking.	Replace compressor(s).
	Refrigerant overcharged.	Recover excess refrigerant.
<b>Suction Pressure Too Low.</b>	Dirty air filter.	Replace filter.
	Low refrigerant charge.	Check for leaks, repair, and recharge.
	Metering device or low side restricted.	Remove source of restriction.
	Insufficient evaporator airflow.	Increase air quantity. Check filter and replace if necessary.
	Temperature too low in conditioned area.	Reset thermostat.
	Field-installed filter drier restricted.	Replace.
	Outdoor ambient temperature below 25 F.	Install low-ambient kit.
<b>Compressor No. 2 Will Not Run.</b>	Unit in economizer mode.	Proper operation; no remedy necessary.

**Table 31 — Perfect Humidity™ Dehumidification System Subcooling Mode Service Analysis**

PROBLEM	CAUSE	REMEDY
<b>Subcooling Mode (Liquid Reheat) Will Not Energize.</b>	No power to control transformer from evaporator-fan motor.	Check power source and evaporator-fan relay. Ensure all wire connections are tight.
	No power from control transformer to liquid line solenoid valve.	1. Fuse open; check fuse. Ensure continuity of wiring. 2. Low-pressure switch open. Cycle unit off and allow low-pressure switch to reset. Replace switch if it will not close. 3. Transformer bad; check transformer.
	Liquid line solenoid valve will not operate.	1. Solenoid coil defective; replace. 2. Solenoid valve stuck open; replace.
	Liquid line solenoid valve will not open.	Valve is stuck closed; replace valve.
<b>Low System Capacity.</b>	Low refrigerant charge or frosted evaporator coil.	1. Check charge amount. Charge per Fig. 51-53. 2. Evaporator coil frosted; check and replace low-pressure switch if necessary.
<b>Loss of Compressor Superheat Conditions with Subcooling/Reheat Dehumidification Coil Energized.</b>	Thermostatic expansion valve (TXV).	1. Check TXV bulb mounting, and secure tightly to suction line. 2. Replace TXV if stuck open or closed.

**Table 32 — Perfect Humidity Dehumidification Hot Gas Reheat Mode Service Analysis**

PROBLEM	CAUSE	REMEDY
<b>Reheat Mode Will Not Energize.</b>	No power to control transformer from evaporator-fan motor.	Check power source and evaporator-fan relay. Ensure all wire connections are tight.
	No power from control transformer to hot gas line solenoid valve.	1. Fuse open; check fuse. Ensure continuity of wiring. 2. Low-pressure switch open. Cycle unit off and allow low-pressure switch to reset. Replace switch if it will not close. 3. Transformer bad; check transformer.
	Hot gas line solenoid valve will not operate.	1. Solenoid coil defective; replace. 2. Solenoid valve stuck closed; replace.
	Low refrigerant charge or frosted evaporator coil.	1. Check charge amount. Charge per Fig. 51-53. 2. Evaporator coil frosted; check and replace low-pressure switch if necessary.
<b>Loss of Compressor Superheat Conditions with Subcooling/Reheat Dehumidification Coil Energized.</b>	Thermostatic expansion valve (TXV).	1. Check TXV bulb mounting, and secure tightly to suction line. 2. Replace TXV if stuck open or closed.
<b>Excessive Superheat.</b>	Liquid line solenoid valve will not operate.	Valve is stuck; replace valve.
	Hot gas line solenoid valve will not close.	Valve is stuck; replace valve.

## II. ECONOMISER IV TROUBLESHOOTING

See Table 33 for EconoMi\$er IV logic.

A functional view of the EconoMi\$er IV is shown in Fig. 54. Typical settings, sensor ranges, and jumper positions are also shown. An EconoMi\$er IV simulator program is available from Bryant to help with EconoMi\$er IV training and troubleshooting.

### A. EconoMi\$er IV Preparation

This procedure is used to prepare the EconoMi\$er IV for troubleshooting. No troubleshooting or testing is done by performing the following procedure.

**NOTE:** This procedure requires a 9-v battery, 1.2 kilo-ohm resistor, and a 5.6 kilo-ohm resistor which are not supplied with the EconoMi\$er IV.

**IMPORTANT:** Be sure to record the positions of all potentiometers before starting troubleshooting.

1. Disconnect power at TR and TR1. All LEDs should be off. Exhaust fan contacts should be open.
2. Disconnect device at P and P1.
3. Jumper P to P1.
4. Disconnect wires at T and T1. Place 5.6 kilo-ohm resistor across T and T1.
5. Jumper TR to 1.
6. Jumper TR to N.
7. If connected, remove sensor from terminals S<sub>O</sub> and +. Connect 1.2 kilo-ohm 4074EJM checkout resistor across terminals S<sub>O</sub> and +.
8. Put 620-ohm resistor across terminals S<sub>R</sub> and +.
9. Set minimum position, DCV set point, and exhaust potentiometers fully CCW (counterclockwise).
10. Set DCV maximum position potentiometer fully CW (clockwise).
11. Set enthalpy potentiometer to D.
12. Apply power (24 vac) to terminals TR and TR1.

### B. Differential Enthalpy

To check differential enthalpy:

1. Make sure EconoMi\$er IV preparation procedure has been performed.
2. Place 620-ohm resistor across S<sub>O</sub> and +.
3. Place 1.2 kilo-ohm resistor across S<sub>R</sub> and +. The Free Cool LED should be lit.
4. Remove 620-ohm resistor across S<sub>O</sub> and +. The Free Cool LED should turn off.
5. Return EconoMi\$er IV settings and wiring to normal after completing troubleshooting.

### C. Single Enthalpy

To check single enthalpy:

1. Make sure EconoMi\$er IV preparation procedure has been performed.
2. Set the enthalpy potentiometer to A (fully CCW). The Free Cool LED should be lit.
3. Set the enthalpy potentiometer to D (fully CW). The Free Cool LED should turn off.
4. Return EconoMi\$er IV settings and wiring to normal after completing troubleshooting.

### D. DCV (Demand Controlled Ventilation) and Power Exhaust

To check DCV and Power Exhaust:

1. Make sure EconoMi\$er IV preparation procedure has been performed.
2. Ensure terminals AQ and AQ1 are open. The LED for both DCV and Exhaust should be off. The actuator should be fully closed.
3. Connect a 9-v battery to AQ (positive node) and AQ1 (negative node). The LED for both DCV and Exhaust should turn on. The actuator should drive to between 90 and 95% open.
4. Turn the Exhaust potentiometer CW until the Exhaust LED turns off. The LED should turn off when the potentiometer is approximately 90%. The actuator should remain in position.
5. Turn the DCV set point potentiometer CW until the DCV LED turns off. The DCV LED should turn off when the potentiometer is approximately 9 v. The actuator should drive fully closed.
6. Turn the DCV and Exhaust potentiometers CCW until the Exhaust LED turns on. The exhaust contacts will close 30 to 120 seconds after the Exhaust LED turns on.
7. Return EconoMi\$er IV settings and wiring to normal after completing troubleshooting.

### E. DCV Minimum and Maximum Position

To check the DCV minimum and maximum position:

1. Make sure EconoMi\$er IV preparation procedure has been performed.
2. Connect a 9-v battery to AQ (positive node) and AQ1 (negative node). The DCV LED should turn on. The actuator should drive to between 90 and 95% open.
3. Turn the DCV Maximum Position potentiometer to midpoint. The actuator should drive to between 20 and 80% open.
4. Turn the DCV Maximum Position potentiometer to fully CCW. The actuator should drive fully closed.
5. Turn the Minimum Position potentiometer to midpoint. The actuator should drive to between 20 and 80% open.
6. Turn the Minimum Position Potentiometer fully CW. The actuator should drive fully open.
7. Remove the jumper from TR and N. The actuator should drive fully closed.
8. Return EconoMi\$er IV settings and wiring to normal after completing troubleshooting.

### F. Supply-Air Input

To check supply-air input:

1. Make sure EconoMi\$er IV preparation procedure has been performed.
2. Set the Enthalpy potentiometer to A. The Free Cool LED turns on. The actuator should drive to between 20 and 80% open.
3. Remove the 5.6 kilo-ohm resistor and jumper T to T1. The actuator should drive fully open.

- Remove the jumper across T and T1. The actuator should drive fully closed.
- Return EconoMi\$er IV settings and wiring to normal after completing troubleshooting.

#### G. EconoMi\$er IV Troubleshooting Completion

This procedure is used to return the EconoMi\$er IV to operation. No troubleshooting or testing is done by performing the following procedure.

- Disconnect power at TR and TR1.
- Set enthalpy potentiometer to previous setting.
- Set DCV maximum position potentiometer to previous setting.

- Set minimum position, DCV set point, and exhaust potentiometers to previous settings.
- Remove 620-ohm resistor from terminals S<sub>R</sub> and +.
- Remove 1.2 kilo-ohm checkout resistor from terminals S<sub>O</sub> and +. If used, reconnect sensor from terminals S<sub>O</sub> and +.
- Remove jumper from TR to N.
- Remove jumper from TR to 1.
- Remove 5.6 kilo-ohm resistor from T and T1. Reconnect wires at T and T1.
- Remove jumper from P to P1. Reconnect device at P and P1.
- Apply power (24 vac) to terminals TR and TR1.

Table 33 — EconoMi\$er IV Input/Output Logic

Demand Control Ventilation (DCV)	INPUTS				OUTPUTS			
	Enthalpy*		Y1	Y2	Compressor		N Terminal†	
	Outdoor	Return			Stage 1	Stage 2	Occupied	Unoccupied
	High (Free Cooling LED Off)	Low	On	On	On	On	Minimum position	Closed
Below set (DCV LED Off)	High (Free Cooling LED Off)	Low	On	Off	On	Off		
			On	Off	On	Off		
			Off	Off	Off	Off		
	Low (Free Cooling LED On)	High	On	On	On	Off	Modulating** (between min. position and full-open)	Modulating** (between closed and full-open)
			On	Off	Off	Off	Modulating** (between min. position and full-open)	Modulating** (between closed and full-open)
			Off	Off	Off	Off	Minimum position	Closed
Above set (DCV LED On)	High (Free Cooling LED Off)	Low	On	On	On	On	Modulating†† (between min. position and DCV maximum)	Modulating†† (between closed and DCV maximum)
			On	Off	On	Off	Modulating†† (between min. position and DCV maximum)	Modulating†† (between closed and DCV maximum)
			Off	Off	Off	Off	Modulating†† (between min. position and DCV maximum)	Modulating†† (between closed and DCV maximum)
	Low (Free Cooling LED On)	High	On	On	On	Off	Modulating***	Modulating†††
			On	Off	Off	Off	Modulating***	Modulating†††
			Off	Off	Off	Off	Modulating***	Modulating†††

\*For single enthalpy control, the module compares outdoor enthalpy to the ABCD set point.

†Power at N terminal determines Occupied/Unoccupied setting:  
24 vac (Occupied), no power (Unoccupied).

\*\*Modulation is based on the supply-air sensor signal.

††Modulation is based on the DCV signal.

\*\*\*Modulation is based on the greater of DCV and supply-air sensor signals, between minimum position and either maximum position (DCV) or fully open (supply-air signal).

†††Modulation is based on the greater of DCV and supply-air sensor signals, between closed and either maximum position (DCV) or fully open (supply-air signal).




Fig. 54 — EconoMi\$er IV Functional View

## INDEX

- Access panels 14
- Barometric flow capacity 16
- Charging chart, refrigerant 43-45
- Clearance 2, 5
- CO<sub>2</sub> sensor
  - Configuration 20
  - Settings 18, 20
- Compressor
  - Lubrication 42
  - Mounting 38
  - Rotation 38
- Condensate drain
  - Cleaning 42
  - Location 2, 4
- Condenser coil 6
  - Cleaning 41
- Condenser fan 6
  - Adjustment 42
- Control circuit
  - Wiring 11
  - Wiring raceway 11
- Convenience outlet 13
- Demand ventilation control 19
  - Dehumidification 20
- Dimensions 3, 5
- Ductwork 1
- EconoMi\$er IV 13-20, 48, 49
  - Adjustment 42
  - Components 14
  - Damper movement 19
  - Wiring 15
- Electrical connections 7
- Electrical data 8-10
- Electric heaters 10
- Enthalpy changeover set points 18
- Evaporator coil 6
  - Cleaning 41
- Evaporator fan motor 6
  - Lubrication 42
  - Motor data 22, 23
  - Performance 24-37
  - Pulley adjustment 22
  - Pulley setting 6, 22
  - Speed 6
- Factory-installed options
  - Convenience outlet 13
  - Disconnect switch 11
  - EconoMi\$er IV 13-20
  - Manual outdoor air damper 13
  - Perfect Humidity™ dehumidification system 11, 12
- Filter
  - Cleaning 42
  - Installation 15
  - Size 6
- Freeze protection thermostat 6
- Heat anticipator settings 11
- High flow valves 38
- High pressure switch 6
- Horizontal units 1, 2
- Humidistat 12
  - Indoor air quality sensor 18
  - Low pressure switch 6
  - Manual outdoor air damper 13
- Mounting
  - Unit 2
- Non-fused disconnect switch 11
- Operating sequence
  - Cooling 39
  - EconoMi\$er IV 39
  - Heating 39
- Perfect Humidity™ dehumidification package 39-41
- Outdoor air hood 13-15
- Outdoor air temperature sensor 14
- Outdoor air inlet screens
  - Cleaning 42
- Perfect Humidity™ dehumidification system 11, 12, 21, 39-42, 45, 47
  - Physical data 6
  - Power supply
    - Wiring 7
  - Pressure, drop
    - EconoMi\$er IV 23
    - Electric heat 23
  - Perfect Humidity dehumidification 21
  - Pressure switches
    - High pressure 6
    - Low pressure 6
  - Pre-start-up 38
  - Refrigerant
    - Charge 6, 42
    - Type 6
  - Refrigerant service ports 38
  - Replacement parts 45
  - Return air filter 6, 38
  - Return air temperature sensor 17
  - Rigging unit 2, 4
  - Roof curb
    - Assembly 1
    - Dimensions 3
    - Connector package 3
    - Leveling tolerances 4
    - Weight 6
  - Safety considerations 1
  - Safety relief 39
  - Service 41-45
  - Service ports 38
  - Slab mount 1
  - Start-up 38-41
  - Start-up checklist CL-1
  - Supply air temperature sensor 14
  - Thermostat 11
  - Troubleshooting 46-49
  - Ventilation 39
  - Weight
    - Corner 5
    - EconoMi\$er IV 5, 6
  - Perfect Humidity dehumidification 6
  - Unit 4-6
  - Wiring
    - EconoMi\$er IV 15
    - Humidistat 12
    - Perfect Humidity system 12
    - Power connections 7



**START-UP CHECKLIST**  
**(Remove and Store in Job File)**

**I. PRELIMINARY INFORMATION**

MODEL NO.: \_\_\_\_\_

SERIAL NO.: \_\_\_\_\_

DATE: \_\_\_\_\_

TECHNICIAN: \_\_\_\_\_

BUILDING LOCATION: \_\_\_\_\_

**II. PRE-START-UP (insert checkmark in box as each item is completed)**

- VERIFY JOBSITE VOLTAGE AGREES WITH VOLTAGE LISTED ON RATING PLATE
- VERIFY THAT CONDENSATE CONNECTION IS INSTALLED PER INSTALLATION INSTRUCTIONS
- CHECK THAT ALL ELECTRICAL CONNECTIONS AND TERMINALS ARE TIGHT
- CHECK THAT RETURN (INDOOR SECTION) AIR FILTERS ARE CLEAN AND IN PLACE
- VERIFY THAT UNIT INSTALLATION IS LEVEL
- CHECK FAN WHEEL AND PROPELLER FOR LOCATION IN HOUSING AND ORIFICE AND CHECK THAT SETSCREW IS TIGHT
- CHECK PULLEY ALIGNMENT AND BELT TENSION PER INSTALLATION INSTRUCTIONS
- CHECK TO ENSURE THAT ELECTRICAL WIRING IS NOT IN CONTACT WITH REFRIGERANT LINES OR SHARP METAL EDGES

**III. START-UP**

**ELECTRICAL**

SUPPLY VOLTAGE	L1-L2	_____	L2-L3	_____	L3-L1	_____
CIRCUIT 1 COMPRESSOR AMPS	L1	_____	L2	_____	L3	_____
CIRCUIT 2 COMPRESSOR AMPS	L1	_____	L2	_____	L3	_____
EVAPORATOR FAN AMPS	L1	_____	L2	_____	L3	_____

**TEMPERATURES**

OUTDOOR-AIR TEMPERATURE	_____	DB	_____	WB
RETURN-AIR TEMPERATURE	_____	DB	_____	WB
COOLING SUPPLY AIR	_____	DB	_____	WB

**PRESSESURES**

REFRIGERANT SUCTION, CIRCUIT 1	_____	PSIG AT	_____	F (AT SERVICE PORT)
REFRIGERANT SUCTION, CIRCUIT 2	_____	PSIG AT	_____	F (AT SERVICE PORT)
REFRIGERANT DISCHARGE, CIRCUIT 1	_____	PSIG AT	_____	F (CONDENSER LIQUID LINE OUTLET TUBE)
REFRIGERANT DISCHARGE, CIRCUIT 2	_____	PSIG AT	_____	F (CONDENSER LIQUID LINE OUTLET TUBE)

- VERIFY THAT 3-PHASE SCROLL COMPRESSOR IS ROTATING IN THE CORRECT DIRECTION
- VERIFY REFRIGERANT CHARGE USING CHARGING CHARTS ON PAGES 43-45.

CUT ALONG DOTTED LINE