



## 1500 Series User's Guide




June 2007

[www.lexmark.com](http://www.lexmark.com)

## Safety information


Use only the power supply and power supply cord provided with this product or the manufacturer's authorized replacement power supply and power supply cord.

Connect the power supply cord to an electrical outlet that is near the product and easily accessible.

 **CAUTION:** Do not twist, bind, crush, or place heavy objects on the power cord. Do not subject the power cord to abrasion or stress. Do not pinch the power cord between objects such as furniture and walls. If the power cord is misused, a risk of fire or electrical shock results. Inspect the power cord regularly for signs of misuse. Remove the power cord from the electrical outlet before inspecting it.

Refer service or repairs, other than those described in the user documentation, to a professional service person.

This product is designed, tested, and approved to meet strict global safety standards with the use of specific Lexmark components. The safety features of some parts may not always be obvious. Lexmark is not responsible for the use of other replacement parts.

 **CAUTION:** Do not set up this product or make any electrical or cabling connections, such as the power supply cord or telephone, during a lightning storm.

**SAVE THESE INSTRUCTIONS.**

# Contents

---

<b>Safety information.....</b>	<b>2</b>
<b>Introduction.....</b>	<b>9</b>
Finding information about the printer.....	9
Operating system notice.....	12
Wireless network compatibility.....	12
<b>Setting up the printer.....</b>	<b>13</b>
Checking the box contents.....	13
Understanding the parts of the printer.....	14
Installing the printer software.....	16
Understanding the printer software.....	17
Security Information.....	19
<b>Networking.....</b>	<b>20</b>
General networking.....	20
Networking overview .....	20
Common home network configurations .....	20
What information do I need and where do I find it? .....	22
Finding the MAC address .....	22
Printing a network setup page .....	23
Wireless networking.....	23
Finding IP addresses.....	23
Assigning an IP address.....	24
Configure IP address.....	24
Finding the signal strength .....	24
Tips for using network adapters .....	24
Types of wireless networks .....	24
Advanced wireless setup.....	25
Creating an ad hoc wireless network using Windows .....	25
Adding a printer to an existing ad hoc wireless network using Windows .....	27
<b>Loading paper and original documents.....</b>	<b>28</b>
Loading paper.....	28
Loading envelopes.....	28
Loading labels.....	29
Loading greeting cards, index cards, photo cards, and postcards.....	29
Loading transparencies.....	30
Loading iron-on transfers.....	30
Loading custom-size paper.....	30

Loading banner paper.....	31
<b>Printing.....</b>	<b>32</b>
Printing basic documents.....	32
Printing a document.....	32
Printing a Web page.....	32
Printing photos or images from a Web page.....	33
Printing multiple copies of a document.....	33
Collating copies.....	34
Printing the last page first (reverse page order).....	34
Printing multiple pages on one sheet (N-Up).....	34
Printing documents or photos from a removable storage device.....	35
Pausing print jobs.....	35
Canceling print jobs.....	35
Printing specialty documents.....	35
Choosing compatible specialty paper types.....	35
Printing envelopes.....	36
Printing greeting cards, index cards, photo cards, and postcards.....	36
Printing a document as a poster.....	36
Printing an image as a poster.....	37
Printing a booklet.....	37
Assembling a booklet.....	38
Printing on custom-size paper.....	38
Printing iron-on transfers.....	38
Printing transparencies.....	39
Printing a banner.....	39
Changing printer settings.....	39
Saving and deleting print settings.....	39
Resetting the printer to factory default settings.....	40
Printing on both sides of the paper (duplexing).....	40
Understanding the two-sided printing (duplexing) function.....	40
Printing on both sides of the paper (duplexing) automatically.....	41
Printing on both sides of the paper (duplexing) manually.....	41
<b>Working with photos.....</b>	<b>43</b>
Retrieving and managing photos.....	43
Inserting a memory card.....	43
Inserting a flash drive.....	44
Connecting a PictBridge-enabled digital camera.....	45
Transferring all photos from a memory card using the computer.....	45
Transferring selected photos from a memory card using the computer.....	46
Transferring all photos from a CD or flash drive using the computer.....	46
Transferring selected photos from a CD or flash drive using the computer.....	46
Changing the Productivity Studio temporary files preferences.....	47
Changing the Productivity Studio searched folders preferences.....	47
Changing the Productivity Studio library preferences.....	47

Changing the Productivity Studio transfer settings.....	48
Editing photos.....	48
Cropping a photo .....	48
Rotating a photo .....	48
Changing the Resolution / Size of a photo .....	48
Applying One-Click Auto Fixes to a photo .....	49
Reducing the red-eye effect in a photo.....	49
Blurring/Sharpening a photo.....	49
Enhancing a photo.....	50
Changing the Hue / Saturation of a photo .....	50
Changing the Gamma Value of a photo or image .....	50
Despeckling a photo .....	50
Changing the Brightness / Contrast settings of a photo .....	51
Applying a color effect to a photo .....	51
Printing photos.....	51
Printing photos from a CD or removable storage device using the computer .....	51
Viewing / Printing photos from the Productivity Studio .....	52
Printing Photo Packages .....	52
Creating Photo Greeting Cards .....	52
Printing all photos from a memory device .....	53
Using a PictBridge-enabled digital camera to control printing photos .....	54
Printing photos from a digital camera using DPOF .....	55
Creating and viewing a slideshow.....	55
<b>Maintaining the printer.....</b>	<b>56</b>
Installing print cartridges.....	56
Removing a used print cartridge.....	57
Using genuine Lexmark print cartridges.....	58
Refilling print cartridges.....	58
Aligning the print cartridges.....	59
Cleaning the print cartridge nozzles.....	59
Wiping the print cartridge nozzles and contacts.....	59
Cleaning the exterior of the printer.....	60
Preserving the print cartridges.....	61
Ordering supplies.....	61
Ordering print cartridges.....	61
Ordering paper and other supplies.....	61
<b>Troubleshooting.....</b>	<b>63</b>
Setup Troubleshooting.....	63
Power button is not lit .....	63
Power light is blinking .....	64
Duplex light is blinking.....	64
Power light and duplex light are blinking alternately.....	64

Software does not install .....	66
Page does not print .....	67
Solving printer communication problems.....	68
Understanding Warning levels.....	68
Removing and reinstalling the software.....	68
Enabling the USB port.....	69
Wireless troubleshooting.....	69
How do I find out what type of security my network is using? .....	69
Wi-Fi indicator light is orange .....	70
Wi-Fi indicator light is blinking orange during installation .....	70
Wi-Fi indicator light is not lit.....	72
Check your security keys.....	74
Printer is configured correctly, but cannot be found on the network.....	74
Wireless network printer does not print .....	75
Wireless printer is no longer working.....	76
Changing wireless settings after installation.....	77
Resetting an internal wireless print server to factory default settings.....	77
Network printer does not show up in the printer selection list during installation .....	78
Wireless Setup Utility cannot communicate with the printer during installation (Windows users only) .....	78
Checking your network name (Windows users only).....	79
Ping the access point .....	79
Ping the printer .....	80
Run the Wireless Setup Utility (Windows users only).....	80
Changing wireless settings after installation (Windows users only) .....	81
Check printer ports (Windows users only).....	81
Print troubleshooting.....	81
Partial document or photo prints.....	81
Improving print quality .....	81
Poor text and graphic quality .....	82
Poor quality at the edges of the page.....	83
Print speed is slow.....	83
Skewed print.....	84
Photo smudges.....	84
Checking the print cartridges.....	84
Ink levels seem incorrect.....	84
Ink levels seem to go down too quickly .....	85
A blank or incorrect page prints.....	85
Characters on printout are missing or unexpected.....	85
Colors on printout are faded or differ from colors on the screen .....	86
Glossy photo paper or transparencies stick together .....	86
Page prints with different fonts .....	86
Print is too dark or smudged.....	87
Printed characters are improperly formed or are not aligned correctly.....	87
Printouts have alternating bands of light and dark print .....	87
Transparencies or photos contain white lines .....	88
Vertical straight lines are not smooth .....	88

White lines appear in graphics or solid black areas .....	88
Checking the printer status .....	89
Checking printer readiness .....	89
Checking the Spool Settings for banner printing .....	90
Resolving font problems .....	90
Printer is busy printing another job .....	91
Ready or Busy Printing is listed as the status .....	91
Printing a test page.....	91
Test page does not print.....	92
Cable is not connected, is loose, or is damaged .....	92
Printer is plugged in but does not print .....	93
Printer is trying to print to File.....	93
Printer cannot communicate with computers over peer-to-peer network .....	93
Printer is not able to communicate with the computer .....	95
Wrong printer is attached .....	95
Printer is out of paper .....	95
Updating the printer software .....	95
Bidirectional communication is not established .....	95
Experiencing poor quality or incorrect output .....	96
Cannot print from a memory card or flash drive .....	96
Cannot print from digital camera using PictBridge .....	96
Partial photo prints when using a PictBridge-enabled digital camera.....	97
Jams and misfeeds troubleshooting.....	97
Paper jam in the printer .....	97
Paper jam in the paper support .....	97
Paper jam in the duplex unit .....	98
Paper or specialty media misfeeds.....	99
Printer does not feed paper, envelopes, or specialty media.....	99
Banner paper jams .....	100
Paper continues to jam.....	100
Duplex unit does not operate correctly .....	101
Cartridge carrier jam.....	101
Memory card troubleshooting.....	102
Memory card cannot be inserted.....	102
Nothing happens when memory card is inserted .....	102
Photos do not transfer from a memory card across a wireless network.....	103
Error messages on the computer screen.....	104
Clearing error messages .....	104
Left/Right Cartridge Missing .....	104
Communication not available .....	104
General Printing Problem .....	105
Ink Low .....	105
Out of Memory.....	105
Out of Paper .....	105
Fixing a printing failure .....	105
Print File Error .....	106

Unsupported file types found on memory card.....	106
Paper Jam .....	106
Multiple All-In-Ones found .....	106
<b>Notices.....</b>	<b>107</b>
Product information.....	107
Edition notice.....	107
European EC directives conformity statement for radio products.....	109
Power consumption.....	112
<b>Networking glossary.....</b>	<b>117</b>
<b>Index.....</b>	<b>119</b>



# Introduction

---

## Finding information about the printer



### *Quick Setup sheet*

Description	Where to find
The <i>Quick Setup</i> sheet gives you instructions for setting up hardware and software.	You can find this document in the printer box or on the Lexmark Web site at <b>www.lexmark.com</b> .


### *User's Guide*

Description	Where to find
<p>The <i>User's Guide</i> gives you instructions for setting up hardware and software (on Windows operating systems) and some basic instructions for using the printer.</p> <p><b>Note:</b> If your printer supports Macintosh operating systems, see the Mac Help:</p> <ol style="list-style-type: none"><li>1 From the Finder desktop, double-click the <b>Lexmark 1500 Series</b> folder.</li><li>2 Double-click the printer <b>Help</b> icon.</li></ol>	You can find this document in the printer box or on the Lexmark Web site at <b>www.lexmark.com</b> .

## User's Guide: Comprehensive Version

Description	Where to find
<p>The <i>User's Guide: Comprehensive Version</i> gives you instructions for using the printer and other information such as:</p> <ul style="list-style-type: none"> <li>• Using the software (on Windows operating systems)</li> <li>• Loading paper</li> <li>• Printing</li> <li>• Working with photos</li> <li>• Scanning (if supported by your printer)</li> <li>• Making copies (if supported by your printer)</li> <li>• Faxing (if supported by your printer)</li> <li>• Maintaining the printer</li> <li>• Connecting the printer to a network (if supported by your printer)</li> <li>• Troubleshooting problems with printing, copying, scanning, faxing, paper jams, and misfeeds</li> </ul> <p><b>Note:</b> If your printer supports Macintosh operating systems, see the Mac Help:</p> <ol style="list-style-type: none"> <li>1 From the Finder desktop, double-click the <b>Lexmark 1500 Series</b> folder.</li> <li>2 Double-click the printer <b>Help</b> icon.</li> </ol>	<p>When you install the printer software, the <i>User's Guide: Comprehensive Version</i> will be installed.</p> <ol style="list-style-type: none"> <li>1 Do one of the following: <ul style="list-style-type: none"> <li>• In Windows Vista, click .</li> <li>• In Windows XP and earlier, click <b>Start</b>.</li> </ul> </li> <li>2 Click <b>Programs</b> or <b>All Programs</b> → <b>Lexmark 1500 Series</b>.</li> <li>3 Click <b>User's Guide</b>.</li> </ol> <p>If the link to the <i>User's Guide</i> is not on your desktop, follow these instructions:</p> <ol style="list-style-type: none"> <li>1 Insert the CD. The installation screen appears. <b>Note:</b> If necessary, click  → <b>All Programs</b> → <b>Run</b>. In Windows XP and earlier versions, click <b>Start</b> → <b>Run</b>, and then type <b>D:\setup</b>, where <b>D</b> is the letter of your CD-ROM drive.</li> <li>2 Click <b>Documentation</b>.</li> <li>3 Click <b>View User's Guide (including Setup Troubleshooting)</b>.</li> <li>4 Click <b>Yes</b>. An icon of the <i>User's Guide</i> appears on your desktop, and the <i>User's Guide: Comprehensive Version</i> appears on the screen.</li> </ol> <p>You can also find this document on the Lexmark Web site at <b>www.lexmark.com</b>.</p>

## Lexmark Solution Center

Description	Where to find
<p>The Lexmark Solution Center software is included on your CD. It installs with the other software, if your printer connects to a computer.</p>	<p>To access the Lexmark Solution Center:</p> <ol style="list-style-type: none"> <li>1 Do one of the following: <ul style="list-style-type: none"> <li>• In Windows Vista, click .</li> <li>• In Windows XP and earlier, click <b>Start</b>.</li> </ul> </li> <li>2 Click <b>Programs</b> or <b>All Programs</b> → <b>Lexmark 1500 Series</b>.</li> <li>3 Select <b>Lexmark Solution Center</b>.</li> </ol>

## Customer support

Description	Where to find (North America)	Where to find (rest of world)
<b>Telephone support</b>	<p>Call us at</p> <ul style="list-style-type: none"> <li>US: 1-800-332-4120 Monday–Friday (8:00 AM–11:00 PM ET) Saturday (Noon–6:00 PM ET)</li> <li>Canada: 1-800-539-6275 <i>English</i> Monday–Friday (8:00 AM–11:00 PM ET) Saturday (Noon–6:00 PM ET) <i>French</i> Monday–Friday (9:00 AM–7:00 PM ET)</li> <li>Mexico: 01-800-253-9627 Monday–Friday (8:00 AM–8:00 PM ET)</li> </ul> <p><b>Note:</b> Support numbers and times may change without notice. For the most recent phone numbers available, see the printed warranty statement that shipped with your printer.</p>	<p>Telephone numbers and support hours vary by country or region.</p> <p>Visit our Web site at <b>www.lexmark.com</b>. Select a country or region, and then select the Customer Support link.</p> <p><b>Note:</b> For additional information about contacting Lexmark, see the printed warranty that shipped with your printer.</p>
<b>E-mail support</b>	<p>For e-mail support, visit our Web site: <b>www.lexmark.com</b>.</p> <ol style="list-style-type: none"> <li>1 Click <b>CUSTOMER SUPPORT</b>.</li> <li>2 Click <b>Technical Support</b>.</li> <li>3 Select your printer family.</li> <li>4 Select your printer model.</li> <li>5 From the Support Tools section, click <b>e-Mail Support</b>.</li> <li>6 Complete the form, and then click <b>Submit Request</b>.</li> </ol>	<p>E-mail support varies by country or region, and may not be available in some instances.</p> <p>Visit our Web site at <b>www.lexmark.com</b>. Select a country or region, and then select the Customer Support link.</p> <p><b>Note:</b> For additional information about contacting Lexmark, see the printed warranty that shipped with your printer.</p>

## Limited Warranty

Description	Where to find (US)	Where to find (rest of world)
Limited Warranty Information Lexmark International, Inc. furnishes a limited warranty that this printer will be free of defects in materials and workmanship for a period of 12 months after the original date of purchase.	<p>To view the limitations and conditions of this limited warranty, see the Statement of Limited Warranty included with this printer, or set forth at <b>www.lexmark.com</b>.</p> <ol style="list-style-type: none"> <li>1 Click <b>CUSTOMER SUPPORT</b>.</li> <li>2 Click <b>Warranty Information</b>.</li> <li>3 From the Statement of Limited Warranty section, click <b>Inkjet &amp; All-In-One Printers</b>.</li> <li>4 Scroll through the Web page to view the warranty.</li> </ol>	<p>Warranty information varies by country or region. See the printed warranty that shipped with your printer.</p>

Record the following information (located on the store receipt and the back of the printer), and have it ready when you contact us so that we may serve you faster:

- Machine Type number
- Serial number
- Date purchased
- Store where purchased

## Operating system notice

All features and functions are operating system-dependent. For complete descriptions:

- **Windows users**—See the *User's Guide*.
- **Macintosh users**—If your product supports Macintosh, see the Mac Help installed with the printer software.


## Wireless network compatibility

Your printer contains an IEEE 802.11g wireless print server. Your printer is compatible with IEEE 802.11 b/g/n routers that are Wi-Fi certified. If you are having issues with an N router, verify with your router manufacturer that the current mode setting is compatible with G devices, as this setting varies depending on the router brand/model.

# Setting up the printer


---








## Checking the box contents




	Name	Description
1	Power supply cord	Fits into the power supply attached to the back of the printer
2	Installation software CD	<ul style="list-style-type: none"><li>• Installation software for the printer</li><li>• <i>Mac Help</i></li><li>• <i>User's Guide: Comprehensive Version</i> in electronic format</li></ul>
3	Installation cable	Connects the printer to the computer temporarily during some methods of installation
4	<i>User's Guide</i>	Printed booklet that serves as a guide <b>Note:</b> Complete user information ( <i>Mac Help</i> or <i>User's Guide: Comprehensive Version</i> ) can be found on the installation software CD
5	<i>Quick Setup</i> sheet	Initial setup instructions
6	Color print cartridge	Cartridge to be installed in the right cartridge carrier
7	Black print cartridge	Cartridge to be installed in the left cartridge carrier




## Understanding the parts of the printer



	Use the	To
1		<ul style="list-style-type: none"> <li>Turn the printer on and off. <ul style="list-style-type: none"> <li>If the printer is inactive for 30 minutes, the printer reverts to sleep mode to conserve energy. Press  or start a print job to turn the printer back on.</li> <li>When the printer is in sleep mode, pressing and holding  for two seconds will turn off the printer.</li> </ul> </li> <li>Cancel a print job. Press  in the middle of a print job.</li> <li>Be alerted for errors. For more information, see “Power light is blinking” on page 64.</li> </ul>
2		<ul style="list-style-type: none"> <li>Load or eject paper.</li> <li>Cancel a print job. Press  in the middle of a print job.</li> </ul>
3		<ul style="list-style-type: none"> <li>Print on both sides of the paper (duplex). A green backlight comes on when the duplex function is activated. <p><b>Note:</b> This button is not functional with a Macintosh operating system. You can print two-sided documents with a Macintosh operating system by using the settings in the Two-Sided menu of the Print dialog.</p> </li> <li>Be alerted for errors. For more information, see “Duplex light is blinking” on page 64 and “Power light and duplex light are blinking alternately” on page 64.</li> </ul>
4	PictBridge port	Connect a PictBridge-enabled digital camera or a flash drive to the printer.
5	Card reader light	Check card reader status. The light blinks to indicate a memory card is being accessed.
6	Memory card slots	Insert a memory card. For more information on what types of memory cards can be inserted into each slot, see “Inserting a memory card” on page 43.

	Use the	To
7	Wi-Fi indicator	<p>Check wireless status:</p> <ul style="list-style-type: none"> <li>• <b>Off</b> indicates that the printer is not turned on or that no wireless option is installed.</li> <li>• <b>Orange</b> <ul style="list-style-type: none"> <li>– indicates that the printer is ready to be configured for wireless printing</li> <li>– indicates that the printer is connected for USB printing</li> </ul> </li> <li>• <b>Orange blinking</b> indicates that the printer is configured but is unable to communicate with the wireless network.</li> <li>• <b>Green</b> indicates that the printer is connected to a wireless network.</li> </ul>
8	Paper exit tray	Stack paper as it exits.
9	Access cover	<ul style="list-style-type: none"> <li>• Install or change the print cartridges.</li> <li>• Clear paper jams.</li> </ul>
10	Paper feed guard	Prevent items from falling into the paper slot.
11	Paper guides	Keep paper straight when feeding.
12	Paper support	Load paper.



	Use the	To
1	Power supply	<p>Connect the printer to a power source using the power cord.</p> <ol style="list-style-type: none"> <li>1 Plug the power cord all the way into the power supply on the printer.</li> <li>2 Plug the power cord into an electrical outlet that other electrical devices have been using.</li> </ol>  <ol style="list-style-type: none"> <li>3 If the  light is not on, press .</li> </ol>
2	Duplex unit	<ul style="list-style-type: none"> <li>• Print on both sides of the paper.</li> <li>• Remove paper jams. For more information, see “Paper jam in the duplex unit” on page 98.</li> </ul>
3	USB port	<p>Connect the printer to a computer using an installation cable.</p> <p><b>Warning:</b> Do not touch the USB port except when plugging in or removing a USB cable or installation cable.</p>
4	Internal wireless print server	Connect to a wireless network.

## Installing the printer software

### *Using the installation software CD (Windows users only)*

Using the CD that came with the printer:

- 1 Start Windows.
- 2 When the desktop appears, insert the software CD.  
The software installation screen appears.



- 3 Click **Install**.

### ***Using the installation software CD (Macintosh users only)***

- 1 Close all open software applications.
- 2 Insert the software CD.
- 3 From the Finder desktop, double-click the printer CD icon that automatically appears.
- 4 Double-click the **Install** icon.
- 5 Follow the instructions on the computer screen.


### ***Using the World Wide Web***

- 1 Go to the Lexmark Web site at **www.lexmark.com**.
- 2 From the home page, navigate through the menu selection, and then click **Drivers & Downloads**.
- 3 Choose the printer and the printer driver for your operating system.
- 4 Follow the instructions on the computer screen to download the driver and install the printer software.



## **Understanding the printer software**



Using the software that installed with your printer, you can edit photos, maintain your printer, and do many other tasks. The following is an overview of features of the Productivity Studio and the Solution Center.

To open the Productivity Studio Welcome Screen, use one of these methods:

Method 1	Method 2
From the desktop, double-click the <b>Productivity Studio</b> icon.	<ol style="list-style-type: none"><li>1 Do one of the following:<ul style="list-style-type: none"><li>• In Windows Vista, click .</li><li>• In Windows XP and earlier, click <b>Start</b>.</li></ul></li><li>2 Click <b>Programs</b> or <b>All Programs</b> → <b>Lexmark 1500 Series</b>.</li><li>3 Select <b>Productivity Studio</b>.</li></ol>

Click the **Productivity Studio** icon for the task you want to complete. Depending on the printer you have, some of the features of this software may not be applicable.


Click	To	Details
	Transfer Photos	Download photos from a memory card, flash drive, CD, or digital camera to the Library.
	Photo Greeting Cards	Make quality greeting cards from your photos.



Click	To	Details
	Photo Packages	Print multiple photos in various sizes.
	Poster	Print a photo as a multiple-page poster.



At the bottom left corner of the Welcome Screen, there are two Settings choices:

Click	To
Printer Status and Maintenance	<ul style="list-style-type: none"> <li>• Check ink levels.</li> <li>• Order print cartridges.</li> <li>• Find maintenance information.</li> <li>• Select other Solution Center tabs for more information, including how to change printer settings and troubleshooting.</li> </ul>

The Solution Center is a complete guide to such printing features as printing photos, troubleshooting printing problems, and installing print cartridges and performing maintenance tasks. To open the Solution Center, use one of the following methods.

Method 1	Method 2
<ol style="list-style-type: none"> <li>1 From the desktop, double-click on the <b>Solution Center</b> icon.</li> <li>2 Click <b>Setup and diagnose printer</b>. The Solution Center appears with the Maintenance tab open.</li> </ol>	<ol style="list-style-type: none"> <li>1 Do one of the following: <ul style="list-style-type: none"> <li>• In Windows Vista, click .</li> <li>• In Windows XP and earlier, click <b>Start</b>.</li> </ul> </li> <li>2 Click <b>Programs</b> or <b>All Programs</b> → <b>Lexmark 1500 Series</b>.</li> <li>3 Select <b>Solution Center</b>.</li> </ol>

From here	You can:
How To 	<ul style="list-style-type: none"> <li>• Learn how to: <ul style="list-style-type: none"> <li>– Use basic features.</li> <li>– Print projects such as photos, envelopes, cards, banners, iron-on transfers, and transparencies.</li> </ul> </li> <li>• Find the electronic <i>User's Guide: Comprehensive Version</i> for more information.</li> <li>• View ink levels and order new print cartridges.</li> </ul>
Troubleshooting 	<ul style="list-style-type: none"> <li>• Learn tips about the current status.</li> <li>• Solve printer problems.</li> <li>• View ink levels and order new print cartridges.</li> </ul>

From here	You can:
Advanced 	<ul style="list-style-type: none"> <li>• Change the appearance of the Printing Status window.</li> <li>• Turn printing voice notification on or off.</li> <li>• Change network printing settings.</li> <li>• Share information with us regarding how you use the printer.</li> <li>• Obtain software version information.</li> <li>• View ink levels and order new print cartridges.</li> </ul>
Maintenance 	<ul style="list-style-type: none"> <li>• Install a new print cartridge.</li> <li>• Order new print cartridges.</li> <li>• Print a test page.</li> <li>• Clean print cartridges to fix horizontal streaks.</li> <li>• Align print cartridges to fix blurry edges.</li> <li>• View ink levels.</li> <li>• Troubleshoot other ink problems.</li> </ul>

## Security Information

Third-party applications, including anti-virus, security, and firewall programs may alert you about the printer software being installed. For your printer to work properly, allow the printer software to run on your computer.

# Networking

---

## General networking

### *Networking overview*

A *network* is a collection of devices such as computers, printers, Ethernet hubs, wireless access points, and routers connected together for communication through cables or through a wireless connection. A network can be either wired, wireless, or designed to have both wired and wireless devices.

Devices on a wired network use cables to communicate with each other.

Devices on a wireless network use radio waves instead of cables to communicate with each other. For a device to be able to communicate wirelessly, it must have a wireless print server attached or installed that enables it to receive and transmit radio waves.

### *Common home network configurations*


For desktop computers, laptops, and printers to communicate with each other over a network, they must be connected by cables and/or have wireless network adapters built in or installed in them.

There are different ways a network can be set up. Five common examples appear below.

**Note:** The printers in the following diagrams represent Lexmark printers with Lexmark internal print servers built in or installed in them so that they can communicate over a network. Lexmark internal print servers are devices made by Lexmark to enable Lexmark printers to be connected to wired or wireless networks.

#### **Wired network example**

- A computer, a laptop, and a printer are connected by Ethernet cables to a hub, router, or switch.
- The network is connected to the Internet through a DSL or a cable modem.




#### **Wireless network examples**

Four common wireless networks appear below:

- Scenario 1: Laptop and printer connected wirelessly with Internet
- Scenario 2: Computer, laptop, and printer connected wirelessly with Internet
- Scenario 3: Computer, laptop, and printer connected wirelessly without Internet
- Scenario 4: Laptop connected wirelessly to printer without Internet


### Scenario 1: Laptop and printer connected wirelessly with Internet

- A computer is connected to a wireless router by an Ethernet cable.
- A laptop and a printer are connected wirelessly to the router.
- The network is connected to the Internet through a DSL or a cable modem.




### Scenario 2: Computer, laptop, and printer connected wirelessly with Internet

- A computer, a laptop, and a printer are connected wirelessly to a wireless router.
- The network is connected to the Internet through a DSL or a cable modem.




### Scenario 3: Computer, laptop, and printer connected wirelessly without Internet

- A computer, a laptop, and a printer are connected wirelessly to a wireless access point.
- The network has no connection to the Internet.



### Scenario 4: Laptop connected wirelessly to printer without Internet

- A laptop is directly connected wirelessly to a printer without going through a wireless router.
- The network has no connection to the Internet.



## What information do I need and where do I find it?

This printer may contain an internal wireless print server, which allows the printer to be used on a wireless network. You need the following settings from your existing wireless network:

- The network name, also known as the SSID
- The wireless mode (the type of wireless network you are using, either infrastructure or ad hoc)
- The type of security used on the network (WEP, WPA, or WPA2)
- Any applicable security keys or passwords used with the network security encryption type

**Note:** You must know this information in order to properly set up the printer for use on the wireless network. To obtain these settings, see the documentation that came with your wireless router or consult the person who set up your wireless network.

## Finding the MAC address

Most network equipment has a unique hardware identification number to distinguish it from other devices on the network. This is called the *Media Access Control (MAC)* address.

If your printer has a factory installed internal wireless print server, the MAC address is a series of letters and numbers located on the back of your printer.








If you purchased the internal wireless print server separately, the MAC address appears on an adhesive label that came with the wireless print server. Attach the adhesive label to your printer so you will be able to find the MAC address when you need it.



**Note:** A list of MAC addresses can be set on a router so that only devices with matching MAC addresses can be allowed to operate on the network. This is called *MAC filtering*. If MAC filtering is enabled in your router and you want to add a printer to your network, the MAC address of the printer must be included in the MAC filter list.

## ***Printing a network setup page***

A network setup page lists your printer's configuration settings, including the IP address and MAC address of the printer.

- 1 Make sure the printer is turned on.
- 2 Press .
- The  light pulses.
- 3 Press and hold .
- 4 While holding , press .
- 5 When the  light becomes steady, release .
- The network setup page prints.

## **Wireless networking**

### ***Finding IP addresses***

An IP address is a unique number used by devices on an IP network to locate and communicate with each other. Devices on an IP network can only communicate with each other if they have unique and valid IP addresses. A unique IP address means no two devices on the same network have the same IP address.

### **How to locate a printer IP address**

You can locate the printer IP address by printing out the printer network setup page. For more information, see "Printing a network setup page" on page 23.

## How to locate a computer IP address

1 Do one of the following:

- In Windows Vista, click  → **All Programs → Accessories → Command Prompt.**
- In Windows XP, click **Start → Programs** or **All Programs → Accessories → Command Prompt.**

2 Type **ipconfig**.

3 Press **Enter**.

The IP address appears as four sets of numbers separated by periods, such as 192.168.0.100.

## Assigning an IP address

An IP address may be assigned by the network using DHCP. The print object, created at the end of the installation, sends all print jobs across the network to the printer using this address.

Many networks have the ability to automatically assign an IP address. Auto-IP is the ability for individual devices to assign themselves a unique IP address. Most networks use DHCP to assign addresses.

During the Direct IP printing installation of printer software, the IP address is visible in the printer list only as it is being assigned. The print object that is created in the Printers folder of the operating system will reference the MAC address of the printer in the port name.

If the IP address is not automatically assigned, you can try manually entering an address after selecting your printer from the available list.

## Configure IP address

If you have lost communication with the printer over a network, select **Use DHCP** to reestablish communication with the printer.

You must assign an IP address in any of the following situations:

- You manually assigned IP addresses for the other network devices.
- You want to assign a specific IP address.
- You move the printer to a remote subnet.
- The printer is listed as **Unconfigured** in the Configuration Utility.

Contact your system support person for more information.

## Finding the signal strength

Wireless devices have built-in antennas that transmit and receive radio signals. The signal strength listed on the printer network setup page indicates how strongly a transmitted signal is being received. Many factors can affect the signal strength. One factor is interference from other wireless devices or even other devices such as microwave ovens. Another factor is distance. The farther two wireless devices are from each other, the more likely it is that the communication signal will be weaker.

## Tips for using network adapters

- Make sure the adapter connections are secure.
- Make sure the computer is turned on.
- Make sure you entered the correct IP address.

## Types of wireless networks

Networks can operate in one of two modes: infrastructure or ad hoc. Lexmark recommends setting up a network in infrastructure mode using the installation CD that came with the printer.



A wireless network where each device communicates with others through a wireless access point (wireless router) is set up in infrastructure mode. All devices must have valid IP addresses and share the same SSID and channel. In addition, they must share the same SSID and channel as the wireless access point (wireless router).

A simple type of wireless network is one where a PC with a wireless adapter communicates directly with a printer equipped for wireless networking. This mode of communication is called *ad hoc*. A device in this type of network must have a valid IP address and be set to ad hoc mode. The wireless print server must also be configured with the same SSID and channel.

	<b>Infrastructure</b>	<b>Ad hoc</b>
<b><i>Characteristics</i></b>		
Communication	Through wireless access point (wireless router)	Directly between devices
Security	More security options	
Range	Determined by range and number of access points	Restricted to range of individual devices on network
Speed	Usually faster	Usually slower
<b><i>Requirements for all devices on the network</i></b>		
Unique IP address for each device	Yes	Yes
Mode set to	Infrastructure mode	Ad hoc mode
Same SSID	Yes, including the wireless access point (wireless router)	Yes
Same channel	Yes, including the wireless access point (wireless router)	Yes

Infrastructure mode is the recommended setup method because it has:

- Increased network security
- Increased reliability
- Faster performance
- Easier setup


## Advanced wireless setup

### ***Creating an ad hoc wireless network using Windows***

The recommended way to set up your wireless network is to use a wireless access point (wireless router). A network set up this way is called an *infrastructure network*. If you have an infrastructure network in your home, you should configure your printer for use on that network.

If you don't have a wireless access point (wireless router) or would like to set up a standalone network between your printer and a computer with a wireless network adapter, you can set up an *ad hoc network*.

#### **For Windows Vista users**

- 1 Click  → **Control Panel** → **Network and Internet**.
- 2 Under Network and Sharing Center, click **Connect to a Network**.

- 3 In the Connect to a Network dialog, click **Set up a wireless ad-hoc (computer-to-computer) network**, and then click **Next**.
- 4 Follow the instructions in the “Set up a wireless ad hoc network” wizard. As part of the setup:
  - a Create a network name or SSID for the network between the computer and your printer.
  - b Write the name of your network in the space provided. Be sure to use the exact spelling and capitalization.
  - c Go to the Security Type drop-down, choose WEP, and create a security key (or password).  
**Note:** WEP passwords must be either 5 or 13 characters.
  - d Write the password for your network in the space provided. Be sure to use the exact spelling and capitalization.

Windows Vista will enable the ad hoc network for you. It will appear in the “Connect to a network” dialog under available networks, indicating that the computer is configured for the ad hoc network.
- 5 Close the Control Panel and any remaining windows.
- 6 Insert the printer CD into the computer and follow the direction for wireless installation.
- 7 When the available networks are displayed, provide the network name and the security information you created in step 4. The installer will configure the printer for use with the computer.
- 8 Store a copy of your network name and security information in a safe place for future reference.

### For Windows XP users

- 1 Click **Start → Settings → Control Panel → Network Connections**.
- 2 Right-click **Wireless Network Connections**.
- 3 If **Enable** appears in the pop-up menu, click it.  
**Note:** If Enable does not appear, your wireless connection is already enabled.
- 4 Right-click the **Wireless Network Connection** icon.
- 5 Click **Properties**.
- 6 Click the **Wireless Networks** tab.  
**Note:** If the Wireless Networks tab does not appear, your computer has third-party software that controls your wireless settings. You must use that software to set up the ad hoc wireless network. For more information, see the documentation for that software to learn how to create an ad hoc network.
- 7 Select the **Use Windows to configure my wireless network settings** check box.
- 8 Under Preferred Networks, delete any existing networks.
  - a Click the network to be removed.
  - b Click the **Remove** button.
- 9 Click **Add** to create an ad hoc network.
- 10 In the **Network Name (SSID)** box, type the name you want to give your wireless network.
- 11 Write down the network name you chose so you can refer to it when running the wireless setup. Make sure you copy it down exactly, including capital letters.
- 12 If **Network Authentication** appears in the list, select **Open**.
- 13 In the **Data encryption** list, select **WEP**.

- 14** If necessary, deselect the **The key is provided for me automatically** check box.
- 15** In the **Network Key** box, type in a security code.
- 16** Write down the security code you chose so you can refer to it when running the wireless setup. Make sure you copy it down exactly, including any capital letters.
- Note:** For more information about passwords (security keys), see “Check your security keys” in the “Wireless troubleshooting” section of the “Troubleshooting” chapter.
- 17** Type the same security code in the **Confirm network key** box.
- 18** Select the **This is a computer-to-computer (ad hoc) network; wireless access points are not used.** check box.
- 19** Click **OK** twice to close the two open windows.
- 20** It may take a few minutes for your computer to recognize the new settings. To check on the status of your network:
- a** Right-click the **Wireless Network Connections** icon.
  - b** Select **View Available Wireless Networks**.
    - If the network is listed but the computer is not connected, select the ad hoc network and then click the **Connect** button.
    - If the network does not appear, wait a minute and then click the **Refresh network list** button.
- 21** Click **Programs** or **All Programs → Lexmark 1500 Series**.
- 22** Click **Wireless Setup Utility**.
- Note:** You may be prompted to connect the printer to the computer again using the installation cable as part of the setup process.
- 23** Follow the prompts on the computer screen.
- 24** Store your network name and security code in a safe place for future reference.

### ***Adding a printer to an existing ad hoc wireless network using Windows***

- 1** Click **Programs** or **All Programs → Lexmark 1500 Series**.
- 2** Click **Wireless Setup**.
- 3** Follow the instructions on the computer screen.


# Loading paper and original documents

---

## Loading paper

- 1 Make sure:
  - You use paper designed for inkjet printers.
  - If you are using photo, glossy, or heavyweight matte paper, you load it with the glossy or printable side facing you. (If you are not sure which side is the printable side, see the instructions that came with the paper.)
  - The paper is not used or damaged.
  - If you are using specialty paper, you follow the instructions that came with it.
  - You do not force paper into the printer.
- 2 Before loading paper the first time, slide the paper guides out toward the edges of the paper support. You can load up to:
  - 100 sheets of plain paper
  - 25 sheets of heavyweight matte paper
  - 25 sheets of photo paper
  - 25 sheets of glossy paper

**Note:** Photos require more drying time. Remove each photo as it exits, and allow it to dry to avoid ink smudging.
- 3 Load the paper vertically in the center of the paper support, and adjust the paper guides to rest against the edges of the paper.



**Note:** To avoid paper jams, make sure the paper does not buckle when you adjust the paper guides.


## Loading envelopes

You can load up to 10 envelopes at a time.

**Warning:** Do not use envelopes that have metal clasps, string ties, or metal folding bars.

- 1 Load envelopes in the center of the paper support with the stamp location in the upper left corner.
- 2 Make sure:
  - The print side of the envelopes faces you.
  - The envelopes are designed for use with inkjet printers.

- The paper guides rest against the edges of the envelopes.



#### Notes:

- Do not load envelopes with holes, perforations, cutouts, or deep embossing.
- Do not use envelopes that have exposed flap adhesive.
- Envelopes require more drying time. Remove each envelope as it exits, and allow it to dry to avoid ink smudging.

## Loading labels

You can load up to 25 sheets of labels at a time.

**1** Load labels with the print side facing you and the top of the sheet fed into the printer first.

**2** Make sure:

- The print side of the labels faces you.
- The top of the labels feeds into the printer first.
- The adhesive on the labels does not extend to within 1 mm of the edge of the labels.
- You use full label sheets. Partial sheets (with areas exposed by missing labels) may cause labels to peel off during printing, resulting in a paper jam.
- The labels are loaded in the center of the paper support.
- The paper guides rest against the edges of the labels.

**Note:** Labels require more drying time. Remove each sheet of labels as it exits, and allow it to dry to avoid ink smudging.


## Loading greeting cards, index cards, photo cards, and postcards

You can load up to 25 greeting cards, index cards, photo cards, or postcards at a time.

**1** Load cards with the print side facing you.

**2** Make sure:

- The cards are loaded in the center of the paper support.
- The paper guides rest against the edges of the cards.



**Note:** Photo cards require more drying time. Remove each photo card as it exits, and allow it to dry to avoid ink smudging.

## Loading transparencies

You can load up to 50 transparencies at a time.

- 1 Load transparencies with the rough side facing you. If the transparencies have a removable strip, each strip should face away from you and down toward the printer.
- 2 Make sure:
  - The transparencies are loaded in the center of the paper support.
  - The paper guides rest against the edges of the transparencies.

### Notes:

- Transparencies with paper backing sheets are not recommended.
- Transparencies require more drying time. Remove each transparency as it exits, and allow it to dry to avoid ink smudging.

## Loading iron-on transfers

You can load up to 10 iron-on transfers at once, but you will achieve best results loading them one at a time.

- 1 Load iron-on transfers with the print side of the transfer facing you.
- 2 Make sure:
  - You follow the loading instructions that came with the iron-on transfers.
  - The transfers are loaded in the center of the paper support.
  - The paper guides rest against the edges of the transfers.

## Loading custom-size paper


You can load up to 100 sheets of custom-size paper at a time.

- 1 Load paper with the print side facing you.
- 2 Make sure:
  - The paper size fits within these dimensions:
    - Width:
      - 76.0–216.0 mm
      - 3.0–8.5 inches
    - Length:
      - 127.0–432.0 mm
      - 5.0–17.0 inches
  - The stack height does not exceed 10 mm.
  - The paper is loaded in the center of the paper support.
  - The paper guides rest against the edges of the paper.

## Loading banner paper

You can load up to 20 sheets of banner paper at a time.

- 1** Remove all paper from the paper support before loading the banner paper.
- 2** Tear off only the number of pages needed to print the banner.
- 3** Place the required stack of banner paper on a flat surface behind the printer.
- 4** Feed the leading edge of the banner paper into the printer first.



- 5** Make sure:
  - The paper is loaded in the center of the paper support.
  - The paper guides rest against the edges of the paper.

# Printing

---

## Printing basic documents

### *Printing a document*

- 1 Load paper.
- 2 With a document open, click **File → Print**.
- 3 Click **Properties, Preferences, Options, or Setup**.
- 4 Adjust the settings.
- 5 Click **OK**.
- 6 Click **OK** or **Print**.

### *Printing a Web page*

You can use the Toolbar to create a printer-friendly version of any Web page.



- 1 Load paper.
- 2 Open a Web page using Microsoft Internet Explorer 5.5 or later.
- 3 If you want to check or change your print settings:
  - a From the Toolbar, click **Lexmark → Page Setup**.
  - b Adjust the print settings.
  - c Click **OK**.
- 4 If you want to view the Web page before printing:
  - a Click **Preview**.
  - b Use the Toolbar options to scroll between pages, zoom in or out, or select whether to print text and images or text only.
  - c Click:
    - **Print** in the Print Preview window, then click **Print** in the Print dialog that opens
    - or
    - **Close**, and continue to the next step.
- 5 If needed, select a print option from the Toolbar:
  - **Normal**
  - **Quick**
  - **Black and White**
  - **Text Only**



## ***Printing photos or images from a Web page***

- 1** Load paper. For best results, use photo or heavyweight matte paper, with the glossy or printable side facing you. (If you are not sure which side is the printable side, see the instructions that came with the paper.)
- 2** Open a Web page with Microsoft Internet Explorer 5.5 or later.  
On the Toolbar, the number of photos valid for printing appears next to Photos.



- 3** If no number appears next to Photos:
  - a** From the Lexmark logo drop-down menu, select **Options**.
  - b** Select the **Advanced** tab.
  - c** Select a lower minimum photo size.
  - d** Click **OK**.The number of photos valid for printing appears next to Photos.
- 4** Click **Photos**.  
The Fast Pics dialog appears.
- 5** If you want to print all the photos or images using the same settings, select the size you want, the blank paper size in the printer, and the number of copies.
- 6** If you want to print one photo or image at a time:
  - a** Click the photos or images you do *not* want to print to deselect them.
  - b** To make common editing changes:
    - 1** Right-click the photo or image.
    - 2** Click **Edit**.
    - 3** Make your selections.
    - 4** Follow the instructions on the screen.
    - 5** When you are finished making changes, click **Done**.
    - 6** Select the size you want, the blank paper size in the printer, and the number of copies.
- 7** Click **Print Now**.


## ***Printing multiple copies of a document***

- 1** With a document open, click **File → Print** or **Printer Setup**.
- 2** From the Print Setup dialog box, click **Properties**, **Preferences**, **Options**, or **Setup**.
- 3** In the Copies section of the **Quality/Copies** tab, enter the number of copies you want to print.  
**Note:** If you print multiple copies of a multiple-page document and want them collated, click **Collate Copies**.
- 4** Click **OK** to close any printer software dialog boxes that are open.
- 5** Print the document.

## Collating copies

If you print multiple copies of a document, you can choose to print each copy as a set (collated) or to print the copies as groups of pages (not collated).

### Collated



### Not collated



- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click the **Quality/Copies** tab.
- 4 From the Multiple Copies section, click **Collate Copies**.
- 5 Click **OK** to close any printer software dialog boxes that are open.
- 6 Print the document.

### Notes:

- This option is available only when you are printing multiple copies.
- If printing photos, to prevent smudging, remove each photo as it exits the printer, and let it dry before stacking.

## Printing the last page first (reverse page order)

- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 From the **Quality/Copies** tab, select **Print Last Page First**.
- 4 Click **OK**.
- 5 Click **OK** or **Print**.

## Printing multiple pages on one sheet (N-Up)

- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 From the **Print Layout** tab, select **N-up**.
- 4 Select the number of pages to print on each page.
- 5 If you want each page image to be surrounded by a border, select **Print Page Borders**.
- 6 Click **OK**.
- 7 Click **OK** or **Print**.

## ***Printing documents or photos from a removable storage device***

- 1 Insert a memory card into a card slot, or insert a flash drive into the PictBridge port on the front of the printer.

If there are documents or photos stored on the memory card or flash drive, a dialog appears on the computer screen giving you the option to save the files or photos to the computer or to select files or photos to print.

- 2 Click **Select files to print** or **Select photos to print**.

- 3 Select the document or photo you want to print.

### **Notes:**

- For documents, the appropriate program opens. You can print your document directly from the program.
- For photos, the **Productivity Studio** opens. You can edit and print your photo directly from this program.

- 4 Print the document or photo.

## ***Pausing print jobs***

- 1 For Windows Vista, click  → **Control Panel** → **Printer**.

For Windows XP, click **Start** → **Settings** → **Printers and Faxes**.

- 2 Right-click the **Lexmark 1500 Series** icon.

- 3 Select **Pause**.

## ***Canceling print jobs***

- 1 In Windows Vista, click  → **Control Panel** → **Printer**.

In Windows XP, click **Start** → **Settings** → **Printers and Faxes**.

- 2 Right-click the **Lexmark 1500 Series** icon.

- 3 Select **Open**.

- 4 Right-click the document name.

- 5 Select **Cancel**.

## **Printing specialty documents**

### ***Choosing compatible specialty paper types***

- **Heavyweight matte paper**—A photo paper with a matte finish used for printing high-quality graphics.
- **Lexmark PerfectFinish™ Photo paper**—A high-quality photo paper specifically designed for Lexmark inkjet printers, but compatible with all inkjet printers. It is used specifically for printing professional quality photos with a glossy finish. It is best when used with genuine Lexmark evercolor™ 2 ink, providing photos that are fade- and water-resistant.
- **Lexmark Photo Paper**—An outstanding "everyday" heavyweight inkjet photo paper designed for use with Lexmark printers, but compatible with all brands of inkjet printers. Although inexpensive, it offers excellent image quality and outstanding value.
- **Transparency**—A clear, plastic media primarily used for overhead projectors.
- **Card stock**—A very thick paper used for printing sturdier items, such as greeting cards.
- **Iron-On transfer**—A type of media that has a reverse image printed on it that can be ironed onto fabric.

## ***Printing envelopes***

- 1 Load envelopes.
- 2 With a document open, click **File → Print**.
- 3 Click **Properties, Preferences, Options, or Setup**.
- 4 From the “I Want To” menu, select **Print on an envelope**.
- 5 From the Envelope Size list, select the envelope size loaded.
- 6 Select **Portrait** or **Landscape** orientation.

### **Notes:**

- Most envelopes use landscape orientation.
- Make sure the same orientation is also selected in the software application.

- 7 Click **OK** to close any printer software dialogs that are open.
- 8 Click **OK** or **Print**.

## ***Printing greeting cards, index cards, photo cards, and postcards***

- 1 Load greeting cards, index cards, photo cards, or postcards.
- 2 With a document open, click **File → Print**.
- 3 Click **Properties, Preferences, Options, or Setup**.
- 4 Select a Quality/Speed setting.  
Select **Photo** for photos and greeting cards, and select **Normal** for other types of cards.
- 5 Click the **Paper Setup** tab.
- 6 Select **Paper**.
- 7 From the Paper Size list, select a card size.
- 8 Click **OK**.
- 9 Click **OK** or **Print**.

### **Notes:**

- To avoid paper jams, do not force the cards into the printer.
- To prevent smudging, remove each card as it exits, and let it dry before stacking.

## ***Printing a document as a poster***

- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click the **Print Layout** tab.
- 4 From the Layout list, select **Poster**.
- 5 Select the poster size you want to print. The number you select represents the number of pages that make up the height and width of the poster.

- 6 Select **Print Crop Marks** if you want each page of the poster to show crop marks.
- 7 Click **Select Pages To Print** to reprint any damaged poster pages without having to print all of the poster pages. Click pages to select or cancel them.
- 8 Click **OK** to close any printer software dialogs that are open.
- 9 Print the document.

**Note:** Certain programs may cause text to be clipped or to disappear when using extra-large or extra-small fonts. If this occurs, try decreasing or increasing the font size.

### ***Printing an image as a poster***

- 1 From the desktop, double-click the **Productivity Studio** icon.
- 2 From the “Projects and Tools” area of the Welcome screen, click **Poster**.
- 3 Open the folder that contains your photo.
- 4 Drag the photo to the Print a Multi-Page Poster preview area of the screen.
- 5 Click **Next Step** at the bottom of the left pane.
- 6 From the “Paper size to print poster on” drop-down list, select a paper size.
- 7 From the “Print Quality for poster” drop-down list, select a print quality.
- 8 From the Poster Size drop-down list, select the poster size.
- 9 If you want to rotate the poster so that it fits better on the printed pages, click **Rotate 90 degrees**.
- 10 Click **Print Now** in the bottom right corner of the screen.

### ***Printing a booklet***

- 1 Before you change any Print Properties settings, you must select the correct paper size from the program. You can print booklets using these paper sizes:
    - Letter
    - A4
  - 2 Load the paper.
  - 3 With a document open, click **File → Print**.
  - 4 Click **Properties, Preferences, Options, or Setup**.
  - 5 Click the **Print Layout** tab, and then click **Booklet**.
  - 6 If you are printing a large booklet, select a number of **Printed sheets per bundle**.
    - a Click **Options → Layout Options**.
    - b From the **Printed sheets per bundle** drop-down menu, select a number of printed sheets per bundle.
- Note:** A bundle is a set number of sheets of paper folded together. The printed bundles are stacked, one on top of the other, keeping the correct page order. The stacked bundles can be bound to make a booklet. When printing with a heavier paper stock, select a smaller number of **Printed sheets per bundle**.
- 7 Click **OK** to close any printer software dialog boxes that are open.
  - 8 Print the document.

## ***Assembling a booklet***

- 1 Flip the printed stack of papers over in the paper exit tray.
- 2 Take the first bundle from the stack, fold it in half, and then set it aside with the front page down.
- 3 Take the next bundle from the stack, fold it in half, and then stack it with the front page down on top of the first bundle.



- 4 Stack the rest of the bundles with the front page down, one on top of the other, until the booklet is complete.
- 5 Bind the bundles together to complete the booklet.



## ***Printing on custom-size paper***

- 1 Load up to 100 sheets of custom-size paper.
- 2 With a document open, click **File → Print**.
- 3 From the Quality/Copies tab, select a Quality/Speed setting.
- 4 Click the **Paper Setup** tab.
- 5 From the Paper Size section, select **Paper** and then select **Custom Size**.
- 6 Select the measurement units to use.
- 7 Use the sliders, or type the size of the paper loaded into the printer.
- 8 Click **OK** to close any printer software dialogs that are open.
- 9 Print the document.

**Note:** Do not force paper into the printer.

## ***Printing iron-on transfers***

- 1 Load up to 10 iron-on transfers.
- 2 With an image open, click **File → Print**.
- 3 Click **Properties, Preferences, Options, or Setup**.
- 4 From the Print Layout tab, select **Mirror** if you want the printer software to flip the image.  
Select **Normal** if you have a program that automatically flips the image.
- 5 Click **OK** to close any printer software dialogs that are open.
- 6 Print the iron-on transfers.

**Note:** Do not force iron-on transfers into the printer.

## ***Printing transparencies***

- 1 Load up to 50 transparencies.
- 2 With a document open, click **File → Print**.
- 3 Click **OK** or **Print**.

**Note:** To prevent smudging, remove each transparency as it exits, and let it dry before stacking. Transparencies may require up to 15 minutes to dry.

## ***Printing a banner***

- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 From the Print Layout tab, select **Banner**.  
**Note:** After you print a banner, return the setting to **Normal**.
- 4 To keep banner paper from jamming, select **Letter Banner** or **A4 Banner** from the Banner Paper Size dialog.
- 5 From the Paper Setup tab, select **Landscape** orientation.
- 6 Click **OK**.
- 7 Click **OK** or **Print**.

## **Changing printer settings**







### ***Saving and deleting print settings***

- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click the **Quality/Copies** tab.
- 4 Make necessary adjustments to any of the settings in the Quality/Speed, Paper Type, and Multiple Copies sections.
- 5 From the Save Settings drop-down menu, select **Save your current settings**.
- 6 Click a radio button next to the number of the location where you want to save your settings, and then type a name for your settings in the selected box.  
**Note:** The first location contains factory default settings, which cannot be changed or deleted.
- 7 Click **Save**.

#### **Notes:**

- To retrieve your print settings, click the **Save Settings** drop-down menu, and then select them from the list.
- To delete settings, choose **Delete a setting** from the Save Settings drop-down menu. Select the radio button next to the setting you want to delete, and then click **Delete**.

## Resetting the printer to factory default settings

- 1 Make sure the printer is turned off.
- 2 Open the access cover and leave it open.
- 3 Press and hold .
- 4 While holding , press .
- 5 When the  light blinks, release .
- 6 Close the access cover.
- 7 Wait for the  light to stop blinking.

The printer is reset to factory default settings.

## Printing on both sides of the paper (duplexing)

### Understanding the two-sided printing (duplexing) function

The printer has a built-in duplex unit that lets you print on both sides of the paper automatically. This function is also known as two-sided printing or duplexing.










**Note:** Automatic two-sided printing (duplexing) works only with plain paper in letter and A4 sizes. If you want to print two-sided documents on another size or type of paper, use the manual duplexing method.

To print a two-sided copy, the  light must be on. The  button works in tandem with the Duplexing settings in the printer software. To access the Duplexing settings:



- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click the **Print Layout** tab.

The Duplexing area is on the lower portion of the dialog.

The options under the Duplexing drop-down box are “Use Printer Settings,” “On,” “Off,” and “Manual.”

Select	To
Use Printer Settings	Control two-sided printing using the  button. Press  to turn the  light on or off. <ul style="list-style-type: none"><li>• When the  light is on, your documents are printed on both sides of the paper (duplexed).</li><li>• When the  light is off, your documents are <i>not</i> printed on both sides of the paper.</li></ul> <b>Note:</b> Use Printer Settings is the factory default setting.
On	Turn on the  button so that <i>all</i> documents are printed on both sides of the paper. <b>Note:</b> The  light stays on until you select a different option.
Off	Turn off the  button so that all documents are printed on one side of the paper. <b>Note:</b> The  light stays off until you select a different option.





Select	To
Manual	<p>Duplex a print job manually. You must select this option when printing two-sided jobs that will be printed on a size or type of paper other than letter- or A4-size plain paper (such as greeting cards).</p> <p><b>Note:</b> You can select to print the two-sided pages so they turn like the pages of a magazine</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>( Side-Flip)</p> </div> <div style="text-align: center;">  <p>Top-Flip).</p> </div> </div> <p>( Side-Flip is the factory default setting.</p>

For more information, see “Printing on both sides of the paper (duplexing) automatically” on page 41 and “Printing on both sides of the paper (duplexing) manually” on page 41.

## ***Printing on both sides of the paper (duplexing) automatically***

The printer has a built-in duplex unit that lets you print on both sides of the paper automatically.

**Note:** Automatic two-sided printing (duplexing) works only with plain paper in letter and A4 sizes. If you want to print two-sided documents on another size or type of paper, use the manual duplexing method.

- 1 Press .
- 2 With a document open, click **File → Print**.
- 3 Click **Properties, Preferences, Options, or Setup**.
- 4 From the Duplexing area, select **Use Printer Settings** from the drop-down menu.
- 5 Make sure the  light is on.
- 6 Click **OK** to close any printer software dialogs that are open.

**Note:** To return to single-sided printing, make sure the  light is not on.


## ***Printing on both sides of the paper (duplexing) manually***

If you want to print a two-sided (duplex) job on a size or type of paper other than letter- or A4-size plain paper, you must use the manual duplex method. This method involves printing the odd-numbered pages, then flipping and reloading the stack of paper to print the even-numbered pages on the other side of the sheets.

- 1 With a document open, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click the **Print Layout** tab.
- 4 From the Duplexing area, select **Manual** from the drop-down box.
- 5 Select the **Print manual duplex instructions** check box.
- 6 The printer will print the odd-numbered pages and the instruction sheet, which describes how to flip and reload the paper.

**7** Following the instruction sheet, flip and reload the paper print side down.

**8** The printer will then print the even-numbered pages on the reverse sides of the odd-numbered pages, completing the two-sided copies.


**Note:** To activate the  button so that you can control two-sided printing using this button, return to the Duplexing drop-down box, and reset to the default setting, “Use Printer Settings.”

# Working with photos

## Retrieving and managing photos

### *Inserting a memory card*

- 1 Insert a memory card.
- Insert the card with the brand name label facing to the left.
  - If there is an arrow on the card, make sure it points toward the printer.
  - Make sure you connect the memory card to the adapter that came with it before inserting it into the slot.



Slots	Memory card
1	<ul style="list-style-type: none"><li>• xD-Picture Card</li><li>• Secure Digital</li><li>• Mini Secure Digital (with adapter)</li><li>• Micro Secure Digital (with adapter)</li><li>• MultiMedia Card</li><li>• Reduced Size MultiMedia Card (with adapter)</li><li>• Memory Stick</li><li>• Memory Stick PRO</li><li>• Memory Stick Duo (with adapter) or Memory Stick PRO Duo (with adapter)</li><li>• MultiMedia Card mobile (with adapter)</li></ul>
2	<ul style="list-style-type: none"><li>• Compact Flash Type I and Type II</li><li>• Microdrive</li></ul>

- 2 Wait for the light located above the memory card slots on the printer to come on. The light blinks to indicate the memory card is being read or is transmitting data.

**Warning:** Do not touch cables, any network adapter, the memory card, or the printer in the area shown while actively printing, reading, or writing from a memory card. A loss of data can occur. Also, do not remove a memory card while actively printing, reading, or writing from a memory card.




- 3 When the computer recognizes that a memory card is installed, the message **New photos have been found. What do you want to do?** appears.

If the printer does not read the memory card, remove and reinsert it. For more information, see “Memory card troubleshooting” on page 102.

**Note:** The computer recognizes one active memory card at a time from your printer. If you insert more than one memory card, a message appears on the display prompting you to remove the memory card that is not in use.

### ***Inserting a flash drive***

- 1 Insert the flash drive into the PictBridge port on the front of the printer.



**Note:** An adapter may be necessary if your flash drive does not fit directly into the port.

- 2 Wait for the computer to recognize that a flash drive is installed. When the flash drive is recognized, the message **New photos have been found. What do you want to do?** appears.

If the printer does not read the flash drive, remove and reinsert it.

**Warning:** Do not touch cables, any network adapter, the flash drive, or the printer in the area shown while actively printing, reading, or writing from the flash drive. A loss of data can occur. Also, do not remove the flash drive while actively printing, reading, or writing from the flash drive.



**Note:** The computer recognizes one active media device at a time from your printer. If you insert a memory card and a flash drive, a message appears on the display prompting you to designate the device you want the printer to recognize.

### ***Connecting a PictBridge-enabled digital camera***

PictBridge is a technology available in most digital cameras that lets you print directly from your digital camera without using a computer. You can connect a PictBridge-enabled digital camera to the printer, and use the buttons on the camera to control and print photos.

- 1 Insert one end of the USB cable into the camera.

**Note:** Use only the USB cable that came with your camera.

- 2 Insert the other end of the cable into the PictBridge port on the front of the printer.

**Notes:**

- Make sure the PictBridge-enabled digital camera is set to the correct USB mode. For more information, see the documentation that came with your camera.
- The printer recognizes one active media device at a time. Remove any memory cards from the printer when you connect the camera.

- 3 If the PictBridge connection is successful, the camera automatically switches to print mode, the **PictBridge** PictBridge symbol appears on the camera display, or a message recognizing the connection appears on the camera display, depending on your camera.

For more information, see the documentation that came with your camera.

### ***Transferring all photos from a memory card using the computer***

- 1 Insert a memory card into the printer with the label facing the printer control panel. If the computer is connected to a wireless network, you will need to select the printer.

**Note:** For a network connection, you must manually open the application and select the printer you want to use.

The Productivity Studio software launches automatically on your computer.

- 2 Click **Automatically save all photos to “My Pictures”**.

- 3 If you want to erase the photos from the memory card, click **Yes**.

**Note:** Make sure all the photos have been copied before you click **Yes** to erase.

- 4 Click **Done**. Remove the memory card to view your transferred photos in the Library.

## ***Transferring selected photos from a memory card using the computer***

- 1 Insert a memory card into the printer with the label facing the printer control panel.

The Productivity Studio software launches automatically on your computer.

**Note:** For a wireless network connection, you must first open the application and then select the printer you want to use.

- 2 Click **Select photos to save**.
- 3 Click **Deselect All**.
- 4 Click to select the photo(s) you want to transfer.
- 5 Click **Next**.
- 6 If you want to save the photos to the default folder, click **Next**.
- 7 If you want to save the photos in a folder other than the default folder:
  - a Click **Browse**.
  - b Select the folder you want.
  - c Click **OK**.
- 8 If you want to assign a prefix to all of the photos you just transferred, click the check box and enter a name.
- 9 Click **Next**.
- 10 If you want to erase the photos from the memory card, click **Yes**.

**Note:** Make sure all the photos have been copied before you select **Yes** to erase.
- 11 Click **Done**. Remove the memory card to view your transferred photos in the Photo Library.

## ***Transferring all photos from a CD or flash drive using the computer***

- 1 Insert a CD or a flash drive into the computer.
- 2 If you are using Windows Vista, an AutoPlay screen appears.

Click **Transfer photos to your computer**.
- 3 If you are using Windows XP, a “What do you want Windows to do?” screen appears.

Click **Copy pictures to a folder on my computer using Microsoft Scanner and Camera Wizard**.
- 4 If you are using Windows 2000:
  - a From the desktop, double-click the **Productivity Studio** icon.
  - b Click **Transfer Photos**.
- 5 Click **Automatically save all photos to “My Pictures”**.
- 6 Remove the flash drive or CD to view your transferred photos in the Library.

## ***Transferring selected photos from a CD or flash drive using the computer***

- 1 Insert a CD or a flash drive into the computer.
- 2 If you are using Windows Vista, an “AutoPlay” screen appears.

Click **Transfer Photos to your computer using the Productivity Studio**.

- 3 If you are using Windows XP, a “What do you want Windows to do?” screen appears.  
Click **Transfer Photos to your computer using the Productivity Studio**.  
If you are using Windows 2000:
  - a From the desktop, double-click the **Productivity Studio** icon.
  - b Click **Transfer Photos**.
- 4 Click **Select photos to save**.
- 5 Click **Deselect All**.
- 6 Click to select the photo(s) you want to transfer.
- 7 If you want to save the photos to the default folder, click **Next**.
- 8 If you want to save the photos in a folder other than the default folder:
  - a Click **Browse**.
  - b Select the folder you want.
  - c Click **OK**.
- 9 If you want to assign a prefix to all of the photos you just transferred, select the check box and enter a name.
- 10 Click **Next**.
- 11 Remove the CD or flash drive to view your transferred photos in the Library.

### ***Changing the Productivity Studio temporary files preferences***

- 1 From the desktop, double-click the **Productivity Studio** icon.
- 2 From the Tools menu, click **Preferences**.
- 3 Click **Temporary Files**.
  - a Use the slider to set the maximum disk space you want to allocate for temporary files created by the Productivity Studio.
  - b Click **Browse** to choose a different folder for saving the temporary files.
- 4 Click **OK**.

### ***Changing the Productivity Studio searched folders preferences***

- 1 From the desktop, double-click the **Productivity Studio** icon.
- 2 From the Tools menu, click **Preferences**.
- 3 Click **Searched Folders**.
- 4 If you want to exclude system folders when looking for photos, select **Ignore system folders**.
- 5 Click **OK**.

### ***Changing the Productivity Studio library preferences***

- 1 From the desktop, double-click the **Productivity Studio** icon.
- 2 From the Tools menu, click **Preferences**.

**3 Click Library.**

From here, you can choose how you want to sort photos. You can also set the minimum file size for the photo to appear in the library.

**4 Click OK.**

## ***Changing the Productivity Studio transfer settings***

**1** From the desktop, double-click the **Productivity Studio** icon.

**2** From the Tools menu, click **Preferences**.

**3** Click **Transfer Settings**.

- a** Select “**Skip Save option and go automatically to**”, and choose to Automatically Save, Manually Save, or Print your photos from the photo storage device connected to your computer.
- b** Click **Browse** to choose a different folder to transfer your photos to.
- c** Select “**Always erase photos from my media after transferring**” to automatically delete photos from your photo storage device after transferring them to your computer.

**4** Click **OK**.

## **Editing photos**

### ***Cropping a photo***

**1** From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.

**2** With an image open, click **Crop Photo** on the Quick Fixes tab.

**3** Click and drag with your mouse to select the section of the image that you want to crop. You can adjust the cropped area by using your mouse and dragging the lines to increase or decrease the cropped area.

**4** Click **Crop Now**.

**5** The cropped portion of the original image displays in the Preview pane. You can save the cropped image.

### ***Rotating a photo***

**1** From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.

**2** With an image open, click the **Quick Fixes** tab.

**3** Click **Rotate Left** or **Rotate Right** to rotate the image 90 degrees in either direction.

The thumbnail of the photo is updated.

### ***Changing the Resolution / Size of a photo***

*Resolution* refers to dpi (dots per inch).

**1** From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.

**2** With an image open, click **Advanced**.

**3** Click **Image Resolution / Size**.



- 4 Select **Photo Size** to select from a list of defined photo sizes, or click **Custom Size** to enter a different photo size.

**Note:** If you selected **Photo Size**, you can click **Rotate** to rotate your photo 90 degrees clockwise.

- 5 If you selected **Custom Size**, enter the width and height for your custom-size photo.

**Note:** **Maintain Aspect Ratio** is selected by default. This ensures that your image will remain proportional.

## ***Applying One-Click Auto Fixes to a photo***

From the Productivity Studio Welcome Screen, click the **Quick Fixes** tab to access all three One-Click Auto Fixes.

- 1 Click **File → Open** to select the image you want to edit.
- 2 With an image open, click **One-Click Auto Fix** to let the software automatically adjust the brightness and contrast of your image.
- 3 Click **Automatic Brightness** to adjust only the brightness of your image.
- 4 Click **Automatic Red-Eye Reduction** to let the software automatically reduce the appearance of red-eye in your image.

**Note:** Click **Undo** at the top of the window if you are not satisfied with the results after applying any of the One-Click Auto Fixes.

## ***Reducing the red-eye effect in a photo***

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click the **Quick Fixes** tab.
- 3 Click **Automatic Red-Eye Reduction** to let the software reduce the red-eye effect automatically. If you are not satisfied with the results, continue with the following steps.
- 4 Click **Manual Red-Eye Reduction**.
- 5 Move the cursor across the photo, and place it over an affected eye.
- 6 Click to reduce the red-eye effect.

## ***Blurring/Sharpening a photo***

Increasing the amount of blur will soften your image. Increasing the sharpness will make your image seem more focused.

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click the **Enhancements** tab.
- 3 Click **Blur / Sharpen**.
- 4 Use the slider to blur or sharpen the image. You can preview the changes to the image by comparing the **Before** and **After** preview panes at the top of the window.
- 5 Click **OK** to accept your changes, or click **Cancel** to reject them.

## ***Enhancing a photo***

The Enhance feature lets you make subtle adjustments to the brightness, contrast, and sharpness of an image.

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click the **Enhancements** tab.
- 3 Click **Enhance**.
- 4 Use the slider to adjust the Enhance setting. You can preview the changes to your image by comparing the **Before** and **After** preview panes at the top of the window.  
**Note:** Click **Automatic** to let the software automatically enhance your photo.
- 5 Click **OK** to accept your changes, or click **Cancel** to reject them.

## ***Changing the Hue / Saturation of a photo***

Adjusting hue lets you control the color of an image. Adjusting its saturation lets you control the intensity of the color.

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click the **Enhancements** tab.
- 3 Click **Hue / Saturation**.
- 4 Use the slider to adjust the hue or saturation of your photo. You can preview the changes to the image by comparing the **Before** and **After** preview panes at the top of the window.
- 5 Click **OK** to accept your changes, or click **Cancel** to reject them.

## ***Changing the Gamma Value of a photo or image***

Adjusting the gamma value helps you to control the overall brightness of an image—particularly those intended to be viewed on a computer monitor. When images are not properly gamma-corrected, they will look either too light or too dark.

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click **Advanced**.
- 3 Type a value in the text box, or use the up or down arrows to select a higher or lower gamma value.  
**Note:** You can enter gamma values from -10–10. If you are not satisfied with your changes, return the gamma value back to 0.
- 4 Click **Save** to keep your changes.

## ***Despeckling a photo***

Despeckling lets you remove specks that appear in your photo.

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click **Enhancements**.
- 3 Click **Despeckle**.
- 4 Using the slider, adjust the Despeckle setting. You can preview the changes to your image by comparing the **Before** and **After** preview panes at the top of the window.
- 5 Click **OK**. The thumbnail is updated.

## ***Changing the Brightness / Contrast settings of a photo***

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click **Enhancements**.
- 3 Click **Brightness / Contrast**.
- 4 Adjust the brightness and contrast settings. You can preview the changes to the image by comparing the **Before** and **After** preview panes at the top of the window.
- 5 Click **OK** to accept your changes, or click **Cancel** to reject them.

**Note:** You can let the software automatically adjust only the brightness of the image by clicking **Automatic Brightness** on the Quick Fixes tab.

## ***Applying a color effect to a photo***

- 1 From the Productivity Studio Welcome Screen, click **File → Open** to select the image you want to edit.
- 2 With an image open, click **Enhancements**.
- 3 Click **Color Effects**.
- 4 Apply a color effect.  
You can select sepia, antique brown, black and white, or antique grey.
- 5 Click **OK**.

## **Printing photos**

### ***Printing photos from a CD or removable storage device using the computer***

- 1 Load photo paper with the glossy or printable side facing you. (If you are not sure which side is the printable side, see the instructions that came with the paper.)
- 2 Insert a CD or any removable storage device (such as a flash drive, memory card, or digital camera) into the computer.
  - If you are using Windows Vista, an “AutoPlay” screen appears. Click **Transfer Photos to your computer using the Productivity Studio**.
  - If you are using Windows XP, a “What do you want Windows to do?” screen appears. Click **Transfer Photos to your computer using the Productivity Studio**.
  - If you are using Windows 2000:
    - a From the desktop, double-click the **Productivity Studio** icon.
    - b Click **Transfer Photos**.
- 3 Click **Select photos to print**.
- 4 To print all photos, click **Print**.
- 5 To print selected photos, click **Deselect All** and select only the photo(s) you want to print.
- 6 Click **Print**.
- 7 From the Quality drop-down list, select a print quality.
- 8 From the Paper Size in Printer drop-down list, select the paper size.

- 9 To select multiple prints of a photo, or to select photo sizes other than 10 x 15 cm (4 x 6 in.), select the options you want in the table. Use the drop-down list in the last column to view and select other sizes.

**Note:** If you want to edit your photo(s) before printing, click **Edit Photo** above the Print Preview pane. Select **One-Click Auto Fix**, **Automatic Red-Eye Reduction**, or **Automatic Brightness Fix** to let the software edit your photo(s) automatically. Click **More Retouch Tools** to go to the photo-editing window. When you've completed your edit(s), click **Return with edits** in the bottom right corner to return to the print window.

- 10 Click **Print Now** in the bottom right corner of the window.

- 11 Remove the CD or storage device.

## ***Viewing / Printing photos from the Productivity Studio***

- 1 From the desktop, double-click the **Productivity Studio** icon.
- 2 Click **Work with Documents and Photos**.
- 3 Click to select the photo(s) you want to print.
- 4 From the Productivity Studio taskbar located at the bottom of the screen, click **Photo Prints**.
- 5 From the Quality drop-down list, select a copy quality.
- 6 From the Paper Size in Printer drop-down list, select the paper size.
- 7 From the Paper Type in Printer drop-down list, select the paper type
- 8 To select multiple prints of a photo, or to select photo sizes other than 10 x 15 cm (4 x 6 in.), select the options you want in the table. Use the drop-down list in the last column to view and select other sizes.
- 9 Click **Print Now** in the bottom right corner of the screen.

## ***Printing Photo Packages***

- 1 From the desktop, double-click the **Productivity Studio** icon.
- 2 Click **Photo Packages**.
- 3 Click to select the photos you want to include in your photo package.
- 4 Click **Next**.
- 5 From the Quality drop-down list, select a copy quality.
- 6 From the Paper Size in Printer drop-down list, select the paper size.
- 7 To select multiple prints of a photo, or to select photo sizes other than 4 x 6 in. (10 x 15 cm), select the options you want in the table. Use the drop-down list in the last column to view and select other sizes.
- 8 Click **Print Now** in the bottom right corner of the screen.

## ***Creating Photo Greeting Cards***

- 1 From the desktop, double-click the **Productivity Studio** icon.
- 2 Click **Photo Greeting Cards**.
- 3 From the Style tab, click to select a style for your greeting card.
- 4 From the Photo tab, select and drag a photo into the preview pane on the right side of the screen.
- 5 Click the text area to be able to add text to your photo greeting card.

- 6 When you have finished editing your text, click **OK**.
- 7 If you want to create another photo greeting card using a different style and/or photo, click **Add New Card**, and repeat step 3 on page 52 through step 6 on page 53.
- 8 If you want to print your photo greeting card, select **Print your Photo Greeting Card** from the Share tab.
- 9 Select the number of copies from the Copies drop-down list.
- 10 Select the copy quality from the Quality drop-down list.
- 11 Select the paper size from the Paper Size in Printer drop-down list.

Paper sizes supported	Dimensions
A4	210 x 297 millimeters
Letter	8.5 x 11 inches
Greeting cards	4 x 8 inches (10.16 x 20.32 centimeters)

- 12 Click **Print Now**.
- 13 If you want to e-mail your photo greeting card, click **E-mail your Photo Greeting Card** from the Share tab.
- 14 From the Send Quality and Speed area of the screen, select the image size.
- 15 Click **Create E-mail** to create an e-mail message with your photo greeting card(s) attached.


### ***Printing all photos from a memory device***

- 1 Load photo paper with the glossy or printable side facing you. (If you are not sure which side is the printable side, see the instructions that came with the paper.)
- 2 Insert a memory card or flash drive that contains the images you want to print.  
The “Photos have been found. What do you want to do?” screen appears.
- 3 Click **Select photos to print**.  
The “Please select photos to print” screen appears.
- 4 Select any or all photos you want to print, and then click **Print**.  
The Productivity Studio software opens on your computer.
- 5 Change the print settings as necessary.  
You can select a print quality, the paper size in the printer, the paper type in the printer, and a print size for your photos.
- 6 Click **Print Now**.

## Using a PictBridge-enabled digital camera to control printing photos

You can connect a PictBridge-enabled digital camera to the printer, and use the buttons on the camera to control and print photos.



- 1 Insert one end of the USB cable into the camera.
- 2 Insert the other end of the cable into the PictBridge port on the front of the printer.



**Warning:** Do not touch the USB cable, any network adapter, or the printer in the area shown while actively printing from a PictBridge-enabled digital camera. A loss of data can occur. Also, do not remove the USB cable or network adapter while actively printing from a PictBridge-enabled digital camera.



### Notes:

- Make sure the PictBridge-enabled digital camera is set to the correct USB mode. For more information, see the documentation that came with your camera.
- The printer recognizes one active media device at a time. If you have a memory card already inserted when you connect a PictBridge-enabled digital camera, the  light and the  light blink alternately until the memory card is removed or the camera is unplugged.



- 3 If the PictBridge connection is successful, the camera automatically switches to print mode, the **PictBridge** PictBridge symbol appears on the camera display, or a message recognizing the connection appears on the camera display, depending on your camera.

For more information, see the documentation that came with your camera.

- 4 Follow the instructions in the documentation that came with your camera to select and print photos.

## ***Printing photos from a digital camera using DPOF***


If your camera supports Digital Print Order Format (DPOF), you can use the camera to specify which photos to print and how many of each. The printer recognizes these settings when you connect the camera to the printer or insert the memory card of the camera into the printer.

**Note:** If you specified a photo size in the camera, make sure the size of the paper loaded in the printer is not smaller than the size you specified in the DPOF selection.

- 1 Load photo paper with the glossy or printable side facing you. (If you are not sure which side is the printable side, see the instructions that came with the paper.)
- 2 Insert one end of the USB cable into the camera.
- 3 Insert the other end of the cable into the PictBridge port on the front of the printer.

### **Notes:**

- Make sure the PictBridge-enabled digital camera is set to the correct USB mode. For more information, see the documentation that came with your camera.
- The printer recognizes one active media device at a time. Make sure there is no memory card in the card slots.

- 4 If the PictBridge connection is successful, the camera automatically switches to print mode, the  PictBridge symbol appears on the camera display, or a message recognizing the connection appears on the camera display.

For more information, see the documentation that came with your camera.

- 5 Follow the instructions in the documentation that came with your camera to select and print photos.

**Note:** If no DPOF selections were specified in your camera beforehand, you can make the selections while the camera is connected to the printer. For more information, see the documentation that came with your camera.

## **Creating and viewing a slideshow**

- 1 From the Productivity Studio Welcome Screen, click **Work with Documents and Photos**.
- 2 Select the folder that contains the photos you want to include in the slideshow. Thumbnails of the photos in the folder will appear in a preview pane.
- 3 Click to select the photos you want to include in the slideshow, and then select **Slideshow**.

If you want additional photos to appear in specific order, click the photos in the order you want them to appear, and then drag them into the “Photos in Your Slideshow” area.

- 4 Click the **Slideshow Settings** tab to adjust the amount of time between each photo in the slideshow. You can also modify the setting that lets the slideshow replay automatically (loop).
- 5 Click the **Share** tab to save or print your slideshow.
- 6 Click **View Show** in the lower-right corner of the window to start the slideshow.


**Note:** You can exit the slideshow any time by moving your cursor to the bottom center of the screen and clicking **Exit Slideshow**.

# Maintaining the printer

---


## Installing print cartridges

- 1 Open the printer.
- 2 Remove the used print cartridge or cartridges.
- 3 If you are installing new print cartridges, remove the tape from the back and bottom of the black cartridge, and insert the cartridge in the left carrier.




**Warning:** Do *not* touch the gold contact area on the back or the metal nozzles on the bottom of the cartridge.

- 4 Close the black cartridge carrier lid.




- 5 Remove the tape from the back and bottom of the color cartridge, and insert the cartridge in the right carrier.




**Warning:** Do *not* touch the gold contact area on the back or the metal nozzles on the bottom of the cartridge.



- 6 Close the color cartridge carrier lid.



- 7 Close the printer.




**Note:** The printer must be closed to start a new print job.

- 8 Press .


## Removing a used print cartridge

- 1 Make sure the printer is on.
- 2 Lift the access cover.

The print cartridge carrier moves and stops at the loading position, unless the printer is busy.



- 3 Press down on the cartridge carrier latch to raise the cartridge carrier lid.



- 4 Remove the used print cartridge.

**Note:** If you are removing both cartridges, repeat step 3 and step 4 for the second cartridge.

## Using genuine Lexmark print cartridges

Lexmark printers, print cartridges, and photo paper are designed to perform together for superior print quality.

If you receive an **Out of Original Lexmark Ink** message, the original Lexmark ink in the indicated cartridge (s) has been depleted.

If you believe you purchased a new, genuine Lexmark print cartridge, but the **Out of Original Lexmark Ink** message appears:

- 1 Click **Learn More** on the message.
- 2 Click **Report a non-Lexmark print cartridge**.

To prevent the message from appearing again for the indicated cartridge(s):


- Replace your cartridge(s) with new Lexmark print cartridge(s).
- If you are printing from a computer, click **Learn more** on the message, select the check box, and click **Close**.
- If you are using the printer without a computer, press **Cancel**.

Lexmark's warranty does not cover damage caused by non-Lexmark ink or print cartridges.

## Refilling print cartridges


The warranty does not cover repair of failures or damage caused by a refilled cartridge. Lexmark does not recommend use of a refilled cartridge. Refilling a cartridge can affect print quality and may cause damage to the printer. For best results, use Lexmark supplies.

## Aligning the print cartridges

- 1 Load plain paper.
- 2 Do one of the following:
  - In Windows Vista, click .
  - In Windows XP and earlier, click **Start**.
- 3 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.
- 4 Click **Lexmark Solution Center**.
- 5 From the Maintenance tab, click **Align to fix blurry edges**.
- 6 Follow the instructions on the computer screen.

If you aligned the cartridges to improve print quality, print your document again. If print quality has not improved, clean the print cartridge nozzles.


## Cleaning the print cartridge nozzles

- 1 Load plain paper.
- 2 Do one of the following:
  - In Windows Vista, click .
  - In Windows XP and earlier, click **Start**.
- 3 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.
- 4 Click **Solution Center**.
- 5 From the Maintenance tab, click **Clean Print Nozzles**.


A page prints, forcing ink through the print cartridge nozzles to clean them.
- 6 To verify that the print quality has improved, print the document again.
- 7 If print quality has not improved, try cleaning the nozzles up to two more times.

## Wiping the print cartridge nozzles and contacts

- 1 Remove the print cartridges.
- 2 Dampen a clean, lint-free cloth with water, and place the cloth on a flat surface.
- 3 Gently hold the nozzles against the cloth for about three seconds, and then wipe in the direction shown.




- 4 Using another clean section of the cloth, gently hold the cloth against the contacts for about three seconds, and then wipe in the direction shown.



- 5 With another clean section of the cloth, repeat step 3 and step 4.
- 6 Let the nozzles and contacts dry completely.
- 7 Reinsert the print cartridges.
- 8 Print the document again.
- 9 If the print quality does not improve, clean the print nozzles. For more information, see “Cleaning the print cartridge nozzles” on page 59.
- 10 Repeat step 9 up to two more times.
- 11 If print quality is still not satisfactory, replace the print cartridges.

## Cleaning the exterior of the printer

- 1 Make sure that the printer is turned off and unplugged from the wall outlet.

 **CAUTION:** To avoid the risk of electric shock, unplug the power cord from the wall outlet and disconnect all cables to the printer before proceeding.

- 2 Remove paper from the paper support and paper exit tray.
- 3 Dampen a clean, lint-free cloth with water.  
**Warning:** Do not use household cleaners or detergents, as they may damage the finish of the printer.
- 4 Wipe only the outside of the printer, making sure to remove any ink residue that has accumulated on the paper exit tray.  
**Warning:** Using a damp cloth to clean the interior may cause damage to your printer.
- 5 Make sure the paper support and paper exit tray are dry before beginning a new print job.

## Preserving the print cartridges

- Keep new cartridges in their packaging until you are ready to install them.
- Do not remove a cartridge from the printer except to replace, clean, or store it in an airtight container. The cartridges do not print correctly if left exposed for an extended period of time.

## Ordering supplies

### Ordering print cartridges

Lexmark 1500 Series models

Item	Part number	Average cartridge standard page yield is up to <sup>1</sup>
Black cartridge	42A	220
Black cartridge <sup>2</sup>	42	220
High yield black cartridge	44	500
Color cartridge	41A	210
Color cartridge <sup>2</sup>	41	210
High yield color cartridge	43	350
Photo cartridge	40	Not applicable
<sup>1</sup> Values obtained by continuous printing. Declared yield value in accordance with ISO/IEC 24711.		
<sup>2</sup> Licensed Return Program Cartridge		

### Ordering paper and other supplies

To order supplies or to locate a dealer near you, visit our Web site at [www.lexmark.com](http://www.lexmark.com).

#### Notes:

- For best results, use only Lexmark print cartridges.
- For best results when printing photos or other high-quality images, use Lexmark Photo Paper or Lexmark Perfectfinish™ Photo Paper. Do *not* use Lexmark Premium Photo Paper. Your print cartridges are not compatible with this type of paper.
- To prevent smudging or scratching, avoid touching the printed surface with your fingers or sharp objects. For best results, remove each printed sheet individually from the paper exit tray, and allow the sheets to dry at least 24 hours before stacking, displaying, or storing.

Item	Part Number
USB cable	1021294
For more information, go to <a href="http://www.lexmark.com">www.lexmark.com</a> .	


Paper	Paper size
Lexmark Photo Paper	<ul style="list-style-type: none"> <li>• Letter</li> <li>• A4</li> <li>• 4 x 6 in.</li> <li>• 10 x 15 cm</li> </ul>
Lexmark PerfectFinish Photo Paper	<ul style="list-style-type: none"> <li>• Letter</li> <li>• A4</li> <li>• 4 x 6 in.</li> <li>• 10 x 15 cm</li> <li>• L</li> </ul>
<b>Note:</b> Availability may vary by country or region.	

For information on how to purchase Lexmark Photo Paper or Lexmark PerfectFinish Photo Paper in your country or region, go to **[www.lexmark.com](http://www.lexmark.com)**.

# Troubleshooting

---

If you set up your printer on a wireless network, make sure:


- The wireless network is working properly.
- The computer and printer are both connected to the same wireless network.
- The printer is within the range of the wireless network. The effective range for optimal performance is generally 100–150 feet.
- The printer is located away from other electronic devices that may interfere with the wireless signal.
- The power supply is connected to the printer, and  is lit.
- The Wi-Fi indicator light is green.
- The printer driver is installed on the computer from which you are performing a task.
- The correct printer port is selected.

## Setup Troubleshooting

### ***Power button is not lit***


These are possible solutions. Try one or more of the following:



#### **Press power button**

Make sure the printer is on by pressing .

#### **Disconnect and reconnect the power cord**



- 1 Disconnect the power cord from the wall outlet, and then from the printer.
- 2 Plug the cord all the way into the power supply on the printer.



- 3 Plug the cord into an electrical outlet that other electrical devices have been using.
- 4 If the  light is not on, press .

## ***Power light is blinking***

The power light blinks when it detects errors in the printer.

**Note:** If the  light and the  light blink alternately, see “Power light and duplex light are blinking alternately” on page 64.

These are possible solutions. Try one or more of the following:

### **Check print cartridges**

Make sure there is a cartridge installed in the printer. If you are using a photo cartridge, make sure there is also a color cartridge installed.

If a cartridge is missing, install the missing cartridge.

### **Check the ink level of the color print cartridge**

The color cartridge may be low on ink or out of ink. Check the ink level of the color cartridge. For more information, see “Checking the print cartridges” on page 84.

If the color ink level is low, replace the color cartridge with a new one. To order a new cartridge, see “Ordering print cartridges” on page 61.



### **Load paper**

The printer is out of paper. Load more paper to continue printing. For more information, see “Loading paper” on page 28.

### **Clear the paper jam**

Check to see if the paper jam is in the paper support or in the duplex unit, and then remove the paper jam. For more information, see “Jams and misfeeds troubleshooting” on page 97.



## ***Duplex light is blinking***

**Note:** If the  light and the  light blink alternately, see “Power light and duplex light are blinking alternately” on page 64.

The black cartridge may be low on ink or out of ink. Check the ink level of the black cartridge. For more information, see “Checking the print cartridges” on page 84.

If the black ink level is low, replace the black cartridge with a new one. To order a new cartridge, see “Ordering print cartridges” on page 61.

## **Power light and duplex light are blinking alternately**

The  light and the  light blink alternately when the printer detects errors in the memory card slots or in the PictBridge port.

These are possible solutions. Try one or more of the following:

### **Remove extra memory devices**



The printer recognizes one active media device at a time. Do not insert two memory cards at one time, a flash drive and a memory card at one time, or a PictBridge-enabled digital camera and a memory card at one time.

### **Make sure your camera is a PictBridge-enabled digital camera**

Check to see if your camera is a PictBridge-enabled digital camera. For more information, see the documentation that came with your camera.



## Enable PictBridge printing from the camera

Enable PictBridge printing on the camera by selecting the correct USB mode. If the camera USB selection is incorrect, the camera is detected as a USB storage device, or the  light and  light blink alternately. For more information, see the documentation that came with your camera.

## Make sure you inserted a valid device into the PictBridge port

Only the following devices are recognized by the PictBridge port:

- PictBridge-enabled digital camera
- Flash drive

Any other USB devices are not recognized.

## Make sure the paper size setting on the camera is supported by the printer

Use only the following paper sizes when printing photos from your camera:

- 3.5 x 5 inches
- 4 x 6 inches
- 4 x 8 inches
- 5 x 7 inches
- 10 x 20 inches
- Letter (8.5 x 11 inches)
- A6 (105 x 148 mm)
- A5 (148 x 210 mm)
- A4 (210 x 297 mm)
- L (89 x 127 mm)
- 2L (127 x 178 mm)
- Hagaki card (100 x 148 mm)
- 10 x 15 cm
- 13 x 18 cm

To view or change the print size settings on your camera, see the documentation that came with your camera.

## Make sure the printer is properly communicating with the camera



If the PictBridge connection is successful, the camera automatically switches to print mode, the **PictBridge** PictBridge symbol appears on the camera display, or a message recognizing the connection appears on the camera display, depending on your camera.

If the PictBridge connection is unsuccessful, try one or more of the following:

- Make sure you are using the USB cable that came with your camera.
- Make sure the USB cable that you are using is not damaged.

If the error occurs after the printer has successfully connected with the camera, try one or more of the following:

- Disconnect the camera, and then connect it again.
- If the lights keep on blinking, check for error messages on the camera display, and then see the documentation that came with your camera.

## ***Software does not install***

These are possible solutions. Try one or more of the following:

### **Check your operating system**

The following operating systems are supported: Windows Vista, Windows XP, Windows 2000 with Service Pack 3 or later, and Mac OS X.

### **Check your system requirements**

Check that your computer meets the minimum system requirements listed on the printer box.

### **Check USB connection**

If the printer is connected to the computer through a USB cable:



- 1 Check the USB cable for any obvious damage.
- 2 Firmly plug the square end of the USB cable into the back of the printer.
- 3 Firmly plug the rectangular end of the USB cable into the USB port of the computer.

The USB port is marked with the  USB symbol.

### **Check wireless connection**

If the printer supports networking, and you are using the printer on a wireless network, check to see if the Wi-Fi indicator light is on.

### **Reconnect power supply**

- 1 Press  to turn the printer off.
- 2 Disconnect the power cord from the wall outlet.
- 3 Gently remove the power supply from the printer.
- 4 Reconnect the power supply to the printer.
- 5 Plug the power cord into the wall outlet.
- 6 Press  to turn the printer on.

### **Disable anti-virus programs (for Windows users only)**

- 1 Close all open software applications.
- 2 Disable any anti-virus programs.
- 3 Double-click the **My Computer** icon.

In Windows XP, click **Start** to access the My Computer icon.

- 4 Double-click the **CD-ROM drive** icon.
- 5 If necessary, double-click **setup.exe**.
- 6 Follow the instructions on the computer screen to install the software.

**Note:** You may enable the anti-virus programs again after the software is successfully installed.

## Uninstall and reinstall software

Uninstall the printer software, and then reinstall it.

## ***Page does not print***

These are possible solutions. Try one or more of the following:

### **Check messages**

If an error message is displayed, see “Error messages on the computer screen” on page 104.

### **Check power**

If the  light is not on, see “Power button is not lit” on page 63.

### **Reload paper**


Remove and then load paper.

### **Check ink**

Check the ink levels, and install new print cartridges if necessary.


### **Check cartridges**

- 1 Remove the print cartridges.
- 2 Make sure the sticker and tape have been removed.





- 3 Reinsert the cartridges.

### **Check printer default and pause settings**

- 1 Click:
  - In Windows Vista:  → **Control Panel** → **Printers** (under Hardware and Sound).
  - In Windows XP: **Start** → **Printers and Faxes**.
  - In Windows 2000: **Start** → **Settings** → **Printers**.
- 2 Double-click the printer queue device.
- 3 Click **Printer**.
  - Make sure no check mark appears next to Pause Printing.
  - If a check mark does not appear next to Set As Default Printer, you must select the print queue device for each file you want to print.

### **Reconnect power supply**

- 1 Press  to turn the printer off.
- 2 Disconnect the power cord from the wall outlet.
- 3 Gently remove the power supply from the printer.

- 4 Reconnect the power supply to the printer.
- 5 Plug the power cord into the wall outlet.
- 6 Press  to turn the printer on.

## **Removing and reinstalling the software**

Uninstall the printer software, and then reinstall it. For more information, see “Removing and reinstalling the software” on page 68.

## ***Solving printer communication problems***

The printer and the computer cannot exchange data.


These are possible solutions. Try one or more of the following:

### **Establish bidirectional communication between the printer and the computer**

For more information, see “Bidirectional communication is not established” on page 95.

### **Make sure the printer is not in sleep mode**

If the power light is blinking on and off slowly, the printer is in sleep mode.

- 1 Unplug the power cable from the wall outlet.
- 2 Wait ten seconds, and then insert the power cable into the wall outlet.
- 3 Press  to turn the printer on.


## ***Understanding Warning levels***

- A green check indicates system requirements were met.
- A yellow question mark indicates system requirements were not met. Most major functions will work, but you may experience some performance impact.
- A red question mark indicates system requirements were not met. Most major functions may not work.
- A red X indicates system requirements were not met. Installation will not continue.

For proper installation, make sure the computer supports all system requirements. System requirements are located on the printer box.

## ***Removing and reinstalling the software***

If the printer is not functioning properly, or if a communications error message appears when you try to use the printer, you may need to remove and reinstall the printer software.

- 1 In Windows Vista, click . In Windows XP or earlier, click **Start**.
- 2 Click **Programs** or **All Programs → Lexmark 1500 Series**.
- 3 Select **Uninstall**.
- 4 Follow the instructions on the computer screen to remove the printer software.
- 5 Restart the computer before reinstalling the printer software.

6 Click **Cancel** on all New Hardware Found screens.

7 Insert the CD, and then follow the instructions on the computer screen to reinstall the software.

**Note:** If the install screen does not appear automatically after you restart your computer, click **Start → Run**, and then type **D:\setup**, where **D** is the letter of your CD-ROM drive.

If the software still does not install correctly, visit our Web site at **www.lexmark.com** to check for the latest software.

1 In all countries or regions except the United States, select your country or region.

2 Click the links for drivers or downloads.

3 Select your printer family.

4 Select your printer model.

5 Select your operating system.

6 Select the file you want to download, and then follow the directions on the computer screen.

## ***Enabling the USB port***

To confirm that the USB port is enabled on the computer:

1 In Windows Vista, click  → **Control Panel**.

In Windows XP, click **Start → Control Panel**.

In Windows 2000, click **Start → Settings → Control Panel**.

2 If you are using Windows Vista, click the **System and Maintenance** icon, and then click **Device Manager**.

If you are using Windows XP or Windows 2000:

a Click **Performance and Maintenance**, and then click the **System** icon.

b Click the **Hardware** tab.

c Click **Device Manager**.

3 Click the plus sign (+) beside **Universal Serial Bus Controller**.

If USB Host Controller and USB Root Hub are listed, the USB port is enabled.

Did you find the problem?

### **Yes**

If USB Host Controller and USB Root Hub are *not* listed, the USB port is *not* enabled. For more information, see the computer documentation.

### **No**

Contact the Customer Support Center.

1 Click **Programs** or **All Programs → Lexmark 1500 Series**.

2 Click **Solution Center**.

3 Click the **Contact Information** tab.

## **Wireless troubleshooting**

### ***How do I find out what type of security my network is using?***

You must know the security key and security mode in order to properly set up the printer for use on the wireless network. To obtain this information, see the documentation that came with your wireless router, see the Web page associated with the router, or consult the person who set up your wireless network.

## ***Wi-Fi indicator light is orange***

These are possible solutions. Try one or more of the following:

### **Check cable**

Make sure the installation cable is not connected to the printer.

### **Configure the optional internal wireless print server**

**Note:** This solution does not apply to printers that have a pre-installed internal wireless print server.

If you purchased the optional internal wireless print server after your printer was already set up, see “Configuring the optional internal wireless print server” in the “Setting up the printer” chapter.

### **Check network name**

Make sure your network does not have the same name as another network near you. For example, if you and your neighbor both use a manufacturer's default network name, your printer could be connecting to your neighbor's network.

If you are not using a unique network name, consult the documentation for your wireless access point (wireless router) to learn how to set a network name.

If you set a new network name, you must reset the printer and computer SSID to the same network name.

For more information, see “Checking your network name” in the “Wireless troubleshooting” section.

### **Check security keys**

Make sure security keys are correct. For more information, see “Check your security keys” on page 74.

### **Move your computer and/or printer**

Move the computer and/or printer closer to the wireless access point (wireless router). Although the possible distance between devices in 802.11b or 802.11g networks is 300 feet, the effective range for optimal performance is generally 100–150 feet.

You can find the signal strength of the network on the network setup page. For information on how to print a setup page, see “Printing a network setup page” on page 23.

### **Check MAC address**

If your network uses MAC address filtering, provide the MAC address for the printer to your network. If you need help finding the MAC address, see “Finding the MAC address” on page 22.

## ***Wi-Fi indicator light is blinking orange during installation***

When the Wi-Fi indicator light is blinking orange, it indicates that the printer has been set up for wireless networking but cannot connect to the network for which it has been configured. The printer may be unable to join the network because of interference or its distance from the wireless access point (wireless router), or until its settings are changed.

These are possible solutions. Try one or more of the following:

### **Make sure the access point is on**

Check the access point and, if necessary, turn it on.

## Move your wireless access point (wireless router) to minimize interference

There may be temporary interference from other devices such as microwave ovens or other appliances, cordless phones, baby monitors, and security system cameras. Make sure your wireless access point (wireless router) is not positioned too closely to these devices.

## Try adjusting external antennas

Generally, antennas work best if they are pointing straight up. You may find, however, that reception improves if you experiment with different angles for your printer and/or wireless access point (wireless router) antennas.

## Move your computer and/or printer

Move the computer and/or printer closer to the wireless access point (wireless router). Although the possible distance between devices in 802.11b or 802.11g networks is 300 feet, the effective range for optimal performance is generally 100–150 feet.

You can find the signal strength of the network on the network setup page. For information on how to print a setup page, see “Printing a network setup page” on page 23.



## Check security keys

Make sure security keys are correct. For more information, see “Check your security keys” on page 74.

## Check MAC address

If your network uses MAC address filtering, provide the MAC address for the printer to your network. If you need help finding the MAC address, see “Finding the MAC address” on page 22.

## Ping the wireless access point (wireless router) to make sure the network is working


- 1 If you do not already know it, find the IP address of the access point.
  - a Click:
    - In Windows Vista:  → **All Programs → Accessories → Command Prompt.**
    - In Windows XP and earlier: **Start → Programs or All Programs → Accessories → Command Prompt.**
  - b Type **ipconfig**.
  - c Press **Enter**.
    - The “Default Gateway” entry is typically the wireless access point (wireless router).
    - The IP address appears as four sets of numbers separated by periods, such as 192.168.0.100. Your IP address might also start with the numbers 10 or 169. This is determined by your operating system or wireless network software.
- 2 Ping the wireless access point (wireless router).
  - a Click:
    - In Windows Vista:  → **All Programs → Accessories → Command Prompt.**
    - In Windows XP and earlier: **Start → Programs or All Programs → Accessories → Command Prompt.**
  - b Type **ping** followed by a space and the IP address of the wireless access point (wireless router). For example:  

```
ping 192.168.0.100
```
  - c Press **Enter**.

- 3 If the wireless access point (wireless router) responds, you will see several lines appear that start with “Reply from”. Turn off and restart the printer.
- 4 If the wireless access point (wireless router) does not respond, it will take several seconds and then you will see “Request timed out.”

Try the following:

**a** Click:

- In Windows Vista:  → **Control Panel** → **Network and Internet** → **Network and Sharing Center**
- In Windows XP and earlier: **Start** → **Settings** or **Control Panel** → **Network Connection**

**b** Select the appropriate connection from the ones shown.

**Note:** If the computer is connected to the access point (router) by an Ethernet cable, the connection may not include the word “wireless” in its name.

**c** Right-click the connection, and then click **Repair**.


## Run the wireless setup again

If your wireless settings have changed, you must run the printer wireless setup again. Some reasons your settings may have changed include your having manually changed your WEP or WPA keys, channel, or other network settings; or the wireless access point (wireless router) having been reset to factory defaults.

### Notes:

- If you change network settings, change them on all the network devices before changing them for the wireless access point (wireless router).
- If you have already changed the wireless network settings on your wireless access point (wireless router), you must change the settings on all the other network devices before you can see them on the network.

**1** Click:

- In Windows Vista: .
- In Windows XP and earlier: **Start**.

**2** Click **Programs** or **All Programs** → **Lexmark 1500 Series**.

**3** Click **Wireless Setup**.

**Note:** You may be prompted to connect the printer to the computer again using the installation cable as part of the setup process.

**4** Follow the instructions on the computer screen.

## ***Wi-Fi indicator light is not lit***

### **Check power**

If the  light is not on, see “Power button is not lit” on page 63.




## Remove and reinstall the internal print server


- 1 Turn off your printer, and then unplug the power cord from the wall outlet.

**Warning:** Failure to unplug the printer can cause damage to your printer and to the internal wireless print server. Make sure the printer is turned off and the power cord is unplugged from the wall outlet before you proceed.

- 2 While holding the printer firmly with one hand, hold the internal print server with your other hand and then pull it away from the printer.



### 3 Reinstall the internal print server.



**Warning:** Wireless print servers are easily damaged by static electricity. Touch something metal such as the printer frame before you touch the wireless print server.

### ***Check your security keys***

A security key is like a password. All devices on the same network share the same security key.

**Note:** Make sure you copy down the security key exactly, including any capital letters, and store it in a safe place for future reference.

The security key must follow the following criteria.

#### **WEP key**


- Exactly 10 or 26 hexadecimal characters. Hexadecimal characters are A–F and 0–9.
- Exactly 5 or 13 ASCII characters. ASCII characters are letters, numbers, and symbols found on a keyboard.

#### **WPA-PSK or WPA2-PSK key**

- Up to 64 hexadecimal characters. Hexadecimal characters are A–F and 0–9.
- Between 8 and 64 ASCII characters. ASCII characters are letters, numbers, and symbols found on a keyboard.

### ***Printer is configured correctly, but cannot be found on the network***


Make sure:

- The printer has power and the  light is on.
- The printer is within range of the wireless network.
- The printer is located away from other electronic devices that may interfere with the wireless signal.
- Your wireless network is using a unique network name (SSID). If not, it is possible that the printer/print server is communicating over a different, nearby network that uses the same network name.
- The printer has a valid IP address on the network.

## ***Wireless network printer does not print***

These are possible solutions. Try one or more of the following:

### **Check power**

Make sure the  light is on.

### **Check cable**

- Make sure the power cable is connected to the printer and to the electrical outlet.
- Make sure the USB cable or the installation cable is not connected.


### **Check Wi-Fi indicator light**

Make sure the Wi-Fi indicator light is green. If it is not green, see “Wi-Fi indicator light is orange” or “Wi-Fi indicator light is blinking orange during installation” in “Wireless troubleshooting.”

### **Check if printer driver is installed**

Make sure the printer driver is installed on the computer from which you are sending the print job.

1 Do one of the following:

- In Windows Vista, click:  → **Control Panel → Printers**.
- In Windows XP, click: **Start → Settings → Printers and Faxes**.
- In Windows 2000 and earlier, click: **Start → Settings → Printers**.

If you cannot find the icon for your printer, then the printer driver is not installed.

2 If the printer driver is not installed, insert the installation software CD into your computer.

3 Follow the instructions on the computer screen.

**Note:** You must install the printer driver on each computer that uses the network printer.

### **Check if printer is connected to the wireless network**

- 1 Print a network setup page. For more information, see “Printing a network setup page.”
- 2 Check to see if “Status: Connected” appears under Network Card.


### **Reboot the computer**

Turn off and restart the computer.

### **Check printer ports**

Make sure the correct printer port is selected.

1 Click:

- In Windows Vista:  → **Control Panel → Printers**.
- In Windows XP: **Start → Settings → Printers and Faxes**.
- In Windows 2000 and earlier: **Start → Settings → Printers**.

2 Right-click the **Lexmark 1500 Series** icon.

3 Click **Properties → Ports**.

- 4 Verify that **XXXX\_Series\_nnnnnn\_P1** is selected, where XXXX is the model series number of your printer and nnnnnn is the last six numbers of the MAC address of your printer.

**Note:** The MAC address is located at the back of the printer beside the serial number.

- 5 If **USB** is selected instead:

- a Select the port name from step 4.
- b Click **Apply**.
- c Close the window, and try printing again.

## Reinstall software

Uninstall and then reinstall the printer software.

**Note:** If more than one printer appears in the "Select your printer" list, pick the printer with the MAC address that matches the address on the back of your printer.

## *Wireless printer is no longer working*

These are possible solutions. Try one or more of the following:

### Check power

- Make sure the printer power light is on. For more information, see "Power button is not lit" in the "Troubleshooting" chapter.
- Make sure the wireless access point (wireless router) is on.

## Move your wireless access point (wireless router) to minimize interference

There may be temporary interference from other devices such as microwaves or other appliances, cordless phones, baby monitors, and security system cameras. Make sure your wireless access point (wireless router) is not positioned too closely to these devices.

## Move your computer and/or printer

Move the computer and/or printer closer to the wireless access point (wireless router). Although the possible distance between devices in 802.11b or 802.11g networks is 300 feet, the effective range for optimal performance is generally 100–150 feet.

You can find the signal strength of the network on the network setup page. For more information, see "Printing a network setup page" in the "Networking" chapter.

## Try adjusting external antennas

Generally, antennas work best if they are pointing straight up. You may find, however, that reception improves if you experiment with different angles for your printer and/or wireless access point (wireless router) antennas.

## Check network name

The network name, or SSID (Service Set Identifier) is a setting on a wireless device that allows devices to join the same wireless network.

For more information, see "Checking your network name" for Windows or Mac in the "Wireless troubleshooting" section.

## Reboot the computer

Turn off and restart the computer.

## Ping the wireless access point

Ping the wireless access point (wireless router) to make sure the network is working.

For more information, see “Ping the access point” for Windows or Mac in the “Wireless troubleshooting” section

## Ping the printer

Ping the printer to make sure it is on the network.

For more information, see “Ping the printer” for Windows or Mac in the “Wireless troubleshooting” section.

## Run the wireless setup again

If your wireless settings have changed, you will need to run the printer wireless setup again. Some reasons your settings may have changed include your having manually changed your WEP or WPA keys, channel, or other network settings, or the wireless access point (wireless router) having been reset to factory defaults.

### Notes:






- If you change network settings, change them on all the network devices before changing them for the wireless access point (wireless router).
- If you have already changed the wireless network settings on your wireless access point (wireless router), you must change the settings on all the other network devices before you can see them on the network.

For more information, see “Run the Wireless Setup Utility” for Windows or “Run the Wireless Setup Assistant” for Mac.

## *Changing wireless settings after installation*

To change your password, network name, or other wireless setting, rerun the wireless setup. For more information, see “Run the Wireless Setup Utility” for Windows or the “Run the Wireless Setup Assistant” for Mac.

## *Resetting an internal wireless print server to factory default settings*

- 1 Make sure the printer is turned off.
- 2 Open the access cover and leave it open.
- 3 Press and hold .
- 4 While holding , press .
- 5 Wait for the printer to turn on, and then release .
- 6 Close the access cover.
- 7 Wait for the  light to stop blinking.

The internal wireless print server is reset to factory default settings. To verify, print a network setup page.

## ***Network printer does not show up in the printer selection list during installation***

### **Check whether the printer is on the same wireless network as the computer**


The SSID of the printer must match the SSID of the wireless network.

- 1 If you do not know the SSID of the network, use the following steps to obtain it before rerunning the Wireless Setup Utility.

- a Enter the IP address of your wireless access point (wireless router) into the Web address field of your browser.

If you do not know the IP address of the wireless access point (wireless router):

- 1 Do one of the following:

- In Windows Vista, click  → **All Programs → Accessories → Command Prompt**.
- In Windows XP, click **Start → Programs** or **All Programs → Accessories → Command Prompt**.

- 2 Type **ipconfig**.

- 3 Press **Enter**.

- The “Default Gateway” entry is typically the wireless access point (wireless router).
- The IP address appears as four sets of numbers separated by periods, such as 192.168.0.100.

- b Enter your user name and password when prompted.

- c Click **OK**.

- d On the main page, click **Wireless** or any other selection where settings are stored. The SSID will be displayed.

- e Write down the SSID, security type, and the security keys if they are shown.

**Note:** Make sure you copy them down exactly, including any capital letters.

- 2 Click **Programs** or **All Programs → Lexmark 1500 Series**.

- 3 Click **Wireless Setup**.

**Note:** You may be prompted to connect the printer to the computer again using the installation cable as part of the setup process.


- 4 Follow the instructions on the computer screen, including typing in the SSID of the wireless access point (wireless router) and the security keys when prompted.

- 5 Store the SSID and the security keys in a safe place for future reference.


## ***Wireless Setup Utility cannot communicate with the printer during installation (Windows users only)***

These are possible solutions for Windows users. Try one or more of the following:

### **Check power**

If the  light is not on, see “Power button is not lit” on page 63.

## Check the installation cable

- 1 Disconnect the installation cable and check it for any obvious damage.
- 2 Firmly plug the rectangular end of the USB cable into the USB port of the computer.  
The USB port is marked with the  USB symbol.
- 3 Firmly plug the square end of the USB cable into the USB port on the back of the printer.
- 4 Cancel the software installation.
- 5 Click **Programs** or **All Programs → Lexmark 1500 Series**.
- 6 Click **Wireless Setup Utility**.
- 7 Follow the prompts on the computer screen to reinstall the software.

## Checking your network name (Windows users only)



Make sure your network does not have the same name as another network near you. For example, if you and your neighbor both use a manufacturer's default network name, your printer could be connecting to your neighbor's network.

If you are not using a unique network name, consult the documentation for your wireless access point (wireless router) to learn how to set a network name.


If you set a new network name, you must reset the printer and computer SSID to the same network name.

- To reset the computer network name, see the documentation that came with your computer.
- To reset the printer name:
  - 1 Click **Programs** or **All Programs → Lexmark 1500 Series**.
  - 2 Click **Wireless Setup Utility**.
  - 3 Follow the instructions on the computer screen, and enter the new network name when prompted.

## Ping the access point



- 1 If you do not already know it, find the IP address of the wireless access point (wireless router).
  - a Do one of the following:
    - In Windows Vista, click  → **All Programs → Accessories → Command Prompt**.
    - In Windows XP, click **Start → Programs or All Programs → Accessories → Command Prompt**.
  - b Type **ipconfig**.
  - c Press **Enter**.
    - The "Default Gateway" entry is typically the wireless access point (wireless router).
    - The IP address appears as four sets of numbers separated by periods, such as 192.168.0.100.
- 2 Ping the wireless access point (wireless router).
  - a Do one of the following:
    - In Windows Vista, click  → **All Programs → Accessories → Command Prompt**.
    - In Windows XP, click **Start → Programs or All Programs → Accessories → Command Prompt**.
  - b Type **ping** followed by a space and the IP address of the wireless access point (wireless router). For example:  

```
ping 192.168.0.100
```
  - c Press **Enter**.

- 3 If the wireless access point (wireless router) responds, you will see several lines appear that start with “Reply from”. Turn off and restart the printer.
- 4 If the wireless access point (wireless router) does not respond, after several seconds you will see “Request timed out.”
  - a Do one of the following:
    - In Windows Vista, click the  → **Control Panel** → **Network and Internet** → **Network and Sharing Center**.
    - In Windows XP, click **Start** → **Settings** or **Control Panel** → **Network Connection**.
  - b Select the appropriate connection from the ones shown.

**Note:** If the computer is connected to the access point (router) by an Ethernet cable, the connection may not include the word “wireless” in its name.
  - c Right-click the connection, and then click **Repair**.

## ***Ping the printer***

- 1 Do one of the following:
  - In Windows Vista, click  → **All Programs** → **Accessories** → **Command Prompt**.
  - In Windows XP, click **Start** → **Programs** or **All Programs** → **Accessories** → **Command Prompt**.
- 2 Type **ping** followed by the IP address of the printer. For example,  
`ping 192.168.0.25`
- 3 Press **Enter**.
- 4 If the printer responds, you will see several lines appear that start with “Reply from”.  
Turn off and restart the printer, and then try resending your print job.
- 5 If the printer does not respond, you will see “Request timed out.”
  - a Check that the computer has a wireless IP address.
    - 1 Do one of the following:
      - In Windows Vista, click  → **All Programs** → **Accessories** → **Command Prompt**.
      - In Windows XP, click **Start** → **Programs** or **All Programs** → **Accessories** → **Command Prompt**.
    - 2 Type **ipconfig**.
    - 3 Press **Enter**.
    - 4 Check the Windows IP Configuration screen that appears for the wireless IP address of the computer.

**Note:** Your computer may have an IP address for a wired network, a wireless network, or both.
    - 5 If your computer does not have an IP address, see the documentation that came with your wireless access point (wireless router) to learn how to connect your computer to the wireless network.
  - b The printer may need to be reconfigured for new wireless network settings. For more information, see “Run the Wireless Setup Utility”.

## ***Run the Wireless Setup Utility (Windows users only)***

- 1 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.
- 2 Click **Wireless Setup Utility**.

**Note:** You may be prompted to connect the printer to the computer again using the installation cable as part of the setup process.



- 3 Follow the instructions on the computer screen.

## ***Changing wireless settings after installation (Windows users only)***

To change your password, network name, or other wireless setting:

- 1 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.

- 2 Click **Wireless Setup Utility**.

**Note:** You may be prompted to connect the printer to the computer again using the installation cable as part of the setup process.

- 3 Follow the prompts on the computer screen to reinstall the software, and make the changes you want.

## ***Check printer ports (Windows users only)***

Make sure the correct printer port is selected.

- 1 Click **Start** → **Control Panel** → **Printers**.

- 2 Right-click **Lexmark XXXX**, where XXXX is the model series number of your printer.

- 3 Click **Properties** → **Ports**.

- 4 Verify that **XXXX\_Series\_nnnnnn\_P1** is selected, where XXXX is the model series number of your printer and nnnnnn is the last six numbers of the MAC address of your printer.

**Note:** The MAC address is located at the back of the printer beside the serial number.

- 5 If **USB** is selected instead:

- a Select the port name from step 4.
- b Click **Apply**.
- c Close the window, and try printing again.

## **Print troubleshooting**

### ***Partial document or photo prints***

Make sure the paper size being used matches the document or photo size you selected.

### ***Improving print quality***

These are possible solutions. Try one or more of the following:

#### **Check paper**

- Use the appropriate paper for the document. If you are printing photos or other high-quality images, for best results use Lexmark Photo Paper or Lexmark PerfectFinish Photo Paper. Do *not* use Lexmark Premium Photo Paper. Your print cartridges are not compatible with this type of paper.
- Use a paper that is a heavier weight or bright white.

## Check print cartridges

If the document still does not have the print quality you want, follow these steps:

- 1** Align the print cartridges. For more information, see “Aligning the print cartridges” on page 59.  
If print quality has not improved, continue to step 2.
- 2** Clean the print cartridge nozzles. For more information, see “Cleaning the print cartridge nozzles” on page 59.  
If print quality has not improved, continue to step 3.
- 3** Remove and reinsert the print cartridges. For more information, see “Removing a used print cartridge” on page 57 and “Installing print cartridges” on page 56.  
If print quality has not improved, continue to step 4.
- 4** Wipe the print nozzles and contacts. For more information, see “Wiping the print cartridge nozzles and contacts” on page 59.  
If print quality is still not satisfactory, replace the print cartridges. For more information, see “Ordering print cartridges” on page 61.

## Poor text and graphic quality

- Blank pages
- Dark print
- Faded print
- Incorrect colors
- Light and dark bands in print
- Skewed lines
- Smudges
- Streaks
- White lines in print

These are possible solutions. Try one or more of the following:

### Check ink

Check the ink levels, and install new print cartridges if necessary.

### Remove sheets as they are printed

To avoid ink smudging when you are working with the following media, remove each sheet as it exits, and allow it to dry:

- Documents with graphics or images
- Photo paper
- Heavyweight matte or glossy paper
- Transparencies
- Labels
- Envelopes
- Iron-on transfers

**Note:** Transparencies may take up to 15 minutes to dry.

### Use a different brand of paper

Each paper brand accepts ink differently and prints with color variations. If you are printing photos or other high-quality images, for best results use Lexmark photo papers.

## **Check paper condition**

Use only new, unwrinkled paper.

## **Removing and reinstalling the software**

Software may not be installed correctly.

## ***Poor quality at the edges of the page***

These are possible solutions. Try one or more of the following:

### **Check minimum print settings**

Unless you are using the borderless feature, use these minimum print margin settings:

- Left and right margins:
  - 6.35 mm (0.25 in.) for letter-size paper
  - 3.37 mm (0.133 in.) for all paper sizes except letter
- Top margin: 1.7 mm (0.067 in.)
- Bottom margin: 12.7 mm (0.5 in.)

### **Select the Borderless print feature**

- 1 From the software application, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click **Print Layout**.
- 4 Click **Borderless**.

### **Make sure you use photo paper**

Borderless printing requires photo paper. Small margins are printed when you select the Borderless feature when you are printing on plain paper.

### **Make sure the paper size matches the printer setting**

- 1 From the software application, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click **Paper Setup**.
- 4 Check the paper size.

## ***Print speed is slow***

These are possible solutions. Try one or more of the following:

### **Maximize computer processing speed**

- Close all applications not in use.
- Minimize the number and size of graphics and images in the document.
- Remove as many unused fonts as possible from your system.

### **Add memory**

Consider purchasing more RAM.

## Select a lower print quality

- 1 From the software application, click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 Click **Quality/Copies**.
- 4 From the Quality/Speed area, select a lower print quality.

## Remove and reinstall the software

It is sometimes helpful to remove the existing printer software and reinstall it.

## *Skewed print*

### Check the paper guides

Move the guides in the tray to the correct positions for the paper size loaded.

### Check the paper

Make sure you are using paper that meets the printer specifications.

## *Photo smudges*

To prevent smudging, avoid touching the surface of a printed photo. For best results, remove each printed sheet individually from the paper exit tray, and allow the prints to dry at least 24 hours before stacking, displaying, or storing.

## *Checking the print cartridges*


### Are the print cartridges properly installed?

For more information, see “Installing print cartridges” on page 56.

### Are the sticker and tape removed from the cartridges?

Lift the access cover. Press down on the cartridge carrier latches to raise the cartridge carrier lids.

### Are the cartridges low on ink?

- 1 Do one of the following:
  - In Windows Vista, click .
  - In Windows XP and earlier, click **Start**.
- 2 Click **Programs** or **All Programs → Lexmark 1500 Series**.
- 3 Click **Solution Center**.
- 4 If an exclamation point (!) appears on a cartridge, the ink level is low. Install a new cartridge. For more information, see “Installing print cartridges” on page 56.

For cartridge-ordering information, see “Ordering paper and other supplies” on page 61.

## *Ink levels seem incorrect*

These are possible solutions. Try one or more of the following:

### Are you printing graphics or photos?

When you print documents with a large number of graphics, or with the Photo Quality/Speed setting, the printer uses more ink. The type of documents you print and the print quality you select affect the amount of ink the printer uses.

## **Are you printing a large file?**

The ink levels displayed in the printer software are not updated during a print job; they represent the ink level at the beginning of a print job. The ink levels may seem inconsistent in the Printing Status window when you are printing a large file.

## ***Ink levels seem to go down too quickly***

These are possible solutions. Try one or more of the following:

## **Are you printing photos or documents with a large number of graphics?**

Because photos and graphics require more ink than text documents, ink usage increases when you print photos or graphics.

## **Are you printing with the Best Quality/Speed setting?**

To reduce ink usage, select **Photo** only when you are printing on photo or heavyweight matte paper. All other paper types print best at a lower Quality/Speed setting. Use the Quick Print or Normal setting to print most text documents.

## ***A blank or incorrect page prints***



### **Remove the sticker and tape from the print cartridges**

Lift the access cover, and remove the print cartridges from the print cartridge carrier. Make sure the sticker and tape are removed from the print nozzles located on the bottom of the cartridges.

### **Make sure the cartridges are properly installed**

With the front of the printer facing you, check for proper print cartridge installation. If you are using a color cartridge, make sure it is properly installed in the right carrier. If you are using a black or photo cartridge, make sure it is properly installed in the left carrier.

### **Check the USB connection**

- 1 Check that the USB cable is connected to the computer. The USB port on the back of the computer is marked by the  USB symbol. Plug the long, flat end of the USB cable into this port.
- 2 Make sure that the smaller, more square end of the USB cable is plugged into the back of the printer.
- 3 Check that the USB cable is not damaged and that the  light is on.

### **Close other open files before printing**

Before sending a file to print, close all other open files in the program you are using. The printer prints a blank page when too many files are open in the same program.

## ***Characters on printout are missing or unexpected***

These are possible solutions. Try one or more of the following:

### **Make sure the printer is set as the default printer**

For more information, see “Checking the printer status.”

### **Make sure the fonts are applied correctly in the program**

Most programs do not print a stretched or resized font.

## **Make sure the TrueType font is available on the computer**

The font you are trying to print may not be available in the program font selection box. Not all fonts are designed to be printed; make sure the font is a TrueType font. See the program documentation for more information.

## **Make sure the document was formatted or created for the printer**

Windows may substitute different fonts. Line and page breaks may change with the font. Use the program that created the document to fix these problems, and then save the changes for the next time you print.

## ***Colors on printout are faded or differ from colors on the screen***


Check the following. When you think you have solved the problem, test the solution by sending a document to print.

### **Are the color and print speed settings correct?**

You may need to adjust the color and print speed. For more information, see “Saving and deleting print settings.”

### **Are the print cartridges low on ink?**

- 1 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.
- 2 Click **Solution Center**.



- 3 If an exclamation point (!) appears on either of the print cartridges, the ink level is low. Install a new cartridge. For more information, see “Installing print cartridges”.

For cartridge ordering information, see “Ordering print cartridges.”

## ***Glossy photo paper or transparencies stick together***

### **Do photos or transparencies dry and stick together on the paper exit tray?**

Remove the photos or transparencies from the paper exit tray as they exit the printer. Allow them to dry before stacking. Because transparencies and photo papers do not absorb ink, the ink on the surface of the paper or transparency takes longer to dry than most printouts.

### **Are you using a transparency or photo paper designed for an inkjet printer?**

For information on ordering supplies, see “Choosing compatible specialty paper types” on page 35.

## ***Page prints with different fonts***

### **Is the printer selected as the default printer?**

For more information, see “Checking the printer status.”

### **Are the fonts applied correctly?**

The problem may be with the fonts. For more information, see “Resolving font problems.”

## ***Print is too dark or smudged***

These are possible solutions. Try one or more of the following:

### **Make sure the ink dry before handling the paper**

Remove the paper as it exits, and let the ink dry before handling.

### **Make sure the Quality/Speed setting is appropriate for the paper type loaded in the printer**

The Photo Quality/Speed setting may cause smearing if used with plain paper. If you are using plain paper, try using the Normal setting.

### **Make sure the print cartridge nozzles are clean**

You may need to clean the print cartridge nozzles. For more information, see “Cleaning the print cartridge nozzles.”


## ***Printed characters are improperly formed or are not aligned correctly***

### **Have you added spaces at the left margin?**

If the print is not aligned correctly, make sure you have not added spaces by pressing Enter or the spacebar (hard-coded spaces).

### **Do you need to align the print cartridges?**

The cartridges may be out of alignment.

- 1 Do one of the following:
  - In Windows Vista, click  → **Control Panel**.
  - In Windows XP or 2000, click **Start**.
- 2 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.
- 3 Click **Solution Center**.
- 4 Click the **Maintenance** tab.
- 5 Click **Align to fix blurry edges**.

### **Are the print cartridges clean?**


You may need to clean the print cartridge nozzles.

## ***Printouts have alternating bands of light and dark print***

If the printer pauses frequently during a print job and prints pages with alternating bands of light and dark print, it is printing data faster than the computer can send it. Banded printing occurs when the printer pauses frequently. You may need to change the printer software settings, or the problem may be that the printer and the computer are not able to communicate properly.

### **Are the printer and the computer able to communicate data?**

Check the printer status:

- 1 Do one of the following:
  - In Windows Vista, click  → **Control Panel**.
  - In Windows XP or 2000, click **Start**.
- 2 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.

3 Click **Solution Center**.

4 If the Printer Status is:

- **Cannot Communicate**, the problem could be hardware or printer software settings.
- **Ready** or **Busy Printing**, the problem may be with the printer software settings.

### ***Transparencies or photos contain white lines***

#### **Do you need to adjust the Quality/Speed settings?**

1 With a document or photo open, click **File → Print**.

2 Click **Properties, Preferences, Options, or Setup**.

3 From the Quality/Copies tab, select:

- **Photo** when printing photos
- **Normal** when printing transparencies

#### **Is the problem with program settings?**

Use a different fill pattern in the program. For more information, see the program documentation.

#### **Are the print cartridges clean?**

You may need to clean the print cartridge nozzles. For more information, “Cleaning the print cartridge nozzles.”

### ***Vertical straight lines are not smooth***

#### **Adjust the Quality/Speed settings**

1 With a document or photo open, click **File → Print**.


2 Click **Properties, Preferences, Options, or Setup**.

3 From the Quality/Copies tab, select:

- **Photo** when printing photos
- **Normal** when printing transparencies

#### **Align the print cartridges**

1 Do one of the following:

- In Windows Vista, click  → **Control Panel**.
- In Windows XP or 2000, click **Start**.

2 Click **Programs** or **All Programs → Lexmark 1500 Series**.

3 Click **Solution Center**.

4 Click the **Maintenance** tab.

5 Click **Align to fix blurry edges**.

### ***White lines appear in graphics or solid black areas***

#### **Adjust the Quality/Speed settings**

- For excellent print quality and reduced print speed, select **Best**.
- For good print quality and average print speed, select **Normal**.



- For reduced print quality and faster print speed, select **Quick Print**.
- For the default print quality, select **Automatic**. The paper type sensor determines the print quality based on the type of paper it detects loaded in the paper support.

## Adjust the application settings for the document


Use a different fill pattern in the application you are using to print the graphics. For more information, see the documentation that came with the application.

## Perform maintenance on the print cartridges

You may need to clean the print cartridge nozzles.

## Checking the printer status

### Windows Vista users only

- 1 Click  → **Control Panel** → **Printer**.
- 2 Make sure:
  - The printer icon does not say **Paused**. If the printer is paused, right-click the icon, and then click **Resume Printing**.
  - The printer icon says **Ready**. If it says **Offline**, right-click the icon, and then click **Use Printer Online**.
  - The printer icon has a check mark indicating that the printer is set as the default printer. If it is not, right-click the icon, and then click **Set as Default**.

### Windows XP users only

- 1 Click **Start** → **Settings** → **Printers and Faxes**.
- 2 Make sure:
  - The printer icon does not say **Paused**. If the printer is paused, right-click the icon, and then click **Resume Printing**.
  - The printer icon says **Ready**. If it says **Offline**, right-click the icon, and then click **Use Printer Online**.
  - The printer icon has a check mark indicating that the printer is set as the default printer. If it is not, right-click the icon, and then click **Set as Default**.

### Windows 2000 users only

- 1 Click **Start** → **Settings** → **Printers**.
- 2 Right-click the **Lexmark 1500 Series** icon.
- 3 Make sure:
  - **Set as Default Printer** is selected.
  - **Pause Printing** is *not* selected.
  - **Use Printer Offline** is *not* selected.

## Checking printer readiness

The printer may not be ready to print. Check the following. When you think you have solved the problem, test the solution by sending a document to print.


### Make sure the printer has paper and is properly loaded

Make sure you have followed the correct loading instructions for your printer.

## Remove the sticker and tape from the print cartridges



- 1 Lift the access cover.
- 2 Remove the print cartridges from the print cartridge carrier.
- 3 Make sure the sticker and tape are removed from the bottom and back of the cartridges.

## Do the print cartridges have ink?

- 1 Do one of the following:
  - In Windows Vista, click .
  - In Windows XP and earlier, click **Start**.
- 2 Click **Programs** or **All Programs → Lexmark 1500 Series**.
- 3 Click **Solution Center**.


If an exclamation point (!) appears on either of the print cartridges, the ink level is low. Install a new cartridge.

## Check the USB connection

- 1 Check that the USB cable is connected to the computer. The USB port on the back of the computer is marked by the  USB symbol. Plug the long, flat end of the USB cable into this port.
- 2 Make sure that the smaller, more square end of the USB cable is plugged into the back of the printer.
- 3 Check that the USB cable is not damaged and that the  light is on.

## Checking the Spool Settings for banner printing

Banner printing is not possible if certain Spool Settings are selected. Verify that you have the right settings selected.

- 1 For Windows Vista, click  → **Control Panel → Printer**.  
For Windows XP, click **Start → Settings → Printers** or **Printers and Faxes**.
- 2 Right-click the **Lexmark 1500 Series** icon.
- 3 Select **Properties**.
- 4 Click the **Advanced** tab.
- 5 At the bottom of the Advanced tab, click **Print Processor**.
- 6 Verify that the Default data type is LEMF. If it is not, select **LEMF** from the available choices, and then click **OK**.

## Resolving font problems

### Have you applied the fonts correctly in the program?

Most programs do not print a stretched or resized font.

### Is the font a TrueType font? Is it available on the computer?

The font you are trying to print may not be available in the program font selection box. Not all fonts are designed to be printed; make sure the font is a TrueType font. See the program documentation for more information.

## Was the document formatted or created for the printer?

Windows may substitute different fonts. Line and page breaks may change with the font. Use the program that created the document to fix these problems, and then save the changes for the next time you print.



## *Printer is busy printing another job*

Wait until the printer has finished printing all other print jobs before sending this job to print.

## *Ready or Busy Printing is listed as the status*

If Ready or Busy Printing is listed as the Printer Status on the Status tab of the Solution Center while you are attempting to print, try the suggestions below. Next, test the solution by sending a document to print.

## Is there a problem with the connections?

- 1 Check that the USB cable is connected to the computer. The USB port on the back of the computer is marked by the  USB symbol. Plug the long, flat end of the USB cable into this port.
- 2 Make sure that the smaller, more square end of the USB cable is plugged into the back of the printer.
- 3 Check that the USB cable is not damaged and that the  light is on.

## Do you need to adjust the Quality/Speed settings?


Select **Photo** from the Quality/Copies tab in Printing Preferences.

- 1 Click **File → Print**.
- 2 Click **Properties, Preferences, Options, or Setup**.
- 3 From the Quality/Copies tab, make changes as needed.
- 4 Click **OK** to close any dialog boxes that are open.

## Is the problem with the program?

Try printing a different image. If it prints correctly, the problem may be with the program you are using. For more information, see the program documentation.

## *Printing a test page*


- 1 Do one of the following:
  - In Windows Vista, click .
  - In Windows XP and earlier, click **Start**.
- 2 Click **Programs** or **All Programs → Lexmark 1500 Series**.
- 3 Click **Solution Center**.
- 4 From the Maintenance tab, click **Print a test page**.
- 5 Compare the printed page to the image displayed on the computer screen. If the printed image matches the image displayed on the screen, then you are finished.
- 6 If the test page did not print at all or has quality problems, attend to any error messages that appear on the screen.

## ***Test page does not print***



These are possible solutions. Try one or more of the following:

### **Make sure the printer is receiving power**

If the  light is not on, the printer may not be receiving power.

- Press .
- Plug the printer into a different electrical outlet.
- If the printer is plugged into a surge protector, unplug the printer, and plug it directly into an electrical outlet.

### **Check the USB connection**

- 1 Check that the USB cable is connected to the computer. The USB port on the back of the computer is marked by the  USB symbol. Plug the long, flat end of the USB cable into this port.
- 2 Make sure that the smaller, more square end of the USB cable is plugged into the back of the printer.
- 3 Check that the USB cable is not damaged and that the  light is on.


### **Make sure the cartridges are properly installed**

With the front of the printer facing you, check for proper print cartridge installation. If you are using a color cartridge, make sure it is properly installed in the right carrier. If you are using a black cartridge or photo cartridge, make sure it is properly installed in the left carrier.

Make sure the sticker and tape are removed from the print cartridges:

- 1 Lift the access cover.
- 2 Remove the print cartridges from the print cartridge carrier.
- 3 Make sure the sticker and tape are removed from the bottom and back of the print cartridges.


### **Try printing the test page again**

- 1 Do one of the following:
  - In Windows Vista, click .
  - In Windows XP and earlier, click **Start**.
- 2 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.
- 3 Click **Solution Center**.
- 4 Click the **Maintenance** tab.
- 5 Click **Print a test page**.

## ***Cable is not connected, is loose, or is damaged***

The printer cable must be fully connected and undamaged for proper communication.

### **Make sure the USB cable is connected to the USB port on the back of the computer**


The USB port on the back of the computer is marked by . Plug the long, flat end of the USB cable into this port.

### **Make sure the other end of the USB cable is connected to the back of the printer**

Plug the smaller, more square end of the USB cable into the back of the printer.

## **Make sure the cable is not damaged or loose**

Make sure:

- The USB cable is not damaged.
- The  light is on.

For more information, see “Printer is plugged in but does not print.”

## ***Printer is plugged in but does not print***

These are possible solutions. Try one or more of the following:

### **Make sure the printer is set as the default printer**

Try printing a test page.

### **Make sure the print queue is ready to print**

Make sure the printer is set as the default printer and is not being held or paused.

## ***Printer is trying to print to File***

If the computer is sending the print jobs to File rather than to the printer connected to the computer, first make sure the printer is attached with a USB cable to a USB port on the computer.

To verify the USB port:

- 1 In Windows Vista, click  → **Control Panel** → **Printers** (under Hardware and Sound).

In Windows XP, click **Start** → **Settings** → **Printers and Faxes**.

- 2 Right-click the **Lexmark 1500 Series** icon.

- 3 From the sidebar menu, select **Properties**.

- 4 Click the **Ports** tab.

- 5 Make sure:

- The port is set to a USB port.
- File is not set as the port.

If the document still does not print, then the USB port may not be enabled in the computer. For more information, see the related topic, “Enabling the USB port.”

## ***Printer cannot communicate with computers over peer-to-peer network***

These are possible solutions. Try one or more of the following:



### **Check the status of the host computer and printer**

Make sure:

- The host computer is on and is directly connected to the printer.
- The host computer can print to the printer.
- The printer is shown as **Shared** in the Printers and Faxes folder (Windows XP and Windows 2000) or Printers folder (Windows Vista) on the host computer.

## Check the printer status

Windows Vista users:

- 1 Click:
  - (default Start menu)  → **Settings → Printers**.
  - (Classic Start menu)  → **Control Panel → Printers**.
- 2 Right-click the **Lexmark 1500 Series** icon.
- 3 Click **Sharing**.
- 4 Click **Change Sharing Options**, and confirm the Windows prompt.
- 5 Select **Share this printer**, and then give the printer a distinctive name.
- 6 Click **OK**.

Windows XP users:

- 1 Click **Start → Settings → Printers and Faxes**.
- 2 Right-click the **Lexmark 1500 Series** icon.
- 3 Click **Sharing**.
- 4 Select **Share this printer**, and then give the printer a distinctive name.
- 5 Click **OK**.

Windows 2000 users:

- 1 Click **Start → Settings → Printers**.
- 2 Right-click the **Lexmark 1500 Series** icon.
- 3 Click **Sharing**.
- 4 Select **Shared as**, and then give the printer a distinctive name.
- 5 Click **OK**.

## Try to locate the printer from the remote computer

If the printer is shown as Shared on the host computer, but you still cannot print, try to locate the printer from the remote computer.

Windows 2000, Windows XP, or Windows Vista users:

- 1 Open the **Printers** or **Printers and Faxes** folder.
- 2 Right-click the **Lexmark 1500 Series** icon.
- 3 Click **Properties**.
- 4 Click the **Ports** tab, and then click the **Add Port** button.
- 5 Select **Local Port**, and then click the **New Port** button.
- 6 Type the Universal Naming Convention (UNC) Port name, which consists of the server name and the distinctive printer name.

The name should be in the form `\\server\printer`.

7 Click **OK**.

8 Click **Close**.

9 Make sure the new port has been selected on the Ports tab, and then click **Apply**.


The new port is listed with the printer name.

10 Click **OK**.

## **Restart the host computer and the remote computer**

Try printing again.

### ***Printer is not able to communicate with the computer***

The printer and computer are not able to exchange data. Verify that the printer is plugged in, and the  light is on.

### ***Wrong printer is attached***

The printer attached to the computer is not the correct printer. See the setup documentation for help attaching the printer.

## **Printer is out of paper**

1 Load paper.

2 Press .

### ***Updating the printer software***

The printer software needs to be updated to run properly.

1 Start Windows.

2 When the desktop appears, insert the software CD for Windows.

The installation screen appears.

3 Click **Install**.

4 When the Existing Printer Driver Found dialog box appears, select **Update the existing driver software**.

### ***Bidirectional communication is not established***

The printer and computer may not be able to exchange data.

These are possible solutions. Try one or more of the following:

#### **Make sure there is no problem with the connections**

For more information, see “Cable is not connected, is loose, or is damaged” on page 92.

#### **Make sure the printer is receiving power**

If the  button is not lit, the printer may not be receiving power.

- Plug the printer into a different outlet.
- If the printer is plugged into a surge protector, unplug the printer, and plug it directly into an electrical outlet.

## ***Experiencing poor quality or incorrect output***

See the topic that best describes the problem.

- Print is too dark or smudged
- Vertical straight lines are not smooth
- White lines appear in graphics or solid black areas
- Characters are missing or unexpected
- Colors on printout are faded or differ from colors on the screen
- Printouts have alternating bands of light and dark print
- Page prints with different fonts
- Printed characters are improperly formed or are not aligned correctly at the left margin
- Transparencies or photos contain white lines
- Glossy photo paper or transparencies stick together

## ***Cannot print from a memory card or flash drive***

These are possible solutions. Try one or more of the following:

### **Check the file types stored on the memory card or flash drive**

Make sure the file types stored on the memory device are supported by the programs installed on your computer.

### **Check the memory card or flash drive**

Make sure the memory card or flash drive is not corrupted. Remove memory devices properly from the printer to avoid corruption or loss of data.

### **Check the network connection**

If the printer and computer are connected over a network, make sure that the correct host and device are communicating. Select the correct printer from the computer.

### **Make sure the printer is connected to the computer through a USB cable**

You cannot print directly from a memory device if you are using a wireless connection. Transfer the photos from the memory device to the computer before printing the photos.



## ***Cannot print from digital camera using PictBridge***

These are possible solutions. Try one or more of the following:

### **Make sure the camera is a PictBridge-enabled digital camera**

See the documentation that came with your camera to determine whether it is a PictBridge-enabled digital camera.

### **Enable PictBridge printing from the camera**

Enable PictBridge printing on the camera by selecting the correct USB mode. If the camera USB selection is incorrect, the camera is detected as a USB storage device, or the  light and  light blink alternately. For more information, see the documentation that came with your camera.



## Make sure the printer is properly communicating with the camera



If the PictBridge connection is successful, the camera automatically switches to print mode, the **PictBridge** PictBridge symbol appears on the camera display, or a message recognizing the connection appears on the camera display, depending on your camera.

If the PictBridge connection is unsuccessful, try one or more of the following:

- Make sure you are using the USB cable that came with your camera.
- Make sure the USB cable that you are using is not damaged.

If the error occurs after the printer has successfully connected with the camera, try one or more of the following:

- Disconnect the camera, and then connect it again.
- If the lights keep on blinking, check for error messages on the camera display, and then see the documentation that came with your camera.

## Remove memory cards

Remove memory cards from the printer. The printer recognizes one active media device at a time.

## Check error messages

If an error message appears on the camera display, see the documentation that came with your camera.

## ***Partial photo prints when using a PictBridge-enabled digital camera***

### **Make sure photo size and paper size are set correctly**

Make sure the photo paper in the paper support matches the photo size or print size selected on your digital camera.

To view the print size settings on your digital camera, see the documentation that came with your camera.

## Jams and misfeeds troubleshooting

### ***Paper jam in the printer***


- 1 Firmly grasp the paper, and gently pull it out.
- 2 Press .

### ***Paper jam in the paper support***


- 1 Firmly grasp the paper, and gently pull it out.
- 2 Press .

## ***Paper jam in the duplex unit***


- 1 Push down on the duplex latch as you grasp the duplex unit.




- 2 Pull out the duplex unit.



- 3 Firmly grasp the paper, and gently pull it out.



- 4 Push down on the duplex latch as you reinstall the duplex unit.



5 Press .

6 On your computer, delete or stop the print job, and then try sending it again.

## ***Paper or specialty media misfeeds***

These are possible solutions if paper or specialty media misfeeds or skews, or if multiple sheets feed or stick together. Try one or more of the following:

### **Check paper condition**

Use only new, unwrinkled paper.

### **Check paper loading**

- Load a smaller amount of paper into the printer.
- Load paper with the print side facing you. (If you are not sure which side is the printable side, see the instructions that came with the paper.)

See “Loading paper” on page 28 and its related topics for information about:

- Maximum loading amounts per paper type
- Specific loading instructions for supported paper and specialty media


### **Remove each page as it is printed**

Remove each page as it exits, and let it dry completely before stacking.

### **Adjust the paper guides**

Adjust the paper guides:

- When using media less than 8.5 inches wide
- To rest against the edges of the paper or media, making sure it does not buckle



## ***Printer does not feed paper, envelopes, or specialty media***

These are possible solutions. Try one or more of the following:


### **Check for paper jams**

Check for and clear any paper jams. For more information, see “Paper jam in the printer” on page 97 and “Paper jam in the paper support” on page 97.

### **Check media loading**

- Verify that the specialty media is loaded correctly. For more information, see “Loading paper” on page 28.
- Try loading one page, envelope, or sheet of specialty media at a time.


## Check printer default and pause settings

- 1 Do one of the following:
  - In Windows Vista, click  → **Control Panel** → **Printers**.
  - In Windows XP, click **Start** → **Settings** → **Printers and Faxes**.
  - In Windows 2000, click **Start** → **Settings** → **Printers**.
- 2 Double-click the print queue device.
- 3 Click **Printer**.
  - Make sure no check mark appears next to **Pause Printing**.
  - If a check mark does not appear next to **Set As Default Printer**, you must select the print queue device for each file you want to print.

## ***Banner paper jams***

These are possible solutions. Try one or more of the following:

### **Clear banner paper jams**

- 1 Firmly grasp the paper, and gently pull it out.
- 2 Press .

### **Review banner printing checklist**

- Use only the number of sheets needed for the banner.
- Select the following settings to enable the printer to feed paper continuously without jamming:
  - 1 With a document open, click **File** → **Print**.
  - 2 Click **Properties**, **Preferences**, **Options**, or **Setup**.
  - 3 Click the **Paper Setup** tab.
  - 4 From the Paper Size area, select **Banner**.
  - 5 Select **Letter Banner** or **A4 Banner** as the paper size.
  - 6 Select **Portrait** or **Landscape**.
  - 7 Click **OK**.
  - 8 Click **OK** or **Print**.

## ***Paper continues to jam***

### **Are you using paper designed for an inkjet printer?**

Check the type of paper you are using. Some low-quality papers may be too thin or too slick to be fed correctly into the printer. For more information, see “Choosing compatible specialty paper types” on page 35.

### **Are you loading the paper correctly?**

For more information, see “Loading paper” on page 28.

**Note:** Do not force paper into the printer.

## ***Duplex unit does not operate correctly***

These are possible solutions. Try one or more of the following:

### **Check paper size and type**

Check the paper size and type to make sure the paper is supported by the printer. If you are using automatic duplexing, use only letter- or A4-size plain paper.

### **Check for paper jams**

Check for and clear any paper jams. For more information, see “Paper jam in the duplex unit” on page 98.


### **Make sure the duplex unit is properly installed**

Remove the duplex unit and reinstall it. For more information, see “Paper jam in the duplex unit” on page 98.

## **Cartridge carrier jam**


These are possible solutions. Try one or more of the following:

### **Remove any obstructions in the cartridge carrier**


- 1 Lift the access cover.
- 2 Remove any objects blocking the path of the print cartridge carrier.
- 3 Make sure the cartridge carrier lids are closed.
- 4 Close the access cover.
- 5 Press .

### **Remove and reinstall the print cartridges**


- 1 Lift the access cover.
- 2 Press down on the cartridge carrier levers to raise the cartridge carrier lids.




- 3 Remove both print cartridges.



4 Reinstall the print cartridges.



5 Snap the lids closed.



6 Close the access cover.

7 Press .

## Memory card troubleshooting

### ***Memory card cannot be inserted***

There are possible solutions. Try one or more of the following:

#### **Check memory card type**

Make sure that the type of memory card you are using can be used in the printer. For more information, see “Inserting a memory card” on page 43.

#### **Check memory card placement**

Make sure you have inserted the memory card in the correct slot. For more information, see “Inserting a memory card” on page 43.

### ***Nothing happens when memory card is inserted***

These are possible solutions. Try one or more of the following:

#### **Reinsert the memory card**

The memory card may not have been inserted properly. Remove the memory card and then reinsert it.

#### **Check memory card type**

Make sure that the type of memory card you are using can be used in the printer. For more information, see “Inserting a memory card” on page 43.

## Check memory card placement

Make sure you inserted the memory card into the correct slot. For more information, see “Inserting a memory card” on page 43.



## Check to see if the memory card is damaged

Check to see if there is no obvious damage to the memory card. Remove memory cards properly from the printer to avoid corruption of data.

## Check the file types stored on the memory card

Make sure the file types stored on the memory card are supported by the programs installed on your computer.

## Make sure the USB cable is connected

- 1 Check that the USB cable is connected to the computer. The USB port on the back of the computer is marked by the  USB symbol. Plug the long, flat end of the USB cable into this port.
- 2 Make sure that the smaller, more square end of the USB cable is plugged into the back of the printer.
- 3 Check that the USB cable is not damaged and that the  light is on.

## Check the network connection


If the printer and computer are connected over a network, make sure that the correct host and device are communicating. Select the correct printer from the computer.

## *Photos do not transfer from a memory card across a wireless network*

These are possible solutions. Try one or more of the following:

### Select the printer on your wireless network

If you have more than one printer and use Windows, you must select your wireless network printer.

- 1 Do one of the following:
  - In Windows Vista, click  → **Control Panel** → **Printers**.
  - In Windows XP and earlier, click **Start** → **Settings** → **Printers and Faxes**.
- 2 From the list shown, select the printer on your wireless network.

**Note:** To select the printer, right click the printer, and then select **Set as Default Printer**.
- 3 Insert the memory card in the printer.
- 4 Follow the instructions on the computer screen.

## Check memory card placement

Make sure you inserted the memory card into the correct slot.

## Check memory card type

Make sure that the type of memory card you are using can be used in the printer.

## Check to see if the memory card is damaged


Check to see that there is no obvious damage to the memory card. Remove memory cards properly from the printer to avoid corruption of data.

## Check to see if your printer or the computer is turned on

Make sure that your printer and your computer are turned on.

## Check to see if your wireless connection is active

If your wireless connection is down:

- 1 Do one of the following:
  - In Windows Vista, click  → **Control Panel** → **Printers**.
  - In Windows XP and earlier, click **Start** → **Settings** → **Printers** or **Printers and Faxes**.
- 2 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.
- 3 Click **Wireless Setup Utility**.

## Error messages on the computer screen

### *Clearing error messages*

- 1 Correct the error condition explained in the error message. Click **Help** on the error message dialog box for specific instructions.
- 2 After correcting the error condition, click **Continue** to resume printing.

If the error remains, but you want to clear the error message:

- 1 Click **Cancel Printing**. The error message closes, and the Canceling Printing dialog box appears.
- 2 Follow the instructions on the Canceling Printing dialog box.

## Left/Right Cartridge Missing



You need to install a print cartridge. For more information, see the related topic below.

To order a new cartridge, see “Ordering print cartridges.”

## Communication not available

The printer and computer may not be able to exchange data.

### Is the printer receiving power?

If  is not lit, the printer may not be receiving power.

- Plug the printer into a different outlet.
- If the printer is plugged into a surge protector, unplug the printer, and plug it directly into an electrical outlet.

### Is there a problem with the connections?

If the printer is connected to an external device, the problem may be with this device. Check the setup information that came with the device to make sure it is properly installed.



If printing using a USB cable, make sure the cable is securely attached to both the printer and the computer.  
Before you print, you may need to restart the computer.

## General Printing Problem

You cannot receive a more specific error message because the printer and the computer do not have bidirectional communication.

To receive a more specific error message, see “Bidirectional communication is not established” on page 95.

To find the problem without establishing bidirectional communication, see “Checking printer readiness” on page 89.

## Ink Low

A print cartridge is almost out of ink.



Install a new cartridge. For more information, see “Installing print cartridges” on page 56.

To order a new cartridge, see “Ordering paper and other supplies” on page 61.

## Out of Memory


The printer software cannot obtain enough memory to print.

Try the following:

- Before sending a document to print, close any other open programs. The printer may print a blank page when too many programs are open on the computer.
- Follow the instructions on the error screen. These instructions reduce the amount of memory needed to print.

## Out of Paper

1 Load paper. For more information, see “Loading paper” on page 28.

2 Press  to continue printing.


**Note:** Do not force paper into the printer.

## Fixing a printing failure

Follow the instructions on the computer screen.

If the printer still does not print, contact the Customer Support Center:

1 Do one of the following:

- In Windows Vista, click .
- In Windows XP and earlier, click **Start**.

2 Click **Programs** or **All Programs** → **Lexmark 1500 Series**.

3 Click **Solution Center**, and then click the **Contact Information** tab.

## ***Print File Error***

To use the Print Files function, your printer must be connected to a computer, and both the printer and computer must be on.

The error may include any of the following causes listed below.

Cause	Solution
The printer failed to find an application or software on the computer to print the file or files stored on the memory device.	Make sure you have software installed on your computer that can open files with the desired file extensions.
The printer failed to retrieve the file or files stored on the memory device.	Make sure that: <ul style="list-style-type: none"><li>• The memory device has not been removed.</li><li>• The memory card or flash drive is not damaged or corrupted.</li></ul>

## ***Unsupported file types found on memory card***

The memory card inserted in the printer contains unsupported file types. Insert a memory card with supported file types. For more information on supported file types, see the *User's Guide* on the CD that came with your printer.

## **Paper Jam**

The printer has a paper jam, and you must clear the paper path.

**Note:** To avoid paper jams, do not force paper into the printer.

## ***Multiple All-In-Ones found***

Multiple Lexmark printers, attached either locally or over a network, have been detected on your computer. You can choose which printer you want to use:

- 1 Select the printer from the list.
- 2 Click **OK**.

# Notices

---

## Product information

Product name:

Lexmark 1500 Series

Machine type:

4118

Model(s):

W22

W2E

## Edition notice

June 2007

**The following paragraph does not apply to any country where such provisions are inconsistent with local law:** LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

For Lexmark technical support, visit [support.lexmark.com](http://support.lexmark.com).

For information on supplies and downloads, visit [www.lexmark.com](http://www.lexmark.com).

If you don't have access to the Internet, you can contact Lexmark by mail:

Lexmark International, Inc.  
Bldg 004-2/CSC  
740 New Circle Road NW  
Lexington, KY 40550

© 2007 Lexmark International, Inc.

All rights reserved.

## UNITED STATES GOVERNMENT RIGHTS

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

## Trademarks

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

evercolor and PerfectFinish are trademarks of Lexmark International, Inc.

TrueType is a trademark of Apple Inc.

All other trademarks are the property of their respective owners.

## Conventions

**Note:** A *Note* identifies something that could help you.

**Warning:** A *Warning* identifies something that could damage your product hardware or software.



**CAUTION:** A *CAUTION* identifies something that could cause you harm.



**CAUTION:** This type of *CAUTION* indicates that you should *not touch* the marked area.



**CAUTION:** This type of *CAUTION* indicates a *hot surface*.



**CAUTION:** This type of *CAUTION* indicates a *shock hazard*.



**CAUTION:** This type of *CAUTION* indicates a *tipping hazard*.

## Federal Communications Commission (FCC) compliance information statement

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The FCC Class B limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your point of purchase or service representative for additional suggestions.

The manufacturer is not responsible for radio or television interference caused by using other than recommended cables or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate this equipment.

**Note:** To assure compliance with FCC regulations on electromagnetic interference for a Class B computing device, use a properly shielded and grounded cable such as Lexmark part number 1021294 for USB attach. Use of a substitute cable not properly shielded and grounded may result in a violation of FCC regulations.

Any questions regarding this compliance information statement should be directed to:

Director of Lexmark Technology & Services  
Lexmark International, Inc.  
740 West New Circle Road  
Lexington, KY 40550  
(859) 232-3000

## Exposure to radio frequency radiation

The following notice is applicable if your printer has a wireless network card installed.

The radiated output power of this device is far below the radio frequency exposure limits of the FCC and other regulatory agencies. A minimum separation of 20 cm (8 inches) must be maintained between the antenna and any persons for this device to satisfy the RF exposure requirements of the FCC and other regulatory agencies.

## Industry Canada compliance statement

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003.

## Avis de conformité aux normes de l'industrie du Canada

Cet appareil numérique de classe B est conforme aux exigences de la norme canadienne relative aux équipements pouvant causer des interférences NMB-003.

## European Community (EC) directives conformity

This product is in conformity with the protection requirements of EC Council directives 89/336/EEC and 2006/95/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility and safety of electrical equipment designed for use within certain voltage limits.

A declaration of conformity with the requirements of the directives has been signed by the Director of Manufacturing and Technical Support, Lexmark International, Inc., S.A., Boigny, France.

This product satisfies the Class B limits of EN 55022 and safety requirements of EN 60950.

## Industry Canada notice

The following notices are applicable if your printer has a wireless network card installed.

### ***Industry Canada (Canada)***

This device complies with Industry Canada specification RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate only with the antenna provided. Use of any other antenna is strictly prohibited per regulations of Industry Canada.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF fields in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site [www.hc-sc.gc.ca/rpb](http://www.hc-sc.gc.ca/rpb).

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

### ***Industry Canada (Canada)***

Cet appareil est conforme à la norme RSS-210 d'Industry Canada. Son fonctionnement est soumis aux deux conditions suivantes :

(1) cet appareil ne doit pas provoquer d'interférences et (2) il doit accepter toute interférence reçue, y compris celles risquant d'altérer son fonctionnement.

Cet appareil a été conçu pour fonctionner uniquement avec l'antenne fournie. L'utilisation de toute autre antenne est strictement interdite par la réglementation d'Industry Canada.

En application des réglementations d'Industry Canada, l'utilisation d'une antenne de gain supérieur est strictement interdite.

Pour empêcher toute interférence radio au service faisant l'objet d'une licence, cet appareil doit être utilisé à l'intérieur et loin des fenêtres afin de garantir une protection optimale.

Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

L'installateur de cet équipement radio doit veiller à ce que l'antenne soit implantée et dirigée de manière à n'émettre aucun champ HF dépassant les limites fixées pour l'ensemble de la population par Santé Canada. Reportez-vous au Code de sécurité 6 que vous pouvez consulter sur le site Web de Santé Canada [www.hc-sc.gc.ca/rpb](http://www.hc-sc.gc.ca/rpb).

Le terme « IC » précédant le numéro de d'accréditation/inscription signifie simplement que le produit est conforme aux spécifications techniques d'Industry Canada.

## European EC directives conformity statement for radio products

**The following notices are applicable if your printer has a wireless network card installed**

This product is in conformity with the protection requirements of EC Council directives 89/336/EEC, 2006/95/EC, and 1999/5/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment.

Compliance is indicated by the CE marking.



The Alert sign indicates that there are restrictions within certain member states.

A declaration of conformity with the requirements of the directives is available from the Director of Manufacturing and Technical Support, Lexmark International, S. A., Boigny, France.

The following restrictions apply:

Country/region	Restriction
All countries/regions	This product is for indoor use only. This product may not be used outdoors.
L'Italia	Si fa presente inoltre che l'uso degli apparati in esame è regolamentato da: <ul style="list-style-type: none"> <li>D.Lgs 1.8.2003, n.259, articoli 104 (attività soggette ad autorizzazione generale) e 105 (libero uso), per uso privato;</li> <li>D.M. 28.5.03, per la fornitura al pubblico dell'accesso R-LAN alle reti e ai servizi di telecomunicazioni.</li> </ul>

This product satisfies the limits of EN 55022; safety requirements of EN 60950; radio spectrum requirements of ETSI EN 300 328; and the EMC requirements of EN 55024, ETSI EN 301 489-1 and ETSI EN 301 489-17.

Česky	Společnost Lexmark International, Inc. tímto prohlašuje, že výrobek tento výrobek je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.
Dansk	Lexmark International, Inc. erklærer herved, at dette produkt overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Deutsch	Hiermit erklärt Lexmark International, Inc., dass sich das Gerät dieses Gerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Ελληνική	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η LEXMARK INTERNATIONAL, INC. ΔΗΛΩΝΕΙ ΟΤΙ ΑΥΤΟ ΤΟ ΠΡΟΪΟΝ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
English	Hereby, Lexmark International, Inc., declares that this type of equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Español	Por medio de la presente, Lexmark International, Inc. declara que este producto cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Eesti	Käesolevaga kinnitab Lexmark International, Inc., et seade see toode vastab direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele muudele asjakohastele sätetele.
Suomi	Lexmark International, Inc. vakuuttaa täten, että tämä tuote on direktiivin 1999/5/EY oleellisten vaatimusten ja muiden sitä koskevien direktiivin ehtojen mukainen.
Français	Par la présente, Lexmark International, Inc. déclare que l'appareil ce produit est conforme aux exigences fondamentales et autres dispositions pertinentes de la directive 1999/5/CE.
Magyar	Alulírott, Lexmark International, Inc. nyilatkozom, hogy a termék megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.
Íslenska	Hér með lýsir Lexmark International, Inc. yfir því að þessi vara er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.
Italiano	Con la presente Lexmark International, Inc. dichiara che questo prodotto è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latviski	Ar šo Lexmark International, Inc. deklarē, ka šis izstrādājums atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lietuvių	Šiuo Lexmark International, Inc. deklaruojama, kad šis produktas atitinka esminius reikalavimus ir kitas 1999/5/EB direktyvos nuostatas.
Malti	Bil-preżenti, Lexmark International, Inc., jiddikjara li dan il-prodott huwa konformi mal-ħtiġijiet essenzjali u ma dispożizzjonijiet oħrajn rilevanti li jinsabu fid-Direttiva 1999/5/KE.

Nederlands	Hierbij verklaart Lexmark International, Inc. dat het toestel dit product in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Norsk	Lexmark International, Inc. erklærer herved at dette produktet er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.
Polski	Niniejszym Lexmark International, Inc. oświadcza, że niniejszy produkt jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.
Português	A Lexmark International Inc. declara que este produto está conforme com os requisitos essenciais e outras disposições da Diretiva 1999/5/CE.
Slovensky	Lexmark International, Inc. týmto vyhlasuje, že tento produkt spĺňa základné požiadavky a všetky príslušné ustanovenia smernice 1999/5/ES.
Slovensko	Lexmark International, Inc. izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.
Svenska	Härmed intygar Lexmark International, Inc. att denna produkt står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

## Noise emission levels

The following measurements were made in accordance with ISO 7779 and reported in conformance with ISO 9296.

**Note:** Some modes may not apply to your product.

1-meter average sound pressure, dBA	
Printing	48
Ready	inaudible

Values are subject to change. See [www.lexmark.com](http://www.lexmark.com) for current values.

## Waste from Electrical and Electronic Equipment (WEEE) directive



The WEEE logo signifies specific recycling programs and procedures for electronic products in countries of the European Union. We encourage the recycling of our products. If you have further questions about recycling options, visit the Lexmark Web site at [www.lexmark.com](http://www.lexmark.com) for your local sales office phone number.

## Product disposal

Do not dispose of the printer or supplies in the same manner as normal household waste. Consult your local authorities for disposal and recycling options.

## Temperature information

Ambient temperature	15° ~ 32° C (60° ~ 90° F)
Shipping and storage temperature	-40° ~ 60° C (-40° ~ 140° F), 1° ~ 60° C (34° ~ 140° F)

## ENERGY STAR



## Power consumption

### *Product power consumption*

The following table documents the power consumption characteristics of the product.

**Note:** Some modes may not apply to your product.

Mode	Description	Power consumption (Watts)
Printing	The product is generating hard-copy output from electronic inputs.	13.8
Copying	The product is generating hard-copy output from hard-copy original documents.	not applicable
Scanning	The product is scanning hard-copy documents.	not applicable
Ready	The product is waiting for a print job.	7.5
Power Saver	The product is in energy-saving mode.	5.8
High Off	The product is plugged into a wall outlet, but the power switch is turned off.	not applicable
Low Off (<1 W Off)	The product is plugged into a wall outlet, the power switch is turned off, and the product is in the lowest possible power consumption mode.	not applicable
Off	The product is plugged into a wall outlet, but the power switch is turned off.	0.6

The power consumption levels listed in the previous table represent time-averaged measurements. Instantaneous power draws may be substantially higher than the average.

Values are subject to change. See [www.lexmark.com](http://www.lexmark.com) for current values.

### *Power Saver*

This product is designed with an energy-saving mode called Power Saver. The Power Saver Mode is equivalent to the EPA Sleep Mode. The Power Saver Mode saves energy by lowering power consumption during extended periods of inactivity. The Power Saver Mode is automatically engaged after this product is not used for a specified period of time, called the Power Saver Timeout.

Factory default Power Saver Timeout for this product (in minutes):	30
--	----

### *Off mode*

If this product has an off mode which still consumes a small amount of power, then to completely stop product power consumption, disconnect the power supply cord from the wall outlet.

### *Total energy usage*

It is sometimes helpful to calculate the total product energy usage. Since power consumption claims are provided in power units of Watts, the power consumption should be multiplied by the time the product spends in each mode in order to calculate energy usage. The total product energy usage is the sum of each mode's energy usage.

## Statement of Limited Warranty

### *Lexmark International, Inc., Lexington, KY*

This limited warranty applies to the United States. For customers outside the U.S., see the country-specific warranty information that came with your product.



This limited warranty applies to this product only if it was originally purchased for your use, and not for resale, from Lexmark or a Lexmark remarketer, referred to in this statement as "Remarketer."

### ***Limited warranty***

Lexmark warrants that this product:

- Is manufactured from new parts, or new and serviceable used parts, which perform like new parts
- Is, during normal use, free from defects in material and workmanship

If this product does not function as warranted during the warranty period, contact a Remarketer or Lexmark for repair or replacement (at Lexmark's option).

If this product is a feature or option, this statement applies only when that feature or option is used with the product for which it was designed. To obtain warranty service, you may be required to present the feature or option with the product.

If you transfer this product to another user, warranty service under the terms of this statement is available to that user for the remainder of the warranty period. You should transfer proof of original purchase and this statement to that user.

### ***Limited warranty service***

The warranty period starts on the date of original purchase as shown on the purchase receipt. The warranty period ends 12 months later.

To obtain warranty service you may be required to present proof of original purchase. You may be required to deliver your product to the Remarketer or Lexmark, or ship it prepaid and suitably packaged to a Lexmark designated location. You are responsible for loss of, or damage to, a product in transit to the Remarketer or the designated location.

When warranty service involves the exchange of a product or part, the item replaced becomes the property of the Remarketer or Lexmark. The replacement may be a new or repaired item. The replacement item assumes the remaining warranty period of the original product.

Replacement is not available to you if the product you present for exchange is defaced, altered, in need of a repair not included in warranty service, damaged beyond repair, or if the product is not free of all legal obligations, restrictions, liens, and encumbrances.

Before you present this product for warranty service, remove all print cartridges, programs, data, and removable storage media (unless directed otherwise by Lexmark).

For further explanation of your warranty alternatives and the nearest Lexmark authorized servicer in your area, contact Lexmark at (800) 332-4120, or on the World Wide Web at <http://support.lexmark.com>.

Remote technical support is provided for this product throughout its warranty period. For products no longer covered by a Lexmark warranty, technical support may not be available or only be available for a fee.

### ***Extent of limited warranty***

We do not warrant uninterrupted or error-free operation of any product.

Warranty service does not include repair of failures caused by:

- Modification or attachments
- Accidents or misuse
- Unsuitable physical or operating environment
- Maintenance by anyone other than Lexmark or a Lexmark authorized servicer
- Operation of a product beyond the limit of its duty cycle
- Use of printing media outside of Lexmark specifications
- Supplies (such as ink) not furnished by Lexmark
- Products, components, parts, materials, software, or interfaces not furnished by Lexmark

**TO THE EXTENT PERMITTED BY APPLICABLE LAW, NEITHER LEXMARK NOR ITS THIRD PARTY SUPPLIERS OR REMARKETERS MAKE ANY OTHER WARRANTY OR CONDITION OF ANY KIND, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS PRODUCT, AND SPECIFICALLY DISCLAIM THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND SATISFACTORY QUALITY. ANY WARRANTIES THAT MAY NOT BE DISCLAIMED UNDER APPLICABLE LAW ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES, EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD. ALL INFORMATION, SPECIFICATIONS, PRICES, AND SERVICES ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE.**

## ***Limitation of liability***

Your sole remedy under this limited warranty is set forth in this document. For any claim concerning performance or nonperformance of Lexmark or a Remarketer for this product under this limited warranty, you may recover actual damages up to the limit set forth in the following paragraph.

Lexmark's liability for actual damages from any cause whatsoever will be limited to the amount you paid for the product that caused the damages. This limitation of liability will not apply to claims by you for bodily injury or damage to real property or tangible personal property for which Lexmark is legally liable. IN NO EVENT WILL LEXMARK BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, INCIDENTAL DAMAGE, OR OTHER ECONOMIC OR CONSEQUENTIAL DAMAGES. This is true even if you advise Lexmark or a Remarketer of the possibility of such damages. Lexmark is not liable for any claim by you based on a third party claim.

This limitation of remedies also applies to claims against any Suppliers and Remarketers of Lexmark. Lexmark's and its Suppliers' and Remarketers' limitations of remedies are not cumulative. Such Suppliers and Remarketers are intended beneficiaries of this limitation.

## ***Additional rights***

Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations or exclusions contained above may not apply to you.

This limited warranty gives you specific legal rights. You may also have other rights that vary from state to state.

## **LEXMARK LICENSE AGREEMENTS**

PLEASE READ CAREFULLY: BY USING THIS PRODUCT, YOU AGREE TO BE BOUND BY ALL THE TERMS AND CONDITIONS OF THESE LICENSE AGREEMENTS. IF YOU DO NOT AGREE WITH THE TERMS OF THESE LICENSE AGREEMENTS, PROMPTLY RETURN THE PRODUCT UNUSED AND REQUEST A REFUND OF THE AMOUNT YOU PAID. IF YOU ARE INSTALLING THIS PRODUCT FOR USE BY OTHER PARTIES, YOU AGREE TO INFORM THE USERS THAT USE OF THE PRODUCT INDICATES ACCEPTANCE OF THESE TERMS.

### ***CARTRIDGE LICENSE AGREEMENT***

I agree that the patented print cartridge(s) shipped with this printing device are sold subject to the following license/agreement: The patented print cartridge(s) contained inside is/are licensed for a single use only and is/are designed to stop working after delivering a fixed amount of ink. A variable amount of ink will remain in the cartridge when replacement is required. After this single use, the license to use the print cartridge terminates, and the used cartridge must be returned only to Lexmark for remanufacturing, refilling or recycling. If I buy another cartridge in the future that is sold subject to the above terms, I accept such terms as to that cartridge. If you do not accept the terms of this single use license/agreement; return this product in its original packaging to your point of purchase. A replacement cartridge sold without these terms is available at [www.lexmark.com](http://www.lexmark.com).

### ***LEXMARK SOFTWARE LICENSE AGREEMENT***

This Software License Agreement ("License Agreement") is a legal agreement between you (either an individual or a single entity) and Lexmark International, Inc. ("Lexmark") that, to the extent your Lexmark product or Software Program is not otherwise subject to a written software license agreement between you and Lexmark or its suppliers, governs your use of any Software Program installed on or provided by Lexmark for use in connection with your Lexmark product. The term "Software Program" includes machine-readable instructions, audio/visual content (such as images and recordings), and associated media, printed materials and electronic documentation, whether incorporated into, distributed with or for use with your Lexmark product.

- 1 STATEMENT OF LIMITED WARRANTY.** Lexmark warrants that the media (e.g., diskette or compact disk) on which the Software Program (if any) is furnished is free from defects in materials and workmanship under normal use during the warranty period. The warranty period is ninety (90) days and commences on the date the Software Program is delivered to the original end-user. This limited warranty applies only to Software Program media purchased new from Lexmark or an Authorized Lexmark Reseller or Distributor. Lexmark will replace the Software Program should it be determined that the media does not conform to this limited warranty.
- 2 DISCLAIMER AND LIMITATION OF WARRANTIES.** EXCEPT AS PROVIDED IN THIS LICENSE AGREEMENT AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, LEXMARK AND ITS SUPPLIERS PROVIDE THE SOFTWARE PROGRAM "AS IS" AND HEREBY DISCLAIM ALL OTHER WARRANTIES AND CONDITIONS, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, TITLE, NON-INFRINGEMENT, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND ABSENCE OF VIRUSES, ALL WITH REGARD TO THE SOFTWARE PROGRAM. This Agreement is to be read in conjunction with certain statutory provisions, as that may be in force from time to time, that imply warranties or conditions or impose obligations on Lexmark that cannot be excluded or modified. If any such provisions apply, then to the extent Lexmark is able, Lexmark hereby limits its liability for breach of those provisions to one of the following: replacement of the Software Program or reimbursement of the price paid for the Software Program.

**3 LICENSE GRANT.** Lexmark grants you the following rights provided you comply with all terms and conditions of this License Agreement:

- a Use.** You may Use one (1) copy of the Software Program. The term "Use" means storing, loading, installing, executing, or displaying the Software Program. If Lexmark has licensed the Software Program to you for concurrent use, you must limit the number of authorized users to the number specified in your agreement with Lexmark. You may not separate the components of the Software Program for use on more than one computer. You agree that you will not Use the Software Program, in whole or in part, in any manner that has the effect of overriding, modifying, eliminating, obscuring, altering or de-emphasizing the visual appearance of any trademark, trade name, trade dress or intellectual property notice that appears on any computer display screens normally generated by, or as a result of, the Software Program.
- b Copying.** You may make one (1) copy of the Software Program solely for purposes of backup, archiving, or installation, provided the copy contains all of the original Software Program's proprietary notices. You may not copy the Software Program to any public or distributed network.
- c Reservation of Rights.** The Software Program, including all fonts, is copyrighted and owned by Lexmark International, Inc. and/or its suppliers. Lexmark reserves all rights not expressly granted to you in this License Agreement.
- d Freeware.** Notwithstanding the terms and conditions of this License Agreement, all or any portion of the Software Program that constitutes software provided under public license by third parties ("Freeware") is licensed to you subject to the terms and conditions of the software license agreement accompanying such Freeware, whether in the form of a discrete agreement, shrink-wrap license, or electronic license terms at the time of download. Use of the Freeware by you shall be governed entirely by the terms and conditions of such license.

**4 TRANSFER.** You may transfer the Software Program to another end-user. Any transfer must include all software components, media, printed materials, and this License Agreement and you may not retain copies of the Software Program or components thereof. The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end-user receiving the transferred Software Program must agree to all these License Agreement terms. Upon transfer of the Software Program, your license is automatically terminated. You may not rent, sublicense, or assign the Software Program except to the extent provided in this License Agreement, and any attempt to do so shall be void.

**5 UPGRADES.** To Use a Software Program identified as an upgrade, you must first be licensed to the original Software Program identified by Lexmark as eligible for the upgrade. After upgrading, you may no longer use the original Software Program that formed the basis for your upgrade eligibility.

**6 LIMITATION ON REVERSE ENGINEERING.** You may not alter, decrypt, reverse engineer, reverse assemble, reverse compile or otherwise translate the Software Program, except as and to the extent expressly permitted to do so by applicable law for the purposes of inter-operability, error correction, and security testing. If you have such statutory rights, you will notify Lexmark in writing of any intended reverse engineering, reverse assembly, or reverse compilation. You may not decrypt the Software Program unless necessary for the legitimate Use of the Software Program.

**7 ADDITIONAL SOFTWARE.** This License Agreement applies to updates or supplements to the original Software Program provided by Lexmark unless Lexmark provides other terms along with the update or supplement.

**8 LIMITATION OF REMEDIES.** To the maximum extent permitted by applicable law, the entire liability of Lexmark, its suppliers, affiliates, and resellers, and your exclusive remedy shall be as follows: Lexmark will provide the express limited warranty described above. If Lexmark does not remedy defective media as warranted, you may terminate your license and your money will be refunded upon the return of all of your copies of the Software Program.

**9 LIMITATION OF LIABILITY.** To the maximum extent permitted by applicable law, for any claim arising out of Lexmark's limited warranty, or for any other claim whatsoever related to the subject matter of this Agreement, Lexmark's and its suppliers' liability for all types of damages, regardless of the form of action or basis (including contract, breach, estoppel, negligence, misrepresentation, or tort), shall be limited to the greater of \$5,000 or the money paid to Lexmark or its Authorized remarketers for the license hereunder for the Software Program that caused the damages or that is the subject matter of, or is directly related to, the cause of action.

IN NO EVENT WILL LEXMARK, ITS SUPPLIERS, SUBSIDIARIES, OR RESELLERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, EXEMPLARY, PUNITIVE, OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LOST PROFITS OR REVENUES, LOST SAVINGS, INTERRUPTION OF USE OR ANY LOSS OF, INACCURACY IN, OR DAMAGE TO, DATA OR RECORDS, FOR CLAIMS OF THIRD PARTIES, OR DAMAGE TO REAL OR TANGIBLE PROPERTY, FOR LOSS OF PRIVACY ARISING OUT OR IN ANY WAY RELATED TO THE USE OF OR INABILITY TO USE THE SOFTWARE PROGRAM, OR OTHERWISE IN CONNECTION WITH ANY PROVISION OF THIS LICENCE AGREEMENT), REGARDLESS OF THE NATURE OF THE CLAIM, INCLUDING BUT NOT LIMITED TO BREACH OF WARRANTY OR CONTRACT, TORT (INCLUDING NEGLIGENCE OR STRICT LIABILITY), AND EVEN IF LEXMARK, OR ITS SUPPLIERS, AFFILIATES, OR REMARKETERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY YOU BASED ON A THIRD-PARTY CLAIM, EXCEPT TO THE EXTENT THIS EXCLUSION OF DAMAGES IS DETERMINED LEGALLY INVALID. THE FOREGOING LIMITATIONS APPLY EVEN IF THE ABOVE-STATED REMEDIES FAIL OF THEIR ESSENTIAL PURPOSE.

**10 TERM.** This License Agreement is effective unless terminated or rejected. You may reject or terminate this license at any time by destroying all copies of the Software Program, together with all modifications, documentation, and merged portions in any form, or as otherwise described herein. Lexmark may terminate your license upon notice if you fail to comply with any of the terms of this License Agreement. Upon such termination, you agree to destroy all copies of the Software Program together with all modifications, documentation, and merged portions in any form.

- 11 TAXES.** You agree that you are responsible for payment of any taxes including, without limitation, any goods and services and personal property taxes, resulting from this Agreement or your Use of the Software Program.
- 12 LIMITATION ON ACTIONS.** No action, regardless of form, arising out of this Agreement may be brought by either party more than two years after the cause of action has arisen, except as provided under applicable law.
- 13 APPLICABLE LAW.** This Agreement is governed by the laws of the Commonwealth of Kentucky, United States of America. No choice of law rules in any jurisdiction shall apply. The UN Convention on Contracts for the International Sale of Goods shall not apply.
- 14 UNITED STATES GOVERNMENT RESTRICTED RIGHTS.** The Software Program has been developed entirely at private expense. Rights of the United States Government to use the Software Program is as set forth in this Agreement and as restricted in DFARS 252.227-7014 and in similar FAR provisions (or any equivalent agency regulation or contract clause).
- 15 CONSENT TO USE OF DATA.** You agree that Lexmark, its affiliates, and agents may collect and use information you provide in relation to support services performed with respect to the Software Program and requested by you. Lexmark agrees not to use this information in a form that personally identifies you except to the extent necessary to provide such services.
- 16 EXPORT RESTRICTIONS.** You may not (a) acquire, ship, transfer, or reexport, directly or indirectly, the Software Program or any direct product therefrom, in violation of any applicable export laws or (b) permit the Software Program to be used for any purpose prohibited by such export laws, including, without limitation, nuclear, chemical, or biological weapons proliferation.
- 17 AGREEMENT TO CONTRACT ELECTRONICALLY.** You and Lexmark agree to form this License Agreement electronically. This means that when you click the "Agree" or "Yes" button on this page or use this product, you acknowledge your agreement to these License Agreement terms and conditions and that you are doing so with the intent to "sign" a contract with Lexmark.
- 18 CAPACITY AND AUTHORITY TO CONTRACT.** You represent that you are of the legal age of majority in the place you sign this License Agreement and, if applicable, you are duly authorized by your employer or principal to enter into this contract.
- 19 ENTIRE AGREEMENT.** This License Agreement (including any addendum or amendment to this License Agreement that is included with the Software Program) is the entire agreement between you and Lexmark relating to the Software Program. Except as otherwise provided for herein, these terms and conditions supersede all prior or contemporaneous oral or written communications, proposals, and representations with respect to the Software Program or any other subject matter covered by this License Agreement (except to the extent such extraneous terms do not conflict with the terms of this License Agreement, any other written agreement signed by you and Lexmark relating to your Use of the Software Program). To the extent any Lexmark policies or programs for support services conflict with the terms of this License Agreement, the terms of this License Agreement shall control.

# Networking glossary

---

<b>ad hoc mode</b>	A setting for a wireless device that lets it communicate directly with other wireless devices without an access point or router
<b>ad hoc network</b>	A wireless network that does not use an access point
<b>AutoIP address</b>	An IP address automatically assigned by a network device. If the device is set to use DHCP, but no DHCP server is available, an AutoIP address may be assigned by the device.
<b>BSS (Basic Service Set)</b>	Basic Service Set describes the type of wireless network that you are using. The BSS type can be one of the following: Infrastructure network or Ad-Hoc network.
<b>channel</b>	A specific radio frequency used by two or more wireless devices to communicate with each other. All devices on the network must use the same channel.
<b>DHCP (Dynamic Host Configuration Protocol)</b>	A language used by DHCP servers
<b>DHCP IP address</b>	An IP address automatically assigned by a DHCP server
<b>DHCP server</b>	A computer or router that gives a unique IP address to each device on the network. Unique addresses prevent conflicts.
<b>infrastructure mode</b>	A setting for a wireless device that lets it communicate directly with other wireless devices using an access point or router
<b>installation cable</b>	Connects the printer to the computer temporarily during some methods of installation.
<b>internal wireless print server</b>	A device that lets computers and printers talk to each other over a network without cables
<b>IP (Internet Protocol) address</b>	The network address of a computer or printer. Each device on the network has its own network address. The address may be assigned manually by you (Static IP address), automatically by the DHCP server (DHCP IP address), or automatically by the device (AutoIP address).
<b>ipconfig</b>	A command that displays the IP address and other network information of a Windows computer
<b>MAC (Media Access Control) address</b>	A hardware address that uniquely identifies each device on a network. You can usually find the MAC address printed on the device.
<b>MAC filtering</b>	A method of limiting access to your wireless network by specifying which MAC addresses may communicate on the network. This setting may be specified on wireless routers or access points.
<b>network adapter/card</b>	A device that lets computers or printers talk to each other over a network
<b>network hub</b>	A device that connects multiple devices on a wired network
<b>network name</b>	See “SSID (Service Set Identifier)” on page 117
<b>ping</b>	A test to see if your computer can communicate with another device
<b>printer nickname</b>	The name you assign to your printer so that you and others can identify it on the network
<b>router</b>	A device that shares a single Internet connection with multiple computers or other devices. The basic router controls network traffic.
<b>security key</b>	A password, such as a WEP key or a WPA pass phrase, used to make a network secure
<b>signal strength</b>	Measure of how strongly a transmitted signal is being received
<b>SSID (Service Set Identifier)</b>	The name of a wireless network. When you connect a printer to a wireless network, the printer needs to use the same SSID as the network. Also referred to as network name or BSS (Basic Service Set).
<b>Static IP address</b>	An IP address assigned manually by you
<b>switch</b>	A device similar to a network hub that can connect different networks together

<b>UAA (Universally Administered Address)</b>	An address assigned to a network printer or print server by the manufacturer. To find the UAA, print a network setup page and look for the UAA listing.
<b>USB cable</b>	A lightweight, flexible cable that lets the printer communicate with the computer at much higher speeds than parallel cables
<b>USB port</b>	A small, rectangular port on the back of the computer that connects the peripheral devices using a USB cable, and lets them communicate at high speeds
<b>WEP (Wired Equivalent Privacy)</b>	A security setting that helps prevent unauthorized access to a wireless network. Other possible security settings are WPA and WPA2.
<b>wireless access point</b>	A device that connects wireless devices together to form a wireless network
<b>wireless router</b>	A router that also serves as a wireless access point
<b>Wi-Fi</b>	An industry term that describes the technology used to create an interoperable wireless local area network (WLAN).
<b>WPA (Wi-Fi Protected Access)</b>	A security setting that helps prevent unauthorized access to a wireless network. WPA is not supported on ad hoc wireless networks. Other possible security settings are WEP and WPA2.
<b>WPA2</b>	A newer version of WPA. Older routers are less likely to support this. Other possible security settings are WPA and WEP.

# Index

---

## A

- access cover 15
- ad hoc wireless network
  - adding a printer using Windows 27
  - creating using Windows 25
- adjusting brightness
  - automatically 49, 51
- adjusting the hue of a photo 50
- adjusting the saturation of a photo 50
- Advanced button 18
- aligning print cartridges 59
- assigning IP address 24
- automatic duplex 41

## B

- banner paper
  - loading 31
- banner paper jams 100
- banner printing problems
  - checking spool settings 90
- banner, printing 39
- blank or incorrect page prints 85
- blurring photo 49
- booklet, assembling 38
- booklets
  - printing 37
- both sides of the paper, printing on 41
- box contents 13
- Brightness
  - automatic adjustment 49, 51
- Brightness / Contrast setting
  - changing 51
- button
  - duplex 14
  - form feed 14
  - power 14
- buttons, Productivity Studio
  - Photo Greeting Cards 17
  - Photo Packages 17
  - Poster 17
  - Transfer Photos 17
  - using 17
- buttons, Solution Center
  - Advanced 18
  - How To 18
  - Maintenance 18
  - Troubleshooting 18
  - using 18

## C

- cable connections
  - checking 91, 92
- canceling print jobs 35
- cannot print
  - from a flash drive 96
  - from a memory card 96
  - from digital camera using PictBridge 96
- card reader light 14
- cards
  - loading 29
  - memory 43
  - printing 36
- cartridge carrier jam 101
- cartridge missing error 104
- cartridge nozzles, cleaning 59
- cartridges, print
  - aligning 59
  - cleaning the nozzles 59
  - installing 56
  - ordering 61
  - preserving 61
  - removing 57
  - using genuine Lexmark 58
  - wiping 59
- CD
  - printing photos from 51
  - transferring all photos using computer 46
  - transferring selected photos using the computer 46
- changing
  - temporary files preferences 47
- changing gamma value of a photo or image 50
- changing library preferences 47
- Changing photo resolution/size 48
- changing searched folders preferences 47
- changing temporary files preferences 47
- changing transfer settings 48
- changing wireless settings after installation 77
- changing wireless settings after installation (Windows) 81
- characters on printout are missing or unexpected 85
- check printer ports (Windows) 81
- checking printer readiness 89

- checking your network name (Windows) 79
- cleaning
  - exterior of the printer 60
  - print cartridge nozzles 59
- color effects
  - applying 51
- colors on paper do not match colors on the screen 86
- communication not available error 104
- communication problems
  - establishing bidirectional communication 95
- connecting
  - PictBridge-enabled digital camera 45
- connecting cables 91, 92
- contents, box 13
- creating and viewing slideshow 55
- cropping
  - photo 48
- custom-size paper, loading 30
- custom-size paper, printing 38

## D

- Despeckle
  - change setting 50
- digital camera
  - printing photos using the computer 51
- Digital Print Order Format
  - printing photos 55
- documents
  - printing 32
- duplex
  - light is blinking 64
- duplex unit 14
  - does not operate correctly 101
- duplexing
  - understanding 40
- duplexing (two-sided printing) manually 41
- duplexing (two-sided printing) automatically 41

## E

- emission
  - notices 108, 109, 110, 111
- Enhancements tab
  - blur 49

- Brightness / Contrast 51
- Brightness / Contrast setting 51
- Despeckle setting 50
- enhance 50
- hue 50
- saturation 50
- selecting color effect 51
- sharpen 49
- enhancing photo 50
- envelopes
  - loading 28
  - printing 36
- error messages
  - cartridge missing 104
  - clearing 104
  - communication not available 104
  - general printing problem 105
  - ink low 105
  - out of memory 105
  - out of paper 105
  - paper jam 106
  - printing failure 105
  - unsupported file types found on memory card 106
- error messages troubleshooting
  - print file error 106
- exterior of the printer
  - cleaning 60

## F

- factory default settings
  - resetting internal wireless print server 77
  - resetting the printer 40
- faded colors 86
- FCC notices 108
- finding
  - information 9
  - publications 9
  - Web site 9
- flash drive
  - cannot print from 96
  - inserting 44
  - printing documents or photos from 35
  - printing photos using the computer 51
  - transferring all photos using computer 46
  - transferring selected photos using the computer 46
- fonts
  - resolving problems 90

## G

- gamma value
  - changing 50
- general printing problem error 105
- getting a document to print 93
- glossy paper, loading 28
- glossy photo paper or transparencies stick together 86
- greeting cards
  - loading 29
  - printing 36

## H

- heavyweight matte paper, loading 28
- How To button 18

## I

- image, changing gamma value 50
- improving print quality 81
- index cards
  - loading 29
  - printing 36
- information, finding 9
- ink levels seem incorrect 84
- ink levels seem to go down quickly 85
- ink low error 105
- inserting
  - flash drives 44
  - memory cards 43
- installing
  - network printer 24
  - print cartridges 56
  - printer software 16, 68
- internal wireless print server 16
  - resetting to factory default settings 77
- IP address, assigning 24
- iron-on transfers, loading 30
- iron-on transfers, printing 38

## J

- jams and misfeeds troubleshooting
  - banner paper jams 100
  - cartridge carrier jam 101
  - paper jam in printer 97
  - paper jam in the duplex unit 98
  - paper jam in the paper support 97
  - paper or specialty media misfeeds 99
  - printer does not feed paper, envelopes, or specialty media 99

## L

- labels, loading 29
- last page first 34
- Lexmark Productivity Studio
  - creating and viewing slideshow 55
- library preferences
  - changing 47
- loading
  - banner paper 31
  - custom-size paper 30
  - envelopes 28
  - glossy paper 28
  - greeting cards 29
  - heavyweight matte paper 28
  - index cards 29
  - iron-on transfers 30
  - labels 29
  - paper 28
  - photo cards 29
  - photo paper 28
  - postcards 29
  - transparencies 30

## M

- MAC address 22
- Maintenance button 18
- manual duplex 41
- memory card
  - cannot print from 96
  - inserting 43
  - printing documents or photos from 35
  - printing photos using the computer 51
  - transferring all photos using the computer 45
  - transferring selected photos using the computer 46
- memory card and PictBridge
  - troubleshooting
    - nothing happens when memory card is inserted 102
- memory card cannot be inserted 102
- memory card reader and PictBridge
  - troubleshooting
    - power light and duplex light are blinking alternately 64
- memory card slots 14
- memory card troubleshooting
  - memory card cannot be inserted 102



## N

- network adapters
  - using 24
- network printer
  - installing 24
- network printer does not show up in printer selection list during installation (Windows) 78
- network setup page
  - printing 23
- networking
  - IP addresses 23
- noise emission levels 111
- nothing happens when memory card is inserted 102
- notices 108, 109, 110, 111, 112
- N-up feature 34

## O

- One-Click Auto Fix 49
- ordering paper and other supplies 61
- out of memory error 105
- out of paper error 105

## P

- page does not print 67
- page prints with different fonts 86
- paper
  - choosing specialty 35
- paper and other supplies
  - ordering 61
- paper continues to jam 100
- paper exit tray 15
- paper feed guard 15
- paper guides 15
- paper jam
  - duplex unit 98
  - paper support 97
  - printer 97
- paper jam error 106
- paper or specialty media misfeeds 99
- paper support 15
- paper, loading 28
- partial document or photo prints 81
- partial photo prints when using PictBridge 97
- parts
  - access cover 15
  - card reader light 14
  - duplex button 14
  - duplex unit 14
  - form feed button 14

- memory card slots 14
- paper exit tray 15
- paper feed guard 15
- paper guides 15
- paper support 15
- PictBridge port 14
- power button 14
- power supply 16
- print server 16
- USB port 16
- Wi-Fi indicator 15
- pausing print jobs 35
- photo
  - adjusting hue 50
  - adjusting saturation 50
  - applying color effect 51
  - blurring 49
  - cropping 48
  - enhancing 50
  - sharpening 49
- photo cards, loading 29
- Photo Greeting Cards button 17
- Photo Packages 52
- Photo Packages button 17
- photo paper, loading 28
- Photo resolution/size
  - changing 48
- photo smudges 84
- photo, changing gamma value 50
- photos
  - automatic red-eye reduction 49
  - printing all from a memory device 53
  - printing from a Web page 33
  - printing from CD using the computer 51
  - printing from digital camera using the computer 51
  - printing from PictBridge-enabled digital camera 54
  - printing from removable storage device using the computer 51
  - red-eye reduction 49
  - rotating 48
  - smudges, preventing 84
  - transferring all photos from CD or flash drive using computer 46
  - transferring all photos from memory card using the computer 45
  - transferring selected photos from CD or flash drive using the computer 46

- transferring selected photos from memory card using the computer 46
- photos do not print from memory card across wireless network 103
- PictBridge port 14
- PictBridge-enabled digital camera
  - connecting 45
  - printing photos from 54
- ping the printer (Windows) 80
- ping the wireless access point (Windows) 79
- poor text and graphic quality 82
- postcards
  - loading 29
  - printing 36
- poster 37
- Poster button 17
- posters, printing 36
- power
  - button 14
  - light blinking alternately with duplex light 64
  - light is blinking 64
  - supply 16
- power button is not lit 63
- preferences, library
  - changing 47
- preferences, searched folders
  - changing 47
- preferences, temporary files
  - changing 47
- print cartridge
  - checking 84
- print cartridge nozzles, cleaning 59
- print cartridges
  - aligning 59
  - cleaning the nozzles 59
  - installing 56
  - ordering 61
  - preserving 61
  - refilling 58
  - removing 57
  - using genuine Lexmark 58
  - wiping 59
- print file error 106
- print is dark or smudged 87
- print jobs
  - canceling 35
- print quality troubleshooting
  - skewed print 84
- print quality, improving 81
- print settings
  - saving and deleting 39

- print speed is slow 83
- print troubleshooting
  - blank or incorrect page prints 85
  - cannot print from digital camera using PictBridge 96
  - checking printer readiness 89
  - duplex unit does not operate correctly 101
  - establishing bidirectional communication 95
  - flash drive, cannot print from 96
  - improving print quality 81
  - ink levels seem incorrect 84
  - ink levels seem to go down quickly 85
  - memory card, cannot print from 96
  - partial document or photo prints 81
  - partial photo prints when using PictBridge 97
  - photo smudges 84
  - poor quality at the edges of the page 83
  - poor text and graphic quality 82
  - print speed is slow 83
  - printer is out of paper 95
  - test page does not print 92
  - white lines appear in graphics or black areas 88
- printed characters are improperly formed or not aligned 87
- printer
  - no communication 95
- printer cannot communicate over peer-to-peer network 93
- printer does not feed paper, envelopes, or specialty media 99
- printer is out of paper 95
- printer plugged in but does not print 93
- printer software
  - installing 16
  - reinstalling 68
  - removing 68
  - updating 95
- printer status
  - checking 89
- printing
  - all photos from a memory device 53
  - banner 39
  - booklets 37
  - cards 36
  - collate 34

- custom-size paper 38
- document 32
- documents or photos from memory card or flash drive 35
- envelopes 36
- greeting cards 36
- index cards 36
- iron-on transfers 38
- last page first 34
- multiple pages on one sheet 34
- network setup page 23
- on both sides of the paper 40
- Photo Packages 52
- photos from CD using the computer 51
- photos from digital camera using the computer 51
- photos from PictBridge-enabled digital camera 54
- photos from Productivity Studio 52
- photos from removable storage device using the computer 51
- photos from the Productivity Studio 52
- photos using DPOF settings 55
- postcards 36
- poster 37
- posters 36
- reverse page order 34
- test page 91
- transparencies 39
- two-sided 40, 41
- Web page 32
- Web page, photos only 33
- printing failure error 105
- printouts have alternating bands of light and dark print 87
- Productivity Studio
  - printing photos 52
  - viewing photos 52
- Productivity Studio buttons
  - Photo Greeting Cards 17
  - Photo Packages 17
  - Poster 17
  - Transfer Photos 17
- understanding 17
- Productivity Studio, understanding 17
- publications, finding 9

**Q**

- quality settings, checking 91
- Quick Fixes tab
  - using One-Click Auto Fix 49

**R**

- ready or busy printing is listed as status 91
- recycling
  - WEEE statement 111
- red-eye
  - automatic reduction 49
  - manual reduction 49
- refilling print cartridges 58
- removing print cartridges 57
- resetting
  - internal wireless print server to factory default settings 77
  - printer to factory default 40
- reverse page order 34
- rotating photo 48
- run the Wireless Setup Utility (Windows) 80

**S**

- safety information 2
- saving and deleting print settings 39
- searched folders preferences
  - changing 47
- security information 19
- security keys 74
- setup troubleshooting
  - duplex light is blinking 64
  - page does not print 67
  - power button is not lit 63
  - power light is blinking 64
  - software does not install 66
- sharpening photo 49
- slideshow
  - creating and viewing 55
- smudging, preventing in photos 84
- software
  - Productivity Studio 17
  - removing and reinstalling 68
  - Solution Center 18
- software does not install 66
- Solution Center
  - understanding 18
- Solution Center buttons
  - Advanced 18
  - How To 18
  - Maintenance 18
  - Troubleshooting 18
  - understanding 18
- solving printer communication problems 68
- speed settings, checking 91

## T

- test page
  - printing 91
- test page does not print 92
- Toolbar
  - printing a Web page 32
  - printing only the photos from a Web page 33
- Transfer Photos button 17
- transfer settings
  - changing 48
- transferring photos
  - from CD using computer 46
  - from CD using the computer 46
  - from flash drive using computer 46
  - from flash drive using the computer 46
  - from memory card using the computer 45, 46
- transparencies
  - loading 30
  - printing 39
- transparencies or photos contain white lines 88
- troubleshooting
  - cartridge missing error 104
  - characters on printout are missing or unexpected 85
  - checking printer status 89
  - checking quality/speed settings 91
  - colors on paper do not match colors on the screen 86
  - communication not available error 104
  - faded colors 86
  - font selections 85
  - general printing problem error 105
  - getting document to print 93
  - glossy photo paper or transparencies stick together 86
  - ink low error 105
  - out of memory error 105
  - page prints with different fonts 86
  - paper continues to jam 100
  - paper jam error 106
  - print is dark or smudged 87
  - printed characters are improperly formed or not aligned 87
  - printer cannot communicate over peer-to-peer network 93
  - printer communication problems 68
  - printer is trying to print to file 93
  - printer not communicating with computer 95
  - printer plugged in but does not print 93
  - printer status 89
  - printouts have alternating bands of light and dark print 87
  - ready or busy printing is listed as status 91
  - resolving font problems 90
  - transparencies or photos contain white lines 88
  - unsupported file types found on memory card 106
  - vertical straight lines are not smooth 88
  - wrong printer attached 95
- Troubleshooting button 18
- troubleshooting, error messages
  - out of paper 105
  - print file error 106
  - printing failure error 105
- troubleshooting, jams and misfeeds
  - banner paper jams 100
  - cartridge carrier jam 101
  - paper jam in printer 97
  - paper jam in the duplex unit 98
  - paper jam in the paper support 97
  - paper or specialty media misfeeds 99
  - printer does not feed paper, envelopes, or specialty media 99
- troubleshooting, memory card
  - memory card cannot be inserted 102
- troubleshooting, memory card and PictBridge
  - nothing happens when memory card is inserted 102
- troubleshooting, memory card reader and PictBridge
  - power light and duplex light are blinking alternately 64
- troubleshooting, print
  - blank or incorrect page prints 85
  - cannot print from digital camera using PictBridge 96
  - checking printer readiness 89
  - duplex unit does not operate correctly 101
  - establishing bidirectional communication 95
  - flash drive, cannot print from 96
  - improving print quality 81
  - ink levels seem incorrect 84
  - ink levels seem to go down quickly 85
  - memory card, cannot print from 96
  - partial document or photo prints 81
  - partial photo prints when using PictBridge 97
  - photo smudges 84
  - poor quality at the edges of the page 83
  - poor text and graphic quality 82
  - print speed is slow 83
  - printer is out of paper 95
  - test page does not print 92
  - white lines appear in graphics or black areas 88
- troubleshooting, print quality
  - skewed print 84
- troubleshooting, setup
  - duplex light is blinking 64
  - page does not print 67
  - power button is not lit 63
  - power light is blinking 64
  - software does not install 66
- troubleshooting, wireless
  - changing wireless settings after installation 77
  - changing wireless settings after installation (Windows) 81
  - check printer ports (Windows) 81
  - checking network name (Windows) 79
  - network printer does not show up in printer selection list during installation (Windows) 78
  - photos do not print from memory card across wireless network 103
  - ping printer (Windows) 80
  - ping wireless access point (Windows) 79
  - run Wireless Setup Utility (Windows) 80
  - WiFi indicator light is not lit 72
  - wireless network printer does not print 75
  - wireless printer is no longer working 76

- Wireless Setup Utility cannot communicate with printer during installation 78
- Wi-Fi indicator light is blinking orange 70
- Wi-Fi indicator light is orange 70
- two-sided
  - printing, automatic 41
  - printing, manual 41
- two-sided printing
  - understanding 40

## U

- unsupported file types found on memory card 106
- updating printer software 95
- USB port 16
  - enabling 69
- using One-Click Auto Fix 49
  - Quick Fixes tab 49

## V

- vertical straight lines are not smooth 88
- viewing
  - photos from Productivity Studio 52
  - photos in the Productivity Studio 52

## W

- Web page
  - printing 32
  - printing only the photos 33
- Web site
  - finding 9
- white lines appear in graphics or black areas 88
- WiFi indicator
  - light is not lit 72
- wireless network
  - adding a printer to existing ad hoc network using Windows 27
  - common home configurations 20
  - creating an ad hoc network using Windows 25
  - MAC address 22
  - networking overview 20
  - security keys 74
  - signal strength 24
  - types of wireless networks 24
- wireless network compatibility 12
- wireless network printer does not print 75

- wireless printer is no longer working 76
- Wireless Setup Utility cannot communicate with printer during installation 78
- wireless troubleshooting
  - changing wireless settings after installation 77
  - changing wireless settings after installation (Windows) 81
  - check printer ports (Windows) 81
  - checking network name (Windows) 79
  - network printer does not show up in printer selection list during installation (Windows) 78
  - photos do not print from memory card across wireless network 103
  - ping printer (Windows) 80
  - ping wireless access point (Windows) 79
  - run Wireless Setup Utility (Windows) 80
  - WiFi indicator light is not lit 72
  - wireless network printer does not print 75
  - wireless printer is no longer working 76
  - Wireless Setup Utility cannot communicate with printer during installation 78
  - Wi-Fi indicator light is blinking orange 70
  - Wi-Fi indicator light is orange 70
- Wi-Fi indicator 15
- Wi-Fi indicator light is blinking orange 70
- Wi-Fi indicator light is orange 70
- wrong printer attached 95