

Digital Video Camera Recorder

Operating Guide

Table of contents

Getting started

Recording/Playback

Making good use of your camcorder

Saving movies and photos with a computer

Saving images with an external device

Customizing your camcorder

Additional information

Quick reference



HANDYCAM



Read this first

Before operating the unit, please read this manual thoroughly, and retain it for future reference.

WARNING

To reduce fire or shock hazard, do not expose the unit to rain or moisture.

Do not expose the batteries to excessive heat such as sunshine, fire or the like.

CAUTION

Battery pack

If the battery pack is mishandled, the battery pack can burst, cause a fire or even chemical burns. Observe the following cautions.

- Do not disassemble.
- Do not crush and do not expose the battery pack to any shock or force such as hammering, dropping or stepping on it.
- Do not short circuit and do not allow metal objects to come into contact with the battery terminals.
- Do not expose to high temperature above 60°C (140 °F) such as in direct sunlight or in a car parked in the sun.
- Do not incinerate or dispose of in fire.
- Do not handle damaged or leaking lithium ion batteries.
- Be sure to charge the battery pack using a genuine Sony battery charger or a device that can charge the battery pack.
- Keep the battery pack out of the reach of small children.
- Keep the battery pack dry.
- Replace only with the same or equivalent type recommended by Sony.
- Dispose of used battery packs promptly as described in the instructions.

Replace the battery with the specified type only. Otherwise, fire or injury may result.

AC Adaptor

Do not use the AC Adaptor placed in a narrow space, such as between a wall and furniture.

Use the nearby wall outlet (wall socket) when using the AC Adaptor. Disconnect the AC Adaptor from the wall outlet (wall socket) immediately if any malfunction occurs while using your camcorder.

Even if your camcorder is turned off, AC power source (mains) is still supplied to it while connected to the wall outlet (wall socket) via the AC Adaptor.

FOR CUSTOMERS IN EUROPE

Notice for the customers in the countries applying EU Directives

The manufacturer of this product is Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. The Authorized Representative for EMC and product safety is Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters please refer to the addresses given in separate service or guarantee documents.

ATTENTION

This product has been tested and found compliant with the limits set out in the EMC Directive for using connection cables shorter than 3 meters (9.8 feet).

The electromagnetic fields at the specific frequencies may influence the picture and sound of this unit.

Notice

If static electricity or electromagnetism causes data transfer to discontinue midway (fail), restart the application or disconnect and connect the communication cable (USB, etc.) again.



Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.



Disposal of waste batteries (applicable in the European Union and other European countries with separate collection systems)

This symbol on the battery or on the packaging indicates that the battery provided with this product shall not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. The chemical symbols for mercury (Hg) or lead (Pb) are added if the battery contains more than 0.0005% mercury or 0.004% lead. By ensuring these batteries are disposed of correctly, you will help prevent potentially negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling of the battery. The recycling of the materials



will help to conserve natural resources. In case of products that for safety, performance or data integrity reasons require a permanent connection with an incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery will be treated properly, hand over the product at end-of-life to the applicable collection point for the recycling of electrical and electronic equipment.

For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery over to the applicable collection point for the recycling of waste batteries.

For more detailed information about recycling of this product or battery, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

Notice for customers in the United Kingdom

A moulded plug complying with BS 1363 is fitted to this equipment for your safety and convenience.

Should the fuse in the plug supplied need to be replaced, a fuse of the same rating as the supplied one and approved by ASTA or BSI to BS 1362, (i.e., marked with an  or  mark) must be used. If the plug supplied with this equipment has a detachable fuse cover, be sure to attach the fuse cover after you change the fuse. Never use the plug without the fuse cover. If you should lose the fuse cover, please contact your nearest Sony service station.

For the customers in the U.S.A.

If you have any questions about this product, you may call:
Sony Customer Information Center 1-800-222-SONY (7669).
The number below is for the FCC related matters only.

Regulatory Information

Declaration of Conformity

Trade Name: SONY
Model No.: DCR-SX45E
Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo, San Diego, CA 92127 U.S.A.
Telephone No.: 858-942-2230
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

Trade Name: SONY
Model No.: DCR-SX65E
Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo, San Diego, CA 92127 U.S.A.
Telephone No.: 858-942-2230
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

Trade Name: SONY
Model No.: DCR-SX85E
Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo, San Diego, CA 92127 U.S.A.
Telephone No.: 858-942-2230
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the

equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The supplied interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.


Battery pack

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Supplied items

The numbers in () are the supplied quantity.

- AC Adaptor (1)
- Power cord (Mains lead) (1)
- A/V connecting cable (1) **A**
- USB connection support cable (1) **B**
 - Attach this to the Built-in USB Cable (p. 12), if the Built-in USB Cable is not long enough.
- Rechargeable battery pack NP-FV30 (1)
- CD-ROM “Handycam” Application Software (1)
 - “PMB” (software, including “PMB Help”)
 - “Handycam” Handbook (PDF)
- “Operating Guide” (This manual) (1)




- “PMB Portable” software is pre-loaded on the camcorder (p. 33).
- See page 17 for the memory card you can use with this camcorder.


Using the camcorder

- Do not hold the camcorder by the following parts, and also do not hold the camcorder by the jack covers.

LCD screen



Battery pack



Built-in USB Cable




- The camcorder is not dustproofed, dripproofed or waterproofed. See “Precautions” (p. 55).

Menu items, LCD panel, and lens

- A menu item that is grayed out is not available under the current recording or playback conditions.

- The LCD screen is manufactured using extremely high-precision technology, so over 99.99% of the pixels are operational for effective use. However, there may be some tiny black points and/or bright points (white, red, blue, or green in color) that appear constantly on the LCD screen. These points are normal results of the manufacturing process and do not affect the recording in any way.



White, red, blue or green points

- Exposing the LCD screen or the lens to direct sunlight for long periods of time may cause malfunctions.
- Do not aim at the sun. Doing so might cause your camcorder to malfunction. Take images of the sun only in low light conditions, such as at dusk.

About changing the language setting

- The on-screen displays in each local language are used for illustrating the operating procedures. Change the screen language before using your camcorder if necessary (p. 15).

Recording

- When you use a memory card with your camcorder for the first time, formatting the memory card with your camcorder (p. 47) is recommended for stable operation. All data recorded on the memory card will be deleted when it is formatted, and cannot be recovered. Save important data to your computer, etc., beforehand.
- Before starting to record, test the recording function to make sure that the image and sound are recorded without any problems.
- Compensation for the contents of recordings cannot be provided, even if recording or

playback is not possible due to a malfunction of the camcorder, storage media, etc.

- TV color systems differ depending on the country/region. To view your recordings on a TV, you need a PAL system-based TV.
- Television programs, films, video tapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to copyright laws.

Note on playback

- Images recorded on your camcorder may not play correctly on other devices. Conversely, images recorded on other devices may not play correctly on this camcorder.
- Movies recorded on SD memory cards cannot be played on AV equipment of other manufacturers.

Save all your recorded image data

- To prevent your image data from being lost, save all your recorded images on external media periodically. It is recommended that you save the image data on a disc such as a DVD-R using your computer. Also, you can save your image data using a VCR or a DVD/HDD recorder, etc. (p. 38).

Notes on battery pack/AC Adaptor

- Be sure to remove the battery pack or the AC Adaptor after turning off the camcorder.
- Disconnect the AC Adaptor from the camcorder, holding both the camcorder and the DC plug.


Note on the camcorder/battery pack temperature

- When the temperature of the camcorder or battery pack becomes extremely high or extremely low, you may not be able to record or play back on the camcorder, due to the protection features of the camcorder being activated in such situations. In this case, an indicator appears on the LCD screen.

When the camcorder is connected to a computer or accessories

- Do not try to format the recording media of the camcorder using a computer. If you do so, your camcorder may not operate correctly.
- When connecting your camcorder to another device with a cable, be sure to insert the connector plug in the correct way. Pushing the plug forcibly into the terminal will damage the terminal and may result in a malfunction of your camcorder.
- Do not close the LCD screen while your camcorder is turned on and connected to USB. The recorded movies or photos may be lost.

If you cannot record/play back images, perform [MEDIA FORMAT]

- If you repeat recording/deleting images for a long time, fragmentation of data occurs on the recording media. Images cannot be saved or recorded. In such a case, save your images on some type of external media first, and then perform [MEDIA FORMAT] by touching **MENU** (MENU) → [Show others] → [MEDIA FORMAT] (under  [MANAGE MEDIA] category) → the desired medium (DCR-SX65E/SX85E) → [YES] → [YES] → **OK**.

Carl Zeiss lens

- Your camcorder is equipped with a Carl Zeiss lens, which was developed jointly by Carl Zeiss, in Germany, and Sony Corporation, and produces superior images. It adopts the MTF measurement system for video cameras and offers a quality typical of a Carl Zeiss lens. MTF= Modulation Transfer Function. The number value indicates the amount of light from a subject coming into the lens.

Notes on optional accessories

- We recommend using genuine Sony accessories.
- Availability of such products is subject to country/region.

About images, illustrations, and screen displays of this manual

- The example images used in this manual for

illustration purposes are captured using a digital still camera, and therefore may appear different from images and screen indicators that actually appear on your camcorder. And, the illustrations of your camcorder and its screen indication are exaggerated or simplified for understandability.



- In this manual, the internal memory (DCR-SX65E/SX85E) of your camcorder and memory card are called “recording media.”
- Design and specifications of your camcorder and accessories are subject to change without notice.

Confirm the model name of your camcorder

- The model name is shown in this manual when there is a difference in specification between models. Confirm the model name on the bottom of your camcorder.
- The main differences in specification of this series are as follows.

	Recording media	Capacity of internal recording media
DCR-SX45E	Memory card	—
DCR-SX65E	Internal memory + memory card	4 GB
DCR-SX85E		16 GB


Notes on use

- Do not do any of the following, otherwise, the recording media may be damaged, recorded images may be impossible to play back or may be lost, or other malfunctions could occur.
 - Eject the memory card when the access lamp (p. 18) is lit or flashing
 - Remove the battery pack or AC Adaptor from the camcorder, or subject the camcorder to shock or vibration when the  (Movie)/ (Photo) lamps (p. 14) or the access lamp (p. 18) are lit or flashing
- When using a shoulder belt (sold separately), do not crash the camcorder against an object.

Operation flow

Getting started (p. 11)

Prepare the power source and recording media.



Recording movies and photos (p. 19)

Recording movies → p. 20

💡 Changing the recording mode

💡 Expected recording time (MEDIA INFO)


Shooting photos → p. 21



Playing movies and photos

Playback on the camcorder → p. 23

Playing images on a TV → p. 26




Saving images

Saving movies and photos with a computer → p. 30

Saving movies and photos in external media → p. 35

Saving images with a DVD writer/recorder → p. 38



Deleting movies and photos (p. 28)

If you delete the image data that has been saved on your computer or a disc, you can record new images on the free media space again.





Table of contents

Read this first	2
Operation flow	8
Getting started	
Step 1: Charging the battery pack	11
Charging the battery pack abroad	13
Step 2: Turning the power on, and setting the date and time	14
Changing the language setting	15
Step 3: Preparing the recording media	16
To check the recording media settings	17
Dubbing or copying movies and photos from the internal recording media to memory card (DCR-SX65E/SX85E)	18
Recording/Playback	
Recording	19
Playback on the camcorder	23
Playing images on a TV	26
Making good use of your camcorder	
Deleting movies and photos	28
Saving movies and photos with a computer	
Preparing a computer	30
When using a Macintosh	30
Starting PMB (Picture Motion Browser)	33
Using "PMB Portable"	33
Saving images with an external device	
Saving images in external media (DIRECT COPY)	35
Creating a disc with a DVD writer, recorder	38
Customizing your camcorder	
Using menus	43
Getting detailed information from the "Handycam" Handbook	49
Additional information	
? Troubleshooting	50
Recording time of movies/number of recordable photos	53
Precautions	55
Specifications	57

■ Quick reference

Screen indicators.....	59
Parts and controls.....	60
Index.....	62

Step 1: Charging the battery pack



You can charge the “InfoLITHIUM” battery pack (V series) after attaching it to your camcorder.

⚡ Notes


- You cannot attach any “InfoLITHIUM” battery pack other than the V series to your camcorder.

- Turn off your camcorder by closing the LCD screen.
- Attach the battery pack by sliding it in the direction of the arrow until it clicks.
- Connect the AC Adaptor and the power cord (mains lead) to your camcorder and the wall outlet (wall socket).
 - Align the ▲ mark on the DC plug with that on the DC IN jack.
 The CHG (charge) lamp lights up and charging starts. The CHG (charge) lamp turns off when the battery pack is fully charged.
- When the battery is charged, disconnect the AC Adaptor from the DC IN jack of your camcorder.

To charge with a computer

This function is useful if the AC Adaptor is not at hand.

- ① Turn off the power of your camcorder, then attach the battery.
- ② Connect your camcorder to the computer that is turned on with the Built-in USB Cable.



- ③ When charging is finished, terminate the USB connection between your camcorder and computer (p. 32).

⚡ Notes


- Correct operation with all computers is not guaranteed.
- Charging the battery or the connection with customized or hand-built computers is not guaranteed. Depending on the type of USB device used, charging may not function properly.
- If you connect the camcorder to a notebook computer that is not connected to an AC power source, the battery of the notebook computer may be depleted rapidly. In this case, do not leave your camcorder connected for a long time.

💡 Tips

- You can charge your camcorder by using the Built-in USB Cable from the wall outlet (wall socket) with the USB charging AC adaptor AC-U501AD/AC-U50AG (sold separately). You cannot use Sony portable power unit CP-AH2R/CP-AL (sold separately).
- The USB charging AC adaptor may not be available in some countries/regions.
- The CHG (charge) lamp may not light when the battery is low. Charge with the AC adaptor in such situation.
- See page 53 on recording and playing time.
- When your camcorder is on, you can check the approximate amount of remaining battery power with the remaining battery indicator at the upper left on the LCD screen.

To remove the battery pack

Close the LCD screen. Slide the BATT (battery) release lever (①) and remove the battery pack (②).



To use a wall outlet (wall socket) as a power source

Make the same connections as “Step 1: Charging the battery pack.” Even if the battery pack is attached, the battery pack is not discharged.



Charging the battery pack abroad

You can charge the battery pack in any countries/regions using the AC Adaptor supplied with your camcorder within the AC 100 V - 240 V, 50 Hz/60 Hz range.

Notes

- Do not use an electronic voltage transformer.

Notes on the battery pack

- When you remove the battery pack or disconnect the AC Adaptor, close the LCD screen and make sure that the  (Movie)/ (Photo) lamps (p. 14), the access lamp (p. 18) are turned off.
- The CHG (charge) lamp flashes during charging under the following conditions:
 - The battery pack is not attached correctly.
 - The battery pack is damaged.
 - The temperature of the battery pack is low.
Remove the battery pack from your camcorder and put it in a warm place.
 - The temperature of the battery pack is high.
Remove the battery pack from your camcorder and put it in a cool place.
- In the default setting, the power turns off automatically if you leave your camcorder without any operation for about 5 minutes, to save battery power ([A.SHUT OFF]).

Notes on the AC Adaptor


- Use the nearby wall outlet (wall socket) when using the AC Adaptor. Disconnect the AC Adaptor from the wall outlet (wall socket) immediately if any malfunction occurs while using your camcorder.
- Do not use the AC Adaptor placed in a narrow space, such as between a wall and furniture.
- Do not short-circuit the DC plug of the AC Adaptor or battery terminal with any metallic objects. This may cause a malfunction.

Step 2: Turning the power on, and setting the date and time

1 Open the LCD screen of your camcorder.



Your camcorder is turned on and the lens cover is opened.

- To turn on your camcorder when the LCD screen is open, press POWER.



2 Select the desired geographical area with / , then touch [NEXT].

Touch the button on the LCD screen.




- To set the date and time again, touch **MENU** (MENU) → [Show others] → [CLOCK/🗨️LANG] (under [GENERAL SET] category) → [CLOCK SET]. When an item is not on the screen, touch / until the item appears.





3 Set [SUMMERTIME], date and time, then touch **OK**.

The clock starts.


- If you set [SUMMERTIME] to [ON], the clock advances 1 hour.



⚡ Notes

- The date and time do not appear during recording, but they are automatically recorded on the recording media, and can be displayed during playback. To display the date and time, touch **MENU** (MENU) → [Show others] → [PLAYBACK SET] (under  [PLAYBACK] category) → [DATA CODE] → [DATE/TIME] → **OK** →  → **X**.
- You can turn off the operation beeps by touching **MENU** (MENU) → [Show others] → [SOUND/DISP SET] (under  [GENERAL SET] category) → [BEEP] → [OFF] → **OK** →  → **X**.
- If the button you touch does not react correctly, calibrate the touch panel.

To turn off the power





Close the LCD screen. The  (Movie) lamp flashes for a few seconds and the power is turned off.

👉 Tips

- You can turn off your camcorder also by pressing POWER.
- When [POWER ON BY LCD] is set to [OFF], turn off your camcorder by pressing POWER.

Changing the language setting

You can change the on-screen displays to show messages in a specified language.

Touch **MENU** (MENU) → [Show others] → [CLOCK/LANG] (under  [GENERAL SET] category) → [LANGUAGE SET] → a desired language → **OK** →  → **X**.

Step 3: Preparing the recording media

The recording media that can be used differs depending on your camcorder. The following icons are displayed on the screen of your camcorder.

DCR-SX45E:



Memory card

DCR-SX65E/SX85E:



Internal memory



Memory card

* In the default setting, both movies and photos are recorded on this recording media. You can perform recording, playback and editing operations on the selected medium.

Tips

- See page 53 for the recordable time of movies.
- See page 54 for the number of recordable photos.

Selecting the recording media for movies (DCR-SX65E/SX85E)

- 1 Touch **MENU** (MENU) → [Show others] → [MEDIA SETTINGS] (under [MANAGE MEDIA] category) → [MOVIE MEDIA SET].

The [MOVIE MEDIA SET] screen appears.

- 2 Touch the desired recording media.
-

- 3 Touch [YES] → **OK**.

The recording medium is changed.

Selecting the recording media for photos (DCR-SX65E/SX85E)

- 1 Touch **MENU** (MENU) → [Show others] → [MEDIA SETTINGS] (under [MANAGE MEDIA] category) → [PHOTO MEDIA SET].

The [PHOTO MEDIA SET] screen appears.


- 2 Touch the desired recording media.
-

- 3 Touch [YES] → **OK**.

The recording medium is changed.

To check the recording media settings

When recording in movie recording mode or photo recording mode, the recording media icon is displayed in the top right corner of the screen.



Recording media icon

- The icon displayed on the LCD screen varies depending on the camcorder you use.

Inserting a memory card

Notes

- Set the recording medium to [MEMORY CARD] to record movies and/or photos on memory card (DCR-SX65E/SX85E).

Types of memory card that can be used with your camcorder

- Only “Memory Stick PRO Duo” media, “Memory Stick PRO-HG Duo” media, SD memory cards (Class 2 or faster), SDHC memory cards (Class 2 or faster) and SDXC memory cards (Class 2 or faster) can be used with this camcorder. Operation with all memory cards is not assured.
- “Memory Stick PRO Duo” media of up to 32 GB and SD memory cards of up to 64 GB have been tested and proven to operate with your camcorder.
- For recording movies on “Memory Stick PRO Duo” media, it is recommended that you use “Memory Stick PRO Duo” media of 512 MB or larger.
- In this manual, “Memory Stick PRO Duo” media and “Memory Stick PRO-HG Duo” media are called “Memory Stick PRO Duo” media and SD memory cards, SDHC memory cards and SDXC memory cards are called SD memory cards.

Notes

- MultiMediaCard cannot be used.
- Images recorded on SDXC memory cards cannot be played back or imported on non-exFAT*-compatible computers, AV components, etc., connected to this camcorder by USB cable. Check that the connected devices are compatible with exFAT beforehand. If you connect a device that is not compatible with exFAT, the screen for initialization may appear. Never execute initialization, otherwise all recorded contents will be lost.

* exFAT is the file system used in SDXC memory cards.

Size of memory cards that can be used with your camcorder




- Only “Memory Stick Duo” media that is about a half the size of the standard “Memory Stick” media, and standard-sized SD memory cards can be used.

- Do not attach a label, etc., to a memory card or memory card adaptor. Doing so may cause a malfunction.

Open the cover, orient the memory card's notched corner as shown in the illustration, and insert into the memory card slot until it clicks.

- Close the cover after inserting the memory card.




Note direction of notched corner.

The [Create a new Image Database File.] screen may appear if you insert a new memory card. In that case, touch [YES]. If you record only photos on the memory card, touch [NO].

- Confirm the direction of the memory card. If you forcibly insert the memory card in the wrong direction, the memory card, memory card slot, or image data may be damaged.

⚡ Notes


- If [Failed to create a new Image Database File. It may be possible that there is not enough free space.] is displayed, initialize the memory card by touching **MENU** (MENU) → [Show others] → [MEDIA FORMAT] (under  [MANAGE MEDIA] category) → [MEMORY CARD] (DCR-SX65E/SX85E) → [YES] → [YES] → **OK**.

To eject the memory card

Open the cover and lightly push the memory card in once.

- Do not open the cover during recording.
- When inserting or ejecting the memory card, be careful so that the memory card does not pop out and drop.

Dubbing or copying movies and photos from the internal recording media to memory card (DCR-SX65E/SX85E)

Touch **MENU** (MENU) → [Show others] → [MOVIE DUB]/[PHOTO COPY] (under  [EDIT] category), then follow the displays on the screen.

Recording

In the default setting, movies are recorded on the following recording media.


DCR-SX45E: Memory card

DCR-SX65E/SX85E: Internal memory

Tips

- See page 16 on changing the recording media (DCR-SX65E/SX85E).


1 Fasten the grip belt.



2 Open the LCD screen of your camcorder.

Your camcorder is turned on and the lens cover is opened.



- To turn on your camcorder when the LCD screen is already open, press POWER (p. 14).
- You can switch recording modes by pressing MODE. Press MODE to light up the desired recording mode lamp.



Recording movies

Press START/STOP to start recording.


- You can start recording also by touching ● in the bottom left of the LCD screen.



To stop recording, press START/STOP again.

- You can stop recording also by touching ● in the bottom left of LCD screen.

-
- The icons and indicators on the LCD panel will be displayed for about 3 seconds, then disappear after turning on your camcorder or switching the recording (movie/photo)/playback modes. To display the icons and indicators again, touch anywhere on the screen except the rec & zoom buttons on the LCD.




⚡ Notes

- If you close the LCD screen while recording movies, the camcorder stops recording.
- The maximum continuous recordable time of movies is about 13 hours.
- When a movie file exceeds 2 GB, the next movie file is created automatically.
- It will take several seconds until you can start recording after you turn on the camcorder. You cannot operate your camcorder during this time.
- The following states will be indicated if data is still being written onto the recording media after recording has finished. During this time, do not apply shock or vibration to the camcorder, or remove the battery or AC Adaptor.
 - Access lamp (p. 18) is lit or flashing
 - The media icon in the upper right of the LCD screen is flashing

Tips

- You can capture photos from recorded movies.
- See page 53 on the recordable time of movies.
- You can check the recordable time, estimated remaining capacity, etc., by touching **MENU** (MENU) → [Show others] → [MEDIA INFO] (under **MANAGE MEDIA** category).
- The LCD screen of your camcorder can display recording images across the entire screen (full pixel display). However, this may cause slight trimming of the top, bottom, right and left edges of images when played back on a TV which is not compatible with full pixel display. In this case, set [GUIDEFRAAME] to [ON], and record images using the outer frame displayed on the screen as a guide.
- [STEADYSHOT] is set to [STANDARD] in the default setting.
- To adjust the angle of the LCD panel, first open the LCD panel 90 degrees to the camcorder (①), and then adjust the angle (②).



Data code during recording

The recording date, time and condition are recorded automatically on the recording media. They are not displayed during recording. However, you can check them as [DATA CODE] during playback. To display them, touch **MENU** (MENU) → [Show others] → [PLAYBACK SET] (under **PLAYBACK** category) → a desired setting → **OK** → **↶** → **✕**.

Shooting photos

In the default setting, photos are recorded on the following recording media.

DCR-SX45E: Memory card

DCR-SX65E/SX85E: Internal memory


Tips



- See page 16 on changing the recording media (DCR-SX65E/SX85E).


1 Press MODE to turn on the **📷** (Photo) lamp.

The LCD screen display switches for photo recording mode, and the screen aspect ratio becomes 4:3.



2 Press PHOTO lightly to adjust the focus, then press it fully.

- You can record photos also by touching  on the LCD screen.



When  disappears, the photo is recorded.

Tips

- To change the image size, touch **MENU** (MENU) → [Show others] → [ IMAGE SIZE] (under  [PHOTO SETTINGS] category) → a desired setting → **OK** → **X**.

Playback on the camcorder

In the default setting, movies and photos that are recorded on the following recording media are played.

DCR-SX45E: Memory card

DCR-SX65E/SX85E: Internal memory

Tips


- See page 16 on changing the recording media (DCR-SX65E/SX85E).

1 Open the LCD screen of your camcorder.


Your camcorder turns on.

- To turn on your camcorder when the LCD screen is already open, press POWER (p. 14).

2 Press (VIEW IMAGES).




The VISUAL INDEX screen appears after some seconds.

- You can display the VISUAL INDEX screen also by touching  (VIEW IMAGES) on the LCD screen.

3 Touch (Movie) (1) → a desired movie (2) to play back a movie. Touch the (Photo) (1) → a desired photo (2) to view a photo.

Movies are displayed and sorted by recording date.



- A** Switches operating button display.
- B** To MENU screen

C Displays the screen to select the index type ([DATE INDEX]/[FILM ROLL]/[FACE]).

D / : Displays movies recorded on the previous/next date.*

E / : Displays the previous/next movie.


F Returns to the recording screen.

* **D** is displayed when **A** is touched.

- You can scroll the display by touching and dragging **A**, **D** or **E**.
- appears with the movie or photo that was most recently played or recorded. If you touch the movie or photo with , you can continue playback from the previous time. appears on the photo recorded on a memory card.

Playing movies

Your camcorder starts playing the selected movie.



Tips

- When playback from the selected movie reaches the last movie, the screen returns to the VISUAL INDEX screen.
- Touch / during pause to play back movies slowly.
- As you repeat touching / during playback, movies are played as fast as about 5 times → about 10 times → about 30 times → about 60 times.
- You can display the VISUAL INDEX by touching **MENU** (MENU) → [Show others] → [VISUAL INDEX] (under [PLAYBACK] category).
- The recording date, time, and shooting conditions are recorded automatically during recording. This information is not displayed during recording, but you can display it during playback by touching **MENU** (MENU) → [Show others] → [PLAYBACK SET] (under [PLAYBACK] category) → [DATA CODE] → a desired setting → **OK** → → **X**.


To adjust the sound volume of movies

While playing back movies, touch → adjust with / → .

- You can also adjust the sound volume by using / in the OPTION MENU.

Viewing photos

Your camcorder displays the selected photo.



Tips

- When viewing photos recorded on a memory card, **101** (playback folder) appears on the screen.

Playing images on a TV


Connect your camcorder to the input jack of a TV or VCR using the A/V connecting cable **1** or an A/V connecting cable with S VIDEO **2**. Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor for this operation (p. 13). Refer also to the instruction manuals supplied with the devices to be connected.

1 A/V connecting cable (supplied)

Connecting to another device via the A/V Remote Connector using an A/V connecting cable.

2 A/V connecting cable with S VIDEO (sold separately)

When connecting to another device via the S VIDEO jack, by using an A/V connecting cable with an S VIDEO cable (sold separately), higher quality images can be produced than with an A/V connecting cable. Connect the white and red plugs (left/right audio) and the S VIDEO plug (S VIDEO channel) of the A/V connecting cable with an S VIDEO cable (sold separately). The yellow plug connection is not necessary. Connecting only the S VIDEO plug will not output audio.



1 Set the input selector of the TV to the input your camcorder will be connected to.



For details, refer to the instruction manuals supplied with the TV.

- 2** Connect your camcorder to a TV with the A/V connecting cable (1, supplied) or an A/V connecting cable with S VIDEO (2, sold separately).

Connect your camcorder to the input jack of the TV.

- 3** Play back movies and photos on your camcorder (p. 23).

To set the aspect ratio according to the connected TV (16:9/4:3)

Touch **MENU** (MENU) → [Show others] → [OUTPUT SETTINGS] (under  [GENERAL SET] category) → [TV TYPE] → [16:9] or [4:3] → **OK** →  → **X**.

If your TV/VCR has a 21-pin adaptor (EUROCONNECTOR)

Use a 21-pin adaptor (sold separately) to view playback pictures.




 Notes



- When you set [TV TYPE] to [4:3], the image quality may deteriorate. Also, when the recorded image's aspect ratio switches between 16:9 (wide) and 4:3, the image may jitter.
- On some 4:3 TVs, the photos recorded in 4:3 aspect ratio may not be displayed full screen. This is not a malfunction.



- When you play back an image recorded in 16:9 (wide) aspect ratio on a 4:3 TV not compatible with the 16:9 (wide) signal, set [TV TYPE] to [4:3].



 Tips

- To check information (counter, etc.) on the screen of the monitor, touch **MENU** (MENU) → [Show others] → [OUTPUT SETTINGS] (under  [GENERAL SET] category) → [DISP OUTPUT] → [V-OUT/PANEL] → **OK** →  → **X**.


Deleting movies and photos


You can free media space by deleting movies and photos from recording media.



Notes



- You cannot restore images once they are deleted. Save important movies and photos in advance.
- Do not remove the battery pack or the AC Adaptor from your camcorder while deleting the images. It may damage the recording media.
- Do not eject memory card while deleting images from the memory card.
- You cannot delete protected movies and photos. Undo the protection of the movies and photos to delete them, before you try to delete them.
- If the deleted movie is included in the Playlist, the movie added to the Playlist is deleted also from the Playlist.

Tips


- You can delete an image on the playback screen from  OPTION MENU.
- To delete all images recorded in the recording media, and recover all the recordable space of the media, format the media.
- Reduced-size images which enable you to view many images at the same time on an index screen are called “thumbnails.”


1 Touch **MENU** (MENU) → [Show others] → [DELETE] (under  [EDIT] category).


2 To delete movies, touch  [DELETE] →  [DELETE].

- To delete photos, touch  [DELETE] →  [DELETE].




3 Touch and display the ✓ mark on the movies or photos to be deleted.






- Press and hold the image down on the LCD screen to confirm the image. Touch  to return to the previous screen.

4 Touch **OK** → [YES] → **OK** → .

To delete all movies/photos at one time



In step 2, touch  [DELETE] →  [DELETE ALL] → [YES] → [YES] → **OK** → .


- To delete all photos at one time, touch  [DELETE] →  [DELETE ALL] → [YES] → [YES] → **OK** → .


To delete all the movies/photos recorded on the same day at one time







Notes

- You cannot delete photos on memory card by recording date.

① In step 2, touch  [DELETE] →  [DELETE by date].

- To delete all photos on the same day at one time, touch  [DELETE] →  [DELETE by date].



- ② Touch  /  to select the recording date of the desired movies/photos, then touch .
- Touch the image down on the LCD screen to confirm the image. Touch  to return to the previous screen.
- ③ Touch [YES] →  → .

Preparing a computer

You can perform following operations using “PMB (Picture Motion Browser).”

- Importing images to a computer
- Viewing and editing imported images
- Creating a disc
- Uploading movies and photos to websites

To save movies and photos using a computer, install “PMB” from the supplied CD-ROM beforehand.

⚡ Notes

- Do not format the media of your camcorder from a computer. Your camcorder may not operate correctly.
- You can create discs using 12 cm discs of following type with “PMB.”
 - DVD-R/DVD+R/DVD+R DL: Unrewritable
 - DVD-RW/DVD+RW: Rewritable

Step 1 Checking the computer system

Windows

OS* ¹
Microsoft Windows XP SP3* ² /Windows Vista SP2* ³ /Windows 7
CPU* ⁴
Intel Pentium III 1 GHz or faster
Application
PMB/PMB Portable
Memory
256 MB or more Other system requirements for OS should be met.
Hard disk
Disk volume required for installation: Approximately 500 MB (5 GB or more may be necessary when creating DVD discs.)
Display
Minimum 1,024 dots × 768 dots

Others

USB port (this must be provided as standard, Hi-Speed USB (USB 2.0 compatible)), DVD burner (CD-ROM drive is necessary for installation)

Macintosh

OS

PMB Portable: Mac OS X*⁵ (v10.5-v10.6)

- *¹ Standard installation is required. Operation is not assured if the OS has been upgraded or in a multi-boot environment.
- *² 64-bit editions and Starter (Edition) are not supported. Windows Image Mastering API (IMAPI) Ver.2.0 or newer is required to use disc creation function, etc.
- *³ Starter (Edition) is not supported.
- *⁴ Faster processor is recommended.
- *⁵ Macintosh equipped with Intel processor

⚡ Notes

- Operation with all computer environments is not assured.

When using a Macintosh

The supplied software “PMB” is not supported by Macintosh computers. To import the movies and photos to the computer, please contact Apple Inc..

Step 2 Installing the supplied software “PMB”

Install “PMB” before connecting your camcorder to a computer.

⚡ Notes

- If a version of “PMB” under 5.0.00 has been installed on your computer, you may be unable to use some functions of those “PMB” when installing the “PMB” from the supplied CDROM. Also, “PMB Launcher” is installed from the supplied CD-ROM and you can start “PMB” or other software by using the “PMB

Launcher." Double-click the "PMB Launcher" short-cut icon on the computer screen to start "PMB Launcher."

1 Confirm that your camcorder is not connected to the computer.

2 Turn on the computer.

- Log on as an Administrator for installation.
- Close all applications running on the computer before installing the software.

3 Place the supplied CD-ROM in the disc drive of your computer.

The installation screen appears.

- If the screen does not appear, click [Start] → [Computer] (in Windows XP, [My Computer]), then double-click [SONYPMB (E:)] (CD-ROM)*.
- * Drive names (such as (E:)) may vary depending on the computer.

4 Click [Install].




5 Select the country or region.

6 Select the language for the application to be installed, then proceed to the next screen.


7 Read the terms of the license agreement carefully. If you agree to the terms, change to , and then click [Next] → [Install].

8 Turn on your camcorder, then connect the camcorder to the computer using the supplied USB cable.




The [USB SELECT] screen appears on the camcorder screen automatically.

9 Touch the one of the media types displayed on the screen to make the computer recognize your camcorder.

[ USB CONNECT]: Internal memory (DCR-SX65E/SX85E)

[ USB CONNECT]: Memory card


- The displayed recording media differ depending on the model.
- If the [USB SELECT] screen does not appear, touch **MENU** (MENU) → [Show others] → [USB CONNECT] (under  [OTHERS] category).




10 Click [Continue] on the computer screen.

11 Follow the on-screen instructions to install the software.

- Depending on the computer, you may need to install third party software. If the installation screen appears, follow the instructions to install the required software.
- Connect the camcorder to the computer during the installation.

When the installation is completed, following icons will appear.
Remove the CD-ROM from your computer.




- : Starts “PMB.”
 - : Displays “PMB Help.”
 - : Displays “PMB Launcher.” “PMB Launcher” enables you to start “PMB” or other software, or to open web sites.
- Other icons may appear.
 - No icon may appear depending on the installation procedure.

⚡ Notes

- To create discs or use other functions on Windows XP, Image Mastering API v2.0 for Windows XP should be installed. If Image Mastering API v2.0 for Windows XP has not been installed yet, select it from required programs on the installation screen and install it following the procedures displayed. (The computer must be connected to the internet for the installation.) You may install Image Mastering API v2.0 for Windows XP in response to the message displayed when you try to start those functions.

To disconnect your camcorder from the computer

- ① Click the  icon at the bottom right of the desktop of the computer → [Safely remove USB Mass Storage Device].



- ② Touch [END] → [YES] on the camcorder screen.
- ③ Disconnect the USB cable.

⚡ Notes

- Access from the computer using the supplied software “PMB.” Do not modify the files or folders on the camcorder from the computer. The image files may be destroyed or may not be played back.
- When importing a long movie or edited image, use the supplied software “PMB” If you use any other software, images may not be imported properly.
- Operation is not guaranteed, if you perform the above operation.
- The maximum file size is 2GB. Should a file exceed 2 GB, it will be divided automatically. Although the file may appear to be divided when viewed on a PC, your camcorder and the “PMB” importing function will process the file appropriately.
- When you delete image files, follow the steps on page 28. Do not delete the image files on the camcorder directly from the computer.
- Do not copy the files on the recording media from the computer. Operation is not guaranteed.

Starting PMB (Picture Motion Browser)

Double-click the “PMB” short-cut icon on the computer screen.



Notes

- If the icon is not displayed on the computer screen, click [Start] → [All Programs] → [PMB] to start “PMB.”

You can view, edit, or create discs of movies and photos using “PMB.”

Reading “PMB Help”

For details on how to use “PMB,” read the “PMB Help.” Double-click the “PMB Help” short-cut icon on the computer screen to open the “PMB Help.”



Notes

- If the icon is not displayed on the computer screen, click [Start] → [All Programs] → [PMB] → [PMB Help]. You can also open the “PMB Help” from [Help] of “PMB.”

Using “PMB Portable”

The application “PMB Portable” is pre-loaded in this camcorder.

You can easily upload images to a network service, even with a computer on which “PMB” is not installed.

You can see the detailed usage when you click the help button in the upper right after starting “PMB Portable.”

Starting up “PMB Portable” (Windows)

- 1 Turn on your camcorder, then connect it to a computer with the Built-in USB cable.

The [USB SELECT] screen appears on the LCD of your camcorder.

- 2 Touch to select the recording media for which you wish to use “PMB Portable.”

[USB CONNECT]: Internal memory (DCR-SX65E/SX85E)

[USB CONNECT]: Memory card

- If the [USB SELECT] screen does not appear, touch **MENU** (MENU) → [Show others] → [USB CONNECT] (under [OTHERS] category).

- 3 Click “PMB Portable.”


The User Agreement screen appears.

- 4 Configure the settings, following the instructions on the screen.

“PMB Portable” starts up.

Starting up “PMB Portable” (Macintosh)

- 1 Turn on your camcorder, then connect it to a computer with the Built-in USB cable.



The [USB SELECT] screen appears on the LCD of your camcorder.

- 2 Touch to select the recording media for which you wish to use “PMB Portable.”

[PMBPORTABLE] appears on the desktop of the computer when connection between camcorder and computer is established.

- 3 Click [PMBP_Mac] in the [PMBPORTABLE] folder.

The Region Selection screen appears.

- 4 Select the appropriate [Region] and [Country/Area], and then click [OK].

The User Agreement screen appears.

- 5 Read the agreement carefully. If you accept the terms of the agreement, click [I Agree].

“PMB Portable” starts up.

For more details on “PMB Portable,” see the “PMB Portable” help.

⚡ Notes

- Always connect to a network when uploading images using “PMB Portable.”
- If [PMB Portable] is not displayed within the AutoPlay Wizard, click [Computer] → [PMBPORTABLE], then double-click [PMBP_Win.exe].

Saving images in external media (DIRECT COPY)

You can save movies and photos on external media (USB storage device), such as an external hard disk drive. You can also play back images on the camcorder or another playback device.

Notes

- For this operation, you need the USB Adaptor Cable VMC-UAM1 (sold separately).
- The USB Adaptor Cable VMC-UAM1 may not be available in some countries/regions.
- You cannot use the following devices as an external media.
 - media with a capacity exceeding 2 TB
 - ordinary disc drive such as CD or DVD drive
 - media connected via USB hub
 - media with built-in USB hub
 - card reader
- You may not be able to use external media with a code function.
- FAT file system is available for your camcorder. If the external media was formatted to NTFS file system, etc., format the external media on your camcorder before use. The format screen appears when the external media is connected to your camcorder. The format screen may appear even in the case of media utilizing the FAT file system.
- Operation is not assured with every connectable device.
- Connect your camcorder to the wall outlet (wall socket) using the supplied AC adaptor (p. 13).
- Refer to the instruction manual supplied with the external media.
- Refer to the Sony support page for your country/region for details on external media that can be used.

Tips

- You can also import images recorded on external media using the supplied software "PMB".


1 Connect the AC Adaptor and the power cord (mains lead) to the DC IN jack of your camcorder and the wall outlet (wall socket).

2 If the external media has the AC power cable, connect it to the wall outlet (wall socket).

3 Connect the USB Adaptor Cable to the external media.

4 Connect the USB Adaptor Cable to the Ψ (USB) jack of your camcorder.

When the [Create a new Image Database File.] screen appears, touch [YES].



- You cannot connect to the Built-in USB Cable.

5 Touch [Copy.] on the camcorder screen.

DCR-SX65E/SX85E:

Movies and photos in the internal

recording media of the camcorder that have not yet been saved on to external media can be saved.

DCR-SX45E:

Movies and photos that have not yet been saved on to external media can be saved.

- This screen will appear only when there are newly recorded images.


6 After the operation is completed, touch **OK** on the camcorder screen.

Notes

- The number of scenes you can save on the external media are as follows.
Movies: 9,999 movies
Photos: 9,999 frames × 899 folders
The number of scenes may be smaller depending on the type of images recorded.

When connecting an external media

The images saved in the external media are displayed on the LCD screen. The movie display and photo display buttons on the VISUAL INDEX screen change as illustrated below.



You can make menu settings of the external media such as deleting images. Touch **MENU** (MENU) → [Show others] on the VISUAL INDEX screen.

To save desired movies and photos

You can also save images recorded on memory cards.

Notes

- You cannot search or copy photos recorded on memory card by recording date.

① Touch [Play without copying.] in step 5 above.

The VISUAL INDEX screen of the external media is displayed.


② Touch **MENU** (MENU) → [Show others] → [MOVIE DUB] (when selecting movies)/[PHOTO COPY] (when selecting photos).

③ Follow the on-screen instructions to select the recording media (DCR-SX65E/SX85E) and image selection methods.

④ When you selected [DUB by select], touch the image to be saved.

✓ appears.

- When you selected [DUB by date], select the date of the images to be dubbed with **^** / **v**, then touch **OK** and go to step ⑤.



Remaining external media capacity

- Press and hold the image down on the LCD screen to confirm the image. Touch **↶** to return to the previous screen.
- By touching date, you can search for images by date.

⑤ Touch **OK** → [YES] → **OK** on the camcorder screen.

To play back images in the external media on the camcorder

- ① Touch [Play without copying.] in step 5 above.


The VISUAL INDEX screen of the external media is displayed.

- ② Play back the image (p. 23).
 - You can also view images on a TV connected to your camcorder (p. 26).

⚡ Notes

- The Date Index of photos cannot be displayed.
- If your camcorder does not recognize the external media, try the following operations.
 - Reconnect the USB Adaptor Cable to your camcorder
 - If the external media has the AC power cable, connect it to the wall outlet (wall socket)

To finish the external media connection

- ① Touch  on the VISUAL INDEX screen of the external media.
- ② Disconnect the USB Adaptor Cable.

Creating a disc with a DVD writer, recorder

Creating a disc with the dedicated DVD writer, DVDirect Express

You can create a disc or play back the images on a created disc by using the dedicated DVD writer, DVDirect Express (sold separately).


Refer also to the instruction manual supplied with the DVD writer.

Notes

- Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor for this operation (p. 13).
- Only unused discs of the following types can be used:
 - 12cm DVD-R
 - 12cm DVD+R
- The device does not support two-layered discs.
- DVDirect Express is referred to as “DVD writer” in this section.

- 1 Connect the AC Adaptor and the power cord (mains lead) to the DC IN jack of your camcorder and the wall outlet (wall socket) (p. 13).

- 2 Turn on your camcorder, and connect the DVD writer to the Ψ (USB) jack of your camcorder with the USB cable of the DVD writer.



- You cannot connect to the Built-in USB Cable.

- 3 Insert an unused disc into the DVD writer, and close the disc tray.

The [DISC BURN] screen appears on the camcorder screen.

- 4 Press \odot (DISC BURN) on the DVD writer.

Movies recorded on the internal recording media that have not been saved on any discs will be recorded onto the disc (DCR-SX65E/SX85E). Movies that have not been saved on any discs will be recorded onto the disc (DCR-SX45E).

- 5 Repeat steps 3 and 4 when the total memory size of movies to be burnt exceeds that of the disc.

- 6 Touch **OK** → [END] → [EJECT DISC] on the camcorder screen.

Remove the disc after the operation is completed.


- 7 Touch **OK**, then disconnect the USB cable.

To customize a disc with DISC BURN OPTION



Perform this operation in the following cases:

- When dubbing a desired image
- When creating multiple copies of the same disc
- When dubbing images in the memory card (DCR-SX65E/SX85E)


- ① Touch [DISC BURN OPTION] in step 4.
- ② Select the recording media containing the movie(s) you want to save (DCR-SX65E/SX85E).
- ③ Touch the movie you want to burn on the disc.
✓ appears.



Remaining Disc capacity


- Press and hold the image down on the LCD screen to confirm the image. Touch  to return to the previous screen.
 - By touching date, you can search for images by date.
- ④ Touch  → [YES] on the camcorder screen.
 - To create another disc of the same contents, insert a new disc and touch [CREATE SAME DISC].
 - ⑤ After the operation is completed, touch [EXIT] → [END] on the camcorder screen.
 - ⑥ Disconnect the USB cable from your camcorder.

To play back a disc on the DVD writer



- ① Connect the AC Adaptor and the power cord (mains lead) to the DC IN jack of your camcorder and the wall outlet (wall socket) (p. 13).

- ② Turn on your camcorder, and connect the DVD writer to the Ψ (USB) jack of your camcorder with the USB cable of the DVD writer.
 - You can play back movies on the TV screen by connecting the camcorder to a TV (p. 26).
- ③ Insert a created disc into the DVD writer.

The movies on the disc appear as VISUAL INDEX on the camcorder screen.
- ④ Press the play button on the DVD writer.
 - You can also operate by the camcorder screen.
- ⑤ Touch [END] → [EJECT DISC] on the camcorder screen and remove the disc after the operation is completed.
- ⑥ Touch  and disconnect the USB cable.

⚠ Notes

- Do not do any of the following when creating a disc.
 - Turn off the camcorder
 - Disconnect the USB cable or the AC adaptor
 - Subject the camcorder to mechanical shock or vibration
 - Eject the memory card from the camcorder
- Play the created disc to make sure dubbing was performed correctly before deleting the movies on your camcorder.
- If [Failed.] or [DISC BURN failed.] appears on the screen, insert another disc into the DVD writer and perform the DISC BURN operation again.

💡 Tips

- If the total memory size of movies to be burnt by the DISC BURN operation exceeds that of the disc, disc creation stops when the limit is reached. The last movie on the disc may be cut off.
- Disc creation time to dub movies to the limit of the disc is about 20 minutes to 60 minutes.

It may take more time depending on the recording mode or the number of scenes.

- If you cannot play back created discs on any DVD player, connect the camcorder to the DVD writer, and then play back.

Creating a disc with a DVD writer, etc., other than DVDDirect Express


You can save movies on a disc by connecting your camcorder to disc creation devices, such as a Sony DVD writer other than DVDDirect Express, with the USB cable. Refer also to the instruction manuals supplied with the devices to be connected.

⚡ Notes

- Sony DVD writer may not be available in some countries/regions.
- Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor for this operation (p. 13).

-
- 1 Connect the AC Adaptor and the power cord (mains lead) to the DC IN jack of your camcorder and the wall outlet (wall socket) (p. 13).

-
- 2 Turn on your camcorder, and connect a DVD writer, etc. to the ⚡ (USB) jack of your camcorder with the Built-in USB Cable.



The [USB SELECT] screen appears on the camcorder screen.

- If the [USB SELECT] screen does not appear, touch **MENU** (MENU) → [Show others] → [USB CONNECT] (under **[OTHERS]** category).

-
- 3 Touch the recording media that contains the images on the camcorder screen.

[**[Internal Memory]** USB CONNECT]: Internal memory (DCR-SX65E/SX85E)

[**[Memory Card]** USB CONNECT]: Memory card

- The displayed recording media differ depending on the model.

-
- 4 Record movies on the connected device.

- For details, refer to the instruction manuals supplied with the device to be connected.

5 After the operation is completed, touch [END] → [YES] on the camcorder screen.

6 Disconnect the USB cable.

Creating a disc with a recorder, etc.

You can dub images played back on your camcorder on a disc or video cassette, by connecting your camcorder to a disc recorder, a Sony DVD writer, etc., other than DVDirect Express, with the A/V connecting cable. Connect the device in either way of **1** or **2**. Refer also to the instruction manuals supplied with the devices to be connected.

⚡ Notes


- Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor for this operation (p. 13).
- Sony DVD writer may not be available in some countries/regions.

1 A/V connecting cable (supplied)

Connect the A/V connecting cable to the input jack of another device.

2 A/V connecting cable with S VIDEO (sold separately)

When connecting to another device via the S VIDEO jack, by using an A/V connecting cable with an S VIDEO cable (sold separately), higher quality images can be produced than with an A/V connecting cable. Connect the white and red plug (left/right audio) and the S VIDEO plug (S VIDEO channel) of the A/V connecting cable with an S VIDEO cable. If you connect the S VIDEO plug only, you will hear no sound. The yellow plug (video) connection is not necessary.



➡ Signal flow

1 Insert the recording media in the recording device.

- If your recording device has an input selector, set it to the input mode.

2 Connect your camcorder to the recording device (a disc recorder, etc.) with the A/V connecting cable **1** (supplied) or an A/V connecting cable with S VIDEO **2** (sold separately).









- Connect your camcorder to the input jacks of the recording device.

3 Start playback on your camcorder, and record it on the recording device.

- Refer to the instruction manuals supplied with your recording device for details.

4 When dubbing is finished, stop the recording device, and then your camcorder.

Notes

- Since dubbing is performed via analog data transfer, the image quality may deteriorate.
- To hide the screen indicators (such as a counter, etc.) on the screen of the monitor device connected, touch **MENU** (MENU) → [Show others] → [OUTPUT SETTINGS] (under  [GENERAL SET] category) → [DISP OUTPUT] → [LCD PANEL] (the default setting) → **OK** →  → **X**.
- To record the date/time or camera settings data, touch **MENU** (MENU) → [Show others] → [PLAYBACK SET] (under  [PLAYBACK] category) → [DATA CODE] → a desired setting → **OK** →  → **X**. In addition, touch **MENU** (MENU) → [Show others] → [OUTPUT SETTINGS] (under  [GENERAL SET] category) → [DISP OUTPUT] → [V-OUT/PANEL] → **OK** →  → **X**.
- When the screen size of display devices (TV, etc.) is 4:3, touch **MENU** (MENU) → [Show others] → [OUTPUT SETTINGS] (under  [GENERAL SET] category) → [TV TYPE] → [4:3] → **OK** →  → **X**.
- When you connect a monaural device, connect the yellow plug of the A/V connecting cable to the video input jack, and the white (left channel) or the red (right channel) plug to the audio input jack on the device.

Using menus

Using the menus, you can perform useful functions and change various settings. If you make good use of menu operations, you can enjoy using your camcorder.

The camcorder has various menu items under each of eight menu categories.

M **MANUAL SETTINGS** (Items to adjust for scene condition) → p. 46

SHOOTING SET (Items for customized shooting) → p. 46

PHOTO SETTINGS (Items for recording photos) → p. 46

PLAYBACK (Items for playback) → p. 46

EDIT (Items for editing) → p. 47


OTHERS (Items for other settings) → p. 47

MANAGE MEDIA (Items for recording media) → p. 47

GENERAL SET (Other setup items) → p. 48

Menu items are described in more details in the “Handycam” Handbook.

Operating menus



⬆️ / ⬇️ : The menu list moves from category to category.

⬆️ / ⬇️ : The menu list moves through 4 items at once.

- You can touch buttons and drag the screen to scroll the list of the menu.
- The selected category icon is displayed in orange.
- You can return to the MY MENU screen by touching **MY** when displayed.

① Touch **MENU**.

② Touch [Show others] on the MY MENU screen.

- See the next page for details on MY MENU.

③ Touch the central part of the left side of screen to change the display.

④ Touch the menu item to be changed.

⑤ After changing the setting, touch **OK**.

To finish setting the menu, touch **X**.

To return to the previous menu screen, touch **↶**.

- **OK** may not be displayed depending on the menu item.

⚡ Notes

- You may not be able to set some menu items, depending on the recording or playback conditions.
- Grayed out menu items or settings are not available.


💡 Tips

- Depending on the menu items being changed, your camcorder switches between playback mode and recording mode (movie/photo).

Using MY MENU

You can use the menu items more easily by registering the menu items you use most often on MY MENU. You can register 6 menu items on each MY MENU of the MOVIE, PHOTO, and PLAYBACK.

Example: deleting [SPOT MTR/FCS] and registering [FADER]





- ① Touch **MENU**.
- ② Touch **[MY MENU SETTING]**.
- ③ Touch **[MOVIE]**.
- ④ Touch **[SPOT MTR/FCS]**.
- ⑤ Touch **OK**.
- ⑥ Touch **[FADER]** (under **[M]** **[MANUAL SETTINGS]** category).
- ⑦ When MY MENU is displayed, touch **✕**.


Repeat the same steps above to register menu items on MY MENU, and enjoy using your “Handycam.”



💡 Tips

- When an external storage device is connected, the exclusive MY MENU appears.

Using the OPTION MENU

The OPTION MENU appears just like the pop-up window that appears when you right-click the mouse on a computer. When  is displayed at bottom-right of the screen, you can use the OPTION MENU. You touch , and the menu items you can change in the context appear.




- ① Touch  (OPTION).
- ② Touch the desired tab → the item to change the setting.
- ③ After completing the setting, touch .

Notes





- Grayed out menu items or settings are not available.
- When the item you want is not on the screen, touch another tab. (There may be no tab.)
- The tabs and items that appear on the screen depend on the recording/playback status of your camcorder at the time.

Menu lists



(MANUAL SETTINGS) category

- SCENE SELECTION Selects an appropriate recording setting according to the type of scene, such as night view or beach.
-  FADER Fades scenes in or out.
- WHITE BAL Adjusts the color balance to the brightness of the recording environment.
- SPOT MTR/FCS Adjusts the brightness and focus for the selected subject simultaneously.
- SPOT METER Adjusts the brightness of images to a subject you touch on the screen.
- SPOT FOCUS Focuses on a subject you touch on the screen.
- EXPOSURE Adjusts the brightness of movies and photos.
- FOCUS Focuses manually.
- TELE MACRO Shoots a subject in focus with, the background out of focus.



(SHOOTING SET) category


-  REC MODE Sets the mode to record movies. When recording fast moving subject, a high image quality is recommended.
- GUIDEFAME Displays the frame to make sure the subject is horizontal or vertical.
-  STEADYSHOT Sets the SteadyShot function when recording movies.
- AUTO SLW SHUTTR Adjusts the shutter speed automatically.
- FACE DETECTION Adjusts the image quality of the face(s) automatically.
- AUDIO REC SET
- BLT-IN ZOOM MIC Records movies with vivid sound appropriate to the zoom position.
- MICREF LEVEL Sets the microphone level.
- OTHER REC SET
-  DIGITAL ZOOM Sets the maximum zoom level of the digital zoom that exceeds the zoom level of the optical zoom.
- BACK LIGHT Adjusts the exposure for backlit subjects automatically.
-  WIDE SELECT Sets the horizontal to vertical ratio when recording movies.

(PHOTO SETTINGS) category

-  SELF-TIMER Sets the self-timer when your camcorder is in photo recording mode.
-  IMAGE SIZE Sets the photo size.
- FILE NO. Sets how to assign the file number.

(PLAYBACK) category

- VISUAL INDEX Displays recording images as thumbnails (p. 23).
- VIEW IMAGES
- DATE INDEX Enables searching for desired images by date.
-  FILM ROLL Displays and plays the scenes by a certain interval.
-  FACE Displays and plays the face scenes.
- PLAYLIST Displays and plays the playlist of movies.
- PLAYBACK SET
- DATA CODE Displays the detailed recording data during playback.

 (EDIT) category


DELETE

 DELETE Deletes movies.

 DELETE Deletes photos.

PROTECT

 PROTECT Protects movies to avoid deleting.

 PROTECT Protects photos to avoid deleting.

 DIVIDE Divides movies.

PHOTO CAPTURE* Captures photos from desired scenes of movies.

MOVIE DUB*

DUB by select Selects movies and dub.

DUB by date Dubs all movies of a specified date.



 DUB ALL Dubs all saved movies in a playlist.


PHOTO COPY*


COPY by select Selects photos and copy.


COPY by date Copies all photos of a specified date.


PLAYLIST EDIT

 ADD Adds movies in a playlist.

 ADD by date Adds movies recorded on a same day at one time in a playlist.


 ERASE Erases movies from a playlist.


 ERASE ALL Erases all movies from a playlist.

 MOVE Changes the order of movies in a playlist.

 (OTHERS) category

USB CONNECT

 USB CONNECT* Connects the internal memory via USB.

 USB CONNECT Connects the memory card via USB.

DISC BURN Allows you to save images onto discs.

BATTERY INFO Displays the battery information.

 (MANAGE MEDIA) category

MEDIA SETTINGS*

MOVIE MEDIA SET Sets the media for recording movies (p. 16).

PHOTO MEDIA SET Sets the media for recording photos (p. 16).

MEDIA INFO Displays information on the recording media, such as free space.

MEDIA FORMAT

INT. MEMORY* Deletes all data on the internal memory.

MEMORY CARD Deletes all data on the memory card.

REPAIR IMG.DB F.

INT. MEMORY* Repairs the image database file on the internal memory (p. 51).

MEMORY CARD Repairs the image database file on the memory card (p. 51).

(GENERAL SET) category


SOUND/DISP SET

- VOLUME..... Adjusts the volume of playback sound (p. 24).
- BEEP Sets whether the camcorder sounds operation beeps or not.
- LCD BRIGHT Adjusts the brightness of the LCD screen.
- LCD BL LEVEL Adjusts the backlight of the LCD screen.
- LCD COLOR..... Adjusts the color intensity of the LCD screen.
- DISPLAY SET Sets the duration that icons or indicators are displayed on the LCD screen.

OUTPUT SETTINGS

- TV TYPE Converts the signal depending on the TV connected (p. 26).
- DISP OUTPUT..... Sets whether the on-screen displays appears on the TV screen or not.

CLOCK/LANG

- CLOCK SET Sets the date and time (p. 14).
- AREA SET Adjusts for a time difference without stopping the clock (p. 14).
- SUMMERTIME..... Sets the summertime (p. 14).
-  LANGUAGE SET Sets the display language (p. 15).

POWER SETTINGS

- A.SHUT OFF Changes the [A.SHUT OFF] setting (p. 11).
- POWER ON BY LCD Sets whether or not the camcorder is turned on and off when you open and close the LCD screen.

OTHER SETTINGS

- DEMO MODE..... Sets whether the demonstration appears or not.
 - CALIBRATION Calibrates the touch panel.
 - USB LUN SETTING Sets the compatibility of your camcorder when using a USB connection.
-


* DCR-SX65E/SX85E

Getting detailed information from the “Handycam” Handbook

The “Handycam” Handbook is a user guide designed to be read on a computer screen. The “Handycam” Handbook is intended to be read when you want to know more about operating your camcorder.

1 To install the “Handycam” Handbook on a Windows computer, place the supplied CD-ROM in the disc drive of your computer.

2 On the installation screen displayed, click [Handbook].



3 Select the desired language and the model name of your camcorder, then click [Install]. Install by following the instructions on the screen.

- The model name of your camcorder is printed on its bottom surface.

To view the “Handycam” Handbook, double-click the short-cut icon on the computer screen.



- When using a Macintosh, open the [Handbook] – [GB] folder in the CD-ROM, then copy [Handbook.pdf].
- You need Adobe Reader to read “Handycam” Handbook. If it is not installed on your computer, you can download it from the Adobe Systems web page: <http://www.adobe.com/>
- Refer to “PMB Help” for details on the supplied software “PMB” (p. 33).

? Troubleshooting

If you run into any problems using your camcorder, follow the steps below.

- 1 Check the list (p. 50 to 52), and inspect your camcorder.
- 2 Remove the power source, attach the power source again after about 1 minute, and turn the camcorder on.
- 3 Press RESET (p. 60) using a pointed object, and turn the camcorder on. If you press RESET, all settings, including the clock setting, are reset.
- 4 Contact your Sony dealer or local authorized Sony service facility.

- Your camcorder may be required to initialize or change the current internal recording media of your camcorder, depending on the problem. In the event of this, the data stored on the internal recording media will be deleted. Be sure to save the data on the internal recording media on other media (backup) before sending your camcorder for repair. We will not compensate you for any loss of internal recording media data.
- During repair, we may check a minimum amount of data stored on the internal recording media in order to investigate the problem. However, your Sony dealer will neither copy nor retain your data.
- See the "Handycam" Handbook (p. 49) for details on the symptoms of your camcorder, and "PMB Help" (p. 33) on connecting your camcorder to a computer.

The power does not turn on.

- Attach a charged battery pack to the camcorder (p. 11).
- Connect the plug of the AC Adaptor to the wall outlet (wall socket) (p. 13).

The camcorder does not operate even when the power is set to on.

- It takes a few seconds for your camcorder to be ready to shoot after the power is turned on. This is not a malfunction.
- Disconnect the AC Adaptor from the wall outlet (wall socket) or remove the battery pack, then reconnect it after about 1 minute. If your camcorder still does not work, press RESET (p. 60) using a pointed object. (If you press RESET, all settings, including the clock setting, are reset.)
- The temperature of your camcorder is extremely high. Turn off the camcorder and leave it for a while in a cool place.
- The temperature of your camcorder is extremely low. Leave the camcorder with the power turned on. If you still cannot operate your camcorder, turn off the camcorder and take it to a warm place. Leave the camcorder there for a while, then turn on the camcorder.



Your camcorder gets warm.

- Your camcorder may become warm during operation. This is not a malfunction.

The power abruptly turns off.

- Use the AC Adaptor (p. 13).
- Turn on the power again.
- Charge the battery pack (p. 11).

Pressing START/STOP or PHOTO does not record images.

- Press MODE to turn on the  (Movie) or  (Photo) lamp.
- Your camcorder is recording the image you have just shot on the recording media. You cannot make any new recordings during this period.
- The recording media is full. Delete unnecessary images (p. 28).
- Total number of movie scenes or photos has exceeded the recordable capacity of your camcorder. Delete unnecessary images (p. 28).

The recording stops.

- The temperature of your camcorder is extremely high/low. Turn off your camcorder and leave it for a while in a cool/warm place.

"PMB" cannot be installed.

- Check the computer environment or installation procedure required to install "PMB" (p. 30).

"PMB" does not work correctly.

- Quit "PMB" and restart your computer.

The camcorder is not recognized by the computer.

- Disconnect devices from the USB jack of the computer other than the keyboard, mouse, and your camcorder.
- Disconnect the USB cable from the computer and your camcorder, and restart the computer, then connect the computer and your camcorder again in an orderly manner.

Self-diagnosis display/Warning indicators

If indicators appear on the LCD screen, check the following.

If the problem persists even after you have tried to fix a couple of times, contact your Sony dealer or local authorized Sony service facility. In this case, when you contact them, give them all the numbers of the error code beginning with C or E.

C:04:□□

- The battery pack is not an "InfoLITHIUM" battery pack V series. Use an "InfoLITHIUM" battery pack (V series) (p. 11).
- Connect the DC plug of the AC Adaptor to your camcorder securely (p. 11).

C:06:□□

- The battery pack temperature is high. Change the battery pack or place it in a cool place.

C:13:□□ / C:32:□□

- Remove the power source. Reconnect it and operate your camcorder again.

E:□□:□□

- Follow the steps from ② to ④ on page 50.



- Battery power is low.



- The battery pack temperature is high. Change the battery pack or place it in a cool place.



- The temperature of your camcorder is getting high. Turn off your camcorder and leave it in a cool place.



- The temperature of your camcorder is low. Make the camcorder warm.



- No memory card is inserted (p. 17).
- When the indicator flashes, there is not enough free space for recording images. Delete unnecessary images (p. 17), or format the memory card after storing the images on other media.
- The Image Database File is damaged. Check the data base file by touching **MENU** (MENU) → [Show others] → [REPAIR IMG.DB F.] (under [MANAGE MEDIA] category) → the recording medium (DCR-SX65E/SX85E).



- The memory card is damaged. Format the memory card with your camcorder (p. 47).



- Incompatible memory card is inserted (p. 17).



- Access to the memory card was restricted on another device.



- The camcorder is unsteady. Hold the camcorder steady with both hands. However, note that the camera-shake warning indicator does not disappear.



- The recording media is full. Delete unnecessary images (p. 28).

Recording time of movies/number of recordable photos

Expected time of recording and playback with each battery pack

Recording time

Approximate time available when you use a fully charged battery pack.

Internal memory

DCR-SX65E/SX85E

(unit: minute)

Battery pack	Continuous recording time	Typical recording time
NP-FV30 (supplied)	105	60
NP-FV50	200	110
NP-FV70	415	210
NP-FV100	830	375

Memory card

(unit: minute)

Battery pack	Continuous recording time	Typical recording time
NP-FV30 (supplied)	110	60
NP-FV50	215	120
NP-FV70	440	220
NP-FV100	870	390

- Each recording time is measured when the [RECORD MODE] is set to SP.
- Typical recording time shows the time when you repeat recording start/stop, switching the MODE lamp, and zooming.
- Times measured when using the camcorder at 25 °C (77 °F), 10 °C to 30 °C (50 °F to 86 °F) is recommended.
- The recording and playback time will be shorter when you use your camcorder in low temperatures.
- The recording and playback time will be shorter depending on the conditions under which you use your camcorder.

Playing time

Approximate time available when you use a fully charged battery pack.

Internal memory

DCR-SX65E/SX85E

(unit: minute)

Battery pack	
NP-FV30 (supplied)	145
NP-FV50	280
NP-FV70	565
NP-FV100	1120

Memory card

(unit: minute)

Battery pack	
NP-FV30 (supplied)	160
NP-FV50	300
NP-FV70	610
NP-FV100	1205

Expected recording time of movies

Internal memory

DCR-SX65E

(unit: minute)

Recording mode	Recording time
[HQ]	55 (50)
[SP]	80 (50)
[LP]	175 (110)

DCR-SX85E

(unit: minute)

Recording mode	Recording time
[HQ]	235 (210)
[SP]	340 (210)

(unit: minute)

Recording mode	Recording time
[LP]	715 (465)

Tips

- You can record movies of a maximum of 9,999 scenes.
- The maximum continuous recording time of movies is approximately 13 hours.
- Your camcorder uses the VBR (Variable Bit Rate) format to automatically adjust image quality to suit the recording scene. This technology causes fluctuations in the recording time of the media. Movies containing quickly moving and complex images are recorded at a higher bit-rate, and this reduces the overall recording time.

Memory card

(unit: minute)

	HQ	SP	LP
512MB	6 (5)	9 (5)	20 (10)
1GB	10 (10)	20 (10)	40 (25)
2GB	25 (25)	40 (25)	85 (55)
4GB	55 (50)	80 (50)	170 (110)
8GB	115 (100)	165 (100)	350 (225)
16GB	230 (205)	330 (205)	690 (445)
32GB	465 (415)	670 (415)	1405 (910)

Notes

- The recordable time may vary depending on the recording and subject conditions, [REC MODE] (p. 46).
- The number in () is the minimum recordable time.

Expected number of recordable photos

Internal recording media (DCR-SX65E/SX85E)

You can record the maximum 9,999 photos.

Memory card

	VGA(0.3M) VGA
512MB	2800
1GB	5700
2GB	11500
4GB	22500
8GB	46500
16GB	91000
32GB	185000

- The indicated number of recordable photos on a memory card is based on the maximum image size of your camcorder. The actual number of recordable photos is displayed on the LCD screen during recording (p. 59).
- The maximum number of recordable photos on a memory card may vary depending on the recording conditions.

Tips

- You can also use memory card with a capacity of under 512 MB for recording photos.
- The following list shows the average bit-rate, the recording pixels, and the aspect ratio of each movie recording mode.
 - HQ: Approx. 9Mbps 720 pixels × 576 pixels/16:9, 4:3
 - SP: Approx. 6Mbps 720 pixels × 576 pixels/16:9, 4:3
 - LP: Approx. 3Mbps 720 pixels × 576 pixels/16:9, 4:3
- The photo recording pixels and the aspect ratio.
 - Photo recording mode:
 - 640 dots × 480 dots/4:3
 - 640 dots × 360 dots/16:9
 - Capturing a photo from a movie:
 - 640 dots × 360 dots/16:9
 - 640 dots × 480 dots/4:3

Precautions

On use and care

- Do not use or store the camcorder and accessories in the following locations:
 - Anywhere extremely hot, cold or humid. Never leave them exposed to temperatures above 60 °C (140 °F), such as under direct sunlight, near heaters or in a car parked in the sun. They may malfunction or become deformed.
 - Near strong magnetic fields or mechanical vibration. The camcorder may malfunction.
 - Near strong radio waves or radiation. The camcorder may not be able to record properly.
 - Near AM receivers and video equipment. Noise may occur.
 - On a sandy beach or anywhere dusty. If sand or dust gets in your camcorder, it may malfunction. Sometimes this malfunction cannot be repaired.
 - Near windows or outdoors, where the LCD screen or the lens may be exposed to direct sunlight. This damages the inside of the LCD screen.
- Operate your camcorder on DC 6.8 V/7.2 V (battery pack) or DC 8.4 V (AC Adaptor).
- For DC or AC operation, use the accessories recommended in these operating instructions.
- Do not let your camcorder get wet, for example, from rain or sea water. If your camcorder gets wet, it may malfunction. Sometimes this malfunction cannot be repaired.
- If any solid object or liquid gets inside the casing, unplug your camcorder and have it checked by a Sony dealer before operating it any further.
- Avoid rough handling, disassembling, modifying, physical shock, or impact such as hammering, dropping or stepping on the product. Be particularly careful of the lens.
- Keep the camcorder turning off when you are not using your camcorder.
- Do not wrap your camcorder with a towel, for example, and operate it. Doing so might cause heat to build up inside.
- When disconnecting the power cord (mains lead), pull it by the plug and not the cord (lead).
- Do not damage the power cord (mains lead)

such as by placing anything heavy on it.

- Do not use a deformed or damaged battery pack.
- Keep metal contacts clean.
- If the battery electrolytic liquid has leaked:
 - Consult your local authorized Sony service facility.
 - Wash off any liquid that may have contacted your skin.
 - If any liquid gets in your eyes, wash with plenty of water and consult a doctor.

When not using your camcorder for a long time

- To keep your camcorder in optimum state for a long time, turn it on and let it run by recording and playing back images about once a month.
- Use up the battery pack completely before storing it.

LCD screen

- Do not exert excessive pressure on the LCD screen, as it may cause damage.
- If your camcorder is used in a cold place, a residual image may appear on the LCD screen. This is not a malfunction.
- While using your camcorder, the back of the LCD screen may heat up. This is not a malfunction.

To clean the LCD screen

- If fingerprints or dust make the LCD screen dirty, it is recommended that you use a soft cloth to clean it. When you use the LCD Cleaning Kit (sold separately), do not apply the cleaning liquid directly to the LCD screen. Use cleaning paper moistened with the liquid.

On handling the casing

- If the casing is soiled, clean the camcorder body with a soft cloth lightly moistened with water, and then wipe the casing with a dry soft cloth.
- Avoid the following to avoid damage to the finish:
 - Using chemicals such as thinner, benzine, alcohol, chemical cloths, repellent, insecticide and sunscreen

- Handling the camcorder with above substances on your hands
- Leaving the casing in contact with rubber or vinyl objects for a long period of time

About care and storage of the lens

- Wipe the surface of the lens clean with a soft cloth in the following instances:
 - When there are fingerprints on the lens surface
 - In hot or humid locations
 - When the lens is exposed to salty air such as at the seaside
- Store in a well-ventilated location subject to little dirt or dust.
- To prevent mold, periodically clean the lens as described above.

On charging the pre-installed rechargeable battery

Your camcorder has a pre-installed rechargeable battery to retain the date, time, and other settings even when the camcorder is turned off. The pre-installed rechargeable battery is always charged while your camcorder is connected to the wall outlet (wall socket) via the AC Adaptor or while the battery pack is attached. The rechargeable battery will be fully discharged in about 3 months if you do not use your camcorder at all. Use your camcorder after charging the pre-installed rechargeable battery. However, even if the pre-installed rechargeable battery is not charged, the camcorder operation will not be affected as long as you are not recording the date.

Procedures

Connect your camcorder to a wall outlet (wall socket) using the supplied AC Adaptor, and leave it with the LCD screen closed for more than 24 hours.

Note on disposal/transfer of the camcorder (DCR-SX65E/SX85E)

Even if you delete all movies and still images, or perform [MEDIA FORMAT], data on the internal recording media may not be completely erased.

When you transfer the camcorder, it is recommended that you perform [EMPTY]

(See “Getting detailed information from the “Handycam” Handbook” on page 49.) to prevent the recovery of your data. Also, when you dispose of the camcorder, it is recommended that you destroy the actual body of the camcorder.

Note on disposal/transfer of memory card

Even if you delete data in the memory card or format the memory card on your camcorder or a computer, you may not delete data from the memory card completely. When you give the memory card to somebody, it is recommended that you delete data completely using data deletion software on a computer. Also, when you dispose of the memory card, it is recommended that you destroy the actual body of the memory card.

Specifications

System

Signal format: PAL color, CCIR standards

Movie recording format:

Video: MPEG-2 PS

Audio: Dolby Digital 2ch

Dolby Digital Stereo Creator

Photo file format

: DCF Ver.2.0 Compatible

: Exif Ver.2.21 Compatible

: MPF Baseline Compatible

Recording media (Movie/Photo)

Internal memory

DCR-SX65E: 4 GB

DCR-SX85E: 16 GB

“Memory Stick PRO Duo” media

SD memory card (Class 2 or faster)

When measuring media capacity, 1 GB equals 1 billion bytes, a portion of which is used for system management and/or application files.

The capacity that a user can use is below.

DCR-SX65E: Approx. 3.86 GB

DCR-SX85E: Approx. 15.5 GB

Image device

2.25 mm (1/8 type) CCD (Charge Coupled Device)

Gross: Approx. 800 000 pixels

Effective (Movie, 16:9): Approx.

490 000 pixels

Effective (Photo, 16:9): Approx. 490 000 pixels

Effective (Photo, 4:3): Approx. 560 000 pixels

Lens

Carl Zeiss Vario-Tessar

60 × (Optical)*1, 70 × (Extended)*2, 2 000 × (Digital)

Filter diameter: 37 mm (1 1/2 in.)

F1.8 ~ 6.0

Focal length:

f=1.8 mm ~ 108 mm (3/32 in. ~ 4 3/8 in.)

When converted to a 35 mm still camera

For movies: 39 mm ~ 2 340 mm (1 9/16 in. ~ 92 1/4 in.) (16:9)

For photos: 38 mm ~ 2 280 mm (1 1/2 in. ~ 89 7/8 in.) (4:3)

Color temperature: [AUTO], [ONE PUSH], [INDOOR] (3 200 K), [OUTDOOR] (5 800 K)

Minimum illumination

3 lx (lux) ([AUTO SLW SHUTTR] is set to [ON]),
6 lx (lux) ([AUTO SLW SHUTTR] is set to [OFF] (default setting)), shutter speed 1/25 second

*1 When [STEADYSHOT] is set to [ACTIVE]

*2 When [STEADYSHOT] is set to [STANDARD] or [OFF]

Input/Output connectors

A/V Remote Connector: Video/audio output jack

USB jack: mini-AB/TypeA (Built-in USB), output only

LCD screen

Picture: 7.5 cm (3 type, aspect ratio 16:9)

Total number of pixels: 230 400 (960 × 240)

General

Power requirements: DC 6.8 V/7.2 V (battery pack) DC 8.4 V (AC Adaptor)

Average power consumption: During camera recording, using LCD screen at normal brightness:

Internal memory: 1.9 W (DCR-SX65E/SX85E)

Memory card: 1.8 W

USB charging: DC 5V 500mA

Operating temperature: 0 °C to 40 °C (32 °F to 104 °F)

Storage temperature: -20 °C to +60 °C (-4 °F to +140 °F)

Dimensions (approx.)

52.5 mm × 57 mm × 113.5 mm (2 1/8 in. × 2 1/4 in. × 4 1/2 in.) (w/h/d) including the projecting parts

52.5 mm × 57 mm × 123.5 mm (2 1/8 in. × 2 1/4 in. × 4 7/8 in.) (w/h/d) including the projecting parts, and the supplied rechargeable battery pack attached

Mass (approx.)

230 g (8.1 oz) main unit only

270 g (9.5 oz) including the supplied rechargeable battery pack and memory card

AC Adaptor AC-L200C/AC-L200D

Power requirements: AC 100 V - 240 V, 50 Hz/60 Hz

Current consumption: 0.35 A - 0.18 A

Power consumption: 18 W

Output voltage: DC 8.4 V*

Operating temperature: 0 °C to 40 °C (32 °F to 104 °F)

Storage temperature: -20 °C to +60 °C (-4 °F to +140 °F)

Dimensions (approx.): 48 mm × 29 mm × 81 mm
(1 15/16 in. × 1 3/16 in. × 3 1/4 in.) (w/h/d)
excluding the projecting parts

Mass (approx.): 170 g (6.0 oz) excluding the
power cord (mains lead)

* See the label on the AC Adaptor for other
specifications.

Rechargeable battery pack NP-FV30

Maximum output voltage: DC 8.4 V

Output voltage: DC 7.2 V

Maximum charge voltage: DC 8.4 V

Maximum charge current: 2.12 A

Capacity

typical: 3.6 Wh (500 mAh)

minimum: 3.6 Wh (500 mAh)

Type: Li-ion

Design and specifications of your camcorder and
accessories are subject to change without notice.

- Manufactured under license from Dolby
Laboratories.

Charging time


Approximate time (min.) required when you fully
charge a fully discharged battery pack.

	AC adaptor	Built-in USB Cable*
NP-FV30 (supplied)	115	155
NP-FV50	155	315
NP-FV70	195	600
NP-FV100	390	1050

- Times measured when using the camcorder at
25 °C (77 °F). 10 °C to 30 °C (50 °F to 86 °F) is
recommended.


* When not using the USB connection support
cable

On trademarks

- “Handycam” and **HANDYCAM** are
registered trademarks of Sony Corporation.
- “Memory Stick,” , “Memory Stick Duo,”
“**MEMORY STICK DUO**,” “Memory Stick PRO
Duo,” “**MEMORY STICK PRO DUO**,” “Memory
Stick PRO-HG Duo,”
“**MEMORY STICK PRO-HG DUO**,” “Memory Stick
Micro,” “MagicGate,” “**MAGICGATE**,”
“MagicGate Memory Stick” and “MagicGate
Memory Stick Duo” are trademarks or
registered trademarks of Sony Corporation.
- “InfoLITHIUM” is a trademark of Sony
Corporation.
- “DVDirect” is a trademark of Sony
Corporation.
- Dolby and the double-D symbol are trademarks
of Dolby Laboratories.
- Microsoft, Windows, Windows Vista, and
DirectX are either registered trademarks or
trademarks of Microsoft Corporation in the
United States and/or other countries.
- Macintosh and Mac OS are registered
trademarks of Apple Inc. in the U.S. and other
countries.
- Intel, Intel Core, and Pentium are trademarks
or registered trademarks of Intel Corporation
or its subsidiaries in the United States and other
countries.
- Adobe, the Adobe logo, and Adobe Acrobat
are either registered trademarks or trademarks
of Adobe Systems Incorporated in the United
States and/or other countries.
- SDXC logo is a trademark of SD-3C, LLC.
- MultiMediaCard is a trademark of
MultiMediaCard Association.

All other product names mentioned herein may
be the trademarks or registered trademarks of
their respective companies. Furthermore, TM and
® are not mentioned in each case in this manual.

Screen indicators



Bottom

Upper left

Indicator	Meaning
	MENU button
	Self-timer recording
	MICREF LEVEL low
	WIDE SELECT
	BLT-IN ZOOM MIC
	Remaining battery
	Recording folder of memory card
	VIDEO LIGHT
	Return button

Center

Indicator	Meaning
	Recording status
	Photo size
	Slide show set
	Warning
	Playback mode

Upper right

Indicator	Meaning
	Recording mode (HQ/SP/LP)
	Recording/playback/editing media
	Counter (hour:minute:second)

Indicator	Meaning
	Estimated recording remaining time
	FADER
	Approximate number of recordable photos and recording media
	Playback folder of memory card
	Current playing movie or photo/Number of total recorded movies or photos


Bottom

Indicator	Meaning
	[FACE DETECTION] set to [OFF]
	Manual focus
	SCENE SELECTION
	White balance
	SteadyShot off
	SPOT MTR/FCS / SPOT METER / EXPOSURE
	TELE MACRO
	BACK LIGHT
	INTELLIGENT AUTO
	OPTION button
	VIEW IMAGES button
	Slide show button
	Data file name
	Protected image
	Index button


- Indicators and their positions are approximate and may differ from what you actually see.
- Some indicators may not appear, depending on your camcorder model.

Parts and controls


Figures in () are reference pages.





- 1 Lens (Carl Zeiss lens)
- 2 LED VIDEO LIGHT
- 3 Built-in microphone



- 1 LCD screen/Touch panel
- If you rotate the LCD panel 180 degrees, you can close the LCD panel with the LCD screen facing out. This is convenient during playback operations.



- 1 (VIEW IMAGES) button (23)
- 2 POWER button (14)
- 3 LIGHT button
Press to light up the LIGHT.
- 4 iAUTO button
- 5 Speaker
- 6 (USB) jack (31, 35, 40)
- 7 Power zoom lever
- 8 PHOTO button (22)
- 9 MODE button (19)
- 10 (movie)/ (photo) lamp (19)
- 11 RESET button
Press RESET using a pointed object.
Press RESET to initialize all the settings including the clock setting.



- 1 Battery pack (11)
- 2 START/STOP button (20)
- 3 CHG (charge) lamp (11)
- 4 DC IN jack (11)
- 5 A/V Remote Connector (26)

- 6** Grip belt (19)
- 7** Access lamp (memory card) (17)
While the lamp is lit or flashing, the camcorder is reading or writing data.
- 8** Memory card slot (17)
- 9** Built-in USB Cable
- 10** Tripod receptacle
Attach a tripod (sold separately) to the tripod receptacle using a tripod screw (sold separately: the length of the screw must be less than 5.5 mm (7/32 in.)).
- 11** BATT (battery) release lever (12)

Index

- Symbols**
 - 16:927
 - 4:327
- A**
 - A/V connecting cable.....26, 41
- B**
 - Battery pack.....11
 - Built-in USB Cable.....5, 12
- C**
 - Care55
 - Charging the battery pack11
 - Charging the battery pack abroad13
 - CLOCK SET14
 - Computer.....30
 - Computer system.....30
 - Copy18
 - Creating a disc38
- D**
 - DATA CODE15
 - DATE/TIME.....15
 - DELETE.....28
 - Disc recorder.....41
 - Dubbing.....18
 - DVDDirect Express.....38
 - DVD writer.....38, 40
- E**
 - External media.....35
- F**
 - Fully charged.....11
- H**
 - “Handycam” Handbook.....49
- I**
 - Install.....30
 - Internal memory.....16
- L**
 - LANGUAGE SET15
- M**
 - Macintosh30
 - Maintenance.....55
 - MEDIA SETTINGS.....16
 - Memory card.....17
 - “Memory Stick PRO Duo” media17
 - Menus.....43, 46
 - MOVIE MEDIA SET16
 - Movies20, 23
 - MY MENU43
 - MY MENU SETTING43
- O**
 - Operation beeps.....15
 - Operation flow.....8
 - OPTION MENU45
- P**
 - PHOTO MEDIA SET16
 - Photos21, 23
 - Playback.....23
 - PMB (Picture Motion Browser)30, 33
 - PMB Help33
 - Power on14
 - Precautions.....55
- R**
 - Rec & zoom buttons on LCD....20
 - Recording20
 - Recording media.....16
 - Recording time of movies/
number of recordable photos...53
 - Repair.....50
 - RESET60
- S**
 - Saving images in external media35
 - Screen indicators59
 - Self-diagnosis display.....51
 - Setting the date and time.....14
 - Software30
 - Specifications57
 - Supplied items.....5
- T**
 - Thumbnail28
 - Tripod.....61
 - Troubleshooting.....50
 - Turning the power on14
 - TV26
 - TV TYPE.....26
- U**
 - USB cable.....38, 40
 - USB CONNECT.....38, 40
- V**
 - VBR53
 - VIEW IMAGES23
 - VISUAL INDEX23
 - Volume.....24
- W**
 - Wall outlet (wall socket)11
 - Warning indicators.....51
 - Windows.....30
- Z**
 - Zoom.....20

You will find the menu lists on pages 46 to 48.

Additional information on this product and answers to frequently asked questions can be found at our Customer Support Website.

<http://www.sony.net/>

Printed on 70% or more recycled paper.

© 2011 Sony Corporation

Printed in China

