Canon PUB. DIE-324

Digital Video Camcorder
Instruction Manual

LEGRIA FS20

LEGRIA FS21

LEGRIA FS22

LEGRIA FS200



PAL



Important Usage Instructions

WARNING!



TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING!



TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK AND TO REDUCE ANNOYING INTERFERENCE, USE THE RECOMMENDED ACCESSORIES ONLY.

CAUTION:

DISCONNECT THE MAINS PLUG FROM THE SUPPLY SOCKET WHEN NOT IN USE.

The Mains plug is used as the disconnect device. The Mains plug shall remain readily operable to disconnect the plug in case of an accident.

While using the compact power adapter, do not wrap it or cover it with a piece of cloth, and do not place it in confined narrow spaces. Heat may build up, the plastic case may deform and it could result in electric shock or fire.

CA-570 identification plate is located on the bottom.



Using any device other than the Compact Power Adapter CA-570 may damage the camcorder.

European Union (and EEA) only.



These symbols indicate that this product is not to be disposed of with your household waste, according to the WEEE Directive (2002/96/EC), the Battery Directive (2006/66/EC) and/or your national laws implementing those Directives.

This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE) and batteries and accumulators.

Improper handling of this type of waste could have a possible impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources.

For more information about the recycling of this product, please contact your local city office, waste authority, approved scheme or your household waste disposal service or visit www.canon-europe.com/environment. (EEA: Norway, Iceland and Liechtenstein)

Getting to Know the Camcorder

What is so special about recording on flash memory?

Your videos and photos are recorded in the built-in memory (F522 / F521 / F520 only) or on a memory card (SD or SDHC card). Recording on flash memory means that there are no moving parts in the recorder unit of the camcorder. To you, it means a camcorder that is smaller, lighter and faster.





Other features of this camcorder

Whether you are using a camcorder for the first time or are very experienced, this camcorder offers many easy-to-use functions. The following are just but a few examples of the many functions that can enrich your shooting experience.

- Dual Shot (\$\superscript{\text{\pi}} 23\$): With Dual Shot (\$\superscript{\pi}\$ mode), recording is as simple as pressing a single button and using the zoom lever. The camcorder will take care of the rest!
- Pre-recording function (46): The camcorder records for 3 seconds before you start shooting, ensuring that those once-in-a-lifetime moments do not slip by.
- Video snapshot (
 44): Create a montage of scenes and even set it to music when you play it back.

Table of contents

Introd	luc	tion					
	3 8	Getting to Know the Camcorder About this Manual					
	10	Overview					
	10	Supplied Accessories and CD-ROMs					
	11 14	Components Guide Screen Displays					
Prepa	ırat	ions					
	17	Getting Started					
	17	Charging the Battery Pack					
	19 21	Preparing the Wireless Controller (
	23	Basic Operation of the Camcorder					
	23	Operating Modes					
	24	Joystick and Joystick Guide					
	25	Using the Menus					
	26	First Time Settings					
	26	Setting the Date and Time					
	27	Changing the Language					
	27	Changing the Time Zone					
	28	Using a Memory Card					
	28	Memory Cards Compatible for Use with the Camcorder					
	28	Inserting and Removing a Memory Card					
	29	F522 / F521 / F520 Selecting the Memory for the Recordings					
	29	Initializing the Built-In Memory (1522 / 1521 / 1520 only) or Memory Card					

Video _____

31 31	Basic Recording Shooting Video
32	Selecting the Video Quality (Recording Mode)
32 34	Zooming: Optical, Advanced and Digital Zoom Quick Start Function
35	Basic Playback
35	Playing Back the Video
37	Selecting What Recordings to Play Back
37	Selecting Scenes by Recording Date
38	Selecting the Playback Starting Point from the Movie Timeline
39	Pre-selecting Recordings from the Index Screen
40	Deleting Scenes
41	Advanced Functions
41	Special Scene Recording Programs
42	Controlling Shutter Speed and Other Functions while Shooting
43	Mini Video Light
44	Video Snapshot
46	Pre-recording Function
46	Self Timer
47	Automatic Backlight Correction and Manual Exposure Adjustment
48	Manual Focus Adjustment
48	White Balance
49	Image Effects
50	Digital Effects
51	On-Screen Displays and Data Code
51	Using Headphones
52	Using an External Microphone
53	Playlist and Scene Operations
53	Dividing Scenes
53	Editing the Playlist: Adding, Deleting and Moving Playlist Scenes

FS22 / FS21 / FS20 Copying Scenes

Photos

55

57 57 57 59	Basic Recording Taking Photos Selecting Photo Size and Quality Erasing a Photo Right After Recording It
59 59 61 62	Basic Playback Viewing Photos Magnifying Photos during Playback Deleting Photos
63 63 64 64 65 66	Additional Functions (\$22) / (\$521) / (\$520) Drive Mode: Continuous Shooting and Exposure Bracketing Histogram Display Protecting Photos (\$522) / (\$521) / (\$520) Copying Photos Other Functions You Can Use When Taking Photos
66 66 67 69	Printing Photos Printing Photos Selecting the Print Settings Print Orders

External Connections

72	Terminals on the Camcorder
72	Connection Diagrams

Connection Diagrams

Playback on a TV Screen 73

Saving and Backing Up Your Recordings 74

- Backing Up Your Recordings on a Computer 74
- 74 Authoring DVD Discs and Photo DVDs
- 77 Copying your Recordings to an External Video Recorder

	_	
Addi	tion	al Information
	81	Appendix: Menu Options Lists
	81	FUNC. Menu
	83	Setup Menus
	83	Camera Setup (Zoom Type, Image Stabilizer, etc.)
	85	Memory Operations (Initialization, etc.)
	85	Display Setup (LCD Brightness, Language, etc.)
	87	System Setup (Speaker Volume, Beep, etc.)
	89	Date/Time Setup
	90	Trouble?
	90	Troubleshooting
	94	List of Messages
	102	Do's and Don'ts
	102	Handling Precautions
	105	Maintenance/Others
	106	Using the Camcorder Abroad
	106	Music Files
	108	General Information
	108	System Diagram
	109	Optional Accessories
	112	Specifications

Transferring Photos to a Computer (Direct Transfer) Transfer Orders

77 80

115

Index

About this Manual

Thank you for purchasing the Canon LEGRIA FS22/FS21/FS20/FS200*. Please read this manual carefully before you use the camcorder and retain it for future reference. Should your camcorder fail to operate correctly, refer to *Troubleshooting* (90).

* Availability differs from area to area.

Conventions Used in this Manual


- **()** IMPORTANT: Precautions related to the camcorder's operation.
- (i) NOTES: Additional topics that complement the basic operating procedures.
- POINTS TO CHECK: Restrictions or requirements regarding the function described.
- II: Reference page number in this manual.

To complete some operations you will need to refer also to other instruction manuals. This will be indicated with the following icons and the name of the relevant chapter or section.

Refer to the "Digital Video Software" instruction manual, included as a PDF file in the supplied **DIGITAL VIDEO Solution Disk** CD-ROM.

DW-100> Refer to the instruction manual of the optional DW-100 DVD Burner.


- FS20: Text that applies only to the model shown in the icon.
- The following terms are used in this manual: When not specified as "memory card" or "built-in memory", the term "memory" by itself refers to both (1322) / 1321) / 1320 only).
 - "Scene" refers to one movie unit from the point you press the Start/Stop button to start recording until you press again to pause the recording.
- The photos included in this manual are simulated pictures taken with a still camera. Unless indicated otherwise, illustrations and menu icons refer to the



For a detailed explanation refer to *Using the Menus* (\$\sup\$ 25).

Supplied Accessories and CD-ROMs

The following accessories are supplied with the camcorder.




The following CD-ROMs and software are supplied with the camcorder.

- PIXELA Application Disc Ver.1 Disc 1 CD-ROM* and 'PIXELA ImageMixer 3 SE Ver.4 Installation Guide'
- ImageMixer 3 SE Ver.4 Transfer Utility For saving and transferring movies.
- Music Transfer Utility Ver.1 For transferring music for Video Snapshot and slideshow playback to the camcorder.
- PIXELA Application Disc Ver.1 Disc 2 CD-ROM*
 - ImageMixer 3 SE Ver.4 Video Tools For managing, editing, and playing back movies.
- DIGITAL VIDEO Solution Disk CD-ROM* Contains software for saving, managing, and printing photos.
- Instruction Manual/Music Data Disc CD-ROM Contains the full-length camcorder instruction manual (electronic version on PDF file) as well as music files for playing back Video Snapshot scenes. This CD-ROM cannot be played back on a CD player. The music files on this CD-ROM are for exclusive use with the supplied PIXELA applications, Music Transfer Utility and ImageMixer 3 SE Video Tools. For more details, refer to the 'Music Transfer Utility Software Guide' and 'ImageMixer 3 SE Software Guide' on the PIXELA Application Disc Ver.1 Disc 1 CD-ROM.


^{*} The CD-ROM includes the instruction manual of the software (electronic version on PDF file).

Components Guide


Left side view




Right side view




Front view




- 1 RESET button (93)
- ② VIDEO SNAP (Video Snapshot) button (□ 44)/□ ~ (print/share) button (□ 67, 77)
- ③ DISP. (on-screen display) button (☐ 51, 64)/ BATT. INFO button (☐ 16)
- 4 USB terminal (72)
- ⑤ AV OUT/ terminal (□ 72)
- 6 MIC terminal (red) (52)
- ⑦ Speaker (□ 35)
- ® Strap mount (D 20)
- 10 Grip belt
- 1) DC IN terminal (17)
- 12 Mini video light (43)
- (13) Stereo microphone



Top view



Bottom view




- 14 **FS22** Remote sensor (11 19)
- 15 LCD screen (Q 21)
- (i) ON/OFF(CHG) (power/charge) indicator (□ 18)
- (17) Camera mode dial (12) 23)
- (8) Start/Stop button (11) 31)
- (9 ➡► (camera/play) button (□ 24)
- 20 PLAYLIST button (53)/ Zoom in **T** (telephoto) button (32)
- ② (stop) button (□ 35)/
 Zoom out **W** (wide-angle) button (□ 32)
- ≥ large of the property of the property
- 23 FUNC. button (QQ 25, 81)
- 24 Joystick (24)
- 25 PHOTO button (57)
- 26 Zoom lever (1 32)
- 27 POWER button
- 28 Tripod socket (11 102)
- 29 Battery release latch (11 18)
- 30 Memory card slot (1 28)
- 31 Battery compartment (17)
- ③ Battery compartment cover/ Memory card slot cover
- 33 Serial number

The serial number label is located on the top surface of the battery compartment cover.




Wireless Controller WL-D88



- ① START/STOP button (CC 31)
- ② FUNC. button (25, 81)
- ③ MENU button (11 25, 83)
- 4 PLAYLIST button (53)
- ⑤ Navigation buttons (▲/▼/◄/▶)
- ⑥ ◀II (frame reverse) button (□ 36)
- ⑦ ◀◀ (fast reverse) button (□ 36)
- (8) ▶ (play) button (☐ 35)
- ⑨ (pause) button (□ 35)
- (1) **(stop)** button (□ 35)
- ① PHOTO button (57)
- 12 Zoom buttons (11 32)
- 13 SET button
- (frame advance) button (36)
- (fast forward) button (☐ 36)
- (6) DISP. (on-screen display) button(□ 51, 64)

Screen Displays

Recording Movies




Playing Movies (During Playback)




- ① Operating mode (QQ 23)
- 2 Recording program (41, 42)
- ③ White balance (48)
- 4 Image effects (49)
- (5) Digital effects (111 50)
- 6 Recording mode (32)
- 7) Remote sensor off (87)
- (8) Manual focus (111 48)
- 9 Image stabilizer (\$\square\$ 83)
- 10 Pre-recording function (46)
- 11) Memory operation (11) 16)
- 12 Number of scenes recorded (record pause)/Time code (hours : minutes : seconds, while recording)
- 13 Remaining recording time
 - On the memory card
 - (FS22) / (FS21) / (FS20) (III) In the built-in memory
- (14) Remaining battery time (16)
- 15 Headphone output (D 51)
- 16 Wind screen off (83)
- 17 Backlight correction (47)
- 18 Joystick guide (11 24)
- 19 Mini video light (43)
- 20 Level marker (85)
- 21 Audio level indicator (85)
- 22 Time code/Playback time (hours : minutes : seconds)
- 23 Scene number
- 24 Data code (85)

Recording Photos



▶ Viewing Photos





- 25 Zoom (□ 32), Exposure •——• (□ 47)
- 26 Recording program (41, 42)
- ② White balance (48)
- 28 Image effect (11 49)
- 29 Digital effect (III 50)
- 30 Drive mode (63)
- 3) Photo quality/size (57)
- 32 Manual focus (III 48)
- Remaining battery time (16)
 Number of photos available (16)
 On the memory card

On the memory card

[522 / [532] / [5320] In the built-in memory

- 35 Self timer (46)
- 36 AF frame (84)
- 37 Joystick guide (11 24)
- 38 Mini video light (D 43)
- 39 Focus and exposure lock (57)
- 40 Camcorder shake warning (84)
- 4) FS22 Remote sensor off (\$\infty\$ 87)
- 42 Photo number (11 16, 88)
- 43 Current photo / Total number of photos
- 44 Histogram (64)
- 45 Date and time of recording
- 46 Photo protection mark (64)
- ∅ Manual exposure (□ 47)
- 48 Photo size (57)
- 49 File size
- 50 Aperture value
- 5) Shutter speed (11 42)

11 Memory operation

- Record, II Record pause,
- ► Playback, Playback pause,
- ►► Fast playback.
- ◀■ Fast reverse playback,
- I► Slow playback.
- ◆I Slow reverse playback

FS22 only:

- ▶ Frame advance,
- ■II Frame reverse

(3) Remaining recording time

14, 33 Remaining battery time



- The icon shows a rough estimate of the remaining charge as a percentage of the full charge of the battery pack. The remaining recording/playback time of the battery pack is displayed, in minutes, next to the icon.
- When is displayed in red, replace the battery pack with a fully charged one.
- When you attach an empty battery pack, the power may turn off without displaying
- The first time you use a battery pack, fully charge it and then use the camcorder until the battery pack is completely exhausted. Doing so will ensure that the remaining recording time will be displayed accurately.

- Depending on the conditions under which the camcorder and the battery pack are used, the actual battery charge may not be indicated accurately.
- When the camcorder is off, press BATT.INFO to display the charge status of a battery pack. The Intelligent System will display the charge status (as a percentage) and the remaining recording time (in minutes) for 5 seconds. If the battery pack is exhausted, the battery information may not be displayed.

34 Number of photos available

in red: No card

- in green: 6 or more photos
- in vellow: 1 to 5 photos
- in red: No more photos can be recorded
- When viewing the photos, the display will always be in green.
- Depending on the recording conditions, the number of available photos displayed may not decrease even after a recording has been made, or may decrease by 2 photos at once.

42 Photo number

The photo number indicates the name and location of the file on the memory card. For example, the file name of photo 101-0107 is "IMG_0107.JPG", stored under the folder "DCIM\101CANON"





Preparations


This chapter describes basic operations, such as navigating the menus, and first time settings to help you learn more about your camcorder.

Getting Started

Charging the Battery Pack


The camcorder can be powered with a battery pack or directly using the compact power adapter. Charge the battery pack before use.

For approximate charging times and recording/playback times with a full battery pack, refer to the tables on pages 109-110.




 Connect the power cord to the compact power adapter.

- 2 Plug the power cord into a power outlet.
- 3 Connect the compact power adapter to the camcorder's DC IN terminal.



- 4 Slide the battery compartment cover away from the lens and open it.
- 5 Insert the battery pack all the way into the compartment and press gently until it clicks.
- 6 Close the cover and slide it toward the lens until you hear a click.

ON/OFF(CHG) indicator




7 Charging will start when the camcorder is turned off.

- The ON/OFF(CHG) indicator starts flashing in red. The indicator will go out when the charging is completed.
- If the indicator flashes quickly, refer to *Troubleshooting* (□ 90).

ONCE THE BATTERY PACK IS FULLY CHARGED

- 1 Disconnect the compact power adapter from the camcorder.
- 2 Unplug the power cord from the power outlet and the compact power adapter.

TO REMOVE THE BATTERY PACK



Battery release latch

- 1 Slide the battery compartment cover away from the lens and open it.
- 2 Press the battery release latch and pull out the battery pack.
- 3 Close the cover and slide it toward the lens until you hear a click.

IMPORTANT

- Turn off the camcorder before connecting or disconnecting the compact power adapter. After turning off the camcorder, important data is updated in the memory. Be sure to wait until the ON/OFF(CHG) indicator turns off.
- We recommend charging the battery pack in temperatures between 10 °C and 30 °C. Outside the temperature range of 0 °C to 40 °C, the charging will not start.
- Do not connect to the camcorder's DC IN terminal or to the compact power adapter any electrical equipment that is not expressly recommended for use with this camcorder.
- To prevent equipment breakdowns and excessive heating, do not connect the




supplied compact power adapter to voltage converters for overseas travels or special power sources such as those on aircraft and ships, DC-AC inverters, etc.

(i) NOTES

- Turn off the camcorder before charging the battery pack. The battery pack will not charge while the camcorder is on.
- If remaining battery time is an issue, you can power the camcorder using the compact power adapter so the battery pack will not be consumed.
- Charged battery packs continue to discharge naturally. Therefore, charge them on the day of use, or the day before, to ensure a full charge.
- We recommend that you prepare battery packs to last 2 to 3 times longer than you think you might need.


Preparing the Wireless Controller () and Accessories

First, insert the supplied lithium button battery CR2025 into the wireless controller.



- 1 Press the tab in the direction of the arrow and pull out the battery holder.
- 2 Place the lithium button battery with the + side facing up.
- 3 Insert the battery holder.

TO USE THE WIRELESS CONTROLLER



Point the wireless controller at the camcorder's remote sensor when you press the buttons.

You can rotate the LCD panel 180 degrees to use the wireless controller from the front of the camcorder.

(i) NOTES

- The wireless controller may not work properly when the remote sensor is situated under strong light sources or direct sunlight.


Accessories



Fasten the grip belt.

- Adjust the grip belt so that you can reach the zoom lever with your index finger, and the Start/Stop button with your thumb.
- You can remove the grip belt and replace it with the supplied wrist strap.

TO REMOVE THE GRIP BELT



- Lift the padded handgrip's flap and detach the strap from the Velcro pad.
- 2 Pull the strap to remove it first from the front bracket on the camcorder, then to unthread it from the handgrip and finally to remove it from the rear bracket on the camcorder.


TO ATTACH A WRIST STRAP



Pass the attaching end of the wrist strap through the back bracket on the camcorder, thread the wrist strap through the loop and fasten.

You can also attach the wrist strap to the strap mount on the grip belt to use both for extra convenience and protection.

TO ATTACH A SHOULDER STRAP



Pass the ends of the shoulder strap through the strap mount on the grip belt and adjust the length of the strap.



You can also remove the grip belt and attach the shoulder strap directly to the rear bracket on the camcorder.

TO REATTACH THE GRIP BELT

- Pass the end of the strap through the rear bracket on the camcorder.
- 2 Thread the strap through the padded handgrip and then pass it through the front bracket on the camcorder.
- 3 Fasten the grip belt as necessary, attach the strap to the Velcro pad on the handgrip and close the flap.

Adjusting the Position and Brightness of the LCD Screen


Rotating the LCD Panel

downward.

Open the LCD panel 90 degrees.

- You can rotate the panel 90 degrees
- You can rotate the panel 180 degrees toward the lens. Rotating the LCD panel 180 degrees can be useful in the following cases:
 - When you wish to include yourself in the picture when recording with the self timer.

 F522 To allow the camcorder to be operated with the wireless controller from the front.






Subject can monitor the LCD screen

(i) NOTES

About the LCD screen: The screen is produced using extremely high-precision manufacturing techniques, with more than 99.99% of the pixels operating to specification. Less than 0.01% of the pixels may occasionally misfire or appear as black, red, blue or green dots. This has no effect on the recorded image and does not constitute a malfunction.

LCD Backlight

You can set the brightness of the screen to dim, normal or bright. To set the screen to dim, turn on [LCD DIMMER] (\$\subseteq\$ 85). To toggle between normal and bright or to turn off [LCD DIMMER], perform the following procedure.



While the camcorder is on, hold DISP. pressed down for more than 2 seconds.

Repeat the operation to switch between normal and bright.

(i) NOTES

- This setting does not affect the brightness of the recording.
- Using the bright setting will shorten the effective usage time of the battery pack.
- When the compact power adapter is connected while the brightness of the screen is normal, the brightness will automatically change to bright.



Basic Operation of the Camcorder

Operating Modes


The camcorder's operating mode is determined by the The button and the position of the camera mode dial. In this manual, The indicates that a function is available in the operating mode shown and The indicates that the function is not available. See the following table for a summary of the operating modes.

Recording: Dual Shot and Flexible Recording

The camcorder offers two basic modes for recording video or photos: **Dual Shot** (mode) for beginners or if you just prefer not to bother with detailed camcorder settings, and **flexible recording** mode, which lets

you change the camcorder's settings to your preference.





Turn the camera mode dial to ** to set the camcorder to ** mode. You do not need to worry about any settings and can shoot video using just ** Start/Stop* (** 31) or take photos using just **PHOTO* (***) 57). You can also use the zoom lever, Quick Start (***) 34) and

To set the camcorder to flexible recording mode, turn the camera mode dial to ¹, for movies or □ for photos.

Video Snapshot (44).

Operating mode	lcon display	Operation	
***	AUTO	Recording movies or photos to the memory (Dual Shot)	23
!	(green)	Recording movies to the memory	31
	(blue)	Recording photos to the memory	57
ΪŻ	(green)	Playing movies from the memory (press ≒ ↓ while the camera mode dial is set to ♠ or ≒)	35
	(blue)	Viewing photos from the memory (press $^{\backprime}\!$	59

^{* (}ES22) / (ES21) / (ES20) only.

You can access the menus and change settings to your preference. Even in flexible recording mode, the camcorder can help you with the settings. For example, you can use the Special Scene recording programs (

41) to set at once all the optimal settings to match special recording conditions.

Playback

(i) NOTES

In mode you cannot access the menus or joystick guide but you can change the following settings in advance, before setting the camcorder to mode.

- Recording mode of movies
- Size/quality of photos
- Widescreen
- Auto slow shutter
- All settings in the [SYSTEM SETUP]
- LCD screen dimmer
- Demo mode
- Image stabilizer

Joystick and Joystick Guide

Use the joystick to operate the camcorder's menus.

Push the joystick up, down, left or right (▲▼, ◀►) to select an item or change settings.



Press the joystick itself ((1)) to save the settings or confirm an action. On menu screens, this is indicated by the icon ((SET)).



The functions that appear in the joystick guide depend on the operating mode. By default, the joystick guide is minimized. Push the joystick (▲) to display it.

During • or omega mode, select (value a function and press of to change the setting. With some functions, you will need to make further adjustments (indicated by small arrows).

During playback mode, select (▲▼) a "row" of functions and press ⊕ to operate the function in the middle or push the joystick (◀►) to operate the function on the left or right side of the row, respectively.




In either mode, if you wait a few seconds, the joystick guide will minimize again but the selected function can still be operated. You can also push the joystick (▼) to hide the joystick quide.

Using the Menus

Many of the camcorder's functions can be adjusted from the menus that open after pressing the FUNC. button ((FUNC.)). To access the menus, set the camcorder to flexible recording mode. In mode, except for a few exceptions, most menu settings will return to their default values. For details about the available menu options and settings, refer to the

appendix Menu Options Lists (81).

Selecting a FUNC. Menu Option in Recording Mode




- 1 Press FUNC.
- 2 Select (▲▼) the icon of the function you want to change from the left side column.

Menu items not available will appear grayed out.

- 3 Select (◄►) the desired setting from the available options at the bottom bar.
 - The selected option will be highlighted in orange.
 - With some settings you will need to make further selections and/or press (F). Follow the additional operation guides that will appear on the screen (such as the series, small arrows, etc.).
- 4 Press FUNC. to save the settings and close the menu.

You can press FUNC. to close the menu at any time.

Selecting an Option from the Setup Menus



1 Press FUNC.

2 Select (▲▼, ◀►) the iii icon and press iii to open the setup menus.

You can also press MENU on the wireless controller (FS22) only) or hold FUNC. pressed down for more than 1 second or to open directly the setup menus screen.

- 3 Select (▲▼) the desired menu from the left side column and press (€F).

 The title of the selected menu appears on top of the screen and under it the list of settings.
- 4 Select (▲▼) the setting you want to change and press (♣).
 - The orange selection bar indicates the menu setting currently selected. Items not available appear in black.
 - Push the joystick (◄) to return to the menu selection screen (step 3).
- 5 Select (▲▼) the desired option and press (♣₹) to save the setting.
- 6 Press FUNC.

You can press FUNC. to close the menu at any time.

First Time Settings

Setting the Date and Time

You will need to set the date and time of the camcorder before you can start using it. The [DATE/TIME] screen will appear automatically when the camcorder's clock is not set.



When the [DATE/TIME] screen appears, the year will be displayed in orange and indicated with up/down arrows.

- Change (▲▼) the year and move
 (►) to the month.
- 2 Change the rest of the fields (month, day, hour and minutes) in the same way.
- 3 Select (▶) [OK] and press (□) to start the clock and close the setup screen.



 When you do not use the camcorder for about 3 months, the built-in rechargeable lithium battery may discharge completely and the date and time setting may be lost. In such case, recharge the built-in lithium battery
 104) and set the time zone, date and time again.



- The date appears in a year-month-day format only in the first setup screen. In subsequent screen displays the date and time will appear as day-month-year (for example, [1.JAN,2009 12:00 AM]). You can change the date format (89).
- · You can also change the date and time later on (not during the initial setup). To open the [DATE/TIME] screen:

FUNC. D [MENU] D DATE/TIME SETUP] [DATE/TIME]

Changing the Language













Options

♦ Default value

[ČEŠTINA]	[MELAYU]	[العربية]
[DEUTSCH]	[NEDERLANDS]	[فارسى]
[EVVHNIKA]	[POLSKI]	[ภาษาไทย]
[ENGLISH]◆	[PORTUGUÊS]	[简体中文]
[ESPAÑOL]	[ROMÂNĂ]	[繁體中文]
[FRANÇAIS]	[TÜRKÇE]	[한국어]
[ITALIANO]	[РУССКИЙ]	[日本語]
[MAGYAR]	[УКРАЇНСЬКА]	

FUNC.

[Ⅲ MENU] 🔊

[DISPLAY SETUP] 🔊 [LANGUAGE 1 6

Desired language

FUNC.

NOTES

- If you changed the language by mistake, select the menu item with the @ mark and change the setting.
- The displays SET and FUNC that appear in some menu screens refer to the name of buttons on the camcorder and will not change, regardless of the language selected.

Changing the Time Zone

Change the time zone to match your location. The default setting is Paris.



TO SET THE HOME TIME ZONE

FUNC.

[Ⅲ MENU] 🔊

[DATE/TIME SETUP]

[T.ZONE/DST] 🔘 🧥 🔘

Your local time zone* FUNC.

WHEN YOU TRAVEL

FUNC.

[Ⅲ MENU] 🔊

[DATE/TIME SETUP]

[T.ZONE/DST] 🕥 💢 🔘 Local time at your destination*

FUNC.

* To adjust for daylight saving time, select the area name marked with a 🔌.

 $(\Box 23)$

Using a Memory Card

Memory Cards Compatible for Use with the Camcorder

You can use commercially available SDHC (SD high capacity) memory cards and SD SD memory cards with this camcorder to record movies and photos. However, depending on the memory card, you may not be able to record movies on it. Refer to the following table.


As of December 2008, the movie recording function has been tested using SD/SDHC memory cards made by Panasonic, SanDisk and Toshiba.

(i) NOTES

About the SD Speed Class: The SD Speed Class is a standard that indicates the minimum guaranteed data transfer speed of SD/SDHC memory cards. When you buy a new memory card, look for the Speed Class logo on the package.

Inserting and Removing a Memory Card

Make sure to initialize all memory cards before using them with this camcorder (
29).



- 1 Turn off the camcorder.

 Make sure that the ON/OFF(CHG) (power/charge) indicator is off.
- 2 Slide the memory card slot cover away from the lens and open it.
- 3 Insert the memory card straight, with the label facing away from the lens, all the way into the memory card slot until it clicks.
- 4 Close the cover and slide it toward the lens until you hear a click.

Memory cards usable for recording movies

Memory card	Capacity	SD Speed Class	Recording movies
	64 MB or less	_	_
SD memory cards	128 MB to 2 GB	-	•*
	512 MB to 2 GB	CLASS@ or higher	•
SDHC memory cards	4 GB to 32 GB	CLASS@ or higher	•

^{*} Depending on the memory card, it may not be possible to record movies.



Do not force the cover closed if the memory card is not correctly inserted.

depend on the recording mode (for movies) or size/quality (for photos) currently in use.

IMPORTANT

Memory cards have front and back sides that are not interchangeable. Inserting a memory card facing the wrong direction can cause a malfunction of the camcorder.



To remove the memory card: Push the memory card once to release it. When the memory card springs out, pull it all the way out.

(3522) / (3521) / (3520) Selecting the Memory for the Recordings

You can select to record your movies and photos in the built-in memory or on the memory card. The built-in memory is the default media for recording both.











FUNC.

[Ⅲ MENU] ◎

[

 MEMORY OPER.]
 MEDIA:MOVIES] or

[MEDIA:PHOTOS] 🔘

The memory you want to use* Press 🗊 🔊

FUNC.

* For each media, you can check the total, used, and approximate available space. The approximate available space will

Initializing the Built-In Memory (1322) / (1320) only) or Memory Card

Initialize memory cards when you use them with this camcorder for the first time. You can also initialize a memory card or the built-in memory (1522) / (1520) only) to permanently delete all the data it contains.

[522] / (1521) / (1520) At the time of purchase, the built-in memory comes pre-initialized and contains music files

purchase, the built-in memory comes pre-initialized and contains music files for Video Snapshot and slideshow playback.







Options

[INITIALIZE]

Clears the file allocation table but does not physically erase the stored data.

[COMPL.INIT.]

Erases all data completely.

FS22 / FS21 / FS20

FUNC.

[Ⅲ MENU] ◎

[MEMORY OPER.]

[INITIALIZE]
The memory you

want to initialize
Initialization method

[YES]* (○ [OK] (○

FUNC.

FS200

FUNC.

[Ⅲ MENU] ⑤

[☐ MEMORY OPER.] ◎

[INITIALIZE]

Initialization method

[YES]* **○** [OK] **○**

FUNC.

* Press (f) to cancel the complete initialization while it is in progress. All recordings will be erased but the recording media can be used without any problem.

■ IMPORTANT

- Initializing the memory will permanently erase all data. Lost original recordings cannot be recovered. Make sure you back up important recordings in advance using an external device (
 74).
- Music files for Video Snapshot will also be erased. Use the supplied software Music Transfer Utility to transfer the music files on the supplied Instruction Manual/Music Data Disc CD-ROM.
 For details, refer to the software's instruction manual (PDF file).
- While the initialization is in progress, do not disconnect the power source or turn off the camcorder





Video

This chapter covers functions related to shooting movies, including recording, playback, and memory operations.

Basic Recording

Shooting Video










(🗀 23)



- 2 Turn on the camcorder.

 \$22 / \$321 / \$320 You can select
 the memory to be used for recording
 movies (\$\superbox{10}{\superbox{29}}\$.
- 3 Press Start/Stop to begin recording.
 - Recording starts; press Start/Stop again to pause the recording.

 You can also press START/STOP on the LCD panel.

WHEN YOU HAVE FINISHED RECORDING

- Make sure that the ACCESS indicator is off.
- 2 Turn off the camcorder.
- 3 Close the LCD panel.



Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss or damage to the memory.

- Do not open the memory card slot cover.
- Do not disconnect the power source or turn off the camcorder.
- Do not change the operating mode.

i) NOTES

- About the Power Save mode: To save power when the camcorder is powered by a battery pack, the camcorder will automatically shut off if left without any operations for 5 minutes (\$\subseteq\$ 87). Press
 POWER to turn on the camcorder.
- When recording in bright places it may be difficult to use the LCD screen.
 Conversely, when recording in dark places, the LCD panel may be a nuisance to others nearby. In such cases, change the brightness of the LCD screen accordingly (21, 86).

Selecting the Video Quality (Recording Mode)

The camcorder offers 3 recording modes. Changing the recording mode will change the recording time available on the memory. Select XP mode for better movie quality; select LP mode for longer recording times. The following table gives approximate recording times.



FUNC.

[ST STANDARD PLAY 6Mbps] Desired recording mode FUNC.

(i) NOTES

- The camcorder uses a variable bit rate (VBR) to encode video so the actual recording times will vary depending on the content of the scenes.
- The camcorder retains the last setting used even if you set the camcorder to make mode.

Zooming: Optical, Advanced and Digital Zoom

The camcorder offers three types of zoom: optical, advanced and digital zoom. In mode, all three types are available. In mode, only the advanced zoom is available; in mode, only the optical zoom is available.

Approximate recording times for movies

◆ Default value

Recording mode → Memory ↓	ХР	SP◆	LP
1 GB memory card	10 min.	20 min.	35 min.
2 GB memory card	25 min.	40 min.	1 hr. 15 min.
4 GB memory card	55 min.	1 hr. 20 min.	2 hr. 35 min.
8 GB memory card	1 hr. 50 min.	2 hr. 45 min.	5 hr. 10 min.
ES21 Built-in memory/ 16 GB memory card	3 hr. 40 min.	5 hr. 30 min.	10 hr. 20 min.
ES22 Built-in memory/ 32 GB memory card	7 hr. 20 min.	11 hr. 5 min.	20 hr. 50 min.

- When a recording exceeds 4 GB, it will be divided and saved as scenes smaller than 4 GB.
- [5322] / [5320] The camcorder comes pre-installed with about 170 MB of music files.



Selecting the Zoom Type







 $(\square 23)$

Options

♦ Default value

[37x OPTICAL] (37x)

The zoom range is limited to the optical magnification ratio of the lens.

[45x ADVANCED] (Advanced Zoom)

In addition to the optical zoom range, the camcorder processes the image digitally to obtain a larger zoom range without any deterioration in image quality. When recording movies with a 16:9 aspect ratio, the field of view (picture angle) will change. Refer to the table in the NOTES section. F5200 The default setting is [41x ADVANCED].

[2000x DIGITAL] (2000x)

When this option is selected, the camcorder will switch to digital zoom (light blue area on the zoom indicator) when you zoom in beyond the optical zoom range (white area on the zoom indicator). With the digital zoom, the image is processed digitally so image quality will deteriorate the more you zoom in.

FUNC.



[Ⅲ MENU] ⑤

[CAMERA SETUP]

[ZOOM TYPE] Desired option

FUNC.

(i) NOTES

• The zoom range of the advanced zoom will change depending on the aspect ratio of the scene (83).

[WIDESCREEN] set to [ON ON] (16:9)

FS22 / **FS21** / **FS20** 45x*, FS200 41x**

- The picture angle will be wider at both full telephoto and full wide-angle.
- ** The picture angle will be wider at full wide-angle.

[WIDESCREEN] set to [OFF OFF] (4:3)

FS22 / **FS21** / **FS20** 46x. FS200 Not available


Using the Zoom







(23)









Move the zoom lever toward W to zoom out (wide-angle). Move it toward **T** to zoom in (telephoto).

Press gently for a slow zoom; press harder for faster zooms. You can also set [ZOOM SPEED] (83) to one of three constant speeds (3 is the fastest, 1 the slowest).

(i) NOTES

- Keep at least 1 m away from the subject. At full wide angle, you can focus on a subject as close as 1 cm.
- When [ZOOM SPEED] is set to [VAR VARIABLE]:
 - The zoom speed will be faster in record pause mode than when actually recording.
 - When you use the **T** and **W** buttons on the wireless controller (**1522**) only) or LCD panel, the zoom speed will be constant at [**232**] SPEED 3].

Ouick Start Function

When you close the LCD panel with the camcorder on, the camcorder enters the standby mode. In standby mode the camcorder consumes only about half the power used when recording, saving energy when you are using a battery pack. Additionally, when you open the LCD panel or change the position of the mode dial, the camcorder is ready to start recording in approximately 1 second*, allowing you to record the subject right away.

* The actual time required varies depending on the shooting conditions.



 With the camcorder on and in a recording mode, close the LCD panel.

A beep will sound and the ON/ OFF(CHG) (power/charge) indicator will change to orange to indicate the camcorder entered the standby mode.

2 When you wish to resume recording, open the LCD panel.

The ON/OFF(CHG) indicator will return to green and the camcorder will be ready to record.



IMPORTANT

Do not disconnect the power source during standby mode (while the ON/ OFF(CHG) indicator is lit in orange).

(i) NOTES


- If you close the LCD panel under some circumstances (for example while recording, while a menu is being displayed, while the battery charge is low, or while the memory card slot cover is open), the camcorder may not enter the standby mode. Check that the ON/OFF(CHG) indicator changes to orange.
- The camcorder will shut off if left in standby mode for 10 minutes, regardless of the [POWER SAVE] setting (
 87). Press POWER to turn on the camcorder.
- You can select the length of time until shut-off or turn off the Quick Start function with the [QUICK START] setting (88).



Basic Playback

Playing Back the Video





- Set the camera mode dial to ♣
 or ♣
- 2 Press '\sigma\subset \overline{\Pi}\subset \overline{\Pi}\subset.
 - Even if the camcorder is off, pressing '\sigma\subset \subset will turn on the camcorder in playback mode.
 - The original movies index screen appears after a few seconds.
- 3 Move (▲▼, ◄►) the selection frame to the scene you want to play back.

Push the joystick (▲▼) to extend the selection frame and browse (◀►) through whole index pages. Push the joystick (▲▼) to return to the index screen.

4 Press ▶/II or ⑤ to begin the playback.

- Playback will start from the scene selected and continue until the end of the last scene recorded.
- Press again to pause the playback.
- Press to stop the playback and return to the index screen.

ADJUSTING THE VOLUME



- Push the joystick (▲) to display the joystick guide.
- 2 Push the joystick (▲▼) to select the top row.
- 3 Adjust (◄►) the volume. To turn off the volume, keep the joystick pressed (◄) toward ◄୬ until the volume bars disappear.

IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.
 - Do not open the memory card slot cover.
 - Do not disconnect the power source or turn off the camcorder.
 - Do not change the operating mode.
- You may not be able to play back with another device the movies you recorded on the memory card with this camcorder. In such case, play back the

movies on the memory card using this camcorder.

 You may not be able to play back with this camcorder movies recorded using another device.



Depending on the recording conditions, you may notice brief stops in video or sound playback between scenes.

Special playback modes

To enter the special playback modes, use the wireless controller (322 only; 13) and joystick guide (24). There is no sound during the special playback modes.

Fast playback

From normal playback, play back scenes at a faster speed than normal. Every time the operation is performed, the playback speed is increased $5x \rightarrow 15x \rightarrow 60x$.

Display the joystick guide ⑤ select (▲▼) the middle row ⑥ Push the joystick (◀►) toward ◀◀ or ►►.

■ Alternatively, press ◀ or ►► on the wireless controller.

Slow playback

From playback pause mode, play back scenes at a slower speed than normal. Slow playback is 1/8 the normal speed; slow reverse playback is 1/12 the normal speed.

Display the joystick guide
Select

(▲▼) the middle row
Push the
joystick (◀►) toward ◀ or I►.

S22 Alternatively, press
on the wireless controller.

Frame Advance/Reverse () only)

In playback pause mode, press III or III on the wireless controller to reverse a few frames (approx.

0.5 seconds) or to advance one frame. Hold the button pressed for continuous playback.

Skipping scenes

To skip to the next scene:

Display the joystick guide ⑤ Select
(▲▼) the bottom row ⑥ Push the
joystick (▶) toward ﴾.

■ Alternatively, press ⑥ on the
wireless controller.

* Repeat to skip to the beginning of the previous scene.

Ending special playback modes

During any special playback mode, press [>III] on the camcorder or on the wireless controller ([522] only) to return the camcorder to its initial playback mode.




- During some special playback modes, you may notice some anomalies (blocky video artifacts, banding, etc.) in the playback picture.
- The speed indicated on the screen is approximate.



Selecting What Recordings to Play Back

From the index screen, you can select whether to play back movies or photos. You can also use the tabs on the top of the screen to select the media from which to play back recordings (\$\frac{1522}{1521}\$ / \$\frac{1520}{1520}\$ only).











1 In the index screen, move (▲▼) the orange selection frame to the tabs on the top of the screen.

FS22 / FS21 / FS20



FS200



- Movies
- Photos
- Recordings in the built-in memory
- Recordings on the memory card
- 2 Select (◄►) the media (☐ 522 / ☐ 521 / ☐ 520 only) and the recording type (scenes or photos).

3 Return (▲▼) to the index screen to select the scene or photo.

Selecting Scenes by Recording Date

You can search for all the recordings you made on a particular date (for example, to find all the movies you shot during a special event).













Selecting scenes by recording date is available only from the original movies index screen.

Selecting from the List of Recordings

- 1 Open the original movies index screen.
 - From this index screen, you can also press VIDEO SNAP to open the index screen for Video Snapshot
 44) scenes.
 - **IS22** / **IS21** / **IS20** You can select the scenes in the built-in memory or on the memory card (37).
- 2 Open the list of recordings.

FUNC. (SELECT DATE)

- The list of recordings displays all dates in which recordings were made. An orange selection frame appears on the day.
- The thumbnail shows a photo from the first scene recorded on that

day. Below it will appear the number of scenes recorded and the total recording time for the same day.

- 3 Change (▲▼) the day and move (◀►) to the month or year.
- 4 Change the other fields in the same way to select the desired date and press (\$\varepsilon\$).

The index screen will appear with the selection frame on the first scene recorded on the selected date.

Selecting from the Calendar Screen

- 1 Open the original movies index screen.

 - **(522)** / **(532)** / You can select the scenes in the built-in memory or on the memory card (1) 37).
- 2 Open the calendar screen.

FUNC. (SCENE SEARCH) (ICALENDAR)

- The calendar screen appears.
- Dates that contain scenes (that is, movies were recorded on that date) appear in white. Dates without recordings appear in black
- 3 Move (▲▼, ◀►) the cursor to the desired date.
 - When you move the cursor to a date displayed in white, a thumbnail showing a photo from the first scene recorded on that date will be displayed next to the calendar. Below it will appear the

- number of scenes recorded and the total recording time for the same day.
- You can select (▲▼) the year or month field and change (◀►) the year or month to move faster between calendar months.
- 4 Press (ET) to return to the index screen.

The orange selection frame will appear on the first scene recorded on the selected date.


(i) NOTES

- You can change on what day to start the week for the calendar display (86).
- You can press FUNC. to return to the index screen at any time.

Selecting the Playback Starting Point from the Movie Timeline


You can display a timeline of the scene and select where to begin the playback. This is very convenient when you want to play back a long scene from a specific point.







- 1 In the index screen select the scene you want to view and press DISP.
 - The timeline screen appears. The large thumbnail will show the first frame of the scene. Below it, the timeline ruler shows frames taken from the scene at fixed intervals.
 - Press DISP. again to return to the index screen.



- 2 Select (◄►) the playback starting point from the timeline ruler.
- 3 Press (ET) to begin the playback.

TO SELECT ANOTHER SCENE

Move (▲▼) the orange selection frame to the large thumbnail and change (◀▶) the scene.

TO MOVE BETWEEN TIMELINE RULER PAGES

Move (▲▼) the orange selection frame to the slidebar below the ruler and display (◀►) the previous/next 5 frames in the scene.

TO CHANGE THE INTERVAL BETWEEN FRAMES

FUNC. Desired interval FUNC.

Pre-selecting Recordings from the Index Screen

You can select in advance a number of movies or photos from the index screen in order to perform certain actions on them collectively, all at once.

mode: Delete (40), copy (522) / 521 / 520 only; 55) or add the selected scenes to the playlist (53).

mode: Delete (62), copy (522) / 5321 / 5320 only; 65) or protect (64) the selected photos or mark all of them with print orders (69) or transfer orders (80).



1 Select the movies or the photo index screen.

- From this index screen, you can also press VIDEO SNAP to open the index screen for Video Snapshot (
 44) scenes.
- (522) / (5321) / (5320) You can select the scenes in the built-in memory or on the memory card (1) 37).
- 2 Open the selection screen.

FUNC. (>) [V SELECT] (>) [INDIVIDUAL SCENES] or [INDIVIDUAL PHOTOS]

• The selection screen appears.

- 3 Move (▲▼, ◀►) between the scenes or photos in the index screen and press (₤) to select an individual scene/photo.

 - Repeat this step to add all the scenes/photos you want to include in your selection (up to 100).

Total number of scenes selected



4 Press FUNC. twice to close the menu.

TO CANCEL ALL THE SELECTIONS



(i) NOTES

- The selection of scenes/photos will be canceled if you turn off the camcorder or change the operating mode.
- Scenes in the playlist cannot be included in the selection.

Deleting Scenes

You can delete original scenes that you are not interested in keeping. Deleting scenes also allows you to free up space on the memory. To delete scenes in the playlist, refer to *Deleting Scenes from the Playlist* (

54).



Options

FALL SCENES

Deletes all the scenes.

[ALL SCENES (THIS DATE)]

Deletes all the scenes recorded on the same day as the selected scene.

[ONE SCENE]

Deletes only the selected scene.

[SELECTED SCENES]

Deletes all the scenes selected in advance (marked with a ✓ checkmark). Refer to *Preselecting Recordings from the Index Screen* (□ 39).

1 Select (▲▼, ◄►) the scene you want to delete, or a scene recorded on the date you want to delete.

This step is not necessary to delete all scenes or previously selected scenes.

2 Delete the scene(s).



* If you selected any option other than [ONE SCENE], you can press 🗊 to interrupt the



operation while it is in progress. Some scenes will be deleted nevertheless.

A

IMPORTANT

- Be careful when deleting original recordings. Once deleted, an original scene cannot be recovered.
- Back up important scenes before deleting them (
 74).
- Observe the following precautions while the ACCESS indicator is on or flashing (while scenes are being deleted).
 - Do not open the memory card slot cover.
 - Do not disconnect the power source or turn off the camcorder.
 - Do not change the operating mode.

(i) NOTES

- Deleting a scene from the original movies index screen also deletes that scene from the playlist.
- To delete all movies and make all recordable space available again you may prefer to initialize the memory (2)
- You may not be able to delete scenes recorded or edited using another device.

Advanced Functions

Special Scene Recording Programs

Recording in a very bright ski resort or capturing the full colors of a sunset or a fireworks display becomes as easy as selecting a Special Scene recording program. For details about the available options, refer to the sidebar on page 42.







(🕮 23)



[PROGRAM AE] ◎
[N PORTRAIT] ◎

Press (ET) to display the Special Scene (SCN) recording programs (SC)

Desired recording program

FUNC.

(i) NOTES

- [NIGHT]
 - Moving subjects may leave a trailing afterimage.
 - Picture quality may not be as good as in other modes.
 - White points may appear on the screen.
 - Autofocus may not work as well as in other modes. In such case, adjust the focus manually.
- [FIREWORKS]
 - To avoid camcorder shake, we recommend using a tripod. Make sure to use a tripod especially in mode, as the shutter speed slows down.

PORTRAIT]

The camcorder uses a large aperture. achieving a focus on the subject while



blurring other distracting details.

[SPORTS]

Use this mode to record sports scenes such as tennis or golf.



[SUNSET]

[BEACH]

Use this mode to

record on a sunny

beach. It prevents

the subject from

Use this mode to record sunsets in vibrant colors.



[NIGHT]

Use this mode to record in dimly lit places.



[A SPOTLIGHT]

Use this mode to record spotlit scenes.



[*8" SNOW]

Use this mode to record in bright ski resorts. It prevents the subject from being underexposed.



ſ ∰ FIREWORKS1

Use this mode to record fireworks.





• [MPORTRAIT]/[MSPORTS]/

- The picture may not appear smooth during playback.
- [PORTRAIT]
 - The blur effect of the background increases the more you zoom in (T).

• [SSNOW]/[SBEACH]

- The subject may become overexposed on cloudy days or in shaded places. Check the image on the screen.

Controlling Shutter Speed and Other Functions while Shooting

Use the automatic exposure (AE) program to use functions like the white

balance or image effects, or give priority to the shutter speed. Use faster shutter speeds to record subjects moving quickly; use slower shutter speeds to add motion blur. emphasizing the feel of movement.





Options

Default value

[PROGRAM AEI ◆

The camcorder automatically adjusts the aperture and shutter speed to obtain the optimal exposure for the subject.

[TV SHUTTER-PRIO.AE]

Set the shutter speed value. The camcorder automatically sets the appropriate aperture value.

FUNC.

[PROGRAM AE] Desired recording program*

FUNC.

 When you select [TV SHUTTER-PRIO.AE], do not press FUNC. and continue instead with the following procedure.

TO SET THE SHUTTER SPEED

- 1 Adjust (◄►) the shutter speed to the desired value and then press (SET).
- 2 Press FUNC. .

Shutter speed guidelines

Note that on screen only the denominator is displayed - [TV 250] indicates a shutter speed of 1/250 second, etc.

1/2*, 1/3*, 1/6, 1/12, 1/25

To record in dimly lit places.

To record under most ordinary conditions.

To record indoor sports scenes.

1/250. 1/500. 1/1000**

To record from within a moving car or train or to shoot fast-moving subjects such as roller coasters.

1/2000**

To record outdoor sports scenes on sunny days.

- mode only.
- ** Pm mode only.

NOTES

「■ SHUTTER-PRIO.AEI

- When setting the shutter speed, the number display will flash if the value is not appropriate for the recording conditions. In such case, select a different value.
- If you use a slow shutter speed in dark places, you can obtain a brighter image, but image quality may be lower, and autofocus may not work well.
- The image may flicker when recording with fast shutter speeds.

Mini Video Liaht

You can turn on the mini video light to shoot video or take photos in dark places.






- 1 Push the joystick (▲) to display the joystick guide.
- 2 Select (▲▼) [VID.LIGHT ۞] and press ⑸.
 - appears on the screen.
 - Press (ET) again to turn the mini video light off.

Video Snapshot

Record a series of short scenes and combine them with music to add a new level of enjoyment to your movies. By changing the music, you can give your scenes an entirely new feel. You can also add to the playlist (\square 53) just the scenes you want to watch and change their order.

Music Transfer Utility to transfer in advance the music files on the supplied Instruction Manual/Music Data Disc.

CD-ROM. For details, refer to the software's instruction manual (PDF file).



Recording Scenes



- 1 Press VIDEO SNAP .
 - The button's light illuminates.
 - A blue border appears on the screen.
- 2 Press Start/Stop.
 - The camcorder records for about 4 seconds and then automatically switches to record pause mode.
 - The blue border changes to black and roughly indicates how much time has passed. When the camcorder has finished recording, the screen will momentarily turn black as if a camera shutter had released.

Combining Scenes with Music





- 1 In the original movies index screen, press (VIDEO SNAP).
 - The button's light illuminates.
 - An index screen appears that contains only the Video Snapshot scenes.

2 Set the background music.

- * Press (£T) to start/stop the track. Select [OFF] to set the original audio of the scenes.
- IS22 / IS21 / IS20 Make sure the music files are in the same media (built-in memory or memory card) that contains the scenes. For details, refer to the instruction manual (PDF file) of the supplied software Music Transfer Utility.

Playing Back the Scenes



Select a scene from which to start playback and press ▶/II.

There is no sound during fast playback.

TO DELETE A MUSIC TRACK

- In the track selection screen, select (▲▼) a track to delete.
- 2 Select (▶) m and press (□).
- 3 Select (►) [YES] and press ⑤. Press ⑥UNC twice to return to the index screen.



Music files transferred to the camcorder with the supplied software **Music**

Transfer Utility may not be used without permission from the copyright holder, except for cases permitted under applicable laws, such as for personal use. Make sure to follow applicable laws when using music files.

(i) NOTES

- If the memory is initialized, the music files in the memory will also be erased. Use the supplied software Music Transfer Utility to transfer the music files on the supplied Instruction Manual/Music Data Disc CD-ROM to the camcorder.
- (352) (352) / (352) The Instruction Manual/Music Data Disc CD-ROM contains the tracks pre-installed in the built-in memory as well as tracks that were not. You can change the tracks in the memory and try out new combinations.
- For details, refer to the instruction manual (PDF file) of the supplied software Music Transfer Utility.
- Video Snapshot is deactivated if the camcorder is switched to playback mode.
- Before transferring music files, we recommend making sure that there is enough available space in the memory (about 5 times more than the size of the music files). If there is not enough available space, the video and audio may not play back correctly.
- If the USB cable is disconnected while transferring music files to the camcorder, playback of those files may not be possible. In such case, erase those music files in the

camcorder (45) and transfer the files again.

Pre-recording Function

The camcorder will start recording 3 seconds before you press <code>Start/Stop</code>, ensuring you do not miss important shooting opportunities. This is especially useful when it is difficult to predict when to start recording.







- 1 Push the joystick (▲) to display the joystick guide.
- 2 Select (▲▼) [Pre REC 🍎] and press 🗊.
 - **(6)** appears.
 - Press (ET) again to turn prerecording off.
- 3 Press Start/Stop to begin recording.
 The recording will include the 3 seconds before Start/Stop was pressed.

(i) NOTES

- While pre-recording is on, all operational sounds will be turned off.
- The camcorder will not record the full 3 seconds if any of the following operations are not performed before 3 seconds have elapsed.

- Turning on pre-recording
- Exiting standby mode
- Stopping a recording
- Pre-recording will be turned off when any of the following operations are performed.
 - Opening the FUNC. menu or setup
 - Leaving the camcorder without any operation for 5 minutes
 - Changing the operating mode
 - Turning on Video Snapshot
 - Setting the camcorder to standby mode

Self Timer



FUNC.

[Ⅲ MENU] ◎

FUNC.

appears.

mode: In record pause mode, press

Start/Stop .

The camcorder starts recording after a 10-second countdown*. The countdown appears on the screen.

mode:

Press PHOTO, first halfway to activate the autofocus and then fully.

The camcorder will record the photo after a 10-second countdown*. The countdown appears on the screen.



* **F522** 2 seconds when using the wireless controller.

(i) NOTES

- When the LCD panel is rotated toward the lens, we recommend pushing the joystick (▼) to hide the joystick guide and make the ⋈ icon appear larger.
- The self timer will be canceled when any of the following operations are performed.
 - Pressing Start/Stop (when recording movies) or PHOTO (when taking photos) once the countdown has begun
 - Turning off the camcorder
 - Changing the operating mode
 - Setting the camcorder to standby mode

Automatic Backlight Correction and Manual Exposure Adjustment

At times, backlit subjects may appear too dark (underexposed) or subjects under very strong lights may appear too bright or glaring (overexposed). To correct this, you can manually adjust the exposure or use the automatic backlight correction.





Select a recording program other than [#FIREWORKS].

Automatic Backlight Correction





When shooting subjects with a strong light source behind them, you can have the camcorder automatically correct for the backlight.

- 1 Push the joystick (▲) to display the joystick guide.
- 2 Select (▲▼) [BLC *i] and press (SET).
- appears on the screen.
- Press (ET) again to end the backlight correction mode.

Manual Exposure Adjustment





- 1 Push the joystick (▲) to display the joystick guide.
- 2 Select (▲▼) [EXPOSURE 🔀] and press (ミデ).
 - The exposure will be locked.
 - The exposure adjustment indicator
 and the neutral value [±0]
 appear on the screen.
 - The adjustment range and the length of the exposure adjustment indicator will vary depending on the initial brightness of the picture.
- 3 Adjust the (◀▶) the brightness of the image as required.
 - If you operate the zoom lever during exposure lock, the brightness of the image may change.

 During exposure lock, press (E) to return the camcorder to automatic exposure.

Manual Focus Adjustment

Autofocus may not work well on the following subjects. In such case, focus manually.

- Reflective surfaces
- Subjects with low contrast or without vertical lines
- Fast moving subjects
- Through wet windows
- · Night scenes





Adjust the zoom before you start the procedure.



- 1 Push the joystick (▲) to display the joystick guide.
- 2 Select (▲▼) [FOCUS ⑤] and press ⑤□.

[MF] appears on the screen.

- 3 Adjust (◀▶) the focus as necessary.
 - The focus will be locked.
 - During focus lock, press (ET) to return the camcorder to autofocus.

Infinity Focus

Use this function when you wish to focus on faraway subjects such as mountains or fireworks.

Instead of step 3 in the previous procedure:

Push the joystick (▶) toward ▲ and hold it down.

- ∞ appears.
- If you operate the zoom or push the joystick (◄) and hold it down, ∞ changes to [MF] and the camcorder returns to manual focus.

White Balance

The white balance function helps you to accurately reproduce colors under different lighting conditions so that white objects will always look truly white in your recordings.



POINTS TO CHECK

Select a recording program other than the Special Scene recording programs.



「 **※** DAYLIGHT1

For recording outdoors on a bright day.



[* TUNGSTEN]

For recording under tungsten and tungsten type (3-wavelength) fluorescent lighting.

[SET]

Use the custom white balance setting to make white subjects appear white under colored lighting.

FUNC.

[ANB AUTO] 🕥

Desired option*

FUNC.

* When you select [SET], do not press FUNC. and continue instead with the following procedure.

TO SET THE CUSTOM WHITE BALANCE

- 1 Point the camcorder at a white object, zoom in until it fills the whole screen and press (st).

 When the adjustment is completed, stops flashing and stays on. The camcorder retains the custom setting even if you turn off the camcorder.
- 2 Press FUNC. to save the setting and close the menu.
- (i) NOTES
- . When you select the custom white balance:
 - Set the custom white balance in a sufficiently illuminated place.
 - Select a zoom type other than [2000x DIGITAL] (\$\square\$ 32).
 - Reset the white balance when the lighting conditions change.
 - Depending on the light source, sample may keep flashing. The result will still be better than with [## AUTO].

- Custom white balance may provide better results in the following cases:
 - Changing lighting conditions
 - Close-ups
 - Subjects in a single color (sky, sea or forest)
 - Under mercury lamps and certain types of fluorescent lights

Image Effects

You can use the image effects to change the color saturation and contrast to record images with special color effects.













Select a recording program other than the Special Scene recording programs.

Options

Default value

[<∂FF IMAGE EFFECT OFF]*

Records with no image enhancing effects.

[**�v** VIVID]

Emphasizes the contrast and color saturation.

[NEUTRAL]

Tones down the contrast and color saturation.

[SD SOFT SKIN DETAIL]

Softens the details in the skin tone area for a more complimentary appearance. To obtain the best effect, use this setting when recording a person in close-up. Note that areas similar to the skin color may lack in detail.

FUNC.

[<a>fr IMAGE EFFECT OFF] ○ Desired option ○

FUNC.

Digital Effects











Options

♦ Default value

[## D.EFFECT OFF]◆

Select this setting when you do not intend to use the digital effects.

[F1 FADE-T] (fade trigger), [F2 WIPE]

Select one of the faders to begin or end a scene with a fade from or to a black screen.

[E1 BLK&WHT]*

Records images in black and white.

[SEPIA1*

Records images in sepia tones for an "old" look.

[E3 ART], [E4 MOSAIC]

Select one of these digital effects to add "flavor" to your recordings.

* Only these digital effects are available in mode.

Setting



[端 D.EFFECT OFF] 🕥

Desired fader/effect*

FUNC. **

- * You can preview the digital effect on the screen.
- **The icon of the selected digital effect appears.

Applying





- 1 Push the joystick (▲) to display the joystick guide.
- 2 Select (▲▼) [D.EFFECT [♣] and press (♣T).
 - The icon of the selected effect turns green.
 - Press (a) again to deactivate the digital effect (its icon will turn white again).

TO FADE IN

Activate the selected fader in record pause mode (• II), then press Start/Stop to start recording with a fade in.

TO FADE OUT

Activate the selected fader while recording (•), then press Start/Stop to fade out and pause the recording.

TO ACTIVATE AN EFFECT

mode: Activate the selected effect while recording or in record pause mode.

mode: Activate the selected effect and then press PHOTO to record the photo.




(i) NOTES

- When you apply a fader, not only the picture but also the sound will fade in or out. When you apply an effect, the sound will be recorded normally.
- The camcorder retains the last setting used even if you turn off the digital effects or change the recording program.

On-Screen Displays and Data Code

With every scene or photo recorded, the camcorder keeps a data code that includes the date, time and information about the camera setup at the time of recording. While viewing a photo, all the data is displayed in the form of information icons. During movie playback you can select what to display with the [DATA CODE] setting (

86). You can also turn most on-screen displays on or off.



Repeatedly press DISP. to turn the on-screen displays on/off in the following sequence:

- 📺, 👩 mode:
- All displays on
- Most displays off*

mode:

- · All displays on
- · Data code only
- All displays off

mode:

- All displays on
- Regular displays only (removes the histogram and information icons)
- All displays off
- * The following icons will appear even when all other on-screen displays are turned off:
 The icons and II (in Image mode), the
 icon and AF frames when the autofocus is locked (in Image mode), screen markers (both recording modes).

Using Headphones

Use headphones for playback or to check the audio level while recording. The headphones are connected to the AV OUT/ \(\hat{\Omega}\) terminal, which is used for both the headphones and the audio/ video output. Before connecting the headphones, follow the procedure below to change the function of the terminal from AV output to \(\hat{\Omega}\) (headphones) output.



* If recording in node, change the terminal's setting and headphone volume in advance.



nappears.

TO ADJUST THE VOLUME OF THE HEADPHONES

In ♠ mode, adjust the volume of the headphones with the [PHONES VOL.] setting (♠ 87). In ♠ mode, adjust the headphone's volume the same way you adjust the speaker's volume (♠ 35). During slideshow playback, push the joystick (◄►) to adjust the volume.

■ IMPORTANT

- When using headphones, make sure to lower the volume to an appropriate level.
- Do not connect the headphones to the AV OUT/ \(\) terminal if the \(\frac{\cappa}{\cappa}\) icon does not appear on the screen. Only noise will be output in such case.

(i) NOTES

- Use commercially available headphones with a Ø 3.5 mm minijack and a cable no longer than 3 m.
- Even if the AV OUT/ () terminal is set to [PHONES] during playback mode, the setting will change to [AV AV] when the operating mode is changed to mode.

Using an External Microphone


You can attach a commercially available microphone for recording movies.

When recording in very quiet surroundings, the built-in microphone may pick up the sound of the camcorder's internal machinery. In such case, we recommend using an external microphone.



Connecting a Microphone

Connect the external microphone to the MIC terminal. Use commercially available condenser microphones with their own power supply and a cable no longer than 3 m. You can connect almost any stereo microphone with a Ø 3.5 mm plug but audio recording levels may vary.



() IN

IMPORTANT

Make sure to check the audio recording level before recording with the external microphone (

85).



When an external microphone is connected to the camcorder, [WIND SCREEN] will automatically be set to [● OFF %] .



Playlist and Scene Operations

Dividing Scenes

You can divide scenes (original scenes only) in order to leave out the best parts and later cut out the rest.





- Open the original movies index screen.
 - the movies in the built-in memory or on the memory card (37).
- 2 Select (▲▼, ◀▶) the scene you want to divide.

The scene selected will start playing back.

- 4 Select (◀▶) the ∌ icon and press (ET) where you want to divide the scene.
 - You can use the following icons to bring the scene to a precise point.
 - √Image: Fast playback reverse/forward.
 - Skip to the beginning/end of the current scene.
 - ◀I / II ➤: Frame reverse/advance.Press FUNC. or to stop the playback and exit the scene
- division screen.

 5 Select (▶) [YES] and press (☞).

- A progress bar will be displayed on the screen.
- You can press (ET) to cancel the operation while it is in progress.
- 6 When the confirmation screen appears, press (ET).

The video from the division point to the end of the scene will appear as a new scene in the index screen.

i NOTES

- In this mode, the scene playback will pause only at points where the scene can be divided.
- · The following scenes cannot be divided:
 - Scenes included in the scene selection (marked with a √ checkmark). Remove the selection mark in advance.
 - Scenes too short (5 seconds or shorter).
 - Video Snapshot scenes
 - Scenes that were not recorded with this camcorder.
- Scenes cannot be divided within 2 seconds from the beginning or the end of the scene.
- During the playback of a scene that was divided, you may notice some anomalies in the picture/sound at the point where the scene was cut.

Editing the Playlist: Adding, Deleting and Moving Playlist Scenes

Create a playlist to play back only the scenes you prefer and in the order of your choice and even set them to music (
44). You can also create a playlist that contains only Video Snapshot

scenes (

44). Moving or deleting scenes in the playlist will not affect the original recordings.



Adding Scenes to the Playlist

Options

FALL SCENES (THIS DATE)

Adds to the playlist all the scenes that were recorded on the same day as the selected scene.

[ONE SCENE]

Adds to the playlist only the scene marked with the orange selection frame.

ISELECTED SCENES

Adds to the playlist all the scenes selected in advance (marked with a ✓ checkmark). Refer to *Pre-selecting Recordings from the Index Screen* (□ 39).

1 Open the original movies index screen.

- From the this index screen, you can also press VIDEO SNAP to open the index screen for Video Snapshot (44) scenes.
- **IS22** / **IS21** / **IS20** You can select the movies in the built-in memory or on the memory card (1) 37).
- 2 Select (▲▼, ◄►) the scene you want to add to the playlist, or a scene recorded on the date you want to add to the playlist.

This step is not necessary for scenes selected in advance.

3 Add the scene(s) to the playlist.

FUNC. Desired option [YES]

- When the operation is completed [ADDED TO PLAYLIST] will be displayed.
- F522 / F521 / F520 Scenes are added to the playlist on the same media they are recorded on.
- To check the playlist, press PLAYLIST].

(i) NOTES

- IS22 / IS21 / IS20 You can copy scenes from the built-in memory to the memory card (□ 55) to include in the memory card's playlist also scenes that were originally recorded in the built-in memory.
- You may not be able to add scenes to the playlist if they were recorded or edited using another device or if there is not enough space available in the memory.
- **1522** You can press <u>PLAYLIST</u> on the wireless controller to switch between the original movies index screen and the playlist of the respective memory.

Deleting Scenes from the Playlist

Deleting scenes from the playlist will not affect your original recordings.

Options

[ALL SCENES]

Deletes all the scenes from the playlist.

[ONE SCENE]

Deletes from the playlist only the scene marked with the orange selection frame.

1 Open the playlist index screen. In the original movies index screen, press [PLAYLIST].



2 Select (▲▼, ◄►) the scene you want to delete.

This step is not necessary to delete all scenes.

3 Delete the scene(s).

FUNC.	7] 🔘	Í DEL	.ETE] (
Desire	d opti	ion 👩	[YES]	0	[OK]	0
FUNC.						

Moving Scenes in the Playlist

Move the scenes in the playlist to play them back in the order of your choice.

- 1 Open the playlist index screen.
 In the original movies index screen, press [PLAYLIST].
- 2 Select (▲▼, ◀►) the scene you want to move.
- 4 Move (▲▼, ◄►) the orange marker to the desired position of the scene and press (♠).

The original position of the scene and the current position of the marker are displayed at the bottom of the screen.

5 Select (►) [YES] and press (ET) to move the scene.

(i) NOTES

You may not be able to move scenes in the playlist if there is not enough space available in the memory.

(ESSE) / (ESSE) / (ESSE) Copying Scenes

You can copy original movies or the entire playlist only from the built-in memory to the corresponding location on the memory card.



Copying Original Movies

Options

[ALL SCENES]

Copies all the scenes to the memory card.

FALL SCENES (THIS DATE)

Copies to the memory card all the scenes that were recorded on the same day as the selected scene.

[ONE SCENE]

Copies only the scene marked with the orange selection frame to the memory card.

ISELECTED SCENES1

Copies to the memory card all the scenes selected in advance (marked with a ✓ checkmark). Refer to *Pre-selecting Recordings from the Index Screen* (□ 39).

- Open the original movies index screen of the built-in memory.
- 2 Select (▲▼, ◄►) the scene you want to copy to the memory card, or a scene recorded on the date you want to copy.

This step is not necessary to copy all scenes or previously selected scenes.

3 Copy the scene(s).

FUNC. [[COPY] Desired option [YES]* [OK] FUNC.


* Press (a) to interrupt the operation while it is in progress.

Copying the Entire Playlist

Open the index screen of the builtin memory's playlist.

In the original movies index screen of the built-in memory, press [PLAYLIST].

2 Copy the scene(s).



* Press (11) to interrupt the operation while it is in progress.

■ IMPORTANT

Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.

- Do not open the memory card slot cover.
- Do not disconnect the power source or turn off the camcorder.
- Do not change the operating mode.

i NOTES

- If the memory card does not have enough free space, you will not be able to copy movies.
- If the memory card slot cover is open, or the LOCK switch on the memory card is set to prevent writing, you will not be able to copy movies to the memory card.






Photos

Refer to this chapter for details on shooting photos – from capturing and playing back photos to printing them.

Basic Recording

Taking Photos



- 2 Turn on the camcorder.

 (552) / (552) / (552) You can select the memory to be used for recording photos (1) 29).
- 3 Press PHOTO halfway.
 - Once the focus is automatically adjusted, • will turn green and one or more AF frames will appear.

- #322 When you press PHOTO on the wireless controller, the photo is recorded after the autofocus is activated and locked.
- 4 Press PHOTO fully.

 The ACCESS indicator will flash as the photo is being recorded.

IMPORTANT

Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.

- Do not open the memory card slot cover.
- Do not disconnect the power source or turn off the camcorder.
- Do not change the operating mode.

(i) NOTES

If the subject is not suitable for autofocus, turns yellow. Adjust the focus manually 48).

Selecting Photo Size and Quality


Photos are recorded as JPG files. As a general rule, select a larger photo size for higher quality. (532) / (5



 $(\square 23)$

Options

Photo size options and the approximate number of photos that can be recorded on memory cards of various sizes are given in the table below.



* Press (E) to move back and forth between size and quality selection. The number displayed on the right corner indicates the approximate number of photos that can be recorded with the current quality/size setting.

i NOTES

- The camcorder retains the last setting used even if you set the camcorder to mode.
- When printing photos, use the following guidelines as a reference for selecting the print size.

Photo size	Recommended use			
LW 1152x648	To print photos on wide- sized photo paper or to view photos on a TV with a 16:9 aspect ratio.			
L 1152x864 or L 1024x768	To print photos up to L size (9 x 13 cm) or postcard size (10 x 14.8 cm).			
\$ 640x480	To send photos as e-mail attachments or to post on the Web.			

Approximate number of photos on a memory card

♦ Default value

Memory card	128 MB		512 MB			1 GB			
Photo quality ¹ →	ß	4.	4	B	4.	4	B	4.	
Photo size ↓	ы			ы			ы		
LW 1152x648 (ES22 / ES21 / ES20 only)	245	360	695	970	1,435	2,740	1,945	2,875	5,490
L 1152x864 [†] (ES22 / ES21 / ES20 only)	185	280	545	735	1,115	2,155	1,470	2,235	4,315
L 1024x768 [♦] (FS200 only)	235	345	695	940	1,370	2,740	1,885	2,745	5,490
S 640x480	585	850	1,530	2,320	3,350	6,035	4,645	6,710	12,085 ²

¹ **△** : [SUPER FINE], **△** : [FINE], **→** : [NORMAL]

² Approximate number of photos that can actually be recorded on the memory card. (The maximum number of remaining photos displayed on the screen is 9999.)



Erasing a Photo Right After Recording It

You can erase the photo recorded last while reviewing it within the time set for the [REVIEW] option or immediately after recording it, if [REVIEW] is set to OFF].






While reviewing the photo immediately after recording:

- 1 Push the joystick (▲) to display the joystick guide.
- 2 Press (SET).
- 3 Select (◀▶) [YES] and press ⑤ .

Basic Playback

Viewing Photos





When the camera mode dial is set to ** or **.

- 1 Press '∰\$▶.
 - Even if the camcorder is off, pressing '\□\□\□\□ will turn on the camcorder in playback mode.
 - The original movies index screen appears after a few seconds.
- 2 Move (AV) the orange selection frame to the tabs on the top of the screen.
- 3 Select (◄►) the tab that contains the photos you want to play back.
 - IS22 / IS21 / IS20 You can switch between the photos recorded in the built-in memory and those recorded on the memory card. Refer to Selecting What Recordings to Play Back (37).

- 4 Return (▲▼) to the index screen.
- 5 Select (▲▼, ◀▶) a photo.
 - Move the orange selection frame to the photo you want to view.
 - Push the joystick (▲▼) to extend the selection frame and browse (◀►) through whole index pages.
 Push the joystick (▲▼) to return to the index screen.
- 6 Press (SET).

The index screen closes and the selected photo is displayed.

7 Push the joystick (◀▶) to move between images.

Push the joystick (◀►) and hold it down to run quickly through the photos.

When the camera mode dial is set to **a**:

- 1 Press '∰\$ ▶.
 - Even if the camcorder is off, pressing '\sigma\subsets will turn on the camcorder in playback mode.
 - The last photo recorded will appear.
- 2 Push the joystick (◀▶) to move between photos.

Push the joystick (◀►) and hold it down to run quickly through the photos.


Photo Jump Function

When you have recorded a large number of photos, you can jump 10 or 100 photos at a time.





- Push the joystick (▲) to display the joystick guide.
- 2 Select (▲▼) ☆ and press ⑤ .



- 3 Select (▲▼) [☐ JUMP 10 PHOTOS] or [☐ JUMP 100 PHOTOS].
- 4 Jump (◀▶) the number of photos selected and press (♣).

Index Screen

- 1 Move the zoom lever toward W.
 - The photo index screen appears.
 - (E322) / (E321) / (E320) You can switch between the photos recorded in the built-in memory and those recorded on the memory card. Refer to Selecting What Recordings to Play Back (C) 37).
- 2 Select (▲▼, ◀▶) a photo.
 - Move the orange selection frame to the photo you want to view.
 - Push the joystick (▲▼) to extend the selection frame and browse (◀►) through whole index pages.
 Push the joystick (▲▼) to return to the index screen.
- 3 Press (SET).

The index screen closes and the selected photo is displayed.

Slideshow

You can play a slideshow of all the photos and even set it to music.

1 Select the first photo of the slideshow.



2 Press | to play back the photos one after another.

Press to stop the slideshow.

To set the slideshow to music

- 1 In the photo index screen, press FUNC.
- 2 Select a track to play with the slideshow.



- * Press 🗊 to start/stop the track.
- You can delete music files to free up space in the memory (
 45).
- Refer to Adjusting the volume

 (35) for details on adjusting the speaker's volume.

IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing.
 Failing to do so may result in permanent data loss.
 - Do not open the memory card slot cover.
 - Do not disconnect the power source or turn off the camcorder.
 - Do not change the operating mode.
- The following may not be displayed correctly.
 - Photos not recorded with this camcorder.
 - Photos edited on or uploaded from a computer.
 - Photos whose file names have been changed.

(i) NOTES

- (5522) / (5521) / (5520) When playing back a slideshow, make sure the music files are in the same media (built-in memory or memory card) that contains the photos. For details, refer to the instruction manual (PDF file) of the supplied software Music Transfer Utility.
- When playing back a slideshow from a memory card, we recommend using a memory card that is rated Speed Class 2 or higher. When using memory cards with no Speed Class rating, it may take longer than usual for photos to advance or there may be brief stops in the sound.

Magnifying Photos during Playback

During playback, photos can be magnified up to 5 times.









1 Move the zoom lever toward T.

- The photo is magnified by 2 times and a frame appears indicating the position of the magnified area.
- To further enlarge the photo, move the zoom lever toward T. To reduce the magnification to less than 2 times, move it toward W.

- will appear for photos that cannot be enlarged.
- 2 Move (▲▼, ◀►) the frame to the part of the photo you want to see enlarged.

To cancel the magnification, move the zoom lever toward **W** until the frame disappears.

Deleting Photos

You can delete those photos that you are not interested in keeping.



Deleting a Single Photo



- 1 Select (◀►) the photo you want to erase.
- 2 Push the joystick (▲) to display the joystick guide.
- 3 Select (▲▼) 'w and press .
- 4 Select (◄►) [YES] and press (□).

Deleting Photos from the Index Screen

Options

[ALL PHOTOS] Deletes all the photos.

[ONE PHOTO]

Deletes only the photo marked with the orange selection frame.

ISELECTED PHOTOS1

Deletes all the photos selected in advance (marked with a ✓ checkmark). Refer to *Preselecting Recordings from the Index Screen* (□ 39).

- 1 Open the photo index screen.
 - Move the zoom lever toward W.
 - \$22 / \$21 / \$20 You can switch between the photos recorded in the built-in memory and those recorded on the memory card. Refer to Selecting What Recordings to Play Back (\$\square\$ 37).
- 2 Select (▲▼, ◄►) the photo you want to delete.

This step is not necessary to delete all photos or previously selected photos.

3 Delete the photo(s).



* If you selected an option other than [ONE PHOTO], you can press (a) to interrupt the operation while it is in progress. Some photos will be deleted nevertheless.



Be careful when deleting photos. Deleted photos cannot be recovered.



Protected photos cannot be deleted.



Additional Functions

(3522) / (3521) / (3520) Drive Mode: Continuous Shooting and Exposure Bracketing

Take a series of photos of a moving subject or record the same photo in 3 levels of exposure in order to choose later the photo you like the best.



POINTS TO CHECK

Select a recording program other than [#FIREWORKS].

Options

Default value

[
Records a single photo.
[CONT.SH00T.] (Continuous Shooting)

[HISPEED CONT.SHOOT.] (High-Speed Continuous Shooting)

Captures a series of photos as long as you hold PHOTO pressed down. For the number of shots per second, refer to the sidebar on page 63.

[AEB] (Auto Exposure Bracketing)

The camcorder records a photo in three different exposures (dark, normal, light in 1/2 EV steps), allowing you to choose the shot you like the best.

FUNC.
[□ SINGLE] ⊘
Desired option 🕥
FUNC.

CONTINUOUS SHOOTING/ HIGH-SPEED CONTINUOUS SHOOTING

- 1 Press PHOTO halfway to activate the autofocus.
- 2 Press PHOTO fully and hold it pressed down.

A series of photos will be recorded as long as you hold the button pressed.

Maximum number of continuous shots

Number of photos per second				
Normal speed	2.5 photos			
법 High speed	4.1 photos			

Maximum number of continuous shots					
LW 1152 x 648,	10 photos				
L 1152 x 864					
S 640 x 480	20 photos				

These figures are approximate and vary with the recording conditions and subjects. The actual number of frames per second will be lower when the shutter speed is 1/25 or slower.

AUTO EXPOSURE BRACKETING

Press PHOTO, first halfway to activate the autofocus and then fully to record the photos.


Three photos in different exposures will be recorded.

Histogram Display

When viewing photos you can display the histogram and the icons of all the functions used at the time of recording. Use the histogram as a reference to verify the correct exposure of the photo.



The area to the right of the histogram represents highlights and the left side represents shadows. A photo whose histogram skews to the right is relatively bright; while one whose histogram peaks to the left, is relatively dark.



(i) NOTES

The histogram will appear also after recording a photo, while reviewing it within the time set for the [REVIEW] option. You can choose to turn off the histogram by pressing DISP. (51).

Protecting Photos

You can protect photos from accidental erasure.



Protecting Single Photos

- 1 Open the photo selection screen.
 - FUNC. PROTECT]

 [on PROTECT] appears on the screen.
- 2 Select (◄►) the photo you want to protect.
- 3 Press (ET) to protect the photo.

 (m) appears on the bottom bar and the photo cannot be deleted. Press (ET) again to remove the protection.
- 4 Repeat steps 2-3 to protect additional photos or press FUNC. twice to close the menu.

Protecting Photos from the Index Screen

Options

[INDIVIDUAL PHOTOS]

Opens the same screen described in *Protecting Single Photos* (64). Continue from step 3 of that procedure to protect the photo.

[SELECTED PHOTOS]

Protects all the photos selected in advance (marked with a ✓ checkmark). Refer to *Preselecting Recordings from the Index Screen* (□ 39).

IREMOVE ALL SELECTIONS

Removes the protection from all photos.



FUNC.

[O₁ PROTECT] ◎

Desired option ○ [YES] ○ [OK]

1 0110



Initializing the recording media (\square 29) will permanently erase all recordings, including protected photos.

(ESS22) / (ESS21) / (ESS20) Copying Photos

You can copy photos only from the built-in memory to the memory card.











Copying Single Photos

- 1 Open in single photo view the photo you want to copy (60).
- 2 Copy the photo to the memory card.

Copying Photos from the Index Screen

Options

[ALL PHOTOS]

Copies all the photos.

IONE PHOTO1

Copies only the photo marked with the orange selection frame.

[SELECTED PHOTOS]

Copies all the photos selected in advance (marked with a ✓ checkmark). Refer to *Preselecting Recordings from the Index Screen* (□ 39).

 Open the index screen of the photos recorded in the built-in memory.

Move the zoom lever toward **W** and then select the (built-in memory) tab.

- 2 If you want to copy only one photo, select (▲▼, ◄►) the photo you want to copy.
- 3 Copy the photo(s).

FUNC. ◎ [喧 COPY] ◎
Desired option ◎ [YES]* ◎ [OK]** ◎
FUNC.

- * If you selected [SELECTED PHOTOS] or [ALL PHOTOS], you can press (a) to interrupt the operation while it is in progress.
- **This step is not required when copying a single photo.

IMPORTANT

Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.

- Do not open the memory card slot cover.
- Do not disconnect the power source or turn off the camcorder.
- Do not change the operating mode.

(i) NOTES

 If there is not enough space on the memory card, the camcorder will copy as many photos as possible before stopping the operation. If the memory card slot cover is open, or the LOCK switch on the memory card is set to prevent writing, you will not be able to copy photos to the memory card

You can also use the following functions...

The following functions and features of the camcorder can be used either for shooting video or for taking photos. The way to set and use them was already explained in detail, so we refer you to the relevant page in the "Video" section.

- Zoom (□□ 32)
- Quick Start (34)
- Recording programs (41, 42)
- Mini video light (43)
- Self timer (46)
- Automatic backlight correction and manual exposure adjustment (47)
- Manual focus adjustment (48)
- White balance (48)
- Image effects (49)
- Digital effects (\$\subset\$ 50)

Printing Photos

Printing Photos

The camcorder can be connected to any PictBridge-compatible printer. You can mark in advance the photos you want to print and set the desired number of copies as a print order (\$\square\$ 69).



Canon printers: SELPHY printers of the CP, DS and ES series and inkjet printers marked with the PictBridge logo.



Connecting the Camcorder to the Printer

- 1 Turn on the printer.
- 2 Connect the camcorder to the printer using the supplied USB cable.
 - Connection 2. Refer to Connection Diagrams (☐ 72).
 - If the device type selection screen appears, select [PC/PRINTER] and press (ET).
 - (3522) / (3521) / (3520) Select in advance the memory from which you want to print the photos (12) 37).
 - If the photo index screen is displayed, move the zoom lever toward T to display a photo.



- appears and changes to
- The △ ~ (print/share) button lights up and the current print settings will be displayed for approx.
 6 seconds.

MPORTANT


- If a continues to flash (for more than 1 minute) or if does not appear, the camcorder is not correctly connected to the printer. In such case, disconnect the USB cable and turn off the camcorder and the printer. After a short while, turn them on again, set the camcorder to
- mode and restore the connection.
 During the following operations, even if you connect a printer to the camcorder it will not be recognized.
 - Erasing all photos
 - Erasing all transfer orders
 - Erasing all print orders

(i) NOTES

- will appear for photos that cannot be printed.
- We recommend powering the camcorder using the compact power adapter.
- Refer also to the printer's instruction manual.
- Connection to a PictBridge-compatible printer will not work when the memory card contains 1,800 photos or more.
- For best performance, we recommend keeping the number of photos on the memory card under 100.
- Disconnect the USB cable before changing the operating mode.

Printing with the $\triangle \sim$ (Print/Share) Button

You can print a photo without changing the settings simply by pressing \triangle .



- 1 Select (◀▶) the photo you wish to print.
- 2 Press 🖺 🐼 .

 - To continue printing, select (◄►) another photo.

Selecting the Print Settings

You can select the number of copies and other settings for printing. The setting options vary depending on your printer model.



Options

[PAPER]

[D PAPER SIZE]: Available paper sizes vary depending on the printer model.

[D PAPER TYPE]: Select [PHOTO], [FAST PHOTO], [PLAIN] or [DEFAULT].

[B PAGE LAYOUT]: Select [DEFAULT], [BORDERED] or one of the following page layouts.

[BORDERLESS]: The photo is enlarged and may be slightly cropped at the edges to fit the paper. [2-UP], [4-UP], [8-UP], [9-UP], [16-UP]: Refer to the sidebar on page 69.

[⊘] (Date print)

Select [ON], [OFF] or [DEFAULT].

[M] (Print effect)

Available only with printers compatible with the Image Optimize function. Select [ON], [OFF] or [DEFAULT].

Canon inkjet/SELPHY DS printers: You can also select [VIVID], [NR] and [VIVID+NR].

[📵] (Number of copies)

Select 1-99 copies.

i NOTES

Print setting options and [DEFAULT] settings vary depending on the printer model. For details, refer to the printer's instruction manual.

Printing after Changing the Print Settings






1 Push the joystick (▲) to display the joystick guide.

2 Select (▲▼) 占 and press 🖭.

The print settings menu appears.



- 3 In the print settings menu, select (▲▼, ◄►) the setting you want to change and press ⑤□.
- 4 Select (▲▼) the desired setting option and press (ET).
- 5 Select (▲▼, ◀▶) [PRINT] and press ⑸.
 - Printing starts. The print settings menu disappears when the printing is completed.
 - To continue printing, select (◄►) another photo.

TO CANCEL THE PRINTING

- 1 Press (ET) while printing.
- 2 Select (◀►) [OK] and press ⑤ET).

WHEN YOU HAVE FINISHED PRINTING

Disconnect the cable from the camcorder and printer and turn off the camcorder.



PRINT ERRORS

If an error occurs while printing, an error message, for example [NO PAPER], will appear on the camcorder. Solve the problem referring to the error message list (\$\square\$ 100) and to the printer's instruction manual.

- Canon's PictBridge-compatible printers: If printing does not resume automatically after you solved the problem, select [CONTINUE] and press (F) to resume printing. If that option is not available, select [STOP] and press (F) and then restart printing from the beginning.
- Other printers or if the error still persists with a Canon printer: If printing does not resume automatically, disconnect the USB cable and turn off the camcorder. After a short while, turn on the camcorder and restore the USB connection.

- changed or that were recorded, created, edited or changed with any device other than this camcorder.
- If [BUSY] does not disappear, disconnect the USB cable and restore the connection after a short while.

Print Orders

You can mark in advance the photos you want to print and set the desired number of copies as a print order. Later, you can easily print out the print orders by connecting the camcorder to a PictBridge-compatible printer (66). You can set print orders for up to 998 photos.











(23)

IMPORTANT

 You may not be able to print correctly with a PictBridge-compatible printer photos whose file names have been

Printing multiple photos on the same sheet [2-UP], [4-UP], etc.

When using Canon printers you can print the same photo multiple times on the same sheet of paper. Use the following table as a guideline for the recommended number of copies depending on the [$^{\circ}$ D PAPER SIZE] setting.

[[®] PAPER SIZE] ⇒	[CREDITCARD]	[9 x 13 cm]	[10 x 14.8 cm]	[A4]	
Canon printer 4					
Inkjet printers SELPHY DS	_	_	2, 4, 9 or 16 ¹	4	
SELPHY CP/ES	2, 4 or 8 ²	2 or 4	2 or 4	_	

¹ You can also use the special sticker sheets.

SELPHY CP: When you use the wide-sized photo paper with the [DEFAULT] setting, you can also use [2-UP] or [4-UP].

With the [8-UP] setting, you can also use the special sticker sheets (SELPHY CP printers only).

Selecting Photos for Printing (Print Order)

Set the print orders before connecting the supplied USB cable to the camcorder.

Marking Single Photos with Print Orders

- 1 Open the photo selection screen.
 - FUNC. [A PRINT ORDER]

 [A 0] appears on the screen.
- 2 Select (◀▶) the photo you want to mark with a print order.
- 3 Press (ET) to set the print order.
 The number of copies appears in orange.
- 4 Set (▲▼) the number of copies desired and press (ET).

To cancel the print order, set the number of copies to 0.

5 Repeat steps 2-4 to mark additional photos with print orders or press FUNC. twice to close the menu.

Setting Print Orders from the Index Screen

Options

[INDIVIDUAL PHOTOS]

Opens the same screen described in *Marking Single Photos with Print Orders* (\square 70). Continue from step 3 of that procedure to set the print order.

[SELECTED PHOTOS(1 COPY)]

Sets a print order of 1 copy of each of the photos selected in advance (marked with a √ checkmark). Refer to *Pre-selecting Recordings* from the Index Screen (□ 39).

[REMOVE ALL]

Removes all the print orders.

FUNC. ○

[□ PRINT ORDER] ○

Desired option ○ [YES] ○ [OK]

FUNC.

Printing the Photos Marked with Print Orders

 Connect the camcorder to the printer using the supplied USB cable.

Connection 2. Refer to Connection Diagrams (72).

2 Open the print settings menu.

FUNC. ⊘ [I MENU] ⊘ [→ B PRINT]

- The print settings menu appears.
- If there are no photos marked with print orders, [SET
 PRINT ORDER] appears.
- 3 Select (▲▼, ◀►) [PRINT] and press (ET).



Printing starts. The print settings menu disappears when the printing is completed.

(i) NOTES

- To cancel the printing, refer to page 68.
- Restarting Printing: Open the print settings menu as explained in step 2. In the print settings menu, select [RESUME]* and press (ET). The remaining photos will be printed. Printing cannot be restarted when the print order settings have been changed or if you deleted a photo with print order settings.
 - * In case the print order was interrupted after the first photo, this menu option will appear as [PRINT] instead.





External Connections

This chapter explains how to connect your camcorder to an external device such as a TV, VCR, or computer.

Terminals on the Camcorder



1) AV OUT/ () Terminal


Access: Open the LCD panel.

Sound from the built-in speaker will be muted while the STV-250N Stereo Video Cable is connected to the camcorder


② USB Terminal


Access: Open the LCD panel.

Connection Diagrams









(23)

Playback on a TV Screen

Connect the camcorder to a TV to enjoy your recordings with family and friends. Before making the connection, set [AV/ PHONES] to [AV AV] in advance (m 87).



- 1 Turn off the camcorder and the TV.
- 2 Connect the camcorder to the TV. Refer to Connection Diagrams (m 72) and select the most appropriate connection for your TV.
- 3 Turn on the connected TV. On the TV, select as the video input the same terminal to which you connected the camcorder. Refer to

the instruction manual of the connected TV.

4 Set the camcorder to produce mode (m 35) or **b** mode (m 59). Start the playback of movies or photos.

) NOTES

- We recommend powering the camcorder using the compact power adapter.
- · Sound from the built-in speaker will be muted while the STV-250N Stereo Video Cable is connected to the camcorder.
- Adjust the volume using the TV.
- When you play back your 16:9 movies on standard TV sets with a 4:3 aspect ratio, the TV set will switch automatically to widescreen mode if it is compatible with the WSS system. Otherwise, change the aspect ratio of the TV manually.

Saving and Backing Up Your Recordings

Backing Up Your Recordings on a Computer

Movies recorded with this camcorder are saved on the memory card or in the built-in memory (\$522) / \$520 only). Because space on the memory is limited, make sure to back up your movies onto a computer on a regular basis.

PIXELA ImageMixer 3 SE

With the supplied software **ImageMixer** 3 SE Transfer Utility you can save scenes in the camcorder to your computer's hard disk. On the computer. you can neatly organize all your video recordings into albums and add comments for quick and easy searches. With the supplied software ImageMixer 3 SE Video Tools, you can also edit scenes, convert and resize them to upload them to your Web site or to take with you on your portable video player and more. For details about the functions available, refer to the software's instruction manual (PDF file). For details about installing the software refer to PIXELA ImageMixer 3 SE Installation Guide.

Saving your Recordings without a Computer

If you prefer to save your recordings without having to use a computer, you can use the optional DW-100 DVD Burner to create DVD discs of your movies and Photo DVDs of your photos (\$\square\$ 74)\$. You can also connect the camcorder to an external recording device (DVD or HDD recorder, VCR, etc.) to save copies of your movies (\$\square\$ 77)\$.



IMPORTANT

- When the camcorder is connected to a computer: Do not access, change or delete folders and files in the camcorder directly from the computer as this may result in permanent data loss.
- While the camcorder is connected to a computer, do not open the memory card slot cover and do not remove the memory card.

Authoring DVD Discs and Photo DVDs

You can connect the camcorder to the optional DW-100 DVD Burner to create DVD discs from your movies or Photo DVD discs from your photos. For details about the connection and operation, refer to the instruction manual of the DW-100.

Refer to this section along with the relevant sections in the instruction manual of the DW-100.











(1 23)



Options for creating DVD discs (PR mode)

(EA) IIIOUE

[ALL SCENES]

Add all the scenes to the disc(s).

[REM.SCENES]

Add only those scenes that have not been previously added to a disc.

[PLAYLIST]

Add only the scenes included in the playlist $(\longrightarrow 53)$.

Options for creating Photo DVDs

(mode)

FALL PHOTOS1

Add all the photos to the slideshow on the disc.

[TRANS.ORD]

Add only photos marked with transfer orders $(\bigcirc 80)$.

Preparations on the Camcorder

- 1 Set the camcorder to R mode to create DVD discs of your movies or mode to create Photo DVDs of your photos.
 - Power the camcorder using the compact power adapter.
 - (522) / (521) / (520) Select in advance the memory from which you want to add the scenes or photos (1) 37).
- 2 Select the scenes or photos you want to add to the disc.

Connecting to the DVD Burner and Creating a Disc

- 1 Turn on the DVD burner.

 DW-100 > Refer to Creating DVDs.
- 2 Connect the camcorder to the DVD burner using the supplied USB cable.
 - Connection 2. Refer to Connection Diagrams (☐ 72) and DW-100 > Connections.
 - If the device type selection screen appears, select [DVD BURNER] and press (st).
 - When the connection is completed, [NO DISC] will be displayed.
- 3 Insert a brand new disc into the DVD burner.
 - Use the OPEN/CLOSE button on the DVD burner to open and close the disc tray.
 - After the disc is recognized, an information screen will display the type of DVD you are creating, the estimated time and number of discs it will require (based on the disc you inserted).
 - If you inserted a DVD-RW disc that already contains data, [THE DISC CONTAINS DATA] will be displayed. To overwrite the data (erasing the previous content of the disc), press (ET), select [YES] and press (ET) again.



4 Press the start button on the DVD burner.

- A progress bar will be displayed on the screen.
- After pressing the start button (while the current disc is being written) the operation cannot be canceled.
- When the disc (or the last disc, if the data requires multiple discs) is finalized, [TASK COMPLETED] will be displayed. Take out the disc and close the disc tray.

WHEN THE DATA REQUIRES MULTIPLE DISCS

After a disc is finalized it will be ejected automatically and [INSERT A NEW/BLANK DISC AND CLOSE THE DISC TRAY] will appear. Insert the next disc and close the disc tray.

TO CREATE AN ADDITIONAL COPY OF THE SAME DISC

After the operation is finished, [INSERT A NEW/BLANK DISC] will be displayed again. Insert a brand new disc and close the disc tray.

TO PLAY BACK A DVD DISC

Discs created with this camcorder and the DVD burner can be played back on DVD players and computers that meet the following requirements:

- Compatible with the discs you created (DVD-R/DVD-R DL/DVD-RW discs)
- Compatible with DVD-Video specifications

 DVD playback software that is installed and running (in the case of computers)

Refer to the instruction manual of the external device and make sure it is compatible.

n

IMPORTANT

- While the camcorder is connected to the DVD burner, do not open the memory card slot cover and do not remove the memory card.
- Observe the following precautions while the ACCESS indicator on the camcorder is on or flashing. Failing to do so may result in permanent data loss.
 - Do not open the memory card slot cover.
 - Do not disconnect the USB cable.
 - Do not disconnect the power source or turn off the camcorder or the DVD burner.
- When creating discs with the optional DW-100 DVD Burner, you cannot add, using the [PLAYLIST] option, scenes recorded while the pre-recording function was on or divided scenes. To add such scenes, use the [ALL SCENES] or [REM.SCENES] option.
- For important information on handling your discs, refer to DW-100 Cautions on handling.



- The FUNC. menu and setup menus cannot be accessed while the camcorder is connected to the DVD burner.
- Disconnect the USB cable before changing the operating mode.
- The amount of time required for step 2 depends on how many scenes are being included on a disc. We recommend keeping the number of scenes to 2000



or less. (In such case, the connection time will be about 3 minutes 30 seconds).

Copying your Recordings to an External Video Recorder

You can copy your recordings by connecting the camcorder to a VCR or a digital video device.



Connecting

Connect the camcorder to the VCR using Connection 1 or 1. Refer to Connection Diagrams (72). Before making the connection, set [AV/PHONES] to [AV] AV] in advance (87).

Recording

- External device: Load a blank cassette or disc and set the device to record pause mode.
- 2 Camcorder: Locate the scene you wish to copy and pause playback shortly before the scene.
- 3 Camcorder: Resume the movie playback.
- 4 External device: Begin recording when the scene you wish to copy appears. Stop recording when copying is complete.
- 5 Camcorder: Stop playback.

(i) notes

- We recommend powering the camcorder using the compact power adapter.
- By default, on-screen displays will be embedded in the output video signal.
 You can change the displays by repeatedly pressing DISP. (

 51).

Transferring Photos to a Computer (Direct Transfer)



Preparations

Install the software before you connect the camcorder to the computer for the first time. (Windows users only: you also need to select CameraWindow's auto-launch setting.) After that, just connect the camcorder to the computer (steps 2 and 3) and proceed directly to transfer the photos (\square 79).

1 Install the supplied Digital Video Software.

DVSD Refer to Installing the Digital Video Software.

2 Set the camcorder to node.

(522) / **(532)** / **(532)** Select in advance the memory from which you want to transfer photos (37).

3 Connect the camcorder to the computer using the USB cable.

- Connection 2. Refer to Connection Diagrams (m 72).
- If the device type selection screen appears, select [PC/PRINTER] and press (ET).
- The direct transfer menu appears on the camcorder screen and the △ button lights up.

FIRST-TIME CONNECTION TO A COMPUTER RUNNING WINDOWS

The first time you connect the camcorder to the computer, you need also to select the CameraWindow autolaunch setting.

DVSD

Refer to
Starting CameraWindow.

CONNECTION TO A COMPUTER RUNNING MAC OS

When you connect the camcorder to the computer, CameraWindow appears automatically.

DVSD Refer to Downloading Still Images.

- While the camcorder is connected to the computer, do not open the memory card slot cover and do not remove the memory card.
- Observe the following precautions while the ACCESS indicator is on or flashing.
 Failing to do so may result in permanent data loss.

- Do not open the memory card slot cover.
- Do not disconnect the USB cable.
- Do not turn off the camcorder or the computer.
- Do not change the operating mode.
- Operation may not work correctly depending on the software and the specifications/settings of your computer.
- If you wish to use the image files on your computer, make copies of them first.
 Use the copied files, retaining the originals.
- During the following operations, even if you connect the camcorder to the computer it will not be recognized.
 - Erasing all photos
 - Erasing all transfer orders
 - Erasing all print orders

i) NOTES

- We recommend powering the camcorder using the compact power adapter.
- Refer also to the computer's instruction manual.
- Users of Windows Vista, Windows XP and Mac OS X: Your camcorder is equipped with the standard Picture Transfer Protocol (PTP) allowing you to transfer photos (JPEG only) simply by connecting the camcorder to a computer using the USB cable without having to install the supplied software.
- Depending on the number of photos on the memory card (Windows: 1,800 photos or more; Macintosh: 1,000 photos or more), you may not be able to



- transfer photos to a computer. Try using a card reader.
- Disconnect the USB cable before changing the operating mode.

Transferring Photos



Automatic Transfer Options

All the relevant photos will be transferred to the computer in one batch and their thumbnails will be displayed on the computer.

Transfers all photos. [☼ NEW PHOTOS] Transfers only those photos that have not yet been transferred to the computer. [☼ TRANSFER ORDERS]

Transfers photos marked with transfer orders $(\square 80)$.

Manual Transfer Options


You can select the photo(s) to transfer.

[☐ SELECT & TRANSFER]

Select the photo(s) to transfer.

[WALLPAPER]

Select a photo and set it as your computer's desktop background.





AUTOMATIC TRANSFER OPTIONS

Select (▲▼) a transfer option and press △៷.

- The camcorder returns to the transfer menu once the transfer is completed.
- To cancel the transfer, select (◀▶) [CANCEL] and press (₤), or press (FUNC.].

MANUAL TRANSFER OPTIONS

- 1 Select (▲▼) a transfer option and press △៷.
- 2 Select (◀▶) the photo you wish to transfer and press (SET).
 - [SELECT & TRANSFER]: Repeat this step to select other photos to transfer.
- 3 Press FUNC. to return to the transfer menu.



When the camcorder is connected to the computer and the photo selection screen is displayed, press FUNC. to return to the transfer menu.

Transfer Orders

You can mark in advance the photos you want to transfer to the computer as transfer orders. You can set transfer orders for up to 998 photos.



Selecting Photos to Transfer (Transfer Order)

Set the transfer orders before connecting the camcorder to the computer.

(\$521) / \$520 Select in advance the memory from which you want to transfer photos (\$\square\$ 37).

Marking Single Photos with Transfer Orders

- 1 Open the photo selection screen.

 FUNC. ◎ [➡ TRANSFER ORDER]

 ➡ appears on the screen.
- 2 Select (◀▶) the photo you want to mark with a transfer order.
- 3 Press (st) to set the transfer order.

 A checkmark ✓ appears in the box next to the transfer order icon □.

 Press (st) again to cancel the transfer order.

4 Repeat steps 2-3 to mark additional photos with transfer orders or press FUNC. twice to close the menu.

Setting Transfer Orders from the Index

Options

FINDIVIDUAL PHOTOSI

Opens the same screen described in *Marking Single Photos with Transfer Orders* (80). Continue from step 3 of that procedure to set the transfer order.

[SELECTED PHOTOS]

Marks all the photos selected in advance (marked with a ✓ checkmark) with a transfer order. Refer to *Pre-selecting Recordings from the Index Screen* (☐ 39).

[REMOVE ALL]

Removes all the transfer orders.

FUNC. ○

[□ TRANSFER ORDER] ○

Desired option ○ [YES] ○ [OK] ○

FUNC.

TO TRANSFER PHOTOS MARKED WITH TRANSFER ORDERS

Connect the camcorder to the computer and select [☐ TRANSFER ORDERS] in the transfer menu (☐ 79).





Additional Information

This chapter contains troubleshooting advice, screen messages, handling and maintenance tips, and other information.

Appendix: Menu Options Lists

Menu items not available appear grayed out in the FUNC. menu or in black in the setup menus. For details about how to select an item, refer to *Using the Menus* (\square 25). For details about each function, see the reference page. Menu options without a reference page are explained below the tables.

FUNC. Menu (Recording Modes)

Menu item	Setting options	7		Ш
Recording programs	[PROGRAM AE], [NSHUTTER-PRIO.AE]	•	•	42
	[ऒ PORTRAIT], [☑ SPORTS], [☑ NIGHT], [☑ SNOW], [☑ BEACH], [☑ SUNSET], [☑ SPOTLIGHT], [FIREWORKS]	•	•	41
White balance	[# AUTO], [* DAYLIGHT], [* TUNGSTEN], [. SET]	•	•	48
Image effects	[<6FF IMAGE EFFECT OFF], [⟨SV VIVID], [⟨SN NEUTRAL], [<\$D SOFT SKIN DETAIL]	•	•	49
Digital effects	[編 D.EFFECT OFF], [画 FADE-T], [配 WIPE], [画 BLK&WHT], [配 SEPIA], [配 ART], [配 MOSAIC]	•	_	50
	[締: D.EFFECT OFF], [画] BLK&WHT], [画 SEPIA]	_	•	
FS22 / FS21 / FS20 Drive mode	[□ SINGLE], [□ CONT.SHOOT.], [삡 HISPEED CONT.SHOOT.], [AEB]	_	•	63
Recording mode	[P HIGH QUALITY 9Mbps], [SP STANDARD PLAY 6Mbps], [LP LONG PLAY 3Mbps]	•	_	32
Photos size/quality	[ES22] / (ES21) / (ES20) [LW 1152x648], [L 1152x864], [S 640x480] (ES200) [L 1024x768], [S 640x480]	_	•	57
	[& SUPER FINE], [A FINE], [NORMAL]			

FUNC. Menu (Playback Modes)

Menu item	Setting options	県		Ш
[SELECT MUSIC]	[OFF], list of music files in the camcorder	●1	•	44
[SELECT]	[INDIVIDUAL SCENES], [REMOVE ALL SELECTIONS], [CANCEL]	●2	_	39
	From the index screen: [INDIVIDUAL PHOTOS], [REMOVE ALL SELECTIONS], [CANCEL]	_	•	39
FS22 / FS21 / FS20 [COPY]	[ALL SCENES], [ALL SCENES (THIS DATE)], [ONE SCENE], [SELECTED SCENES], [CANCEL]	●2	_	55
	[NO], [YES]	●3	_	56
	From single photo view: [NO], [YES]	_	•	65
	From the index screen: [ALL PHOTOS], [ONE PHOTO], [SELECTED PHOTOS], [CANCEL]	_	•	65
[ADD TO PLAYLIST] ²	[ALL SCENES (THIS DATE)], [ONE SCENE], [SELECTED SCENES], [CANCEL]	•	_	53
[DIVIDE] ⁴	_	•	_	53
[MOVE] ³	_	•	_	55
[PROTECT]	From single photo view: - From the index screen: [INDIVIDUAL PHOTOS], [SELECTED PHOTOS], [REMOVE ALL SELECTIONS], [CANCEL]	_	•	64
[PRINT ORDER]	From single photo view: 0-99 copies From the index screen: [INDIVIDUAL PHOTOS], [SELECTED PHOTOS(1 COPY)], [REMOVE ALL], [CANCEL]	_	•	69
[TRANSFER ORDER]	From single photo view: - From the index screen: [INDIVIDUAL PHOTOS], [SELECTED PHOTOS], [REMOVE ALL], [CANCEL]	_	•	80



Menu item	Setting options	'E		Ш
[DELETE]	[ALL SCENES], [ALL SCENES (THIS DATE)], [ONE SCENE], [SELECTED SCENES], [CANCEL]	●2	_	40
	[ALL SCENES], [ONE SCENE], [CANCEL]	●3	_	54
	From single photo view: [NO], [YES] From the index screen: [ALL PHOTOS], [ONE PHOTO], [SELECTED PHOTOS], [CANCEL]	_	•	62
[SCENE SEARCH] ²	[CALENDAR], [SELECT DATE], [CANCEL]	•	_	37

¹ Option not available from the original movies index screen.

PARCAMERA SETUP

Menu item	Setting options	7		Ш
[SELF TIMER]	[ON ON 🕸], [OFF OFF]	•	•	46
[ZOOM TYPE]	[37x OPTICAL], [45x ADVANCED] ¹ , [2000x DIGITAL]	•	_	33
[ZOOM SPEED]	[VAR VARIABLE], [SSS SPEED 3], [SSS SPEED 2], [SSS SPEED 1]	•	•	32
[IMG STAB]	[ON ON (44))], [OFF OFF]	•	_	_
[WIDESCREEN]	[ON ON], [OFF OFF]	•	_	_
[FOCUS PRI.]	[ATA: ON:AIAF], [ON:CENTER], [OFF OFF]	_	•	_
[A.SL SHUTTER] ²	[ON ON], [OFF OFF]	•	•	-
[WIND SCREEN]	[A AUTO], [OFF OFF ☆ Q]	•	_	-
[REVIEW] ³	[OFF OFF], [2se: 2 sec], [4se: 4 sec], [6se: 6 sec], [8se: 8 sec], [flose 10 sec]	-	•	-

^{1 [46}x ADVANCED] when [WIDESCREEN] is set to [077 OFF]. [F5200] The default setting is [41x ADVANCED].

2 Option available only when the recording program is set to [PROGRAM AE].

[IMG STAB]: The image stabilizer compensates for camcorder shake even at full telephoto.

- The image stabilizer is designed to compensate for a normal degree of camcorder shake. **\$\frac{15200}\$** The image stabilizer may not be able to successfully eliminate all blur if the camcorder or the subject is moving too much.
- **(5200)** The image stabilizer may not work well on subjects with low contrast, with a recurring, repetitive pattern or without vertical lines.

² Option available from the original movies index screen and Video Snapshot index screen.

³ Option available from the playlist index screen and Video Snapshot playlist index screen.

⁴ Option available from the original movies index screen.

³ F522 / F521 / F520 Option available only when the drive mode is set to [SINGLE].

• We recommend setting the image stabilizer to [OFF] when using a tripod.

[WIDESCREEN]: The camcorder uses the full width of the image sensor providing high-resolution 16:9 recordings.

- Since the screen on the camcorder has an aspect ratio of 16:9, recordings with a 4:3 aspect ratio will appear in the center of the screen with black sidebars.
- The camcorder retains the last setting used even if you set the camcorder to mode.

[FOCUS PRI.]: When the focus priority is activated, the camcorder records a photo only after the focus has been adjusted automatically. You can also select which AF frames to use. [MM] ON:AiAF]: One or more AF frames out of the nine frames available are automatically selected and the focus is fixed on them.

[ON:CENTER]: A single focusing frame appears in the center of the screen and the focus is automatically fixed on it.

[OFF]: No AF frame will appear and the photo will be recorded immediately after you press [PHOTO].

 When the recording program is set to [BFIREWORKS], focus priority is automatically set to [OFF].

[A.SL SHUTTER]: The camcorder automatically uses slow shutter speeds to obtain brighter recordings in places with insufficient lighting.

- The camcorder uses shutter speeds down to 1/25 (1/12 in mode).
- The setting can be changed when the camcorder is set to 📜 or 🔼 mode. The camcorder retains the last setting used even if you set the camcorder to 🕡 mode.
- If a trailing afterimage appears, set the slow shutter to [OFF OFF].
- If (camcorder shake warning) appears, we recommend stabilizing the camcorder, for example, by mounting it on a tripod.

[WIND SCREEN]: The camcorder automatically reduces the background sound of wind when recording outdoors.

[REVIEW]: Selects the time to display a photo after it has been recorded to the memory.

If you press DISP. while reviewing a photo it will continue to be displayed indefinitely.
 Press PHOTO halfway to return to the normal display.



MEMORY OPER.

Menu item	Setting options			À		
FS22 / FS21 / FS20 [MEMORY INFO]	_	•	•	•	•	_
[CARD INFO]	_	•	•	•	•	_
FS22 / FS21 / FS20 [MEDIA:MOVIES]	[BUILT-IN MEM], [CARD]	•	•	_	_	29
FS22 / FS21 / FS20 [MEDIA:PHOTOS]	[BUILT-IN MEM], [CARD]	•	•	_	_	29
[INITIALIZE]	[BUILT-IN MEM], [CARD], [CANCEL]	•	•	•*	•	29
	[INITIALIZE], [COMPL.INIT.], [CANCEL]					

^{*} Option available from the original movies index screen and Video Snapshot index screen.

[MEMORY INFO]/[CARD INFO]: Displays a screen where you can verify how much of the built-in memory ([522] / [532] / [532] only) or the memory card is currently in use (total recording time and total number of photos) and approximately how much memory remains available for recording.

- Estimated figures about available movie recording time and available number of photos are approximate and based on the recording mode and photo quality/size settings currently in use.
- In the [CARD INFO] screen you can also verify the Speed Class of the memory card.
- The maximum number of remaining photos displayed on the screen is 99999.

DISPLAY SETUP

Menu item	Setting options	P.		Ä		m m
[BRIGHTNESS]	* *	•	•	•	•	-
[LCD DIMMER]	[ON ON], [OFF OFF]	•	•	•	•	-
[AUDIO LEVEL]	[ON ON], [OFF OFF]	•	-	_	_	-
[TV SCREEN]	[ON ON], [OFF OFF]	•	•	-	_	_
[DATA CODE]	[-	_	•	_	_
[MARKERS]	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	•	•	_	_	_


Menu item	Setting options	P		点		
[LANGUAGE 🗐]	「ČEŠTINA],[DEUTSCH], [EΛΛΗΝΙΚΑ] [ENGLISH], [ESPAÑOL], [FRANÇAIS], [ITALIANO], [MAGYAR], [MELAYU], [NEDERLANDS], [POLSKI], [PORTUGUÊS], [ROMÂNĂ], [TÜRKÇE], [РУССКИЙ], [УКРАЇНСЬКА], [・「していまう], [ションプルロ], [简体中文], [繁體中文], [한국어], [日本語]	•	•	•	•	27
[START WEEK]	[SATURDAY], [SUNDAY], [MONDAY]	_	_	•	_	-
[DEMO MODE]	[ON ON], [OFF OFF]	•	•	_	_	_

[BRIGHTNESS]: Adjusts the brightness of the LCD screen.

 Changing the brightness of the LCD screen does not affect the brightness of your recordings or that of the playback image on a TV.

- To turn off the LCD screen dimmer, change this setting to [OFF] or press DISP. for 2 seconds or more.
- Dimming the LCD screen does not affect the brightness of your recordings or that of the playback image on a TV.
- When the LCD screen dimmer is turned off, the screen's brightness returns to the previous setting.

[AUDIO LEVEL]: Displays the audio level indicator on the LCD screen so you can check the audio recording level while recording.



ITV SCREEN

 When set to [IN] ON], the camcorder's on-screen displays will appear also on the screen of a TV or monitor connected using the STV-250N Stereo Video Cable.

[DATA CODE]: Displays the date and/or time when the scene was recorded. [The CAMERA DATA]: Displays the aperture (f-stop) and shutter speed used when recording.

[MARKERS]: You can display a grid or a horizontal line at the center of the screen. Use the markers as a reference to make sure your subject is framed correctly (vertically and/or horizontally).

• Using the markers will not affect the recordings.

ISTART WEEK1: Select the day on which the week starts for the calendar display (37).



[DEMO MODE]: The demonstration mode displays the camcorder's main features. It starts automatically when the camcorder is powered with the compact power adapter if you leave it turned on for more than 5 minutes.

 To cancel the demo mode once it has started, press any button or turn off the camcorder.

SYSTEM SETUP

Menu item	Setting options	-		凉		Ш
[BATTERY INFO]	_	•	•	•	•	_
[WL.REMOTE]	[ON ON], [OFF OFF ((#))]	•	•	•	•	-
[BEEP]	['@>> HIGH VOLUME], ['@> LOW VOLUME], [OFF OFF]	•	•	•	•	-
[POWER SAVE]	ON ON, OFF OFF	•	•	•	•	-
[QUICK START]	[OFF OFF], [10min 10 min], [20min 20 min], [30min 30 min]	•	•	_	_	_
[AV/PHONES]	[AV AV], [PHONES]	•	•	•	•	52
[PHONES VOL.]	o	•	•	•	•	52
[SPEAKER VOL.]	Фф	_	-	•	•	-
[TV TYPE]	[STORMAL TV], [1659 WIDE TV]	_	_	•	•	_
[USB SETTING]	[■DVD BURNER], [■ PC/PRINTER], [← CONNECT&SET]	_	-	•	•	-
[ADD TO DISC]	[ALL SCENES], [REM.SCENES], [PLAYLIST]	_	-	•	-	74
	[ALL PHOTOS], [TRANS.ORD]	_	_	_	•	74
[PHOTO NOS.]	[RESET], [CONTINUOUS]	_	•	_	•	_
[FIRMWARE]	-	_	_	_	•	_

[BATTERY INFO]: Displays a screen where you can verify the battery charge (as a percentage) and the remaining recording time (mode) or playback time (mode).

[WL.REMOTE]: Allows the camcorder to be operated with the wireless controller.

[BEEP]: A beep will accompany some operations like turning on the camcorder, the self-timer countdown, etc.

[POWER SAVE]: In order to save power when the camcorder is powered by a battery pack, it will automatically shut off if left without any operation for 5 minutes.

• Approximately 30 seconds before the camcorder shuts off, [AUTO POWER OFF] will appear.

- In standby mode, the camcorder will shut off after the time selected for the [QUICK START] setting.
- The Power Save mode cannot be set while the compact power adapter is connected to the camcorder.

[QUICK START]: Select whether to activate the Quick Start function (\square 34) when you close the LCD panel in a recording mode and the length of time after which the camcorder will end the standby mode and shut off automatically.

[SPEAKER VOL.]: Adjust (◀►) the volume of the playback. You can also adjust the volume using the joystick quide (□ 35).

[TV TYPE]: In order to display the picture in full and in the correct aspect ratio, select the setting according to the type of television to which you will connect the camcorder.

[EN] NORMAL TVI: TV sets with 4:3 aspect ratio.

[16:9] WIDE TVI: TV sets with 16:9 aspect ratio.

 When the TV type is set to [NORMAL TV], the picture displayed on the LCD screen will be smaller than the full display area.

[USB SETTING]: Select the connection protocol to use when connecting the camcorder to an external device using the USB cable.

[DVD BURNER]: To connect exclusively to the optional DW-100 DVD Burner.

PC/PRINTER]: To connect to a computer, a printer or similar USB peripherals.

[+÷ CONNECT&SET]: To make the selection from a screen that appears at the time of the connection to the external device.

[PHOTO NOS.]: Select the photo numbering method to be used on a new memory card. Photos are automatically assigned consecutive photo numbers from 0101 to 9900, and stored in folders containing up to 100 photos. Folders are numbered from 101 to 998. [ENESET]: Photo numbers will restart from 101-0101 every time you insert a new memory card.

[CONTINUOUS]: Photo numbers will continue from the number following that of the last photo recorded with the camcorder.

- If the memory card you insert already contains a photo with a larger number, a new photo will be assigned a number one higher than that of the last photo on the memory card.
- We recommend using the [CONTINUOUS] setting.

[FIRMWARE]: You can verify the current version of the camcorder's firmware. This menu option is usually unavailable.



DATE/TIME SETUP

Menu item	Setting options	P		Ä		
[T.ZONE/DST]	List of world time zones.	•	•	•	•	27
[DATE/TIME]	-	•	•	•	•	26
[DATE FORMAT]	[Y.M.D (2009.1.1 AM 12:00)], [M.D,Y (JAN. 1, 2009 12:00 AM)], [D.M.Y (1.JAN.2009 12:00 AM)]	•	•	•	•	_

[DATE FORMAT]: Select the date format to be used for most on-screen displays, and (if selected) for the date printed on photos.

Troubleshooting

If you have a problem with your camcorder, refer to this section. Sometimes what you think is a malfunction of the camcorder may have the simplest of solutions - please read the "CHECK THIS FIRST" box before going on to the more detailed problems and solutions. Consult your dealer or a Canon Service Center if the problem persists.

CHECK THIS FIRST

Power supply

Is the battery charged? Is the compact power adapter correctly connected to the camcorder? (
17)

Recording

Did you turn the camcorder on and set it to recording mode? (23) If you are recording to a memory card, is one correctly inserted into the camcorder? (28)

Playback

Did you turn the camcorder on and set it to playback mode? (23)

If you are playing back recordings from a memory card, is one correctly inserted into the camcorder? (
28) Does it contain any recordings?

Power source

The camcorder will not turn on or it turns off by itself.

- The battery pack is exhausted. Replace or charge the battery pack (17).
- Remove the battery pack and reattach it correctly.

Cannot charge the battery pack

- The battery pack's temperature has either fallen below 0 °C or risen above 40 °C. If the battery pack is too cold, warm it up. If the battery pack is too hot, let it cool down until its temperature is below 40 °C.
- Charge the battery pack in temperatures between 0 °C and 40 °C.
- The battery pack is damaged. Use a different battery pack.
- The camcorder cannot communicate with the battery pack attached. Such battery packs cannot be charged using this camcorder.

A noise can be heard from the compact power adapter.

A faint sound can be heard while the compact power adapter is connected to a power outlet. This is not a
malfunction.

After using the camcorder for a long time, it becomes hot.

The camcorder may become hot after using it continuously for long periods of time; this is not a malfunction.
 If it becomes hot very quickly or it becomes too hot to touch, it may indicate a problem with the camcorder.
 Consult a Canon Service Center.



The battery pack is exhausted extremely quickly even at normal temperatures.

- The battery may have reached the end of its battery life. Buy a new battery pack.

Recording

Pressing Start/Stop will not start recording.

- You cannot record while the camcorder is writing previous recording onto the memory (while the ACCESS indicator is on or flashing).

The point where Start/Stop was pressed does not match the beginning/end of the recording.

- There is a slight interval between pressing (Start/Stop) and the actual start of recording. This is not a malfunction.
- When the pre-recording function is used, the beginning of the scene will differ from when Start/Stop was pressed.

The camcorder will not focus.

- Autofocus does not work on the subject. Focus manually (48).
- Lens is dirty. Clean the lens with a soft lens-cleaning cloth (🗀 105). Never use tissue paper to clean the lens.

A vertical light bar appears on the screen.

- Bright light in a dark scene may cause a vertical light bar (smear) to appear. This is not a malfunction.

Changing the operating mode between recording (●)/record pause (● ▮▮)/playback (▶) takes longer than usual.

 When the memory contains a large number of scenes, some operations may take longer than usual. Back up your recordings (74) and initialize the memory (29).

Movies or photos cannot be recorded properly.

Playback

Cannot add scenes to the playlist.

- The playlist cannot contain more than 99 scenes or 100 hours of scenes.
- You may not be able to add scenes to the playlist if they were recorded or edited using another device.

Cannot delete a scene.

- You may not be able to delete scenes recorded or edited using another device.

Deleting scenes takes longer than usual.

 When the memory contains a large number of scenes, some operations may take longer than usual. Back up your recordings (74) and initialize the memory (29).

Cannot erase a photo

- The photo is protected. Remove the protection (64).

Cannot play back a music track.

If the music tracks were erased when the memory was initialized, use the supplied software Music Transfer
 Utility to transfer the music files on the supplied Instruction Manual/Music Data Disc CD-ROM. For details,
 refer to the software's instruction manual (PDF file).

When playing back recordings combined with music, the video and audio do not play back correctly (playback skips or stops).

 This occurs when music files are transferred and there is not enough available space in the memory (about 5 times more than the size of the music files). Make sure there is enough space and then transfer the music files again.

When playing a slideshow, it takes longer than usual for the photos to advance or there are brief stops in the audio.

 This may occur when using a memory card with no Speed Class rating or playing back photos recorded with another device. Play back photos taken with this camcorder from a memory card rated Speed Class 2 or higher.

Indicators and Onscreen Displays

liahts	III	in	red.

- Battery pack is exhausted. Replace or charge the battery pack (17).

appears on the screen.

 The camcorder cannot communicate with the battery pack attached so the remaining battery time cannot be displayed.

lights up in red.

- A memory card error occurred. Turn off the camcorder. Remove and reinsert the memory card. Initialize the memory card (2 29) if the display does not change back to normal.
- The memory card is full. Replace the memory card or delete some recordings (40, 62) to free some space on the memory card.

The ON/OFF(CHG) (power/charge) indicator flashes rapidly while the camcorder is charging.

- * * * * * * (one flash at 0.5-second intervals)

Charging has stopped because the compact power adapter or the battery pack is faulty. Consult a Canon Service Center.

The ON/OFF(CHG) (power/charge) indicator flashes very slowly while the camcorder is charging.

- * (one flash at 2-second intervals)

The battery pack's temperature has either fallen below 0 °C or risen above 40 °C. If the battery pack is too cold, warm it up. If the battery pack is too hot, let it cool down until its temperature is below 40 °C.

- Charge the battery pack in temperatures between 0 °C and 40 °C.
- The battery pack is damaged. Use a different battery pack.

Picture and Sound

The LCD screen appears dim.

- The LCD screen dimmer is on. To turn it off, press DISP. for 2 seconds or more.



Screen displays turn on and off repeatedly.

- The battery pack is exhausted. Replace or charge the battery pack (11).
- Remove the battery pack and reattach it correctly.

Abnormal characters appear on the screen and the camcorder does not operate properly.

Disconnect the power source and reconnect it after a short time. If the problem still persists, disconnect the
power source and press the RESET button with a pointed item. Pressing the RESET button resets all settings.

Video noise appears on screen.

 When using the camcorder close to devices that emit strong electromagnetic fields (plasma TVs, cellular phones, etc.), keep a distance between the camcorder and these devices.

Sound is distorted or is recorded at lower levels.

When recording near loud sounds (such as fireworks, shows or concerts), sound may become distorted or it
may not be recorded at the actual levels. This is not a malfunction.

The picture is displayed correctly but there is no sound from the built-in speaker.

- Speaker volume is turned off. Adjust the volume (35).
- If the STV-250N Stereo Video Cable is connected to the camcorder, disconnect it.
- [AV/PHONES] is set to [PHONES]. Change it to [AV AV] (PAV AV).

Memory Card and Accessories

Cannot insert the memory card.

- The memory card was not facing the correct direction. Turn the memory card over and insert it (1) 28).

Cannot record on the memory card.

- The memory card is full. Erase some recordings to free some space or replace the memory card.
- Initialize the memory card (29) when you use it with the camcorder for the first time.
- The LOCK switch on the SD or SDHC memory card is set to prevent accidental erasure. Change the position of the LOCK switch.
- In order to record movies, a compatible memory card must be inserted (28).
- The folder and file numbers have reached their maximum value. Set [PHOTO NOS.] to [RESET] (87) and insert a new memory card.
- The camcorder may not be able to record on a memory card that was recorded on with another device.

The wireless controller will not work.

- Set [WL.REMOTE] to [ON].
- Replace the battery of the wireless controller.

Connections with External Devices

Video noise appears on the TV screen.

 When using the camcorder in a room where a TV is located, keep a distance between the compact power adapter and the power or antenna cables of the TV.

Playback looks fine on the camcorder but there is no image on the TV screen.

 The video input on the TV is not set to the video terminal to which you connected the camcorder. Select the correct video input. The computer doesn't recognize the camcorder even though the camcorder is connected correctly.

- [USB SETTING] is set to [DVD BURNER]. Set it to [PC/PRINTER] or to [CONNECT&SET] (87).
- Disconnect the USB cable and turn off the camcorder. After a short while, turn it on again and restore the connection.

The printer is not working even though the camcorder and printer are connected correctly.

- [USB SETTING] is set to [DVD BURNER]. Set it to [PC/PRINTER] or to [CONNECT&SET] (22 87).
- Disconnect the USB cable. Turn the printer off and then on again and restore the connection.

The camcorder doesn't recognize the DW-100 DVD Burner even though it is connected correctly.

- [USB SETTING] is set to [PC/PRINTER]. Set it to [DVD BURNER] or to [CONNECT&SET] ([] 87).

List of Messages (in alphabetical order)

Following the list of messages for the camcorder you can find separate lists for printing-related messages (\bigcirc 100) and for messages that appear only when using the optional DW-100 DVD Burner (\bigcirc 99).

ACCESSING THE CARD DO NOT REMOVE THE CARD

 You opened the memory card slot cover while the camcorder was accessing the memory card or the camcorder started accessing the memory card as you opened the memory card slot cover. Do not remove the memory card until this message disappears.

BACK UP RECORDINGS REGULARLY

- This message may appear when you turn on the camcorder. In the event of a malfunction, recordings may be lost so back up your recordings regularly (74).

BUFFER OVERFLOW RECORDING WAS STOPPED

 The data transfer rate was too high for the memory card in use and the recording was stopped. Replace the memory card with one rated Speed Class 2 or higher.

FS22 / FS21 / FS20 BUILT-IN MEM INITIALIZE USING ONLY THE CAMCORDER

 There is a problem that prevents accessing the built-in memory. Initialize the built-in memory with this camcorder (
29).

(ES22) / (ES21) / (ES20) BUILT-IN MEMORY ERROR

 The built-in memory could not be read. This may indicate a problem with the camcorder. Consult a Canon Service Center

FS22 / FS21 / FS20 BUILT-IN MEMORY FULL

The built-in memory is full ([END] appears on the screen). Delete some recordings (40, 62) to free some space.

FS22 / FS21 / FS20 CANNOT ACCESS THE BUILT-IN MEMORY

- There is a problem with the built-in memory.

CANNOT COMMUNICATE WITH THE BATTERY PACK CONTINUE USING THIS BATTERY PACK?

- You attached a battery pack that is not recommended by Canon for use with this camcorder.



(ES22) / (ES21) / (ES20) CANNOT COPY

 The total size of the scenes you selected to copy exceeds the available space on the memory card. Delete some recordings on the memory card (\$\sum\$ 40, 62) or reduce the number of scenes to copy.

CANNOT DIVIDE THE SCENE. INITIALIZE ONLY USING THE CAMCORDER.

- The scene could not be divided because data could not be added to the camcorder's file management data. Back up the recordings (74) and initialize the memory (29).

CANNOT FDIT

- Cannot move or delete original scenes or scenes in the playlist.

CANNOT EDIT CHECK THE CARD

 The memory card in the camcorder was initialized using a computer. Initialize the memory card with this camcorder (□□ 29).

CANNOT ENTER THE STANDBY MODE NOW

- The camcorder cannot enter the standby mode if the remaining battery charge is too low.

CANNOT PLAY BACK

- There is a problem with the memory.

ES22 / ES21 / ES20 CANNOT PLAY BACK CANNOT ACCESS THE BUILT-IN MEMORY

- There is a problem with the built-in memory.

CANNOT PLAY BACK CHECK THE CARD

- There is a problem with the memory card.

(\$522) / (\$521) / (\$520) CANNOT PLAY THE MOVIES IN THE BUILT-IN MEMORY INITIALIZE USING ONLY THE CAMCORDER

 The camcorder's built-in memory was initialized using a computer. Initialize the built-in memory with this camcorder (29).

CANNOT PLAY THE MOVIES ON THIS CARD

- Movies cannot be played back from a memory card with a capacity of 64 MB or less.

CANNOT PLAY THE MOVIES ON THIS CARD INITIALIZE USING ONLY THE CAMCORDER

 The memory card in the camcorder was initialized using a computer. Initialize the memory card with this camcorder (2) 29).

CANNOT RECORD

- There is a problem with the memory.

(ES22) / (ES21) / (ES20) CANNOT RECORD CANNOT ACCESS THE BUILT-IN MEMORY

- There is a problem with the built-in memory.

CANNOT RECORD CHECK THE CARD

- There is a problem with the memory card.

(\$522) / (\$521) / (\$520) CANNOT RECORD MOVIES IN THE BUILT-IN MEMORY INITIALIZE USING ONLY THE CAMCORDER

 The camcorder's built-in memory was initialized using a computer. Initialize the built-in memory with this camcorder (2).

CANNOT RECORD MOVIES ON THIS CARD

- Movies cannot be recorded on a memory card with a capacity of 64 MB or less.

CANNOT RECORD MOVIES ON THIS CARD INITIALIZE USING ONLY THE CAMCORDER

 The memory card in the camcorder was initialized using a computer. Initialize the memory card with this camcorder (□□ 29).

CARD FULL

- The memory card is full. Erase some recordings (40, 62) to free some space or replace the memory card.

(ES22) / (ES24) / (ES24) CARD REACHED THE MAXIMUM NUMBER OF SCENES

 The memory card already contains 3,999 scenes (the maximum number of scenes); no further scenes can be copied onto the memory card. Delete some recordings (40) to free some space.

CARD UNABLE TO RECOGNIZE THE DATA

- The memory card contains scenes recorded in a different television system (NTSC).

CHANGE THE BATTERY PACK

- Battery pack is exhausted. Replace or charge the battery pack (17).

CHECK THE CARD

- Cannot access the memory card. Check the memory card and make sure it is inserted correctly (12) 28).
- A memory card error occurred. The camcorder cannot record or display the image.
- If after the message disappears, appears in red, perform the following: Turn off the camcorder and remove and reinsert the memory card. If turns back to green you can resume recording/playback.
- Initialize the memory card (22). (Doing so will erase all the recordings on the memory card.)

CONNECT THE COMPACT POWER ADAPTER

 When the camcorder is in mode and is connected to the computer, this message will appear if the camcorder is being powered by the battery pack. Connect the compact power adapter to the camcorder.

COULD NOT ADD TO PLAYLIST

- The playlist cannot contain more than 100 hours of scenes.

CARD INITIALIZE USING ONLY THE CAMCORDER

 There is a problem that prevents accessing the memory card. Initialize the memory card with this camcorder (
 (
) 29).

LCD SCREEN HAS BEEN DIMMED

- Hold DISP. pressed down for 2 seconds or more.

MAY NOT BE POSSIBLE TO RECORD MOVIES ON THIS CARD

 You may not be able to record movies on a memory card without a Speed Class rating. Replace the memory card with one rated Speed Class 2 or higher.

NAMING FRROR

- The folder and file numbers have reached their maximum value. Set [PHOTO NOS.] to [RESET] (87) and erase all the photos on the memory card or initialize it.

NEED TO RECOVER FILES FROM THE CARD. CHANGE THE POSITION OF THE CARD'S LOCK SWITCH.

This message will appear the next time you turn on the camcorder if power supply was accidentally
interrupted while the camcorder was writing to the memory card and later the position of the card's LOCK
switch was changed to prevent erasure. Change the position of the LOCK switch.

NO CARD

- There is no memory card in the camcorder.



NO PHOTOS

- There are no photos to play back.

NO SCENES

- There are no scenes recorded in the memory selected.

NOT AVAILABLE IN DUAL SHOT

 You pressed a button that cannot be used in mode. Turn the camera mode dial to a flexible recording mode (**, or a).

NOT ENOUGH AVAILABLE SPACE CANNOT DIVIDE THE SCENE

PLAYLIST IS FULL. CANNOT DIVIDE THE SCENE.

- Scene could not be divided. The playlist cannot contain more than 99 scenes. Delete some scenes (40).

PRINT ORDER ERROR

- You attempted to set more than 998 photos in the print order.

PROCESS CANCELED

- The process was canceled following user intervention.

REACHED THE MAXIMUM NUMBER OF SCENES

- The maximum number of scenes has been reached. Delete some scenes (40).
- Scene could not be added to the playlist (53). The playlist cannot contain more than 99 scenes. Delete some scenes (54).

FS22 / FS21 / FS20 READING THE BUILT-IN MEMORY

- Reading data from the built-in memory.

READING THE CARD

- Reading data from the memory card.

SCENE RECORDED USING ANOTHER DEVICE. CANNOT DIVIDE THE SCENE.

- Scenes recorded with another device cannot be divided using this camcorder.

SOME On PHOTOS COULD NOT BE DELETED

- Protected photos cannot be deleted. Cancel the protection setting before deleting.

SOME SCENES COULD NOT BE ADDED

 Scene could not be added to the playlist. The playlist cannot contain more than 99 scenes. Delete some scenes from the playlist (\$\sum_{\text{\$\sum}}\$ 54).

SOME SCENES COULD NOT BE DELETED

- Movies that were protected/edited with other devices cannot be deleted.

TASK IN PROGRESS DO NOT DISCONNECT THE POWER SOURCE

 The camcorder is updating the memory. Do not disconnect the compact power adapter or remove the battery pack.

THE CAMCORDER IS SET TO MOVIE MODE

- You pressed PHOTO while the camera mode dial was set to ...

THE CAMCORDER IS SET TO PHOTO MODE

- You pressed Start/Stop while the camera mode dial was set to a.

THE CARD IS SET FOR ERASURE PREVENTION

 The LOCK switch on the SD or SDHC memory card is set to prevent accidental erasure. Change the position of the LOCK switch.

THE MEMORY CARD COVER IS OPEN

- After inserting a memory card, close the memory card slot cover (28).

THIS On PHOTO COULD NOT BE DELETED

- Protected photos cannot be deleted. Cancel the protection setting before deleting.

TOO MANY PHOTOS DISCONNECT USB CABLE

Disconnect the USB cable and decrease the number of photos on the memory card to fewer than 1,800.
 If a dialog box appeared on the computer screen, close it. Disconnect the USB cable, and restore the connection after a short while.

TRANSFER ORDER ERROR

 You attempted to set more than 998 transfer orders. Reduce the number of photos marked with transfer orders

UNABLE TO RECOGNIZE THE DATA

- A memory card with data recorded in a different television system (NTSC) was inserted into the camcorder.

UNABLE TO RECOVER DATA

- Could not recover a corrupted file.

WHILE THE CAMCORDER IS CONNECTED TO A PC DO NOT DISCONNECT THE USB CABLE OR POWER SOURCE CANNOT TURN OFF POWER OR CHANGE MODES

- When the camcorder is in producted and is connected to the computer with a USB cable, the camcorder cannot be operated. Disconnecting the USB cable or power source while this message appears may result in permanent loss of the recordings in the camcorder. Use the computer's Safely Remove Hardware function to end the connection and disconnect the USB cable before using the camcorder.



Messages Related to the Optional DW-100 DVD Burner

If a message appears while the camcorder is connected to the optional DW-100 DVD Burner, refer to the following section and also to the instruction manual of the DVD Burner

CANNOT READ THE DISC CHECK THE DISC

 During disc recording mode, this message can appear when a commercially available DVD disc (a DVD disc containing movies, software, etc.) or an 8 cm mini DVD disc is inserted.

CLOSE THE MEMORY CARD SLOT COVER

- The memory card slot cover is open. Close the cover after correctly inserting the memory card (28).

CONNECT THE COMPACT POWER ADAPTER

- The camcorder is being powered by the battery pack. Connect the compact power adapter to the camcorder.

DISC ACCESS FAILURE CHECK THE DISC

- There was an error when reading the disc or attempting to write onto it.
- This message can also appear if condensation has formed. Wait until the DVD burner dries completely before resuming use (
 105).
- The disc may not be loaded correctly. Try removing the disc and reinserting it.

ERROR READING THE DATA

- Error while reading the recordings from the camcorder.
- Check that the USB cable was not accidentally disconnected.

LOADING THE DISC

- Reading data from the disc.

NO DISC

- Insert a disc into the DVD burner.

NO PHOTOS

- There are no photos to add to the disc.

NO SCENES

- There are no movies to add to the disc.

NO SCENES LEFT TO ADD

 You selected to create a DVD with the [REM.SCENES] setting, but all the scenes have already been added to discs created in the past; there are no applicable scenes.

NO TRANSFER ORDERS

OPERATION CANCELED

- The USB cable was disconnected and the operation was canceled. Check the USB connection.

UNABLE TO RECOVER DATA

Could not recover a corrupted file.

Direct Print Related Messages

CANNOT PRINT!

 You attempted to print a photo that was recorded with another camcorder, has a different compression, or was edited on a computer.

CHECK PRINT SETTINGS

- Current print settings cannot be used for printing with the 🖹 ~ button.

COMMUNICATION ERROR

- The printer is experiencing a data transfer error. Cancel printing, disconnect the USB cable and turn off the printer. After a while, turn the printer back on and reconnect the USB cable. When you are printing using the

 △ ✓ button, check the print settings.
 - Or, you attempted to print from a memory card that contains a large number of photos. Reduce the number of photos.

COULD NOT PRINT X PHOTOS

 You attempted to use the print order settings to print X photos that were recorded with another camcorder, with a different compression or were edited on a computer.

FILE FRROR

 You attempted to print a photo that was recorded with another camcorder, has a different compression, or was edited on a computer.

HARDWARF FRROR

Cancel printing. Turn off the printer and turn it back on. Check the printer status. If the printer is equipped with
a battery, it might be exhausted. In such case, turn off the printer, replace the battery and turn it back on.

INCOMPATIBLE PAPER SIZE

- The paper settings of the camcorder conflict with the printer's settings.

INK ABSORBER FULL

 Select [CONTINUE] to resume printing. Consult a Canon Service Center (refer to the list included with the printer) to replace the ink absorber.

INK ERROR

- There is a problem with the ink. Replace the ink cartridge.

I OW INK I EVEL

- The ink cartridge needs to be replaced soon. Select [CONTINUE] to restart printing.

NO INK

- The ink cartridge is not inserted or is out of ink.

NO PAPER

- Paper is not correctly inserted or there is no paper.

NO PRINTHFAD

- No print head is installed in the printer or the print head is defective.

PAPER ERROR

- There is a problem with the paper. The paper is not correctly loaded or the paper size is wrong. Alternatively, if the paper output tray is closed, open it to print.



PAPER JAM

 The paper jammed during printing. Select [STOP] to cancel printing. After removing the paper, set some paper again and retry printing.

PAPER LEVER ERROR

- Paper lever error occurred. Adjust the paper selection lever to the proper position.

PRINT ERROR

- Cancel printing, disconnect the USB cable and turn off the printer. After a while, turn the printer back on and reconnect the USB cable. Check the printer status.
- When you are printing using the 🗅 ~ button, check the print settings.

PRINTER COVER OPEN

- Close the printer cover securely.

PRINTER ERROR

- A malfunction has occurred that may require repairs. (Canon inkjet printers: the printer's green power lamp and orange error lamp flash alternately.)
- Disconnect the USB cable and turn off the printer. Unplug the printer's power cord from the power outlet and contact the appropriate customer support center or service center.

PRINTER IN USE

- The printer is in use. Check the printer status.

SET A PRINT ORDER

- No photo has been marked with a print order.



About Canon Inkjet/SELPHY DS Printers: If the printer's error indicator flashes or an error message appears on the printer's operation panel, refer to the printer's instruction manual.

 If you cannot solve the problem even after consulting this list and the printer's instruction manual, contact the closest Canon Service Center (refer to the list included with the printer).

Handling Precautions

Camcorder

Be sure to observe the following precautions to ensure maximum performance.

- Back up your recordings periodically. Make sure to transfer your recordings to an external device such as a computer or digital video recorder (☐ 74) and back them up on a regular basis. This will protect your important recordings in case of damage and create more free space on the memory. Canon shall not be liable for any data loss.
- When using the wrist strap or a shoulder strap, do not allow the camcorder to swing and hit an object.
- Do not carry the camcorder by the LCD panel. Be careful when closing the LCD panel.
- Do not leave the camcorder in places subject to high temperatures (like the inside of a car under direct sunlight), or high humidity.
- Do not use the camcorder near strong electromagnetic fields such as above TVs, near plasma TVs or mobile phones.
- Do not point the lens at strong light sources. Do not leave the camcorder pointed at a bright subject.
- Do not use or store the camcorder in dusty or sandy places. The camcorder is not waterproof – avoid also water, mud or salt. If any of the above should get into the camcorder

it may damage the camcorder and/or the lens.

- Be careful of heat generated by lighting equipment.
- Do not disassemble the camcorder. If the camcorder does not function properly, consult qualified service personnel.
- Handle the camcorder with care. Do not subject the camcorder to shocks or vibration as this may cause damage.
- When mounting the camcorder on a tripod, make sure that the tripod's fastening screw is shorter than
 5.5 mm. Using other tripods may damage the camcorder.



When recording movies, try to get a calm, stable picture. Excessive camcorder movement while shooting and extensive use of fast zooms and panning can result in jittery scenes. In extreme cases, the playback of such scenes may result in visually induced motion sickness. If you experience such a reaction, immediately stop the playback and take a rest break as necessary.

Long-term Storage

If you do not intend to use the camcorder for a long time, store it in a



place free of dust, in low humidity, and at temperatures not higher than 30 °C.

Battery Pack

DANGER!

Treat the battery pack with care.

- Keep it away from fire (or it might explode).
- Do not expose the battery pack to temperature higher than 60 °C. Do not leave it near a heater or inside a car in hot weather.
- Do not try to disassemble or modify it.
- Do not drop it or subject it to shocks.
- · Do not get it wet.

CAUTION:

Danger of explosion if battery is incorrectly attached. Attach only with the same type.

 Dirty terminals may cause a poor contact between the battery pack and the camcorder. Wipe the terminals with a soft cloth.

Remaining Battery Time

If the remaining battery time displayed is not correct, charge the battery pack fully. However, the correct time may not be displayed if a fully charged battery pack is used continuously in high temperatures or it is left unused for long periods of time. Additionally, depending on the battery life, the correct time may not be displayed. Use the time shown on the screen as an approximation.

Long-term Storage

- Store battery packs in a dry place at temperatures no higher than 30 °C.
- To extend the battery life of the battery pack, discharge it completely before storing it.
- Charge and discharge all your battery packs fully at least once a year.

Regarding batteries that do not bear the Intelligent System mark

- If you use with the camcorder battery packs that are not genuine Canon battery packs, (2) will appear and the remaining battery time will not be displayed.

Memory Card

- We recommend backing up the recordings on the memory card onto your computer. Data may be corrupted or lost due to memory card defects or exposure to static electricity. Canon makes no warranties for corrupted or lost data.
- Do not touch or expose the terminals to dust or dirt.
- Do not use memory cards in places subject to strong magnetic fields.
- Do not leave memory cards in places subject to high humidity and high temperature.

- Do not disassemble, bend, drop, or subject memory cards to shocks and do not expose them to water.
- Check the direction before inserting the memory card. Forcing a memory card into the slot if it is not correctly oriented may damage the memory card or the camcorder.
- Do not attach any labels or stickers on the memory card.
- SD/SDHC memory cards have a physical switch to prevent writing on the card so as to avoid the accidental erasure of the card's content. To write protect the memory card, set the switch to the LOCK position.



Built-in Rechargeable Lithium Battery

The camcorder has a built-in rechargeable lithium battery to keep the date/time and other settings. The built-in lithium battery is recharged while you use the camcorder; however, it will become totally discharged if you do not use the camcorder for about 3 months.

To recharge the built-in lithium battery:

Connect the compact power adapter to the camcorder and leave it connected for about 24 hours with the camcorder off.

Lithium Button Battery

WARNING!

- The battery used in this device may present a fire or chemical burn hazard if mishandled.
- Do not disassemble, modify, immerse in water, heat above 100 °C or incinerate the battery.
- Replace with a CR2025 battery made by Panasonic, Hitachi Maxell, Sony, Sanyo, or with Duracell2025. Use of other batteries may present a risk of fire or explosion.
- Do not insert the battery into the mouth. If swallowed, seek medical assistance immediately. The battery case may break and the battery fluids may cause internal damage.
- Keep the battery out of the reach of children.
- Do not recharge, short-circuit or insert the battery in the wrong direction.
- The used battery should be returned to the supplier for safe disposal.
- Do not pick up the battery using tweezers or other metal tools, as this will cause a short circuit.
- Wipe the battery with a clean dry cloth to ensure proper contact.

Disposal

When you delete movies or initialize the built-in memory (\$322 / \$321 / \$320 only) or memory card, only the file allocation table is altered and stored data is not physically erased. Take the



necessary precautions when you dispose of the camcorder or memory card, for example by physically damaging it to prevent the leakage of private data.

(\$22) (\$21) (\$20) If giving the camcorder to another person, initialize the built-in memory using the [COMPL.INIT.] setting (\$\subseteq\$ 29), fill it up with unimportant recordings, and then initialize it again using the same method. This makes recovering the original recordings very difficult.

Maintenance/Others

Cleaning

Camcorder Body

 Use a soft, dry cloth to clean the camcorder body. Never use chemically treated cloths or volatile solvents such as paint thinner.

Lens

If the lens surface is dirty, the autofocus may not work properly.

- Remove any dust or dirt particles using a non-aerosol type blower brush.
- Use a clean, soft lens-cleaning cloth to gently wipe the lens. Never use tissue paper.

LCD Screen

- Clean the LCD screen using a clean, soft lens-cleaning cloth.
- Condensation may form on the surface of the screen when the temperature changes suddenly. Wipe it with a soft dry cloth.

Condensation

Moving the camcorder rapidly between hot and cold temperatures may cause condensation (water droplets) to form on its internal surfaces. Stop using the camcorder if condensation is detected. Continued use may damage the camcorder.

Condensation may form in the following cases:

- When the camcorder is moved quickly from cold to warm places
- When the camcorder is left in a humid room
- When a cold room is heated rapidly

TO AVOID CONDENSATION

- Do not expose the camcorder to sudden or extreme changes in temperature.
- Place the camcorder in an airtight plastic bag and let it adjust to temperature changes slowly before removing it from the bag.

WHEN CONDENSATION IS DETECTED

The camcorder automatically shuts off. The precise time required for water droplets to evaporate will vary depending on the location and weather conditions. As a general rule, wait for 2 hours before resuming use of the camcorder.

Using the Camcorder Abroad

Power Sources

You can use the compact power adapter to operate the camcorder and to charge battery packs in any country with power supply between 100 and 240 V AC, 50/60 Hz. Consult a Canon Service Center for information on plug adapters for overseas use.

Playback on a TV Screen

You can only play back your recordings on TVs compatible with the PAL system. PAL (or the compatible SECAM system) is used in the following regions/countries:

Europe: All of Europe and Russia. Americas: Only in Argentina, Brazil, Uruguay and French territories (French Guiana, Guadeloupe, Martinique, etc.). Asia: Most of Asia (except in Japan, the Philippines, South Korea, Taiwan and Myanmar). Africa: All of Africa and African islands. Australia/Oceania: Australia, New Zealand, Papua New Guinea; most Pacific islands (except for Micronesia, Samoa, Tonga and US territories like Guam and American Samoa).

Music Files

The specifications of the music files compatible with the camcorder are as follows.

Audio encoding: Linear PCM Audio sampling: 48 kHz, 16 bits, 2 channels

Minimum length: 10 seconds

File extension: WAV

The music files are saved in the memory under the following folder structure.




On the memory card:

```
[CANON]
[PRIVATE]
[MY_MUSIC]
MUSIC_01.WAV to
MUSIC_99.WAV
```

(FS22) / (FS21) / (FS20)


In the built-in memory:



The supplied Instruction Manual/
Music Data Disc CD-ROM contains a
folder called [MUSIC]. This folder
contains two folders called [MUSIC 1]
and [MUSIC 2]. [MUSIC 1] contains the
tracks that are pre-installed in the builtin memory of the FS22/FS21/FS20.
[MUSIC 2] contains tracks different
from those in [MUSIC 1]. Use tracks
from both folders to your liking or to
restore the pre-installed tracks if the
built-in memory was initialized (1552) /

107

System Diagram (Availability differs from area to area)





Optional Accessories

Use of genuine Canon accessories is recommended.

This product is designed to achieve excellent performance when used with genuine Canon accessories. Canon shall not be liable for any damage to this product and/or accidents such as fire, etc., caused by the malfunction of non-genuine Canon accessories (e.g., a leakage and/or explosion of a battery pack). Please note that this warranty does not apply to repairs arising out of the malfunction of non-genuine Canon accessories, although you may request such repairs on a chargeable basis.

Battery Packs

When you need extra battery packs, make sure you select the BP-808.




Intelligent Li-ion Battery

When you use battery packs bearing the

Intelligent System mark, the camcorder will communicate with the battery and display the remaining usage time (accurate to 1 minute). You can only use and charge these battery packs with camcorders and chargers compatible with Intelligent System.

CG-800E Battery Charger

Use the battery charger to charge the battery packs.



Charging Times

The charging times given in the following table are approximate and vary according to charging conditions and initial charge of the battery pack.

Charging conditions	Charging time
Using the camcorder	140 min.*
Using the CG-800E Battery Charger	105 min.

* When the camcorder charges an exhausted battery pack for the first 20 minutes, it can be used for 3 times longer than it was charged. In other words, you can record with the camcorder for 60 minutes after a 20-minute charge.

Recording and Playback Times

The recording and playback times given in the following table are approximate and vary according to recording mode and charging, recording or playback conditions. The effective usage time of the battery pack may decrease when recording in cold surroundings, when using the brighter screen settings, etc.

Using the built-in memory (ES22) / ES21) / ES20 only)

Recording mode →	VD	CD	I P
Usage time ↓	XP	SP	LP
Maximum recording time	210 min.	215 min.	215 min.
Typical recording time*	105 min.	105 min.	110 min.
Playback time	290 min.	295 min.	295 min.

Using a memory card (FS22 / FS21 / FS20)

Recording mode →	ХР	SP	LP
Usage time ↓			
Maximum recording time	205 min.	205 min.	205 min.
Typical recording time*	100 min.	100 min.	105 min.
Playback time	275 min.	275 min.	280 min.

Using a memory card (ES200)

Recording mode → Usage time ↓	XP	SP	LP
Maximum recording time	205 min.	210 min.	210 min.
Typical recording time*	100 min.	105 min.	105 min.
Playback time	290 min.	295 min.	295 min.

^{*} Approximate times for recording with repeated operations such as start/stop, zooming, and power on/off.

Shoulder Strap

You can attach a shoulder strap for more security and portability.





SC-2000 Soft Carrying Case

A handy camcorder bag with padded compartments and plenty of space for accessories.



This mark identifies genuine Canon video accessories. When you use Canon video equipment, we recommend Canon-brand accessories or products bearing the same mark.



Specifications

LEGRIA FS22/FS21/FS20/FS200

System

<u>, </u>		00.151			
Recording System	Movies:	SD-Vide			
			compression: MPEG-2		
	Dhatas		compression: Dolby Digital 2ch (AC-3)		
	Photos:		esign rule for camera system), compatible with er. 2.2 and with DPOF		
			compression: JPEG (Super Fine, Fine, Normal)		
Television System		CCIR standard (625 lines, 50 fields) PAL color signal			
Recording Media		ash memory, 32 (GB; SD or SDHC (SD High Capacity) memory card (not		
	included)				
	ES21 Built-in f included)	FS21 Built-in flash memory, 16 GB; SD or SDHC (SD High Capacity) memory card (not included)			
	FS20 Built-in f	flash memory, 8 G	BB; SD or SDHC (SD High Capacity) memory card (not		
	included)				
	FS200 SD or	SDHC (SD High Ca	apacity) memory card (not included)		
Maximum Recording Time	FS22 Built-in n	nemory, 32 GB			
(approximate figures)		XP: 7 hr. 20 min., SP: 11 hr. 5 min., LP: 20 hr. 50 min.			
		FS21) Built-in memory, 16 GB			
	XP: 3 hr. 40 min., SP: 5 hr. 30 min., LP: 10 hr. 20 min.				
	FS20 Built-in memory, 8 GB				
	XP: 1 hr. 50 min., SP: 2 hr. 45 min., LP: 5 hr. 10 min.				
	4 GB memory card				
	XP: 55 min., SP: 1	hr. 20 min., LP: 2	2 hr. 35 min.		
Image Sensor	FS22 / FS21)	/ FS20 1/6-ind	ch CCD, approx. 1,070,000 pixels		
	Effective pixels ² (a				
	16:9 Movies (ad		480,000 (T) / 710,000 (W) pixels		
	(or	otical zoom)	550,000 pixels		
	4:3 Movies (ad	dvanced zoom)	440,000 (T) / 690,000 (W) pixels		
	(or	otical zoom)	690,000 pixels		
	16:9 Photos		600,000 pixels		
	4:3 Photos		800,000 pixels		
	FS200 1/6-in				
		Effective pixels ² (all figures are approximate values)			
	16:9 Movies (ad		440,000 (T) / 540,000 (W) pixels		
		otical zoom)	440,000 pixels		
		otical zoom)	400,000 pixels		
	Photos		530,000 pixels		
LCD Screen	2.7 in., wide, TFT	color, approx. 12:	3,000 dots		
Microphone	Stereo electret coi	ndenser micropho	one		



Lens	FS22 / FS21 / FS20 f=2.6-96.2 mm, F/2.0-5.2, 37x optical zoom			
	35 mm equivalent (all figures are approximate values)			
	16:9 Movies (advanced zoom) 41.7-1,877 mm			
	(optical zoom) 47.1-1,743 mm			
	4:3 Movies (advanced zoom) 44.6-2,052 mm			
	(optical zoom) 44.6-1,650 mm			
	16:9 Photos 45.2-1,672 mm			
	4:3 Photos 41.5-1,536 mm			
	FS200 f=2.6-96.2 mm, F/2.0-5.2, 37x optical zoom			
	35 mm equivalent (all figures are approximate values)			
	16:9 Movies (advanced zoom) 40.5-1,676 mm			
	(optical zoom) 45.3-1,676 mm			
	4:3 Movies (advanced zoom) 49.8-1,843 mm			
	Photos 43.6-1,613 mm			
Lens Configuration	10 elements in 8 groups (1 double-sided, aspheric element)			
AF System	TTL autofocus, manual focus available			
Minimum Focusing Distance	1 m; 1 cm at full wide angle			
White Balance	Auto white balance, preset white balance (DAYLIGHT, TUNGSTEN) or custom white			
	balance			
Minimum Illumination	[NIGHT] recording program, Shutter speed at 1/6:			
	FS22 / FS21 / FS20 1.5 lx FS200 1.1 lx			
	[PROGRAM AE], Auto slow shutter [ON], Shutter speed at 1/25:			
	FS22 / FS21 / FS20 5.5 lx FS200 4.5 lx			
Recommended Illumination	More than 100 lx			
Image Stabilization	Electronic			
Size of Photos	FS22 / FS21 / FS20 1152 x 864, 1152 x 648, 640 x 480 pixels			

¹ This camcorder supports Exif 2.2 (also called "Exif Print"). Exif Print is a standard for enhancing the communication between camcorders and printers. By connecting to an Exif Print-compliant printer, the camcorder's image data at the time of shooting is used and optimized, yielding extremely high quality prints.

Terminals

AV OUT/() Terminal	Ø 3.5 mm minijack; Output only		
	(dual purpose terminal also for headphones stereo output)		
	Video: 1 Vp-p / 75 Ω unbalanced		
	Audio: $-10 \text{ dBV } (47 \text{ k}\Omega \text{ load}) / 3 \text{ k}\Omega \text{ or less}$		
USB Terminal	mini-B, USB 2.0 (Hi-Speed USB)		
MIC Terminal	Ø 3.5 mm stereo minijack		
	–57 dBV (with 600 Ω microphone) / 5 k Ω or more		
Power/Others			
Power supply (rated)	7.4 V DC (battery pack), 8.4 V DC (compact power adapter)		
Power consumption	1.8 W (LCD screen, normal brightness, recording in the built-in memory*)		
(SP mode, AF on)	* (FS22) / (FS21) / (FS20) only		
	1.8 W (LCD screen, normal brightness, recording on a memory card)		
Operating temperature	0 - 40 °C		
Dimensions (W x H x D)	55 x 59 x 121 mm excluding the grip belt		
Weight (camcorder body only)	225 g excluding the grip belt		

When two values are given, the first indicates the value at full telephoto (**T**) and the second indicates the value at full wide-angle (**W**).

CA-570 Compact Power Adapter

Power supply	100 – 240 V AC, 50/60 Hz
Rated output / consumption	8.4 V DC, 1.5 A / 29 VA (100 V) – 39 VA (240 V)
Operating temperature	0 – 40 °C
Dimensions	52 x 29 x 90 mm
Weight	135 g

BP-808 Battery Pack

Battery type	Rechargeable lithium ion battery, compatible with Intelligent System
Rated voltage	7.4 V DC
Operating temperature	0 - 40 °C
Battery capacity	890 mAh
Dimensions	30.7 × 23.3 × 40.2 mm
Weight	46 g

Weight and dimensions are approximate. Errors and omissions excepted. The information in this manual is verified as of January 2009. Subject to change without notice.

Index	Deleting/Erasing 40, 54 Photos 59, 62 Digital effects 50
Abroad, using the camcorder	Drive mode
Backing up recordings	Focus priority
Calendar display	Image stabilizer
Data code	Language

¹ **FS22** / **FS21** / **FS20** only.

М	Recording mode32
	Recording programs 41, 42
Magnifying photos	Recording time
Maintenance	Remote sensor 1
Manual exposure adjustment 47	RESET 93
Markers	Reviewing photos
Memory card	3 1
MIC terminal	S
Microphone	
Mini video light	Screen icons
Music Files	SD/SDHC memory card 28
	Searching scenes by date 37
N	Selecting the media ²
	for playback
Night (recording program) 42	for recording
	Self timer
0	Serial number
Onscreen display selection 51, 64	Setup menus
	Shutter speed
P	Slideshow
	Snow (recording program)
P (recording program)	(01 0)
Photo numbers	Special Scene (recording programs) 41
Photo quality	Sports (recording program) 42
Photo size	Spotlight (recording program) 42
Playback	Sunset (recording program) 42
Movies35	
Photos	T
Playlist	Telephoto
Portrait (recording program) 42	Timeline
Power save	Transfer order
Pre-recording	
Print order	Transferring to a computer
Print/share button	Movies
	Photos
Printing photos	Troubleshooting 90
Protecting photos64	Tv (recording program) 42
0	
Q	U
Quick Start function34	USB terminal
R	
	
Recording	
Movies	
Photos57	
	¹ F522 only



V	
VIDEO SNAP	4
Video Snapshot4	4
Volume	7
W	
White balance48	3
Wide angle	2
Wind screen	4
Wireless controller 1	9

W

oom	
Advanced zoom	32
Zoom speed	83
Zoom type	33

¹ (ES22) only.

Trademark Acknowledgements

- . The SD logo is a trademark. The SDHC logo is a trademark.
- Microsoft, Windows and Windows Vista are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.
- . Macintosh and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries.
- Manufactured under license from Dolby Laboratories.

 "Dally:" and the double Downtol and traderante of 5.

 "Dally:"

"Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

 Other names and products not mentioned above may be trademarks or registered trademarks of their respective companies.



ANY USE OF THIS PRODUCT OTHER THAN CONSUMER PERSONAL USE IN ANY MANNER THAT
COMPLIES WITH THE MPG-2 STANDARD FOR ENCODING VIDEO INFORMATION FOR PACKAGED MEDIA IS EXPRESSLY PROHIBITED
WITHOUT A LICENSE UNDER APPLICABLE PATENTS IN THE MPGG-2 PATENT PORTFOLIO, WHICH LICENSE IS AVAILABLE FROM MPEG
LA, L.L.C., 250 STEELE STREET, SUITE 300, DENVER, COLORADO 80206.

Canon

Canon Europa N.V.

Bovenkerkerweg 59-61, 1185 XB Amstelveen, The Netherlands www.canon-europa.com

Canon UK Ltd.

CCI Service Centre, Unit 130 Centennial Park, Borehamwood, Hertfordshire, WD6 3SE, England Telephone 0870-241-2161

Canon Australia Pty Ltd

Tel: 13-13-83 (within Australia only) (61) 02-9805-2555 www.canon.com.au

Canon New Zealand Ltd

Tel: 800-222-666 (within New Zealand only) (64) 02-9805-2555

www.canon.co.nz

Canon Singapore Pte. Ltd

1 HarbourFront Avenue, #04-01 Keppel Bay Tower, Singapore 098632

Tel: (65) 6799 8888 Fax: (65) 6799 8882

Canon Hongkong Company Ltd

19/F, The Metropolis Tower, 10 Metropolis Drive,

Hunghom, Kowloon, Hong Kong

Tel: +852 3191 2333, Fax: +852 2428 3963

Canon Latin America, Inc.

Sales & Enquiries: 703 Waterford Way, Suite 400, Miami, FL 33126 USA

For support concerning the supplied PIXELA software, please call PIXELA customer support (details in the PIXELA ImageMixer 3 SE Installation Guide).