



Parts, Adjustment and Maintenance Manual




**Air-cooled, Prepackaged
Automatic Standby Generators**

Models:

ASPAS1CCA007 (6 kW NG, 7 kW LP)

ASPAS1CCA012 (12 kW NG, 12 kW LP)

ASPAS1CCA015 (13 kW NG, 15 kW LP)



**Not intended for use as Primary Power in place of utility
or in life-support applications.**



— ! DANGER ! —

DEADLY EXHAUST FUMES. OUTDOOR INSTALLATION ONLY!!

INTRODUCTION

This Carrier model is a compact, high performance, air-cooled, engine-driven generator designed to automatically supply electrical power to operate critical loads during a utility power failure.

This unit is factory installed in an all-weather, metal enclosure that is intended exclusively for outdoor installation. This generator will operate using either vapor withdrawn liquid propane (LP) or natural gas (NG).

◆ READ THIS MANUAL THOROUGHLY

Throughout this publication, and on tags and decals affixed to the generator, DANGER, WARNING, CAUTION and NOTE blocks are used to alert personnel to special instructions about a particular operation that may be hazardous if performed incorrectly or carelessly. Observe them carefully. Their definitions are as follows:



After this heading, read instructions that, if not strictly complied with, will result in serious personal injury, including death, in addition to property damage.



After this heading, read instructions that, if not strictly complied with, may result in serious personal injury or property damage.




After this heading, read instructions that, if not strictly complied with, could result in damage to equipment and/or property.


NOTE:

After this heading, read explanatory statements that require special emphasis.


These safety warnings cannot eliminate the hazards that they indicate. Common sense and strict compliance with the special instructions while performing the service are essential to preventing accidents.

Four commonly used safety symbols accompany the DANGER, WARNING and CAUTION blocks. The type of information each indicates follows:

 This symbol points out important safety information that, if not followed, could endanger personal safety and/or property of others.

 This symbol points out potential explosion hazard.

 This symbol points out potential fire hazard.

 This symbol points out potential electrical shock hazard.

The operator is responsible for proper and safe use of the equipment. Carrier strongly recommends that the dealer read this *Parts, Adjustment and Maintenance Manual* and thoroughly understand all instructions before using this equipment. Carrier also strongly recommends instructing other users to properly start and operate the unit. This prepares them if they need to operate the equipment in an emergency.

◆ CONTENTS

This manual contains pertinent information for three different Carrier models:

- ASPAS1CCA007 – 6 kW NG, 7 kW LP, single-cylinder GH-410 Engine
- ASPAS1CCA012 – 12 kW NG, 12 kW LP, V-twin GT-990 Engine
- ASPAS1CCA015 – 13 kW NG, 15 kW LP, V-twin GT-990 Engine

◆ OPERATION AND MAINTENANCE

It is the operator's responsibility to perform all safety checks, to make sure that all maintenance for safe operation is performed promptly, and to have the equipment checked periodically by a Carrier Dealer. Normal maintenance service and replacement of parts are the responsibility of the owner/operator and, as such, are not considered defects in materials or workmanship within the terms of the warranty. Individual operating habits and usage contribute to the need for maintenance service.

Proper maintenance and care of the generator ensures a minimum number of problems and keep operating expenses at a minimum. See a Carrier Dealer for service aids and accessories.

◆ HOW TO OBTAIN SERVICE

When the generator requires servicing or repairs, contact a Carrier Dealer for assistance. Service technicians are factory-trained and are capable of handling all service needs.

When inquiring about parts or service, always supply the complete model number and serial number of the unit as given on its data decal, which is located on the generator. See Figure 1.1 or Figure 1.2 in Section 1.4 of the *Owner's Manual* for decal location.

Model No. _____ Serial No. _____

IntroductionInside Front Cover

| | |
|-----------------------------------|-----|
| Read This Manual Thoroughly | IFC |
| Contents | IFC |
| Operation and Maintenance | IFC |
| How to Obtain Service | IFC |

Important Safety Instructions2

| | |
|-----------------------|---|
| Standards Index | 3 |
|-----------------------|---|

**Section 1 – Post Installation Start-up and
Adjustments4**

| | |
|--|---|
| 1.1 Before Initial Start Up | 4 |
| 1.2 Check Transfer Switch Operation..... | 4 |
| 1.3 Electrical Checks | 4 |
| 1.4 Generator Tests Under Load | 5 |
| 1.5 Checking Automatic Operation..... | 5 |
| 1.6 Adjusting The Regulator (Natural Gas Only) | 5 |
| 1.7 Reconfiguring The Fuel System | 6 |
| 1.7.1 7kW, 410cc Engine | 6 |
| 1.7.2 12kW and 15kW, V-Twin Engines..... | 7 |
| 1.8 Engine Governor Adjustment | 7 |
| 1.8.1 7kW Units | 7 |
| 1.8.2 12kW and 15kW Units..... | 8 |
| 1.9 Voltage Regulator Adjustment | 8 |
| 1.10 Adjusting GH-410/GT-990 Valve Clearance..... | 8 |
| 1.11 The Battery | 8 |

Section 2 – Troubleshooting10

| | |
|---------------------------------|----|
| 2.1 Troubleshooting Guide | 10 |
|---------------------------------|----|

Section 3 – Maintenance11

| | |
|----------------------------|----|
| 3.1 Service Schedule | 11 |
|----------------------------|----|

Section 4 – Electrical Data12

**Section 5 – Exploded Views and
Parts Lists.....26**

Section 6 – Unit Dimensions47

Section 7 – Notes48

SAVE THESE INSTRUCTIONS – The manufacturer suggests that these rules for safe operation be copied and posted near the unit's installation site. Safety should be stressed to all operators and potential operators of this equipment.

WARNING:

The engine exhaust from this product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

WARNING:

This product contains or emits chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

Study these SAFETY RULES carefully before installing, operating or servicing this equipment. Become familiar with this *Parts, Adjustment and Maintenance Manual* and with the unit. The generator can operate safely, efficiently and reliably only if it is properly installed, operated and maintained. Many accidents are caused by failing to follow simple and fundamental rules or precautions.

Carrier cannot possibly anticipate every possible circumstance that might involve a hazard. The warning in this manual, and on tags and decals affixed to the unit are, therefore, not all-inclusive. If using a procedure, work method or operating technique that Carrier does not specifically recommend, satisfy yourself that it is safe for others. Also make sure the procedure, work method or operating technique chosen does not render the generator unsafe.

DANGER

Despite the safe design of this generator, operating this equipment imprudently, neglecting its maintenance or being careless can cause possible injury or death. Permit only responsible and capable persons to install, operate or maintain this equipment.

Potentially lethal voltages are generated by these machines. Ensure all steps are taken to render the machine safe before attempting to work on the generator.

Parts of the generator are rotating and/or hot during operation. Exercise care near running generators.

GENERAL HAZARDS

- For safety reasons, Carrier recommends that this equipment be installed, serviced and repaired by a Carrier Dealer.
- The engine exhaust fumes contain carbon monoxide gas, which can be DEADLY. This dangerous gas, if breathed in sufficient concentrations, can cause unconsciousness or even death. For that reason, adequate ventilation must be provided. This exhaust system must be installed properly, in strict compliance with applicable codes and standards. Following installation, do nothing that might render the system unsafe or in noncompliance with such codes and standards.
- Keep hands, feet, clothing, etc., away from drive belts, fans, and other moving or hot parts. Never remove any drive belt or fan guard while the unit is operating.
- Adequate, unobstructed flow of cooling and ventilating air is critical to correct generator operation. Do not alter the installation or permit even partial blockage of ventilation provisions, as this can seriously affect safe operation of the generator. The generator must be installed outdoors.
- When working on this equipment, remain alert at all times. Never work on the equipment when physically or mentally fatigued.
- Inspect the generator regularly, and contact the nearest Carrier Dealer for parts needing repair or replacement.
- Before performing any maintenance on the generator, disconnect its battery to prevent accidental start up. Disconnect the cable from the battery post indicated by a NEGATIVE, NEG or (—) first. Reconnect that cable last.
- Never use the generator or any of its parts as a step. Stepping on the unit can stress and break parts, and may result in dangerous operating conditions from leaking exhaust gases, fuel leakage, oil leakage, etc.

ELECTRICAL HAZARDS

- All generators covered by this manual produce dangerous electrical voltages and can cause fatal electrical shock. Utility power delivers extremely high and dangerous voltages to the transfer switch as well as the standby generator. Avoid contact with bare wires, terminals, connections, etc., on the generator as well as the transfer switch, if applicable. Ensure all appropriate covers, guards and barriers are in place before operating the generator. If work must be done around an operating unit, stand on an insulated, dry surface to reduce shock hazard.
- Do not handle any kind of electrical device while standing in water, while barefoot, or while hands or feet are wet. **DANGEROUS ELECTRICAL SHOCK MAY RESULT.**
- If people must stand on metal or concrete while installing, operating, servicing, adjusting or repairing this equipment, place insulative mats over a dry wooden platform. Work on the equipment only while standing on such insulative mats.
- The National Electrical Code (NEC) requires the frame and external electrically conductive parts of the generator to be connected to an approved earth ground. This grounding will help prevent dangerous electrical shock that might be caused by a ground fault condition in the generator set or by static electricity. Never disconnect the ground wire. Local electrical codes also may require proper grounding of the generator electrical system.
- After installing this home standby electrical system, the generator may crank and start at any time without warning. When this occurs, load circuits are transferred to the STANDBY (generator) power source. To prevent possible injury if such a start and transfer occur, always set the generator's Auto/Off/Manual switch to its OFF position before working on equipment and remove the 7.5A and 15A fuses from the generator control panel.
- In case of accident caused by electric shock, immediately shut down the source of electrical power. If this is not possible, attempt to free the victim from the live conductor. **AVOID DIRECT CONTACT WITH THE VICTIM.** Use a nonconducting implement, such as a dry rope or board, to free the victim from the live conductor. If the victim is unconscious, apply first aid and get immediate medical help.
- Never wear jewelry when working on this equipment. Jewelry can conduct electricity resulting in electric shock, or may get caught in moving components causing injury.

FIRE HAZARDS

- Keep a fire extinguisher near the generator at all times. Do NOT use any carbon tetra-chloride type extinguisher. Its fumes are toxic, and the liquid can deteriorate wiring insulation. Keep the extinguisher properly charged and be familiar with its use. Consult the local fire department for any questions pertaining to fire extinguishers.

EXPLOSION HAZARDS

- Do not smoke around the generator. Wipe up any fuel or oil spills immediately. Ensure that no combustible materials are left in the generator compartment, or on or near the generator, as FIRE or EXPLOSION may result. Keep the area surrounding the generator clean and free from debris.
- Fuels such as natural gas and LP gas are extremely EXPLOSIVE. Install the fuel supply system according to applicable fuel-gas codes. Before placing the home standby electric system into service, fuel system lines must be properly purged and leak tested according to applicable code. After installation, inspect the fuel system periodically for leaks. No leakage is permitted.

◆ **STANDARDS INDEX**

In the absence of pertinent standards, codes, regulations and laws, the published information listed below may be used as installation guide for this equipment.


1. NFPA No. 37, STATIONARY COMBUSTION ENGINES AND GAS TURBINES, available from the National Fire Protection Association, 470 Atlantic Avenue, Boston, MA 02210.
2. NFPA No. 76A, ESSENTIAL ELECTRICAL SYSTEMS FOR HEALTH CARE FACILITIES, available same as Item 1.
3. NFPA No. 54, NATIONAL FUEL GAS CODE, available same as Item 1.
4. NFPA No. 58, AMERICAN NATIONAL STANDARD FOR STORAGE AND HANDLING OF LIQUEFIED PETROLEUM GAS, available same as Item 1.
5. NFPA No. 70, NFPA HANDBOOK OF NATIONAL ELECTRIC CODE, available same as Item 1.
6. Article X, NATIONAL BUILDING CODE, available from the American Insurance Association, 85 John Street, New York, N.Y. 10038.
7. AGRICULTURAL WIRING HANDBOOK, available from the Food and Energy Council, 909 University Avenue, Columbia, MO 65201.
8. ASAE EP-3634, INSTALLATION AND MAINTENANCE OF FARM STANDBY ELECTRICAL SYSTEMS, available from the American Society of Agricultural Engineers, 2950 Niles Road, St. Joseph, MI 49085.
9. NFPA No. 30, FLAMMABLE AND COMBUSTIBLE LIQUIDS CODE, available same as Item 1.

1.1 BEFORE INITIAL START-UP

Before starting, complete the following:

1. Set the generator's main circuit breaker to its OFF (or open) position.
2. Set the generator's AUTO/OFF/MANUAL switch to the OFF position.
3. Turn OFF the utility power supply to the transfer switch using the means provided (such as the utility main line circuit breaker).
4. Turn OFF all loads connected to the transfer switch terminals T1 and T2.
5. Check the engine crankcase oil level and, if necessary, fill to the dipstick FULL mark with the recommended oil. Do not fill above the FULL mark.
6. Check the fuel supply. Gaseous fuel lines must have been properly purged and leak tested in accordance with applicable fuel-gas codes. All fuel shutoff valves in the fuel supply lines must be open.




-  **Never operate the engine with the oil level below the "Add" mark on the dipstick. Doing this could damage the engine.**

1.2 CHECK TRANSFER SWITCH OPERATION

Refer to Section 3.5, of the owner's manual for manual operation procedures.




-  **Do not attempt manual transfer switch operation until all power voltage supplies to the transfer switch have been positively turned off. Failure to turn off all power voltage supplies will result in extremely hazardous and possibly fatal electrical shock.**

1.3 ELECTRICAL CHECKS

Complete electrical checks as follows:


1. Set the generator's main circuit breaker to its OFF (or open) position.
2. Set the generator's Auto/Off/Manual switch to the OFF position.
3. Turn OFF all loads connected to the transfer switch terminals T1 and T2.
4. Turn on the utility power supply to the transfer switch using the means provided (such as a utility main line circuit breaker).



-  **The transfer switch is now electrically "hot." Contact with "hot" parts will result in extremely hazardous and possibly fatal electrical shock. Proceed with caution.**

5. Use an accurate AC voltmeter to check utility power source voltage across transfer switch terminals N1 and N2. Nominal line-to-line voltage should be 240 volts AC.
6. Check utility power source voltage across terminals N1 and the transfer switch neutral lug; then across terminal N2 and neutral. Nominal line-to-neutral voltage should be 120 volts AC.
7. When certain that utility supply voltage is compatible with transfer switch and load circuit ratings, turn OFF the utility power supply to the transfer switch.
8. On the generator panel, set the AUTO/OFF/MANUAL switch to MANUAL. The engine should crank and start.
9. Let the engine warm up for about five minutes to allow internal temperatures to stabilize. Then, set the generator's main circuit breaker to its ON (or CLOSED) position.



-  **Proceed with caution! Generator power voltage is now supplied to the transfer switch. Contact with live transfer switch parts will result in dangerous and possibly fatal electrical shock.**

10. Connect an accurate AC voltmeter and a frequency meter across transfer switch terminal lugs E1 and E2. Voltage should be 242-252 volts; frequency should read about 61-63 Hertz.
11. Connect the AC voltmeter test leads across terminal lug E1 and neutral; then across E2 and neutral. In both cases, voltage reading should be 121-126 volts AC.
12. Set the generator's main circuit breaker to its OFF (or open) position. Let the engine run at no-load for a few minutes to stabilize internal engine generator temperatures.
13. Set the generator's AUTO/OFF/MANUAL switch to OFF. The engine should shut down.

NOTE:

It is important not to proceed until certain that generator AC voltage and frequency are correct and within the stated limits. Generally, if both AC frequency and voltage are high or low, the engine governor requires adjustment. If frequency is correct, but voltage is high or low, the generator's voltage regulator requires adjustment.


1.4 GENERATOR TESTS UNDER LOAD

To test the generator set with electrical loads applied, proceed as follows:

1. Set generator's main circuit breaker to its OFF (or OPEN) position.
2. Turn OFF all loads connected to the transfer switch terminals T1 and T2.
3. Set the generator's AUTO/OFF/MANUAL switch to OFF.
4. Turn OFF the utility power supply to the transfer switch, using the means provided (such as a utility main line circuit breaker).



WARNING

 **Do not attempt manual transfer switch operation until all power voltage supplies to the transfer switch have been positively turned off. Failure to turn off all power voltage supplies will result in extremely hazardous and possibly fatal electrical shock.**

5. Manually set the transfer switch to the STANDBY position, i.e., load terminals connected to the generator's E1/E2 terminals. The transfer switch operating lever should be down.
6. Set the generator's AUTO/OFF/MANUAL switch to MANUAL. The engine should crank and start immediately.
7. Let the engine stabilize and warm up for a few minutes.
8. Set the generator's main circuit breaker to its ON (or closed) position. Loads are now powered by the standby generator.
9. Turn ON electrical loads connected to transfer switch T1 and T2. Apply an electrical load equal to the full rated wattage/ampere capacity of the installed generator.
10. Connect an accurate AC voltmeter and a frequency meter across terminal lugs E1 and E2. Voltage should be greater than 230 volts; frequency should be greater than 58 Hertz.
11. Let the generator run at full rated load for 20-30 minutes. Listen for unusual noises, vibration or other indications of abnormal operation. Check for oil leaks, evidence of overheating, etc.
12. When testing under load is complete, turn OFF electrical loads.
13. Set the generator's main circuit breaker to its OFF (or OPEN) position.
14. Let the engine run at no-load for a few minutes.
15. Set the AUTO/OFF/MANUAL switch to OFF. The engine should shut down.

1.5 CHECKING AUTOMATIC OPERATION

To check the system for proper automatic operation, proceed as follows:

1. Set generator's main circuit breaker to its OFF (or OPEN) position.
2. Check that the AUTO/OFF/MANUAL switch is set to OFF.
3. Turn OFF the utility power supply to the transfer switch, using means provided (such as a utility main line circuit breaker).
4. Manually set the transfer switch to the UTILITY position, i.e., load terminals connected to the utility power source side.
5. Turn ON the utility power supply to the transfer switch, using the means provided (such as a utility main line circuit breaker).
6. Set the AUTO/OFF/MANUAL switch to AUTO. The system is now ready for automatic operation.
7. Turn OFF the utility power supply to the transfer switch.

With the AUTO/OFF/MANUAL switch at AUTO, the engine should crank and start when the utility source power is turned OFF. After starting, the transfer switch should connect load circuits to the standby side. Let the system go through its entire automatic sequence of operation.

With the generator running and loads powered by generator AC output, turn ON the utility power supply to the transfer switch. The following should occur:

- After about six seconds, the switch should transfer loads back to the utility power source.
- About one minute after retransfer, the engine should shut down.

1.6 ADJUSTING THE REGULATOR (NATURAL GAS ONLY)

Although the generator has been factory set to provide maximum power, it may be necessary in some areas to adjust this setting. Because natural gas has different BTU or power content across the country the engine may not perform as designed.

If experiencing engine problems at high or full load conditions follow these steps. It will require a frequency meter to perform this procedure.

1. Turn off utility power to the main distribution panel in the house. This can be done by switching the service main breaker to the off or open position.
2. Allow the generator to start. Before loading the generator, confirm that the No Load Frequency, with the top open and front panel off, is set to 63-63.5 Hz. Transfer load to emergency circuits.

Section 1 — Post Installation Start-up and Adjustments


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

- Turn on appliances, lights, pumps, etc., that are on the emergency circuits in an attempt to fully load the generator. Be cautious not to overload the generator. Use the following chart as a guide:

| Unit | 120 Volts | 240 Volts |
|-------|------------|-----------|
| 7 kW | 50.0 amps | 25.0 amps |
| 12 kW | 100.0 amps | 50.0 amps |
| 13 kW | 108.3 amps | 54.1 amps |


- When full load has been achieved. Connect a frequency meter to the output lugs of the generator's main line circuit breaker.
- The fuel regulator is fitted with one (7 kW), or two (12 & 15 kW) adjustment screws. While watching the frequency meter, slowly turn the adjustment screws clockwise or counterclockwise one at a time until the highest frequency is read on the meter. Only limited adjustment is available because of the set pin. Under no circumstances should any of the pins be removed (Figures 1.1 and 1.2).

Figure 1.1 — Dual Fuel Regulators



- When the highest frequency is reached maximum power has been set. From this point turn both adjustment screws 1/4 turn counterclockwise. The regulator is now set.

Figure 1.2 — Placement of Regulator



- Turn utility power to the main distribution panel back on. This can be done by switching the service main breaker to the on or closed position. Allow the generator to shut down.

⚠ WARNING ⚠

- ⚠ Do not make any unnecessary adjustments. Factory settings are correct for most applications. However, when making adjustments, be careful to avoid overspeeding the engine.

1.7 RECONFIGURING THE FUEL SYSTEM

◆ 1.7.1 7 KW, 410CC ENGINE


To reconfigure the fuel system from NG to LP, follow these steps (Figure 1.3):

NOTE:

The primary regulator for the propane supply is **NOT INCLUDED** with the generator. A fuel pressure of 11 to 14 inches of water column (0.4 to 0.5 psi) to the fuel inlet of the generator **MUST BE SUPPLIED**.

- Turn off the main gas supply (if connected).
- Open the top and remove the front panel.
- Remove the battery (if installed).
- Disconnect wire #0 and wire #14 from the gas solenoid on top of the demand regulator.
- Remove the carburetor fuel hose from the outlet port of the demand regulator.
- Remove the demand regulator by removing the fastener that retains the regulator mounting bracket.
- Remove the square headed steel pipe plug from outlet port #1 and the brass hose barb fitting from outlet port #2.
- Refit the brass hose barb fitting to outlet port #1 and the square headed steel pipe plug to outlet port #2.

Figure 1.3 – Demand Regulator



9. Reverse procedure steps 1-5 to reinstall demand regulator.
10. Reverse the procedure to convert back to natural gas.

◆ 1.7.2 12KW AND 15KW, V-TWIN ENGINES

To reconfigure the fuel system from NG to LP, follow these steps:

NOTE:

The primary regulator for the propane supply is NOT INCLUDED with the generator. A fuel pressure of 11 to 14 inches of water column (0.4 to 0.5 psi) to the fuel inlet of the generator MUST BE SUPPLIED.

1. Turn off the gas supply. (if connected)
2. Open the top and remove the front panel.
3. Remove the battery. (if installed)
4. Remove the engine air in baffle located on the left-hand side of the battery compartment. Two M6 screws are located on top of the baffle and two M6 screws are located on the inside of the baffle towards the back.
5. Remove the small hose clamp and hose from the fuel regulator. It may be necessary to pry the hose off of the brass fitting using a screwdriver to gently lift up the hose edge.
6. Remove the small brass hose fitting from the regulator casting.
7. Place the small fuel jet, thread side first, into the threaded hole originally occupied by the brass hose fitting (Figure 1.4).
8. Using a short No. 2 Phillips screw driver, thread the small fuel jet into the regulator casting. Do not over tighten.
9. Apply thread sealant to the threads of the hose fitting and replace it into the regulator body.
10. Re-attach the small hose and hose clamp and tighten as necessary.
11. Replace the engine air in baffle using the four M6 screws.
12. Identify both brass adjustment screws on the regulator.


NOTE:

One adjustment screw can be accessed from the front of the unit and the second can be accessed from the back of the unit enclosure by removing the plastic hole plug. The screw can be turned with a long flat blade screwdriver.

13. To adjust the system to run on LP fuel, turn BOTH adjuster screws 1/2 TURN CLOCKWISE. The system should now be set for maximum power and best performance. **DO NOT, UNDER ANY CIRCUMSTANCES, REMOVE THE SET PINS FROM THE REGULATOR HOUSING. THIS WILL VOID THE WARRANTY.**

14. It may be necessary to make minor adjustments to the preset adjustment screw settings to achieve maximum power, particularly at higher altitudes. If experiencing problems with the unit producing maximum power, follow the procedure in Section 1.6 (Adjusting the Fuel Regulator).

Figure 1.4 - Demand Regulator




1.8 ENGINE GOVERNOR ADJUSTMENT

If both AC frequency and voltage are correspondingly high or low, adjust the engine governor as follows:

◆ 1.8.1 7 KW UNITS

1. Loosen the governor clamp bolt (Figures 1.5).
2. Hold the governor lever at its wide open throttle position, and rotate the governor shaft clockwise as far as it will go. Then, tighten the governor lever clamp bolt to 70 inch-pounds (8 N-m).
3. Start the generator; let it stabilize and warm up at no-load.
4. Connect a frequency meter (or high quality multi-meter set to the frequency mode) across the generators AC output leads.
5. Turn the speed adjust nut to obtain a frequency reading of 63 Hertz.

**Figure 1.5 — Engine Governor Adjustment
Single Cylinder Engines**




6. When frequency is correct at no load, check the AC voltage reading. If voltage is incorrect, the voltage regulator may require adjustment.


◆ 1.8.2 12 KW AND 15 KW UNITS

1. Loosen governor clamp bolt (See Figure 1.6).
2. Completely remove the idle spring.
3. With governor arm at wide open throttle position (rotated fully clockwise), rotate governor shaft fully clockwise. Tighten clamp bolt to 84 inch-pounds.
4. Start unit and apply full load. Use full load speed adjust screw (Figure 1.7) to adjust frequency to 58 Hz.
5. Remove load, stop engine, loosen the idle adjust screw and reconnect the idle spring.
6. Push the governor arm to the closed throttle position. Make sure the idle spring does not stretch at all.

**Figure 1.6 — Engine Governor Adjustment
V-Twin Engines**



**Figure 1.7 — Full Load Speed Adjust Screw
V-Twin Engines**




7. Restart the unit.
8. Slowly turn the idle adjust screw to adjust the no-load idle frequency to 63-63.5 Hz (with top open).
9. The governor is now set.

1.9 VOLTAGE REGULATOR ADJUSTMENT

With the frequency between 62-63 Hertz, slowly turn the slotted potentiometer (Figure 1.8) until line voltage reads 247-252 volts.

Figure 1.8 — Voltage Adjustment Potentiometer



NOTE:

The access panel on top of the control panel must be removed to adjust the voltage regulator.

NOTE:

The voltage regulator is housed above the generator's control panel. The regulator maintains a voltage in direct proportion to frequency at a 2-to-1 ratio. For example, at 62 Hertz, line-to-neutral voltage will be 124 volts.

1.10 ADJUSTING GH-410/GT-990 VALVE CLEARANCE

After the first 6 months of operation, adjust the valve clearance in the engine.

Important: If feeling uncomfortable about doing this procedure or the proper tools are not available, please contact a Carrier dealer for service assistance. This step necessary to insure the longest life for the engine.

To adjust valve clearance:

- Make sure the engine is at room temperature.
- Make sure that the spark plug wire is removed from the spark plug and out of the way.


- Remove the four screws attaching the valve cover with a #2 or #3 phillips screwdriver.
- Make sure the piston is at Top Dead Center (TDC) of its compression stroke (both valves closed). To get the piston at TDC, remove the intake screen at the front of the engine to gain access to the flywheel nut. Use a large socket and socket wrench to rotate the nut and hence the engine. While watching the piston through the spark plug hole. The piston should move up and down. The piston is at TDC when it is up as high as it can go.
- Loosen the rocker jam nut. Use an 10mm allen wrench to turn the pivot ball stud while checking clearance between the rocker arm and the valve stem with a feeler gauge. Correct clearance is 0.002-0.004 inch (0.05-0.1 mm).

NOTE:

Hold the rocker arm jam nut in place as the pivot ball stud is turned.

When valve clearance is correct, hold the pivot ball stud in place with the allen wrench and tighten the rocker arm jam nut. Tighten the jam nut to 174 in/lbs. torque. After tightening the jam nut, recheck valve clearance to make sure it did not change.

Figure 1.9 - Valve Clearance Adjustment



- Install new valve cover gasket.
- Re-attach the valve cover.

NOTE:

Start all four screws before tightening or it will not be possible to get all the screws in place. Make sure the valve cover gasket is in place.

- Re-attach the spark plug wire to the spark plug.
- On GT-990, Repeat the process for the other cylinder.

NOTES:

[illegible]




Section 2 — Troubleshooting

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

2.1 TROUBLESHOOTING GUIDE

| PROBLEM | CAUSE | CORRECTION |
|--|---|---|
| The engine will not crank. | <ol style="list-style-type: none"> 1. Fuse blown. 2. Loose, corroded or defective battery cables. 3. Defective starter contactor. (7 kW) 4. Defective starter motor. 5. Dead Battery. | <ol style="list-style-type: none"> 1. Replace 15A fuse in generator control panel. 2. Tighten, clean or replace as necessary. 3. * 4. * 5. Charge or replace battery. |
| The engine cranks but will not start. | <ol style="list-style-type: none"> 1. Out of fuel. 2. Defective fuel solenoid (FS). 3. Open #14 wire from engine control board. 4. Defective spark plug(s). 5. Valve lash out of adjustment. | <ol style="list-style-type: none"> 1. Replenish fuel. 2. * 3. * 4. Clean, re-gap or replace plug(s). 5. * |
| The engine starts hard and runs rough. | <ol style="list-style-type: none"> 1. Air cleaner plugged or damaged. 2. Defective spark plug(s). 3. Fuel Regulator not set. 4. Fuel Pressure incorrect. | <ol style="list-style-type: none"> 1. Check, replace air cleaner. 2. Clean, re-gap or replace plug(s). 3. Set Fuel Regulator. 4. Confirm fuel pressure to regulator is 11-14" water column (0.4-0.5 psi) for LP, and 5-7" water column (0.18-0.25 psi) for natural gas. |
| The Auto/Off/Manual switch is set to OFF, but the engine continues to run. | <ol style="list-style-type: none"> 1. Defective switch. 2. Auto/Off/Manual switch wired incorrectly. 3. Defective control board. | <ol style="list-style-type: none"> 1. * 2. * 3. * |
| There is no AC output from the generator. | <ol style="list-style-type: none"> 1. Main line circuit breaker open. 2. Generator internal failure. | <ol style="list-style-type: none"> 1. Reset circuit breaker to ON (or closed). 2. * |
| There is no transfer to standby after utility source failure. | <ol style="list-style-type: none"> 1. Defective transfer switch coil. 2. Defective transfer relay. 3. Transfer relay circuit open. 4. Defective control logic board. | <ol style="list-style-type: none"> 1. * 2. * 3. * 4. * |
| Unit consumes large amounts of oil. | Break-in procedure not followed (see Section 3.1). | * |


***Contact the nearest Carrier Dealer for assistance.**



3.1 SERVICE SCHEDULE

ATTENTION: It is recommended that all service work be performed by the nearest Carrier Dealer.

| SYSTEM/COMPONENT | PROCEDURE | | | FREQUENCY |
|--|-------------------------------------|--------|-------|---|
| X = Action R = Replace as Necessary * = Notify Dealer if Repair is Needed. | Inspect | Change | Clean | W = Weekly M = Monthly Y = Yearly |
| FUEL | | | | |
| Fuel lines and connections* | X | | | M |
| LUBRICATION | | | | |
| Oil level | X | | | M |
| Oil | | X | | AFTER BREAK-IN, AND Y |
| Oil filter | | X | | AFTER BREAK-IN, AND Y |
| COOLING | | | | |
| Enclosure louvers | X | | X | W |
| BATTERY | | | | |
| Remove corrosion, ensure dryness | X | | X | M |
| Clean and tighten battery terminals | X | | X | M |
| Check charge state | X | R | | EVERY 6 M |
| Electrolyte level (unsealed batteries only)* | X | R | | EVERY 6 M |
| ENGINE AND MOUNTING | | | | |
| Air cleaner | X | R | | Y |
| Spark plug(s) | X | R | | Y |
| GENERAL CONDITION | | | | |
| Vibration, Noise, Leakage, Temperature* | X | | | M |
| COMPLETE TUNE-UP* | TO BE COMPLETED BY A CARRIER DEALER | | | Y |




Section 4 - Electrical Data

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators Wiring Diagram – Single Cylinder – Drawing No. 0E9014



ENGINE WIRING


DIAGRAM KEY

- BA - BRUSH ASSEMBLY
- BCR - BATTERY CHARGE RELAY
- CB1 - MAIN OUTPUT BREAKER
- CB2 - CIRCUIT BREAKER, ALTERNATOR EXCITATION
- CB3 - CIRCUIT BREAKER, EXTERNAL OUTLET, PUSH/PULL
- D - DIODE
- DSW - PCB MOUNTED DIP SWITCH
- FS - FUEL SOLENOID
- F1 - FUSE 15 AMP
- F2 - FUSE 7.5 AMP
- GRD - CONTROL PANEL GROUND
- HTD - HIGH OIL TEMPERATURE SWITCH
- IC - INLINE CONNECTOR
- ICT - INTERCONNECTION TERMINALS
- IM - IGNITION MODULE
- LOP - LOW OIL PRESSURE SWITCH
- SC - STARTER CONTACTOR
- SP - SPARK PLUG
- SW1 - AUTO / OFF / MANUAL SWITCH
- SW2 - SET EXERCISE SWITCH
- SM - STARTER MOTOR
- TB - INSULATED TERMINAL BLOCK
- TX - TRANSFORMER, 16 Vac 56 VA & 16 Vac 1 VA (DUAL SEC.)



Section 4 - Electrical Data
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
Wiring Diagram – Single Cylinder – Drawing No. 0E9014








Section 4 - Electrical Data


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

Electrical Schematic – Single Cylinder – Drawing No. 0E9015



Section 4 - Electrical Data
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
Electrical Schematic – Single Cylinder – Drawing No. 0E9015





Section 4 - Electrical Data


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

Wiring Diagram – V-Twin – Drawing No. 0E9016



ENGINE WIRING


DIAGRAM KEY

- BA - BRUSH ASSEMBLY
- BCR - BATTERY CHARGE RELAY
- CB1 - MAIN OUTPUT BREAKER
- CB2 - CIRCUIT BREAKER, ALTERNATOR EXCITATION
- CB3 - CIRCUIT BREAKER, EXTERNAL OUTLET, PUSH/PULL
- DSW - PCB MOUNTED DIP SWITCH
- FS - FUEL SOLENOID
- F1 - FUSE 15 AMP
- F2 - FUSE 7.5 AMP
- GRD - CONTROL PANEL GROUND
- HTD - HIGH OIL TEMPERATURE SWITCH
- IC - INLINE CONNECTOR
- ICT - INTERCONNECTION TERMINALS
- IM1 - IGNITION MODULE, CYLINDER #1
- IM2 - IGNITION MODULE, CYLINDER #2
- LDP - LOW OIL PRESSURE SWITCH
- SC - STARTER CONTACTOR
- SCR - STARTER CONTACTOR RELAY
- SP1, SP2 - SPARK PLUGS
- SW1 - AUTO / OFF / MANUAL SWITCH
- SW2 - SET EXERCISE SWITCH
- SM - STARTER MOTOR
- TB - INSULATED TERMINAL BLOCK
- TX - TRANSFORMER, 16 Vac 56 VA & 16 Vac 1 VA (DUAL SEC.)



Section 4 - Electrical Data
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
Wiring Diagram – V-Twin – Drawing No. 0E9016






Section 4 - Electrical Data



Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators


Electrical Schematic – V-Twin – Drawing No. 0E9017



Section 4 - Electrical Data

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators Electrical Schematic – V-Twin – Drawing No. 0E9017








Section 4 - Electrical Data


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

Wiring Diagram – 8 Circuit Load Center – Drawing No. 0E7687A



Section 4 - Electrical Data
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
Wiring Diagram – 8 Circuit Load Center – Drawing No. 0E7687A






Section 4 - Electrical Data



Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators


Wiring Diagram — 10 and 12 Circuit Load Center — Drawing No. 0E7687



Section 4 - Electrical Data

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators Wiring Diagram – 10 and 12 Circuit Load Center – Drawing No. 0E7687








Section 4 - Electrical Data


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

Electical Schematic – 8 Circuit Load Center – Drawing No. 0E7815A




Section 4 - Electrical Data
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
Electical Schematic – 10 and 12 Circuit Load Center – Drawing No. 0E7815






Section 5 - Exploded Views and Parts


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators Enclosure — Drawing No. 0E9161-D



Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
Enclosure — Drawing No. 0E9161-D




| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|-------------------------------------|------|------------|------|---|
| 1 | 0C6140 | 1 | ASSEMBLY, ENCLOSURE BASE | 47 | 047411 | 6 | SCREW HHC M6-1.0 X 16 G8.8 |
| | 0D1901 | 1 | ASSEMBLY, ENCLOSURE BASE (7KW) | | 047411 | 4 | SCREW HHC M6-1.0 X 16 G8.8 (7KW) |
| 2 | 0C6735 | 2 | SUPPORT, ROOF FOLDING | 48 | 043116 | 5 | SCREW HHC M6-1.0 X 12 G8.8 |
| 3 | 0F0063 | 1 | ENCLOSURE, FRONT | | 043116 | 6 | SCREW HHC M6-1.0 X 12 G8.8 (7KW) |
| 4 | 0C7062 | 1 | ENCLOSURE, EXHAUST SIDE | 49 | 0D3700 | 26 | NUT, LOCKING FLANGE M6-1.0 |
| | 0C7062A | 1 | ENCLOSURE, EXHAUST SIDE (7KW) | | 0D3700 | 24 | NUT, LOCKING FLANGE M6-1.0 (7KW) |
| 5 | 0E8811 | 1 | ENCLOSURE, SIDE & BACK | 50 | 0D4662 | 11 | SCREW HHTT M8-1.2 X 20 BP |
| | 0E8811A | 1 | ENCLOSURE, SIDE & BACK (7KW) | 51 | 090388 | 36 | SCREW TAPTITE M6-1.0 X 12 BP |
| 6 | 0E9873 | 1 | ENCLOSURE, ROOF | | | 24 | SCREW TAPTITE M6-1.0 X 12 BP (7KW) |
| 7 | 0C7065 | 1 | PANEL, ALTERNATOR DIVIDER | 52 | 092120 | 2 | NUT LOCK TRIC M6 X 1.0 Y/ZNC |
| | 0C7065A | 1 | PANEL, ALTERNATOR DIVIDER (7KW) | 54 | 0D3167 | 1 | GASKET, BATTERY SUPPORT BRACKET |
| 8 | 0C8101A | 1 | PANEL, MUFFLER BOX SIDE | 55 | 0A3328 | 1 | PLUG, PLASTIC 0.593 |
| | 0C8861 | 1 | PANEL, MUFFLER BOX SIDE (7KW) | 56 | 055414 | 1 | LUG SLDLSS #2-#8X17/64 CU |
| 9 | 0C8101B | 1 | COVER, MUFFLER BOX | 57 | 092079 | 1 | SCREW TAPTITE M6-1.0X25 BP |
| | 0C8862 | 1 | COVER, MUFFLER BOX (7KW) | 58 | 0A1658 | 2 | L/WASH SPECIAL 1/4 |
| 10 | 0C8283 | 1 | GASKET, DOOR SEAL | 59 | 0C2937 | 1 | BRACKET, BATTERY HOLD DOWN (7KW) |
| 11 | 0C8284A | 1 | FOAM, BACK ENCLOSURE | 60 | 086729 | 1 | CONTACTOR, STARTER (7KW) |
| 12 | 0C8284B | 1 | FOAM, ROOF ENCLOSURE | 61 | 0388040AJ0 | 1 | CABLE, #6 RED BATTERY 38.5" |
| 13 | 0C8284C | 1 | FOAM, FRONT ENCLOSURE | 62 | 022127 | 2 | NUT HEX 1/4-20 STEEL (7KW) |
| 14 | 0C8285 | 1 | BRACKET, BATTERY SUPPORT | 63 | 022129 | 6 | WASHER LOCK 5/16 |
| 15 | 0C8899A | 1 | PAD, 24"X48" W/ MOUNTING HOLES | | 022129 | 7 | WASHER LOCK 5/16 (7KW) |
| 16 | 0D1128 | 1 | PANEL, ENGINE DIVIDER | 64 | 074908 | 8 | SCREW TAPTITE M5-0.8 X 10 BP |
| | 0D1128A | 1 | PANEL, ENGINE DIVIDER (7KW) | 65 | 0D2346 | 1 | HARNESS, ENGINE |
| 17 | 0E4244 | 1 | BAFFLE, INTAKE | | 0D2345 | 1 | HARNESS, ENGINE (7KW) |
| | 0D1605A | 1 | BAFFLE, INTAKE (7KW) | 66 | 023484F | 1 | BUSHING, SNAP SB-1000-12 |
| 18 | 0D1606 | 1 | HOUSING, FAN | 67 | 022142 | 1 | SCREW HHC 5/16-18 X 3/4 G5 (7KW) |
| | 0D5264 | 1 | BAFFLE, EXHAUST (7KW) | 68 | 0A7836 | 2 | RIVET, 1/8" X 0.126" - 0.375" LSH POP |
| 19 | 0D1839 | 2 | BRACKET, TOP SUPPORT | 69 | 0A8475 | 2 | L/WASH SPECIAL #10 |
| 20 | 0D1840 | 2 | BRACKET, BOTTOM SUPPORT | 70 | 0912970069 | 1 | ASSEMBLY, ROOF / DOOR GROUND WIRE |
| 21 | 0D2425 | 1 | DUCT, BASE AIR | | | 2 | ASSEMBLY, ROOF / DOOR GROUND WIRE |
| 22 | 0D2588 | 1 | GASKET, FRONT DIVIDER | 71 | 0912970070 | | |
| | 0D2588A | 1 | GASKET, FRONT DIVIDER (7KW) | 72 | 055450 | 2 | PLUG PLASTIC 1.375 |
| 23 | 0D2676 | 1 | COVER, FRONT EXHAUST ENCL. | | 025034 | 1 | PLUG, STEEL 1.0625 (15KW) |
| 24 | 0D2677 | 1 | COVER, BACK EXHAUST ENCL. | 73 | 0E5968 | 11 | GASKET, EXTRUDED TRIM |
| 25 | 0D2979B | 2 | CLOTH, HRDWRE 266.7mm x 146mm | 74 | 0D3701 | 1 | PLATE, "HOT" |
| | 0D2979B | 3 | CLOTH, HRDWRE 266.7mm x 146mm (7KW) | 75 | 0D3472 | 1 | GROMMET 2.75 X 1/16 |
| 26 | 0D2979C | 1 | CLOTH, HRDWRE 543mm x 146mm | 76 | 0C8742 | 1 | EXTERNAL CONNECTION BOX |
| 27 | 0D2979D | 1 | CLOTH, HRDWRE 266.7mm x 387.4mm | 77 | 0C8911 | 1 | POWER BLOCK |
| | 0D2979E | 1 | CLOTH, HARDWARE (7KW) | 78 | 0D8651 | 1 | HARNESS GENERATOR TO EXTERNAL CONNECTION BOX (15KW) |
| 28 | 0E4245 | 1 | FOAM, FRONT INTAKE BAFFLE | | 0D8442 | 1 | HARNESS GENERATOR TO EXTERNAL CONNECTION BOX |
| | 0D3058A | 1 | FOAM, FRONT INTAKE BAFFLE (7KW) | | 0D8652 | 1 | HARNESS GENERATOR TO EXTERNAL CONNECTION BOX (7KW) |
| 29 | 0E4245A | 1 | FOAM, TOP INTAKE BAFFLE | 79 | 036937 | 2 | SCREW PPHM #10-32 X 1 |
| 30 | 0E4245B | 1 | FOAM, BACK INTAKE BAFFLE | 80 | 022152 | 5 | WASHER LOCK #10 |
| | 0D3058C | 1 | FOAM, BACK INTAKE BAFFLE (7KW) | 81 | 051713 | 2 | WASHER FLAT M5 |
| 31 | 0D3057D | 1 | FOAM, BACK ENCL. STRIP | 82 | 022158 | 5 | NUT HEX #10-32 STEEL |
| 32 | 0D3059A | 1 | FOAM, EXHAUST SIDE ENCL END | 83 | 0D3031 | 1 | FUEL LINE, 3/4" OUTDOOR (NOT SHOWN) |
| 33 | 0D3059B | 1 | FOAM, EXHAUST SIDE ENCL FRONT | 84 | 026850 | 1 | WASHER SHAKEPROOF EXT 1/4 STEEL |
| 34 | 0D3059C | 1 | FOAM, EXHAUST FAN HOUSING | 85 | 049813 | 1 | NUT HEX M6-1.0 G8 YELLOW CHROME |
| 35 | 0D7176 | 24 | WASHER, SELF LOCKING | 86 | 0F0164A | 1 | HINGE TYPE A WITH STUDS, SOCKET |
| | | 22 | WASHER, SELF LOCKING (7KW) | 87 | 0F0165A | 1 | HINGE TYPE B WITH STUDS, SOCKET |
| 36 | 0D3059D | 1 | FOAM, FRONT EXHAUST | 89 | 0E2874 | 1 | SCREW HHTR 1/4-20 X 3/4 |
| | | | ENCLOSURE COVER | 90 | 043107 | 4 | SCREW HHC M8-1.25 X 25 |
| 37 | 0D3059E | 1 | FOAM, BACK EXHAUST | 91 | 022145 | 10 | WASHER FLAT 5/16 |
| | | | ENCLOSURE COVER | 92 | 045771 | 4 | NUT HEX M8-1.25 |
| 38 | 0C7781A | 2 | DOOR, PAWL | 93 | 0C3906 | 2 | SELF-ALIGN SCREW M6 HH |
| 39 | 0D3037 | 1 | LATCH, QUARTER TURN LOCKING | 94 | 0E4321 | 1 | PANEL, EXHAUST ALIGNMENT |
| 40 | 0F0164 | 1 | HINGE TYPE A WITH STUDS, PIN | 95 | 0E1330A | 1 | GROMMET, 38.1 CROSS SLIT WITH HOLE |
| 41 | 0F0165 | 1 | HINGE TYPE B WITH STUDS, PIN | 96 | 0E9692 | 1 | BRACKET, REGULATOR MOUNTING |
| 42 | 0D3037A | 1 | LATCH, QUARTER TURN NON-LOCKING | 97 | 042907 | 2 | SCREW HHC M8-1.25 X 16mm |
| 43 | 0A2115 | 4 | WASHER NYLON .250" | | | | |
| 44 | 022097 | 1 | WASHER LOCK M6-1/4" | | | | |
| 46 | 0F0710 | 14 | RIVET POP 0.125" X 0.337" | | | | |




Section 5 - Exploded Views and Parts


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators Control Panel – Drawing No. 0E9162-H



Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
Control Panel – Drawing No. 0E9162-H




| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|---|------|------------|------|--|
| 1 | 0E7886A | 1 | CIRCUIT BREAKER 30A X 2P 240V (7KW) | 27 | 074908 | 4 | SCREW TAPTITE, M5-0.8 x 10 BP |
| | 0E7886E | 1 | CIRCUIT BREAKER 50A X 2P 240V (12KW) | 29 | 082025 | 6 | NUT HEX LOCK M5-0.8 NYLON INSERT |
| | 0E7886F | 1 | CIRCUIT BREAKER 60A X 2P 240V (13KW) | 30 | 0C3910 | 1 | TRANSFORMER |
| | 0E7886G | 1 | CIRCUIT BREAKER 70A X 2P 240V (15KW LP) | 31 | 022507 | 2 | SCREW HHC 1/4"-20 x 1/2" |
| 2 | 0A1801 | 1 | ASSEMBLY, BATTERY CHARGER ENGINE | 32 | 0A9611 | 1 | FUSE 7.55A X AGC5 |
| 3 | 083049 | 1 | ASSEMBLY, POTTED REGULATOR | 33 | 046689 | 1 | BLOCK TERMINAL STRIP 20A 4 X 6 X 1100V |
| 4 | 0C2174 | 1 | RELAY, 12V 25A SPST | 34 | 063617 | 1 | RELAY PANEL 12VDC DPDT 10A 240VAC |
| 5 | 075210A | 1 | BLOCK 1 POSITION | 35 | 075475 | 4 | SCREW PPHM M4-0.7 x 10mm |
| 6 | 0D3062 | 4 | HEX STAND-OFF #6-32 x 3/8" | 36 | 043180 | 2 | WASHER FLAT M4 |
| 7 | 0D8615 | 1 | ASSEMBLY, HOME STANDBY CONTROLLER | 37 | 0E8812 | 1 | COVER, CONTROL PANEL COMPONENT |
| | 0D8615A | 1 | ASSEMBLY, HOME STANDBY CONTROLLER (7KW) | | 0E8895 | 1 | COVER, CONTROL PANEL COMPONENT (7KW) |
| 8 | 032300 | 2 | HOLDER, FUSE | 38 | 092036 | 8 | SCREW PPHMS/LW #6-32 x 1/4" |
| 9 | 022676 | 1 | FUSE, 15AMP X AGC15 | 39 | 045770 | 2 | SCREW HHC M5-0.8 x10mm |
| 10 | 0E4494 | 1 | SWITCH, ROCKER DPDT ON-OFF-ON | 40 | 0E7866 | 1 | COVER, CONTROL PANEL |
| | | | | 41 | 0D3700 | 1 | COVER, CONTROL PANEL (7KW) |
| 11 | 0E7890 | 1 | CIRCUIT BREAKER MOUNTING BRACKET | 42 | 0912970069 | 8 | NUT FLANGE M6-1.0 NYLOK |
| 12 | 023484E | 1 | SNAP BUSHING | | | 1 | ASSEMBLY, ROOF/DOOR GROUND WIRE |
| 13 | 075476 | 4 | SCREW PPHM M4-0.7 x 16mm | 43 | 0E2874 | 1 | SCREW HHTR 1/4"-20 X 3/4" |
| 15 | 0E6480 | 6 | NUT HEX LOCK M4-0.7 NYLON INSERT | 44 | 0A1658 | 2 | WASHER LOCK SPECIAL 1/4" |
| | | | | 45 | 022473 | 3 | WASHER FLAT 1/4"-M6 |
| 17 | 0C1085 | 6 | SCREW PPHM M3-0.5 x 8mm | 46 | 038750 | 1 | SCREW HHC M6-1.0 x 30mm |
| | 0C1085 | 4 | SCREW PPHM M3-0.5 x 8mm (7KW) | 47 | 022097 | 3 | WASHER LOCK M6-1/4" |
| 19 | 054502 | 1 | CIRCUIT BREAKER 3 X 1 ETA 46-500-P | 48 | 049813 | 1 | NUT HEX M6-1.0 |
| | 053623 | 1 | CIRCUIT BREAKER 2.5 X 1 ETA 46-500-P (7KW) | 49 | 031879 | 6 | WASHER FLAT #4 |
| | | | | | 031879 | 4 | WASHER FLAT #4 (7KW) |
| 20 | 0E7870 | 1 | CONTROL, PANEL BOTTOM | 50 | 023897 | 2 | WASHER FLAT #10 |
| | 0E7871 | 1 | CONTROL, PANEL BOTTOM (7KW) | 51 | 0E9056 | 1 | SOCKET, 12VDC ACCESSORY |
| 21 | 075235 | 4 | SCREW HHC M5-0.8 x 30mm | 52 | 0E5840 | 1 | CIRCUIT BREAKER 15A PUSH / PULL MAIN RESET |
| 22 | 0D5240 | 1 | SWITCH, SPST (ON)-ON N/O | 53 | 036903 | 6 | SCREW PPHM #6-32 X 5/8" |
| 23 | 0D9784 | 6 | NUT HEX LOCK M3-0.5 NYLON INSERT | 54 | 0E7833 | 1 | PLATE, WEATHERPROOF GFCI |
| | 0D9784 | 4 | NUT HEX LOCK M3-0.5 NYLON INSERT (7KW) | 55 | 0E4261 | 1 | OUTLET, 15A GFCI DUPLEX |
| 24 | 0D8502 | 1 | NEUTRAL CONNECTOR | 56 | 022985 | 4 | WASHER FLAT #6 |
| 26 | 0E8956 | 1 | HARNESS, CONTROL PANEL (NOT SHOWN) | 57 | 082625 | 4 | NUT LOCK HEX #6-32 NYL INSERT |
| | 0E8957 | 1 | HARNESS, CONTROL PANEL WIRE (NOT SHOWN) (7KW) | 58 | 0E9171 | 1 | GASKET, WEATHERPROOF GFCI |
| | | | | 59 | 04793 | 2 | SCREW PPHM, M3-0.5 X 10MM |




Section 5 - Exploded Views and Parts


**Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
7kW, 8 Circuit Load Center Assembly – Drawing No. 0E7975-B**



Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
7kW, 8 Circuit Load Center Assembly – Drawing No. 0E7975-B




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|-------|--|
| 1 | 0D4801 | 1 | BOX GTS LOAD CENTER |
| 2 | 0D4800 | 1 | COVER, 8 POSITION GTS LOAD CENTER |
| 3 | 0C2237 | 1 | TRANSFER SWITCH HOME STANDBY 100A 2P 250V |
| 3A | 077220 | 1 | COIL UTILITY |
| 3B | 077220A | 1 | COIL STANDBY |
| 3C | 082574 | 1 | INSULATOR-SIDEWALL (NOT SHOWN) |
| 3D | 084464 | 1 | LIMIT SWITCH OPERATION (NOT SHOWN) |
| 4 | 074908 | 8 | SCREW TAPTITE M5-0.8 X 10 BP |
| 5 | 024912 | 1 | SCREW TAPTITE 1/4-20 X 5/8 BP |
| 6 | 0A1658 | 1 | LOCK WASHER, SPECIAL-1/4" |
| 7 | 063617 | 1 | RELAY PANEL 12VDC DPDT 10A@240VAC |
| 8 | 0E7889A | 1 | 8 CIRCUIT LOAD CENTER 125A/240V |
| 9 | 0A1495 | 4 | SCREW HHTT M4-0.7 X 10 |
| 10 | 0A1661 | 2 | RIVET POP 0.156" X 0.675" |
| 11 | 022473 | 1 | WASHER FLAT 1/4-M6 |
| 12 | 0D3094 | 1 | HARNESS,GTS TO MAIN PANEL |
| 13 | 0D4684A | 1 | PLATE HARNESS ADAPTER |
| 14 | 0E7900 | 1 | SUBPLATE, LOAD CENTER |
| 15 | 0F4790 | 10.5" | U-CHANNEL |
| 16 | 022152 | 6 | WASHER LOCK #10 |
| 17 | 064526 | 2 | SCREW HWHS #6-25 X 3/8 |
| 18 | 0E6155 | 1 | ARM EXTENDER PIN |
| 19 | 063378 | 4 | HOLDER CABLE TIE |
| 20 | 0A2110 | 4 | SCREW SWAGE 1/4-20 X 1/2 ZINC |
| 21 | 074138 | 2 | LUG QUICK DISCONNECT NI-S 10X45 DEG BRASS / TIN |
| 22 | 036933 | 6 | SCREW PPHM #10-32 X 3/8" |
| 23 | 077033 | 6 | LUG SLDLSS 1/0-#14X9/16 AL/CU |
| 24 | 048850 | 1 | BLOCK TERMINAL 20A 5 X 6 X 1100V |
| 25 | 028739 | 4 | TIE WRAP UL 3.9" X .10" NAT'L |
| 26 | 0D4802 | 1 | HARNESS, GTS TO EXTERNAL CONNECTION BOX |
| 27 | 0D3191 | 1 | COVER, RELAY & TERM BLOCK |
| 28 | 0D3088 | 1 | WIRE HARNESS,GTS LOAD CENTER (NOT SHOWN FOR CLARITY) |
| 29 | 073591 | 2 | FUSE HOLDER |
| 30 | 073590A | 2 | FUSE 5A X BUSS |
| 31 | 040213B | 4 | PCB SUPPORT SNAP-IN 1-3/8" |
| 32 | 0E7888C | 1 | CIRCUIT BREAKER 20A X 1P |
| 33 | 0A7215 | 4 | SCREW SW 1/4-20X5/8 WITH WASHER |
| 34 | 0E7888B | 5 | CIRCUIT BREAKER 15A X 1P |
| 35 | 0E7888A | 1 | CIRCUIT BREAKER 30A X 2P |
| 36 | 0D3320 | 1 | COVER - HARNESS ENTRY |
| 37 | 0E6193 | 1 | BRACKET, ARM EXTENDER |



Section 5 - Exploded Views and Parts


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

12 kW (10 Circuit) and 15 kW (12 Circuit) Load Center Assembly – Drawing No. 0E7973-E



Section 5 - Exploded Views and Parts


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators 12 kW (10 Circuit) and 15 kW (12 Circuit) Load Center Assembly – Drawing No. 0E7973-E




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|-------|--|
| 1 | 0D3086 | 1 | BOX GTS LOAD CENTER |
| 2 | 0D3092 | 1 | COVER, 12 POSITION GTS LOAD CENTER |
| | 0F5211 | 1 | COVER, 10 POSITION GTS LOAD CENTER |
| 3 | 0C2237 | 1 | TRANSFER SWITCH HOME STANDBY 100A 2P 250V |
| 3A | 077220 | 1 | COIL UTILITY |
| 3B | 077220A | 1 | COIL STANDBY |
| 3C | 082574 | 1 | INSULATOR-SIDEWALL (NOT SHOWN) |
| 3D | 084464 | 1 | LIMIT SWITCH OPERATION (NOT SHOWN) |
| 4 | 074908 | 6 | SCREW HHTT M5-0.8 X 10 |
| 5 | 024912 | 1 | SCREW HHTT 1/4-20 X 5/8 |
| 6 | 0A1658 | 1 | LOCK WASHER, SPECIAL-1/4" |
| 7 | 063617 | 1 | RELAY PANEL 12VDC DPDT 10A@240VAC |
| 8 | 0E7889 | 1 | 12 CIRCUIT LOAD CENTER 125A/240V |
| 9 | 0A1495 | 4 | SCREW HHTT M4-0.7 X 10 |
| 10 | 0A1661 | 2 | RIVET POP .156" X .675" |
| 11 | 022473 | 1 | WASHER FLAT 1/4-M6 ZINC |
| 12 | 055450 | 1 | PLUG PLASTIC 1.375 |
| | 025034 | 1 | PLUG STEEL 1.0625 (15KW) |
| 13 | 0D4684 | 1 | HARNESS ADAPTER PLATE |
| 14 | 0E7900 | 1 | SUBPLATE, LOAD CENTER |
| 15 | 056326 | 10.5" | TRIM VINYL BLACK 1/8"GP |
| 16 | 022152 | 6 | WASHER LOCK #10 |
| 17 | 064526 | 2 | SCREW HWHS #6-25 X 3/8" |
| 18 | 0E6155 | 1 | ARM EXTENDER PIN |
| 19 | 063378 | 4 | HOLDER CABLE TIE |
| 20 | 0D3094 | 1 | HARNESS,GTS TO MAIN PANEL |
| 21 | 074138 | 2 | LUG QUICK DISCONNECT NI-S 10X45 DEG BRASS / TIN |
| 22 | 036933 | 6 | SCREW PPHM #10-32 X 3/8" |
| 23 | 077033 | 6 | LUG SLDLSS 1/0-#14X9/16 AL/CU |
| 24 | 048850 | 1 | BLOCK TERMINAL 20A 5 X 6 X 1100V |
| 25 | 028739 | 4 | TIE WRAP 3.9" X .10" |
| 26 | 0A2110 | 4 | SCREW SWAGE 1/4-20 X 1/2" ZINC |
| 27 | 0D3191 | 1 | COVER, RELAY & TERMINAL BLOCK |
| 28 | 0D3088 | 1 | WIRE HARNESS,GTS LOAD CENTER (NOT SHOWN FOR CLARITY) |
| 29 | 073591 | 2 | FUSE HOLDER |
| 30 | 073590A | 2 | FUSE 5A X BUSS |
| 31 | 040213B | 4 | PCB SUPPORT SNAP-IN 1-3/8" |
| 32 | 0E7888C | 3 | CIRCUIT BREAKER 20A 1P |
| 33 | 0E7888 | 1 | CIRCUIT BREAKER 20A 2P |
| 34 | 0E7888B | 5 | CIRCUIT BREAKER 15A 1P (12 POSITION LOAD CENTER) |
| | 0E7888B | 3 | CIRCUIT BREAKER 15A 1P (10 POSITION LOAD CENTER) |
| 35 | 0E7888A | 1 | CIRCUIT BREAKER 30A 2P |
| 36 | 0D3320 | 1 | COVER - HARNESS ENTRY |
| 37 | 0D3093 | 1 | HARNESS, GTS TO EXT CONN BOX |
| | 0D8597 | 1 | HARNESS, GTS TO EXT CONN BOX (8.5KW) |
| | 0D3926 | 1 | HARNESS, GTS TO EXT CONN BOX (15KW) |
| 38 | 075475 | 2 | SCREW PPHM M4-0.7 X 10 |
| 39 | 0A7215 | 4 | SCREW SW 1/4"-20 X 5/8" WITH WASHER |
| 40 | 0E6193 | 1 | BRACKET, ARM EXTENDER |

Section 5 - Exploded Views and Parts

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GN410 Engine – Drawing No. 0F4716 Page 1




Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GN410 Engine – Drawing No. 0F4716 Page 1




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|---|
| 1 | 0E3221 | 1 | ASSEMBLY, CONNECTING ROD |
| 2 | 0E1466 | 1 | PIN, PISTON D20 |
| 3 | 021533 | 1 | SET, PISTON RING 90MM |
| 4 | 0E2985 | 1 | PISTON, HC |
| 5 | 071983 | 2 | RETAINER, PISTON PIN 20 |
| 6 | 0E8440 | 1 | ASSEMBLY, CRANKSHAFT GH410 SMALL TAPER |
| 7 | 0A7628 | 1 | ARM, GOVERNOR RC45 |
| 8 | 078658 | 1 | PIN, "R" GOVERNOR ARM |
| 9 | 078659 | 2 | WASHER, GOVERNOR ARM THRUST |
| 10 | 088261E | 1 | CRANKCASE, SUBASSEMBLY WITH PLUGS GH410 |
| 11 | 0E3812 | 2 | SEAL, 35 I.D. CRANKSHAFT |
| 12 | 0E6519 | 1 | ASSEMBLY, GOVERNOR GEAR |
| 13 | 078645 | 1 | C-RING, GOVERNOR GEAR RETAINER |
| 14 | 0A7811 | 1 | SPOOL, GOVERNOR- MACHINE |
| 15 | 0A9877 | 1 | ASSEMBLY, CAMSHAFT & GEAR |
| 16 | 076701 | 1 | GASKET , CRANKCASE |
| 17 | 021713B | 1 | GASKET, HEAD 410 |
| 18 | 078691 | 1 | COVER, OIL PRESSURE RELIEF |
| 19 | 0A5771 | 1 | SPRING, OIL RELIEF 360 |
| 20 | 0A5776 | 1 | BALL, DIA 11/32 PRESSURE RELIEF |
| 21 | 076361 | 1 | WASHER, THRUST GOVERNOR GEAR |
| 22 | 0A8898D | 1 | ASSEMBLY, COVER, GEAR TOP CHECK / FILL |
| 23 | 0D2274 | 2 | RETAINER, VALVE SPRING |
| 24 | 0C4391 | 2 | VALVE SPRING LF |
| 25 | 086025 | 1 | SET,GEROTOR 12 THK |
| 26 | 0E3341 | 1 | BALANCER |
| 27 | 021714 | 1 | ASSEMBLY,CYLINDER HEAD SEATS & GUIDES |
| 28 | 086516 | 1 | VALVE, EXHAUST |
| 29 | 086517 | 1 | VALVE, INTAKE |
| 30 | 0D9853B | 2 | PUSH ROD 174.9 |
| 31 | 083897 | 2 | TAPPET |
| 32 | 077158 | 1 | ASSEMBLY, SCREEN OIL PICK-UP |
| 33 | 0C3150 | 1 | GASKET, ROCKER COVER 410 |
| 34 | 072694 | 2 | STUD, D20 PIVOT BALL |
| 35 | 083907 | 2 | ROCKER ARM |
| 36 | 072696 | 2 | NUT, JAM (ROCKER ARM) |
| 37 | 078694 | 1 | PLATE, PUSH ROD GUIDE |
| 38 | 021742 | 4 | SCREW, HHFL M10-1.5 X 105 |
| 39 | 0D6094 | 1 | ASSEMBLY, ROCKER COVER BREATHER |
| 40 | 076329 | 1 | PLUG, OIL FILL PLASTIC |
| 41 | 0E0057 | 1 | O-RING 17.8 I.D. x 2.4 |
| 42 | 0D4788 | 1 | PLUG, STANDARD PIPE 3/8 STEEL SQUARE HEAD |
| 43 | 074908 | 1 | SCREW, TAPTITE M5-0.8 X 10 BP |
| 44 | 086515 | 4 | KEEPER, VALVE SPRING |
| 45 | 078606 | 4 | SCREW & LOCKWASHER M6-1 X 12 |
| 46 | 0A1442 | 8 | SCREW, HHFC M8-1.25 X 42 |
| 47 | 078672 | 1 | SEAL, VALVE STEM D7 |
| 48 | 089673 | 2 | WASHER, VALVE SPRING |
| 49 | 0B2104 | 1 | WASHER, LARGE SPRING |
| 50 | 078699C | 2 | DOWEL, SEAMED SLEEVE |
| 51 | 0A7627 | 1 | SHAFT, GOVERNOR RC55 |
| 52 | 043790A | 1 | BARBED ELBOW 90 3/8NPT X 3/8 LOCKTITE |
| 53 | 088590 | 1 | DOWEL DIA 12 X 18L |
| 54 | 078699B | 1 | DOWEL, SLEEVE SEAMED 12 DIA. |

Section 5 - Exploded Views and Parts

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GN410 Engine – Drawing No. 0F4716 Page 2



Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GN410 Engine – Drawing No. 0F4716 Page 2




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|---------------------------------------|
| 1 | 0C1069 | 5 | SCREW, TAPTITE M6-1.0X8 YELLOW CHROME |
| 2 | 0D2922 | 1 | HOUSING, BLOWER |
| 3 | 0C8435 | 1 | TUBE, DIPSTICK |
| 4 | 0C9997 | 1 | GUARD, FAN |
| 5 | 088434 | 1 | WRAPPER, BOTTOM |
| 6 | 045756 | 11 | SCREW, TAPTITE M6-1X10 YELLOW CHROME |
| 7 | 0C4176A | 1 | WRAPPER, TOP |
| 8 | 0D9004A | 1 | ASSY, STARTER |
| 9 | 059985 | 2 | SCREW, SHC M8-1.25 X 45 G12.9 |
| 10 | 022129 | 3 | WASHER, LOCK M8-5/16 |
| 11 | 0C2458A | 1 | BACKPLATE, L/F D/F |
| 12 | 083512 | 1 | SCREW, TAPTITE M8-1.25 X 16 BP |
| 13 | 0D1401A | 1 | BREATHER TUBE |
| 14 | 091039 | 1 | GASKET, INTAKE ADAPTER |
| 15 | 0C9619 | 1 | ASSEMBLY, PLASTIC CARB |
| 16 | 049811 | 2 | WASHER, FLAT M6 |
| 17 | 022097 | 4 | WASHER, LOCK M6-1/4 |
| 18 | 040945 | 2 | SCREW, SHC M6-1.0 X 20 G12.9 |
| 19 | 086999 | 1 | GASKET,OIL FILTR ADAPTER |
| 20 | 0D5667A | 1 | ADAPTER, OIL FILTER |
| 21 | 049821 | 2 | SCREW, SHC M8-1.25 X 30 G12.9 |
| 22 | 099236 | 1 | SWITCH, OIL 8.0 PSI |
| 23 | 070185D | 1 | OIL FILTER |
| 24 | 082774 | 1 | KEY, WOODRFF 4 X 19D |
| 25 | 091222E | 1 | FLYWHEEL WITH RING GEAR 32DEG. |
| 26 | 067198N | 1 | WASHER,BELV-20 X 2.2 |
| 27 | 067890 | 1 | NUT, HEX - FLYWHEEL |
| 28 | 0E7585 | 1 | SPARKPLUG |
| 29 | 072734 | 1 | ASSEMBLY,GOVERNOR LEVER 12 HP |
| 30 | 072735 | 1 | ROD,GOVERNOR CONTROL. |
| 31 | 0C3978 | 1 | SPRING, ANTI-LASH |
| 32 | 0C6040 | 1 | ASSEMBLY, WIRE |
| 33 | 0D9760 | 1 | ASSEMBLY, IGNITION COIL |
| 34 | 092079 | 2 | SCREW, TAPTITE M6-1.0 X 25 BP |
| 35 | 0F3800 | 1 | SPRING GOVERNOR |
| 36 | 083502 | 1 | BOLT, GOVERNOR ADJUST M5 |
| 37 | 082025 | 1 | NUT HEX LOCK M5-0.8 NYINS ZINC |
| 38 | 0D3083 | 1 | ASSEMBLY, OIL DRAIN HOSE |
| 39 | 0E7887C | 1 | ASSEMBLY, CAP & DIPSTICK |
| 40 | 090072 | 1 | O-RING 9/16 X 3/4 X 3/32 |
| 41 | 075281 | 1 | SWITCH, THERMAL |
| 42 | 022145 | 1 | WASHER FLAT 5/16 - M8 |
| 43 | 0F2094 | 2 | SCREW, M3-0.5 X 6 SEMS |
| 44 | 0C4373 | 1 | SPACER, ENDFRAME |
| 45 | 022717B | 1 | GOMMET |
| 46 | 0F3865 | 1 | SPRING SECONDARY |
| 47 | 0F3855 | 1 | BRACKET SECONDARY GOVERNOR SPRING |
| 48 | 042907 | 1 | SCREW HHC M8-1.25 x 16 |
| 49 | 0D3751 | 1 | SPRING, IDLE RETURNING |
| 50 | 0F3921 | 1 | BARREL GOVERNOR ADJUSTMENT |
| 51 | 0C8493 | 1 | SCREW SHC M5-0.8 x 30 |


Section 5 - Exploded Views and Parts

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GT-990 Engine - Drawing No. F4715 Page 1

| | |
|----|--|
| 66 | 2, 5, 19, 20, 39, 40, 47, 64, 93, 140 |
| 67 | 8, 11, 12, 13 |
| 68 | 4, 5, 6 |
| 69 | 16A, 16B, 17, 18 |
| 70 | 7, 47, 48, 49, 50, 51, 52, 53, 54, 56, 57, 58, 59, 60, 63, 64 |
| 71 | 47, 48, 49, 50, 51, 52, 53, 54, 56, 57, 58, 59, 60, 62, 63, 64 |
| 72 | 27, 28, 29 |
| 73 | 3, 32, 33, 34, 35, 36, 40, 72 |




Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GT-990 Engine - Drawing No. F4715 Page 1




| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|--|------|----------|------|---------------------------------------|
| 1 | 0C5729 | 1 | ASSEMBLY, CRANKCASE HOUSING WITH SLEEVE | 37 | 0C3971C | 1 | ASSEMBLY, DIPSTICK WITH HANDLE |
| 2 | 0E9843 | 1 | SEAL, 38 I.D. CRANKSHAFT | 38 | 0C5305 | 1 | TUBE, DIPSTICK |
| 3 | 090388 | 3 | SCREW, TAPTITE M6-1.0 X 12 YC | 39 | 0C3027 | 1 | O-RING, OIL CLR 3/8 X 1/2 |
| 4 | 0C5372 | 1 | ASSEMBLY, BREATHER | 40 | 0E9842 | 1 | SEAL, 42 I.D. CRANKSHAFT |
| 5 | 0C3005 | 1 | GASKET, BREATHER COVER | 41 | 0C5731 | 1 | ASSEMBLY, HOUSING COVER WITH SLEEVE |
| 6 | 0E3372B | 1 | SEPARATOR, OIL BREATHER | 42 | 0C3006 | 9 | SCREW, HHFC M10-1.5 X 55 |
| 7 | 0D8067A | 1 | ASSEMBLY, HEAD #1 G&S | 43 | 080318 | 8 | SCREW HHFC M6-1.0 X 25 |
| 8 | 071983 | 4 | RETAINER, PISTON PIN 20 | 44 | 093064 | 1 | ASSEMBLY, OIL FILL CAP |
| 9 | 0C2981C | 1 | ROCKER, COVER NO OIL FILL | 45 | 0C8808 | 2 | HOOK, LIFTING |
| 10 | 045761A | 4 | STUD M8-1.25/10MM X 30 G5 ZINC | 46 | 0D2723B | 1 | ROCKER, COVER WITH OIL FILL |
| 11 | 0E2985 | 2 | PISTON, HC | 47 | 0C2979 | 2 | GASKET, VALVE COVER |
| 12 | 021533 | 2 | SET, PISTON RING 90MM | 48 | 086515 | 8 | KEEPER, VALVE SPRING |
| 13 | 0E1466 | 2 | PIN PISTON | 49 | 0D2274 | 4 | RETAINER, VALVE SPRING |
| 14 | 0D4041 | 1 | ASSEMBLY, CAMSHAFT & GEAR | 50 | 0D3867 | 4 | SPRING, VALVE |
| 15 | 0C2983 | 1 | SHAFT, GOVERNOR | 51 | 078672 | 2 | SEAL, VALVE STEM D7 |
| 16 A | 0C2985A | 2 | ROLLER BEARING, GOVERNOR PLATE | 52 | 0C5371 | 4 | WASHER, VALVE SPRING |
| 16 B | 0C2985B | 1 | ROLLER BEARING, GOVERNOR | 53 | 072694 | 4 | STUD, ROCKER ARM PIVOT |
| 17 | 0D4042 | 1 | ASSEMBLY, GOVERNOR GEAR | 54 | 0D3998 | 4 | NUT HEX M8-1.0 G8 YEL CHR |
| 18 | 0A7811 | 1 | SPOOL, GOVERNOR MACHINED | 55 | 0C3027 | 2 | O-RING, 3/8" X 1/2" |
| 19 | 0C2977 | 1 | GASKET, CRANK CASE | 56 | 0D5313 | 4 | ROCKER ARM |
| 20 | 0C5943 | 1 | SEAL, OIL PASSAGE | 57 | 0D6024 | 2 | PLATE, PUSH ROD GUIDE |
| 21 | 0E4357E | 1 | ASSEMBLY, CRANKSHAFT HORIZONTAL DIRECT DRIVE | 58 | 0C2976 | 12 | SCREW HHFC M8-1.25 X 65 |
| 22 | 0E3223 | 2 | ASSEMBLY, CONNECTING ROD | 59 | 086516 | 2 | VALVE, EXHAUST |
| 23 | 0D2157 | 2 | SCREW SHC M6-1.0 X 50 G8.8 | 60 | 0C2229 | 2 | VALVE, INTAKE |
| 24 | 0E6098 | 1 | SCREEN, OIL PICKUP | 61 | 083897 | 4 | TAPPET, SOLID |
| 25 | 0D4123A | 1 | ASSEMBLY, OIL PUMP | 62 | 0D8067B | 1 | ASSEMBLY, HEAD #2 G&S |
| 26 | 078699E | 2 | SLEEVE, SEAMED DOWEL 10 DIA. | 63 | 0D9853D | 4 | PUSHROD, 147 |
| 27 | 0C3011 | 2 | COVER, OIL RELIEF | 64 | 0C2978 | 2 | GASKET, HEAD |
| 28 | 0C3009 | 2 | SPRING, OIL RELIEF | 65 | 043790A | 1 | BARBED ELBOW 90 3/8NPT X 3/8 LOCKTITE |
| 29 | 0C3010 | 2 | BALL, 1/2D OIL RELIEF | 66 | 0D4010 | 1 | KIT GASKET |
| 30 | 093873 | 2 | WASHER, LOCK RIB M6 | 67 | 0D4011 | 1 | KIT PISTON & RINGS |
| 31 | 0C5315 | 1 | GEROTOR, OUTER | 68 | 0D4012 | 1 | KIT BREATHER ASSEMBLY |
| 32 | 0C5998 | 1 | CLAMP, OIL TUBE | 69 | 0D4013 | 1 | KIT GOVERNOR ASSEMBLY |
| 33 | 0D1667 | 1 | ARM, GOVERNOR | 70 | 0D8675A | 1 | KIT HEAD ASSEMBLY CYLINDER 1 |
| 34 | 0C2991 | 2 | E-RING, GOVERNOR ARM | 71 | 0D8675B | 1 | KIT HEAD ASSEMBLY CYLINDER 2 |
| 35 | 0C2988 | 1 | THRUST WASHER, GOVERNOR | 72 | 0D4015 | 1 | KIT OIL RELIEF |
| 36 | 0C2992 | 1 | BUSHING, GOVERNOR LOWER | 73 | 0D4016 | 1 | KIT GEAR COVER |

Section 5 - Exploded Views and Parts


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GT-990/760 Engine - Drawing No. F4715 Page 2



Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
GT-990/760 Engine - Drawing No. F4715 Page 2




| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|--|------|----------|------|--|
| 74 | 0C5136A | 2 | KNOB, AIR CLEANER | 110 | 0F1169A | 1 | HOUSING, BLOWER NG COOLER |
| 75 | 0C3024 | 1 | COVER, AIRBOX NG/LP | 111 | 0D1131 | 1 | GUARD, FAN |
| 76 | 0C3040 | 1 | PRE-CLEANER, | 112 | 045756 | 25 | SCREW TAPTITE M6-1X10 YELLOW CHROME |
| 77 | 0C8127 | 1 | ELEMENT, AIR CLEANER | 113 | 0C9763 | 4 | NUT, GROMMET 1/4 PLUG |
| 78 | 0D8564A | 1 | ASSEMBLY, MIXER/AIRBOX 990 | 114 | 0C3036A | 1 | HOSE, BREATHER |
| | 0D8564B | 1 | ASSEMBLY, MIXER/AIRBOX 760 | 115 | 022145 | 1 | WASHER FLAT 5/16-M8 ZINC |
| 79 | 0D2595 | 4 | SCREW SHOULDER (8MM) M6-1.0 X 18 | 116 | 022129 | 1 | WASHER LOCK M8-5/16 |
| 80 | 0D4417 | 4 | WASHER,RUBBER 1/4" X 1/8" THICK | 117 | 0C3018 | 1 | WRAPPER, UPPER CYLINDER 1 |
| 81 | 0C3025 | 1 | SWITCH, OIL PRESS | 118 | 0C3019 | 1 | WRAPPER, LOWER CYLINDER 1 |
| 82 | 0D3083 | 1 | ASSEMBLY, OIL DRAIN HOSE | 119 | 0D1142A | 1 | WRAPPER, LOWER CYLINDER 2 |
| 83 | 0C7292 | 1 | NIPPLE, 3/4"-16 UNF | 120 | 0D1143 | 1 | WRAPPER, UPPER CYLINDER 2 |
| 84 | 070185D | 1 | OIL FILTER | 121 | 0E6043 | 2 | SCREW TAPTITE M5-0.8 X 8 ZP |
| 85 | 075281 | 1 | SWITCH, THERMAL 284F | 122 | 0F1177 | 1 | ASSEMBLY, GROUND WIRE |
| 86 | 0F2094 | 2 | SCREW M3-0.5 X 6 SEMS | 123 | 0F1338B | 1 | ASSY, IGN COIL W/DIODE NO ADV |
| 87 | 0F1338A | 1 | ASSY, IGN COIL W/DIODE NO ADV | 124 | 022097 | 4 | WASHER LOCK M6-1/4 |
| 88 | 035461A | 2 | BARBED STR 1/4NPT X 3/8 WITH VIBRA SEAL | 125 | 092079 | 4 | SCREW TAPTITE M6-1.0 X 25 BP |
| 89 | 0C7649 | 4 | CLAMP HOSE .38-.87 | 126 | 0E4271 | 1 | STARTER |
| 90 | 0C9806 | 2 | HOSE, 3/8" I.D. X 6" LONG | 127 | 0D4529 | 2 | SPARKPLUG |
| 91 | 0C3026 | 1 | COOLER, OIL | 128 | 022129 | 2 | WASHER LOCK M8-5/16 |
| 92 | 0C9764 | 4 | PLASTITE,1/4-15 X 3/4 | 129 | 061906 | 2 | SCREW HHC M8-1.25 X 85 G8.8 |
| 93 | 0C3043 | 2 | GASKET, MANIFOLD / PORT | 130 | 082774 | 1 | KEY, WOODRUFF 4 X 19D |
| 94 | 0C7694 | 1 | MANIFOLD CYLINDER 2 | 131 | 0E5343 | 1 | NUT HEX LOCK M10-1.50 |
| 95 | 0C7693 | 1 | MANIFOLD CYLINDER 1 | 132 | 0C8468 | 1 | SPRING, ANTI-LASH |
| 96 | 0C3041A | 2 | SLEEVE, RUBBER | 133 | 0C3048 | 1 | ROD, GOVERNOR CONTROL |
| 97 | 070008 | 4 | WASHER FLAT M8 SS | 134 | 0D3754 | 1 | ASSEMBLY, GOVERNOR LEVER |
| 98 | 070006 | 4 | WASHER LOCK M8 SSTL | 135 | 0D3742 | 1 | SPRING, GOVERNOR |
| 99 | 040976 | 4 | SCREW SHC M8-1.25 X 20 G12.9 | 136 | 0C8482 | 1 | ASSEMBLY, GOVERNOR ADJUSTER |
| 100 | 0F1170A | 1 | PLATE, BACKING WITH OIL COOLER | 137 | 0E0486 | 1 | SCREW SHC M10-1.5 X 75 G10.9 |
| 101 | 0E4997 | 1 | GROUND WIRE CONNECTOR | 138 | 0D3743 | 1 | SPRING, GOVERNOR IDLE |
| 102 | 0C3725B | 1 | FLYWHEEL ASSEMBLY | 139 | 0D3705 | 1 | ASSEMBLY, GOVERNOR ADJUSTER BRACKET |
| 103 | 0C3031 | 1 | FAN, NYLON | 140 | 0C2993 | 1 | SEAL, GOVERNOR SHAFT |
| 104 | 0C3032 | 1 | PLATE, FAN | 142 | 045771 | 1 | NUT HEX M8-1.25 G8 |
| 105 | 0A5992 | 2 | WASHER SHAKEPROOF INT M8 SS | 143 | 0D6147 | 7 | SCREW HHFC M6-1.0 X 10mm |
| 106 | 051754 | 2 | SCREW HHC M8-1.25 X 12 G8.8 | 144 | 0E8152 | 1 | O-RING 0.49" I.D. X 0.07" THICK |
| 107 | 0C3033 | 1 | WASHER, 25mm I.D. | | | | |
| 108 | 0C3034 | 1 | NUT,HEX M24 | | | | |
| 109 | 0C8549A | 1 | SNORKEL, AIR INTAKE | | | | |




Section 5 - Exploded Views and Parts


Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators 7 kW Generator - Drawing No. 0D3504-D



Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
7 kW Generator - Drawing No. 0D3504-D




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|------------|---------|--|
| 1 | 0C6934 | 1 | ADAPTER, ENGINE |
| 2 | 0C9935H | 1 | STATOR |
| 3 | 0C9934H | 1 | ROTOR |
| 4 | 0C6043A | 1 | CARRIER, REAR BEARING |
| 5 | 0C8096 | 1 | FAN, 8" CURVED BLADE |
| 6 | 0C9593 | 1 | MUFFLER |
| 7 | 0D3220 | 1 | TAIL PIPE, MUFFLER |
| 8 | 0C8860 | 1 | PANEL, MUFFLER BASE |
| 9 | 031971 | 1 | BEARING #6205-2RS-C3 |
| 10 | 0C3168 | 3 | 5/16 SPECIAL L/WASH |
| 11 | 056147 | 1 | BOLT ROTOR HHCS 5/16"-24 X 13-1/2" G5 |
| 12 | 0D1847 | 4 | BOLT STATOR HHCS M8-1.25 x 305mm |
| 13 | 0C7038C | 1 | BRACKET, ALTERNATOR MOUNTING |
| 14 | 0D1647 | 1 | DUCT, ALTERNATOR AIR |
| 15 | 0D2558 | 1 | GASKET, ALTERNATOR AIR DUCT |
| 16 | 0C7038B | 1 | BRACKET, ENGINE MOUNTING |
| 17 | 0C7758 | 4 | RUBBER MOUNT |
| 18 | 0388050AEO | 1 | CABLE, #6 40" BLACK BATTERY |
| 19 | 0C2417A | 1 | EARTH STRAP 3/8X 3/8 |
| 20 | 082121C | 1 | CLIP-J VINYL COAT .625 ID |
| 21 | 066386 | 1 | ASSEMBLY BRUSH HOLDER |
| 22 | 029451 | 1.8 FT | TAPE ELEC UL FOAM 1/8 X 1/2 |
| 23 | 049451 | 1 | WASHER FLAT .406ID X 1.62OD |
| 24 | 022237 | 4 | WASHER LOCK 3/8 |
| 25 | 022511 | 4 | BOLT HHC 3/8-16 X 1-1/4 G5 |
| 26 | 022131 | 4 | WASHER FLAT 3/8 ZINC |
| 27 | 039287 | 4 | SCREW HHC M8-1.25 X 45 G8.8 |
| 28 | 022145 | 12 | WASHER FLAT 5/16 ZINC |
| 29 | 049820 | 4 | NUT LOCK HEX M8-1.25 NYL INSRT |
| 30 | 090388 | 3 | SCREW TAP M6-1.0X12 BP |
| 31 | 022129 | 13 | WASHER LOCK M8-5/16 |
| 32 | 022259 | 8 | NUT HEX 5/16-18 STEEL |
| 33 | 059637 | 2 | SCREW TAPTITE 3/8-16X 3/4" BP |
| 34 | 048031K | 3 | BAND, HOSE CLAMP 35.05 DIA. |
| 35 | 0C9592 | 1 | BELLOWS |
| 36 | 057822 | 2 | CLAMP HOSE #8 .53 - 1.00 |
| 37 | 040976 | 2 | SCREW SHC M8-1.25 X 20 G12.9 |
| 38 | 0C2824 | 1 | SCREW TAPR #10-32 X 9/16 |
| 39 | 025145 | 1 | U-BOLT 5/16"-18 X 1.25" W/ SADDLE |
| 40 | 090239 | 1 | GASKET, EXHAUST |
| 41 | 0C6989 | 1 | STINGER, ENGINE AIR IN |
| 42 | 0D1214 | 1 | BASE, AIR CLEANER |
| 43 | 0C8127 | 1 | ELEMENT, AIR CLEANER |
| 44 | 0C3024 | 1 | COVER, AIR CLEANER NG/LP |
| 45 | 0D2273 | 1 | TUBE, 1.25"O.D. x 20Ga. x 12.125" LONG |
| 46 | 055934N | 1 | CLAMP VINYL 1.31 X .281 Z |
| 47 | 074994 | 1.25 FT | HOSE 1/2ID PETROLEUM |
| 48 | 0C5136A | 2 | KNOB, AIR CLEANER |
| 49 | 074906 | 4 | SCREW TAPTITE M6-1 X 20 BP |
| 50 | 022473 | 4 | WASHER FLAT 1/4 ZINC |
| 51 | 0D4662 | 6 | SCREW HHTT M8-1.2 X 20 BP |
| 52 | 0C8290 | 1 | GASKET, PANEL |
| 53 | 066849 | 2 | SCREW HHTT M5-0.8 X 16 |




Section 5 - Exploded Views and Parts

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators


12 kW and 15 kW Generator - Drawing No. OD3417-J



Section 5 - Exploded Views and Parts
Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators
12 kW and 15 kW Generator - Drawing No. 0D3417-J




| ITEM | PART NO. | QTY. | DESCRIPTION |
|------|------------|---------|-------------------------------------|
| 1 | 0C6934 | 1 | ADAPTER, ENGINE |
| 2 | 0C7930 | 1 | STATOR 12KW |
| 0 | D2359 | | STATOR 13KW / 15KW |
| 3 | 0C7944 | 1 | ROTOR 12KW |
| | 0D2356 | | ROTOR 13KW / 15KW |
| 4 | 0C6043 | 1 | CARRIER, REAR BEARING |
| 5 | 0D2336 | 1 | FAN, 12" CURVED BLADE |
| 6 | 0D6634 | 1 | MUFFLER |
| 7 | 0D3220 | 1 | TAIL PIPE, MUFFLER |
| 8 | 0C8101 | 1 | PANEL, MUFFLER BASE |
| 9 | 056482 | 1 | BEARING 1.1811-2.8346 |
| 10 | 0C3168 | 3 | 5/16 SPECIAL LOCK WASHER |
| 11 | 0D1838 | 1 | BOLT, HHCS 3/8"-24 x 15.50" |
| 12 | 0D1846 | 4 | BOLT, HHCS M8-1.25 x 345mm |
| 13 | 0C7038 | 1 | BRACKET, ALTERNATOR MOUNTING |
| 14 | 0D1609 | 1 | DUCT, ALTERNATOR AIR |
| 15 | 0D2559 | 1 | GASKET, ALTERNATOR AIR DUCT |
| 16 | 0C7038A | 1 | BRACKET, ENGINE MOUNTING |
| 17 | 0C7758 | 4 | RUBBER MOUNT |
| 18 | 0388050AD0 | 1 | CABLE, #6 48" BLACK BATTERY |
| 19 | 0C2417A | 1 | EARTH STRAP 3/8X 3/8 |
| 20 | 082121C | 1 | CLIP-J, VYNL COAT 0.625" ID |
| 21 | 066386 | 1 | ASSEMBLY BRUSH HOLDER |
| 22 | 029451 | 2.6 FT | TAPE ELEC UL FOAM 1/8 X 1/2 |
| 23 | 049451 | 1 | WASHER FLAT .406ID X 1.62OD |
| 24 | 022237 | 5 | WASHER LOCK 3/8 |
| 25 | 022511 | 4 | SCREW HHC 3/8-16 X 1-1/4 G5 |
| 26 | 022131 | 4 | WASHER FLAT 3/8 ZINC |
| 27 | 051731 | 4 | SCREW HHC M8-1.25 X 50 G8.8 |
| 28 | 022145 | 12 | WASHER FLAT 5/16 ZINC |
| 29 | 049820 | 4 | NUT LOCK HEX M8-1.25 NYL INSERT |
| 30 | 045756 | 2 | SCREW TAPTITE M6-1.0X10 BP |
| 31 | 022129 | 10 | WASHER LOCK M8-5/16 |
| 32 | 022259 | 8 | NUT HEX 5/16-18 STEEL |
| 33 | 059637 | 2 | SCREW TAPTITE 3/8-16 X 3/4 BP |
| 34 | 0D4662 | 4 | SCREW 5/16-18X3/4" HH THD ROLL |
| 35 | 074994 | 3 FT | HOSE RES 1/2 LP GAS |
| 36 | 057822 | 4 | CLAMP HOSE #8 .53 - 1.00 |
| 37 | 0F0462 | 4 | NUT HEX W/TOOTH WSHR M8-1.25 |
| 38 | 0C2824 | 1 | SCREW TAP-R #10-32 x 9/16 |
| 39 | 025145 | 1 | U-BOLT 5/16"-18 X 1.25" WITH SADDLE |
| 40 | 0C4138 | 2 | GASKET, EXHAUST PORT |
| 41 | 048031C | 2 | CLAMP HOSE BAND 1/4" |
| 42 | 030340 | 1.33 FT | HOSE 1/4 ID SAE 30R7 |
| 43 | 066849 | 2 | SCREW HHTT M5-0.8 X 16 |



Section 5 - Exploded Views and Parts

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators Gas Regulator - Drawing No. 0D8720-E





| ITEM | PART NO. | QTY. | DESCRIPTION | ITEM | PART NO. | QTY. | DESCRIPTION |
|------|----------|------|---------------------------------|------|----------|------|--|
| 1 | 0D5694 | 1 | CASTING, TWIN REGULATOR HOUSING | 20 | 0C5762 | 2 | COVER, TWIN REGULATOR |
| 2 | 0F3154 | 1 | SOLENOID COIL, 12VDC | 21 | 045764 | 16 | SCREW, TAPTITE M4X8 BP |
| 3 | 0C4647 | 1 | GASKET , SOLENOID | 22 | 0C6731 | 2 | RIVET, POP .118 X .125 |
| 4 | 0D4166 | 1 | PLUNGER, LP REGULATOR ASSEMBLY | 23 | 0C6067 | 2 | SUPPORT, DIAPHRAGM |
| 5 | 0C6070 | 1 | SPRING-SOLENOID, PLUNGER | 24 | 0C4706 | 2 | DIAPHRAGM, TWIN REGULATOR |
| 8 | 0F4795 | 4 | SCREW PPHM SEMS M4-0.7 X 10 | 25 | 0C6068 | 2 | CAP, DIAPHRAGM SUPPORT |
| 9 | 0C5760E | 1 | JET, GN 410 ENGINE LP (7KW) | 26 | 0C4643A | 2 | INLET, TWIN REGULATOR 11.11 DIA. |
| 10 | 0C6606 | 2* | BARBED STRAIGHT 1/2NPT x 1/2 | 27 | 026073 | 1 | PLUG, STANDARD PIPE 1/8" STEEL SQUARE HEAD |
| 11 | 097934 | 2* | O-RING, CHECK VALVE | | 026073 | 2 | PLUG, STANDARD PIPE 1/8" STEEL SQUARE HEAD (7KW) |
| 12 | 0C4645 | 2* | ADJUSTER SCREW, TWIN REGULATOR | 28 | 0A4032 | 2* | PIN, LIMITED ADJUSTMENT |
| 13 | 0C5761 | 2 | LEVER, REGULATOR | 29 | 0D3308 | 4 | WASHER, FLAT M3 X 10mm O.D. |
| 14 | 0C5968 | 2 | SUPPORT, INLET SEAL | 30 | 024310 | 1 | PLUG, STANDARD PIPE 1/2" STEEL SQUARE HEAD (7KW) |
| 15 | 0C6066 | 2 | SEAL, INLET | 31 | 028414A | 1 | BARBED STRAIGHT 1/8"NPT X 1/4" |
| 16 | 0C5759 | 2 | PIN, PIVOT ARM | 32 | 0D5698A | 1 | JET IDLE PRIMER PHILLIPS HD (V-TWIN ONLY) |
| 17 | 0C5764 | 2 | SPRING, REGULATOR | 37 | 0D3973 | 1 | PLUG, EXPANSION 16mm |
| | 0C5764A | 2 | SPRING, REGULATOR (7KW) | | | | |
| 18 | 070728 | 4 | SCREW, PFHMS M3-0.5 x 5 | | | | |
| 19 | 0C6069 | 2 | GASKET, DIAPHRAGM | | | | |

* A QUANTITY OF 1 IS TO BE USED ON 7KW HOME STANDBY

Section 6 - Unit Dimensions Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators Installation Drawing No. 0D3739-B

INSTALLATION



**ALL DIMENSIONS IN:
MILLIMETERS [INCHES]

NOTES

Section 7 - Notes

Carrier Air-cooled 7 kW, 12 kW and 15 kW Generators

This image shows a full page of blank white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page, providing a template for writing or drawing. There are no margins, text, or other markings present.

This image shows a full page of blank white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page, typical of notebook paper or a document template. There are no margins, text, or other markings present.

