FUJIFILM

BL03401-103

DIGITAL CAMERA
FINEPIX S6800 Series
FINEPIX S6700 Series
FINEPIX S6600 Series

Owner's Manual

Thank you for your purchase of this product. This manual describes how to use your FUJIFILM digital camera and the supplied software. Be sure that you have read and understood its contents and the warnings in "For Your Safety" (III) before using the camera.



For information on related products, visit our website at http://www.fujifilm.com/products/digital_cameras/index.html









Before You Begin

First Steps

Basic Photography and Playback

More on Photography

More on Playback

Movies

Connections

Menus

Technical Notes

Troubleshooting

Appendix

IMPORTANT SAFETY INSTRUCTIONS

- · Read Instructions: All the safety and operating instructions should be read before the appliance is operated
- · Retain Instructions: The safety and operating instructions should be retained for future reference.
- · Heed Warnings: All warnings on the appliance and in the operating instructions should be adhered to.
- · Follow Instructions: All operating and use instructions should be followed.

Installation

Power Sources: This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization: This video product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the This video product should never be An polarized plug.

Alternate Warnings: This product is equipped with a 3-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.

Overloading: Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock

Ventilation: Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the video product and to protect it from overheating, and these openings must not be blocked or covered.

The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface.

This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

placed near or over a radiator or heat

Attachments: Do not use attachments not recommended by the video product manufacturer as they may cause hazards

Water and Moisture: Do not use this video product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool. and the like.

Power-Cord Protection: Power-Supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

Accessories: Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

appliance and cart combination should be moved with care. Quick stops, excessive force. and uneven sur-



faces may cause the appliance and cart combination to overturn

Antennas

Outdoor Antenna Grounding: If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Flectrical Code. ANSI/NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna-discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the arounding electrode.

Power Lines: An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE



Use

Cleaning: Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Object and Liquid Entry: Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

Lightning: For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

Service

Servicing: Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service: Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

When the power-supply cord or plug is damaged.

If liquid has been spilled, or objects have fallen into the video product.

If the video product has been exposed to rain or water.

If the video product has been

dropped or the cabinet has been damaged.

If the video product does not operate normally be following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.

When the video product exhibits a distinct change in performance - this indicates a need for service

Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

Safety Check: Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

Be sure to read this notes before using

Safety Notes

- Make sure that you use your camera correctly. Read these Safety Notes and your Owner's Manual carefully before use.
- After reading these Safety Notes, store them in a safe place.

About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.



This icon indicates that death or serious injury can result if the information is ignored.



This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the information which is to be observed.



Triangular icons tell you that this information requires attention ("important").



Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").



Filled circles with an exclamation mark tell you an action that must be performed ("Required").

/ WARNING



If a problem arises, turn the camera off, remove the battery, disconnect and unplug the AC power adapter.

Continued use of the camera when it is emitting smoke, is emitting any unusual odor, or is in any other abnormal state can cause a fire from power socket.

· Contact your FUJIFILM dealer.

♠ WARNING

Do not allow water or foreign objects to enter the camera.



If water or foreign objects get inside the camera, turn the camera off, remove the battery and disconnect and unplug the AC power adapter.

Continued use of the camera can cause a fire or electric shock.

· Contact your FUJIFILM dealer.



Do not use the camera in the bathroom or shower.

the bathroom or shower.

Do not use in This can cause a fire or electric shock.



Never attempt to disassemble or modify (never open the case).

Failure to observe this precaution can cause fire or electric shock.



Should the case break open as the result of a fall or other accident, do not touch the exposed parts.

Do not touch internal parts Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.



Do not change, heat or unduly twist or pull the connection cord and do not place heavy objects on the connection cord.

These actions could damage the cord and cause a fire or electric shock.

If the cord is damaged, contact your FUJIFILM dealer.



Do not place the camera on an unstable surface.

This can cause the camera to fall or tip over and cause injury.



Never attempt to take pictures while in motion.

Do not use the camera while you are walking or driving a vehicle. This can result in you falling down or being involved in a traffic accident.



Do not touch any metal parts of the camera during a thunderstorm.

This can cause an electric shock due to induced current from the lightning discharge.



Do not use the battery except as specified.

Load the battery as aligned with the indicator.

WARNING



Do not heat, change or take apart the battery. Do not drop or subject the battery to impacts. Do not store the battery with metallic products. Do not use chargers other than the specified model to charge the battery.

Any of these actions can cause the battery to burst or leak and cause fire or injury as a result.




Use only the battery or AC power adapters specified for use with this camera. Do not use voltages other than the power supply voltage shown.





If the battery leaks and fluid gets in contact with your eyes, skin or clothing. Flush the affected area with clean water and seek medical attention or call an emergency number right away.





batteries. Using the charger to charge conventional batteries or other types of rechargeable batteries can cause the battery to leak fluid. overheat or burst.



Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.



Do not use in the presence of flammable objects, explosive gases, or dust.



When carrying the battery, install it in a digital camera or keep it in the hard case. When storing the battery, keep it in the hard case. When discarding, cover the battery terminals with insulation tape.

Contact with other metallic objects or battery could cause the battery to ignite or burst.

Keep Memory Cards out of the reach of small children.



Because Memory Cards are small, they can be swallowed by children. Be sure to store Memory Cards out of the reach of small children. If a child swallows a Memory Card, seek medical attention or call an emergency number.

CAUTION



Do not use this camera in locations affected by oil fumes, steam, humidity or

This can cause a fire or electric shock.

CAUTION




Do not leave this camera in places subject to extremely high temperatures. Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire.



Keep out of the reach of small children. This product could cause injury in the hands of a child.



Do not place heavy objects on the camera.



Do not move the camera while the AC power adapter is still connected. Do not



pull on the connection cord to disconnect the AC power adapter. This can damage the power cord or cables and cause a fire or electric shock.



Do not use the AC power adapter when the plug is damaged or the plug socket connection is loose.

This could cause a fire or electric shock.



Do not cover or wrap the camera or the AC power adapter in a cloth or blanket. This can cause heat to build up and distort the casing or cause a fire.




When you are cleaning the camera or you do not plan to use the camera for an extended period, remove the battery and disconnect and unplug the AC power adapter.

Failure to do so can cause a fire or electric shock.



When charging ends, unplug the charger from the power socket.





Using a flash too close to a person's eyes may temporarily affect the eyesight. Take particular care when photographing infants and young chil-



When a memory card is removed, the card could come out of the slot too quickly. Use your finger to hold it and gently release the card.

Request regular internal testing and cleaning for your camera.



Build-up of dust in your camera can cause a fire or electric shock. · Contact your FUJIFILM dealer to request internal cleaning every 2 vears.

· Please note this is not a free of charge service.



Remove your fingers from the flash window before the flash fires. Failure to observe this precaution could result in burns.



Keep the flash window clean and do not use the flash if the window is obstructed. Failure to observe these precautions could cause smoke or discoloration.

Power Supply and Battery

* Confirm your battery type before reading the following descriptions.

The following explains proper use of batteries and how to prolong their life. Incorrect use of batteries can cause shorter battery life, as well as leakage, excessive heat, fire or explosion.

1 Camera uses the Rechargeable Lithium-ion Battery

- * When shipped, the battery is not fully charged. Always charge the battery before using it.
- * When carrying the battery, install it in a digital camera or keep it in the soft case

■ Battery Features

- · The battery gradually loses its charge even when not used. Use a battery that has been charged recently (in the last day or two) to take pictures.
- · To maximize the life of the battery. turn the camera off as quickly as possible when it is not being used.
- . The number of available frames will be lower in cold locations or at low temperatures. Take along a spare fully charged battery. You can also increase the amount of power produced by putting the battery in your pocket or another warm place to heat it and then loading it into the camera just before you take a picture.

If you are using a heating pad, take **Battery Life** care not to place the battery directly against the pad. The camera may not operate if you use a depleted battery in cold conditions.

■ Charging the Battery

- · You can charge the battery using the battery charger (included).
- The battery can be charged tween 0°C and +40°C (+32°F and +104°F). Refer to the Owner's Manual for the time of charging battery.
- You should charge the battery at an ambient temperature between +10°C and +35°C (+50°F and +95°F). If you charge the battery at a temperature outside this range, charging takes longer because the performance of the battery is impaired.
- You cannot charge the battery at temperatures of 0°C (+32°F) or below.
- · The Rechargeable Lithium-ion Battery does not need to be fully discharged or exhausted flat before being charged.
- · The battery may feel warm after it has been charged or immediately after being used. This is perfectly normal
- · Do not recharge a fully charged battery.

At normal temperatures, the battery can be used at least 300 times. If the time for which the battery . Do not expose the battery to waprovides power shortens markedly, this indicates that the battery has . Always keep the battery terminals reached the end of its effective life and should be replaced.

■ Notes on storage

- at ambient temperatures be- If a battery is stored for long periods while charged, the performance of the battery can be impaired. If the battery will not be used for some time, run the battery out before storing it.
 - · If you do not intend to use the camera for a long period of time, remove the battery from the cam-
 - · Store the battery in a cool place.
 - The battery should be stored in a dry location with an ambient temperature between +15°C and +25°C (+59°F and +77°F).
 - Do not leave the battery in hot or extremely cold places.

■ Handling the Battery Cautions for Your Safety:

· Do not carry or store battery with metal objects such as necklaces or hairpins.

- · Do not heat the battery or throw it into a fire.
- · Do not attempt to take apart or change the battery.
- · Do not recharge the battery with chargers other those specified.

- Dispose of used battery promptly.
- · Do not drop the battery or otherwise subject it to strong impacts.
- clean
- Do not store batteries in hot places. Also, if you use the battery for a long period, the camera body and the battery itself will become warm. This is normal. Use the AC power adapter if you are taking pictures or viewing images for a long period of time.

2 Camera uses AA Alkaline, Rechargeable Ni-MH (nickel-metal hydride) or AA lithium batteries

* For details on the batteries that you can use, refer to the Owner's Manual of your camera.

■ Cautions for Using Battery

- · Do not heat the batteries or throw them into a fire.
- · Do not carry or store batteries with metal objects such as necklaces or hairpins.
- · Do not expose the batteries to water, and keep batteries from getting wet or stored in moist locations.
- · Do not attempt to take apart or change the batteries, including battery casings.
- · Do not subject the batteries to strong impacts.
- · Do not use batteries that are leaking, deformed, discolored.

- · Do not store batteries in warm or humid places.
- · Keep the batteries out of reach of babies and small children.
- Make sure that the battery polarity (⊕ and ⊖) is correct. . Do not use new with used batter-
- ies. Do not use charged and discharged batteries together.
- · Do not use different types or brands of batteries at the same time
- · If you do not intend to use the camera for a long period of time, remove the batteries from the camera. Note if the camera is left **Solution** Using the AA-size Ni-MH batteries with the batteries removed, the time and date settings are cleared.
- · The batteries feel warm right after being used. Before removing the batteries, turn the camera off and wait for the batteries to cool down.
- · Since batteries do not work well in cold weather or locations, warm the batteries by placing them inside your garments before use. Batteries do not work well when cold. They will work again when the temperature returns to normal.
- · Soil (such as fingerprints) on the battery terminals makes the batteries charge less reducing the number of images. Carefully wipe the battery terminals with a soft dry cloth before loading.



If any liquid at all leaks from the batteries, wipe the battery compartment thoroughly and then load new batteries.



If any battery fluid comes into contact with your hands or clothing, flush the area thoroughly with water. Note that battery fluid can cause loss of eyesight if it gets into your eyes. If this occurs, do not rub your eyes. Flush the fluid out with clean water and contact your physician for treatment.

correctly

· Ni-MH batteries left unused in storage for long periods can become "deactivated". Also, repeatedly charging Ni-MH batteries that are only partially discharged can cause them to suffer from the "memory effect". Ni-MH batteries that are "deactivated" or affected by "memory" suffer from the problem of only providing power for a short time after being charged. To prevent this problem, discharge and recharge them several times using the camera's "Discharging rechargeable batteries" function. Deactivation and memory are specific to Ni-MH batteries and are not in fact battery faults.

See Owner's Manual for the procedure for "Discharging rechargeable batteries".

(?) CAUTION

Do not use the "Discharging rechargeable batteries" function when alkaline batteries being used.

- · To charge Ni-MH batteries, use the guick battery charger (sold separately). Refer to the instructions supplied with the charger to make sure that the charger is used correctly.
- · Do not use the battery charger to charge other batteries.
- · Note that the batteries feel warm after being charged.
- · Due to the way the camera is constructed, a small amount of current is used even when the camera is turned off. Note in particular that leaving Ni-MH batteries in the camera for a long period will overdischarge the batteries and may render them unusable even after recharging.
- Ni-MH batteries will self-discharge even when not used, and the time for which they can be used may be shortened as a result.
- · Ni-MH batteries will deteriorate rapidly if over-discharged (e.g. by discharging the batteries in a flashlight). Use the "Discharging rechargeable batteries" function provided in the camera to discharge the batteries.

· Ni-MH batteries have a limited service life. If a battery can only be used for a short time even after repeated discharge-charge cycles, it may have reached the end of its service life.

■ Disposing of Batteries

· When disposing of batteries, do so in accordance with your local waste disposal regulations.

3 Notes on both models (1, 2)

■ AC Power Adapter

Always use the AC Power Adapter with the camera. The use of an AC Power adapter other than FUJIFII M. AC Power Adapter can be damaged to your digital camera.

For details on the AC power adapter, refer to the Owner's Manual of your camera.

- · Use the AC power adapter for indoor use only.
- · Plug the connection cord plug securely into the DC input terminal.
- · Turn off the FUJIFILM Digital camera before disconnecting the cord from the DC input terminal. To disconnect, pull out the plug gently. Do not pull on the cord.
- · Do not use the AC power adapter with any device other than your camera.
- · During use, the AC power adapter will become hot to the touch. This is normal.

- adapter. Doing so could be dangerous.
- in a hot and humid place.
- adapter to strong shocks.
- humming. This is normal.
- · If used near a radio, the AC power adapter may cause static. If this happens, move the camera away from the radio.

Before Using the Camera

Do not aim the camera at extremely bright light sources, such as the sun in a cloudless sky. Failure to observe this precaution could damage the camera image sensor.

■ Test Shots Prior to Photography

For important photographs (such as weddings and overseas trips), always take a test shot and view the image to make sure that the camera is working normally.

· FUJIFILM Corporation cannot accept liability for any incidental losses (such as the costs of photography or the loss of income from photography) incurred as a result of faults with this product.

■ Notes on Copyright

Images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner

· Do not take apart the AC power unless intended only for personal use. Note that some restrictions apply to the photographing of stage • Do not use the AC power adapter performances, entertainments and exhibits, even when intended purely • Do not subject the AC power for personal use. Users are also asked to note that the transfer of Memory • The AC power adapter may emit a Card containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

■ Handling Your Digital Camera

To ensure that images are recorded correctly, do not subject the camera to impact or shock while an image is being recorded.

■ Liquid Crystal

If the LCD monitor is damaged, take particular care with the liquid crystal in the monitor. If any of the following situations arise, take the urgent action indicated.

- · If liquid crystal comes in contact with your skin: Wipe the area with a cloth and
- then wash thoroughly with soap and running water.
- · If liquid crystal gets into your eye: Flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- If liquid crystal is swallowed: Flush your mouth thoroughly with water. Drink large quantities of water and induce vomiting. Then seek medical assistance.

Although the LCD panel is produced Notes on Electrical Interference with highly sophisticated technologies, there may be black spots or permanently lit spots. This is not a this camera may cause interference malfunction, and does not affect recorded images.

■ Trademark Information

xD-Picture Card and ____ are trademarks of FUJIFILM Corporation. The typefaces included herein are solely NTSC: National Television System developed by DynaComware Taiwan Inc. Macintosh, QuickTime, and Mac OS are trademarks of Apple Inc. in the U.S.A. and other countries. Windows 8, Windows 7, Windows Vista, and the Windows logo are trademarks of the Microsoft group of companies. Adobe and Adobe Reader are either trademarks or registered trademarks of Adobe Systems Incorporated in the U.S.A. and/ or other countries. The SDHC and SDXC logos are trademarks of SD-3C. LLC. The HDMI logo is a trademark. YouTube is a trademark of Google Inc. Facebook is a trademark of Facebook, Inc. All other trade names mentioned in this manual are the trademarks or registered trademarks of their respective owners.

If the camera is to be used in hospitals or aircrafts, please note that to other equipment in the hospital or aircraft. For details, please check with the applicable regulations.

■ Explanation of Color Television System

- Committee, color television specifications telecasting adopted mainly in the U.S.A., Canada and Japan.
- PAI: Phase Alternation by Line, a color television system adopted mainly by European countries and China

Fxif Print (Fxif ver. 2.3)

Exif Print Format is a newly revised digital camera file format that contains a variety of shooting information for optimal printing.

IMPORTANT NOTICE: Read Before Using the Software

Direct or indirect export, in whole or in part, of licensed software without the permission of the applicable governing bodies is prohibited.

About This Manual

Before using the camera, read this manual and the warnings on pages ii–viii. For information on specific topics, consult the sources below.

The "Table of Contents" gives an overview of the entire manual. The principal camera operations are listed here.

Having a specific problem with the camera? Find the answer here.

✓ Warning Messages and Displays 114

Find out what's behind that flashing icon or error message in the display.

Memory Cards

Pictures can be stored in an optional SD, SDHC, and SDXC memory cards (🕮 11), referred to in this manual as "memory cards".

Temperature Warning

The camera will turn off automatically before its temperature or the temperature of the battery rise above safe limits. Pictures taken when a temperature warning is displayed may exhibit higher levels of "noise" (mottling). Turn the camera off and wait for it to cool before turning it on again.

Table of Contents

For Your Safety ii IMPORTANT SAFETY INSTRUCTIONS ii Safety Notes iv About This Manual ix
Before You Begin
Introduction1
Symbols and Conventions1
Supplied Accessories1
Parts of the Camera2
Camera Displays4
The Mode Dial7
First Steps
The Strap and Lens Cap8
Inserting the Batteries9
Inserting a Memory Card11
Turning the Camera On and Off14
Shooting Mode14
Playback Mode14
Basic Setup

Basic Photography and Playback	
Taking Pictures in SRAUTO (Scene Recognition) Mode.	16
Viewing Pictures	2
-	
More on Photography	
Shooting Mode	22
SRAUTO SCENE RECOGNITION	22
▲ AUTO	22
SP SCENE POSITION	22
MOTION PANORAMA 360	29
P: PROGRAM AE	3
S: SHUTTER PRIORITY AE	32
A: APERTURE PRIORITY AE	32
M: MANUAL	33
C: CUSTOM MODE	34
Intelligent Face Detection	35
Blink Detection	
Focus Lock	37
Macro and Super Macro Modes (Close-ups)	39
4 Using the Flash (Intelligent Flash)	
🖒 Using the Self-Timer	
Instant Zoom	
Continuous Shooting (Burst Mode)	46
Exposure Compensation	40

More on Playback	
Playback Options	51
Playback Zoom	51
★ Favorites: Rating Pictures	52
Multi-Frame Playback	
Viewing Panoramas	54
□ PhotoBook Assist	55
Creating a PhotoBook	55
Viewing PhotoBooks	56
Editing and Deleting PhotoBooks	56
₫ Image Search	57
m Deleting Pictures	58
Movies	
Recording Movies	59
Movie Frame Size	
► Viewing Movies	61

Connections	
Viewing Pictures on TV	6
Connecting the Camera to High Definition (HD) TV	s6
Printing Pictures via USB	
Connecting the Camera	6
Printing Selected Pictures	6
Printing the DPOF Print Order	6
Creating a DPOF Print Order	
Viewing Pictures on a Computer	
Windows: Installing MyFinePix Studio	
Importing pictures or movies to Mac (Macintosh)	
Connecting the Camera	7
-	
Menus	
Using the Menus: Shooting Mode	7
Using the Shooting Menu	7
Shooting Menu Options	
ISO	
	7
	7
FINEPIX COLOR	
WB WHITE BALANCE	7
PHOTOMETRY	7
AF MODE	8
MOVIE AF MODE	8
■ AE BKT EV STEPS	8
FIRE CLASSIC	

Jsing the Menus: Playback Mode	82
Using the Playback Menu	82
Playback Menu Options	82
MOVIE EDIT	83
MARK FOR UPLOAD	84
■ SLIDE SHOW	86
	87
PROTECT	
CROP	
RESIZE	
☑ IMAGE ROTATE	
☑ VOICE MEMO	
DISP. ASPECT	
Γhe Setup Menu	
Using the Setup Menu	94
Setup Menu Options	
TIME DIFFERENCE	
FORMAT	
☑ IMAGE DISP	
■ FRAME NO	
■ PLAYBACK VOLUME	
★ LCD BRIGHTNESS	
☑ LCD MODE 2	
auto power off	
☑ INTELLIGENT DIGITAL ZOOM	
DISCHARGE (Ni-MH Batteries Only)	
DATE DATE STAMP	103

Technical Notes	
Optional Accessories	
Accessories from FUJIFILM	
Caring for the Camera	106
Troubleshooting	
Troubleshooting	107
Warning Messages and Displays	114
Appendix	
Memory Card Capacity	118
Specifications	119

Introduction

Symbols and Conventions

The following symbols are used in this manual:

1: This information should be read before use to ensure correct operation.

★: Points to note when using the camera.

国: Additional information that may be helpful when using the camera.


E: Other pages in this manual on which related information may be found.

Menus and other text in the camera monitor are shown in bold. In the illustrations in this manual, the monitor display may be simplified for explanatory purposes.

Supplied Accessories

Lens cap


The following items are included with the camera:



CD-ROM

Parts of the Camera

For more information, refer to the page listed to the right of each item.





Self-timer lamp......43


* Illustrations in this manual may	be simplified for explanatory purposes.
iliustrations in this manual ma	y be simplified for explanatory purposes.

Zoom control......17, 51, 53

Shutter button......20 (exposure compensation) button......49








Camera Displays

The following indicators may appear during shooting and playback. The indicators displayed vary with camera settings.


■ Shooting



1	Number of available frames	118
2	Movie mode	60
3	Focus warning	19
4	Date stamp	103
5	Silent mode	19
6	Burst mode	46
7	Metering	79
8	Intelligent Face Detection	
	indicator	35
9	Shooting mode	22
10	Flash mode	40
11	Macro (close-ups) mode	39
12	Self-timer indicator	42
13	Focus frame	37
	l	

4	Blur warning40, 110, 114
15	Date and time15
16	Shutter speed and aperture31
17	Sensitivity76
18	Image size/quality76, 77
19	Temperature warningix
20	FinePix color78
21	White balance78
22	Battery level17
23	Dual IS mode18
24	Exposure indicator49
25	Exposure compensation
	indicator49

■ Playback



1	Gift image	5
2	Silent mode	19
3	Red-eye removal indicator	8
4	Pro low-light mode	2
5	Motion panorama 360	29, 54
6	3D image	2
	Intelligent Face Detection	
	indicator	3
	l e e e e e e e e e e e e e e e e e e e	

8	Playback mode indicator	21, 5
9	Protected image	8
10	DPOF print indicator	6
	Voice memo indicator	
12	Photobook assist indicator	5
13	Mark for upload to	8
14	Frame number	10
15	Rating	5

Hiding and Viewing Indicators

Press **DISP/BACK** to cycle through shooting and playback indicators as follows:

- **Shooting**: Indicators displayed/indicators hidden/best framing/HD framing/histogram
- Playback: Indicators displayed/indicators hidden/★ favorites (□ 52)/photo info






① Image quality and size, ② Sensitivity, ③ Shutter speed/aperture, ④ FinePix color, ⑤ Flash mode, ⑥ White balance, ⑦ Exposure compensation, ⑧ Frame number, ⑨ Picture (overexposed areas blink on and off), ⑩ Histogram

Overexposed areas blink on and off.



Histograms show the distribution of tones in the image. Brightness is shown by the horizontal axis, the number of pixels by the vertical axis.



Optimal exposure: Pixels are distributed in an even curve throughout the tone range.

Overexposed: Pixels are clustered at the right side of the graph.

Underexposed: Pixels are clustered at the left side of the graph.









The Mode Dial

To select a shooting mode, align the mode icon with the mark next to the mode dial.



SRAUTO (SCENE RECOGNITION): A "pointand-shoot" mode in which the camera automatically adjusts settings to suit the scene (🗐 16).

(AUTO): A simple "point-and-shoot" mode recommended for first-time users of digital cameras (■ 22).



P, S, A, M: Select for full control over camera settings, including aperture (M and A) and/or shutter speed (M and S) (■ 31).

C (CUSTOM): Recall stored settings for modes **P**, **S**, **A**, and **M** (**E** 34).


(MOTION PANORAMA): Take a series of photographs and combine them to form a panorama (1992).

SP1/SP2 (SCENE POSITION): Choose a scene suited to the subject or shooting conditions and let the camera do the rest (5) 22).

The Strap and Lens Cap

Attaching the Strap

Attach the strap to the two strap eyelets as shown below.



1


To avoid dropping the camera, be sure the strap is correctly secured.

The Lens Cap

Attach the lens cap as shown.



To avoid losing the lens cap, pass the supplied string through the eyelet (1) and secure the lens cap to the strap (2).



Inserting the Batteries

The camera takes four AA alkaline, lithium, or rechargeable Ni-MH batteries. A set of four alkaline batteries is supplied with the camera. Insert the batteries in the camera as described below.

1 Open the battery-chamber cover.

Slide the battery-chamber latch in the direction shown and open the battery-chamber cover.






Be sure the camera is off before opening the battery-chamber cover.

1

- Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could result in damage to image files or memory cards.
- Do not use excessive force when handling the battery-chamber cover.

2 Insert the batteries.

Insert the batteries in the orientation shown by the "+" and "-" marks inside the battery chamber.



 \mathbf{N}

- Insert the batteries in the correct orientation.
- Never use batteries with peeling or damaged casing or mix old and new batteries, batteries with different charge levels, or batteries of different types.
 Failure to observe these precautions could result in the batteries leaking or overheating.





- · Never use manganese or Ni-Cd batteries.
- The capacity of alkaline batteries varies with the manufacturer and drops at temperatures below 10°C/50°F; Ni-MH batteries are recommended.
- Fingerprints and other soil on the battery terminals can shorten battery life.

? Close the battery-chamber cover.

Close the battery-chamber cover and slide it in until the latch clicks into place.



1

Do not use force. If the battery-chamber cover does not close, check that the batteries are in the correct orientation and try again.

■ Using an AC Power Adapter

The camera can be powered by an optional AC power adapter and DC coupler (sold separately).

Choosing the Battery Type

After replacing the batteries with batteries of a different type, select the battery type using the BATTERY TYPE option in the setup menu (1997) to ensure that the battery level is displayed correctly and the came



displayed correctly and the camera does not turn off unexpectedly.

Inserting a Memory Card


The camera can store pictures on SD, SDHC, and SDXC memory cards (sold separately).

■ Compatible Memory Cards

FUJIFILM and SanDisk SD, SDHC, and SDXC memory cards have been approved for use in the camera. A complete list of approved memory cards is available at http://www.fujifilm.com/products/digital_cameras/index.html. Operation is not guaranteed with other cards. The camera can not be used with xD-Picture Cards or MultiMediaCard (MMC) devices.

1

Memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting a memory card, slide the write-protect switch to the unlocked position.




Write-protect switch

■ Inserting a Memory Card

1 Open the battery-chamber cover.




Be sure the camera is off before opening the battery-chamber cover.



2 Insert the memory card.

Holding the memory card in the orientation shown below, slide it in until it clicks into place at the back of the slot.





Be sure card is in correct orientation; do not insert at an angle or use force. **?** Close the battery-chamber cover.

Close the battery-chamber cover and slide it in until the latch clicks into place.



Removing Memory Cards

After confirming that the camera is off, press the card in and then release it slowly. The card can now be removed by hand.



- The memory card may spring out if you remove your finger immediately after pushing the card in.
- Memory cards may be warm to the touch after being removed from the camera. This is normal and does not indicate a malfunction.


1

- Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or deleted from the card. Failure to observe this precaution could damage the card.
- Format SD/SDHC/SDXC memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device. For more information on formatting memory cards, see page 99.
- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than the standard dimensions of an SD/SDHC/SDXC card may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of SD/SDHC/SDXC memory card. Use a **CLASS** card or better when shooting HD movies.
- Formatting a memory card in the camera creates a folder in which pictures are stored. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures from memory cards; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals.

Turning the Camera On and Off

Shooting Mode

Slide the **ON/OFF** switch in the direction shown below. The lens will extend automatically.



Slide the **ON/OFF** switch to turn the camera off.

■ Switching to Playback Mode


Press the **b** button to start playback. Press the shutter button halfway to return to shooting mode.

1

- Be sure that the lens cap is removed before turning the camera on.
- Forcibly preventing the lens from extending could cause damage or product malfunction.
- Pictures can be affected by fingerprints and other marks on the lens. Keep the lens clean.
- The **ON/OFF** button does not completely disconnect the camera from its power supply.

<u>Playback Mode</u>

To turn the camera on and begin playback, press the ▶ button for about a second.



Press the **D** button again or slide the **ON/OFF** switch to turn the camera off.

■ Switching to Shooting Mode

To exit to shooting mode, press the shutter button halfway. Press the ▶ button to return to playback.

Auto Power Off

The camera will turn off automatically if no operations are performed for the length of time selected in the **AUTO POWER OFF** menu (see page 101). To turn the camera on, use the **ON/OFF** switch or press the button for about a second.

Basic Setup

A language-selection dialog is displayed the first time the camera is turned on. Set up the camera as described below (for information on resetting the clock or changing languages, see page 95).

1 Choose a language.



1.1 Press the selector up or down to highlight a language.



1.2 Press MENU/OK



7 Set the date and time.



2.1 Press the selector left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the selector up or down.



2.2 Press **MENU/OK**. A battery type message will be displayed; if the type differs from the type inserted in the camera, use the setup menu **■ BATTERY TYPE** option (**■** 97) to specify the correct type.




■ The Camera Clock

If the batteries are removed for an extended period, the camera clock and battery type will be reset and the language-selection dialog will be displayed when the camera is turned on. If the batteries are left in the camera for about 10 hours, the battery can be removed for about 24 hours without resetting the clock, language, or battery type.


Taking Pictures in SRAUTO (Scene Recognition) Mode

This section describes how to take pictures in **SRAUTO** mode.

1 Turn the camera on. Slide the ON/OFF switch to turn the camera on.



2 Select SRAUTO mode.
Rotate the mode dial to SRAUTO.



SRAUTO

In this mode, the camera automatically analyzes the composition and selects a scene according to shooting conditions and the type of subject:


• • • (PORTRAIT): Human portrait



- subject.
- • (LANDSCAPE): Man-made or natural landscape.
- **©** (NIGHT): Poorly-lit landscape.
- **②** (MACRO): Subject close to camera.
- 🚱 (NIGHT PORTRAIT): Poorly-lit portrait subject.
- 🚳 (BACKLIT PORTRAIT): Back-lit portrait subject.
- (AUTO) is selected if none of the above are detected.

3 Check the battery level.

Check the battery level in the display.




	Indicator	Description	
NO ICON Batteries are partially discharge		Batteries are partially discharged.	
1 🗖		Batteries are low. Replace as soon	
	(red)	as possible.	
		Batteries are exhausted. Turn cam-	
	(blinks red)	era off and replace batteries.	



A battery warning may not be displayed before the camera turns off, particularly if batteries are reused after having once been exhausted. Power consumption varies greatly from mode to mode; the low battery warning () may not be displayed or may be displayed only briefly before the camera turns off in some modes or when switching from shooting to playback mode.

4 Frame the picture.

Use the zoom control or side lever to frame the picture in the display.





- When the side lever is set to H, M or L, the side lever functions as same as the zoom lever.
- When setting the side lever to **H**, the side lever can zoom faster than zoom lever. In the same way when setting the side lever to **L**, the side lever can zoom slower than zoom lever.
- When using the zoom control and side lever simultaneously, the zoom control is activated.

■ Focus Lock

Use focus lock (🗐 37) to focus on subjects that are not in the focus frame.

Auto back zoom

In the setup menu (E 94), you can change the setting of the side lever. Select SIDE ZOOM LEVER then AUTO BACK to enable auto back zoom. Auto back zoom allows the camera to zoom out and in quickly. It makes it easy to find the lost subject when zooming in.

Holding the Camera

Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.



To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and flash.




Avoiding Blurred Pictures

If the subject is poorly lit, blurring caused by camera shake can be reduced using the **DUAL IS MODE** option in the setup menu (**9** 96). In **n** mode, blur caused by subject movement is also reduced (dual IS mode).

Sensitivity is raised when dual IS is in effect. Note that blurring may still occur depending on the scene. We recommend that you turn dual IS off when using a tripod.

Silent Mode

In situations in which camera sounds or lights may be unwelcome, hold the **DISP/BACK** button down until st is displayed (note that silent mode is not available during movie or voice memo playback).



The camera speaker and AF-assist illuminator/self-timer lamp turn off and volume (\$\equiv 95\$) can not be adjusted (note that the AF-assist illuminator may still light when \$\displaystyle{4}\$ is selected in \$\mathbb{SP1/SP2}\$). To restore normal operation, press the \$\mathbb{DISP/BACK}\$ button until the \$\frac{4}{2}\$ icon is no longer displayed.

5 Focus.

Press the shutter button halfway to focus.





The lens may make a noise when the camera focuses; this is normal. In **SRAUTO** mode, the camera continuously adjusts focus and searches for faces, increasing the drain on the battery.

If the camera is able to focus, it will beep twice and the indicator lamp will glow green.

If the camera is unable to focus, the focus frame will turn red, !AF will be displayed, and the indicator lamp will blink green. Change the composition or use focus lock (EE 37).


6 Shoot.

Smoothly press the shutter button the rest of the way down to take the picture.



■ The Shutter Button

The shutter button has two positions. Pressing the shutter button halfway (①) sets focus and exposure; to shoot, press the shutter button the rest of the way down (②).





If the subject is poorly lit, the AF-assist illuminator may light to assist focus (1 38). For information on using the flash when lighting is poor, see page 40.

The Indicator Lamp



· Indicator lamp

The indicator lamp shows camera status as follows:

Indicator lamp	Camera status
Glows green	Focus locked.
Blinks green	Blur, focus, or exposure warning. Pic-
	ture can be taken.
Blinks green	Recording pictures. Additional pic-
and orange	tures can be taken.
Glows	Recording pictures. No additional pic-
orange	tures can be taken at this time.
Blinks orange	Flash charging; flash will not fire when
	picture is taken.
Blinks red	Lens or memory error (memory card
	full or not formatted, format error, or
	other memory error).


■ Warnings

Detailed warnings appear in the display. See pages 114–117 for more information.

Viewing Pictures

Pictures can be viewed in the monitor. When taking important photographs, take a test shot and check the results.

1 Press the **▶** button.



The most recent picture will be displayed in the monitor



2 View additional pictures.

Press the selector right to view pictures in the order recorded, left to view pictures in reverse order.



Press the shutter button to exit to shooting mode

Deleting Pictures

To delete the picture currently displayed in the monitor, press the selector up (面). The following dialog will be displayed.



 Select FRAME and press MENU/ OK.



 To delete the picture, press MENU/OK.



To exit without deleting the picture, press **DISP/BACK**.

■ The Playback Menu

Pictures can also be deleted from the playback menu (1998).

Shooting Mode

Choose a shooting mode according to the scene or type of subject. To choose a shooting mode, rotate the mode dial to the desired setting (7). The following modes are available:

SRAUTO SCENE RECOGNITION


The camera automatically analyzes the composition and selects the appropriate scene mode according to the subject and shooting conditions (EE 16).

AUTO

Choose for crisp, clear snapshots. This mode is recommended in most situations.

SP SCENE POSITION

The camera offers a choice of "scenes," each adapted to particular shooting conditions or a specific type of subject. Use the SCENE POSITION option in the shooting menu to choose the scene assigned to the SP1/SP2 position on the mode dial.



Scene	Description
PRO LOW-LIGHT	Use to reduce noise and blur when photographing poorly lit subjects or static subjects at high zoom ratios.
THOR HDR	Each time the shutter button is pressed, the camera takes a series of shots, each with different exposure. These are combined into a single image, preserving detail in highlights and shadows.
ZOOM BRACKETING	The camera takes three shots: one at the current zoom ratio, a second zoomed in $1.4\times$, and a third zoomed in $2\times$.
⊕\$ NATURAL & \$	Get good results with backlit subjects and other difficult lighting. The camera takes two shots: one without the flash and one with.
NATURAL LIGHT	Capture natural light indoors, under low light, or where the flash can not be used.
₱ PORTRAIT	Choose this mode for soft-toned portraits with natural skin tones.
⇔ BABY MODE	Choose for natural skin tones when taking portraits of infants. The flash turns off automatically.
SMILE&SHOOT	The shutter is released automatically when Intelligent Face Detection detects a smiling face.
▲ LANDSCAPE	Choose this mode for crisp, clear daylight shots of buildings and landscapes.
≫ SPORT	Choose this mode when photographing moving subjects. Priority is given to faster shutter speeds.
C NIGHT	Choose this mode for poorly lit twilight or night scenes. Sensitivity is automatically raised to reduce blur caused by camera shake.
x ^{(⋆} NIGHT (TRIPOD)	Choose this mode for slow shutter speeds when shooting at night. Use a tripod to prevent blur.

Scene	Description
• FIREWORKS	Slow shutter speeds are used to capture the expanding burst of light from a firework. Rotate the command dial to choose a shutter speed.
🚢 SUNSET	Choose this mode to record the vivid colors in sunrises and sunsets.
SNOW	Choose for crisp, clear shots that capture the brightness of scenes dominated by shining white snow.
≜ BEACH	Choose for crisp, clear shots that capture the brightness of sunlit beaches.
▼ PARTY	Capture indoor background lighting under low-light conditions.
☆ FLOWER	Choose for vivid close-ups of flowers. The camera focuses in the macro range.
TEXT TEXT	Take clear pictures of text or drawings in print. The camera focuses in the macro range.
♣ INDIVID. SHUTTER 3D	Take two shots from different angles to create a 3D image.

■ 🏿 PRO LOW-LIGHT

Fach time the shutter button is pressed, the camera makes four exposures and combines them into a single photograph. Use to reduce noise and blur



when photographing poorly lit subjects or static subjects at high zoom ratios.



A single combined photograph may not be created with some scenes or if the subject or camera moves during shooting. Do not move the camera until shooting is complete.

Pro Low-Light

To save unprocessed copies of pictures taken in these modes, select **ON** for the **SAVE ORG IMAGE** option in the setup menu (# 96).

1

- Keep the camera steady during shooting.
- Frame coverage is reduced.

HDR HDR

Each time the shutter button is pressed, the camera takes a series of shots, each with different exposure. These are combined into a single image, preserving detail in highlights and shadows. Choose for high-contrast scenes.



A single combined photograph may not be created with some scenes or if the subject or camera moves

during shooting. Do not move the camera until shooting is complete.

HDR


To save unprocessed copies of pictures taken in this mode, select ON for the SAVE ORG IMAGE option in the setup menu (196).


Leep the camera steady during shooting

- Keep the camera steady during shooting.
- Frame coverage is reduced.

■ Zoom Bracketing

Each time the shutter button is pressed, the camera takes three pictures: one at the current zoom ratio with an image size of , a second zoomed in 1.4× and cropped to , and a third zoomed in 2× and cropped to , (pictures will only be taken if there is enough memory for three images). Two frames are displayed to show the areas that will be included in the second and third pictures; the outer frame shows the area that will be recorded at 1.4× zoom, the inner frame the area that will be recorded at 2× zoom. Press the button to choose from wide and tall crops.







- Digital zoom can not be used. If digital zoom is active when maximum optical zoom position.
- Burst shooting options can not be used.

■ 04 Natural & 4

This mode helps ensure good results with back-lit subjects and in other situations with difficult lighting. Before shooting, raise the flash; pictures can only be taken when the flash is raised. Each time the shutter button is pressed, the camera takes two shots: one shot without the flash to preserve natural lighting, followed immediately by a second shot with the flash. Do not move the camera until shooting is complete.



- Do not use where flash photography is prohibited.
- Only available if memory remains for two pictures.
- Burst mode is not available.

■ **(** Natural Light

Capture natural light indoors, under low light, or where the flash can not be used. The flash turns off and sensitivity is raised to reduce blur.

■ \$\frac{1}{2}\$ INDIVID. SHUTTER 3D

Take two shots from different angles to create a 3D image.

1 To choose the order in which the pictures are taken, press the selector right to display the current order and then press the selector



left or right to choose from the options below.

 \longrightarrow 2: Take the left shot first.

2 ← **1**: Take the right shot first.

7 Press the shutter button to take the first shot.


1

To exit without recording a picture, press **DISP/BACK**.

3 The first shot will be shown superimposed on the view through the lens. Using it as a guide, frame the second shot and press the shutter release button.



 The 3D effect may not be visible with some subjects or under some shoot-



- ing conditions. For best results, the distance the camera is moved between shots should be about 1/30th to 1/50th of the distance to the subject.
- The camera will turn off automatically if no operations performed for the time selected for
 ☐ AUTO POWER OFF (☐ 101). The first shot will not be saved if the second shot is not taken before the camera turns off.

Viewing and Printing 3D Images

- The camera displays images in 2D. Press the selector down to toggle between the first and second shots.
- Devices equipped for 3D display, such as the FINEPIX REAL 3D V3 digital photo frame or FINEPIX REAL 3D W3 digital camera, will display the images in 3D.
- 3D prints can be ordered from http://www.fujifilm. com/3d/print/
- The supplied software displays 3D anaglyph images.
 3D photos can also be viewed using other applications that support the MP format.
- **3D TVs** that support the MP format can display images in 3D. See the manual for your TV for details.

1

- Images are not output in 3D when printed directly from the camera.
- 3D images are displayed in 2D in slide shows and when output on a conventional TV.
- 3D images can not be edited or retouched.



The MP (Multi-Picture) format is a CIPA standard for files containing multiple still images. Files in MP format are referred to as "MP files" and have the extension "*.MPO". The camera uses this format for 3D images.

MOTION PANORAMA 360

Follow an on-screen guide to take photos that will automatically be joined to form a panorama. The camera zooms all the way out and remains fixed at the widest angle until shooting is complete.



- **1** To select the angle through which you will pan the camera while shooting, press the selector down. Press the selector left or right to highlight an angle and press **MENU/OK**.
- **2** Press the selector right to view a choice of pan directions. Press the selector left or right to highlight a pan direction and press **MENU/OK**.
- **3** Press the shutter button all the way down to start recording. There is no need to keep the shutter button pressed during recording.

4 Pan the camera in the direction shown by the arrow. Shooting ends automatically when the progress bar is full and the panorama is complete.





Shooting ends if the shutter button is pressed all the way down during shooting. No panorama will be recorded if the shutter button is pressed before the camera has been panned through 120°.

1


- Panoramas are created from multiple frames. The camera may in some cases record a greater or lesser angle than selected or be unable to stitch the frames together perfectly. The last part of the panorama may not be recorded if shooting ends before the panorama is complete.
- Shooting may be interrupted if the camera is panned too quickly or too slowly. Panning the camera in a direction other than that shown cancels shooting.
- The desired results may not be achieved with moving subjects, subjects close to the camera, unvarying subjects such as the sky or a field of grass, subjects that are in constant motion, such as waves and waterfalls, or subjects that undergo marked changes in brightness. Panoramas may be blurred if the subject is poorly lit.

For Best Results

For best results, move the camera in a small circle at a steady speed, keeping the camera horizontal and being careful only to pan in the direction shown by the guides. If the desired results are not achieved, try panning at a different speed.

P: PROGRAM AE

In this mode, the camera sets exposure automatically. If desired, you can choose different combinations of shutter speed and aperture that will produce the same exposure (program shift).



1

If the subject is outside the metering range of the camera, the shutter speed and aperture displays will show "---". Press the shutter button halfway to measure exposure again.


Program Shift


Rotate the command dial to choose the desired combination of shutter speed and aperture. The default values can be restored by raising the flash or turning the camera off. Program shift is not available when the flash is raised.



S: SHUTTER PRIORITY AE

Choose the shutter speed using the command dial, while the camera adjusts aperture for optimal exposure.






1

- If the correct exposure can not be achieved at the selected shutter speed, aperture will be displayed in red. Adjust shutter speed until the correct exposure is achieved. If the subject is outside the metering range of the camera, the aperture display will show "F---". Press the shutter button halfway to measure exposure again.
- The shutter speed is restricted depending on the ISO setting.

A: APERTURE PRIORITY AE

Choose the aperture using the command dial, while the camera adjusts shutter speed for optimal exposure.




1


If the correct exposure can not be achieved at the selected aperture, shutter speed will be displayed in red. Adjust aperture until the correct exposure is achieved. If the subject is outside the metering range of the camera, the shutter speed display will show "---". Press the shutter button halfway to measure exposure again.

M: MANUAL

In this mode, you choose both shutter speed and aperture. If desired, exposure can be altered from the value suggested by the camera.



Press the 🔀 button to choose between shutter speed and aperture and rotate the command dial to adjust the selected setting.



1

- Noise in the form of randomly-spaced bright pixels may occur in long exposures.
- The shutter speed is restricted depending on the ISO setting.


The Exposure Indicator

The amount the picture will be under- or over-exposed at current settings is shown by the exposure indicator.



C: CUSTOM MODE

In **P**, **S**, **A** and **M** modes, the **Q CUSTOM SET** option in the shooting menu (**Q** 75) can be used to save current camera and menu settings. These settings are recalled whenever the mode dial is rotated to **C** (custom mode).



Menu/setting	Settings saved
Chaoting manu	ISO, ■ IMAGE SIZE, 🗖 FINEPIX COLOR, 🔛 IMAGE QUALITY, 📵 PHOTOMETRY, 🔢 WHITE BALANCE,
Shooting menu	■ AF MODE, ☑ FLASH, ☑ AE BKT EV STEPS, ☑ FACE DETECTION
	☑ IMAGE DISP, ☑ DUAL IS MODE, № AF ILLUMINATOR, LCD MODE, ☑ BLINK DETECTION,
Setup menu	INTELLIGENT DIGITAL ZOOM
Other	Shooting mode (P, S, A, or M), continuous shooting mode, instant zoom, macro mode, exposure compensa-
other	tion, flash mode, shutter speed, aperture, indicators/best framing

Intelligent Face Detection

Intelligent Face Detection allows the camera to automatically detect human faces and set focus and exposure for a face anywhere in the frame for shots that emphasize portrait subjects. Choose for group portraits (in horizontal or vertical orientations) to prevent the camera from focusing on the background.

- 1 Turn Intelligent Face Detection on.
 To use Intelligent Face Detection, press MENU/
 OK to display the shooting menu and select
 ON for FACE DETECTION.
- **2** Frame the picture.

If a face is detected, it will be indicated by a green border. If there is more than one face in the frame, the camera will select the face clos-



Green border

est to the center; other faces are indicated by white borders

3 Focus.

Press the shutter button halfway to set focus and exposure for the subject in the green border.



1

If no face is detected when the shutter button is pressed halfway (112), the camera will focus on the subject at the center of the display and red-eye will not be removed.

⚠ Shoot.

Press the shutter button all the way down to shoot.



•

If the subject moves as the shutter button is pressed, their face may not be in the area indicated by the green border when the picture is taken. If the number of faces is large, additional time may be required for processing.

Intelligent Face Detection


Intelligent Face Detection is recommended when using the self-timer for group- or self-portraits (1994).



When a picture taken with Intelligent Face Detection is displayed, the camera can automatically select faces for red-eye removal (87), playback zoom (51), slide shows (86), image search (57), image disp. (99), printing (63), and cropping (89).

Blink Detection

If an option other than **OFF** is selected for **IMAGE DISP.** (■ 95), a warning will be displayed if the camera detects subjects who may have blinked when the picture was taken. If **ZOOM (CONTINUOUS)** is selected, you can press the **V** button to zoom in on these subjects.



 \mathbf{N}

Blink detection is not performed if the camera fails to detect a face or when **OFF** is selected for **IMAGE DISP**.

■ Blink Detection

Blink detection can be turned on or off in the setup menu (1996).

Focus Lock

To compose photographs with off-center subjects:

Position the subject in the focus frame.



2 Focus.

Press the shutter button halfway to set focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).



Repeat steps 1 and 2 as desired to refocus before taking the picture.

3 Recompose the picture. Keeping the shutter button pressed halfway, recompose the picture.



4 Shoot.

Press the shutter-release button the rest of the way down to take the picture.



Press the rest of the way down

Autofocus

Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below. If the camera is unable to focus using autofocus, use focus lock (37) to focus on another subject at the same distance and then recompose the photograph.

Very shiny subjects such
 Fast-moving subjects.





- Subjects photographed through a window or other reflective object.
- Dark subjects and subjects that absorb rather than reflect light, such as hair or fur.
- Insubstantial subjects, such as smoke or flame.
- Subjects that show little contrast with the background (for example, subjects in clothing that is the same color as the background).
- Subjects positioned in front of or behind a highcontrast object that is also in the focus frame (for example, a subject photographed against a backdrop of highly contrasting elements).

The AF-Assist Illuminator


If the subject is poorly lit, the AF-assist illuminator will light to assist the focus operation when the shutter button is pressed halfway.



- Avoid shining the AF-assist illuminator directly into your subject's eyes.
- The camera may be unable to focus using the AFassist illuminator in some cases. If the camera is unable to focus in macro mode (@ 39), try increasing the distance to the subject.

Macro and Super Macro Modes (Close-ups)

For close-ups, press the selector left (to choose from the macro options shown below.





Choose from ♥ (macro mode), ₨ (super macro mode), or OFF (macro mode off)

When macro mode is in effect, the camera focuses on subjects near the center of the frame. Use the zoom control to compose pictures. In super macro mode, optical zoom can not be adjusted and the flash can not be used.



- Use of a tripod is recommended to prevent blur caused by camera shake.
- Flash compensation may be required when using the flash (## 81).
- Using the flash at close range may cast a lens shadow. Zoom a little or have more distance from the subject.

4 Using the Flash (Intelligent Flash)

When the flash is used, the camera's *Intelligent Flash* system instantly analyzes the scene based on such factors as the brightness of the subject, its position in the frame, and its distance from the camera. Flash output and sensitivity are adjusted to ensure that the main subject is correctly exposed while preserving the effects of ambient background lighting, even in dimly-lit indoor scenes. Use the flash when lighting is poor, for example when shooting at night or indoors under low light.

1 Raise the flash.

Press the flash pop-up button to raise the flash.


Turning the Flash Off

Lower the flash where flash photography is prohibited or to capture natural lighting under dim light. At slow shutter speeds, **1** will be displayed to warn that pictures may be blurred; use of a tripod is recommended.



7 Choose a flash mode.

Press the selector right (4). The flash mode changes each time the selector is pressed.



	Mode	Description
	AUTO/AR (AUTO FLASH)	The flash fires when required. Recommended in most situations.
•		The flash fires whenever a picture is taken. Use for backlit subjects or for natural coloration when shooting in bright light.
		Capture both the main subject and the background under low light (note that brightly lit scenes may be overexposed).

? Focus.

Press the shutter button halfway to focus. If the flash will fire, **2** will be displayed when the shutter button is pressed halfway. At slow shutter speeds, **3** will appear in the display to warn that pictures may be blurred; use of a tripod is recommended.



4 Shoot.

Press the shutter button the rest of the way down to shoot.

1

The flash may fire several times with each shot. Do not move the camera until shooting is complete.



4

The peripheral part of an image may be dark when using the flash.

Red-Eye Removal

When Intelligent Face Detection is active (■ 35), and **ON** is selected for **© RED EYE REMOVAL** in the setup menu (■ 96), red-eye removal is available in **②**, **©**4, and **③**.

Red-eye removal minimizes "red-eye" caused when light from the flash is reflected from the subject's retinas as shown in the illustration at right.




🖒 Using the Self-Timer

The camera offers a ten-second timer that allows photographers to appear in their own photographs, and a two-second timer that can be used to avoid blur caused by the camera moving when the shutter button is pressed.

1 Set the timer.

Press the selector down (৩), and then press the selector left or right to highlight an option and press **MENU/OK**.





Choose from

OFF (self-timer off),

(10 s delay), or

(2 s delay)

7 Focus.

Press the shutter button halfway to focus.




Stand behind the camera when using the shutter button. Standing in front of the lens can interfere with focus and exposure.




3 Start the timer.

Press the shutter button the rest of the way down to start the timer. The display shows the number of seconds remaining until the shutter is released. To stop the timer before the picture is taken, press **DISP/BACK**.





The self-timer lamp on the front of the camera will blink immediately before the picture is taken. If the two-second timer is selected, the self-timer lamp will blink as the timer counts down.



Intelligent Face Detection

Because it ensures that the faces of portrait subjects will be in focus, Intelligent Face Detection (\$\square\$ 35) is recommended when using the self-timer for group portraits or self-portraits. To use the self-timer with Intelligent Face Detection, select \$\cdot\ 10 \text{ SEC}\$ or \$\cdot\ 2 \text{ SEC}\$ in the self-timer menu and then press the shutter button all the way down to start the timer. The camera will detect faces while the timer is counting down and adjust focus and exposure immediately before the shutter is released. Be careful not to move until the picture has been recorded.



The self-timer turns off automatically when the picture is taken, a different shooting mode is selected, playback mode is selected, or the camera is turned off.

Instant Zoom

In instant zoom, the area surrounding the frame is visible in the display. Use to frame erratically moving subjects such as children, pets, and athletes at sporting events.


1 Position the subject in the focus frame. Use the zoom control to frame the subject in the center of the display.






2 Choose a frame.

Press the selector up ((23)) to cycle through framing options as shown below.





The frame is displayed as shown at right. The composition can be adjusted using the zoom control.



3 Focus and shoot. The framed area will be enlarged to create a

full-sized picture.



■ Intelligent Face Detection

Intelligent Face Detection will not detect faces outside the selected frame.


Intelligent Digital Zoom

- Enable digital zoom. Select **ON** for the **INTELLIGENT DIGITAL ZOOM** option in the setup menu (1102).
- Choose a subject. Frame the subject in the center of the display using intelligent digital zoom.



? Press the selector up ().

The camera will zoom to the maximum optical zoom position with the area that will be recorded using intelligent digital zoom indicated by a frame at the center of the display.







1 Frame the picture.

Use the zoom control to choose the area that will be included in the final photograph.





Focus and shoot. The framed area will be enlarged to create a




- Pictures taken using the instant zoom are lower quality than pictures taken using normal zoom.
 Only horizontal (landscape-orientation) framing is
- available in continuous shooting mode.

Q Continuous Shooting (Burst Mode)

Capture motion or automatically vary selected settings over a series of pictures.

Press the **u** button and choose from the following options:



OFF: OFF

論: 論 CONTINUOUS 記: 記 CONTINUOUS 電: BEST FRAME CAPTURE ほ: 色 CONTINUOUS 絶: 絶 CONTINUOUS 絶: 絶 CONTINUOUS

🔁: AE BKT

1

- Focus and exposure are determined by the first frame in each series. The flash turns off automatically; the previously-selected flash mode is restored when continuous shooting is turned off.
- Frame rate varies with shutter speed, shooting conditions, and the number of pictures in each burst.
- The number of pictures that can be taken in a single burst varies with the scene and camera settings. The number of pictures that can be recorded depends on the memory available.

■ ஹ CONTINUOUS/ஹ CONTINUOUS/ஹ CONTINUOUS/ ஹ CONTINUOUS/迎 CONTINUOUS

The camera takes photographs while the shutter button is pressed.

■ 🖦 BEST FRAME CAPTURE

The camera takes a series of pictures, starting before and ending after the shutter button is pressed. To choose the frame rate and number of shots:

1 Press the selector right when the camera is in shooting mode.



2 Highlight the current frame rate and press the selector right, then press selector up or down to choose a new value and press **MENU/OK** to select.








1

Some frame rates may reduce the number of shots available in Step 3.

3 Highlight the number of shots and press the selector right. Press the selector up or down to choose the number of shots in each burst and left or right to choose their distribution (the number on the left is taken *before* and the number on the right *after* the shutter button is pressed). Press **MENU/OK** when settings are complete.










4 Press **DISP/BACK** to return to shooting mode.



5 Take photographs. The camera begins recording while the shutter button is pressed halfway, and completes the burst when the shutter button is pressed all the way down. The illustration shows a burst of eight shots, three before the shutter button is pressed and four after.



\

- If the shutter button is pressed all the way down before the number of frames selected for the "before" portion is recorded, the remaining frames will be taken after the shutter button is pressed all the way down
- If the shutter button is pressed halfway for an extended period, the camera may record the burst before the shutter button is pressed all the way down.

■ 🔁 AE BKT


Each time the shutter button is pressed, the camera takes three shots: one using the metered value for exposure, the second overexposed by the amount selected for **AEBKT EV STEPS** in the shooting menu (**B** 81), and the third underexposed by the same amount (the camera may not be able to use the selected bracketing increment if the amount of over- or under- exposure exceeds the limits of the exposure metering system).

Exposure Compensation

Use exposure compensation when photographing very bright, very dark, or high-contrast subjects.

1 Press the 🗷 button.

The exposure indicator will be displayed.





2 Choose a value.

Rotate the command dial. The effect is visible in the display.





Choose negative values to reduce exposure ("-" sign turns yellow)

Choose positive values to increase exposure ("+" sign turns yellow)


3 Return to shooting mode.

Press the **b**utton to return to shooting mode.

4 Take pictures.



A \bowtie icon and exposure indicator are displayed at settings other than ± 0 . Exposure compensation is not reset when the camera is turned off; to restore normal exposure control, choose a value of ± 0 .



• Backlit subjects: choose values from +2/3 EV to +12/3 EV




• Highly reflective subjects or very bright scenes (e.g., snowfields): +1 EV



- ullet Scenes that are mostly sky: +1~EV
- **Spotlit subjects** (particularly if photographed against dark backgrounds): –²/₃ EV
- Subjects with low reflectivity (pine trees or dark-colored foliage): -2/3 EV

Playback Options

To view the most recent picture in the monitor, press the **>** button.





Press the selector right to view pictures in the order recorded, left to view pictures in reverse order. Keep the selector pressed to scroll rapidly to the desired frame.





Pictures taken using other cameras are indicated by a figift image") icon during playback.

<u>Playback Zoom</u>

Select **T** to zoom in on pictures displayed in single-frame playback; select **W** to zoom out. When the picture is zoomed in, the selector can be used to view areas of the image not currently visible in the display.





Zoom indicator
Navigation window
shows portion of image
currently displayed in
monitor

Press DISP/BACK to exit zoom.



The maximum zoom ratio varies with image size. Playback zoom is not available with copies resized or cropped to a size of 60 or smaller.

Intelligent Face Detection

Pictures taken with Intelligent Face Detection (■ 35) are indicated by a 🖭 icon. Press the 🔻 button to zoom in on the subject selected with Intelligent Face Detection. You



can then use the zoom control to zoom in and out.

* Favorites: Rating Pictures

To rate the picture currently displayed in full-frame playback, press **DISP/BACK** and press the selector up and down to select from zero to five stars.

■ Favorites

Ratings can be used for image search (🕮 57).

Multi-Frame Playback

To change the number of images displayed during playback, select W.



Use the selector to highlight images and press **MENU/OK** to view the highlighted image full frame. In the nine- and hundred-frame displays, press the selector up or down to view more pictures.

▼ Two-Frame Display

Two-frame display can be used to compare pictures taken in **@**4 mode.





Select W to increase the number of pictures displayed to one frame with previous and next, two. nine, or a hundred.





Select T to reduce the number of images displayed.



Viewing Panoramas

If you press the selector down when a panorama is displayed full frame, the camera will play back the picture from left to right or from bottom to top.



The following operations can be performed during playback:

Operation	Button	Description
Start/pause playback	(MENN) OK	Press the selector down to start playback. Press again to pause.
End playback	MIENU)	Press the selector up to end playback.



Once displayed in full-frame playback, panoramas can be zoomed in or out using the zoom lever.

PhotoBook Assist

Create books from your favorite photos.

Creating a PhotoBook

- 1 Select **PHOTOBOOK ASSIST** in the playback menu.
- **2** Highlight **NEW BOOK**.



3 Press **MENU/OK** to display the new book dialog.



- **4** Choose pictures for the new book.
 - **SELECT FROM ALL**: Choose from all the pictures available.





Neither photographs or smaller nor movies can be selected for photobooks.

5 Scroll through the images and press the selector up to select or deselect the current image for inclusion in the book. To display the current image on the cover, press the selector down.



The first picture selected automatically becomes the cover image. Press the selector down to select a different picture for the cover.

6 Press **MENU/OK** to exit when the book is complete.



Highlight COMPLETE PHOTOBOOK.







Choose **SELECT ALL** to select all photos, or all photos matching the specified search conditions, for the book.

8 Press **MENU/OK**. The new book will be added to the list in the photobook assist menu.



1

- Photobooks can contain up to 300 pictures.
- Books that contain no photos are automatically deleted.

PhotoBooks

Photobooks can be copied to a computer using the supplied MyFinePix Studio software.

Viewing PhotoBooks

Highlight a book in the photobook assist menu and press **MENU/OK** to display the book, then press the selector left and right to scroll through the pictures. Press **DISP/BACK** to return to the photobook assist menu.

Editing and Deleting PhotoBooks

1 Display the photobook and press **MENU/OK** to view book edit options.



- **7** Choose from the following options:
 - **EDIT**: Edit the book as described in "Creating a PhotoBook" on page 55.
 - **ERASE**: Delete the current photobook.
- **3** Follow the on-screen instructions.

Image Search

Search for pictures by date, subject, scene, file type, and rating.

- 1 Select IMAGE SEARCH in the playback Select a search condition. Only picmenu.
- **2** Highlight one of the following options and press **MENU/OK**:





Option	Description
BY DATE	Find all pictures taken on a selected date.
BY FACE	Find all pictures based on specified face information.
BY ★ FAVORITES	Find all pictures with a specified rating (1995) 52).
BY SCENE	Find all pictures that match a selected scene.
BY TYPE OF DATA	Find all still pictures or all movies.
BY UPLOAD MARK	Find all pictures selected for upload to a specified destination (🗎 84).

Select a search condition. Only pictures that match the search condition will be displayed. To delete or protect selected pictures or to view the selected pictures in a slide show, press **MENU/OK** and choose from the following options:





Option	See page
m ERASE	58
o PROTECT	88
■ SLIDE SHOW	86

4 To end the search, select **EXIT SEARCH**.

m Deleting Pictures

To delete individual pictures, multiple selected pictures, or all pictures, press the selector up (面), and choose from the options below. *Note that deleted pictures can not be recovered. Copy important pictures to a computer or other storage device before proceeding.*






Option	Description
FRAME	Press the selector left or right to scroll through pictures and press MENU/OK to delete the current picture (a confirmation dialog is not displayed).
SELECTED FRAMES	Highlight pictures and press MENU/OK to select or deselect (pictures that are protected or in a print order are shown by II). When the operation is complete, press DISP/BACK to display a confirmation dialog, then highlight OK and press MENU/OK to delete the selected pictures.
ALL FRAMES	A confirmation dialog will be displayed; highlight OK and press MENU/OK to delete all unprotected pictures. Pressing DISP/BACK cancels deletion; note that any pictures deleted before the button was pressed can not be recovered.



- Protected pictures can not be deleted. Remove protection from any pictures you wish to delete (🗎 88).
- Pictures can also be deleted by **m ERASE** from playback menu.
- If a message appears stating that the selected images are part of a DPOF print order, press **MENU/OK** to delete the pictures.

Recording Movies

Press • to shoot a movie. During recording, the following indicators will be displayed and sound will be recorded via the built-in microphone (be careful not to cover the microphone during recording).



To end recording, press the ● button again. Recording ends automatically when the movie reaches maximum length or memory is full.



- If the subject is poorly lit, the AF-assist lamp may light to assist the focus operation.

 To turn the AF-assist lamp off, select **OFF** for **AF ILLUMINATOR** in the setup menu (■ 96).
- Exposure and white balance are adjusted automatically throughout recording. The color and brightness of the image may vary from that displayed before recording begins.
- Sounds made by the camera may be recorded.

Taking Photographs during Recording

Press the shutter button to take a photograph during recording.



- Image size is determined by the option selected for **MOVIE MODE**.
- The photo is saved separately from the movie and does not appear as part of the movie.

1

- Photos can not be taken while a high-speed movie is being recorded.
- The number of photos that can be taken is limited.

1

- The indicator lamp lights while movies are being recorded. Do not open the battery chamber during shooting or while the indicator lamp is lit. Failure to observe this precaution could prevent the movie from being played back.
- Vertical or horizontal streaks may appear in movies containing very bright subjects. This is normal and does not
 indicate a malfunction.
- The temperature of the camera may rise if it is used to record movies for an extended period or if the ambient temperature is high. This is normal and does not indicate a malfunction.

Movie Frame Size

Before recording, select a frame size using the **MOVIE MODE** option in the shooting menu (**1** 75).

Option	Description
齏 1920×1080	Full HD (High Definition).
1280×720	High Definition.
640 (640 × 480)	Standard definition.
HS 640 × 480 (120fps)	High speed movie. Sound is not recorded, and focus, exposure, and white balance are not adjusted automatically.
HS 320 × 240 (240fps)	
HS 320 × 120 (480fps)	

Automatic Scene Selection

In ጨ mode, the camera selects the scene according to shooting conditions and the type of subject: ② (portraits), ③ (poorly-lit landscapes), ③ (poorly-lit portraits), ② (landscapes), ③ (close-ups), ③ (backlit portraits), or ⑩ (other subjects).



Scene icon


▶ Viewing Movies

During playback (51), movies are displayed in the monitor as shown at right. The following operations can be performed while a movie is displayed:



Operation	Description		
Start/pause	Press the selector down to start playback.		
playback	Press again to pause.		
End	Press the selector up to end playback. If		
playback/	playback is not in progress, pressing the		
delete	selector up will delete the current movie.		
Advance/ rewind	Press the selector left or right to adjust playback speed. Speed is shown by the number of arrows (\triangleright or \blacktriangleleft).		
Adjust volume	Press MENU/OK to pause playback and display volume controls. Press the selector up or down to adjust the volume; press MENU/OK again to set the volume.		

Progress is shown in the monitor during playback.



▼ Viewing Movies on a Computer

Copy movies to the computer before viewing.

1

Do not cover the speaker during playback.

Viewing Pictures on TV

Connecting the Camera to High Definition (HD) TVs

When an HDMI cable (available from third-party suppliers) is connected, pictures and sound are played back on the TV.

1 Turn the camera off and connect an HDMI cable available from third party suppliers.





The USB cable can not be used while an HDMI cable is connected.

- **2** Tune the television to the video or HDMl input channel. See the documentation supplied with the television for details.
- **3** Press the **\bigsiz** button for about a second to turn the camera on. The camera monitor turns off and pictures and movies are played back on the TV. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.



Image quality drops during movie playback.

1

When connecting the cable, be sure the connectors are fully inserted.

Printing Pictures via USB


If the printer supports PictBridge, the camera can be connected directly to the printer and pictures can be printed without first being copied to a computer. Note that depending on the printer, not all the functions described below may be supported.



Connecting the Camera

1 Connect the supplied USB cable as shown and turn the printer on.





Printing Selected Pictures

1 Press the selector left or right to display a picture you wish to print.



2 Press the selector up or down to choose the number of copies (up to 99).



3 Repeat steps 1–2 to select additional pictures. Press **MENU/OK** to display a confirmation dialog when settings are complete.









Printing the Date of Recording

To print the date of recording on pictures, press **DISP/BACK** in steps 1–2 to display the PictBridge menu (see "Printing the DPOF Print Order," below). Press the selector up or down to highlight **PRINT WITH DATE** and press **MENU/OK** to return to the PictBridge display (to print pictures without the date of recording, select **PRINT WITHOUT DATE**).




If no pictures are selected when the **MENU/OK** button is pressed, the camera will print one copy of the current picture.

Printing the DPOF Print Order

To print the print order created with **PRINT ORDER (DPOF)** in the playback menu (**E** 66).

1 In the PictBridge display, press **DISP/ BACK** to open the PictBridge menu.





Press the selector up or down to highlight **PRINT DPOF**.



Press MENU/OK to display a confirmation dialog.





1 Press **MENU/OK** to start printing.



During Printing

The message shown at right is displayed during printing. Press DISP/BACK to cancel before all pictures are printed (depending on the printer, BACCOCANCEL printing may end before the current picture has printed).



If printing is interrupted, press **D** to turn the camera off and then on again.

Disconnecting the Camera

Confirm that "PRINTING" is not displayed in the monitor and turn the camera off. Disconnect the USB cable



- Print pictures from a memory card that has been formatted in the camera
- If the printer does not support date printing, the **PRINT WITH DATE** option will not be available in the PictBridge menu and the date will not be printed on the pictures in the DPOF print order.
- When pictures are printed via direct USB connection, page size, print quality, and border selections are made using the printer.

Creating a DPOF Print Order

The PRINT ORDER (DPOF) option in the play-back menu can be used to create a digital "print order" for PictBridge-compatible printers (124) or devices that support DPOF.

DP0F

DPOF (Digital Print Order Format) is standard that allows pictures to be printed from "print orders" stored on a memory card. The information in the order includes the pictures to be printed, date imprint, and the number of copies of each picture.

■ WITH DATE _ /WITHOUT DATE

To modify the DPOF print order, select PRINT ORDER (DPOF) in the playback menu and press the selector up or down to highlight WITH DATE or WITHOUT DATE.



WITH DATE : Print date of recording on pictures.

WITHOUT DATE: Print pictures without date.

Press MENU/OK and follow the steps below.

Press the selector left or right to display a picture you wish to include in or remove from the print order.



Press the selector up or down to choose the number of copies (up to 99). To remove a picture from the order, press the selector down until the number of copies is 0.



■ Intelligent Face Detection

If the current picture was created with Intelligent Face Detection, pressing ▼ sets the number of copies to the number of faces detected.



When pictures are printed via direct USB connection, page size, print quality, and border selections are made using the printer.

3 Repeat steps 1–2 to complete the print order. Press **MENU/OK** to save the print order when settings are complete, or **DISP/BACK** to exit without changing the print order.



4 The total number of prints is displayed in the monitor. Press **MENU/OK** to exit.



The pictures in the current print order are indicated by a icon during playback.



- Print orders can contain a maximum of 999 pictures.
- If a memory card is inserted ■RESET DPOF OK? containing a print order created by another camera, the message shown at right will be displayed. Pressing MENU/ OIS YES GACKNO



OK cancels the print order; a new print order must be created as described above.

■ RESET ALL

To cancel the current print order, select **RESET ALL** in the PRINT ORDER (DPOF) menu. The confirmation shown at right will



be displayed; press **MENU/OK** to remove all pictures from the order.

Viewing Pictures on a Computer

The supplied software can be used to copy pictures to a computer, where they can be stored, viewed, organized, and printed. Before proceeding, install the software as described below. **Do NOT connect the camera to the computer until installation is complete**.

Windows: Installing MyFinePix Studio

1 Confirm that the computer meets the following system requirements:

	Windows 8/Windows 7 (SP 1)/Windows Vista (SP 2) ¹	Windows XP (SP 3) ¹	
СРИ	3 GHz Pentium 4 or better 2 GHz Pentium 4 or better		
CPU	(2.4 GHz Core 2 Duo or better) ²	(2.4 GHz Core 2 Duo or better) ²	
RAM	1 GB or more	512 MB or more	
NAW	I do di mole	(1 GB or more) ²	
Free disk space	2 GB or more		
GPU	Supports DirectX 9 or later	Supports DirectX 7 or later	
	(recommended)	(required; performance not guaranteed with other GPUs)	
Video	1,024×768 pixels or more with 24-bit color or better		
	Built-in USB port recommended. Operation is not guaranteed with other USB ports.		
Other	Internet connection (broadband recommended) required to install .NET Framework (if necessary), to use		
Other	auto update feature, and when performing such tasks as sharing pictures on-line or via e-mail.		
	Installation of .Net Framework 3.5 SP1 required to use upload picture feature and MapViewer.		

¹ Other versions of Windows are not supported. Only pre-installed operating systems are supported; operation is not guaranteed on home-built computers or computers that have been upgraded from earlier versions of Windows.

² Recommended when displaying HD movies.

- **2** Start the computer. Log in to an account with administrator privileges before proceeding.
- **3** Exit any applications that may be running and insert the installer CD in a CD-ROM drive.
 - Windows 8/Windows 7/Windows Vista

 If an AutoPlay dialog is displayed, click SETUP.

 EXE. A "User Account Control" dialog will then be displayed; click Yes (Windows 8/Windows 7) or Allow (Windows Vista).

The installer will start automatically; click **Install MyFinePix Studio** and follow the onscreen instructions to install MyFinePix Studio.

If the Installer Does Not Start Automatically (Windows 7/Windows Vista/Windows XP)

If the installer does not start automatics

If the installer does not start automatically, select **Computer** or **My Computer** from the Start menu, then double-click the **FINEPIX** CD icon to open the FINEPIX CD window and double-click **setup** or **SETUP.EXE**.

If the Installer Does Not Start Automatically (Windows 8)

- **1** Select **Desktop** on the Start screen.
- 2 Select File Explorer on the taskbar.
- **3** Select **Computer** in the navigation pane.
- 4 Double-click the drive icon inserting the FINEPIX CD and follow the on-screen instructions to install.
- **4** If prompted to install Windows Media Player or DirectX, follow the on-screen instructions to complete installation.
- **5** Remove the installer CD from the CD-ROM drive when installation is complete. Store the installer CD in a dry location out of direct sunlight in case you need to re-install the software. The version number is printed at the top of the CD label for reference when updating the software or contacting customer support.

Installation is now complete. Proceed to "Connecting the Camera" on page 71.

Importing pictures or movies to Mac (Macintosh)

Use a standard application in Mac OS such as **Image Capture** to import pictures or movies to Mac.

Connecting the Camera

1 If the pictures you wish to copy are stored on a memory card, insert the card into the camera (■ 11).



Windows users may require the Windows CD when starting the software for the first time.

1

Loss of power during transfer could result in loss of data or damage to the memory card. Charge the battery before connecting the camera.

2 Turn the camera off and connect the supplied USB cable as shown, making sure the connectors are fully inserted. Connect the camera directly to the computer; do not use a USB hub or keyboard.



3 Press the ▶ button for about a second to turn the camera on. After starting MyFinePix Studio, follow the on-screen instructions to copy pictures to the computer. To exit without copying pictures, click **Cancel**.

For more information on using the supplied software, start the application and select the appropriate option from the **Help** menu.

1

- If a memory card containing a large number of images is inserted, there may be a delay before the software starts and you may be unable to import or save images. Use a memory card reader to transfer pictures.
- Make sure that the computer does not display a message stating that copying is in progress and that the indicator lamp is out before turning the camera off or disconnecting the USB cable (if the number of images copied is very large, the indicator lamp may remain lit after the message has cleared from the computer display). Failure to observe this precaution could result in loss of data or damage to the memory card.
- Disconnect the camera before inserting or removing memory cards.
- In some cases, it may not be possible to access pictures saved to a network server using the supplied software in the same way as on a standalone computer.
- The user bears all applicable fees charged by the phone company or Internet service provider when using services that require an Internet connection.

Disconnecting the Camera

After confirming that the indicator lamp is out, follow the on-screen instructions to turn the camera off and disconnect the USB cable.

Uninstalling the Supplied Software

Only uninstall the supplied software when it is no longer required or before beginning reinstallation. After quitting the software and disconnecting the camera, open the control panel and use "Programs and Features" (Windows 8/Windows 7/Windows Vista) or "Add or Remove Programs" (Windows XP) to uninstall MyFinePix Studio. Under Windows, one or more confirmation dialogs may be displayed; read the contents carefully before clicking **OK**.

Using the Menus: Shooting Mode

Using the Shooting Menu

- Press **MENU/OK** to display the shooting menu.
- (MENU)
- Press the selector up or down to highlight the desired menu item.



Press the selector right to display options for the highlighted item.



Press the selector up or down to highlight the desired option.



Press **MENU/OK** to select the highlighted option.



Press **DISP/BACK** to exit from the menu.



Shooting Menu Options

Menu item	Description	Options	Default
SCENE POSITION	Choose a scene for SP mode (🕮 22).	・	SP1:⊕ SP2:⊕‡
[<u>50</u> 150	Adjust ISO sensitivity. Choose higher values when the subject is poorly lit.	AUTO (3200)/AUTO (1600)/ AUTO (800)/AUTO (400)/ 12800/6400/3200/1600/ 800/400/200/100	AUTO (1600)
★ IMAGE SIZE	Choose image size and aspect ratio (🕮 76).	4:3/ 3:2/ 16:9/ M 4:3/ M 16:9/ S 4:3/ S 16:9	4:3
Ⅲ IMAGE QUALITY	Choose image quality (🕮 77).	FINE/NORMAL	NORMAL
FINEPIX COLOR	Shoot pictures in standard or saturated color or in blackand white (1998).	Šūr/Č≡/Š≡	डॉक
WB WHITE BALANCE	Adjust color for different light sources (🕮 78).	AUTO/口/来/を/ 岩/岩/岩/	AUTO
FACE DETECTION	Choose whether the camera automatically detects and sets focus and exposure for human portrait subjects (1943) 35).		OFF
國 PHOTOMETRY	Choose how the camera meters exposure (🕮 79).	@/ •]/[]	[0]

Menu item	Description	Options	Default
AF MODE	Choose how the camera selects a focus area (🕮 80).	⊞/+/⊹/□/⊑	⊕
MOVIE AF MODE	This option controls how the camera selects the focus area for movies (© 81).	⊎/□	
₩ MOVIE MODE	Choose a frame size for movies (🕮 60).	## 1920 × 1080/ ## 1280 × 720/ ##/ ## 640 × 480/ ## 320 × 240/ ## 320 × 120	1920 × 1080
☐ AE BKT EV STEPS	Choose the size of the bracketing increment when \blacksquare is selected in continuous shooting mode (\blacksquare 81).	±1/3 EV / ±2/3 EV / ±1 EV	±1/3 EV
₹ FLASH	Adjust flash brightness (🗐 81).	$-\frac{2}{3}$ EV $-+\frac{2}{3}$ EV in steps of $\frac{1}{3}$ EV	0
CUSTOM SET	Save settings for P , S , A , and M modes (🕮 34).	_	_

ISO ISO

Control the camera's sensitivity to light. Higher values can be used to reduce blur when lighting is poor; note, however, that mottling may appear in pictures taken at high sensitivities. If **AUTO**, **AUTO** (800), or **AUTO** (400) is selected, the camera will adjust sensitivity automatically in response to shooting conditions. The maximum values that will be selected by the camera at settings of **AUTO** (800) and **AUTO** (400) are 800 and 400 respectively. Settings other than **AUTO** are shown by an icon in the display.



Sensitivity is not reset when the camera is turned off or another shooting mode is selected.

IMAGE SIZE

Choose the size and aspect ratio at which still pictures are recorded. Large pictures can be printed at large sizes with no drop in quality; small pictures require less memory, allowing more pictures to be recorded.

The number of pictures that can be taken at the selected setting is shown in the display (118).

Size Versus Aspect Ratio				
Size				
	Option	Prints at sizes up to		
	0	34×25 cm (13.5×10 in.)		
	M	24×18 cm (9.5×7 in.)		
	8	17×13 cm (7 × 5 in.)		

Aspect ratio 4:3: Pictures have the same proportions as the camera display.

- **3:2**: Pictures have the same proportions as a frame of 35 mm film
- **16:9**: Suited for display on High Definition (HD) devices.



Image size is not reset when the camera is turned off or another shooting mode is selected.

MAGE QUALITY

Choose how much image files are compressed. Select **FINE** (low compression) for higher image quality, **NORMAL** (high compression) to increase the number of pictures that can be stored.

FINEPIX COLOR

Enhance contrast and color saturation or take pictures in black and white.

Option	Description		
STANDARD	Standard contrast and saturation.		
STANDAND	Recommended in most situations.		
	Vivid contrast and color. Choose		
CHROME	for vivid shots of flowers or en-		
CHROME	Vivid contrast and color. Choose for vivid shots of flowers or en- hanced greens and blues in land-		
	scapes.		
B&W	Take pictures in black and white.		

Settings other than **STANDARD** are shown by an icon in the display.



- FINEPIX COLOR is not reset when the camera is turned off or another shooting mode is selected.
- The effects of CHROME vary from scene to scene and may be difficult to discern with some subjects. Depending on the subject, the effects of CHROME may not be visible in the display.

WB WHITE BALANCE

For natural colors, choose a setting that matches the light source.

Option	Description
AUTO	White balance adjusted automatically.
	Measure a value for white balance.
*	For subjects in direct sunlight.
*=	For subjects in the shade.
₩í	Use under "daylight" fluorescent lights.
₩2	Use under "warm white" fluorescent lights.
辫	Use under "cool white" fluorescent lights.
-Å-	Use under incandescent lighting.

If **AUTO** does not produce the desired results (for example, when taking close-ups), select \square and measure a value for white balance or choose the option that matches the light source.



- At settings other than 📮, auto white balance is used with the flash. Lower the flash (🗎 40) to take pictures at other settings.
- Results vary with shooting conditions. Play pictures back after shooting to check colors in the monitor.

■ □: Custom White Balance

Choose to adjust white balance for unusual lighting conditions. White balance measurement options will be displayed; frame a white object so that it fills the monitor and press the shutter button all the way down to measure white balance.

If "COMPLETED!" is displayed, press **MENU/OK** to set white balance to the measured value. This value can be reselected by pressing **MENU/OK** when custom white balance options are displayed.

If "UNDER" is displayed, raise exposure compensation (☐ 49) and try again.

If "OVER" is displayed, lower exposure compensation and try again.

To give a deliberate color cast to your photographs, measure a value for custom white balance using a colored instead of a white object.

D PHOTOMETRY

Choose how the camera meters exposure when Intelligent Face Detection is off.

- MULTI: Automatic scene recognition is used to adjust exposure for a wide range of shooting conditions.
- End SPOT: The camera meters lighting conditions at the center of the frame. Recommended when the background is much brighter or darker than the main subject. Can be used with focus lock (1999) 37) to meter off-center subjects.
- [] AVERAGE: Exposure is set to the average for the entire frame. Provides consistent exposure across multiple shots with the same lighting, and is particularly effective for landscapes and portraits of subjects dressed in black or white.

I AF MODE

This option controls how the camera selects the focus area when Intelligent Face Detection is off (1) 35). Regardless of the option selected, the camera will focus on the subject in the center of the monitor when macro mode is on (1) 39).

- MULTI: When the shutter button is pressed halfway, the camera detects high-contrast subjects near the center of the frame and selects the focus area automatically (if the focus frame is not displayed, select ① CENTER and use focus lock; ② 37).







Focus frame

• AREA: The focus position can be chosen manually by pressing the selector up, down, left, or right and pressing MENU/OK when the focus



brackets are in the desired position. Choose for precise focus when the camera is mounted on a tripod. Note that exposure is set for the subject in the center of the frame; to meter an off-center subject, use AF/AE lock (EE 37).

- CONTINUOUS: The camera continually adjusts focus to reflect changes in the distance to the subject even when the shutter button is not pressed (note that this increases the drain on the battery).
- ELL TRACKING: Position the subject in the center focus area and press the selector left to select tracking. Focus will track the subject as it moves through the frame.



MOVIE AF MODE

This option controls how the camera selects the focus area for movies.

Option	Description		
(ENTER	The camera focuses on the subject in the center of the frame.		
	in the center of the frame.		
	The camera continuously adjusts focus to reflect changes in the distance to subjects near the center of		
□ CONTINUOUS	focus to reflect changes in the dis-		
LI CONTINUOUS	tance to subjects near the center of		
	the frame.		



Note that in \square mode, the camera focuses continuously, increasing the drain on the battery, and that the sound of the camera focusing may be audible.

AE BKT EV STEPS

Choose the size of the exposure bracketing increment used when ♠ (AE bracketing) is selected in continuous shooting mode (♠ 46).

Choose from increments of $\pm \frac{1}{3}$ EV, $\pm \frac{2}{3}$ EV, and ± 1 EV.

理 FLASH

Adjust flash brightness. Choose from values between $+\frac{2}{3}$ EV and $-\frac{2}{3}$ EV. The default setting is ± 0 . Note that the desired results may not be achieved depending on shooting conditions and the distance to the subject.

Using the Menus: Playback Mode

Using the Playback Menu

1 Press the **b** button to enter playback mode.



2 Press **MENU/OK** to display the playback menu.



3 Press the selector up or down to highlight the desired menu item.



Press the selector right to display options for the highlighted item.



5 Press the selector up or down to highlight the desired option.



6 Press **MENU/OK** to select the highlighted option.



Playback Menu Options

The following options are available:

J 1	tions are available.
Option	Description
□ PHOTOBOOK ASSIST	Create books from your favorite photos (🗐 55).
IMAGE SEARCH	Search for pictures by date, subject, scene, file type, or rating (🕮 57).
m ERASE	Delete all or selected pictures (🕮 58).
MOVIE EDIT	Edit movies (🕮 83).
MARK FOR UPLOAD	Select pictures for upload to YouTube or FACEBOOK (◯ 84).
■ SLIDE SHOW	View pictures in a slide show (🕮 86).
RED EYE REMOVAL	Create copies with reduced red eye (19 87).
□ PROTECT	Protect pictures from accidental deletion (\blacksquare 88).
CROP	Create cropped copies of pictures (1998).
RESIZE	Create small copies of pictures (🕮 90).
IMAGE ROTATE	Rotate pictures (🕮 91).
☑ VOICE MEMO	Add voice memos to pictures (🕮 92).
PRINT ORDER (DPOF)	Select pictures for printing on DPOF- and PictBridge-compatible devices (© 66).
DISP. ASPECT	Choose how High Definition (HD) devices display pictures (🗎 93).

MOVIE EDIT

Fdit movies

■ MOVIE TRIMMING

Remove opening or ending footage to create an edited copy of the current movie.

- Display the desired movie.
- 2 Select MOVIE EDIT in the playback menu, then select MOVIE TRIMMING. To remove footage from the start of the copy, proceed to Step 3; otherwise, proceed to Step 4.
- **3** Press the selector down to begin playback and press it down again when the new opening frame is reached.
- **4** Press **MENU/OK**. To remove footage from the end of the copy, proceed to Step 5; otherwise, proceed to Step 6.
- **5** Press the selector down to begin playback and press it down again when the new closing frame is reached.
- 6 Press MENU/OK to save the copy.

MOVIE JOIN

Add existing footage to the end of the current movie to create an edited copy.

- 1 Display the desired movie.
- 2 Select W MOVIE EDIT in the playback menu, then select MOVIE JOIN.
- **3** Press the selector left or right to highlight a movie.
- 4 Press MENU/OK to add the highlighted footage to the end of the current movie and save the resulting copy, or press DISP/BACK to exit without creating a copy.

1

Both movies must have been recorded at the same frame size and frame rate.

MARK FOR UPLOAD

You can select images and movies to be queued for upload to YouTube, Facebook and MyFinePix.com. Select MARK FOR UPLOAD in the playback menu.

■ Add/Remove Items in the Upload Queue

1 Select an upload destination.



Press MENU/OK.



- **3** Select items to be added to, or removed from, the upload queue.
- **▲** Press **MENU/OK** to confirm.
 - Items not in the upload queue will be added to the queue when you select them and press MENU/OK.
 - Items in the upload queue will be removed from the queue when you select them and press MENU/OK.

5 Repeat steps 3 and 4 as necessary and add or remove items. When finished, press DISP/BACK to save the settings.



1/2

- YouTube, FACEBOOK or MyFinePix.com is displayed to indicate items gueued for upload.
- Only movies can be selected for upload to YouTube.
- Only photos can be selected for upload to MyFinePix.

■ Removing All Items From the Upload Queue

You can remove all items from the upload queue.

1 Select RESET ALL. The screen for removing all items from the upload queue is displayed.





2 Select OK.



Press MENU/OK. All items are removed from the upload queue.




•

If there are many items in the upload queue when you select to remove all items from the queue, it may take some time to remove them. To cancel, press **DISP/BACK**.

■ Upload Items

Items added to the upload queue using the camera can be easily uploaded from a computer by using the MyFinePix Studio.

Install MyFinePix Studio (E 69).



•

This feature is available only when using a computer running Windows.

同 SLIDE SHOW

View pictures in an automated slide show. Choose the type of show and press **MENU/OK** to start. Press **DISP/BACK** at any time during the show to view on-screen help. When a movie is displayed, movie playback will begin automatically, and the slide show will continue when the movie ends. The show can be ended at any time by pressing **MENU/OK**.


Option	Displayed in	
NORMAL	Press selector left or right to go back or skip ahead one frame. Select FADE-IN for fade transitions between	
FADE-IN	frames.	
NORMAL 🖭	As above, except that camera automatically zooms in on faces selected with Intelligent Face detection.	
FADE-IN 🖭	As above, except that camera automatically 200ms in on faces selected with intelligent Face detection.	
MULTIPLE	Display several pictures at once.	



The camera will not turn off automatically while a slide show is in progress.

◯ RED EYE REMOVAL

If the current picture is marked with a 🖭 icon to indicate that it was taken with Intelligent Face Detection, this option can be used to remove red-eye. The camera will analyze the image; if red-eye is detected, the image will be processed to create a copy with reduced red-eye.





- Red eye may not be removed if the camera is unable to detect a face or the face is in profile. Results may differ depending on the scene. Red eye can not be removed from pictures that have already been processed using red-eye removal or pictures created with other devices.
- The amount of time needed to process the image varies with the number of faces detected.
- Copies created with **RED EYE REMOVAL** are indicated by a **loop** icon during playback.

PROTECT

Protect pictures from accidental deletion. The following options are available.

■ FRAME

Protect selected pictures.

1 Press the selector left or right to display the desired picture.







Picture not protected

Protected picture

Press MENU/OK to protect the picture. If the picture is already protected, pressing MENU/OK will remove protection from the image.



3 Repeat steps 1–2 to protect additional images. Press **DISP/BACK** to exit when the operation is complete.



■ SET ALL

Press **MENU/OK** to protect all pictures, or press **DISP/BACK** to exit without changing picture status.



■ RESET ALL

Press **MENU/OK** to remove protection from all pictures, or press **DISP/BACK** to exit without changing picture status.



If the number of pictures affected is very large, a message will be displayed while the operation is in progress. Press **DISP/BACK** to exit before the operation is complete.

1

Protected pictures will be deleted when the memory card is formatted (1999).

CROP

To create a cropped copy of a picture, play the picture back and select **CROP** in the playback menu (**2** 82).

1 Use the zoom control to zoom in and out and use the selector to scroll the picture until the desired portion is displayed (to exit to single-frame playback without creating a cropped copy, press **DISP/BACK**).

Press MENU/OK to view the copy size. Larger crops produce larger copies.



3 Press **MENU/OK** to save the cropped copy to a separate file.



4

Pictures taken with other cameras can not be cropped.







Navigation window shows portion of image currently displayed in monitor

If the size of the final copy will be (40), YES will be displayed in yellow.

■ Intelligent Face Detection

If the picture was shot with Intelligent Face Detection (☐ 35), 🔄 will be displayed in the monitor. Press the 🔻 button to zoom in on the selected face.

RESIZE

To create a small copy of a picture, play the picture back and select **ERESIZE** in the playback menu (**ERESIZE** in the playback menu

1 Highlight a size and press **MENU/OK** to display a confirmation dialog.



2 Press **MENU/OK** to copy the picture at the selected size.





MAGE ROTATE

By default, pictures taken in tall orientation are displayed in wide orientation. Use this option to display pictures in the correct orientation in the monitor. It has no effect on pictures displayed on a computer or other device.



- Protected pictures can not be rotated. Remove protection before rotating pictures (1998).
- The camera may not be able to rotate pictures created with other devices.

To rotate a picture, play the picture back and select **2 IMAGE ROTATE** in the playback menu (**2** 82).

1 Press the selector down to rotate the picture 90° clockwise, up to rotate the picture 90° counterclockwise.





2 Press **MENU/OK** to confirm the operation (to exit without rotating the picture, press **DISP/BACK**).



The next time the picture is played back, it will automatically be rotated.


VOICE MEMO

To add a voice memo to a still picture, select **VOICE MEMO** after displaying the picture in playback mode.




Voice memos can not be added to movies or protected pictures. Remove protection from pictures before recording voice memos (88).

1 Hold the camera at a distance of about 20 cm (8 in.) and face the microphone.



2 Press **MENU/OK** to start recording.





3 Press **MENU/OK** again to end recording. Recording ends automatically after 30 seconds.





- If a voice memo already exists for the current picture, a message will be displayed. Select RE-REC to replace the
 existing memo.
- Voice memos are recorded as PCM-format WAV files.

Playing Voice Memos


Pictures with voice memos are indicated by a **Q** icon during playback. To play the voice memo back, select **PLAY** for **Q VOICE MEMO** in the playback menu.



- The camera may not play voice memos recorded with other devices.
- Do not cover the speaker during playback.

DISP. ASPECT

Choose how High Definition (HD) devices display pictures with an aspect ratio of 4:3 (this option is available only when an HDMl cable is connected). Select **16:9** to display the image so that it fills the screen with its top and bottom cropped out, **4:3** to display the entire image with black bands at either side.





Photographs with an aspect ratio of 16:9 are displayed full screen, those with an aspect ratio of 3:2 in a black frame.

The Setup Menu

Using the Setup Menu

- 1 Display the setup menu.
 - **1.1** Press **MENU/OK** to display the menu for the current mode.



1.2 Press the selector left to highlight a left tab.



1.3 Press the selector up or down to select . €.



The setup menu appears.



- **2** Adjust settings.
 - **2.1** Press the selector right to activate the setup menu.



2.2 Press the selector up or down to highlight a menu item.



2.3 Press the selector right to display options for the highlighted item



2.4 Press the selector up or down to highlight an option.



2.5 Press **MENU/OK** to select the highlighted option.



2.6 Press **DISP/BACK** to exit from the menu.



Setup Menu Options

Menu item	Description	Options	Default
DATE/TIME	Set the camera clock (🕮 15).	=	_
TIME DIFFERENCE	Set the clock to local time (🗐 98).	쇼 / +	企
® 言語/LANG.	Choose a language (🕮 15).	_	ENGLISH
SILENT MODE	Disables the AF-assist illuminator (except for the •\$\fixspace4\$ shooting mode), operation sounds, shutter sound, and movie playback sound.	ON/OFF	OFF
RESET	Reset all settings except	_	_
■ FORMAT	Format memory cards (🗐 99).	_	_
☑ IMAGE DISP.	Choose how long pictures are displayed after shooting (🗐 99).	3 SEC / 1.5 SEC / ZOOM / OFF	1.5 SEC
FRAME NO.	Choose how files are named (🕮 100).	CONT./RENEW	CONT.
OPERATION VOL. SHUTTER VOLUME	Adjust the volume of camera controls. Adjust the volume of the shutter sound.	•••• (high) / ••• (mid) / ••• (low) / ••• (mute)	40
SHUTTER SOUND	Choose the sound made by the shutter.	♪1/♪2	♪ 1
D PLAYBACK VOLUME	Adjust the volume for movie and voice memo playback (🕮 101).	_	7
LCD BRIGHTNESS	Control the brightness of the display (🕮 101).	- 5-+5	0

Menu item	Description	Options	Default
MONITOR SUNLIGHT MODE	Select 0N to make the display in the monitor easier to read in bright light.	ON/OFF	OFF
ISS LCD MODE	Choose 30 fps to increase battery life, 60 fps for improved display quality.	30 fps / 60 fps	30 fps
☑ LCD MODE 2	Choose whether to save power to increase battery life (🗎 101).	☑ POWER SAVE ON / ☑ POWER SAVE OFF	☑ POWER SAVE OFF
AUTO POWER OFF	Choose the auto power off delay (🗐 101).	2 MIN/5 MIN/OFF	2 MIN
DUAL IS MODE	Enable image stabilization during shooting (♠)₁ CONTINUOUS) or only when the shutter button is pressed halfway (♠)₂ SHOOTING ONLY). OFF turns image stabilization off (18).	(4) ₁ / (4) ₂ / 0FF	(4) ₁
RED EYE REMOVAL	Remove "red-eye" effects caused by the flash.	ON/OFF	ON
BLINK DETECTION	Turn blink detection on or off (🗐 36).	ON/OFF	ON
INTELLIGENT DIGITAL ZOOM	Enable or disable intelligent digital zoom (🕮 102).	ON/OFF	OFF
MOVIE ZOOM TYPE	Choose the zoom type when recording movies (🗐 59).	Di / Opt	Opt
ZOOM SIDE ZOOM LEVER	Choose the setting of the side lever (🕮 18).	AUTO BACK/H/M/L	Н
A≅ AF ILLUMINATOR	Turn the AF-assist illuminator on or off (🕮 38).	ON/OFF	ON
SAVE ORG IMAGE	Choose ON to save unprocessed copies of pictures taken using RED EYE REMOVAL, RES PRO LOW-LIGHT MODE, or RES HDR.	ON/OFF	OFF
AUTOROTATE PB	Choose ON to automatically rotate "tall" (portrait-orientation) pictures during playback.	ON/OFF	ON

Menu item	Description	Options	Default
BACKGROUND COLOR	Choose a color scheme.	_	_
■ GUIDANCE DISPLAY	Choose whether to display tool tips.	ON/OFF	ON
CUSTOM RESET	Reset all settings for mode C . A confirmation dialog will be displayed, press the selector up or down to highlight OK and press MENU/OK .		_
BATTERY TYPE	Specify the type of battery used in the camera (🕮 10).	(A/(N/(L	(A)
DISCHARGE	Discharge rechargeable Ni-MH batteries (🗐 102).	_	_
DATE DATE STAMP	Choose whether to add shooting date and time to the pictures.	31 + 4 / 31 / OFF	OFF

TIME DIFFERENCE

When travelling, use this option to switch the camera clock instantly from your home time zone to the local time at your destination.

- **1** Specify the difference between local time and your home time zone.
 - **1.1** Press the selector up or down to highlight **← LOCAL**.



1.2 Press the selector right to display the time difference.



1.3 Press the selector left or right to highlight +, -, hours, or minutes; press up or down to edit.




1.4 Press **MENU/OK** when settings are complete.



2 Switch between local time and your home time zone.

- **△ HOME**: Switch to the time currently selected for **⑤ DATE/TIME** (**□** 15).
- **← LOCAL**: Switch to local time. If this option is selected, **←** and the time and date will be displayed in yellow for three seconds each time the camera is turned on.



After changing time zones, check that the date and time are correct.

■ FORMAT

Format a memory card. Highlight **OK** and press **MENU/OK** to begin formatting.

1

- All data—including protected pictures—will be deleted. Be sure important files have been copied to a computer or other storage device.
- Do not open the battery cover during formatting.

☑ IMAGE DISP.

Choose an option other than **OFF** to display pictures in the monitor after shooting. Pictures can be displayed for 1.5 s (1.5 SEC), 3 s (3 SEC), or until the **MENU/OK** button is pressed (**ZOOM** (**CONTINUOUS**)). If **ZOOM** (**CONTINUOUS**) is selected, photos can be zoomed in to check focus and other fine details (see page 51). Note that **ZOOM** (**CONTINUOUS**) is disabled in continuous shooting mode (**14** 46), and that the colors displayed at settings of **1.5 SEC** and **3 SEC** may differ from those in the final picture.

When the picture is zoomed in, the selector can be used to view areas of the image not currently visible in the display.

ZOOM (CONTINUOUS) is disabled in the following case:


- • is selected in the shooting mode.
- An option other than OFF is selected for CONTINUOUS.

Blink Detection (🕮 36)

At settings other than **OFF**, a warning will be displayed if the camera detects subjects who may have blinked when the picture was taken. If **ZOOM (CONTINUOUS)** is selected, you can view these subjects using zoom.

I FRAME NO.

New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed dur-



ing playback as shown at right. **PRAME NO.** controls whether file numbering is reset to 0001 when a new memory card is inserted or the current memory card is formatted.

- **CONTINUOUS**: Numbering continues from the last file number used or the first available file number, whichever is higher. Choose this option to reduce the number of pictures with duplicate file names
- **RENEW**: Numbering is reset to 0001 after formatting or when a new memory card is inserted.



- If the frame number reaches 999-9999, the shutter release will be disabled (116).
- Selecting RESET (■ 95) resets FRAME NO. to CONTINUOUS but does not reset frame numbering.
- Frame numbers for pictures taken with other cameras may differ.

TD PLAYBACK VOLUME

Press the selector up or down to choose volume for movie and voice memo playback and press **MENU/OK** to select.

IXI LCD BRIGHTNESS

Press the selector up or down to choose display brightness and press **MENU/OK** to select.

☑ LCD MODE 2

Choose whether to save power to increase battery life. This option does not take effect during playback or recording movies.

Option	Description
☑ POWER SAVE ON	The display dims to save power if no operations are performed for a few seconds. Normal brightness can be restored by pressing the shutter button halfway.
☑ POWER SAVE OFF	Automatic dimming off.

FIT AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually. Note that regardless of the option selected, the camera will not turn off automatically when connected to a printer (\$\equiv 63\$) or computer (\$\equiv 71\$) or when a slide show is in progress (\$\equiv 86\$).

Reactivating the Camera

To reactivate the camera after it has turned off automatically, use the **ON/OFF** switch or press the **▶** button for about a second (🗎 14).

INTELLIGENT DIGITAL ZOOM


If **ON** is selected, selecting **T** at the maximum optical zoom position triggers intelligent digital zoom, further magnifying the image while processing it for sharp, high-resolution results.



- Intelligent digital zoom may end when another mode is selected.
- Intelligent digital zoom may sometimes produce lower quality images than optical zoom.
- The time needed to record images increases.
- Intelligent digital zoom is not available in continuous mode or during movie recording.

Zoom indicator,
INTELLIGENT DIGITAL
ZOOM off

Zoom indicator,
INTELLIGENT DIGITAL
ZOOM on (except for super
macro mode)



■ DISCHARGE (Ni-MH Batteries Only)

The capacity of rechargeable Ni-MH batteries may be temporarily reduced when new, after long periods of disuse, or if they are repeatedly recharged before being fully discharged. Capacity can be increased by repeatedly discharging the batteries using the DISCHARGE option and recharging them in a battery charger (sold separately). Do not use DISCHARGE with non-rechargeable batteries, and note that the batteries will not discharge if the camera is powered by an optional AC power adapter and DC coupler.

1 Selecting **DISCHARGE** displays a confirmation dialog. Press **MENU/0K**.



Select OK.



3 Press **MENU/OK** to begin discharging the batteries. When the batteries are fully discharged, the battery level indicator will blink red and the camera will turn off. To cancel the process before the batteries are fully discharged, press **DISP/BACK**.



DATE STAMP


To add shooting date and time, choose **31** + **2**. To add only shooting date, choose **31**. When **OFF** is selected, no information will be added to the pictures.



- Added shooting date and time can not be deleted from the pictures. To take pictures without date and time, select OFF for DATE STAMP.
- When the camera clock is not set, setting dialog will be displayed. Set the date and time (🗎 15).
- When using **DATE STAMP**, selecting **WITHOUT DATE** for **PRINT ORDER (DPOF)** is recommended (☐ 66).
- Date and time can not be added to the movies and the panoramas.

Optional Accessories

The camera supports a wide range of accessories from FUJIFILM and other manufacturers.



^{*1} Available separately.

^{*2} SDXC memory card is not supported.

Accessories from FUJIFILM

The following optional accessories are available from FUJIFILM. For the latest information on the accessories available in your region, check with your local FUJIFILM representative or visit http://www.fujifilm.com/products/digital_cameras/index.html.

AC power adapter	AC-5VX (requires CP-04 DC coupler)	Use for extended playback or when copying pictures to a computer (shape of adapter and plug vary with region of sale).	
DC coupler	CP-04	Connect the AC-5VX AC power adapter to the camera.	
Digital viewer	FINEPIX REAL 3D V3	View 3D images without 3D glasses.	

Caring for the Camera

To ensure continued enjoyment of the product, observe the following precautions.

Storage and Use

If the camera will not be used for an extended period, remove the battery and memory card. Do not store or use the camera in locations that are:

- exposed to rain, steam, or smoke
- very humid or extremely dusty
- exposed to direct sunlight or very high temperatures, such as in a closed vehicle on a sunny day
- extremely cold
- subject to strong vibration
- exposed to strong magnetic fields, such as near a broadcasting antenna, power line, radar emitter, motor, transformer, or magnet
- in contact with volatile chemicals such as pesticides
- next to rubber or vinyl products

■ Water and Sand

Exposure to water and sand can also damage the camera and its internal circuitry and mechanisms. When using the camera at the beach or seaside, avoid exposing the camera to water or sand. Do not place the camera on a wet surface.

■ Condensation

Sudden increases in temperature, such as occur when entering a heated building on a cold day, can cause condensation inside the camera. If this occurs, turn the camera off and wait an hour before turning it on again. If condensation forms on the memory card, remove the card and wait for the condensation to dissipate.

Cleaning

Use a blower to remove dust from the lens and monitor, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of FUJIFILM lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied. Care should be taken to avoid scratching the lens or monitor. The camera body can be cleaned with a soft, dry cloth. Do not use alcohol, thinner, or other volatile chemicals.

Traveling

Keep the camera in your carry-on baggage. Checked baggage may suffer violent shocks that could damage the camera.

Troubleshooting

Power and Battery

	Problem	Possible cause	Solution	Page
		The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	9
		The batteries are not in the correct orienta-	Re-insert the batteries in the correct orienta-	9
		tion.	tion.	9
	The camera does	The battery-chamber cover is not latched.	Latch the battery-chamber cover.	10
	not turn on.	The AC power adapter and DC coupler are	Make sure that the AC power adapter and DC	
	liot tuili on.	not connected properly.	coupler are properly connected.	
		The camera has been left for an extended	After inserting the batteries or connecting the	
		period with no batteries inserted and the	AC power adapter/DC coupler, wait a few mo-	—
		AC power adapter/DC coupler unplugged.	ments before turning the camera on.	
			Warm the batteries by placing them in a pocket	
		The batteries are cold.	or other warm place and re-insert them in the	vi
			camera immediately before taking a picture.	
		There is dirt on the battery terminals.	Clean the terminals with a soft, dry cloth.	_
1		ON is selected for MONITOR SUNLIGHT	Select OFF to reduce the drain on the battery.	96
		MODE.	Select Of to reduce the drain on the battery.	90
	The batteries run	The camera is in SRAUTO mode.	Select another shooting mode.	22
	down quickly.		Discharge Ni-MH batteries using the 🗖 DISCHARGE	
			option and recharge them in a battery charger (sold	
			separately). If the batteries do not hold a charge af-	102
			ter repeated discharging and recharging, they have	102
		(rechargeable Ni-MH batteries only).	reached the end of their service life and must be	
			replaced.	
		☐ CONTINUOUS is selected for ■ AF MODE .	Select a different focusing option.	80
	The camera turns	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	9
	off suddenly.	The AC power adapter or DC coupler has	Make sure that the AC power adapter and DC	
Joil sudd	on suddenly.	been disconnected.	coupler are properly connected.	-

Menus and Displays

Problem	Possible cause	Solution	Page
Menus and displays are	English is not selected for the ② 言語/LANG.	Soloet ENGLISH	15, 95
not in English.	option in the setup menu.	belect ENGLISH .	15, 95

Shooting

	Problem	Possible cause	Solution	Page
		Memory is full.	Insert a new memory card or delete pictures.	11, 58
	No picture is	Memory is not formatted.	Format the memory card.	99
	taken when the shutter	There is dirt on the memory card contacts.	Clean the contacts with a soft, dry cloth.	_
Taking	button is	The memory card is damaged.	Insert a new memory card.	11
pictures	pressed.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	9
pictures	presseu.	The camera has turned off automatically.	Turn the camera on.	14
	The monitor goes dark after shooting.	The flash has fired.	The monitor may darken while the flash charges. Wait for the flash to charge.	40
	The camera	The subject is close to the camera.	Select macro mode.	39
Focus	does not	The subject is far away from the camera.	Cancel macro mode.	39
	focus.	The subject is not suited to autofocus.	Use focus lock.	37
3D image	3D images do not turn out as expected.		Use a tripod or change the distance the camera is moved between the first and second shots.	

	Problem	Possible cause	Solution	Page
		Intelligent Face Detection is not available in the current shooting mode.	Choose a different shooting mode.	22
		The subject's face is obscured by sunglasses, a hat, long hair, or other objects.	Remove the obstructions.	
Intelligent Face	No face is	The subject's face occupies only a small area of the frame.	Change the composition so that the subject's face occupies a larger area of the frame.	35
Detection	detected.	The subject's head is tilted or horizontal.	Ask the subject to hold their head straight.	
		The camera is tilted.	Hold the camera straight.	18
		The subject's face is poorly lit.	Shoot in bright light.	
	Wrong subject selected.	The selected subject is closer to the center of the frame than the main subject.	Recompose the picture or turn face detection off and frame the picture using focus lock.	37, 74
Close-ups	Macro mode is not available.	Macro mode is not available in the current shooting mode.	Choose a different shooting mode.	22, 39
-		The flash is lowered.	Raise the flash.	40
		The flash is charging.	Wait for the flash to charge.	40
	The flash does	The flash is not available in the current shooting mode.	Choose a different shooting mode.	22
	not me.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	9
Flash		The camera is in super macro or continuous shooting mode.	Turn super macro and continuous shooting modes off.	39, 46
	Flash mode not available.	The desired flash mode is not available in the current shooting mode.	Choose a different shooting mode.	22
	The flash does	The subject is not in range of the flash.	Position the subject in range of the flash.	121
	not fully light	The flash window is obstructed.	Hold the camera correctly.	18
	the subject.	Fast shutter speed selected.	Choose a slower shutter speed.	32, 33

	Problem	Possible cause	Solution	Page
		The lens is dirty.	Clean the lens.	106
	Pictures are	The lens is blocked.	Keep objects away from the lens.	18
	blurred.	!AF is displayed during shooting and the focus frame is displayed in red.	Check focus before shooting.	114
		!o is displayed during shooting.	Use the flash or a tripod.	40
Problem images Pictures are mottled. Vertical line appear in pictures.	Dictures are		function.	—
		The camera has been used continuously at high temperatures or a temperature warning is displayed.	Turn the camera off and wait for it to cool down.	_
	1	The camera has been used continuously at high temperatures.	Turn the camera off and wait for it to cool down.	_

Playback

	Problem	Possible cause	Solution	Page
Pictures are grainy.	The pictures were taken with a different make or model of camera.	_		
Pictures	Playback zoom unavailable.	The picture has been resized or cropped to (20) / (20) or is from another make or model of camera.		51
	No sound in	The camera is in silent mode.	Turn silent mode off.	19
Audio	voice memo	Playback volume is too low.	Adjust playback volume.	101
Auulu	and movie playback.	The microphone was obstructed.	Hold the camera correctly during recording.	59, 92
		The speaker is obstructed.	Hold the camera correctly during playback.	61, 93
Deletion	Selected pictures not deleted.	Some of the pictures selected for deletion are protected.	Remove protection using the device with which it was originally applied.	88
Frame no.	File number- ing is unex- pectedly reset.	The battery-chamber cover was opened while the camera was on.	Turn the camera off before opening the bat- tery-chamber cover.	14

Connections

	Problem	Possible cause	Solution	Page
	Monitor is off.	The camera is connected to a TV.	View pictures on the TV.	62
TV	No nicturo or	The camera is not properly connected.	Connect the camera correctly.	62
I V	No picture or sound.	Input on the television is set to "TV".	Set the TV input correctly.	<u> </u>
	souria.	The volume on the television is too low.	Adjust the volume.	
Computer	The computer does not recognize the camera.	The camera is not properly connected.	Connect the camera correctly.	71
	Pictures can	The camera is not properly connected.	Connect the camera correctly.	63
	not be printed.	The printer is off.	Turn the printer on.	
PictBridge	Only one copy is printed. The date is not printed.	The printer is not PictBridge-compatible.	_	_

Miscellaneous

Problem	Possible cause	Solution	Page
Nothing happens when the shutter but-	Temporary camera malfunction.	Remove and reinsert the batteries or disconnect and reconnect the AC power adapter/DC coupler.	9
ton is pressed.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	9
The camera does not function as expected.	Temporary camera malfunction.	Remove and reinsert the batteries or disconnect and reconnect the AC power adapter/DC coupler. If the problem persists, contact your FUJIFILM dealer.	9
I want to use an AC power adapter and DC coupler overseas.	Check the label on the AC power adapter.	The AC power adapter can be used with voltages of 100–240V and power frequency of 50/60Hz. However, power outlets differ depending on the regions. Consult your travel agent for information on plug adapters.	_
Hue or content of display changes unexpectedly.	ON is selected for MONITOR SUNLIGHT MODE.	Choose OFF for MONITOR SUNLIGHT MODE .	96
Date and time added by DATE STAMP are not correct.	The camera clock is not correctly set.	Reset the date and time.	15
Date and time are added to the pictures.	31+② or 31 is selected for ME DATE STAMP option.	Added shooting date and time can not be deleted from the pictures. To take pictures without date and time, select OFF for DATE STAMP .	103

Warning Messages and Displays

The following warnings are displayed in the monitor:

Warning	Description	Solution
□ (red)	Batteries are low.	Insert fresh or fully-charged spare batteries.
□ (blinks red)	Batteries are exhausted.	insert nestroi runy-charged spare batteries.
j oʻ	Slow shutter speed. Picture may be blurred.	Use the flash or mount the camera on a tripod.
!AF (displayed in red with red focus frame)	The camera can not focus.	 Use focus lock to focus on another subject at the same distance, then recompose the picture (37). Use macro mode to focus when taking close-ups.
Aperture or shutter speed shown in red	The subject is too bright or too dark. The picture will be over- or under-exposed.	If the subject is dark, use the flash.
BLINK DETECTED	A subject or subjects may have blinked.	Retake the photograph if desired.
FOCUS ERROR LENS CONTROL ERROR	Camera malfunction.	Turn the camera off and then on again, taking care not
	TURN THE CAMERA OFF, REMOVE LENS CAP OR OBSTRUCTION AND TURN THE CAMERA ON	to touch the lens. If the message persists, contact a FUJIFILM dealer.
!}	The camera has been used continuously at high temperatures. If no action is taken, the camera will turn off automatically.	

Warning	Description	Solution							
	The memory card is not formatted or the memory card was formatted in a computer or other device.	Format the memory card using the EN FORMAT option in the camera setup menu (EM 99).							
CARD NOT INITIALIZED	The memory card contacts require cleaning.	Clean the contacts with a soft, dry cloth. If the me sage is repeated, format the memory card (🗎 99). the message persists, replace the memory card.							
	Camera malfunction.	Contact a FUJIFILM dealer.							
PROTECTED CARD	The memory card is locked.	Unlock the memory card (🕮 11).							
BUSY	The memory card is incorrectly formatted.	Use the camera to format the memory card (🕮 99).							
	The memory card is not formatted for use in the camera.	Format the memory card (🗐 99).							
CARD ERROR	The memory card contacts require cleaning or the memory card is damaged.	Clean the contacts with a soft, dry cloth. If the message is repeated, format the memory card (© 99). If the message persists, replace the memory card.							
	Incompatible memory card.	Use a compatible memory card.							
	Camera malfunction.	Contact a FUJIFILM dealer.							
SD MEMORY FULL	The memory card is full; pictures can not be recorded.	Delete pictures or insert a memory card with more free space.							
WRITE FRROR	Memory card error or connection error.	Re-insert the memory card or turn the camera off and then on again. If the message persists, contact a FUJIFILM dealer.							
While Ennon	Not enough memory remaining to record additional pictures.	Delete pictures or insert a memory card with more free space.							
	The memory card is not formatted.	Format the memory card (🗐 99).							

Warning	Description	Solution
	The file is corrupt or was not created with the camera.	The file can not be played back.
READ ERROR	The memory card contacts require cleaning.	Clean the contacts with a soft, dry cloth. If the message is repeated, format the memory card (🕮 99). If the message persists, replace the memory card.
	Camera malfunction.	Contact a FUJIFILM dealer.
FRAME NO. FULL	The camera has run out of frame numbers (current frame number is 999-9999).	Format the memory card and select RENEW for the FRAME NO. option in the FRAME NO. Take a picture to reset frame numbering to 100-0001, then return to the FRAME NO. menu and select CONTINUOUS .
TOO MANY FRAMES	An attempt was made to search more than 5,000 images.	The maximum number of images on which searches can be performed is 5,000.
PROTECTED FRAME	An attempt was made to add a voice memo to or delete a protected picture.	Remove protection before adding voice memos to or deleting pictures.
■ ERROR	Voice memo file is corrupt.	The voice memo can not be played back.
LINION	Camera malfunction.	Contact a FUJIFILM dealer.
640 CAN NOT CROP	An attempt was made to crop a 🚳 picture.	
CAN NOT CROP	The picture selected for cropping is damaged or was not created with the camera.	These pictures can not be cropped.
CANNOT EXECUTE	An attempt was made to resize a 640 picture.	M and M images can not be recized
620 CANNOT EXECUTE	An attempt was made to resize a 😰 picture.	and 🔯 images can not be resized.

Warning	Description	Solution
DPOF FILE ERROR	The DPOF print order on the current memory card contains more than 999 images.	The maximum number of images to which DPOF print order can be tagged is 999 per memory card.
CAN NOT SET DPOF	The picture can not be printed using DPOF.	_
CAN NOT SET DPOF	Movies can not be printed using DPOF.	_
CAN NOT ROTATE	The picture is protected.	Remove protection before rotating pictures.
CAN NOT ROTATE	Movies can not be rotated.	_
PRESS AND HOLD THE DISP BUTTON TO DEACTIVATE SILENT MODE	An attempt was made to adjust the volume with the camera in silent mode.	Exit silent mode before adjusting the volume.
COMMUNICATION ERROR	A connection error occurred while pictures were being printed or copied to a computer or other device.	Confirm that the device is turned on and that the USB cable is connected.
PRINTER ERROR	Printer out of paper or ink, or other printer er-	Check printer (see printer manual for details). To resume printing, turn the printer off and then turn it back on.
PRINTER ERROR RESUME?	ror.	Check printer (see printer manual for details). If printing does not resume automatically, press MENU/OK to resume.
CAN NOT BE PRINTED		Movies and some pictures created with other devices can not be printed. If the picture was created with the camera, check the printer manual to confirm that the printer supports the JFIF-JPEG or Exif-JPEG format. If it does not, the pictures can not be printed.

Memory Card Capacity

The following table shows the recording time or number of pictures available at different image sizes. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate.

_	Medium	4	GB	86	iB
		FINE	NORMAL	FINE	NORMAL
	4:3	480	960	980	1,930
_	3:2	540	1,070	1,100	2,160
핤	16:9	640	1,270	1,300	2,550
Photographs	₩ 4:3	950	1,860	1,920	3,740
aph	₩ 16:9	1,260	2,430	2,530	4,880
~	S 4:3	1,870	3,530	3,750	7,090
	S 16:9	3,400	6,160	6,840	12,370
_	1920×1080 ¹	28	min.	56 r	min.
Movies	1280×720 ¹	28	min.	56 r	min.
S	640 ²	109	min.	219 r	min.

¹ Use a CLASS Card or better. Individual movies can not exceed 29 minutes in length.

² Use a **CLASS** card or better.

Specifications

System									
Model	Digital Camera FinePix S6800/S6700/S6600 Series								
Effective pixels	16.2 million								
Image sensor	1⁄2.3 -in., square-pixel CMOS with primary color filter								
Storage media	SD/SDHC/SDXC memory cards								
File system	Compliant with Design Rule for Camera File System (DCF), Exif 2.3, and Digital Print Order Forma (DPOF)								
File format	Still pictures: Exif 2.3 JPEG (compressed) Audio: WAV/Linear PCM/stereo sound Movies: MOV (H.264) Audio: Linear PCM/stereo sound								
	• Still pictures (3D): MPO								
Image size (pixels)	• • • 4:3: 4,608×3,456 • • • 3:2: 4,608×3,072 • • • 16:9: 4,608×2,592 • • • 4:3: 3,264×2,448 • • • 16:9: 3,264×1,840								
	• • • • • • • • • • • • • • • • • • •								
Lens Focal length	S6800 series Fujinon 30 × optical zoom lens, F/3.1 (wide angle) – 5.9 (telephoto) f=4.3 mm – 129.0 mm (35-mm format equivalent: 24 mm – 720 mm)								
	S6700 series Fujinon 28 × optical zoom lens, F/3.1 (wide angle) – 5.9 (telephoto) f=4.3 mm – 120.4 mm (35-mm format equivalent: 24 mm – 672 mm) S6600 series								
	Fujinon $26 \times$ optical zoom lens, F/3.1 (wide angle) – 5.9 (telephoto) f=4.3 mm – 111.8 mm (35-mm format equivalent: 24 mm – 624 mm)								

c .												
System												
Digital zoom		prox. $2.0 imes$ (S6800 series : up to $60 imes$ / S	6700 series : up to 56 $ imes$ /									
	S6600 series : up to $52 \times$, with op	<u> </u>										
Aperture	F3.1/F8.0* (wide angle), F5.9/F8.	.0/F20* (telephoto), *uses Neutral D	ensity (ND) filter									
Focus range (distance from	Approx. 15 cm (0.4 ft.)-infini	ty (wide angle); approx. 3 m (9.8 ft.)–	infinity (telephoto)									
front of lens)	• Macro: approx. 5 cm-3.0 m/	/1.9 in.–9.8 ft. (wide angle); approx. 1.	8 m-3.0 m/5.9 ft9.8 ft. (telephoto)									
	• Super macro: approx. 2 cm-	100 cm/0.7 in.–3.2 ft. (wide angle)										
Sensitivity	Standard output sensitivity	equivalent to ISO 100, 200, 400, 8	800, 1600, 3200, 6400, 12800;									
	AUTO (400), AUTO (800), AUTO (1	600), AUTO (3200)										
Metering	256-segment through-the-	lens (TTL) metering; MULTI, SPOT	, AVERAGE									
Exposure control	Programmed AE, shutter-priority AE, aperture-priority AE, and manual exposure											
Exposure compensation	-2 EV - +2 EV in increments	of 1/3 EV (P, S , and A modes)										
Picture stabilization	Optical stabilization (image	-sensor shift)										
Blink detection	Available											
Shutter speed (combined	• P, S, A, M: 8 s – ½,000 S	• (+: ½ S – ½,000 S	• **: 3 S – ½1,500 S									
mechanical and electronic	• :8s-1/2s	 Other modes: ¼ S − ½,000 S 										
shutter)												
Continuous	• 🚇: up to 3 fps; max. 10 fra	mes										
	• №: up to 5 fps; max. 10 fra	ames										
	• №: up to 8 fps; max. 10 fra	imes										
	• 💁: up to 3 fps; max. 10 fra	ames										
	• 🔁: up to 1.2 fps; max. 3 fra	ames										
	• 🛍: up to 60 fps; max. 60 f	rames; image size 1280 × 960										
	• 🟚: up to 120 fps; max. 60	frames; image size 640×480										

System												
Bracketing	±1/3 EV, ±2/3 EV, ±1 EV											
Focus	Mode: CENTER/MULTI/AREA/CONTINU	JOUS/TRACKING										
	Autofocus system: Contrast-detect TTL AF											
White balance		preset modes for direct sunlight, shade, daylight fluorescent, orescent, and incandescent lighting; custom white balance										
Self-timer	Off, 2 sec, 10 sec											
Manual pop-up flash with CMOS-metered auto flash control (using monitor pre-flashes); effective when sensitivity is set to ISO AUTO is approx. 40 cm-7.0 m/1.3 ft22.9 ft. (wide angle) or 2.5 m-3.6 m/3 11.8 ft. (telephoto); effective range in macro mode is approx. 30 cm-3.0 m/0.9 ft9.8 ft. (wide ar 2.0 m-3.0 m/6.5 ft9.8 ft. (telephoto)												
Flash modes		ed-eye removal off); auto with red-eye removal, forced flash th red-eye removal (red-eye removal on)										
Monitor	3.0-in. (7.6 cm), 460k-dot color LCD moni	tor										
Frame coverage	Approx. 97% (shooting), 100% (playback)											
Movie frame rate	• 11 1920×1080: 1080i, 60 fps	• HD 1280×720: 720p, 30 fps										
	• 640 × 480 (VGA), 30 fps	• HS 640×480: 120 fps										
	• HS 320 × 240: 240 fps	• HS 320 × 120: 480 fps										

Input/output terminals	
HDMI output	HDMI Mini Connector
Digital input/output	USB 2.0 High Speed

Power supply/other

Power sources

- AA alkaline batteries (x4)
- AA lithium batteries (x4; available from third-party suppliers)
- AA rechargeable nickel-metal hydride (Ni-MH) batteries (x4; available from third-party suppliers)
 - AC-5VX AC power adapter and CP-04 DC coupler (sold separately)

Battery life (approximate number of frames that can be taken with fresh or fully charged batteries)

Battery type	Approximate number of frames
Alkaline (type supplied with camera)	320
Lithium	700
Ni-MH	500

CIPA standard, measured in (auto) mode using batteries supplied with camera (alkaline batteries only) and SD memory card.

Note: Number of shots that can be taken with battery varies with battery charge level and will decline at low temperatures.

Power supply/other										
Camera dimensions	114.3 mm \times 79.7 mm \times 97.0 mm/4.5 in. \times 3.1 in. \times 3.8 in. (W \times H \times D), excluding projections									
Shooting weight	S6800 series									
	Approx. 523 g/18.7 oz., including batteries and memory card									
	S6700 series									
	Approx. 523 g/18.7 oz., including batteries and memory card									
	S6600 series									
	Approx. 523 g/18.7 oz., including batteries and memory card									
Camera weight	S6800 series									
	Approx. 430 g/15.1 oz., excluding batteries, accessories, and memory cards									
	S6700 series									
	Approx. 430 g/15.1 oz., excluding batteries, accessories, and memory cards									
	S6600 series									
	Approx. 430 g/15.1 oz., excluding batteries, accessories, and memory cards									
Operating conditions	• Temperature : 0 °C - +40 °C/+32 °F - +104 °F • Humidity : 10% - 80% (no condensation)									

Color Television Systems

NTSC (National Television System Committee) is a color television telecasting specification adopted mainly in the U.S.A., Canada, and Japan. PAL (Phase Alternation by Line) is a color television system adopted mainly in European countries and China.

Notices

- Specifications subject to change without notice. FUJIFILM shall not be held liable for damages resulting from errors in this manual.
- Although the monitor is manufactured using advanced high-precision technology, small bright points and anomalous colors (particularly in the vicinity of text) may appear. This is normal for this type of monitor and does not indicate a malfunction; images recorded with the camera are unaffected.
- Digital cameras may malfunction when exposed to strong radio interference (e.g., electric fields, static electricity, or line noise).
- Due to the type of lens used, some distortion may occur at the periphery of images. This is normal.

Memo

Memo

Memo

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN

http://www.fujifilm.com/products/digital_cameras/index.html

Please contact your local distributor for repairs and technical support. (see Worldwide Network list)

Restrictions on Camera Settings

Shooting Mode and Camera Settings

The options available in each shooting mode are listed below.

									. 9					S	hoo	ting	mod	le											
														SP1.															
	Option		SRAUTO	Δ	1	HER	B000	0 4	0	\$	₩	•		*	Ç	Ŗ(^	0	ä	-6	£	Y	*	TEXT	鉛	PANORAMA	P	S	A	М
		OFF		\	~	1	~	~	~	1	1	1	1	1	1			~	1	~	~	~	~						
3	Ł	*		~	~	~	~	~	~													V 1	1	~		~	~	~	~
		&		~	~	~	~		~															~		~	~	~	~
		AUTO	~	~			~			~		~		~					~	~	1					1			
	0		~	~			~	V1		~		~		~				1	~	~			1			~	V1	Ľ.	1
	OFF									~		~			1	V1										~		~	
4 ²		③ ³	~	~	V1	V1	~		1	-	✓ ¹	~	1	~			1		~	~		1		1	✓ ¹	~		~	
Ť		AUTO	~	~			~			~		~							~	~	1					~			
	ON		~	~			~	1		~		~						1	~	~						~	V1	ř	1
		SLUM								~		~			1	V1										~		~	
		③ ³	~	~	V1	V1	~		1	~		~							~	~				V1		~		~	
		₽ 4																								1	1	1	
		•																								~	~	~	~
		នាំ២	V	~					1	1	1	1	1	~	~	1	~	~	1	1	1	1	1			1	~	~	~
		했건	V	~					~	~	~	~	~	~	~	~	~	~	~	~	V	~	~			~	~	~	~
¢	۱	TO_	V	~					~	~	~	V	V	~	~	~	~	~	~	~	V	~	~			~	~	~	~
	_	₽ ⁵	V	V					~	~	~	~	V	~	~	~	~	-	1	~	V	~	~			~	~	~	~
		№ 6	V	~					~	~	~	~	V	~	~	~	~	~	~	~	V	1	~			~	V	~	~
		<u>6</u>	~	~					~	~	~	~	~	~	~	~	~		1	~	1	1	~		41	~	~	~	~
		OFF	~	~					~		1	1	1	~	~	~	1	~	1	~	~	1	~		✓ ¹	~	~	~	~
		<u></u>	V	~	~	~	~	~	~	~	1		~	'	~	~	~	'	~	~	~	1	~	~		~	~	~	~

													ς	hoo	ting	mod	ما											
													SP1			iiiou	_											
	Option	SRAUTO	۵	(Egg	HER		@ 4	0	\$	₩	•	A	*	C	₽C*	0	×	-8-	£	Y	*	TEXT	鉛	PANORAMA	P	s	A	М
	AUTO (3200)																								~	~		
	AUTO (1600)																								~	~		
	AUTO (800)																								~	~		
	AUTO (400)																								~	~		
	12800																								~		1	~
100	6400																								~		~	~
ISO	3200																								1		1	V
	1600																								~		1	~
	800																								~		~	~
	400																								1		1	~
	200																								~		1	~
	100																								1		~	~
	4:3	1	~			1	~	~	V	1	~	~	V	~	~	~	V	~	~	~	~	~	~		1	~	V	~
	3:2	1	~				~	~	V	1	~	~	V	~	~	~	V	~	~	~	~	~	~		~	~	V	~
	16:9	V	V			~	~	~	V	1	~	~	V	~	~	~	~	~	~	~	~	~	~		~	~	V	~
(M 4:3	V	~	V1	1		~	1	V	1	~	~	V	~	~	V	V	~	~	~	~	~	~		~	~	V	~
	16:9	1	1				~	1	V	1	~	1	V	~	~	~	V	~	~	~	~	~	~		~	~	V	~
	S 4:3	V	V				V	~	V	~	~	~	V	V	~	V	V	~	~	V	V	~	~	✓ ¹	~	~	~	1
	S 16:9	1	1				~	1	~	1	~	~	~	~	~	~	~	~	~	~	~	~	~		~	~	V	~
	FINE	1	1	V	~	~	~	1	~	1	~	1	~	~	~	~	~	~	~	~	~	~	~	~	~	~	V	~
H	NORMAL	1	1	1	~	1	~	1	~	1	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	V	~
	STD	1	1	1	~	1	~	1	~	1	~	1	~	~	~	~	~	~	~	~	1	~	~	~	~	~	1	~
	ÒF		1	V	1	1	~	~																~	1	~	~	~
	Ď#	1	~	1	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	V	~	~	1	~	1	~
WB																								~	~	~	1	~
	=	V	V	~	~		~	~	V	~	~	~	V	~	~	~	V	~	~	~	~	V			~	~	~	~
	OFF		V	V	~	~	V	~	~	~		1	1	~	~	V 1	~	~	~	V	V 1	1	1	✓ ¹	~	~	1	~
	ON	1	1	1	1	~	~	1	1	~	/ 1			1	'		1	~	1	~					1	'	1	~

		Shooting mode																										
					SP1/SP2																							
Option		SR AUTO	Δ	III.	HUR	<u> </u>	04	0	\$	₩	•		*	C	Ŗ(*	0	×	-8-	£ĵ	Y	*	TEXT	sh	PANORAMA	P	s	A	М
0 7																									~	~	~	~
																									~	~	~	~
■ (🕿 mode)																												
E	1920×1080																											
	1280 × 720																											
	640																											
	IIS 640 × 480																											
	IIS 320 × 240																											
	HS 320 × 120																											
₹ <u>±</u>																									~	~	~	~
- C																									~	~	~	~
	ф.																								~	~	~	~
	fps	<	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~
	(*))	~	~	~	~	~	~	~	~	~	~	~	~	~	>	~	~	~	~	~	~	~	~	~	~	~	~	~
	e	~	~	~	~	~	~	~	~	~	~			~	\		~	~	~	~					~	~	\	~
	Q		~				~	~	~	~	~	~	~	~	>	~	~	~	~	~	~	~			~	~	~	~
	AF ²	~	~	~	~	~	~	~	~	~				~	~			~	~			~	~		~	~	~	~
	(b)	~	~	~	~	~	~	~	~	~	~	>	~	~	~	~	~	~	~	~	~	~			~	~	~	~

- 1 Automatically optimized for selected shooting mode.
- 2 Flash turns off automatically in super macro mode (%).
- 3 Lower flash to select **3** in modes other than **0**.
- 4 Disabled if flash fires when set to AUTO or an or if flash is set to 4 or 4 and subject is poorly lit.
- 5 Image sizes over S are set to S.
- 6 Image sizes over **M** are set to **M**.
- 7 Fixed at when Intelligent Face Detection is on.