


# Panasonic<sup>®</sup>

## Basic Operating Instructions

Digital Camera

Model No. **DMC-FP5**

# LUMIX



Before use, please read these instructions completely.



More detailed instructions on the operation of this camera are contained in "Operating Instructions for Advanced Features (PDF format)" in the supplied CD-ROM. Install it on your PC to read it.



Web Site: <http://www.panasonic-europe.com>

Model number suffix "EB" denotes UK model.

VQT3F15

H0111AF0

EB

## Dear Customer,

We would like to take this opportunity to thank you for purchasing this Panasonic Digital Camera. Please read these Operating Instructions carefully and keep them handy for future reference.

Please note that the actual controls and components, menu items, etc. of your Digital Camera may look somewhat different from those shown in the illustrations in these Operating Instructions.

### Carefully observe copyright laws.

- Recording of pre-recorded tapes or discs or other published or broadcast material for purposes other than your own private use may infringe copyright laws. Even for the purpose of private use, recording of certain material may be restricted.

## Information for Your Safety

### **WARNING:**

**TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR PRODUCT DAMAGE,**

- **DO NOT EXPOSE THIS APPARATUS TO RAIN, MOISTURE, DRIPPING OR SPLASHING AND THAT NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHALL BE PLACED ON THE APPARATUS.**
- **USE ONLY THE RECOMMENDED ACCESSORIES.**
- **DO NOT REMOVE THE COVER (OR BACK); THERE ARE NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.**

THE SOCKET OUTLET SHALL BE INSTALLED NEAR THE EQUIPMENT AND SHALL BE EASILY ACCESSIBLE.

### ■ Product identification marking

Product	Location
Digital Camera	Bottom
Battery Charger	Bottom



## Caution for AC Mains Lead

For your safety, please read the following text carefully.

This appliance is supplied with a moulded three pin mains plug for your safety and convenience.

A 5-ampere fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5-ampere and that it is approved by ASTA or BSI to BS1362.

Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local dealer.

### **CAUTION!**

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR HOME THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.

THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13-AMPERE SOCKET.

If a new plug is to be fitted please observe the wiring code as stated below. If in any doubt please consult a qualified electrician.

### **IMPORTANT**

The wires in this mains lead are coloured in accordance with the following code:

Blue: Neutral, Brown: Live.

As these colours may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Black or Blue.

The wire which is coloured Brown must be connected to the terminal which is marked with the letter L or coloured Brown or Red.

**WARNING: DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL WHICH IS MARKED WITH THE LETTER E, BY THE EARTH SYMBOL  OR COLOURED GREEN OR GREEN/YELLOW.**

**THIS PLUG IS NOT WATERPROOF—KEEP DRY.**


### **Before use**

Remove the connector cover.


## How to replace the fuse

The location of the fuse differ according to the type of AC mains plug (figures A and B). Confirm the AC mains plug fitted and follow the instructions below. Illustrations may differ from actual AC mains plug.

1. Open the fuse cover with a screwdriver.



2. Replace the fuse and close or attach the fuse cover.



## ■ About the battery pack

### CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

- Do not heat or expose to flame.
- Do not leave the battery(ies) in an automobile exposed to direct sunlight for a long period of time with doors and windows closed.

### Warning

Risk of fire, explosion and burns. Do not disassemble, heat above 60°C or incinerate.

## ■ About the battery charger

### CAUTION!

- DO NOT INSTALL OR PLACE THIS UNIT IN A BOOKCASE, BUILT-IN CABINET OR IN ANOTHER CONFINED SPACE. ENSURE THE UNIT IS WELL VENTILATED. TO PREVENT RISK OF ELECTRIC SHOCK OR FIRE HAZARD DUE TO OVERHEATING, ENSURE THAT CURTAINS AND ANY OTHER MATERIALS DO NOT OBSTRUCT THE VENTILATION VENTS.
- DO NOT OBSTRUCT THE UNIT'S VENTILATION OPENINGS WITH NEWSPAPERS, TABLECLOTHS, CURTAINS, AND SIMILAR ITEMS.
- DO NOT PLACE SOURCES OF NAKED FLAMES, SUCH AS LIGHTED CANDLES, ON THE UNIT.
- DISPOSE OF BATTERIES IN AN ENVIRONMENTALLY FRIENDLY MANNER.

- The battery charger is in the standby condition when the AC power supply cord is connected.  
The primary circuit is always “live” as long as the power cord is connected to an electrical outlet.

### **Information for Users on Collection and Disposal of Old Equipment and used Batteries**



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation and the Directives 2002/96/EC and 2006/66/EC.

By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.



#### **For business users in the European Union**

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

#### **[Information on Disposal in other Countries outside the European Union]**

These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.



**Note for the battery symbol (bottom two symbol examples):**  
This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

Cd

### ■ Cautions for Use

- Do not use any other AV cables except the supplied one.
- Do not use any other USB connection cables except the supplied one.


### **Keep this unit as far away as possible from electromagnetic equipment (such as microwave ovens, TVs, video games etc.).**

- If you use this unit on top of or near a TV, the pictures and/or sound on this unit may be disrupted by electromagnetic wave radiation.
- Do not use this unit near cell phones because doing so may result in noise adversely affecting the pictures and/or sound.
- Recorded data may be damaged, or pictures may be distorted, by strong magnetic fields created by speakers or large motors.
- Electromagnetic wave radiation generated by microprocessors may adversely affect this unit, disturbing the pictures and/or sound.
- If this unit is adversely affected by electromagnetic equipment and stops functioning properly, turn this unit off and remove the battery or disconnect AC adaptor (DMW-AC5E: optional). Then reinsert the battery or reconnect AC adaptor and turn this unit on.

### **Do not use this unit near radio transmitters or high-voltage lines.**

- If you record near radio transmitters or high-voltage lines, the recorded pictures and/or sound may be adversely affected.

# Contents

Information for Your Safety.....	2
Standard Accessories.....	8
Names of the Components.....	10
How to Use the Touch Panel.....	12
Charging the Battery .....	14
About the Built-in Memory / the Card .....	17
Inserting and Removing the Card (optional) / the Battery .....	18
Setting Date / Time (Clock Set) .....	19
• Changing the clock setting .....	19
Setting the Menu .....	20
Recording Sequence .....	21
Taking Pictures Using the Automatic Function	
(  : Intelligent Auto Mode) .....	22
• Scene Detection.....	23
• Tracking moving subjects and focus (AF Tracking).....	23
Recording Motion Pictures .....	24
Playing Back Pictures ([Normal Play]) .....	25
Deleting Pictures .....	25
Reading the Operating Instructions (PDF format) .....	26
Specifications .....	28

## Standard Accessories

Check that all the accessories are included before using the camera. Product numbers are correct as of January 2011. These may be subject to change.

- 1 Battery Pack\*  
(Battery Pack is indicated as **battery pack** or **battery** in the text.)

Charge the battery before use.

- 2 Battery Charger  
(Battery Charger is indicated as **battery charger** or **charger** in the text.)

- 3 AC mains lead

- 4 USB Connection Cable

- 5 AV Cable

- 6 CD-ROM

- Software:

Use it to install the software to your PC.

- Operating Instructions

- 7 Hand Strap

- 8 Stylus Pen









\* When you purchase a spare battery, buy the optional battery (DMW-BCK7E).

- SD Memory Card, SDHC Memory Card and SDXC Memory Card are indicated as **card** in the text.

- **Card is optional.**

**You can record or play back pictures on the built-in memory when you are not using a card.**

- Consult the dealer or your nearest Service Centre if you lose the supplied accessories. (You can purchase the accessories separately.)

 1 NCA-YN101H	 2 DE-A92A
 3 K2CT3YY00034	 4 K1HY08YY0019
 5 K1HY08YY0020	 6 VFF0745
 7 VFC4297	 8 VGQ0C14



## Sales and Support Information

### Customer Care Centre

- For customers within the UK: 0844 844 3852
- For customers within Ireland: 01 289 8333
- Visit our website for product information [www.panasonic.co.uk](http://www.panasonic.co.uk)
- E-mail: [customer.care@panasonic.co.uk](mailto:customer.care@panasonic.co.uk)

### Technical Support for AV Software

- For customers within the UK: 0844 844 3869
- For customers within Ireland: 01 289 8333

### Direct Sales at Panasonic UK

- For customers: 0844 844 3856
- Order accessory and consumable items for your product with ease and confidence by phoning our Customer Care Centre Monday–Thursday 9:00 a.m.–5:30 p.m., Friday 9:30 a.m.–5:30 p.m. (Excluding public holidays)
- Or go on line through our Internet Accessory ordering application at [www.pas-europe.com](http://www.pas-europe.com).
- Most major credit and debit cards accepted.
- All enquiries transactions and distribution facilities are provided directly by Panasonic UK Ltd.
- It couldn't be simpler!
- Also available through our Internet is direct shopping for a wide range of finished products, take a browse on our website for further details.

### ■ **Optional Accessories**


- DC Coupler\*: DMW-DCC10
- AC Adaptor\*: DMW-AC5E
- SDXC Memory Card
  - 64 GB: RP-SDW64GE1K            48 GB: RP-SDW48GE1K
- SDHC Memory Card
  - 32 GB: RP-SDW32GE1K/RP-SDQ32GE1K
  - 24 GB: RP-SDQ24GE1K
  - 16 GB: RP-SDW16GE1K/RP-SDQ16GE1K/RP-SDN16GE1A
  - 8 GB: RP-SDW08GE1K/RP-SDQ08GE1K/RP-SDN08GE1A
  - 4 GB: RP-SDW04GE1K/RP-SDQ04GE1K/RP-SDN04GE1A
- SD Memory Card
  - 2 GB: RP-SDN02GE1A

\* The AC Adaptor (optional) can only be used with the designated Panasonic DC coupler (optional). The AC adaptor (optional) cannot be used by itself.


Some optional accessories may not be available in some countries.

## Names of the Components


- 1 Flash
  - 2 Microphone
  - 3 Lens
  - 4 Lens cover
  - 5 Self-timer Indicator  
AF Assist Lamp
  - 6 Strap eyelet
- Be sure to attach the strap when using the camera to ensure that you will not drop it.



- 7 Touch Panel / LCD Monitor
- 8 Camera ON / OFF switch
- 9 Shutter button
- 10 Zoom lever
- 11 Speaker
- 12 [AV OUT / DIGITAL] socket



- 13 Tripod receptacle
- 14 Card / Battery door
- 15 Release lever
- 16 DC coupler cover





- When using an AC adaptor, ensure that the Panasonic DC coupler (DMW-DCC10; optional) and AC adaptor (DMW-AC5E; optional) are used.
- Always use a genuine Panasonic AC adaptor (DMW-AC5E; optional).
- When using an AC adaptor, use the AC mains lead supplied with the AC adaptor.
- We recommend you use a battery with sufficient battery power or the AC adaptor (DMW-AC5E; optional) and DC coupler (DMW-DCC10; optional) when recording motion pictures.
- If while recording motion pictures using the AC adaptor and the power supply is cut off due to a power outage or if the AC adaptor is disconnected etc., the motion picture being recorded will not be recorded.

## How to Use the Touch Panel

This touch panel is a type that detects pressure.

You can operate the camera by directly touching the icons or images on the LCD monitor (Touch Panel) with your finger or the supplied stylus pen.

<b>Touch</b> To touch and release the touch panel.	<b>Drag</b> A movement without releasing the touch panel.
 <p>Use this to select icons or images, or to set the items.</p> <ul style="list-style-type: none"><li>It may not operate properly when multiple icons are touched simultaneously, so try to touch the centre of the icon.</li></ul>	 <p>Use this to see the next/previous image by dragging horizontally or change the range of the displayed image.</p> <p>This can also be used to switch the page by operating the slide bar.</p>

## Note

- If you use a commercially available liquid crystal protection sheet, please follow the instructions that accompany the sheet. (Depending on the material, visibility or operability may be impaired.)
- **Apply a little extra pressure** when touching if you have a commercially available protection sheet affixed or if you feel it is not responding well.
- Touch panel will not operate properly when the hand holding this unit is pressing on the touch panel.
- Do not press using anything with a sharp tip or anything hard, except for the supplied stylus pen.
- Do not operate with your fingernails.
- Wipe the LCD monitor with dry soft cloth when it gets dirty with finger prints and others.
- Do not scratch or press the LCD monitor too hard.



## ■ About the Stylus pen

It is easier to use the stylus pen (supplied) for detailed operation or if it is hard to operate with your fingers.

- Do not place it where small children can reach.
- Do not place the stylus pen on the LCD monitor when storing. LCD monitor may break when the stylus pen is pressed strongly against the LCD monitor.

## Charging the Battery

### ■ About batteries that you can use with this unit

Supplied battery or dedicated optional batteries (DMW-BCK7E) can be used with this camera.

It has been found that counterfeit battery packs which look very similar to the genuine product are made available to purchase in some markets. Some of these battery packs are not adequately protected with internal protection to meet the requirements of appropriate safety standards. There is a possibility that these battery packs may lead to fire or explosion. Please be advised that we are not liable for any accident or failure occurring as a result of use of a counterfeit battery pack. To ensure that safe products are used we would recommend that a genuine Panasonic battery pack is used.


- Use the dedicated charger and battery.

### ■ Charging


- The battery is not charged when the camera is shipped. Charge the battery before use.
- Charge the battery with the charger indoors.
- It is recommended to charge the battery in a temperature between 10 °C to 30 °C. (The battery temperature should also be the same.)




**Attach the battery making sure the battery direction is correct.**



## 2 Connect the charger to the electrical outlet.

- Charging starts when the [CHARGE] indicator  lights green.



### ■ [CHARGE] indicator

Lights on: Charging

Lights off: Charging complete (Disconnect the charger from the electrical socket and detach the battery after charging is completed.)

### • When the [CHARGE] indicator flashes

- The battery temperature is too high or too low. It is recommended to charge the battery again in an ambient temperature of between 10 °C to 30 °C.
- The terminals of the charger or the battery are dirty. Wipe them with a dry cloth.

### ■ Charging time

	Supplied battery	Optional battery
Charging time (When charging the exhausted battery)	Approx. 115 min	Approx. 120 min

■ **Recording still pictures** (By CIPA standard in Normal Picture Mode)

	<b>Supplied battery</b>	<b>Optional battery</b>
<b>Capacity</b>	<b>660 mAh</b>	<b>680 mAh</b>
<b>Number of recordable pictures</b>	<b>Approx. 260 pictures</b>	<b>Approx. 265 pictures</b>
<b>Recording time</b>	<b>Approx. 130 min</b>	<b>Approx. 132 min</b>

**Recording conditions by CIPA standard\***

\* CIPA is an abbreviation of [Camera & Imaging Products Association].

- Temperature: 23 °C / Humidity: 50%RH when LCD monitor is on.
- Using a Panasonic SD Memory Card (32 MB).
- Using the supplied battery.
- Starting recording 30 seconds after the camera is turned on. (When the Optical Image Stabilizer function is set to [ON].)
- **Recording once every 30 seconds** with full flash every second recording.
- Moving the zoom lever from Tele to Wide or vice versa in every recording.
- Turning the camera off every 10 recordings and leaving it until the temperature of the battery decreases.



## About the Built-in Memory / the Card

### Built-in Memory

- **Memory size: Approx. 70 MB**
- The built-in memory can be used as a temporary storage device when the card being used becomes full.
- The access time for the built-in memory may be longer than the access time for a card.

### Card

The following cards which conform to the SD video standard can be used with this unit. (These cards are indicated as **card** in the text.)

Type of card which can be used with this unit	Remarks
<b>SD Memory Card (8 MB to 2 GB)</b>	<ul style="list-style-type: none"><li>• SDHC Memory Card can be used with SDHC Memory Card or SDXC Memory Card compatible equipment.</li><li>• SDXC Memory Card can only be used with SDXC Memory Card compatible equipment.</li><li>• Check that the PC and other equipment are compatible when using the SDXC Memory Cards. <a href="http://panasonic.net/avc/sdcard/information/SDXC.html">http://panasonic.net/avc/sdcard/information/SDXC.html</a></li></ul>
<b>SDHC Memory Card (4 GB to 32 GB)</b>	
<b>SDXC Memory Card (48 GB, 64 GB)</b>	

- Cards other than the cards with the above capacity cannot be used.
- Use a card with SD Speed Class\* with “Class 6” or higher when recording motion pictures.  
\* The SD Speed Class Rating is the speed standard for successive writes.

(Example) Class 6 **CLASS 6**

- Please confirm the latest information on the following website.  
<http://panasonic.jp/support/global/cs/dsc/>  
(This Site is English only.)

### Note

- Keep the Memory Card out of reach of children to prevent swallowing.


## Inserting and Removing the Card (optional) / the Battery

- Check that this unit is turned off.
- We recommend using a Panasonic card.

**1**

Slide the release lever in the direction of the [OPEN] and open the card / battery door.

- Always use genuine Panasonic batteries (NCA-YN101H; supplied or DMW-BCK7E; optional).
- If you use other batteries, we cannot guarantee the quality of this product.




**2**

Completely insert battery and card.

**Battery:** Check the direction is correct and insert it securely to the end until the clicking sound is heard. Then, confirm the battery is locked by the lever **A**.

**Card:** Check the direction is correct and insert it fully until it clicks.

**B:** Do not touch the terminals!  
Face this side to the LCD side.



### ■ To remove

**Battery:** Pull the lever **A** in the direction of the mark ( $\Delta$ ).

**Card:** Push the centre of the card.


**3**

Close the card / battery door and slide the release lever in the direction of the [LOCK].

## Setting Date / Time (Clock Set)

- The clock is not set when the camera is shipped.

- 1** Open the lens cover.
  - The camera is turned on.



- 2** Touch the language select icon on the screen.

- 3** Select the language.
  - The [Please set the clock] message appears.

- 4** Touch [Clock Set].

- 5** Touch the items you wish to set (Year / Month / Day / Hours / Minutes), and set using [▲] / [▼].

- 6** Touch [Set].

- 7** Touch [Set].


### Changing the clock setting

Select [Clock Set] in the [Rec] or [Setup] menu.

- It can be changed in steps 5 and 6 to set the clock.

## Setting the Menu

Using the menu, you can select your preferred recording or playback functions, or can make basic settings for the camera.

This section describes the operation method using the example of how to set the [AF Mode] in the recording menu to [  ] (Face Detection).

**1** Touch [MENU].

**2** Touch the type of menu.

- In Playback Mode, the playback menu can be selected instead of the recording menu.



**3** Touch the icon in the menu item.

- Touching the icon for a few seconds will display the explanation.
- If there are many selectable items, [◀] and [▶] are displayed at both ends. Touch and display other items.




**4** Touch the setting.

- Touching the icon for a few seconds will display the explanation.
- If there are many selectable items, [◀] and [▶] are displayed at both ends. Touch and display other settings.
- Depending on the item, some settings may not be displayed or they may be displayed in a different way.



### ■ To close the menu

Touch [  ] several times, or press the shutter button halfway.


## Recording Sequence

1

### Open the lens cover.

The camera is turned on in Recording Mode. (Recording is possible with this setting.)

Ⓐ Shutter button



2

### Select Recording Mode.

① Touch [◀📷].

② Touch the mode icon.

- The description is displayed after the first touch.
- When operating from Playback Mode, touch [📷] first to switch to Recording Mode, and then perform ①.

### ■ List of [Rec] Modes

#### **IA Intelligent Auto Mode**

The subjects are recorded using settings automatically selected by the camera.

#### **📷 Normal Picture Mode**

The subjects are recorded using your own settings.

#### **👉 Cosmetic Mode**

Takes a picture adjusting the skin texture.

#### **SCN Scene Mode / MS My Scene Mode**

This allows you to take pictures that match the scene being recorded.

#### **🎞 Motion Picture Mode**


This mode allows you to record motion pictures with audio.

[Rec] Mode: **iA**

## Taking Pictures Using the Automatic Function (**iA** : Intelligent Auto Mode)


The camera will set the most appropriate settings to match the subject and the recording conditions so we recommend this mode for beginners or those who want to leave the settings to the camera and take pictures easily.

Ⓐ Shutter button



**1**

**Touch [**◀**  ] in Recording Mode.**

- When operating from Playback Mode, touch [**📷**] first to switch to Recording Mode, and then touch [**◀**  ].

**2**

**Touch [**iA** ].**

**3**

**Press the shutter button halfway (push lightly) to focus.**

- The focus indication ① (green) lights when the subject is focused.
- The AF area ② is displayed around the subject's face by the Face Detection function. In other cases, it is displayed at the point on the subject which is in focus.
- The focus range is 10 cm (0.33 feet) (Wide) /50 cm (1.64 feet) (Tele) to  $\infty$ .
- The maximum close-up distance (the shortest distance at which the subject can be taken) differs depending on the zoom magnification.



**4**







**Press the shutter button fully (push it in further), and take the picture.**

- You can also take pictures using the Touch Shutter function.



## Scene Detection

When the camera identifies the optimum scene, the icon of the scene concerned is displayed in blue for 2 seconds, after which its colour changes to the usual red.

[iA] →	 [i-Portrait]	 [i-Night Portrait] • Only when [iA] is selected
	 [i-Scenery]	 [i-Night Scenery]
	 [i-Macro]	 [i-Sunset]

- [iA] is set if none of the scenes are applicable, and the standard settings are set.
- When [iPortrait] or [iNight Portrait] is selected, the camera automatically detects a person's face, and it will adjust the focus and exposure (Face Detection).

## Tracking moving subjects and focus (AF Tracking)


Just touching the screen can focus the targeted subject and adjust the exposure. The camera continues to focus the subject and adjust the exposure even if it moves afterwards.

### 1 Touch the subject you wish to focus on the screen.

- The AF area (AF tracking frame) is displayed in yellow and the camera determines the best suited scene.
- Touch [cancel] to cancel the AF Tracking.



### 2 Press the shutter button halfway to fix the focus and then press it fully to take the picture.



[Rec] Mode:

## Recording Motion Pictures

This records motion pictures with sound. (Motion pictures cannot be recorded without audio.)


**1** Touch [] in Recording Mode.

**2** Touch [].

**3** Press the shutter button halfway to focus and then press it fully to start recording.

- Ⓐ Available recording time
- Ⓑ Recording state
- Ⓒ Elapsed recording time

- After pressing the shutter button fully, release it straight away.
- The focus and zoom are fixed to the setting when recording starts (the first frame).




**4** Press the shutter button fully to stop recording.

### Note

- Motion pictures can be recorded continuously for up to 15 minutes. Also, continuous recording exceeding 2 GB is not possible. (Example: [10m 10s] with [HD]) Remaining time for continuous recording is displayed on the screen.




[Playback] Mode: 

## Playing Back Pictures ([Normal Play])

If the card is inserted, pictures in the card are played back. If not, pictures in the built-in memory are played back.


### 1 Touch in Recording Mode.

- Touching  in Recording Mode will automatically enter Normal Playback Mode.

### 2 Forward or rewind the image by dragging the screen horizontally. Forward: drag from right to left Rewind: drag from left to right

- To play back motion pictures , touch .



[Playback] Mode: 

## Deleting Pictures

Once deleted, pictures cannot be recovered.

- Pictures on the built-in memory or the card, which are being played back will be deleted.

### 1 Select the picture to be deleted, and then touch .



### 2 Touch [Delete Single].

### 3 Touch [Yes].



## Reading the Operating Instructions (PDF format)

More detailed instructions on the operation of this camera are contained in “Operating Instructions for Advanced Features (PDF format)” in the supplied CD-ROM. Install it on your PC to read it.

### [Windows]


**1** Turn the PC on and insert the CD-ROM containing the Operating Instructions (supplied).

**2** Click the [Operating Instructions].

**3** Select the desired language and then click [Operating Instructions] to install.

Ⓐ To return to the install menu.

**4** Double click the “Operating Instructions” shortcut icon on the desktop.



### ■ **When the Operating Instructions (PDF format) will not open**

You will need Adobe Acrobat Reader 5.0 or later or Adobe Reader 7.0 or later to browse or print the Operating Instructions (PDF format).

Insert the CD-ROM containing the Operating Instructions (supplied), click [Ⓜ] and then follow the messages on the screen to install.

(Compatible OS: Windows 2000 SP4/Windows XP SP3/Windows Vista SP2/Windows 7)

- You can download and install a version of Adobe Reader that you can use with your OS from the following Web Site.

<http://get.adobe.com/reader/otherversions>

### ■ **To uninstall the Operating Instructions (PDF format)**

Delete the PDF file from the “Program Files\Panasonic\Lumix\” folder.

- When the contents in the Program Files folder cannot be displayed, click the [Show the contents of this folder] to display them.

### **[Macintosh]**

- 1 Turn the PC on and insert the CD-ROM containing the Operating Instructions (supplied).**
- 2 Open the “Manual” folder in the CD-ROM and then copy the PDF file with the desired language inside the folder.**
- 3 Double click the PDF file to open it.**

## Specifications

<b>Digital Camera:</b>	Information for your safety
<b>Power Source:</b>	DC 5.1 V
<b>Power Consumption:</b>	1.1 W (When recording) 0.7 W (When playing back)
<b>Camera Effective pixels:</b>	14,100,000 pixels
<b>Image sensor:</b>	1/2.33" CCD
<b>Total pixels:</b>	14,500,000 pixels Primary colour filter
<b>Lens:</b>	Optical 4 × zoom, f=6.3 to 25.2 mm [35 mm film camera equivalent: 35 to 140 mm] / F3.5 (Wide) to F5.9 (Tele)
<b>Digital zoom:</b>	Max. 4 ×
<b>Extra optical zoom:</b>	Max. 8.4 ×
<b>Focus range:</b>	Normal : 50 cm (1.64 feet) to ∞ Macro / Intelligent auto / Motion Picture: 10 cm (0.33 feet) (Wide) / 50 cm (1.64 feet) (Tele) to ∞ Scene mode: settings may be different to those shown above
<b>Shutter system:</b>	Electronic shutter+Mechanical shutter
<b>Burst recording</b>	
<b>Burst speed:</b>	Approx. 1.7 pictures/second
<b>Number of recordable pictures:</b>	Depends on the remaining capacity of the built-in memory or the card.
<b>Hi-speed burst</b>	
<b>Burst speed:</b>	Approx. 4 pictures/second
<b>Picture size:</b>	3M (4:3), 2.5M (3:2, 1:1) or 2M (16:9) is selected as the picture size.
<b>Number of recordable pictures:</b>	Approx. 15 to 100

<b>Shutter speed:</b>	8 seconds to 1/1,600th of a second [Starry Sky] mode: 15 seconds, 30 seconds, 60 seconds
<b>Exposure (AE):</b>	Auto (Programme AE) Exposure compensation (1/3 EV Step, -2 EV to +2 EV)
<b>Metering mode:</b>	Multiple
<b>LCD monitor:</b>	TFT LCD 3.0" (3:2) (Approx. 230,000 dots) (field of view ratio about 100%) Touch panel
<b>Flash:</b>	Flash range: Approx. 0.3 m (0.99 feet) to 4.9 m (16.08 feet) (Wide [ISO]) AUTO, AUTO / Red-eye reduction, Forced ON (Forced ON / Red-eye reduction), Slow sync. / Red-eye reduction, Forced OFF
<b>Microphone:</b>	Monaural
<b>Speaker:</b>	Monaural
<b>Recording media:</b>	Built-in Memory (Approx. 70 MB) / SD Memory Card / SDHC Memory Card / SDXC Memory Card
<b>Recording file format</b>	
<b>Still Picture:</b>	JPEG (based on "Design rule for Camera File system", based on "Exif 2.3" standard)/DPOF corresponding
<b>Motion pictures:</b>	"QuickTime Motion JPEG" (motion pictures with audio)
<b>Interface</b>	
<b>Digital:</b>	USB 2.0 (High Speed) * Data from the PC cannot be written onto the camera using the USB connection cable.
<b>Analogue video / audio:</b>	PAL / NTSC Composite (Switched by menu) Audio line output (monaural)
<b>Terminal</b>	
<b>AV OUT/DIGITAL:</b>	Dedicated jack (8 pin)

**Dimensions:** Approx. 101.0 mm (W) × 58.9 mm (H) × 18.2 mm (D)  
(3.98" (W) × 2.32" (H) × 0.72" (D))  
(excluding the projection part)

**Mass:** Approx. 141 g/0.31 lb  
(with Memory Card and battery)  
Approx. 124 g/0.27 lb  
(excluding Memory Card and battery)

**Operating Temperature:** 0 °C to 40 °C

**Operating Humidity:** 10%RH to 80%RH

**Battery Charger  
(Panasonic  
DE-A92A):**

Information for your safety

<b>Input:</b>	AC ~ 110 V to 240 V, 50/60 Hz, 0.2 A
<b>Output:</b>	DC = 4.2 V, 0.43 A

**Equipment mobility:** Movable

**Battery Pack  
(lithium-ion)  
(Panasonic  
NCA-YN101H):**

Information for your safety

<b>Voltage/capacity (Minimum):</b>	3.6 V/660 mAh
--	---------------



- SDXC Logo is a trademark of SD-3C, LLC.
- QuickTime and the QuickTime logo are trademarks or registered trademarks of Apple Inc., used under license therefrom.
- This product uses “DynaFont” from DynaComware Corporation. DynaFont is a registered trademark of DynaComware Taiwan Inc.
- Other names, company names, and product names printed in these instructions are trademarks or registered trademarks of the companies concerned.



EU



Pursuant to the directive 2004/108/EC, article 9(2)  
Panasonic Testing Centre  
Panasonic Marketing Europe GmbH  
Winsbergring 15, 22525 Hamburg, Germany

Panasonic Corporation  
**Web Site:** <http://panasonic.net>

VQT3F15  
H0111AF0

© Panasonic Corporation 2011