



Portable Splash-Resistant Speaker System

40-1442


Thank you for buying the RadioShack Portable Splash-Resistant Speaker System. The speaker system provides superior stereo sound from your portable CD player or radio/tape player. These compact and light portable speakers let you enjoy radio programs or music almost anywhere. The unique splash-proof design lets you use the speakers even in high humidity environments.

Connections

1. Align the stand's convex tab with the slot on the bottom of speaker, and then slide the stand all the way until it stops. Repeat this step for the other speaker.
2. Turn the audio source off and set its volume control to the minimum level.
3. Plug the speaker system's 1/8-inch (3.5 mm) plug into the audio source's headphone jack.

Notes:

- If the audio source does not have a 1/8-inch (3.5 mm) jack, you will need an adapter plug, available at your local RadioShack store.
- For the best stereo effect, position the speakers apart from each other, facing the center of the listening area.



Care & Service

Keep the speakers dry; if they get wet, wipe them dry immediately. Use and store the speakers only in room temperature environments. Handle the speakers carefully; do not drop them. Keep the speakers away from dust and dirt, and wipe them with a damp cloth occasionally to keep them looking new.

Caution: You might permanently damage your speakers by cleaning them with a vacuum cleaner. Use a feather duster or a soft loose cloth instead.

If your speakers are not performing as they should, take them to your local RadioShack store for assistance. To locate your nearest RadioShack, use the store locator feature on RadioShack's website (www.radioshack.com), or call 1-800-The Shack (843-7422) and follow the menu options. Modifying or tampering with the speakers' internal components can cause a malfunction and might invalidate their warranty.

Specifications

Speaker	2 Inches (50 mm)
Impedance	4 Ohms
Power Capacity.....	1 W (RMS)
Frequency Response.....	400 Hz to 20 kHz
Dimensions (With Stand)	3 3/4 x 2 3/4 x 2 7/8 Inches
.....	(94 x 70 x 73 mm) (HWD)
Weight (Including Two Stands)	13.40 oz (380g)

Specifications are typical; individual units might vary.
Specifications are subject to change and improvement without notice

Limited 90-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for 90 days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period. This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102 12/99

©2003 RadioShack Corporation.
All Rights Reserved.
RadioShack and RadioShack.com are trademarks
used by RadioShack Corporation.

Cat. No. 40-1442
Printed in China
10A03