







LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Agfa	DC-8330i		•			
Argus	DC-6340		•			
	QC-5340		•			
BenQ	C840			•		
	DC C1050		•			
	DC C530		•			
	DC C630		•			
	DC C740i			•		
	DC C750		•			
	DC C820		•			
	DC C850		•			
	DC E100		•			
	DC E520+		•			
	DC E600		•			
	DC E800		•			
	DC X600	•				
	DSC X800		•			







LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Canon	Digital IXUS 80	•				
	IXUS 70		•			
	IXY Digital 820IS		•			
	PowerShot A1000 IS		•			
	PowerShot A2000 IS		•			
	PowerShot A460			•		
	PowerShot A470			•		
	PowerShot A540/A550/A560			•		
	PowerShot A570 IS			•		
	PowerShot A580			•		
	PowerShot A590 IS			•		
	PowerShot A640					•
	PowerShot A650 IS					•
	PowerShot A700			•		
	PowerShot A720 IS			•		
	PowerShot E1			•		
	PowerShot G10					•
	PowerShot G9				•	
	PowerShot SD1000/IXUS 70	•				
	PowerShot SD1100 IS/IXUS 80	•				
	PowerShot SD40/Ixus i7		•			
	PowerShot SD750/IXUS 75	•				
	PowerShot SD770/IXUS 85	•				
	PowerShot SD790/IXUS 90	•				
	PowerShot SD850 IS/IXUS 950 IS		•			
	PowerShot SD870 IS/IXUS 860 IS		•			
	PowerShot SD880 IS/IXUS 870 IS		•			
	PowerShot SD890 IS/IXUS 970 IS		•			
	PowerShot SD950 IS/Digital IXUS 960 IS		•			
	PowerShot SD990 IS/IXUS 980 IS		•			
	PowerShot SX100 IS					•
	PowerShot SX110 IS					•
PowerShot TX-1		•				
SD850IS/Ixus 950IS		•				

LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Casio	EXILIM EX-S10	•				
	EXILIM EX-S880		•			
	EXILIM EX-V7/V8		•			
	EXILIM EX-Z100		•			
	EXILIM EX-Z1000	•				
	EXILIM EX-Z1050	•				
	EXILIM EX-Z1080		•			
	EXILIM EX-Z11		•			
	EXILIM EX-Z1200		•			
	EXILIM EX-Z200		•			
	EXILIM EX-Z250		•			
	EXILIM EX-Z300		•			
	EXILIM EX-Z600	•				
	EXILIM EX-Z700	•				
	EXILIM EX-Z75	•				
	EXILIM EX-Z77	•				
	EXILIM EX-Z8		•			
	EXILIM EX-Z80	•				
	EXILIM EX-Z85		•			
EXILIM EX-Z850	•					
EXILIM EX-Z9		•				
Concord	ES 500Z		•			
	Eye-Q 3346Z		•			
	Eye-Q 5062AF		•			
	Eye-Q 5345Z			•		
DXG	110		•			
	202V				•	
	305V			•		
	568			•		
	572V					•

*Availability may vary by country or location

LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Fuji	FinePix A610		•			
	FinePix A700		•			
	FinePix A800		•			
	FinePix A820/A825/A900		•			
	FinePix A850		•			
	FinePix A920		•			
	FinePix F100fd		•			
	FinePix F31fd		•			
	FinePix F40fd		•			
	FinePix F470		•			
	FinePix F47fd		•			
	FinePix F480		•			
	FinePix F50fd/F60fd	•				
	FinePix J10		•			
	FinePix J100/J110/J120/J150		•			
	FinePix J12/J50		•			
	FinePix V10	•				
	FinePix Z10fd/Z100fd/Z200fd	•				
	FinePix Z20fd	•				
	FinePix Z3	•				
FinePix Z5fd	•					
GE	A730		•			
	A735/A835		•			
	E1035/E1235		•			
	E1050		•			
	E840S		•			
	G2/G3		•			
	H855		•			
HP	Photosmart E337		•			
	Photosmart E427		•			
	Photosmart M437		•			
	Photosmart M447		•			
	Photosmart M537		•			
	Photosmart M547		•			
	Photosmart M627		•			
	Photosmart M637		•			
	Photosmart M737		•			
	Photosmart Mz67		•			
	Photosmart R725		•			
	Photosmart R727		•			
	Photosmart R742	•				
	Photosmart R837		•			
	Photosmart R847		•			
	Photosmart R937		•			
	Photosmart R967		•			







LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Kodak	EasyShare C443			•		
	EasyShare C513		•			
	EasyShare C530		•			
	EasyShare C603				•	
	EasyShare C613				•	
	EasyShare C643				•	
	EasyShare C653				•	
	EasyShare C663				•	
	EasyShare C703				•	
	EasyShare C713			•		
	EasyShare C743				•	
	EasyShare C763			•		
	EasyShare C875				•	
	EasyShare M1033			•		
	EasyShare M753/M853			•		
	EasyShare M763/M863			•		
	EasyShare M873/M883	•				
	EasyShare M893 IS			•		
	EasyShare Picture Viewer	•				
	EasyShare V1073/V1273			•		
	EasyShare V1233/V1253			•		
	EasyShare V1285			•		
	EasyShare V550			•		
	EasyShare V570			•		
	EasyShare V610				•	
	EasyShare V705			•		
	EasyShare V803/V1003				•	
	EasyShare Z1085 IS				•	
	EasyShare Z1275			•		
	EasyShare Z1285			•		
	EasyShare Z885			•		
	Leica	C-Lux 1		•		
C-Lux 3			•			
D-Lux 3					•	
D-Lux 4					•	
Minox	DC 7022		•			
	DC-6033 WP				•	
	DC-6211	•				
	DC-8011		•			
Mustek	DV-4500				•	
	GSmart D35			•		
	MDC-6500z					•

LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Nikon	Coolpix L10/L11/L12		•			
	Coolpix L14/L15			•		
	Coolpix L16/L18		•			
	Coolpix L5			•		
	Coolpix L6			•		
	Coolpix P3, P4		•			
	Coolpix P50			•		
	Coolpix P5000/P5100			•		
	Coolpix P60			•		
	Coolpix P6000 GPS					•
	Coolpix S10			•		
	Coolpix S200	•				
	Coolpix S210	•				
	Coolpix S50/S50c	•				
	Coolpix S500	•				
	Coolpix S51/S51c		•			
	Coolpix S510	•				
	Coolpix S52		•			
	Coolpix S520	•				
	Coolpix S52c		•			
	Coolpix S550	•				
	Coolpix S560		•			
	Coolpix S60		•			
	Coolpix S600	•				
	Coolpix S610/S610c		•			
	Coolpix S700	•				
	Coolpix S710	•				
	Coolpix S7c	•				
	Coolpix S8	•				
	Coolpix S9	•				

LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Olympus	FE-140		•			
	FE-150		•			
	FE-170/270			•		
	FE-190		•			
	FE-20		•			
	FE-210		•			
	FE-230/240/250	•				
	FE-280	•				
	FE-300		•			
	FE-310		•			
	FE-320		•			
	FE-340		•			
	FE-350		•			
	FE-360		•			
	FE-370		•			
	Mju 1040	•				
	Mju 1050SW		•			
	Mju 1060		•			
	Stylus 1000/Mju Digital 1000		•			
	Stylus 1010/1020		•			
	Stylus 1030SW		•			
	Stylus 1200/Mju Digital 1200		•			
	Stylus 710		•			
	Stylus 720SW		•			
	Stylus 725AW		•			
	Stylus 730/Mju Digital 730		•			
	Stylus 740/Mju Digital 740		•			
	Stylus 750/Mju Digital 750		•			
	Stylus 760/Mju Digital 760		•			
	Stylus 770SW	•				
	Stylus 780		•			
	Stylus 790SW/Mju 790SW		•			
	Stylus 810/Mju Digital 810		•			
	Stylus 820/Mju Digital 820		•			
	Stylus 830/Mju Digital 830		•			
	Stylus 840		•			
	Stylus 850SW		•			
	X775		•			
	X835		•			

LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		    				
		D-Pods 10	D-Pods 20	D-Pods 30	D-Pods 40	D-Pods 50
Panasonic	Lumix DMC- FX07		•			
	Lumix DMC-FS20		•			
	Lumix DMC-FX10/FX12		•			
	Lumix DMC-FX100		•			
	Lumix DMC-FX150		•			
	Lumix DMC-FX30		•			
	Lumix DMC-FX33		•			
	Lumix DMC-FX35		•			
	Lumix DMC-FX37		•			
	Lumix DMC-FX50		•			
	Lumix DMC-FX500		•			
	Lumix DMC-FX55		•			
	Lumix DMC-LS2			•		
	Lumix DMC-LS60/LS75		•			
	Lumix DMC-LS80		•			
	Lumix DMC-LX2			•		
	Lumix DMC-LX3			•		
	Lumix DMC-LZ3/LZ5			•		
	Lumix DMC-LZ6/LZ7		•			
	Lumix DMC-LZ8			•		
Lumix DMC-TZ2/TZ3			•			
Lumix DMC-TZ4/TZ5			•			
Lumix DMC-TZ50			•			
Pentax	Optio A30	•				
	Optio A40	•				
	Optio E30/E35			•		
	Optio E40		•			
	Optio E50		•			
	Optio E60		•			
	Optio L30	•				
	Optio M30		•			
	Optio M40		•			
	Optio M50/M60		•			
	Optio S10		•			
	Optio S12	•				
	Optio S7	•				
	Optio T30		•			
	Optio V10	•				
	Optio V20		•			
	Optio W20		•			
	Optio W30		•			
Optio W60		•				
Optio Z10		•				
Polaroid	A310	•				
	i533P	•				
	i631		•			
	i633	•				
	i733	•				

*Availability may vary by country or location

LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Pure Digital	Flip Video		•			
	Flip Video Ultra		•			
RCA	CDS4100	•				•
	CDS6300					•
Ricoh	Caplio 500G Wide					•
	Caplio GX100				•	
	Caplio GX200			•		
	Caplio R30		•			
	Caplio R40		•			
	Caplio R5		•			
	Caplio R7		•			
	Caplio RR770		•			
	G600			•		
	GR Digital II			•		
	R10		•			
	R50		•			
	R8		•			
Rollei	dp8300		•			
	dr 5		•			
	Prego da6		•			
	Prego dp4200	•				
	Prego dp5300/6300			•		
	Prego dp6200	•				
	Prego dp6500		•			
	Prego dr5100			•		

LOWEPRO D-PODS SERIES MATRIX 10-2008






Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Samsung	Digimax A40			•		
	Digimax A503			•		
	Digimax i100		•			
	Digimax i7		•			
	Digimax i70	•				
	Digimax i8	•				
	Digimax i80	•				
	Digimax i85		•			
	Digimax L60		•			
	Digimax L70			•		
	Digimax L700		•			
	Digimax L730		•			
	Digimax L74 Wide		•			
	Digimax L85			•		
	Digimax S1000		•			
	Digimax S500/S600/S800		•			
	Digimax S700		•			
	L100/110/200/210	•				
	L201/SL201	•				
	L73		•			
	L730		•			
	L77	•				
	L830		•			
	L83T		•			
	NV11		•			
	NV24HD		•			
	NV3		•			
	NV30/NV40		•			
	NV4		•			
	NV5/NV7 OPS			•		
	NV8/10/15/20		•			
	NV9/TL9		•			
	S1060		•			
	S1070		•			
	S630/S730		•			
	S73		•			
	S760/S860		•			
	S830/S1030		•			
	S85		•			
	S850/S1050		•			
SC-M105		•				
SC-X105L		•				

*Availability may vary by country or location

LOWEPRO D-PODS SERIES MATRIX 10-2008







Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Sanyo	VPC-C1E Xacti			•		
	DSC-S5 Xacti			•		
	VPC-C40			•		
	VPC-J4 Xacti		•			
	Xacti DMX-CA8					•
	Xacti VPC-CA65					•
	Xacti VPC-CG65			•		
	Xacti VPC-HD1				•	
	Xacti VPC-HD1000					•
	Xacti VPC-S50		•			
	Xacti VPS-T700	•				
	Xaxcti VPC-CA6			•		
Sharp	VE-CG30U/40U					•
Sigma	DP-1				•	
Sony	DCR-DVD101/201/301					•
	DSC-G1		•			
	DSC-H10					•
	DSC-H3					•
	DSC-N2		•			
	DSC-P100/P120			•		
	DSC-P150/P200		•	•		
	DSC-S500		•			
	DSC-S600			•		
	DSC-S650/S700/S800		•			
	DSC-S730		•			
	DSC-S750/S780		•			
	DSC-T10	•				
	DSC-T100	•				
	DSC-T2	•				
	DSC-T20	•				
	DSC-T200		•			
	DSC-T30	•				
	DSC-T300	•				
	DSC-T33	•				
	DSC-T50	•				
	DSC-T500		•			
	DSC-T70	•				
	DSC-T700		•			
	DSC-T77		•			
	DSC-W110/W200		•			
	DSC-W115/W125		•			
	DSC-W120/W130		•			
	DSC-W150/W170		•			
	DSC-W30/W35/W50/W55/W70/W80/W85/W90		•			
	DSC-W300		•			
	HDR-TG1				•	
	NSC-GC1				•	

*Availability may vary by country or location

LOWEPRO D-PODS SERIES MATRIX 10-2008

Digital Camera Bags

		 D-Pods 10	 D-Pods 20	 D-Pods 30	 D-Pods 40	 D-Pods 50
Vivitar	DVR-310			•		
	DVR-410			•		
	V3105	•				
	V3315		•			
	V3345/3355		•			
	V3625					•
	V3650		•			
	V3695		•			
	V3705/3715				•	
	V3740			•		
	V3750		•			
	V3755					•
	V3825			•		
	V3826			•		
	V5388		•			
	V6200W				•	
	V6300		•			
	V6320		•			
	V7310		•			
	Vivicam 10			•		
	Vivicam 25		•			
	Vivicam 3780		•			
	Vivicam 4000			•		
	Vivicam 4345		•			
	Vivicam 5385		•			
	Vivicam V2655		•			
	Vivicam V2775					•
	Vivicam V3200			•		
	Vivicam V3500					•