


# NEC

## NEAX 2400 IPX Dterm Series i/Dterm IP Digital Extension Reference Guide

This booklet is provided with your NEC telephone, compliments of NEC Business Solutions, as a guide to the features available with the NEAX ECP (Enterprise Communication Platform).



## Dterm Series i/Dterm IP Terminal and Call Outs

## GENERAL FEATURES

My Extension Number is: \_\_\_\_\_

### To Make an Internal Call

- ◆ Dial the required extension number.

### To Make an Outgoing Call

- ◆ Dial  for outside line access.
- ◆ Dial the required number.

### To Call the Operator

- ◆ Dial .

### Last Number Redial/Stack Dial

*To redial any of the last 5 numbers you have dialled internally or externally:*

- ◆ Press **Redial** repeatedly until the desired number is displayed.
- ◆ Press **#** to dial the selected number.

*\*Whenever an operation states "lift handset", you can press Speaker instead for handsfree operation.*

## Hold

*To place a call on hold:*

- ◆ Press **Hold** – held line flashes.

*To retrieve the held call:*

- ◆ Lift handset\*.
- ◆ Press flashing line.

**Note:** *For exclusive hold – press **Hold** twice.*

## To Transfer a Call

- ◆ Whilst on a call press **Transfer**.
- ◆ Dial the extension number and announce the call.
- ◆ If call is accepted, hang up or extension hangs up and call is returned.
- ◆ If extension is busy or unanswered press **Transfer** to return to call.

†Always dial  to make an external call

## Conference Call

*To establish a 3-way conversation:*

- ◆ Whilst on a call press **Transfer**.
- ◆ Dial extension or external number†.
- ◆ When called party answers, press **Conf** for a 3-way conversation.

**Note:** *At most, two parties can be on an external line. Any party may hang up to exit conference.*

## Message Key

*One touch access to Voice Mail System:*

### **To Program**

- ◆ Press **Feature** key.
- ◆ Press **Message** key.
- ◆ Enter Voice Mail System extension number.
- ◆ Press **Feature** key.

### **To Use**

- ◆ Press Message Key.
- ◆ Dterm will automatically connect to Voice Mail System.

## Directory Key

*To allow access to system speed dial numbers:*

### **To Use**


- ◆ Lift handset.
- ◆ Press **Directory** key.
- ◆ Enter number for required speed idal number.
- ◆ System will now automatically dial.

**Note:** *System speed feature needs to be enabled by the administrator.*

# SOFTKEYS FEATURES

## To Use Soft keys

*Softkeys are indicated in the LCD according to the status of the Multiline Terminal (telephone).*

- ◆ Press the  (Scroll) key to scroll the display until the desired feature appears.
- ◆ Press the Softkey under the indicated feature on the LCD.
- ◆ The service feature of the pressed Softkey is activated.

## Help/Exit

- ◆ Press the **Help** key repeatedly until the desired feature displays.
- ◆ Press **Exit** key to exit the help program.

## Call Hold

*Hold one call and make a second:*

- ◆ Press Softkey below “**C HLD**”.
- ◆ Dial extension or external number†.
- ◆ Press “**C HLD**” to swap between the calls.
- ◆ When finished with one call, hang up and second call will ring back.

## Call Forward All

*Forwards all calls immediately.*

### **SET:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below “**FD A**”.
- ◆ Dial extension or external number<sup>†</sup> to which your calls are to be forwarded.

### **CANCEL:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below “**FD A**”.

## Call Forward No Answer

*Forwards only after 4 - 6 rings.*

### **SET:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below “**FD N**”.
- ◆ Dial extension or external number<sup>†</sup> to which your calls are to be forwarded.

### **CANCEL:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below “**FD N**”.

## Call Forward Busy

*Forwards when extension is busy.*

### **SET:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below **"FD B"**.
- ◆ Dial extension or external number<sup>†</sup> to which your calls are to be forwarded.

### **CANCEL:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below **"FD B"**.

## Group Call Pick Up

*To answer another ringing extension in your group:*

- ◆ Lift handset\*.
- ◆ Press the Softkey below **"PICK"**.

## Voice Call

*To speak over the intercom to other Dterm telephones:*

- ◆ Dial desired extension number.
- ◆ Press the Softkey below **"VOICE"**.
- ◆ Speak over Intercom.

## Save & Repeat

*To save a dialled number for later use.*

### **SAVE:**

- ◆ Lift handset.
- ◆ Dial desired telephone number.
- ◆ Press the Soft Key below **"S & R"**.

## REPEAT:

- ◆ Lift handset.
- ◆ Press the Soft Key below “**S & R**”, and the number is redialled.

## Call Wait – Extension

*If you dial a busy extension.*

### SET:

- ◆ Press Softkey below “**CW**”.
- ◆ Your call is now camped on.

### RECEIVE:

- ◆ Press **Answer**.
- ◆ Second call is now connected.
- ◆ You can now swap between calls by pressing **Answer**.
- ◆ When finished with one call, hang up and second call will ring back.

## Call Back

*If you dial a busy extension:*

### SET:

- ◆ Press Softkey below “**CB**”.
- ◆ Hang up.  
You may originate or receive calls during this waiting period.  
When both extensions are free, your phone will ring.
- ◆ Lift handset\* and the previous busy extension will ring.



**CANCEL:**

- ◆ Lift handset\*.
- ◆ Press Softkey below “**CB**”.
- ◆ Hang up.

**Logged Out IP Station – Call Destination**

*Forwards all calls immediately, when Dterm IP is in Logout status.*

**SET:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below “**FD L**”.
- ◆ Dial extension number, or external number† to which your calls are to be forwarded.

**CANCEL:**

- ◆ Lift handset\*.
- ◆ Press the Softkey below “**FD L**”.

# PROGRAMMABLE KEYS FEATURES

## Call Forward All

*Forwards all calls immediately.*

### SET:

- ◆ Lift handset\*.
- ◆ Press **Fwd All** or dial .
- ◆ Dial extension or external number<sup>†</sup> to which your calls are to be forwarded.
- ◆ Hang up.

### CANCEL:

- ◆ Lift handset\*.
- ◆ Press **Fwd All** or dial .
- ◆ Hang up.

## Call Forward No Answer

*Forwards calls after 4 to 6 rings.*

### SET:

- ◆ Lift handset\*.
- ◆ Press **Fwd Nans** or dial .
- ◆ Dial extension or external number<sup>†</sup> to which your calls are to be forwarded.
- ◆ Hang up.

### CANCEL:

- ◆ Lift handset\*.
- ◆ Press **Fwd Nans** or dial .
- ◆ Hang up.

## Call Forward Busy

*Forwards calls only when your extension is busy.*

### SET:

- ◆ Lift handset\*.
- ◆ Press **Fwd Busy** or dial .
- ◆ Dial extension or external number† your calls are to be forwarded.
- ◆ Hang up.

### CANCEL:

- ◆ Lift handset\*.
- ◆ Press **Fwd Busy** or dial .
- ◆ Hang up.

## Call Back

*If you dial a busy extension:*

- ◆ Press **Call Back** or dial .
- ◆ You may originate or receive calls during this waiting period.
- ◆ When both extensions are free, your phone will ring.
- ◆ Lift handset and the previous busy extension will ring.

### CANCEL:

- ◆ Lift handset\*.
- ◆ Press **Call Back** or dial .
- ◆ Hang up.

## Group Call Pick Up

*To answer another extension in your group:*

- ◆ Lift handset\*.
- ◆ Press **Pick** or dial .

## Direct Call Pick Up

*To answer a specific extension in your group or another:*

- ◆ Lift handset\*.
- ◆ Dial  plus extension number of ringing phone.

## Call Waiting – Operator

*To hold one call and answer a second call waiting:*

- ◆ Whilst on a call, hear call waiting tone (one short tone).
- ◆ Press **Answer**.
- ◆ Second call is now connected.
- ◆ You can now swap between calls by pressing **Answer**.
- ◆ When finished with one call, hang up and second call will ring back.

## Manager/Secretary Transfer

**Secretary:**

- ◆ Lift handset and press Manager's ringing line.
- ◆ Ask the caller to wait.
- ◆ Press Manager's line again; Intercom is activated.
- ◆ Announce call to Manager.

## **Manager:**

- ◆ If call is accepted – Secretary replaces handset; Manager presses flashing line and lifts handset.
- ◆ If call is refused – Secretary presses Transfer to return to the caller.

## **Call Park**

- ◆ Ask existing party to hold & press **TRF**.
- ◆ Enter .
- ◆ Call now parked.

*Call can be retrieved from any telephone by:*

- ◆ Lift handset\*.
- ◆ Dial  and extension where call parked from.
- ◆ If retrieving from own handset dial .

## **Message**

### **To Leave a Message:**

- ◆ Lift handset & dial extension.
- ◆ Receive no answer to busy signal.
- ◆ Press **MSG**.

### **To Display Message:**

- ◆ Press **MSG**.
- ◆ Re-press **MSG** to display additional messages.

### **To Respond:**

- ◆ While displaying additional messages press **SPKR**.
- ◆ Press **MSG** to dial extension which left message.
- ◆ Message erased.

## To Cancel:

- ◆ Press **MSG** to display desired message.
- ◆ Dial # while message on display.

## Save & Repeat

### SAVE:

- ◆ Lift handset\*.
- ◆ Dial desired telephone number.
- ◆ Press **S&R**.

### REPEAT:

- ◆ Lift handset\*.
- ◆ Press **S&R** and number saved is redialled.

## Voicecall

*To speak over the intercom to other Dterm telephones only:*

- ◆ Lift handset\*.
- ◆ Dial extension.
- ◆ Press **Voice** or speak over intercom.
- ◆ Hang up to disconnect.

## System Speed Dial

- ◆ Lift handset\*.
- ◆ Dial Access code .
- ◆ Enter 2/3 digit abbreviated code e.g. \_\_\_\_\_070.

## Night Answer

*From any phone:*

- ◆ Lift handset\*.
- ◆ Dial .
- ◆ Caller is connected.

## UNIQUE Dterm FEATURES

### Speed Calling (One Touch Buttons)

**To program (do not lift handset):**

- ◆ Press **Feature**.
- ◆ Press desired Speed Call button.
- ◆ Enter extension or external number†.
- ◆ Press **Feature** again to save.

**To verify:**

- ◆ Press **Feature** button.
- ◆ Press desired Speed Call button.

**To make a call:**

- ◆ Press desired Speed Call button for hands free dialling, or lift handset\* and press desired Speed Call.

***Note:** To change number, override with new number.*

## To Store Numbers In Memory

### To store number:

- ◆ List handset.
- ◆ Enter
- ◆ Enter memory number† 0 - 9.
- ◆ Enter number‡ to be stored.
- ◆ Wait for SPD SET to display.
- ◆ Replace handset.

### To access number:

- ◆ Press **Redial**.
- ◆ Enter memory number† 0 - 9.

## MIC (Microphone)

*To enable hands free conversation:*

### SET:

- ◆ Press the **MIC** key.

### CANCEL:

- ◆ Press the **MIC** key.

***Note:** The MIC LED will illuminate when MIC is on.*

## Lamps

### **Call Indicator Lamp**

A lamp at the top corner of the Dterm flashes when a call is presented to the handset. The lamp remains lit when a message has been left.



## **LCD (Liquid Crystal Display)**

The LCD provides visual Dterm activity plus the date, time and Softkey detail.

## **LED (Light Emitting Diode)**

Some function keys have a built-in LED that lights or flashes according to the activity of that function key.

## **MIC (Microphone)**

Lamp displays the status of the built-in microphone used for hands free operation to the activity of that function key.

## **Display**

*To adjust the Display:*

Press the **▲** or **▼** key up or down while the phone is idle.

## **Speaker/Receiver Volume**

*Adjust Speaker/Receiver Volume:*

Press the **▲** or **▼** key up or down during conversation.

## **Ringer Volume**

*Adjust Ringer Volume:*

Press **▲** or **▼** key up or down during ringing.

## **Feature Key Activities**

**Feature + 0** Side Tone ON/OFF.

**Feature + 1** Turns MIC ON/OFF.

**Feature + 2** Adjusts handset receiver volume.

- Feature + 3** Selects from 4 ring tones (repeat key “3” to select tone).
- Feature + 4** Adjusts transmission/receiving volume.
- Feature + 5** Activates hands free operation.
- Feature + 6** Deactivates hands free operation.
- Feature + 7** Turns call indicator lamp ON/OFF. (If turned OFF, this lamp will still light to indicate message waiting.)

## Function Keys

### ***Recall***

Press this key to terminate current call and re-seize dial tone.

### ***Feature***

Used to activate Dterm setup functions and to program Speed Dial/Feature keys.

### ***Conf (Conference)***

Press this key to establish a 3-way conversation. LED on key lights when key is active.

### ***Redial***

Press this key to activate Last Number Redial, Stack Dial and Speed Calling.

### ***Speaker***

Controls the built-in speaker, which can be used for hands free dialling/monitoring LED on key lights when key is active.

## ***Answer***

When the LED is flashing, press the key to answer a call waiting.

## ***Transfer***

Allows the user to transfer a call.

## ***Hold***

Press this key to place an internal or external call on hold.

## **Power Save Mode**

After a predetermined time, this feature dims the LCD and Line Keys.

(Not applicable to Dterm IP.)

<b>NOTES:</b>
---------------

## SYSTEM INFORMATION

Main Number: \_\_\_\_\_

Main Fax Number: \_\_\_\_\_

Indial Number: \_\_\_\_\_

Voice Mail Pilot: \_\_\_\_\_

Voice Mail Indial: \_\_\_\_\_

System Manager: \_\_\_\_\_

### **SPECIAL NOTE:**

DATA port of DTR-2DT terminal is for  
MODEM connections only.

NOTE: Refer to your detailed user guide (ND-91712)  
for advanced features.

The material contained herein is subject to change  
without prior notice at the sole discretion of  
NEC Business Solutions Ltd.