

OPTIMUS®

Cat. No. 12-1717

Three-Way Flush-Mount Car Speakers

Your Optimus Three-Way Flush-Mount Car Speakers provide clean sound and each speaker can handle up to 30 watts. The panel-mount design lets you easily mount the speakers so that they are flush with the mounting surface. To get the best sound from your speakers, read this entire manual carefully for the proper wiring and mounting procedure.

BEFORE YOU BEGIN

We recommend that you wire the speakers to your sound system before you mount the speakers so that you can test the speakers and the wire connections. Then, disconnect the wires, route the wires, and mount the speakers.

Note: If you are unsure about wiring or mounting, we suggest you have a professional install the speakers.

WIRING THE SPEAKERS

All RadioShack autosound systems come with four color coded speaker wires. The following chart shows RadioShack's standard color codes.

Speaker Terminal	Wire Color
Left Positive (+)	Green
Left Negative (-)	White
Right Positive (+)	Brown
Right Negative (-)	Gray


Connect your stereo's speaker wires to the speakers, using the color-code chart as a guide. Then, turn on your stereo to be sure that you properly connected the speakers.

Note: Other autosound systems are also equipped with four wires but the wires might not use the same color codes. If your autosound system is a brand other than Radio Shack, check the owner's manual for the speaker wire color codes.

Caution: Do not connect any of your speaker wires to the chassis ground. Use all four wires to connect the speakers to your vehicle's auto sound system.

© 1997 Tandy Corporation.
All Rights Reserved.

Optimus and RadioShack are registered trademarks used by Tandy Corporation.



Two-Speaker System

MOUNTING THE SPEAKERS

Four-Speaker System

Follow these steps to mount the speakers.





1. Remove the door panel you want to mount the speaker on and find a location where the speaker will fit. Most vehicles have a prepared cut-out area in the door for speaker placement. Use the supplied template to be sure the location you choose is large enough for the speaker opening.

Note: To be sure the speaker will not interfere with your vehicle's window mechanism, roll down your vehicle's window completely. If the window has a hand crank, be sure the speaker will not hinder you from turning the crank.

2. Mark the mounting hole locations and outline the speaker on the door panel using the supplied template.

Notes:

- Be sure you match the speaker wires to their corresponding positive (+) or negative (-) speaker terminals to ensure proper phasing. Improper phasing can cause poor bass response.
- If your speaker system includes rear speakers, the same color code applies. If your auto sound system has a front to rear fader, connect your speakers as follows:





3. Drill a starter hole inside the out-lined area. Carefully remove the area you marked, using a razor, tin snip, or a hacksaw blade.

6. Replace the door panel. Then, pull the wires through the hole you made for the speaker and connect the wires to the speaker's terminals. See "Wiring the Speakers."

4. Drill three 1/8-inch mounting holes.

7. Mount the speaker as needed.




- If you mount the speaker on a metal surface, align the mounting holes on the speaker with the three drilled holes and secure the speaker with the supplied screws.
- If you mount the speaker on a non-metal surface, insert the three supplied speed clips into the mounting holes to ensure a firm mount and to protect the mounting holes. Then align the mounting holes on the speaker with the three drilled holes and secure the speaker with the supplied screws.

5. Disconnect the wires from the speakers and route them from your sound system through the door sill and to the speaker's mounting location. You might need to drill a hole to route the wire through the door sill. Some cars have predrilled holes and rubber tubes for routing wires.

Cautions:

- Be sure you allow enough slack in the wire to prevent pulling the wire from the speaker when you open the door all the way.
- Tape any exposed wire to prevent the wire from being pinched or cut when the door is closed.

8. Align the speaker grille with the speaker and press it onto the speaker until it snaps into place.



SPECIFICATIONS

Woofer	5 1/4 Inch
Midrange	2 Inch
Piezo Tweeter	1 Inch
Magnet Weight.....	17.72 oz (502.65 g)
Power-Handling Capability	30 Watts Each
Impedance	4 Ohms
Frequency Response	70 Hz–20,000 Hz
Sensitivity	90 dB 1 Watt 50cm

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, Dept. W, 100 Throckmorton St., Suite 600, Fort Worth, TX 76102

We Service What We Sell

3/97

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

9A7

Printed in China