



M3T-DIRECT80S

Direct Dummy IC for 80-pin 0.65mm pitch QFP

User's Manual

Notes regarding these materials

- This document is provided for reference purposes only so that Renesas customers may select the appropriate Renesas products for their use. Renesas neither makes warranties or representations with respect to the accuracy or completeness of the information contained in this document nor grants any license to any intellectual property rights or any other rights of Renesas or any third party with respect to the information in
- Renesas shall have no liability for damages or infringement of any intellectual property or other rights arising out of the use of any information in this document, including, but not limited to, product data, diagrams, charts, programs, algorithms, and application circuit examples.
- You should not use the products or the technology described in this document for the purpose of military applications such as the development of weapons of mass destruction or for the purpose of any other military use. When exporting the products or technology described herein, you should follow the applicable export control laws and regulations, and procedures required by such laws and regulations.

 All information included in this document such as product data, diagrams, charts, programs, algorithms, and application circuit examples, is current see of the date this document is issued. Such information between is
- application circuit examples, is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas products listed in this document, please confirm the latest product information with a Renesas sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas such as that disclosed through our website. (http://www.renesas.com)
- Renesas has used reasonable care in compiling the information included in this document, but Renesas assumes no liability whatsoever for any damages incurred as a result of errors or omissions in the information included in this document.
- When using or otherwise relying on the information in this document, you should evaluate the information in light of the total system before deciding about the applicability of such information to the intended application. Renesas makes no representations, warranties or guaranties regarding the suitability of its products for any particular application and specifically disclaims any liability arising out of the application and use of the information in this document or Renesas products.

 With the exception of products specified by Renesas as suitable for automobile applications, Renesas
- products are not designed, manufactured or tested for applications or otherwise in systems the failure or malfunction of which may cause a direct threat to human life or create a risk of human injury or which require especially high quality and reliability such as safety systems, or equipment or systems for transportation and traffic, healthcare, combustion control, aerospace and aeronautics, nuclear power, or undersea communication transmission. If you are considering the use of our products for such purposes, please contact a Renesas sales office beforehand. Renesas shall have no liability for damages arising out of the uses set forth above. Notwithstanding the preceding paragraph, you should not use Renesas products for the purposes listed below:
- - (1) artificial life support devices or systems (2) surgical implantations

 - (3) healthcare intervention (e.g., excision, administration of medication, etc.)

 - (4) any other purposes that pose a direct threat to human life
 Renesas shall have no liability for damages arising out of the uses set forth in the above and purchasers who
 elect to use Renesas products in any of the foregoing applications shall indemnify and hold harmless Renesas
 Technology Corp., its affiliated companies and their officers, directors, and employees against any and all damages arising out of such applications.
- You should use the products described herein within the range specified by Renesas, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas shall have no liability for malfunctions or damages arising out of the use of Renesas products beyond such specified ranges.

 10. Although Renesas endeavors to improve the quality and reliability of its products, IC products have specific
- characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Please be sure to implement safety measures to guard against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention appropriate treatment for aging degradation or any other applicable measures. Among others, since the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 11. In case Renesas products listed in this document are detached from the products to which the Renesas products are attached or affixed, the risk of accident such as swallowing by infants and small children is very high. You should implement safety measures so that Renesas products may not be easily detached from your
- products. Renesas shall have no liability for damages arising out of such detachment.

 12. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written
- approval from Renesas.

 13. Please contact a Renesas sales office if you have any questions regarding the information contained in this document, Renesas semiconductor products, or if you have any other inquiries



If the requirements shown in the "CAUTION" sentences are ignored, the equipment may cause personal injury or damage to the products.

Renesas Tools Homepage http://www.renesas.com/tools

Rev.2.00 Aug. 01, 2007 REJ10J0335-0200

1. Description

This accessory tool connects an emulation pod and the target. It can be mounted on the same foot pattern as the MCU housed in the 80-pin 0.65mm pitch QFP. It is applicable to the M16C and 740 Family, etc.

2. Package Components (see Figure 1)

- (1) DIRECT80S main unit (16.8x16.8mm)
- (2) DIRECT80S User's Manual (this manual)

3. Specifications

Table 1 Specifications

Item	Description			
Package	PRQP0080JA-A (formerly: 80P6S-A) (80-pin 0.65mm-pitch QFP)			
Max. current	200mA, 5V			
Insertion/removal iterations of connector	20 times guaranteed			
Insulation resistance	100M Ω or over			

4. Application (see Figure 2)

Mount this dummy IC on the foot pattern on the target. Then connect the emulation pod at the top of dummy IC. Before using M3T-DIRECT80S, be sure to read the precautions on page 3.




Figure 1 Package components of M3T-DIRECT80S




Figure 2 Usage of M3T-DIRECT80S

5. Target Foot Pattern

Figure 3 shows the recommended foot pattern of M3T-DIRECT80S.




Figure 3 Recommended foot pattern of M3T-DIRECT80S

6. Precautions

ACAUTION

Caution To Be Taken for This Product:

• Before mounting the M3T-DIRECT80S, be sure to check the pin positions.

Notes for This Product:

- We cannot accept any request for repair.
- For inquiries about the product or the contents of this manual, contact your local distributor.

Renesas Tools Homepage http://www.renesas.com/tools

7. External Dimensions of M3T-DIRECT80S




Figure 4 External dimensions of M3T-DIRECT80S

Some part numbers in this user's manual can be referred to as the following.

In this manual Actual part number

DIRECT80S -> M3T-DIRECT80S

8. Correspondence of Connectors J1 and J2

Table 2 lists the correspondence of M3T-DIRECT80S and connectors J1, J2.


Table 2 Correspondence of M3T-DIRECT80S and connectors J1, J2

Connector pin No.	DIRECT80S pin No.						
J1-1	63	J1-26	NC	J2-1	79	J2-26	23
J1-2	64	J1-27	39	J2-2	80	J2-27	24
J1-3	65	J1-28	40	J2-3	1	J2-28	25
J1-4	66	J1-29	41	J2-4	2	J2-29	26
J1-5	67	J1-30	42	J2-5	3	J2-30	27
J1-6	68	J1-31	43	J2-6	4	J2-31	28
J1-7	69	J1-32	44	J2-7	5	J2-32	29
J1-8	70	J1-33	45	J2-8	6	J2-33	30
J1-9	NC	J1-34	46	J2-9	7	J2-34	NC
J1-10	NC	J1-35	47	J2-10	8	J2-35	NC
J1-11	NC	J1-36	48	J2-11	9	J2-36	NC
J1-12	NC	J1-37	49	J2-12	10	J2-37	NC
J1-13	NC	J1-38	50	J2-13	11	J2-38	NC
J1-14	NC	J1-39	51	J2-14	12	J2-39	NC
J1-15	NC	J1-40	52	J2-15	13	J2-40	NC
J1-16	NC	J1-41	53	J2-16	14	J2-41	NC
J1-17	NC	J1-42	54	J2-17	15	J2-42	NC
J1-18	31	J1-43	55	J2-18	16	J2-43	71
J1-19	32	J1-44	56	J2-19	17	J2-44	72
J1-20	33	J1-45	57	J2-20	18	J2-45	73
J1-21	34	J1-46	58	J2-21	19	J2-46	74
J1-22	35	J1-47	59	J2-22	20	J2-47	75
J1-23	36	J1-48	60	J2-23	21	J2-48	76
J1-24	37	J1-49	61	J2-24	22	J2-49	77
J1-25	38	J1-50	62	J2-25	NC	J2-50	78

(NC: not connected)

9. Recommended Procedure for Soldering M3T-DIRECT80S

(1) Fix the soldering position



(2) Apply the flux



• Apply flux to the semicircular through holes on the four sides.

(3) Solder



- Use a soldering iron having a large contact surface.
- Move the soldering iron in parallel with each surface (with a feeling of causing the solder to flow).
- Pressing the semicircular through holes hard may cause them to get crushed, so be careful.
- Make certain that no solder bridges are present.