

Intel® Blade Server Ethernet Switch Modules SBCEGBESW1 and SBCEGBESW10 CLI Guide

A Guide for System Administrators of Intel® Server Products

Intel Order Number D67145-002

Disclaimer

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Other names and brands may be claimed as the property of others.

Copyright © 2006, Intel Corporation. All Rights Reserved.

This product includes software developed by the OpenSSL Project for use in the Open SSL Toolkit (<http://www.openssl.org/>).

This product includes software developed by the NetBSD Foundation, Inc., and its contributors.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

This product includes software written by Tim Hudson (tjh@cryptsoft.com).

SECURE SOCKETS LAYER DELIVERABLE: The Secure Sockets Layer shall constitute "OpenSSL Deliverables" hereunder. The OpenSSL Deliverables are provided to Licensee under the terms of this Agreement and the OpenSSL License Agreement (the "OpenSSL License"), and any use of such OpenSSL Deliverables shall comply with the terms and conditions of the OpenSSL License and this Agreement. A copy of the OpenSSL License is available in the license.txt file accompanying the Deliverables and at <http://www.openssl.org/source/license.html>.

SSH PROTOCOL SUITE OF NETWORK CONNECTIVITY TOOLS DELIVERABLES: The SSH protocol suite of network connectivity tools shall constitute "Open SSH Deliverables" hereunder. The OpenSSH Deliverables are provided to Licensee under the terms of this Agreement and the BSD License (the "BSD License"), and any use of such OpenSSH Deliverables shall comply with the terms and conditions of the BSD License and this Agreement. A copy of the BSD License is set forth as below:

Copyright © Marvell International Ltd. and its affiliates.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistribution of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by the NetBSD Foundation, Inc. and its contributors.
4. Neither the name of Marvell nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Safety Information

Important Safety Instructions

Read all caution and safety statements in this document before performing any of the instructions.

Wichtige Sicherheitshinweise

Lesen Sie zunächst sämtliche Warn und Sicherheitshinweise in diesem Dokument, bevor Sie eine der Anweisungen ausführen.

Consignes de sécurité

Lisez attention toutes les consignes de sécurité et les mises en garde indiquées dans ce document avant de suivre toute instruction.

Instrucciones de seguridad importantes

Lea todas las declaraciones de seguridad y precaución de este documento antes de realizar cualquiera de las instrucciones.

重要安全指导

在执行任何指令之前，请阅读本文档中的所有注意事项及安全声明。 和/或
<http://support.intel.com/support/motherboards/server/sb/CS-010770.htm> 上的 Intel
Server Boards and Server Chassis Safety Information (《Intel
服务器主板与服务器机箱安全信息》)。

Warnings

Heed safety instructions: Before working with your server product, whether you are using this guide or any other resource as a reference, pay close attention to the safety instructions. You must adhere to the assembly instructions in this guide to ensure and maintain compliance with existing product certifications and approvals. Use only the described, regulated components specified in this guide. Use of other products / components will void the UL listing and other regulatory approvals of the product and will most likely result in noncompliance with product regulations in the region(s) in which the product is sold.

System power on/off: The power button DOES NOT turn off the system AC power. To remove power from system, you must unplug the AC power cord from the wall outlet. Make sure the AC power cord is unplugged before you open the chassis, add, or remove any components.

Hazardous conditions, devices and cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the server and disconnect the power cord, telecommunications systems, networks, and modems attached to the server before opening it. Otherwise, personal injury or equipment damage can result.

Electrostatic discharge (ESD) and ESD protection: ESD can damage disk drives, boards, and other parts. We recommend that you perform all procedures in this chapter only at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground any unpainted metal surface on your server when handling parts.

Preface

About this Manual

Thank you for purchasing and using an Intel® Blade Server Ethernet Switch Module SBCEGBESW1 or SBCEGBESW10.

This manual is written for System Administrators who have knowledge of device management through Command Line Interface (CLI) commands. This document provides the basic rules for understanding how the commands are presented in this guide. The Guide also provides command by command information of all available CLI commands, inclusive of the command description, command syntax, any parameters, other relevant command information, and a basic example. For the latest version of this manual, see <http://support.intel.com>.

Manual Organization

- Chapter 1 Using CLI
- Chapter 2 AAA Commands
- Chapter 3 Address Table Commands
- Chapter 4 ACL Commands
- Chapter 5 Clock Commands
- Chapter 6 Configuration and Image File Commands
- Chapter 7 Ethernet Configuration Commands
- Chapter 8 GVRP Commands
- Chapter 9 IGMP Snooping Commands
- Chapter 10 IP Address Commands
- Chapter 11 LACP Commands
- Chapter 12 Line Commands
- Chapter 13 Management ACL Commands
- Chapter 14 PHY Diagnostics Commands

- [Chapter 15 Port Channel Commands](#)
- [Chapter 16 Port Monitor Commands](#)
- [Chapter 17 QoS Commands](#)
- [Chapter 18 RMON Commands](#)
- [Chapter 19 RADIUS Commands](#)
- [Chapter 20 Web Server Commands](#)
- [Chapter 21 SNMP Commands](#)
- [Chapter 22 Spanning-Tree Commands](#)
- [Chapter 23 SSH Commands](#)
- [Chapter 24 Syslog Commands](#)
- [Chapter 25 System Management Commands](#)
- [Chapter 26 TACACS+ Commands](#)
- [Chapter 27 User Interface Commands](#)
- [Chapter 28 VLAN Commands](#)
- [Chapter 29 802.1x Commands](#)
- [Appendix A: Getting Help](#)

Contents

Important Safety Instructions	iii
Wichtige Sicherheitshinweise	iii
Consignes de sécurité	iii
Instrucciones de seguridad importantes	iii
Warnings	iv
About this Manual	v
Manual Organization	v
Chapter 1: Using CLI	1
Overview	1
Chapter 2: AAA Commands	9
aaa authentication login	9
aaa authentication enable	10
login authentication	11
enable authentication	12
ip http authentication	13
ip https authentication	14
show authentication methods	15
password	16
enable password	17
username	18
Chapter 3: Address Table Commands	21
bridge address	21
bridge multicast filtering	22
bridge multicast address	23
bridge multicast forbidden address	24
bridge multicast forward-all	25
bridge multicast forbidden forward-all	26
bridge aging-time	27
clear bridge	28
port security	28
port security mode	29
port security routed secure-address	30
show bridge address-table	31
show bridge address-table static	32
show bridge address-table count	33
show bridge multicast address-table	34
show bridge multicast filtering	36

show ports security	37
show ports security addresses	38
Chapter 4: ACL Commands	41
ip access-list	41
permit (ip)	42
deny (IP)	44
mac access-list	46
permit (MAC)	47
deny (MAC)	48
service-acl	50
show access-lists	50
show interfaces access-lists	51
Chapter 5: Clock Commands	53
clock set	53
clock source	54
clock timezone	54
clock summer-time	55
snntp authentication-key	57
snntp authenticate	58
snntp trusted-key	59
snntp client poll timer	59
snntp broadcast client enable	60
snntp anycast client enable	61
snntp client enable (Interface)	62
snntp unicast client enable	63
snntp unicast client poll	63
snntp server	64
show clock	65
show snntp configuration	66
show snntp status	67
Chapter 6: Configuration and Image File Commands	69
copy	69
delete	71
boot system	72
show running-config	73
show startup-config	74
show backup-config	75
show bootvar	76
Chapter 7: Ethernet Configuration Commands	79
interface ethernet	79
interface range ethernet	79

shutdown	80
description	81
speed	82
duplex	83
negotiation	84
flowcontrol	85
mdix	86
back-pressure	87
port jumbo-frame	87
clear counters	88
set interface active	89
show interfaces advertise	90
show interfaces configuration	91
show interfaces status	92
show interfaces description	93
show interfaces counters	94
show ports jumbo-frame	97
port storm-control include-multicast (GC)	98
port storm-control include-multicast (IC)	98
port storm-control broadcast enable	99
port storm-control broadcast rate	100
show ports storm-control	101
Chapter 8: GVRP Commands	103
gvrp enable (Global)	103
gvrp enable (Interface)	103
garp timer	104
gvrp vlan-creation-forbid	105
gvrp registration-forbid	106
clear gvrp statistics	107
show gvrp configuration	108
show gvrp statistics	109
show gvrp error-statistics	110
Chapter 9: IGMP Snooping Commands	111
ip igmp snooping (Global)	111
ip igmp snooping (Interface)	111
ip igmp snooping mrouter learn-pim-dvmrp	112
ip igmp snooping host-time-out	113
ip igmp snooping mrouter-time-out	114
ip igmp snooping leave-time-out	115
show ip igmp snooping mrouter	116
show ip igmp snooping interface	117
show ip igmp snooping groups	118

Chapter 10: IP Address Commands	121
ip address	121
ip address dhcp	122
ip default-gateway	123
show ip interface	124
arp	125
arp timeout	126
clear arp-cache	127
show arp	127
ip domain-lookup	128
ip domain-name	129
ip name-server	130
ip host	131
clear host	131
clear host dhcp	132
show hosts	133
Chapter 11: LACP Commands	135
lacp system-priority	135
lacp port-priority	135
lacp timeout	136
show lacp ethernet	137
show lacp port-channel	139
Chapter 12: Line Commands	141
Line	141
show line	141
Chapter 13: Management ACL Commands	145
management access-list	145
Chapter 14: PHY Diagnostics Commands	153
test copper-port tdr	153
show copper-ports tdr	154
show copper-ports cable-length	155
.....	155
Chapter 15: Port Channel Commands	157
.....	157
interface port-channel	157
interface range port-channel	158
channel-group	158
show interfaces port-channel	159
Chapter 16: Port Monitor Commands	161
port monitor vlan-tagging	162

show ports monitor	163
Chapter 17: QoS Commands	165
qos	165
show qos	166
show qos aggregate-policer	166
show qos interface	167
show qos map	169
class-map	170
show class-map	171
match	172
policy-map	173
class	174
show policy-map	175
trust cos-dscp	176
set	177
police	178
service-policy	179
qos aggregate-policer	180
show qos aggregate-policer	181
police aggregate	182
wrr-queue cos-map	183
wrr-queue bandwidth	184
priority-queue out num-of-queues	185
traffic-shape	186
show qos interface	187
qos wrr-queue threshold	189
qos map policed-dscp	190
qos map dscp-queue	191
qos trust (Global)	192
qos trust (Interface)	193
qos cos	194
qos dscp-mutation	195
qos map dscp-mutation	196
Chapter 18: RMON Commands	199
show rmon statistics	199
rmon collection history	201
show rmon collection history	202
show rmon history	203
rmon alarm	206
show rmon alarm-table	208
show rmon alarm	209
rmon event	210
show rmon events	211

show rmon log	212
rmon table-size	214
Chapter 19: RADIUS Commands	215
radius-server host	215
radius-server key	216
radius-server retransmit	217
radius-server source-ip	218
radius-server timeout	219
radius-server deadtime	220
show radius-servers	220
Chapter 20: Web Server Commands	223
ip http server	223
ip http port	223
ip http exec-timeout	224
ip https server	225
ip https port	226
ip https exec-timeout	226
crypto certificate generate	227
crypto certificate request	228
crypto certificate import	230
ip https certificate	231
show crypto certificate mycertificate	232
show ip http	233
show ip https	234
Chapter 21: SNMP Commands	237
snmp-server community	237
snmp-server view	238
snmp-server group	239
snmp-server user	241
snmp-server engineID local	242
snmp-server enable traps	244
snmp-server filter	245
snmp-server host	246
snmp-server v3-host	247
snmp-server trap authentication	248
snmp-server contact	249
snmp-server location	250
snmp-server set	251
show snmp	252
show snmp engineid	253
show snmp views	254
show snmp groups	255

show snmp filters	256
show snmp users	257
Chapter 22: Spanning-Tree Commands	259
spanning-tree	259
spanning-tree mode	259
spanning-tree forward-time	260
spanning-tree max-age	262
spanning-tree priority	263
spanning-tree disable	264
spanning-tree cost	264
spanning-tree port-priority	265
spanning-tree portfast	266
spanning-tree link-type	267
spanning-tree pathcost method	268
spanning-tree bpdu	269
clear spanning-tree detected-protocols	270
spanning-tree mst priority	270
spanning-tree mst max-hops	271
spanning-tree mst port-priority	272
spanning-tree mst cost	273
spanning-tree mst configuration	274
instance (mst)	275
name (mst)	276
revision (mst)	276
show (mst)	277
exit (mst)	278
abort (mst)	279
spanning-tree guard root	279
show spanning-tree	280
Chapter 23: SSH Commands	295
ip ssh port	295
ip ssh server	295
crypto key generate dsa	296
crypto key generate rsa	297
ip ssh pubkey-auth	298
crypto key pubkey-chain ssh	299
user-key	300
key-string	301
show ip ssh	302
show crypto key mypubkey	303
show crypto key pubkey-chain ssh	304
Chapter 24: Syslog Commands	307

logging on	307
logging	308
logging buffered	309
logging buffered size	310
clear logging	310
logging file	311
clear logging file	312
aaa logging	313
file-system logging	313
management logging	314
show logging	315
show logging file	317
show syslog-servers	318
Chapter 25: System Management Commands	321
ping	321
traceroute	322
telnet	325
resume	328
reload	328
hostname	329
show users	330
show sessions	331
show system	332
show system id	333
show system flowcontrol	334
show system mode	335
show version	335
service cpu-utilization	336
show cpu utilization	337
Chapter 26: TACACS+ Commands	339
tacacs-server host	339
tacacs-server key	340
tacacs-server timeout	341
tacacs-server source-ip	342
show tacacs	342
Chapter 27: User Interface Commands	345
enable	345
disable	345
login	346
configure	347
exit (Configuration)	348
exit	348

end	349
help	350
terminal datadump	350
show history	351
show privilege	352
do	353
Chapter 28: VLAN Commands	355
vlan database	355
vlan	355
interface vlan	356
interface range vlan	357
name	358
switchport protected	359
switchport mode	360
switchport access vlan	360
switchport trunk allowed vlan	361
switchport trunk native vlan	362
switchport general allowed vlan	363
switchport general pvid	364
switchport general ingress-filtering disable	365
switchport general acceptable-frame-type tagged-only	366
switchport forbidden vlan	366
ip internal-usage-vlan	367
show vlan	368
show vlan internal usage	369
show interfaces switchport	370
map protocol protocols-group	373
switchport general map protocols-group vlan	374
map mac macs-group	375
switchport general map macs-group vlan	376
map subnet subnets-group	377
switchport general map subnets-group vlan	377
show vlan protocols-groups	378
show vlan macs-groups	379
show vlan subnets-groups	380
Chapter 29: 802.1x Commands	383
aaa authentication dot1x	383
dot1x system-auth-control	384
dot1x port-control	384
dot1x re-authentication	386
dot1x timeout re-authperiod	386
dot1x re-authenticate	387
dot1x timeout quiet-period	388

dot1x timeout tx-period	389
dot1x max-req	390
dot1x timeout supp-timeout	391
dot1x timeout server-timeout	392
show dot1x	393
show dot1x users	395
show dot1x statistics	397
ADVANCED FEATURES	398
dot1x auth-not-req	398
dot1x multiple-hosts	399
dot1x single-host-violation	400
dot1x guest-vlan	401
dot1x guest-vlan enable	402
show dot1x advanced	403
Appendix A: Getting Help	405
World Wide Web	405
Telephone	405

1 Using CLI

Overview

This document describes the Command Line Interface (CLI) used to manage the Intel® Blade Server Ethernet Switch Modules SBCEGBESW1 and SBCEGBESW10. The switches can operate as standalone systems, or can be stacked together in the same system.

Most of the CLI commands are applicable to both switch modules.

This chapter describes how to start using the CLI and the CLI command editing features.

CLI Command Modes

Introduction

The Command Line Interface (CLI) is divided into different command modes. Each command mode has its own set of specific commands. Entering a question mark ? at the system prompt (console prompt) displays a list of commands available for that particular command mode.

From each command mode a specific command is used to navigate from one command mode to another. The order for mode access is as follows: User EXEC mode, Privileged EXEC mode, Global Configuration mode, and Interface Configuration mode.

When starting a session, the initial mode is the User EXEC mode. Only a limited subset of commands are available in User EXEC mode. This task level does not change the configuration. To enter the next level, the Privileged EXEC mode, a password is required.

The Privileged EXEC mode gives access to commands that displays device configuration and provides access to the device Configuration mode.

The Global Configuration mode manages the device configuration on a global level.

The Interface Configuration mode configures specific interfaces in the device.

User EXEC Mode

After logging into the device, the user is automatically in User EXEC command mode unless the user is defined as a privileged user. In general, the User EXEC commands allow the user to perform basic tests, and list system information.

The user-level prompt consists of the device host name followed by the angle bracket (>).

The default host name is Console unless it has been changed using the hostname

```
Console>
```

command in the Global Configuration mode.

Privileged EXEC Mode

Privileged access is password protected to prevent unauthorized use because many of the Privileged commands set operating system parameters. The password is not displayed on the screen and is case sensitive.

Privileged users enter directly into the Privileged EXEC mode. To enter the Privileged EXEC mode from the User EXEC mode, perform the following steps:

At the prompt enter the enable command and press <Enter>. A password prompt is displayed.

Enter the password and press <Enter>. The password is displayed as *. The Privileged EXEC mode prompt is displayed. The Privileged EXEC mode prompt consists of the device host name followed by #.

```
Console#
```

To return from the Privileged EXEC mode to the User EXEC mode, use the disable command. The following example illustrates how to access the Privileged EXEC mode and return to the User EXEC mode:

```
Console> enable
Enter Password: *****
Console#
Console# disable
Console>
```

The exit command is used to return from any mode to the previous mode except when returning to the User EXEC mode from the Privileged EXEC mode. For example, the exit command is used to return from the Interface Configuration mode to the Global Configuration mode.

Global Configuration Mode

Global Configuration mode commands apply to features that affect the system as a whole, rather than just a specific interface. The configure Privileged EXEC mode command is used to enter the Global Configuration mode.

To enter the Global Configuration mode perform the following steps:

1. At the Privileged EXEC mode prompt enter the configure command and press <Enter>. The Global Configuration mode prompt is displayed. The Global

Configuration mode prompt consists of the device host name followed by (config) and #.

2. To return from the Global Configuration mode to the Privileged EXEC mode, the user can use one of the following commands:

```
exit
end
Ctrl+Z
```

The following example illustrates how to access the Global Configuration mode and return to the Privileged EXEC mode:

```
Console#
Console# configure
Console(config)# exit
Console#
```

Interface Configuration and Specific Configuration Modes

Interface Configuration mode commands modify specific interface operations. The following are the Interface Configuration modes:

- Line Interface — Contains commands to configure the management connections. These include commands such as line timeout settings, etc. The line Global Configuration mode command is used to enter the Line Configuration command mode.
- VLAN Database — Contains commands to create a VLAN as a whole. The vlan database Global Configuration mode command is used to enter the VLAN Database Interface Configuration mode.
- Management Access List — Contains commands to define management access-lists. The management access-list Global Configuration mode command is used to enter the Management Access List Configuration mode.
- Ethernet — Contains commands to manage port configuration. The interface ethernet Global Configuration mode command is used to enter the Interface Configuration mode to configure an Ethernet type interface.
- Port Channel — Contains commands to configure port-channels, for example, assigning ports to a port-channel. Most of these commands are the same as the commands in the Ethernet interface mode, and are used to manage the member ports as a single entity. The interface port-channel Global Configuration mode command is used to enter the Port Channel Interface Configuration mode.
- SSH Public Key-chain — Contains commands to manually specify other device SSH public keys. The crypto key pubkey-chain ssh Global Configuration mode command is used to enter the SSH Public Key-chain Configuration mode.
- QoS — Contains commands related to service definitions. The qos Global Configuration mode command is used to enter the QoS services configuration mode.

- MAC Access-List — Configures conditions required to allow traffic based on MAC addresses. The mac access-list Global Configuration mode command is used to enter the MAC access-list configuration mode.

Starting the CLI

The device can be managed over a direct connection via a Telnet connection. The device is managed by entering command keywords and parameters at the prompt. Using the device command-line interface (CLI) is very similar to entering commands on a UNIX system.

If access is via a Telnet connection, ensure that the device has a defined IP address, corresponding management access is granted, and the workstation used to access the device is connected to the device prior to using CLI commands.

1. Enter the following commands to begin the configuration procedure:

```
Console> enable  
Console# configure  
Console(config)#
```

2. Configure the device and enter the necessary commands to complete the required tasks.
3. When finished, exit the session with the exit command.

When a different user is required to log onto the system, use the login Privileged EXEC mode command. This effectively logs off the current user and logs on the new user.

Editing Features

Entering Commands

A CLI command is a series of keywords and arguments. Keywords identify a command, and arguments specify configuration parameters. For example, in the command show interfaces status ethernet Ext.1, show, interfaces and status are keywords, ethernet is an argument that specifies the interface type, and Ext.1 specifies the port.

To enter commands that require parameters, enter the required parameters after the command keyword. For example, to set a password for the administrator, enter:

```
Console(config)# username admin password alansmith
```

When working with the CLI, the command options are not displayed. The command is not selected from a menu, but is manually entered. To see what commands are available in each mode or within an Interface Configuration, the CLI does provide a method of displaying the available commands, the command syntax requirements and in some instances parameters required to complete the command. The standard command to request help is ?.

There are two instances where help information can be displayed:

- Keyword lookup — The character ? is entered in place of a command. A list of all valid commands and corresponding help messages are displayed.
- Partial keyword lookup — If a command is incomplete and the character ? is entered in place of a parameter. The matched keyword or parameters for this command are displayed.

To assist in using the CLI, there is an assortment of editing features. The following features are described:

- Terminal Command Buffer
- Command Completion
- Nomenclature
- Keyboard Shortcuts
- Terminal Command Buffer

Every time a command is entered in the CLI, it is recorded on an internally managed Command History buffer. Commands stored in the buffer are maintained on a First In First Out (FIFO) basis. These commands can be recalled, reviewed, modified, and reissued. This buffer is not preserved across device resets.

By default, the history buffer system is enabled, but it can be disabled at any time. For information about the command syntax to enable or disable the history buffer, see “[show history](#)”.

There is a standard default number of commands that are stored in the buffer. The standard number of 10 commands can be increased to 216. By configuring 0, the effect is the same as disabling the history buffer system. For information about the command syntax for configuring the command history buffer, see history size.

To display the history buffer, see “[show history](#)”.

Negating the Effect of Commands

For many configuration commands, the prefix keyword no can be entered to cancel the effect of a command or reset the configuration to the default value. This guide describes the negation effect for all applicable commands.

Command Completion

If the command entered is incomplete, invalid or has missing or invalid parameters, then the appropriate error message is displayed. This assists in entering the correct command. By pressing the <Tab> button, an incomplete command is entered. If the characters already entered are not enough for the system to identify a single matching command, press ? to display the available commands matching the characters already entered.

Nomenclature

When referring to an Ethernet port in a CLI command, the following format is used:

For an Ethernet port on a standalone device: Ethernet_type port_number

For an Ethernet port on a stacked device: unit_number/Ethernet_type port number

The Ethernet type may be Gigabit Ethernet (indicated by “g”).

For example, g3 stands for Gigabit Ethernet port 3 on a stand-alone device, whereas 1/3 stands for Gigabit Ethernet port 3 on stacking unit.

The ports may be described on an individual basis or within a range. Use format port number-port number to specify a set of consecutive ports and port number, port number to indicates a set of non-consecutive ports. For example, g1-3 stands for Gigabit Ethernet ports 1, 2 and 3, and g1,5 stands for Gigabit Ethernet ports 1 and 5.

Keyboard Shortcuts

The CLI has a range of keyboard shortcuts to assist in editing the CLI commands. The following table describes the CLI shortcuts.

Keyboard KeyDescription

The following list provides a description of keyboard shortcuts:

- Up-arrow key — Recalls commands from the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
- Down-arrow key — Returns the most recent commands from the history buffer after recalling commands with the up arrow key. Repeating the key sequence will recall successively more recent commands.
- Ctrl+A — Moves the cursor to the beginning of the command line.
- Ctrl+E — Moves the cursor to the end of the command line.
- Ctrl+Z / End — Returns back to the Privileged EXEC mode from any configuration mode.
- Backspace key — Deletes one character left to the cursor position.

CLI Command Conventions

When entering commands there are certain command entry standards that apply to all commands. The following table describes the command conventions.

Convention	Description
[]	In a command line, square brackets indicates an optional entry.
{ }	In a command line, curly brackets indicate a selection of compulsory parameters separated by the character. One option must be selected. For example: flowcontrol {auto on off} means that for the flowcontrol command either auto, on or off must be selected.
<i>Italic font</i>	Indicates a parameter.
<Enter>	Indicates an individual key on the keyboard. For example, <Enter> indicates the Enter key.
Ctrl+F4	Any combination keys pressed simultaneously on the keyboard.
all —	When a parameter is required to define a range of ports or parameters and all is an option, the default for the command is all when no parameters are defined. For example, the command interface range port-channel has the option of either entering a range of channels, or selecting all. When the command is entered without a parameter, it automatically defaults to all.

Copying and Pasting Text

Up to 1000 lines of text (or commands) can be copied and pasted into the device.

It is the user's responsibility to ensure that the text copied into the device consists of legal commands only.

This feature is dependent on the baud rate of the device.

When copying and pasting commands from a configuration file, make sure that the following conditions exist:

A device Configuration mode has been accessed.

The commands contain no encrypted data, like encrypted passwords or keys. Encrypted data cannot be copied and pasted into the device.

Using CLI

2 AAA Commands

aaa authentication login

The **aaa authentication login** Global Configuration mode command defines login authentication. To restore defaults, use the no form of this command.

Syntax

```
aaa authentication login {default | list-name} method1 [method2...]  
no aaa authentication login {default | list-name}
```

Parameters

- **default** — Uses the listed authentication methods that follow this argument as the default list of methods when a user logs in.
- *list-name* — Character string used to name the list of authentication methods activated when a user logs in. (Range: 1-12 characters)
- *method1 [method2...]* — Specify at least one method from the following list:

Keyword	Description
enable	Uses the enable password for authentication.
line	Uses the line password for authentication.
local	Uses the local username database for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication.
tacacs	Uses the list of all TACACS+ servers for authentication.

Default Configuration

The local user database is checked. This has the same effect as the command `aaa authentication login list-name local`.

Command Mode

Global Configuration mode

User Guidelines

The default and optional list names created with the **aaa authentication login** command are used with the **login authentication** command.

Create a list by entering the **aaa authentication login** list-name method command for a particular protocol, where list-name is any character string used to name this list. The method argument identifies the list of methods that the authentication algorithm tries, in the given sequence.

The additional methods of authentication are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify none as the final method in the command line.

Example

The following example configures the authentication login.

```
Console(config)# aaa authentication login default radius tacacs enable  
line local none
```

aaa authentication enable

The **aaa authentication enable** Global Configuration mode command defines authentication method lists for accessing higher privilege levels. To restore defaults, use the no form of this command.

Syntax

```
aaa authentication enable {default | list-name} method1 [method2...]
```

```
no aaa authentication enable {default | list-name}
```

Parameters

- **default** — Uses the listed authentication methods that follow this argument as the default list of methods, when using higher privilege levels.
- **list-name** — Character string used to name the list of authentication methods activated, when using access higher privilege levels. (Range: 1-12 characters)
- **method1 [method2...]** — Specify at least one method from the following list:

Keyword	Description
enable	Uses the enable password for authentication.

Keyword	Description
line	Uses the line password for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication. Uses username \$enabx\$, where x is the privilege level.
tacacs	Uses the list of all TACACS+ servers for authentication. Uses username "\$enabx\$." where x is the privilege level.

Default Configuration

If the **default** list is not set, only the enable password is checked. This has the same effect as the command **aaa authentication enable default enable**.

Command Mode

Global Configuration mode

User Guidelines

The default and optional list names created with the **aaa authentication enable** command are used with the **enable authentication** command.

The additional methods of authentication are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify none as the final method in the command line.

All **aaa authentication enable** default requests sent by the device to a RADIUS or TACACS+ server include the username \$enabx\$, where x is the requested privilege level.

Example

The following example sets the enable password for authentication when accessing higher privilege levels.

```
Console(config)# aaa authentication enable default enable
```

login authentication

The **login authentication** Line Configuration mode command specifies the login authentication method list for a remote telnet or console. To restore the default configuration specified by the **aaa authentication login** command, use the no form of this command.

Syntax

```
login authentication {default | list-name}  
no login authentication
```

Parameters

- **default** — Uses the default list created with the aaa authentication login command.
- *list-name* — Uses the indicated list created with the aaa authentication login command.

Default Configuration

Uses the default set with the command **aaa authentication login**.

Command Mode

Line Configuration mode

User Guidelines

To change (or rename) an authentication method, use the negate command and create a new rule with the new method name.

Example

The following example specifies the default authentication method for a console.

```
Console(config)# line console  
Console(config-line)# login authentication default
```

enable authentication

The **enable authentication** Line Configuration mode command specifies the authentication method list when accessing a higher privilege level from a remote Telnet or console. To restore the default configuration specified by the **aaa authentication enable** command, use the no form of this command.

Syntax

```
enable authentication {default | list-name}  
no enable authentication
```

Parameters

- **default** — Uses the default list created with the aaa authentication enable command.
- *list-name* — Uses the indicated list created with the aaa authentication enable command.

Default Configuration

Uses the default set with the **aaa authentication enable** command.

Command Mode

Line Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example specifies the default authentication method when accessing a higher privilege level from a Telnet.

```
Console(config)# line console
Console(config-line)# enable authentication default
```

ip http authentication

The **ip http authentication** Global Configuration mode command specifies authentication methods for HTTP server users. To restore the default configuration, use the no form of this command.

Syntax

```
ip http authentication method1 [method2...]
no ip http authentication
```

Parameters

- *method1 [method2...]* — Specify at least one method from the following list:

Keyword	Description
local	Uses the local username database for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication.
tacacs	Uses the list of all TACACS+ servers for authentication.

Default Configuration

The local user database is checked. This has the same effect as the command **ip http authentication local**.

Command Mode

Global Configuration mode

User Guidelines

The additional methods of authentication are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line.

Example

The following example configures the HTTP authentication.

```
Console(config)# ip http authentication radius tacacs local none
```

ip https authentication

The **ip https authentication** Global Configuration mode command specifies authentication methods for HTTPS server users. To restore the default configuration, use the no form of this command.

Syntax

ip https authentication *method1 [method2...]*

no ip https authentication

Parameters

- *method1 [method2...]* — Specify at least one method from the following list:

Keyword	Description
local	Uses the local username database for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication.
tacacs	Uses the list of all TACACS+ servers for authentication.

Default Configuration

The local user database is checked. This has the same effect as the command **ip https authentication local**.

Command Mode

Global Configuration mode

User Guidelines

The additional methods of authentication are used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify none as the final method in the command line.

Example

The following example configures HTTPS authentication.

```
Console(config)# ip https authentication radius tacacs local none
```

show authentication methods

The **show authentication methods** Privileged EXEC mode command displays information about the authentication methods.

Syntax

show authentication methods

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the authentication configuration.

```
Console# show authentication methods
login Authentication Method Lists
-----
Default: Local

Enable Authentication Method Lists
-----
Default: Radius, Enable
Console_Enable: Enable, None

Line Login Method List Enable Method List
-----
Console Default Default
Telnet Default Default
SSH DefaultDefault

http: Local
https: Local
dot1x:
```

password

The **password** Line Configuration mode command specifies a password on a line. To remove the password, use the no form of this command.

Syntax

password *password* [**encrypted**]

no password

Parameters

- *password* — Password for this level. (Range: 1-159 characters)
- **encrypted** — Encrypted password to be entered, copied from another device configuration.

Default Configuration

No password is defined.

Command Mode

Line Configuration mode

User Guidelines

If a password is defined as encrypted, the required password length is 32 characters.

Example

The following example specifies the password called 'secret' on a Telnet.

```
Console(config)# line console
Console(config-line)# password secret
```

enable password

The **enable password** Global Configuration mode command sets a local password to control access to user and privilege levels. To remove the password requirement, use the no form of this command.

Syntax

enable password [level *level*] *password* [encrypted**]**

no enable password [level *level*]

Parameters

- *password* — Password for this level. (Range: 1-159 characters)
- **level** — Level for which the password applies. If not specified the level is 15 (Range: 1-15).
- **encrypted** — Encrypted password entered, copied from another device configuration.

Default Configuration

No enable password is defined.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets a local level 15 password called 'secret' to control access to user and privilege levels.

```
Console(config)# enable password secret level 15
```

username

The **username** Global Configuration mode command creates a user account in the local database. To remove a user name, use the no form of this command.

Syntax

username *name* [**password** *password*] [**level** *level*] [**encrypted**]

no username *name*

Parameters

- *name* — The name of the user. (Range: 1-20 characters)
- *password* — The authentication password for the user. (Range: 1-159 characters)
- *level* — The user level (Range: 1-15). If a level is not specified, the level is automatically set to 1.
- **encrypted** — Encrypted password entered, copied from another device configuration.

Default Configuration

No user is defined.

Command Mode

Global Configuration mode

User Guidelines

User account can be created without a password.

Example

The following example configures user called bob with password 'lee' and user level 15 to the system.

```
Console(config)# username bob password lee level 15
```

AAA Commands

3 Address Table Commands

bridge address

The bridge address Interface Configuration (VLAN) mode command adds a MAC-layer station source address to the bridge table. To delete the MAC address, use the no form of this command.

Syntax

```
bridge address mac-address {ethernet interface | port-channel port-channel-number}  
[permanent | delete-on-reset | delete-on-timeout | secure]
```

```
no bridge address [mac-address]
```

Parameters

- mac-address — A valid MAC address.
- interface — A valid Ethernet port.
- port-channel-number — A valid port-channel number.
- permanent — The address can only be deleted by the no bridge address command.
- delete-on-reset — The address is deleted after reset.
- delete-on-timeout — The address is deleted after "age out" time has expired.
- secure — The address is deleted after the port changes mode to unlock learning (no port security command). This parameter is only available when the port is in the learning locked mode.

Default Configuration

No static addresses are defined. The default mode for an added address is permanent.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Using the no form of the command without specifying a MAC address deletes all static MAC addresses belonging to this VLAN).

Example

The following example adds a permanent static MAC-layer station source address 3aa2.64b3.a245 on port 1 to the bridge table.

```
Console(config)# interface vlan 2
Console(config-if)# bridge address 3aa2.64b3.a245 ethernet ext.1 permanent
```

bridge multicast filtering

The bridge multicast filtering Global Configuration mode command enables filtering multicast addresses. To disable filtering multicast addresses, use the no form of this command.

Syntax

- bridge multicast filtering
- no bridge multicast filtering

Default Configuration

Filtering multicast addresses is disabled. All multicast addresses are flooded to all ports.

Command Mode

Global Configuration mode

User Guidelines

If multicast devices exist on the VLAN, do not change the unregistered multicast addresses state to drop on the switch ports.

If multicast devices exist on the VLAN and IGMP-snooping is not enabled, the bridge multicast forward-all command should be used to enable forwarding all multicast packets to the multicast switches.

Example

In the following example, bridge multicast filtering is enabled.

```
Console(config)# bridge multicast filtering
```

bridge multicast address

The bridge multicast address Interface Configuration (VLAN) mode command registers a MAC-layer multicast address in the bridge table and statically adds ports to the group. To unregister the MAC address, use the no form of this command.

Syntax

```
bridge multicast address {mac-multicast-address | ip-multicast-address}
bridge multicast address {mac-multicast-address | ip-multicast-address} [add | remove]
{ethernet interface-list | port-channel port-channel-number-list}
no bridge multicast address {mac-multicast-address | ip-multicast-address}
```

Parameters

- add — Adds ports to the group. If no option is specified, this is the default option.
- remove — Removes ports from the group.
- mac-multicast-address — A valid MAC multicast address.
- ip- multicast-address — A valid IP multicast address.
- interface-list — Separate nonconsecutive Ethernet ports with a comma and no spaces; a hyphen is used to designate a range of ports.
- port-channel-number-list — Separate nonconsecutive port-channels with a comma and no spaces; a hyphen is used to designate a range of ports.

Default Configuration

No multicast addresses are defined.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

If the command is executed without add or remove, the command only registers the group in the bridge database.

Static multicast addresses can only be defined on static VLANs.

Example

The following example registers the MAC address:

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast address 01:00:5e:02:02:03
```

The following example registers the MAC address and adds ports statically.

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast address 01:00:5e:02:02:03 add ethernet
ext.1, ext.2
```

bridge multicast forbidden address

The bridge multicast forbidden address Interface Configuration (VLAN) mode command forbids adding a specific multicast address to specific ports. Use the no form of this command to restore the default configuration.

Syntax

```
bridge multicast forbidden address {mac-multicast-address | ip-multicast-address} {add | remove} {etherent interface-list | port-channel port-channel-number-list}
no bridge multicast forbidden address {mac-multicast-address | ip-multicast-address}
```

Parameters

- add — Adds ports to the group.
- remove — Removes ports from the group.
- mac-multicast-address — A valid MAC multicast address.
- ip- multicast-address — A valid IP multicast address.
- interface-list — Separate nonconsecutive Ethernet ports with a comma and no spaces; hyphen is used to designate a range of ports.
- port-channel-number-list — Separate nonconsecutive valid port-channels with a comma and no spaces; a hyphen is used to designate a range of port-channels.

Default Configuration

No forbidden addresses are defined.

Command Modes

Interface Configuration (VLAN) mode

User Guidelines

Before defining forbidden ports, the multicast group should be registered.

Example

In this example, MAC address 0100.5e02.0203 is forbidden on port 2 within VLAN 8.

```
Console(config)# interface vlan 8
Console(config-if)# bridge multicast address 0100.5e.02.0203
Console(config-if)# bridge multicast forbidden address 0100.5e02.0203 add ethernet
ext.2
```

bridge multicast forward-all

The bridge multicast forward-all Interface Configuration (VLAN) mode command enables forwarding all multicast packets on a port. To restore the default configuration, use the no form of this command.

Syntax

bridge multicast forward-all {add | remove} {ethernet interface-list | port-channel port-channel-number-list}

no bridge multicast forward-all

Parameters

- add — Force forwarding all multicast packets.
- remove — Do not force forwarding all multicast packets.
- interface-list — Separate nonconsecutive Ethernet ports with a comma and no spaces; a hyphen is used to designate a range of ports.
- port-channel-number-list — Separates nonconsecutive port-channels with a comma and no spaces; a hyphen is used to designate a range of port-channels.

Default Configuration

This setting is disabled.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

There are no user guidelines for this command.

Example

In this example, all multicast packets on port 1 are forwarded.

```
Console(config)# interface vlan 2
Console(config-if)# bridge multicast forward-all add
ethernet ext.1
```

bridge multicast forbidden forward-all

The bridge multicast forbidden forward-all Interface Configuration (VLAN) mode command forbids a port to be a forward-all-multicast port. To restore the default configuration, use the no form of this command.

Syntax

```
bridge multicast forbidden forward-all {add | remove} {ethernet interface-list | port-channel port-channel-number-list}
```

```
no bridge multicast forbidden forward-all
```

Parameters

- add — Forbids forwarding all multicast packets.
- remove — Does not forbid forwarding all multicast packets.
- interface-list — Separates nonconsecutive Ethernet ports with a comma and no spaces; a hyphen is used to designate a range of ports.
- port-channel-number-list — Separates nonconsecutive port-channels with a comma and no spaces; a hyphen is used to designate a range of port-channels.

Default Configuration

This setting is disabled.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

IGMP snooping dynamically discovers multicast device ports. When a multicast device port is discovered, all the multicast packets are forwarded to it unconditionally.

This command prevents a port from becoming a multicast device port.

Example

In this example, forwarding all multicast packets to 1 with VLAN 2 is forbidden.

```
Console(config)# interface vlan 2
Console(config-if)# bridge multicast forbidden forward-all add ethernet ext.1
```

bridge aging-time

The bridge aging-time Global Configuration mode command sets the address table aging time. To restore the default configuration, use the no form of this command.

Syntax

bridge aging-time seconds

no bridge aging-time

Parameters

- seconds — Time in seconds. (Range: 10-630 seconds)

Default Configuration

The default setting is 300 seconds.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

In the following example, the bridge aging time is set to 250 seconds.

```
Console(config) # bridge aging-time 250
```

clear bridge

The clear bridge Privileged EXEC mode command removes any learned entries from the forwarding database.

Syntax

```
clear bridge
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

In the following example, the bridge tables are cleared.

```
Console# clear bridge
```

port security

The port security Interface Configuration mode command locks the port to block unknown traffic and prevent the port from learning new addresses. To restore the default configuration, use the no form of this command.

Syntax

```
port security [forward | discard | discard-shutdown] [trap seconds] [max]
```

no port security

Parameters

- forward — Forwards packets with unlearned source addresses, but does not learn the address.
- discard — Discards packets with unlearned source addresses. This is the default if no option is indicated.
- discard-shutdown — Discards packets with unlearned source addresses. The port is also shut down.
- seconds — Sends SNMP traps and defines the minimum amount of time in seconds between consecutive traps. (Range: 1-1000000)Default Configuration

This setting is disabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

In this example, port 1 forwards all packets without learning addresses of packets from unknown sources and sends traps every 100 seconds if a packet with an unknown source address is received.

```
Console(config)# interface ethernet ext.1
Console(config-if)# port security forward trap 100
```

port security mode

The port security mode Interface Configuration mode command configures the port security mode. To restore the default configuration, use the no form of this command.

Syntax

port security mode {lock | mac-addresses}

no port security mode

Parameters

- lock — Saves the current dynamic MAC addresses associated with the port and disables learning, relearning and aging.
- mac-addresses — Deletes the current dynamic MAC addresses associated with the port and learns up to the maximum number addresses allowed on the port. Relearning and aging are enabled.

Default Configuration

This setting is disabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

In this example, port security mode is set to dynamic for Ethernet interface 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# port security mode mac-addresses
```

port security routed secure-address

The port security routed secure-address Interface Configuration (Ethernet, port-channel) mode command adds a MAC-layer secure address to a routed port. Use the no form of this command to delete a MAC address.

Syntax

port security routed secure-address mac-address

no port security routed secure-address mac-address

Parameters

mac-address — A valid MAC address.

Default Configuration

No addresses are defined.

Command Mode

Interface Configuration (Ethernet, port-channel) mode. Cannot be configured for a range of interfaces (range context).

User Guidelines

The command enables adding secure MAC addresses to a routed port in port security mode. The command is available when the port is a routed port and in port security mode. The address is deleted if the port exits the security mode or is not a routed port.

Example

In this example, the MAC-layer address 66:66:66:66:66:66 is added to port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# port security routed secure-address 66:66:66:66:66:66
```

show bridge address-table

The show bridge address-table Privileged EXEC mode command displays all entries in the bridge-forwarding database.

Syntax

```
show bridge address-table [vlan vlan] [ethernet interface | port-channel port-channel-number | address mac address]
```

Parameters

- **vlan** — Specifies a valid VLAN, such as VLAN 1.
- **interface** — A valid Ethernet port.
- **port-channel-number** — A valid port-channel number.
- **mac address** — A valid MAC address.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

Internal usage VLANs (VLANs that are automatically allocated on ports with a defined Layer 3 interface) are presented in the VLAN column by a port number and not by a VLAN ID.

"Special" MAC addresses that were not statically defined or dynamically learned are displayed in the MAC address table. This includes, for example, MAC addresses defined in ACLS.

Example

In this example, all classes of entries in the bridge-forwarding database are displayed.

Console# show bridge address-table			
Aging time is 300 sec			
interface	mac address	Port	Type
-----	-----	----	-----
1	00:60:70:4C:73:FF	5	dynamic
1	00:60:70:8C:73:FF	5	dynamic
200	00:10:0D:48:37:FF	5	static

show bridge address-table static

The show bridge address-table static Privileged EXEC mode command displays statically created entries in the bridge-forwarding database.

Syntax

```
show bridge address-table static [vlan vlan] [ethernet interface | port-channel port-channel-number]
```

Parameters

- **vlan** — Specifies a valid VLAN, such as VLAN 1.
- **interface** — A valid Ethernet port.

- port-channel-number — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

In this example, all static entries in the bridge-forwarding database are displayed.

```
Console# show bridge address-table static

Aging time is 300 sec

vlan      mac address          port      type
----      -----
1         00:60:70:4C:73:FF    8         Permanent
1         00:60.70.8C.73:FF    8         delete-on-timeout
200       00:10:0D:48:37:FF    9         delete-on-reset
```

show bridge address-table count

The show bridge address-table count Privileged EXEC mode command displays the number of addresses present in the Forwarding Database.

Syntax

```
show bridge address-table count [vlan vlan] [ethernet interface-number | port-channel port-channel-number]
```

Parameters

- vlan — Specifies a valid VLAN, such as VLAN 1.

Address Table Commands

- interface — A valid Ethernet port.
- port-channel-number — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

In this example, the number of addresses present in all VLANs are displayed.

```
Console# show bridge address-table count

Capacity: 8192
Free: 8083
Used: 109

Secure addresses: 2
Static addresses: 1
Dynamic addresses: 97
Internal addresses: 9
```

show bridge multicast address-table

The show bridge multicast address-table Privileged EXEC mode command displays multicast MAC address or IP address table information.

Syntax

```
show bridge multicast address-table [vlan vlan-id] [address mac-multicast-address | ip-multicast-address] [format ip | format mac]
```

Parameters

- **vlan-id** — Indicates the VLAN ID. This has to be a valid VLAN ID value.
- **mac-multicast-address** — A valid MAC multicast address.
- **ip-multicast-address** — A valid IP multicast address.
- **format ip / mac** — Multicast address format. Can be ip or mac. If the format is unspecified, the default is mac.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

A MAC address can be displayed in IP format only if it is in the range of 0100.5e00.0000-0100.5e7f.ffff.

Example

In this example, multicast MAC address and IP address table information is displayed.

```
Console# show bridge multicast address-table

Vlan      MAC Address          Type      Ports
----      -----
1         01:00:5e:02:02:03    static    1, 2
19        01:00:5e:02:02:08    static    1-8
19        00:00:5e:02:02:08    dynamic   9-11

Forbidden ports for multicast addresses:

Vlan      MAC Address          Ports
----      -----
1         01:00:5e:02:02:03    8
19        01:00:5e:02:02:08    8
```

Address Table Commands

Console# show bridge multicast address-table format ip			
Vlan	IP/MAC Address	Type	Ports
1	224-239.130 2.2.3	static	1, 2
19	224-239.130 2.2.8	static	1-8
19	224-239.130 2.2.8	dynamic	9-11

Forbidden ports for multicast addresses:		
Vlan	IP/MAC Address	Ports
1	224-239.130 2.2.3	8
19	224-239.130 2.2.8	8

A multicast MAC address maps to multiple IP addresses as shown above.

show bridge multicast filtering

The show bridge multicast filtering Privileged EXEC mode command displays the multicast filtering configuration.

Syntax

show bridge multicast filtering vlan-id

Parameters

- **vlan-id** — Indicates the VLAN ID. This has to be a valid VLAN ID value.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

In this example, the multicast configuration for VLAN 1 is displayed.

```
Console# show bridge multicast filtering 1

Filtering: Enabled
VLAN: 1

Port      Static      Status
----      -----      -----
1          Filter
2          Filter
3          -          Filter
```

show ports security

The show ports security Privileged EXEC mode command displays the port-lock status.

Syntax

```
show ports security [ethernet interface | port-channel port-channel-number]
```

Parameters

- **interface** — A valid Ethernet port.
- **port-channel-number** — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

In this example, all classes of entries in the port-lock status are displayed:

Console# show ports security						
Port	Status	Learning	Action	Maximum	Trap	Frequency
---	-----	-----	-----	-----	-----	-----
1	Locked	Dynamic	Discard	3	Enable	100
2	Unlocked	Dynamic	-	28	-	-
3	Locked	Disabled	Discard, Shutdown	8	Disable	-

The following table describes the fields shown above.

Field	Description
Port	The port number.
Status	The values are: Locked/Unlocked.
Learning	The learning mode.
Action	Action on violation.
Maximum	The maximum number of addresses that can be associated on this port in the Static Learning mode or in the Dynamic Learning mode.
Trap	Sends traps in case of a violation.
Frequency	The minimum time interval between consecutive traps.

show ports security addresses

The show ports security addresses Privileged EXEC mode command displays the current dynamic addresses in locked ports.

Syntax

show ports security addresses [ethernet interface | port-channel port-channel-number]

Parameters

- interface — A valid Ethernet port.
- port-channel-number — A valid port-channel number

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

This example displays dynamic addresses in all currently locked ports.

Console# show ports security addresses				
Port	Status	Learning	Current	Maximum
---	-----	-----	-----	-----
1	Disabled	Lock	-	1
2	Disabled	Lock	-	1
3	Enabled	Max-addresses	0	1
4	Port is a member in port-channel ch1			
5	Disabled	Lock	-	1
6	Enabled	Max-addresses	0	10
ch1	Enabled	Max-addresses	0	50
ch2	Enabled	Max-addresses	0	128

Address Table Commands

4 ACL Commands

ip access-list

The **ip access-list** Global Configuration mode command enables the IP-Access Configuration mode and creates Layer 3 ACLs. To delete an ACL, use the **no** form of this command.

Syntax

```
ip access-list name
no ip access-list name
```

Parameters

- *name* — Specifies the name of the ACL. (Range: 0-32 characters)

Default Configuration

The default for all ACLs is deny-all.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example shows how to create an IP ACL.

```
Console(config)# ip access-list ip-acl1
Console(config-ip-al) #
```

permit (ip)

The **permit** IP-Access List Configuration mode command permits traffic if the conditions defined in the permit statement match.

Syntax

```
permit {any | protocol} {any | {source source-wildcard}} {any | {destination destination-wildcard}} [{dscp dscp number | ip-precedence ip-precedence}]
permit-icmp {any | {source source-wildcard}} {any | {destination destination-wildcard}} {any | icmp-type} {any | icmp-code} [{dscp number | ip-precedence number}]
permit-igmp {any | {source source-wildcard}} {any | {destination destination-wildcard}} {any | igmp-type} [{dscp number | ip-precedence number}]
permit-tcp {any | {source source-wildcard}} {any | source-port} {any | {destination destination-wildcard}} {any | destination-port} [{dscp number | ip-precedence number} [flags list-of-flags]]
permit-udp {any | {source source-wildcard}} {any | source-port} {any | {destination destination-wildcard}} {any | destination-port} [{dscp number | ip-precedence number}]
```

Parameters

- *source* — Specifies the source IP address of the packet. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- *source-wildcard* — Specifies wildcard to be applied to the source IP address. Use 1s in bit positions to be ignored. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- *destination* — Specifies the destination IP address of the packet. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- *destination-wildcard* — Specifies wildcard to be applied to the destination IP address. Use 1s in bit positions to be ignored. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- *protocol* — Specifies the abbreviated name or number of an IP protocol. (Range: 0-255)

The following table lists the protocols that can be specified:

IP Protocol	Abbreviated Name	Protocol Number
Internet Control Message Protocol	icmp	1
Internet Group Management Protocol	igmp	2
IP in IP (encapsulation) Protocol	ipinip	4
Transmission Control Protocol	tcp	6
Exterior Gateway Protocol	egp	8

IP Protocol	Abbreviated Name	Protocol Number
Interior Gateway Protocol	igp	9
User Datagram Protocol	udp	17
Host Monitoring Protocol	hmp	20
Reliable Data Protocol	rdp	27
Inter-Domain Policy Routing Protocol	idpr	35
Ipv6 protocol	ipv6	41
Routing Header for IPv6	ipv6-route	43
Fragment Header for IPv6	ipv6-frag	44
Inter-Domain Routing Protocol	idrp	45
Reservation Protocol	rsvp	46
General Routing Encapsulation	gre	47
Encapsulating Security Payload (50)	esp	50
Authentication Header	ah	51
ICMP for IPv6	ipv6-icmp	58
EIGRP routing protocol	eigrp	88
Open Shortest Path Protocol	ospf	89
Protocol Independent Multicast	pim	103
Layer Two Tunneling Protocol	l2tp	115
ISIS over IPv4	isis	124
(any IP protocol)	any	(25504)

- **dscp** — Indicates matching the dscp number with the packet dscp value.
- **ip-precedence** — Indicates matching ip-precedence with the packet ip-precedence value.
- **icmp-type** — Specifies an ICMP message type for filtering ICMP packets. Enter a value or one of the following values: **echo-reply**, **destination-unreachable**, **source-quench**, **redirect**, **alternate-host-address**, **echo-request**, **router-advertisement**, **router-solicitation**, **time-exceeded**, **parameter-problem**, **timestamp**, **timestamp-reply**, **information-request**, **information-reply**, **address-mask-request**, **address-mask-reply**, **traceroute**, **datagram-conversion-error**, **mobile-host-redirect**, **ipv6-where-are-you**, **ipv6-i-am-here**, **mobile-registration-request**, **mobile-registration-reply**, **domain-name-request**, **domain-name-reply**, **skip** and **photuris**. (Range: 0-255)
- **icmp-code** — Specifies an ICMP message code for filtering ICMP packets. ICMP packets that are filtered by ICMP message type can also be filtered by the ICMP message code. (Range: 0-255)
- **igmp-type** — IGMP packets can be filtered by IGMP message type. Enter a number or one of the following values: **dvmrp**, **host-query**, **host-report**, **pim** or **trace**. (Range: 0-255)
- **destination-port** — Specifies the UDP/TCP destination port. (Range: 0-65535)
- **source-port** — Specifies the UDP/TCP source port. (Range: 0-65535)

- *list-of-flags* — Specifies a list of TCP flags that can be triggered. If a flag is set, it is prefixed by “+”.
If a flag is not set, it is prefixed by “-”. The possible values are: **+urg**, **+ack**, **+psh**, **+rst**, **+syn**, **+fin**, **-urg**, **-ack**, **-psh**, **-rst**, **-syn** and **-fin**. The flags are concatenated into one string. For example: **+fin-ack**.

Default Configuration

No IPv4 ACL is defined.

Command Mode

IP-Access List Configuration mode

User Guidelines

Use the **ip access-list** Global Configuration mode command to enable the IP-Access List Configuration mode.

Before an Access Control Element (ACE) is added to an ACL, all packets are permitted. After an ACE is added, an implied **deny-any-any** condition exists at the end of the list and those packets that do not match the conditions defined in the permit statement are denied.

Example

The following example shows how to define a permit statement for an IP ACL.

```
Console(config)# ip access-list ip-acl1
Console(config-ip-acl)# permit rsvp 192.1.1.1 0.0.0.0 any dscp 56
```

deny (IP)

The **deny** IP-Access List Configuration mode command denies traffic if the conditions defined in the deny statement match.

Syntax

```
deny [disable-port] {any | protocol} {any | {source source-wildcard}} {any |
{destination destination-wildcard}} [{dscp dscp number | ip-precedence ip-precedence}]
[in-port port-num | out-port port-num]
```

deny-icmp

deny-igmp

deny-tcp

deny-udp

Parameters

- **disable-port** — Specifies that the port is disabled.
- **source** — Specifies the IP address or host name from which the packet was sent. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- **source-wildcard** — (Optional for the first type) Specifies wildcard bits by placing 1s in bit positions to be ignored. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- **destination** — Specifies the IP address or host name to which the packet is being sent. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- **destination-wildcard** — (Optional for the first type) Specifies wildcard bits by placing 1s in bit positions to be ignored. Specify **any** to indicate IP address 0.0.0.0 and mask 255.255.255.255.
- **protocol** — Specifies the abbreviated name or number of an IP protocol. The following table lists protocols that can be specified:

IP Protocol	Abbreviated Name	Protocol Number
Internet Control Message Protocol	icmp	1
Internet Group Management Protocol	igmp	2
IP in IP (encapsulation) Protocol	ip	4
Transmission Control Protocol	tcp	6
Exterior Gateway Protocol	egp	8
Interior Gateway Protocol	igp	9
User Datagram Protocol	udp	17
Host Monitoring Protocol	hmp	20
Reliable Data Protocol	rdp	27
Inter-Domain Policy Routing Protocol	idpr	35
Ipv6 protocol	ipv6	41
Routing Header for IPv6	ipv6-route	43
Fragment Header for IPv6	ipv6-frag	44
Inter-Domain Routing Protocol	idrp	45
Reservation Protocol	rsvp	46
General Routing Encapsulation	gre	47
Encapsulating Security Payload (50)	esp	50
Authentication Header	ah	51
ICMP for IPv6	ipv6-icmp	58
EIGRP routing protocol	eigrp	88
Open Shortest Path Protocol	ospf	89

IP Protocol	Abbreviated Name	Protocol Number
IP-within-IP Encapsulation Protocol	ipip	94
Protocol Independent Multicast	pim	103
Layer Two Tunneling Protocol	l2tp	115
ISIS over IPv4	isis	124
(any IP protocol)	any	(25504)

- **in-port port-num** — (Optional) Specifies the input port of the device. In case of egress classification this port will be device input port.
- **out-port port-num** — (Optional) Specifies the output port of the device.
- **dscp** — Indicates matching the dscp number with the packet dscp value.
- **ip-precedence** — Indicates matching ip-precedence with the packet ip-precedence value.

Default Configuration

This command has no default configuration

Command Mode

IP-Access List Configuration mode

User Guidelines

Use the **ip access-list** Global Configuration mode command to enable the IP-Access List Configuration mode.

Before an Access Control Element (ACE) is added to an ACL, all packets are permitted. After an ACE is added, an implied **deny-any-any** condition exists at the end of the list and those packets that do not match the defined conditions are denied.

Example

The following example shows how to define a permit statement for an IP ACL.

```
Console(config)# ip access-list ip-ac11
Console(config-ip-ac11)# deny rsvp 192.1.1.1 0.0.0.255 any
```

mac access-list

The **mac access-list** Global Configuration mode command enables the MAC-Access List Configuration mode and creates Layer 2 ACLs. To delete an ACL, use the **no** form of this command.

Syntax

```
mac access-list name  

no mac access-list name
```

Parameters

- *name* — Specifies the name of the ACL. (Range: 0-32 characters)

Default Configuration

The default for all ACLs is deny all.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example shows how to create a MAC ACL.

```
Console(config)# mac access-list macl-acl1  

Console(config-mac-acl) #
```

permit (MAC)

The **permit** MAC-Access List Configuration mode command defines permit conditions of an MAC ACL.

Syntax

```
permit {any | {host source source-wildcard} any | {destination destination-destination-wildcard} }  

[vlan vlan-id] [cos cos cos-wildcard] [ethtype eth-type]
```

Parameters

- *source* — Specifies the source MAC address of the packet.
- *source-wildcard* — Specifies wildcard bits to be applied to the source MAC address. Use 1s in bit positions to be ignored.

- *destination* — Specifies the MAC address of the host to which the packet is being sent.
- *destination-wildcard* — Specifies wildcard bits to be applied to the destination MAC address. Use 1s in bit positions to be ignored.
- *vlan-id* — Specifies the ID of the packet vlan. (Range: 0-4095)
- *cos* — Specifies the Class of Service (CoS) for the packet. (Range: 0-7)
- *cos-wildcard* — Specifies wildcard bits to be applied to the CoS.
- *eth-type* — Specifies the Ethernet type of the packet .(Range: 0-65535)

Default Configuration

No MAC ACL is defined.

Command Mode

MAC-Access List Configuration mode

User Guidelines

Before an Access Control Element (ACE) is added to an ACL, all packets are permitted. After an ACE is added, an implied **deny-any-any** condition exists at the end of the list and those packets that do not match the conditions defined in the permit statement are denied.

If the VLAN ID is specified, the policy map cannot be connected to the VLAN interface.

Example

The following example shows how to create a MAC ACL with permit rules.

```
Console(config)# mac access-list macl-acl1
Console(config-mac-al)# permit 6:6:6:6:6:6 0:0:0:0:0:0 any vlan 6
```

deny (MAC)

The **deny** MAC-Access List Configuration mode command denies traffic if the conditions defined in the deny statement match.

Syntax

```
deny [disable-port] {any | {source source-wildcard} {any | {destination destination-wildcard}}}[vlan vlan-id] [cos cos cos-wildcard] [ethtype eth-type]
```

Parameters

- **disable-port** — Indicates that the port is disabled if the statement is deny.
- *source* — Specifies the MAC address of the host from which the packet was sent.
- *source-wildcard* — (Optional for the first type) Specifies wildcard bits by placing 1s in bit positions to be ignored.
- *destination* — Specifies the MAC address of the host to which the packet is being sent.
- *destination-wildcard* — (Optional for the first type) Specifies wildcard bits by placing 1s in bit positions to be ignored.
- *vlan-id* — Specifies the ID of the packet vlan.
- *cos* — Specifies the packets's Class of Service (CoS).
- *cos-wildcard* — Specifies wildcard bits to be applied to the CoS.
- *eth-type* — Specifies the packet's Ethernet type.

Default Configuration

This command has no default configuration.

Command Mode

MAC-Access List Configuration mode

User Guidelines

MAC BPDU packets cannot be denied.

This command defines an Access Control Element (ACE). An ACE can only be removed by deleting the ACL, using the **no mac access-list** Global Configuration mode command. Alternatively, the Web-based interface can be used to delete ACEs from an ACL.

Before an Access Control Element (ACE) is added to an ACL, all packets are permitted. After an ACE is added, an implied **deny-any-any** condition exists at the end of the list and those packets that do not match the conditions defined in the permit statement are denied.

If the VLAN ID is specified, the policy map cannot be connected to the VLAN interface.

Example

The following example shows how to create a MAC ACL with deny rules on a device.

```
Console(config)# mac access-list macl1
Console (config-mac-acl)# deny 6:6:6:6:6:0:0:0:0:0:0 any
```

service-acl

The **service-acl** Interface Configuration mode command applies an ACL to the input interface. To detach an ACL from an input interface, use the no form of this command.

Syntax

```
service-acl {input acl-name}  
no service-acl {input}
```

Parameters

- *acl-name*—Specifies the ACL to be applied to the input interface.

Default Configuration

This command has no default configuration.

Command Mode

Interface (Ethernet, port-channel) Configuration mode.

User Guidelines

In advanced mode, when an ACL is bound to an interface, the port trust mode is set to trust 12-13 and not to 12.

Example

The following example binds (services) an ACL to VLAN 2.

```
Console(config)# interface vlan 2  
Console(config-if)# service-acl input mac11
```

show access-lists

The **show access-lists** Privileged EXEC mode command displays access control lists (ACLs) defined on the device.

Syntax

```
show access-lists [name]
```

Parameters

- *name* — The name of the ACL.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays access lists defined on a device.

```
Console# show access-lists
IP access list ACL1
permit ip host 172.30.40.1 any
permit rsvp host 172.30.8.8 any
```

show interfaces access-lists

The **show interfaces access-lists** Privileged EXEC mode command displays access lists applied on interfaces.

Syntax

show interfaces access-lists [ethernet *interface* | port-channel *port-channel-number*]

Parameters

- *interface* — Valid Ethernet port. (Full syntax: unit/port)
- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays ACLs applied to the interfaces of a device:

```
Console# show interfaces access-lists

Interface          Input ACL
-----
1                  ACL1
1                  ACL3
```

5 Clock Commands

clock set

The **clock set** Privileged EXEC mode command manually sets the system clock.

Syntax

clock set *hh:mm:ss day month year*

or

clock set *hh:mm:ss month day year*

Parameters

- *hh:mm:ss* — Current time in hours (military format), minutes, and seconds. (hh: 0-23, mm: 0-59, ss: 0-59)
- *day* — Current day (by date) in the month. (Range: 1-31)
- *month* — Current month using the first three letters by name. (Range: Jan, ..., Dec)
- *year* — Current year. (Range: 2000-2097)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets the system time to 13:32:00 on March 7th, 2005.

```
Console# clock set 13:32:00 7 Mar 2005
```

clock source

The **clock source** Global Configuration mode command configures an external time source for the system clock. Use **no** form of this command to disable external time source.

Syntax

```
clock source {sntp}
```

```
no clock source
```

Parameters

- **sntp** — SNTP servers

Default Configuration

No external clock source

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures an external time source for the system clock.

```
Console(config)# clock source sntp
```

clock timezone

The **clock timezone** Global Configuration mode command sets the time zone for display purposes. To set the time to the Coordinated Universal Time (UTC), use the **no** form of this command.

Syntax

```
clock timezone hours-offset [minutes minutes-offset] [zone acronym]
```

no clock timezone**Parameters**

- *hours-offset* — Hours difference from UTC. (Range: -12 hours to +13 hours)
- *minutes-offset* — Minutes difference from UTC. (Range: 0-59)
- *acronym* — The acronym of the time zone. (Range: Up to 4 characters)

Default Configuration

Clock set to UTC.

Command Mode

Global Configuration mode

User Guidelines

The system internally keeps time in UTC, so this command is used only for display purposes and when the time is manually set.

Example

The following example sets the timezone to 6 hours difference from UTC.

```
Console(config)# clock timezone -6 zone CST
```

clock summer-time

The **clock summer-time** Global Configuration mode command configures the system to automatically switch to summer time (daylight saving time). To configure the software not to automatically switch to summer time, use the **no** form of this command.

Syntax

clock summer-time recurring {usa | eu | {week day month hh:mm week day month hh:mm}} [offset offset] [zone acronym]

clock summer-time date date month year hh:mm date month year hh:mm [offset offset] [zone acronym]

clock summer-time date month date year hh:mm month date year hh:mm [offset offset] [zone acronym]

no clock summer-time recurring

Parameters

- **recurring** — Indicates that summer time should start and end on the corresponding specified days every year.
- **date** — Indicates that summer time should start on the first specific date listed in the command and end on the second specific date in the command.
- **usa** — The summer time rules are the United States rules.
- **eu** — The summer time rules are the European Union rules.
- **week** — Week of the month. (Range: 1-5, **first**, **last**)
- **day** — Day of the week (Range: first three letters by name, like **sun**)
- **date** — Date of the month. (Range:1-31)
- **month** — Month. (Range: first three letters by name, like Jan)
- **year** — year - no abbreviation (Range: 2000-2097)
- **hh:mm** — Time in military format, in hours and minutes. (Range: hh: 0-23, mm:0-59)
- **offset** — Number of minutes to add during summer time. (Range: 1-1440)
- **acronym** — The acronym of the time zone to be displayed when summer time is in effect. (Range: Up to 4 characters)

Default Configuration

Summer time is disabled.

offset — Default is 60 minutes.

acronym — If unspecified default to the timezone acronym.

If the timezone has not been defined, the default is UTC.

Command Mode

Global Configuration mode

User Guidelines

In both the **date** and **recurring** forms of the command, the first part of the command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is chronologically after the ending month, the system assumes that you are in the southern hemisphere.

USA rule for daylight savings time:

Start: First Sunday in April
 End: Last Sunday in October
 Time: 2 am local time
 EU rule for daylight savings time:
 Start: Last Sunday in March
 End: Last Sunday in October
 Time: 1.00 am (01:00)

Example

The following example sets summer time starting on the first Sunday in April at 2 am and finishing on the last Sunday in October at 2 am.

```
Console(config)# clock summer-time recurring first sun apr 2:00 last sun oct
2:00
```

sntp authentication-key

The **sntp authentication-key** Global Configuration mode command defines an authentication key for Simple Network Time Protocol (SNTP). To remove the authentication key for SNTP, use the **no** form of this command.

Syntax

```
sntp authentication-key number md5 value
no sntp authentication-key number
```

Parameters

- *number* — Key number (Range: 1-4294967295)
- *value* — Key value (Range: 1-8 characters)

Default Configuration

No authentication key is defined.

Command Mode

Global Configuration mode

User Guidelines

Multiple keys can be generated.

Example

The following example defines the authentication key for SNTP.

```
Console(config) # sntp authentication-key 8 md5 ClkKey
```

sntp authenticate

The **sntp authenticate** Global Configuration mode command grants authentication for received Simple Network Time Protocol (SNTP) traffic from servers. To disable the feature, use the **no** form of this command.

Syntax

```
sntp authenticate
```

```
no sntp authenticate
```

Default Configuration

No authentication

Command Mode

Global Configuration mode

User Guidelines

The command is relevant for both unicast and broadcast.

Example

The following example defines the authentication key for SNTP and grants authentication.

```
Console(config) # sntp authentication-key 8 md5 ClkKey
Console(config) # sntp trusted-key 8
```

sntp trusted-key

The **sntp trusted-key** Global Configuration mode command authenticates the identity of a system to which Simple Network Time Protocol (SNTP) will synchronize. To disable authentication of the identity of the system, use the **no** form of this command.

Syntax

```
sntp trusted-key key-number
no sntp trusted-key key-number
```

Parameters

- *key-number* — Key number of authentication key to be trusted. (Range: 1-4294967295)

Default Configuration

No keys are trusted.

Command Mode

Global Configuration mode

User Guidelines

The command is relevant for both received unicast and broadcast.

If there is at least 1 trusted key, then unauthenticated messages will be ignored.

Example

The following example authenticates key 8.

```
Console(config)# sntp authentication-key 8 md5 ClkKey
Console(config)# sntp trusted-key 8
```

sntp client poll timer

The **sntp client poll timer** Global Configuration mode command sets the polling time for the Simple Network Time Protocol (SNTP) client. To restoreTo restoreTo restore default configuration, use the **no** form of this command.

Syntax

sntp client poll timer *seconds*

no sntp client poll timer

Paramethers

- *seconds* — Polling interval in seconds. (Range: 60-86400)

Default Configuration

Polling interval is 1024 seconds.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets the polling time for the SNTP client to 120 seconds.

```
Console(config) # sntp client poll timer 120
```

sntp broadcast client enable

The **sntp broadcast client enable** Global Configuration mode command enables Simple Network Time Protocol (SNTP) broadcast clients. To disable SNTP broadcast clients, use the **no** form of this command.

Syntax

sntp broadcast client enable

no sntp broadcast client enable

Default Configuration

The SNTP broadcast client is disabled.

Command Mode

Global Configuration mode

User Guidelines

Use the **sntp client enable (Interface)** Interface Configuration mode command to enable the SNTP client on a specific interface.

Example

The following example enables the SNTP broadcast clients.

```
Console(config)# sntp broadcast client enable
```

sntp anycast client enable

The **sntp anycast client enable** Global Configuration mode command enables SNTP anycast client. To disable the SNTP anycast client, use the **no** form of this command.

Syntax

```
sntp anycast client enable  
no sntp anycast client enable
```

Default Configuration

The SNTP anycast client is disabled.

Command Mode

Global Configuration mode

User Guidelines

Polling time is determined by the **sntp client poll timer** Global Configuration mode command.

Use the **sntp client enable (Interface)** Interface Configuration mode command to enable the SNTP client on a specific interface.

Example

The following example enables SNTP anycast clients.

```
console(config) # sntp anycast client enable
```

sntp client enable (Interface)

The **sntp client enable** Interface Configuration (Ethernet, port-channel, VLAN) mode command enables the Simple Network Time Protocol (SNTP) client on an interface. This applies to both receive broadcast and anycast updates. To disable the SNTP client, use the **no** form of this command.

Syntax

```
sntp client enable
```

```
no sntp client enable
```

Default Configuration

The SNTP client is disabled on an interface.

Command Mode

Interface Configuration (Ethernet, port-channel, VLAN) mode

User Guidelines

Use the **sntp broadcast client enable** Global Configuration mode command to enable broadcast clients globally.

Use the **sntp anycast client enable** Global Configuration mode command to enable anycast clients globally.

Example

The following example enables the SNTP client on Ethernet port 3.

```
Console(config) # interface ethernet ext.3
Console(config-if) # sntp client enable
```

sntp unicast client enable

The **sntp unicast client enable** Global Configuration mode command enables the device to use the Simple Network Time Protocol (SNTP) to request and accept SNTP traffic from servers. To disable requesting and accepting SNTP traffic from servers, use the **no** form of this command.

Syntax

```
sntp unicast client enable  
no sntp unicast client enable
```

Default Configuration

The SNTP unicast client is disabled.

Command Mode

Global Configuration mode

User Guidelines

Use the **sntp server** Global Configuration mode command to define SNTP servers.

Example

The following example enables the device to use the Simple Network Time Protocol (SNTP) to request and accept SNTP traffic from servers.

```
Console(config)# sntp unicast client enable
```

sntp unicast client poll

The **sntp unicast client poll** Global Configuration mode command enables polling for the Simple Network Time Protocol (SNTP) predefined unicast servers. To disable the polling for SNTP client, use the **no** form of this command.

Syntax

```
sntp unicast client poll  
no sntp unicast client poll
```

Default Configuration

Polling is disabled.

Command Mode

Global Configuration mode

User Guidelines

Polling time is determined by the **sntp client poll timer** Global Configuration mode command.

Example

The following example enables polling for SNTP predefined unicast clients.

```
Console(config)# sntp unicast client poll
```

sntp server

The **sntp server** Global Configuration mode command configures the device to use the Simple Network Time Protocol (SNTP) to request and accept SNTP traffic from a specified server. To remove a server from the list of SNTP servers, use the **no** form of this command.

Syntax

```
sntp server {ip-address | hostname}[poll] [key keyid]
```

```
no sntp server host
```

Parameters

- *ip-address* — IP address of the server.
- *hostname* — Hostname of the server. (Range: 1-158 characters)
- **poll** — Enable polling.
- *keyid* — Authentication key to use when sending packets to this peer. (Range:1-4294967295)

Default Configuration

No servers are defined.

Command Mode

Global Configuration mode

User Guidelines

Up to 8 SNTP servers can be defined.

Use the **sntp unicast client enable** Global Configuration mode command to enable predefined unicast clients globally.

To enable polling you should also use the **sntp unicast client poll** Global Configuration mode command for global enabling.

Polling time is determined by the **sntp client poll timer** Global Configuration mode command.

Example

The following example configures the device to accept SNTP traffic from the server on 192.1.1.1.

```
Console(config)# sntp server 192.1.1.1
```

show clock

The **show clock** Privileged EXEC mode command displays the time and date from the system clock.

Syntax

show clock [detail]

Parameters

- **detail** — Shows timezone and summertime configuration.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

The symbol that precedes the show clock display indicates the following:

Symbol	Description
*	Time is not authoritative.
(blank)	Time is authoritative.
.	Time is authoritative, but SNTP is not synchronized.

Example

The following example displays the time and date from the system clock.

```
Console# show clock
15:29:03 PDT(UTC-7) Jun 17 2005
Time source is SNTP

Console# show clock detail
15:29:03 PDT(UTC-7) Jun 17 2005
Time source is SNTP

Time zone:
Acronym is PST
Offset is UTC-8

Summertime:
Acronym is PDT
Recurring every year.
Begins at first Sunday of April at 2:00.
Ends at last Sunday of October at 2:00.
Offset is 60 minutes.
```

show sntp configuration

The **show sntp configuration** Privileged EXEC mode command shows the configuration of the Simple Network Time Protocol (SNTP).

Syntax

show sntp configuration

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the current SNTP configuration of the device.

```
Console# show sntp configuration

Polling interval: 1024 seconds

MD5 Authentication keys: 8, 9
Authentication is required for synchronization.
Trusted Keys: 8, 9

Unicast Clients Polling: Enabled

      Server          Polling          Encryption Key
      -----          -----
      176.1.1.8        Enabled           9
      176.1.8.179     Disabled          Disabled

Broadcast Clients: Enabled
Anycast Clients: Enabled
Broadcast Interfaces: 1, 3
```

show sntp status

The **show sntp status** Privileged EXEC mode command shows the status of the Simple Network Time Protocol (SNTP).

Syntax

show sntp status

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example shows the status of the SNTP.

```
Console# show sntp status

Clock is synchronized, stratum 4, reference is 176.1.1.8, unicast
Reference time is AFE2525E.70597B34 (00:10:22.438 PDT Jul 5 1993)

Unicast servers:

  Server      Status      Last response          Offset [mSec]   Delay [mSec]
  -----      -----      -----                  -----
  176.1.1.8    Up        19:58:22.289 PDT Feb 19 2005    7.33       117.79
  176.1.8.179  Unknown    12:17:17.987 PDT Feb 19 2005    8.98       189.19

Anycast server:

  Server      Interface  Status      Last response          Offset [mSec]   Delay [mSec]
  -----      -----      -----      -----                  -----
  176.1.11.8   VLAN 118  Up        9:53:21.789 PDT Feb 19 2005    7.19       119.89

Broadcast:

  Interface  IP Address      Last response
  -----      -----          -----
  13          0.0.0.0          00:00:00.0 Feb 19 2005
  vlan 1      16.1.1.200        15:15:16.0 LLBG Feb 19 2006
```

6 Configuration and Image File Commands

copy

The **copy** Privileged EXEC mode command copies files from a source to a destination.

Syntax

copy *source-url* *destination-url*

Parameters

- *source-url* — The source file location URL or reserved keyword of the source file to be copied.
(Range: 1-160 characters)
- *destination-url* — The destination file URL or reserved keyword of the destination file.
(Range: 1-160 characters)

The following table displays keywords and URL prefixes.

Keyword	Source or Destination
flash:	Source or destination URL for flash memory. It's the default in case a URL is specified without a prefix.
running-config	Represents the current running configuration file.
startup-config	Represents the startup configuration file.
image	If the source file, represents the active image file. If the destination file, represents the non-active image file.
boot	Boot file.
tftp://	Source or destination URL for a TFTP network server. The syntax for this alias is tftp://host/[directory]/filename . The host can be represented by its IP address or hostname.
xmodem:	Source for the file from a serial connection that uses the Xmodem protocol.
unit://member/ image	Image file on one of the units. To copy from the master to all units, specify * in the member field.
unit://member/ boot	Boot file on one of the units. To copy from the master to all units, specify * in the member field.
null:	Null destination for copies or files. A remote file can be copied to null to determine its size.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

The location of a file system dictates the format of the source or destination URL.

The entire copying process may take several minutes and differs from protocol to protocol and from network to network.

*.prv and *.sys files cannot be copied.

Understanding Invalid Combinations of Source and Destination

Some invalid combinations of source and destination exist. Specifically, you cannot copy if one of the following conditions exist:

The source file and destination file are the same file.

xmodem: is the destination file. The source file can be copied to **image**, **boot** and **null:** only.

tftp:// is the source file and destination file on the same copy.

The following table describes copy characters:

Character	Description
!	For network transfers, indicates that the copy process is taking place. Each exclamation point indicates successful transfer of ten packets (512 bytes each).
.	For network transfers, indicates that the copy process timed out. Generally, many periods in a row means that the copy process may fail.

Copying an Image File from a Server to Flash Memory

To copy an image file from a server to flash memory, use the **copy source-url image** command.

Copying a Boot File from a Server to Flash Memory

To copy a boot file from a server to flash memory, enter the **copy source-url boot** command.

Copying a Configuration File from a Server to the Running Configuration File

To load a configuration file from a network server to the running configuration file of the device, enter the **copy source-url running-config** command. The commands in the loaded configuration file are added to those in the running configuration file as if the commands were typed in the command-line interface (CLI). Thus, the resulting configuration file is a combination of the previous running configuration and the loaded configuration files with the loaded configuration file taking precedence.

Copying a Configuration File from a Server to the Startup Configuration

To copy a configuration file from a network server to the startup configuration file of the device, enter **copy source-url startup-config**. The startup configuration file is replaced by the copied configuration file.

Storing the Running or Startup Configuration on a Server

Use the **copy running-config destination-url** command to copy the current configuration file to a network server using TFTP. Use the **copy startup-config destination-url** command to copy the startup configuration file to a network server.

Saving the Running Configuration to the Startup Configuration

To copy the running configuration to the startup configuration file, enter the **copy running-config startup-config** command.

Example

The following example copies system image file1 from the TFTP server 172.16.101.101 to a non-active image file.

```
Console# copy tftp://172.16.101.101/file1 image

Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!! [OK]
Copy took 0:01:11 [hh:mm:ss]
```

delete

The **delete** Privileged EXEC mode command deletes a file from a flash memory device.

Syntax

delete url

Parameters

- *url* — The location URL or reserved keyword of the file to be deleted. (Range: 1-160 characters)

The following table displays keywords and URL prefixes:

Keyword	Source or Destination
flash:	Source or destination URL for flash memory. It's the default in case a URL is specified without a prefix.
startup-config	Represents the startup configuration file.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

*.sys, *.prv, image-1 and image-2 files cannot be deleted.

Example

The following example deletes the file called ‘test’ from the flash memory.

```
Console# delete flash:test  
Delete flash:test? [confirm]
```

boot system

The **boot system** Privileged EXEC mode command specifies the system image that the device loads at startup.

Syntax

```
boot system {image-1 | image-2}
```

Parameters

- **image-1** — Specifies image 1 as the system startup image.
- **image-2** — Specifies image 2 as the system startup image.

Default Configuration

If the unit number is unspecified, the default setting is the master unit number.

Command Mode

Privileged EXEC mode

User Guidelines

Use the **show bootvar** command to find out which image is the active image.

Example

The following example loads the system image 1 at device startup.

```
Console# boot system image-1
```

show running-config

The **show running-config** Privileged EXEC mode command displays the contents of the currently running configuration file.

Syntax

show running-config

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the contents of the running configuration file.

```
Console# show running-config

hostname device

interface ethernet ext.1
ip address 176.242.100.100 255.255.255.0
duplex full
speed 1000

interface ethernet ext.2
ip address 176.243.100.100 255.255.255.0
duplex full
speed 1000
```

show startup-config

The **show startup-config** Privileged EXEC mode command displays the contents of the startup configuration file.

Syntax

```
show startup-config
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the contents of the running configuration file.

```
Console# show startup-config

hostname device

interface ethernet ext.1
ip address 176.242.100.100 255.255.255.0
duplex full
speed 1000

interface ethernet ext.2
ip address 176.243.100.100 255.255.255.0
duplex full
speed 1000
```

show backup-config

The **show backup-config** Privileged EXEC mode command displays the contents of the backup configuration file.

Syntax

show backup-config

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the contents of the backup configuration file.

```
Console# show backup-config

software version 1.1

hostname device

interface ethernet ext.1
ip address 176.242.100.100 255.255.255.0
duplex full
speed 1000

interface ethernet ext.2
ip address 176.243.100.100 255.255.255.0
duplex full
speed 1000
```

show bootvar

The **show bootvar** Privileged EXEC mode command displays the active system image file that is loaded by the device at startup.

Syntax

```
show bootvar
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the active system image file that is loaded by the device at startup.

```
Console# show bootvar

Unit          Active Image      Selected for next boot
-----
1             image-1         image-1
```

Configuration and Image File Commands

7 Ethernet Configuration Commands

interface ethernet

The **interface ethernet** Global Configuration mode command enters the interface configuration mode to configure an Ethernet type interface.

Syntax

interface ethernet *interface*

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables configuring Ethernet port 8

```
Console(config)# interface ethernet ext.8
```

interface range ethernet

The **interface range ethernet** Global Configuration mode command configures multiple Ethernet type interfaces at the same time.

Syntax

```
interface range ethernet {port-list | all}
```

Parameters

- *port-list* — List of valid ports. Where more than one port is listed, separate the nonconsecutive ports with a comma and no spaces, use a hyphen to designate a range of ports and group a list separated by commas in brackets.
- **all** — All Ethernet ports.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Commands under the interface range context are executed independently on each active interface in the range. If the command returns an error on one of the active interfaces, it does not stop executing commands on other active interfaces.

Example

The following example shows how ports 10 to 12 and 1 to 14 are grouped to receive the same command.

```
Console(config)# interface range ethernet 10-12,1-14  
Console(config-if) #
```

shutdown

The **shutdown** Interface Configuration (Ethernet, port-channel) mode command disables an interface. To restart a disabled interface, use the **no** form of this command.

Syntax

```
shutdown  
no shutdown
```

Default Configuration

The interface is enabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example disables Ethernet port 5 operations.

```
Console(config)# interface ethernet ext.5
Console(config-if)# shutdown
```

The following example restarts the disabled Ethernet port.

```
Console(config)# interface ethernet ext.5
Console(config-if)# no shutdown
```

description

The **description** Interface Configuration (Ethernet, port-channel) mode command adds a description to an interface. To remove the description, use the **no** form of this command.

Syntax

description *string*

no description

Parameters

- *string* — Comment or a description of the port to enable the user to remember what is attached to the port. (Range: 1-64 characters)

Default Configuration

The interface does not have a description.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example adds a description to Ethernet port 5.

```
Console(config)# interface ethernet ext.5
Console(config-if)# description "RD SW#3"
```

speed

The **speed** Interface Configuration (Ethernet, port-channel) mode command configures the speed of a given Ethernet interface when not using auto-negotiation. To restore the default configuration, use the **no** form of this command.

Syntax

```
speed {10 | 100 | 1000| 10000}
```

```
no speed
```

Parameters

- **10** — Forces 10 Mbps operation.
- **100** — Forces 100 Mbps operation.
- **1000** — Forces 1000 Mbps operation.
- **10000** — Forces 10000 Mbps operation.

Default Configuration

Maximum port capability

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The **no speed** command in a port-channel context returns each port in the port-channel to its maximum capability.

Example

The following example configures the speed operation of Ethernet port 5 to 100 Mbps operation.

```
Console(config)# interface ethernet ext.5
Console(config-if)# speed 100
```

duplex

The **duplex** Interface Configuration (Ethernet) mode command configures the full/half duplex operation of a given Ethernet interface when not using auto-negotiation. To restore the default configuration, use the **no** form of this command.

Syntax

duplex {half | full}

no duplex

Parameters

- **half** — Forces half-duplex operation
- **full** — Forces full-duplex operation

Default Configuration

The interface is set to full duplex.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

When configuring a particular duplex mode on the port operating at 10/100 Mbps, disable the auto-negotiation on that port.

Half duplex mode can be set only for ports operating at 10 Mbps or 100 Mbps.

Example

The following example configures the duplex operation of Ethernet port 1 to full duplex operation.

```
Console(config)# interface ethernet ext.1
Console(config-if)# duplex full
```

negotiation

The **negotiation** Interface Configuration (Ethernet, port-channel) mode command enables auto-negotiation operation for the speed and duplex parameters of a given interface. To disable auto-negotiation, use the **no** form of this command.

Syntax

negotiation [*capability1 [capability2...capability5]*]

no negotiation

Parameters

- *capability* — Specifies the capabilities to advertise. (Possible values: 10h, 10f, 100h, 100f, 1000f)

Default Configuration

Auto-negotiation is enabled.

If unspecified, the default setting is to enable all capabilities of the port.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

If capabilities were specified when auto-negotiation was previously entered, not specifying capabilities when currently entering auto-negotiation overrides the previous configuration and enables all capabilities.

Example

The following example enables auto-negotiation on Ethernet port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# negotiation
```

flowcontrol

The **flowcontrol** Interface Configuration (Ethernet, port-channel) mode command configures flow control on a given interface. To disable flow control, use the **no** form of this command.

Syntax

```
flowcontrol {auto | on | off}
no flowcontrol
```

Parameters

- **auto** — Indicates auto-negotiation
- **on** — Enables flow control.
- **off** — Disables flow control.

Default Configuration

Flow control is off.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

Negotiation should be enabled for **flow control auto**.

Example

In the following example, flow control is enabled on port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# flowcontrol on
```

mdix

The **mdix** Interface Configuration (Ethernet) mode command enables cable crossover on a given interface. To disable cable crossover, use the **no** form of this command.

Syntax

```
mdix {on | auto}  
no mdix
```

Parameters

- **on** — Manual mdix is enabled.
- **auto** — Automatic mdi/mdix is enabled.

Default Configuration

The default setting is **on**.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

Auto: All possibilities to connect a PC with cross or normal cables are supported and are automatically detected.

On: It is possible to connect to a PC only with a normal cable and to connect to another device only with a cross cable.

No: It is possible to connect to a PC only with a cross cable and to connect to another device only with a normal cable.

Example

In the following example, automatic crossover is enabled on port 1.

```
Console(config)# interface ethernet ext.1  
Console(config-if)# mdix auto
```

back-pressure

The **back-pressure** Interface Configuration (Ethernet, port-channel) mode command enables back pressure on a given interface. To disable back pressure, use the **no** form of this command.

Syntax

back-pressure

no back-pressure

Default Configuration

Back pressure is enabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

In the following example back pressure is enabled on port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# back-pressure
```

port jumbo-frame

The **port jumbo-frame** Global Configuration mode command enables jumbo frames on the device. To disable jumbo frames, use the **no** form of this command.

Syntax

port jumbo-frame

no port jumbo-frame

Default Configuration

Jumbo frames are disabled on the device.

Command Mode

Global Configuration

User Guidelines

This command is relevant to Giga devices only.

This command takes effect only after resetting the device.

Example

In the following example, jumbo frames are enabled on the device.

```
Console(config)# port jumbo-frame
```

clear counters

The **clear counters** Privileged EXEC mode command clears statistics on an interface.

Syntax

```
clear counters [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

In the following example, the counters for interface 1 are cleared.

```
Console# clear counters ethernet ext.2
```

set interface active

The **set interface active** Privileged EXEC mode command reactivates an interface that was shutdown.

Syntax

```
set interface active {ethernet interface | port-channel port-channel-number}
```

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

This command is used to activate interfaces that were configured to be active, but were shutdown by the system for some reason (e.g., **port security**).

Example

The following example reactivates interface 1.

```
Console# set interface active ethernet ext.1
```

show interfaces advertise

The **show interfaces advertise** Privileged EXEC mode command displays auto-negotiation data.

Syntax

```
show interfaces advertise [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays auto-negotiation information.

Console# show interfaces advertise				
Port	Type	Neg	Operational	Link Advertisement
---	-----	-----	-----	-----
1	100M-Copper	Enabled	--	
2	100M-Copper	Enabled	--	
3	100M-Copper	Enabled	--	
4	100M-Copper	Enabled	--	
5	100M-Copper	Enabled	100f, 100h, 10f, 10h	
6	100M-Copper	Enabled	--	
7	100M-Copper	Enabled	--	

8	100M-Copper	Enabled	--
9	100M-Copper	Enabled	--
10	100M-Copper	Enabled	--
11	100M-Copper	Enabled	--
12	100M-Copper	Enabled	--

show interfaces configuration

The **show interfaces configuration** Privileged EXEC mode command displays the configuration for all configured interfaces.

Syntax

show interfaces configuration [ethernet *interface* | port-channel *port-channel-number*]

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the configuration of all configured interfaces:

Console# show interfaces configuration									
Port	Type	Duplex	Speed	Neg	Flow Ctrl	Admin State	Back Pressure	Mdix Mode	
----	-----	-----	-----	-----	----	-----	-----	-----	----

1	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
2	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
3	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
4	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
5	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
6	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
7	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
8	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
9	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
10	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto
11	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto

show interfaces status

The **show interfaces status** Privileged EXEC mode command displays the status of all configured interfaces.

Syntax

```
show interfaces status [ethernet interface | port-channel port-channel-number | ]
```

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the status of all configured interfaces.

Console# show interfaces status									
Port	Type	Duplex	Speed	Neg	Flow Ctrl	Link State	Back Pressure	Mdix Mode	
---	-----	-----	-----	-----	----	-----	-----	-----	----
1	100M-Copper	--	--	--	--	Down	--	--	--
2	100M-Copper	--	--	--	--	Down	--	--	--
3	100M-Copper	--	--	--	--	Down	--	--	--
4	100M-Copper	--	--	--	--	Down	--	--	--
5	100M-Copper	Full	100	Enabled	Off	Up	Disabled	Auto	
6	100M-Copper	--	--	--	--	Down	--	--	--
7	100M-Copper	--	--	--	--	Down	--	--	--
8	100M-Copper	--	--	--	--	Down	--	--	--
9	100M-Copper	--	--	--	--	Down	--	--	--
10	100M-Copper	--	--	--	--	Down	--	--	--
11	100M-Copper	--	--	--	--	Down	--	--	--
12	100M-Copper	--	--	--	--	Down	--	--	--

show interfaces description

The **show interfaces description** Privileged EXEC mode command displays the description for all configured interfaces.

Syntax

show interfaces description [ethernet *interface* | port-channel *port-channel-number*]

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays descriptions of configured interfaces.

```
Console# show interfaces description

Port          Description
-----
1             lab
2
3
4
5
6
ch1
ch2
```

show interfaces counters

The **show interfaces counters** Privileged EXEC mode command displays traffic seen by the physical interface.

Syntax

```
show interfaces counters [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)

- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays traffic seen by the physical interface.

Console# show interfaces counters				
Port	InOctets	InUcastPkts	InMcastPkts	InBcastPkts
---	-----	-----	-----	-----
1	183892	0	0	0
1	0	0	0	0
1	123899	0	0	0
Port	OutOctets	OutUcastPkts	OutMcastPkts	OutBcastPkts
---	-----	-----	-----	-----
1	9188	0	0	0
1	0	0	0	0
1	8789	0	0	0
Ch	InOctets	InUcastPkts	InMcastPkts	InBcastPkts
---	-----	-----	-----	-----
1	27889	0	0	0
Ch	OutOctets	OutUcastPkts	OutMcastPkts	OutBcastPkts
---	-----	-----	-----	-----
1	23739	0	0	0

Ethernet Configuration Commands

The following example displays counters for Ethernet port 1.

Console# show interfaces counters ethernet ext.1				
Port	InOctets	InUcastPkts	InMcastPkts	InBcastPkts
-----	-----	-----	-----	-----
1	183892	0	0	0
Port	OutOctets	OutUcastPkts	OutMcastPkts	OutBcastPkts
-----	-----	-----	-----	-----
1	9188	0	0	0
 FCS Errors: 0				
Single Collision Frames: 0				
Late Collisions: 0				
Excessive Collisions: 0				
Oversize Packets: 0				
Internal MAC Rx Errors: 0				
Received Pause Frames: 0				
Transmitted Pause Frames: 0				

The following table describes the fields shown in the display.

Field	Description
InOctets	Counted received octets.
InUcastPkts	Counted received unicast packets.
InMcastPkts	Counted received multicast packets.
InBcastPkts	Counted received broadcast packets.
OutOctets	Counted transmitted octets.
OutUcastPkts	Counted transmitted unicast packets.
OutMcastPkts	Counted transmitted multicast packets.
OutBcastPkts	Counted transmitted broadcast packets.
FCS Errors	Counted received frames that are an integral number of octets in length but do not pass the FCS check.
Single Collision Frames	Counted frames that are involved in a single collision, and are subsequently transmitted successfully.
Late Collisions	Number of times that a collision is detected later than one slotTime into the transmission of a packet.
Excessive Collisions	Number of excessive collisions received on the selected interface.
Oversize Packets	Counted frames received that exceed the maximum permitted frame size.

Field	Description
Internal MAC Rx Errors	Counted frames for which reception fails due to an internal MAC sublayer received error.
Received Pause Frames	Counted MAC Control frames received with an opcode indicating the PAUSE operation.
Transmitted Pause Frames	Counted MAC Control frames transmitted on this interface with an opcode indicating the PAUSE operation.

show ports jumbo-frame

The **show ports jumbo-frame** Privileged EXEC mode command displays the configuration of jumbo frames.

Syntax

show ports jumbo-frame

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

This command is relevant to Giga devices only.

Example

The following example displays the configuration of jumbo frames on the device.

```
Console# show port jumbo-frame
Jumbo frames are disabled
Jumbo frames will be enabled after reset
```

port storm-control include-multicast (GC)

The **port storm-control include-multicast** Interface Configuration mode command enables counting multicast packets in the **port storm-control broadcast rate** command. To disable counting multicast packets, use the **no** form of this command.

Syntax

```
port storm-control include-multicast  
no port storm-control include-multicast
```

Default Configuration

Multicast packets are not counted.

Command Modes

Interface Configuration (Ethernet) mode

User Guidelines

To control multicasts storms, use the **port storm-control broadcast enable** and **port storm-control broadcast rate** commands.

Example

The following example enables counting multicast packets.

```
Console# configure  
Console(config-if)# port storm-control include-multicast  
Console(config-if)# port storm-control iinclude-multicast unknown-unicast
```

port storm-control include-multicast (IC)

The **port storm-control include-multicast** Interface Configuration (Ethernet) mode command counts multicast packets in broadcast storm control. To disable counting multicast packets, use the **no** form of this command.

Syntax

```
port storm-control include-multicast [unknown-unicast]  
no port storm-control include-multicast
```

Parameters

- **unknown-unicast** — Specifies also counting unknown unicast packets.

Default Configuration

Multicast packets are not counted.

Command Modes

Interface Configuration (Ethernet) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables counting broadcast and multicast packets on Ethernet port 2.

```
Console(config)# interface ethernet ext.2
Console(config-if)# port storm-control include-mcast unknown-unicast
```

port storm-control broadcast enable

The **port storm-control broadcast enable** Interface Configuration (Ethernet) mode command enables broadcast storm control. To disable broadcast storm control, use the **no** form of this command.

Syntax

```
port storm-control broadcast enable
no port storm-control broadcast enable
```

Default Configuration

Broadcast storm control is disabled.

Command Modes

Interface Configuration (Ethernet) mode

User Guidelines

Use the **port storm-control broadcast rate** Interface Configuration (Ethernet) mode command, to set the maximum allowable broadcast rate.

Use the **port storm-control include-multicast** Global Configuration mode command to enable counting multicast packets in the storm control calculation.

Example

The following example enables broadcast storm control on port 1 of a device.

```
Console(config)# interface ethernet ext.1
Console(config-if)# port storm-control broadcast enable
```

port storm-control broadcast rate

The **port storm-control broadcast rate** Interface Configuration (Ethernet) mode command configures the maximum broadcast rate. To restore the default configuration, use the **no** form of this command.

Syntax

```
port storm-control broadcast rate rate
no port storm-control broadcast rate
```

Parameters

- *rate* — Maximum kilobits per second of broadcast and multicast traffic on a port. (Range of 3500-1000000)

Default Configuration

The default storm control broadcast rate is 3500 Kbits/Sec.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

Use the **port storm-control broadcast enable** Interface Configuration mode command to enable broadcast storm control.

Example

The following example configures a port storm-control broadcast rate 4000 on port 2.

```
(config)# interface ethernet ext.2
Console(config-if)# port storm-control broadcast rate 4000
```

show ports storm-control

The **show ports storm-control** Privileged EXEC mode command displays the storm control configuration.

Syntax

show ports storm-control [interface]

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the storm control configuration.

Console# show ports storm-control			
Port	State	Rate [Kbits/Sec]	Included
----	-----	-----	-----
1	Disabled	3500	Broadcast
2	Disabled	3500	Broadcast

Ethernet Configuration Commands

3	Disabled	3500	Broadcast
4	Disabled	3500	Broadcast
5	Disabled	3500	Broadcast
6	Disabled	3500	Broadcast

8 GVRP Commands

gvrp enable (Global)

GARP VLAN Registration Protocol (GVRP) is an industry-standard protocol designed to propagate VLAN information from device to device. With GVRP, a single device is manually configured with all desired VLANs for the network, and all other devices on the network learn these VLANs dynamically.

The **gvrp enable** Global Configuration mode command enables GVRP globally. To disable GVRP on the device, use the **no** form of this command.

Syntax

```
gvrp enable
```

```
no gvrp enable
```

Default Configuration

GVRP is globally disabled.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables GVRP globally on the device.

```
Console(config)# gvrp enable
```

gvrp enable (Interface)

The **gvrp enable** Interface Configuration (Ethernet, port-channel) mode command enables GVRP on an interface. To disable GVRP on an interface, use the **no** form of this command.

Syntax

```
gvrp enable  
no gvrp enable
```

Default Configuration

GVRP is disabled on all interfaces.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

An access port does not dynamically join a VLAN because it is always a member in only one VLAN.

Membership in an untagged VLAN is propagated in the same way as in a tagged VLAN. That is, the PVID is manually defined as the untagged VLAN VID.

Example

The following example enables GVRP on Ethernet port 6.

```
Console(config)# interface ethernet ext.6  
Console(config-if)# gvrp enable
```

garp timer

The **garp timer** Interface Configuration (Ethernet, Port channel) mode command adjusts the values of the join, leave and leaveall timers of GARP applications. To restore the default configuration, use the **no** form of this command.

Syntax

```
garp timer {join | leave | leaveall} timer_value  
no garp timer
```

Parameters

- **{join | leave | leaveall}** — Indicates the type of timer.

- *timer_value* — Timer values in milliseconds in multiples of 10. (Range: 10-2147483640)

Default Configuration

Following are the default timer values:

- Join timer — 200 milliseconds
- Leave timer — 600 milliseconds
- Leave-all timer — 10000 milliseconds

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The following relationship must be maintained between the timers:

Leave time must be greater than or equal to three times the join time.

Leave-all time must be greater than the leave time.

Set the same GARP timer values on all Layer 2-connected devices. If the GARP timers are set differently on Layer 2-connected devices, the GARP application will not operate successfully.

Example

The following example sets the leave timer for Ethernet port 6 to 900 milliseconds.

```
Console(config)# interface ethernet ext.6
Console(config-if)# garp timer leave 900
```

gvrp vlan-creation-forbid

The **gvrp vlan-creation-forbid** Interface Configuration (Ethernet, port-channel) mode command disables dynamic VLAN creation or modification. To enable dynamic VLAN creation or modification, use the **no** form of this command.

Syntax

```
gvrp vlan-creation-forbid
no gvrp vlan-creation-forbid
```

Default Configuration

Dynamic VLAN creation or modification is enabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

This command forbids dynamic VLAN creation from the interface. The creation or modification of dynamic VLAN registration entries as a result of the GVRP exchanges on an interface are restricted only to those VLANs for which static VLAN registration exists.

Example

The following example disables dynamic VLAN creation on Ethernet port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# gvrp vlan-creation-forbid
```

gvrp registration-forbid

The **gvrp registration-forbid** Interface Configuration (Ethernet, port-channel) mode command deregisters all dynamic VLANs on a port and prevents VLAN creation or registration on the port. To allow dynamic registration of VLANs on a port, use the **no** form of this command.

Syntax

```
gvrp registration-forbid
no gvrp registration-forbid
```

Default Configuration

Dynamic registration of VLANs on the port is allowed.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example forbids dynamic registration of VLANs on Ethernet port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# gvrp registration-forbid
```

clear gvrp statistics

The **clear gvrp statistics** Privileged EXEC mode command clears all GVRP statistical information.

Syntax

clear gvrp statistics [ethernet *interface* | port-channel *port-channel-number*]

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example clears all GVRP statistical information on Ethernet port 1.

```
Console# clear gvrp statistics ethernet ext.1
```

show gvrp configuration

The **show gvrp configuration** Privileged EXEC mode command displays GVRP configuration information, including timer values, whether GVRP and dynamic VLAN creation is enabled, and which ports are running GVRP.

Syntax

```
show gvrp configuration [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays GVRP configuration information.

Console# show gvrp configuration						
GVRP Feature is currently enabled on the device.						
Port(s)	Status	Registration	Dynamic VLAN Creation	Timers (milliseconds)		
				Join	Leave	Leave All
-----	-----	-----	-----	-----	-----	-----
1	Enabled	Normal	Enabled	200	600	10000
4	Enabled	Normal	Enabled	200	600	10000

show gvrp statistics

The **show gvrp statistics** Privileged EXEC mode command displays GVRP statistics.

Syntax

```
show gvrp statistics [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example shows GVRP statistical information.

```
Console# show gvrp statistics

GVRP Statistics:
Legend:
rJE : Join Empty Received          rJIn:   Join In Received
rEmp : Empty Received              rLIn:   Leave In Received
rLE : Leave Empty Received        rLA :   Leave All Received
sJE : Join Empty Sent              sJIn:   Join In Sent
sEmp : Empty Sent                  sLIn:   Leave In Sent
sLE : Leave Empty Sent            sLA :   Leave All Sent
Port  rJE  rJIn  rEmp  rLIn  rLE  rLA  sJE  sJIn  sEmp  sLIn  sLE  sLA
```

show gvrp error-statistics

The **show gvrp error-statistics** Privileged EXEC mode command displays GVRP error statistics.

Syntax

```
show gvrp error-statistics [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays GVRP statistical information.

```
Console# show gvrp error-statistics

GVRP Error Statistics:

Legend:
INVPROT : Invalid Protocol Id           INVALEN : Invalid Attribute Length
INVATYP : Invalid Attribute Type        INVEVENT: Invalid Event
INVAVAL : Invalid Attribute Value

Port INVPROT INVATYP INVAVAL INVALEN INVEVENT
```

9 IGMP Snooping Commands

ip igmp snooping (Global)

The **ip igmp snooping** Global Configuration mode command enables Internet Group Management Protocol (IGMP) snooping. To disable IGMP snooping, use the **no** form of this command.

Syntax

```
ip igmp snooping  
no ip igmp snooping
```

Default Configuration

IGMP snooping is disabled.

Command Mode

Global Configuration mode

User Guidelines

IGMP snooping can only be enabled on static VLANs. It must not be enabled on Private VLANs or their community VLANs.

Example

The following example enables IGMP snooping.

```
Console(config)# ip igmp snooping
```

ip igmp snooping (Interface)

The **ip igmp snooping** Interface Configuration (VLAN) mode command enables Internet Group Management Protocol (IGMP) snooping on a specific VLAN. To disable IGMP snooping on a VLAN interface, use the **no** form of this command.

Syntax

```
ip igmp snooping  
no ip igmp snooping
```

Default Configuration

IGMP snooping is disabled.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

IGMP snooping can only be enabled on static VLANs. It must not be enabled on Private VLANs or their community VLANs.

Example

The following example enables IGMP snooping on VLAN 2.

```
Console(config)# interface vlan 2  
Console(config-if)# ip igmp snooping
```

ip igmp snooping mrouter learn-pim-dvmrp

The **ip igmp snooping mrouter learn-pim-dvmrp** Interface Configuration (VLAN) mode command enables automatic learning of multicast device ports in the context of a specific VLAN. To remove automatic learning of multicast device ports, use the **no** form of this command.

Syntax

```
ip igmp snooping mrouter learn-pim-dvmrp  
no ip igmp snooping mrouter learn-pim-dvmrp
```

Default Configuration

Automatic learning of multicast device ports is enabled.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Multicast device ports can be configured statically using the **bridge multicast forward-all** Interface Configuration (VLAN) mode command.

Example

The following example enables automatic learning of multicast device ports on VLAN 2.

```
Console(config) # interface vlan 2
Console(config-if)# ip igmp snooping mrouter learn-pim-dvmrp
```

ip igmp snooping host-time-out

The **ip igmp snooping host-time-out** Interface Configuration (VLAN) mode command configures the host-time-out. If an IGMP report for a multicast group was not received for a host-time-out period from a specific port, this port is deleted from the member list of that multicast group. To restore the default configuration, use the **no** form of this command.

Syntax

ip igmp snooping host-time-out *time-out*

no ip igmp snooping host-time-out

Parameters

- *time-out* — Specifies the host timeout in seconds. (Range: 1-2147483647)

Default Configuration

The default host-time-out is 260 seconds.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

The timeout should be at least greater than 2*query_interval+max_response_time of the IGMP router.

Example

The following example configures the host timeout to 300 seconds.

```
Console(config)# interface vlan 2
Console(config-if)# ip igmp snooping host-time-out 300
```

ip igmp snooping mrouter-time-out

The **ip igmp snooping mrouter-time-out** Interface Configuration (VLAN) mode command configures the mrouter-time-out. The **ip igmp snooping mrouter-time-out** Interface Configuration (VLAN) mode command is used for setting the aging-out time after multicast device ports are automatically learned. To restore the default configuration, use the **no** form of this command.

Syntax

```
ip igmp snooping mrouter-time-out time-out
no ip igmp snooping mrouter-time-out
```

Parameters

- *time-out* — Specifies the Multicast device timeout in seconds (Range: 1-2147483647)

Default Configuration

The default value is 300 seconds.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the multicast device timeout to 200 seconds.

```
Console(config)# interface vlan 2
Console(config-if)# ip igmp snooping mrouter-time-out 200
```

ip igmp snooping leave-time-out

The **ip igmp snooping leave-time-out** Interface Configuration (VLAN) mode command configures the leave-time-out. If an IGMP report for a multicast group was not received for a leave-time-out period after an IGMP Leave was received from a specific port, this port is deleted from the member list of that multicast group. To restore the default configuration, use the **no** form of this command.

Syntax

```
ip igmp snooping leave-time-out {time-out | immediate-leave}
no ip igmp snooping leave-time-out
```

Parameters

- *time-out* — Specifies the leave-timeout in seconds for IGMP queries. (Range: 0-2147483647)
- **immediate-leave** — Indicates that the port should be immediately removed from the members list after receiving IGMP Leave.

Default Configuration

The default leave-time-out configuration is 10 seconds.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

The leave timeout should be set greater than the maximum time that a host is allowed to respond to an IGMP query.

Use **immediate leave** only where there is just one host connected to a port.

Example

The following example configures the host leave timeout to 60 seconds.

```
Console(config)# interface vlan 2
Console(config-if)# ip igmp snooping leave-time-out 60
```

show ip igmp snooping mrouter

The **show ip igmp snooping mrouter** Privileged EXEC mode command displays information on dynamically learned multicast device interfaces.

Syntax

```
show ip igmp snooping mrouter [interface vlan-id]
```

Parameters

- *vlan-id* — Specifies the VLAN number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays multicast device interfaces in VLAN 1000.

```
Console# show ip igmp snooping mrouter interface 10000
```

VLAN	Ports
1000	1

Detected multicast `devices` that are forbidden statically:

VLAN	Ports
-----	-----
1000	19

show ip igmp snooping interface

The **show ip igmp snooping interface** Privileged EXEC mode command displays IGMP snooping configuration.

Syntax

show ip igmp snooping interface *vlan-id*

Parameters

- *vlan-id* — Specifies the VLAN number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays IGMP snooping information on VLAN 1000.

```
Console# show ip igmp snooping interface 4

IGMP Snooping is globally disabled
IGMP Snooping is enabled on VLAN 4
IGMP host timeout is 260 sec
IGMP Immediate leave is disabled. IGMP leave timeout is 10 sec
IGMP mrouter timeout is 300 sec
Automatic learning of multicast router ports is enabled
```

show ip igmp snooping groups

The **show ip igmp snooping groups** Privileged EXEC mode command displays multicast groups learned by IGMP snooping.

Syntax

```
show ip igmp snooping groups [vlan vlan-id] [address ip-multicast-address]
```

Parameters

- *vlan-id* — Specifies the VLAN number.
- *ip-multicast-address* — Specifies the IP multicast address.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

To see the full multicast address table (including static addresses) use the **show bridge multicast address-table** Privileged EXEC command.

Example

The following example shows IGMP snooping information on multicast groups.

```
Console# show ip igmp snooping groups

Vlan          IP Address        Querier      Ports
---          -----
1            224-239.130|2.2.3    Yes         1, 2
19           224-239.130|2.2.8    Yes         9-11

IGMP Reporters that are forbidden statically:
-----
Vlan          IP Address        Ports
---          -----
1            224-239.130|2.2.3    19
```

IGMP Snooping Commands

10 IP Address Commands

ip address

ip address ip-address {mask | prefix-length}

The ip address Interface Configuration (Ethernet, VLAN, port-channel) mode command sets an IP address. To remove an IP address, use the no form of this command.

Syntax

ip address ip-address {mask | prefix-length}

no ip address [ip-address]

Parameters

- *ip-address* — Specifies the valid IP address
- *mask* — Specifies the valid network mask of the IP address.
- *prefix-length* — Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 8-30)

Default Configuration

No IP address is defined for interfaces.

Command Mode

Interface Configuration (Ethernet, VLAN, port-channel) mode

User Guidelines

An IP address cannot be configured for a range of interfaces (range context).

This command is only functional if the device is in Switch mode.

Example

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0

```
Console(config)# interface vlan 1
Console(config-if)# ip address 131.108.1.27 255.255.255.0
```

ip address dhcp

The **ip address dhcp** Interface Configuration (Ethernet, VLAN, port-channel) mode command acquires an IP address for an Ethernet interface from the Dynamic Host Configuration Protocol (DHCP) server. To deconfigure an acquired IP address, use the **no** form of this command.

Syntax

```
ip address dhcp [hostname host-name]
no ip address dhcp
```

Parameters

- *host-name* — Specifies the name of the host to be placed in the DHCP option 12 field. This name does not have to be the same as the host name specified in the **hostname** Global Configuration mode command. (Range: 1-20 characters)

Default Configuration

This command has no default configuration.

Command Mode

Interface Configuration (Ethernet, VLAN, port-channel) mode

User Guidelines

This command is only functional if the device is in Switch mode.

The **ip address dhcp** command allows any interface to dynamically learn its IP address by using the DHCP protocol.

Some DHCP servers require that the DHCPDISCOVER message have a specific host name. The **ip address dhcp hostname** host-name command is most typically used when the host name is provided by the system administrator.

If the device is configured to obtain its IP address from a DHCP server, it sends a DHCPDISCOVER message to provide information about itself to the DHCP server on the network.

If the **ip address dhcp** command is used with or without the optional keyword, the DHCP option 12 field (host name option) is included in the DISCOVER message. By default, the specified DHCP host name is the globally configured host name of the device. However, the **ip address dhcp hostname** host-name command can be used to place a different host name in the DHCP option 12 field.

The **no ip address dhcp** command deconfigures any IP address that was acquired, and sends a DHCPRELEASE message.

Example

The following example acquires an IP address for Ethernet port 16 from DHCP..

```
Console(config)# interface ethernet ext.16
Console(config-if)# ip address dhcp
```

ip default-gateway

The **ip default-gateway** Global Configuration mode command defines a default gateway (device). To restore the default configuration, use the no form of this command.

Syntax

```
ip default-gateway ip-address
no ip default-gateway
```

Parameters

- *ip-address* — Specifies the valid IP address of the currently defined default gateway.

Default Configuration

No default gateway is defined.

Command Mode

Global Configuration mode

User Guidelines

This command is only operational in Switch mode.

Example

The following example defines default gateway 192.168.1.

```
Console(config)# ip default-gateway 192.168.1.1
```

show ip interface

The **show ip interface** Privileged EXEC mode command displays the usability status of configured IP interfaces

Syntax

```
show ip interface [ethernet interface-number | vlan vlan-id | port-channel port-channel number ]
```

Parameters

- *interface-number* — Specifies the valid Ethernet port.
- *vlan-id* — Specifies the valid VLAN number.
- *port-channel number* — Specifies the valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the configured IP interfaces and their types

Console# show ip interface			
Proxy ARP is disabled			
IP address	I/F	Type	Direct Broadcast
10.7.1.192/24	1	Static	disable
10.7.2.192/24	2	Static	disable

arp

The **arp** Global Configuration mode command adds a permanent entry in the Address Resolution Protocol (ARP) cache. To remove an entry from the ARP cache, use the **no** form of this command.

Syntax

arp ip_addr hw_addr {ethernet interface-number | vlan vlan-id | port-channel port-channel number;}

no arp ip_addr {ethernet interface-number | vlan vlan-id | port-channel port-channel number;}

Parameters

- *ip_addr* — Valid IP address or IP alias to map to the specified MAC address.
- *hw_addr* — Valid MAC address to map to the specified IP address or IP alias.
- *interface-number* — Valid Ethernet port.
- *vlan-id* — Valid VLAN number.
- *port-channel number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

The software uses ARP cache entries to translate 32-bit IP addresses into 48-bit hardware addresses. Because most hosts support dynamic resolution, static ARP cache entries do not generally have to be specified.

Example

The following example adds IP address 198.133.219.232 and MAC address 00:00:0c:40:0f:bc to the ARP table.

```
Console(config)# arp 198.133.219.232 00:00:0c:40:0f:bc ethernet ext.6
```

arp timeout

The **arp timeout** Global Configuration mode command configures how long an entry remains in the ARP cache. To restore the default configuration, use the **no** form of this command.

Syntax

arp timeout *seconds*

no arp timeout

Parameters

- *seconds* — Time (in seconds) that an entry remains in the ARP cache. (Range: 1-40000000)

Default Configuration

The default timeout is 60000 seconds.

Command Mode

Global Configuration mode

User Guidelines

It is recommended not to set the timeout value to less than 3600.

Example

The following example configures the ARP timeout to 12000 seconds.

```
Console(config)# arp timeout 12000
```

clear arp-cache

The **clear arp-cache** Privileged EXEC mode command deletes all dynamic entries from the ARP cache.

Syntax

```
clear arp-cache
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example deletes all dynamic entries from the ARP cache.

```
Console# clear arp-cache
```

show arp

The **show arp** Privileged EXEC mode command displays entries in the ARP table.

Syntax

show arp

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays entries in the ARP table.

```
Console# show arp
ARP timeout: 80000 Seconds

Interface      IP address          HW address        Status
-----          -----
1              10.7.1.102          00:10:B5:04:DB:4B  Dynamic
2              10.7.1.135          00:50:22:00:2A:A4  Static
```

ip domain-lookup

The **ip domain-lookup** Global Configuration mode command enables the IP Domain Naming System (DNS)-based host name-to-address translation. To disable DNS-based host name-to-address translation, use the **no** form of this command.

Syntax

ip domain-lookup

no ip domain-lookup

Default Configuration

IP Domain Naming System (DNS)-based host name-to-address translation is enabled.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables IP Domain Naming System (DNS)-based host name-to-address translation.

```
Console(config)# ip domain-lookup
```

ip domain-name

The **ip domain-name** Global Configuration mode command defines a default domain name used by the software to complete unqualified host names (names without a dotted-decimal domain name). To remove the default domain name, use the **no** form of this command.

Syntax

ip domain-name *name*

no ip domain-name

Parameters

- *name* — Specifies the default domain name used to complete unqualified host names. Do not include the initial period that separates an unqualified name from the domain name. (Range: 1-158 characters)

Default Configuration

A default domain name is not defined.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example defines default domain name www.intel.com.

```
Console(config) # ip domain-name www.intel.com
```

ip name-server

The **ip name-server** Global Configuration mode command defines the available name servers. To remove a name server, use the **no** form of this command.

Syntax

```
ip name-server server-address [server-address2 ... server-address8]  
no ip name-server [server-address1 ... server-address8]
```

Parameters

server-address — Specifies IP addresses of the name server.

Default Configuration

No name server addresses are specified.

Command Mode

Global Configuration mode

User Guidelines

The preference of the servers is determined by the order in which they were entered.

Up to 8 servers can be defined using one command or using multiple commands.

Example

The following example sets the available name server..

```
Console(config) # ip name-server 176.16.1.18
```

ip host

The **ip host** Global Configuration mode command defines static host name-to-address mapping in the host cache. To remove the name-to-address mapping, use the **no** form of this command.

Syntax

ip host *name address*

no ip host *name*

Parameters

- *name* — Specifies the name of the host. (Range: 1-158 characters)
- *address* — Specifies the associated IP address.

Default Configuration

No host is defined.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example defines a static host name-to-address mapping in the host cache.

```
Console(config)# ip host accounting.intel.com 126.10.23.1
```

clear host

The **clear host** Privileged EXEC mode command deletes entries from the host name-to-address cache.

Syntax

clear host {*name* | *}

Parameters

- *name* — Specifies the host entry to be removed. (Range: 1-158 characters)
- * — Removes all entries.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example deletes all entries from the host name-to-address cache.

```
Console# clear host *
```

clear host dhcp

The **clear host dhcp** Privileged EXEC mode command deletes entries from the host name-to-address mapping received from Dynamic Host Configuration Protocol (DHCP).

Syntax

```
clear host dhcp {name | *}
```

Parameters

- *name* — Specifies the host entry to be removed. (Range: 1-158 characters)
- * — Removes all entries.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

This command is only operational in Switch mode.

This command deletes the host name-to-address mapping temporarily until the next renewal of the IP address.

Example

The following example deletes all entries from the host name-to-address mapping.

```
Console# clear host dhcp *
```

show hosts

The **show hosts** Privileged EXEC mode command displays the default domain name, a list of name server hosts, the static and the cached list of host names and addresses.

Syntax

```
show hosts [name]
```

Parameters

- *name* — Specifies the host name. (Range: 1-158 characters)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays host information..

```
Console# show hosts

System name: Device
Default domain is gm.com, sales.gm.com, usa.sales.gm.com(DHCP)
Name/address lookup is enabled
Name servers (Preference order): 176.16.1.18 176.16.1.19

Configured host name-to-address mapping:

Host                Addresses
-----
accounting.gm.com      176.16.8.8 176.16.8.9 (DHCP)

Cache:          TTL(Hours)
Host        Total    Elapsed   Type    Addresses
-----
www.stanford.edu     72        3       IP      171.64.14.203
```

11 LACP Commands

lacp system-priority

The **lacp system-priority** Global Configuration mode command configures the system priority. To return to the default configuration, use the **no** form of this command.

Syntax

```
lacp system-priority value
no lacp system-priority
```

Parameters

- *value* — Specifies system priority value. (Range: 1-65535)

Default Configuration

The default system priority is 1.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the system priority to 120.

```
Console(config)# lacp system-priority 120
```

lacp port-priority

The **lacp port-priority** Interface Configuration (Ethernet) mode command configures physical port priority. To return to the default configuration, use the **no** form of this command.

Syntax

lacp port-priority *value*

no lacp port-priority

Parameters

- *value* — Specifies port priority. (Range: 1-65535)

Default Configuration

The default port priority is 1.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example defines the priority of Ethernet port 6 as 247.

```
Console(config)# interface ethernet ext.6
Console(config-if)# lacp port-priority 247
```

lacp timeout

The **lacp timeout** Interface Configuration (Ethernet) mode command assigns an administrative LACP timeout. To return to the default configuration, use the **no** form of this command.

Syntax

lacp timeout {long | short}

no lacp timeout

Parameters

- **long** — Specifies the long timeout value.

- **short** — Specifies the short timeout value.

Default Configuration

The default port timeout value is **long**.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example assigns a long administrative LACP timeout to Ethernet port 6 .

```
Console(config)# interface ethernet ext.6
Console(config-if)# lacp timeout long
```

show lacp ethernet

The **show lacp ethernet** Privileged EXEC mode command displays LACP information for Ethernet ports.

Syntax

show lacp ethernet *interface* [**parameters** | **statistics** | **protocol-state**]

Parameters

- **interface** — Valid Ethernet port. (Full syntax: *unit/port*)
- **parameters** — Link aggregation parameter information.
- **statistics** — Link aggregation statistics information.
- **protocol-state** — Link aggregation protocol-state information.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example display LACP information for Ethernet port 1.

```
Console# show lacp ethernet ext.1

Port 1 LACP parameters:

Actor

    system priority:          1
    system mac addr:         00:00:12:34:56:78
    port Admin key:           30
    port Oper key:            30
    port Oper number:         21
    port Admin priority:      1
    port Oper priority:       1
    port Admin timeout:       LONG
    port Oper timeout:        LONG
    LACP Activity:            ACTIVE
    Aggregation:              AGGREGATABLE
    synchronization:           FALSE
    collecting:                FALSE
    distributing:               FALSE
    expired:                  FALSE

Partner

    system priority:          0
    system mac addr:         00:00:00:00:00:00
    port Admin key:           0
    port Oper key:            0
    port Oper number:         0
    port Admin priority:      0
    port Oper priority:       0
```

port Oper timeout:	LONG
LACP Activity:	PASSIVE
Aggregation:	AGGREGATABLE
synchronization:	FALSE
collecting:	FALSE
distributing:	FALSE
expired:	FALSE
 Port 1 LACP Statistics:	
LACP PDUs sent:	2
LACP PDUs received:	2
 Port 1 LACP Protocol State:	
LACP State Machines:	
Receive FSM:	Port Disabled State
Mux FSM:	Detached State
Periodic Tx FSM:	No Periodic State
Control Variables:	
BEGIN:	FALSE
LACP_Enabled:	TRUE
Ready_N:	FALSE
Selected:	UNSELECTED
Port_moved:	FALSE
NNT:	FALSE
Port_enabled:	FALSE
Timer counters:	
periodic tx timer:	0
current while timer:	0
wait while timer:	0

show lacp port-channel

The **show lacp port-channel** Privileged EXEC mode command displays LACP information for a port-channel.

Syntax

```
show lacp port-channel [port_channel_number]
```

Parameters

- *port_channel_number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays LACP information about port-channel 1.

```
Console# show lacp port-channel 1
Port-Channel 1: Port Type 1000 Ethernet
    Actor
        System Priority:      1
        MAC Address:          00:02:85:0E:1C:00
        Admin Key:            29
        Oper Key:             29

    Partner
        System Priority:      0
        MAC Address:          00:00:00:00:00:00
        Oper Key:              14
```

12 Line Commands

Line

The **Line** Global Configuration mode command identifies a specific line for configuration, and begins the process.

Syntax

```
Line {telnet | ssh}
```

Parameters

- *telnet* — Virtual terminal for remote console access.
- *ssh* — Virtual terminal for secured remote console access.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

This command has no user guidelines.

Example

```
Router (config)# line telnet
Router (config-line) #
```

show line

The **show line** command is used to display the parameters of a line.

Syntax

```
show line {telnet | ssh}
```

Parameters

- *telnet* — Virtual terminal for remote console access.
- *ssh* — Virtual terminal for secured remote console access.

Default Configuration

This command has no default configuration.

Command Mode

Exec mode

User Guidelines

This command has no user guidelines.

Example

The following example configures communication to a device with the IP address 192.168.1.4, in the WLAN domain as a passive.

```
Router> show line
Console configuration:
  Interactive timeout: Disabled
  History: 10
  Baudrate: 9600
  Databits: 8
  Parity: none
  Stopbits: 1

Telnet configuration:
  Interactive timeout: 10 minutes 10 seconds
  History: 10

SSH configuration:
  Interactive timeout: 10 minutes 10 seconds
  History: 10
```

Line Commands

13 Management ACL Commands

management access-list

The **management access-list** Global Configuration mode command configures a management access list and enters the Management Access-list Configuration command mode. To delete an access list, use the **no** form of this command.

Syntax

```
management access-list name
no management access-list name
```

Parameters

- **name** — Access list name. (Range: 1-32 characters)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Use this command to configure a management access list. The command enters the Access-list Configuration mode, where permit and deny access rules are defined using the **permit (Management)** and **deny (Management)** commands.

If no match criteria are defined, the default is deny.

If you reenter an access list context, the new rules are entered at the end of the access list.

Use the **management access-class** command to select the active access list.

The active management list cannot be updated or removed.

Management ACL requires a valid management interface, which is a port, VLAN, or port-channel with an IP address or console interface. Management ACL only restricts access to the device for management configuration or viewing.

Example

The following example creates a management access list called mlist, configures management Ethernet interfaces 1 and 9 and makes the new access list the active list.

```
Console(config)# management access-list mlist
Console(config-macl)# permit ethernet ext.1
Console(config-macl)# permit ethernet ext.9
Console(config-macl)# exit
Console(config)# management access-class mlist
```

The following example creates a management access list called mlist, configures all interfaces to be management interfaces except Ethernet interfaces 1 and 9 and makes the new access list the active list.

```
Console(config)# management access-list mlist
Console(config-macl)# deny ethernet ext.1
Console(config-macl)# deny ethernet ext.9
Console(config-macl)# permit
Console(config-macl)# exit
Console(config)# management access-class mlist
```

permit (Management)

The **permit** Management Access-List Configuration mode command defines a permit rule.

Syntax

```
permit [ethernet interface-number | vlan vlan-id | port-channel port-channel-number |] [service service]
```

```
permit ip-source ip-address [mask mask | prefix-length] [ethernet interface-number | vlan vlan-id | port-channel port-channel-number |] [service service]
```

Parameters

- *interface-number* — A valid Ethernet port number.
- *vlan-id* — A valid VLAN number.
- *port-channel-number* — A valid port channel index.
- *ip-address* — A valid source IP address.
- *mask* — A valid network mask of the source IP address.
- *prefix-length* — Number of bits that comprise the source IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 0-32)
- *service* — Service type. Possible values: **telnet**, **ssh**, **http**, **https** and **snmp**.

Default Configuration

If no permit rule is defined, the default is set to deny.

Command Mode

Management Access-list Configuration mode

User Guidelines

Rules with Ethernet, VLAN and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

The system supports up to 128 management access rules.

Example

The following example permits all ports in the mlist access list.

```
Console(config)# management access-list mlist
Console(config-macl)# permit
```

deny (Management)

The **deny** Management Access-List Configuration mode command defines a deny rule.

Syntax

```
deny [ethernet interface-number | vlan vlan-id | port-channel port-channel-number |]
[service service]

deny ip-source ip-address [mask mask | prefix-length] [ethernet interface-number | vlan
vlan-id | port-channel port-channel-number |] [service service]
```

Parameters

- *interface-number* — A valid Ethernet port number.
- *vlan-id* — A valid VLAN number.
- *port-channel-number* — A valid port-channel number.
- *ip-address* — A valid source IP address.
- *mask* — A valid network mask of the source IP address.
- **mask prefix-length** — Specifies the number of bits that comprise the source IP address prefix.
The prefix length must be preceded by a forward slash (/). (Range: 0-32)
- *service* — Service type. Possible values: **telnet**, **ssh**, **http**, **https** and **snmp**.

Default Configuration

This command has no default configuration.

Command Mode

Management Access-list Configuration mode

User Guidelines

Rules with Ethernet, VLAN and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

The system supports up to 128 management access rules.

Example

The following example denies all ports in the access list called mlist.

```
Console(config)# management access-list mlist
Console(config-macl)# deny
```

management access-class

The **management access-class** Global Configuration mode command restricts management connections by defining the active management access list. To disable this restriction, use the **no** form of this command.

Syntax

management access-class {name}

no management access-class

Parameters

- *name* — Specifies the name of the access list to be used. (Range: 1-32 characters)

Default Configuration

If no access list is specified, an empty access list is used.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures an access list called mlist as the management access list.

```
Console(config)# management access-class mlist
```

show management access-list

The **show management access-list** Privileged EXEC mode command displays management access-lists.

Syntax

show management access-list [name]

Parameters

- *name* — Specifies the name of a management access list. (Range: 1-32 characters)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the mlist management access list.

```
Console# show management access-list mlist
mlist
-----
    permit ethernet ext.1
    permit ethernet ext.2
! (Note: all other access implicitly denied)
```

show management access-class

The **show management access-class** Privileged EXEC mode command displays the active management access list.

Syntax

show management access-class

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays information about the active management access list.

```
Console# show management access-class
Management access-class is enabled, using access list mlist
```

Management ACL Commands

14 PHY Diagnostics Commands

test copper-port tdr

The **test copper-port tdr** Privileged EXEC mode command uses Time Domain Reflectometry (TDR) technology to diagnose the quality and characteristics of a copper cable attached to a port.

Syntax

test copper-port tdr *interface*

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

The port to be tested should be shut down during the test, unless it is a combination port with fiber port active.

The maximum length of the cable for the TDR test is 120 meter.

Example

The following example results in a report on the cable attached to port 3.

```
Console# test copper-port tdr ext.3
Cable is open at 64 meters
Console# test copper-port tdr ext.3
Can't perform this test on fiber ports
```

show copper-ports tdr

The **show copper-ports tdr** User EXEC mode command displays information on the last Time Domain Reflectometry (TDR) test performed on copper ports.

Syntax

```
show copper-ports tdr [interface]
```

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

The maximum length of the cable for the TDR test is 120 meters.

Example

The following example displays information on the last TDR test performed on all copper ports.

Console> show copper-ports tdr			
Port	Result	Length [meters]	Date
1	OK		
2	Short	50	13:32:00 23 July 2005
3	Test has not been performed		
4	Open	64	13:32:00 23 July 2005
5	Fiber	-	-

show copper-ports cable-length

The **show copper-ports cable-length** User EXEC mode command displays the estimated copper cable length attached to a port.

Syntax

```
show copper-ports cable-length [interface]
```

Parameters

- *interface* — A valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

The port must be active and working in 100M or 1000M mode.

Example

The following example displays the estimated copper cable length attached to all ports.

```
Console> show copper-ports cable-length
```

Port	Length [meters]
---	-----
1	< 50
2	Copper not active
3	110-140
1	Fiber

PHY Diagnostics Commands

15 Port Channel Commands

interface port-channel

The **interface port-channel** Global Configuration mode command enters the interface configuration mode to configure a specific port-channel.

Syntax

interface port-channel *port-channel-number*

Parameters

- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Eight aggregated links can be defined with up to eight member ports per port-channel. The aggregated links' valid IDs are 1-8.

Example

The following example enters the context of port-channel number 1.

```
Console(config)# interface port-channel 1
```

interface range port-channel

The **interface range port-channel** Global Configuration mode command enters the interface configuration mode to configure multiple port-channels.

Syntax

```
interface range port-channel {port-channel-range | all}
```

Parameters

- *port-channel-range* — List of valid port-channels to add. Separate nonconsecutive port-channels with a comma and no spaces. A hyphen designates a range of port-channels.
- **all** — All valid port-channels.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Commands under the interface range context are executed independently on each interface in the range.

Example

The following example groups port-channels 1, 2 and 6 to receive the same command.

```
Console(config)# interface range port-channel 1-2,6
```

channel-group

The **channel-group** Interface Configuration (Ethernet) mode command associates a port with a port-channel. To remove a port from a port-channel, use the **no** form of this command.

Syntax

```
channel-group port-channel-number mode {on | auto}
no channel-group
```

Parameters

- *port-channel_number* — Specifies the number of the valid port-channel for the current port to join.
- **on** — Forces the port to join a channel without an LACP operation.
- **auto** — Allows the port to join a channel as a result of an LACP operation.

Default Configuration

The port is not assigned to a port-channel.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example forces port 1 to join port-channel 1 without an LACP operation.

```
Console(config)# interface ethernet ext.1
Console(config-if)# channel-group 1 mode on
```

show interfaces port-channel

The **show interfaces port-channel** Privileged EXEC mode command displays port-channel information.

Syntax

```
show interfaces port-channel [port-channel-number]
```

Parameters

- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays information on all port-channels.

```
Console# show interfaces port-channel

Channel          Ports
-----
1               Active: 1, 2
2               Active: 2, 7 Inactive: 1
3               Active: 3, 8
```

16 Port Monitor Commands

port monitor

The **port monitor** Interface Configuration mode command starts a port monitoring session. To stop a port monitoring session, use the **no** form of this command.

Syntax

port monitor *src-interface* [**rx** | **tx**]

no port monitor *src-interface*

Parameters

- *src-interface*—Valid Ethernet port. (Full syntax: *unit/port*)
- **rx**—Monitors received packets only.
- **tx**—Monitors transmitted packets only.

Default Configuration

Monitors both received and transmitted packets.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

This command enables traffic on one port to be copied to another port, or between the source port (*src-interface*) and a destination port (port being configured).

The following restrictions apply to ports configured as destination ports:

The port cannot be already configured as a source port.

The port cannot be a member in a port-channel.

An IP interface is not configured on the port.

GVRP is not enabled on the port.

The port is not a member of a VLAN, except for the default VLAN (will automatically be removed from the default VLAN).

Port Monitor Commands

The following restrictions apply to ports configured to be source ports:

The port cannot be already configured as a destination port.

Example

The following example copies traffic on port 8 (source port) to port 1 (destination port).

```
Console(config)# interface ethernet ext.11  
Console(config-if)# port monitor ext.8
```

port monitor vlan-tagging

The **port monitor** Interface Configuration (Ethernet) mode command transmits tagged ingress mirrored packets. To transmit untagged ingress mirrored packets, use the **no** form of this command.

Syntax

```
port monitor vlan-tagging  
no port monitor vlan-tagging
```

Default Configuration

Ingress mirrored packets are transmitted untagged.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures all ingress mirrored packets from port 9 to be transmitted as tagged packets.

```
Console (config)# interface ethernet ext.9  
Console (config-if)# port monitor vlan-tagging
```

show ports monitor

The **show ports monitor** User EXEC mode command displays the port monitoring status.

Syntax

show ports monitor

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example shows how the port monitoring status is displayed.

Console> show ports monitor				
Source Port	Destination Port	Type	Status	VLAN Tagging
-----	-----	-----	-----	-----
1	8	RX, TX	Active	No
2	8	RX, TX	Active	No
18	8	RX	Active	No

Port Monitor Commands

17 QoS Commands

qos

The **qos** Global Configuration mode command enables quality of service (QoS) on the device. To disable QoS on the device, use the **no** form of this command.

Syntax

```
qos [basic | advanced | service]  
no qos
```

Parameters

- **basic** — QoS basic mode.
- **advanced** — QoS advanced mode, which enables the full range of QoS configuration.
- **service** — QoS service mode, which enables the user to define QOS in a simpler manner.

Default Configuration

The QoS basic mode is enabled.

Command Mode

Global Configuration mode

User Guidelines

When the QoS service mode is enabled, Access Control Lists (ACLs) are no longer available. Instead the user is prompted to import pre-defined ACLs as Flow Classification Lists (FCLs).

Example

The following example enables QoS on the device.

```
Console(config)# qos
```

show qos

The **show qos** User EXEC mode command displays the quality of service (QoS) mode for the device.

Syntax

show qos

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

Trust mode is displayed if QoS is enabled in basic mode.

Example

The following example displays QoS attributes when QoS is enabled in basic mode on the device.

```
Console> show qos
Qos: basic
Basic tust: dscp
```

show qos aggregate-policer

The **show qos aggregate-policer** Privileged EXEC mode command displays the aggregate policer parameter.

Syntax

show qos aggregate-policer [aggregate-policer-name]

Parameters

- *aggregate-policer-name* — Specifies the name of the aggregate policer to be displayed.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines.

Example

The following example displays the parameters of the aggregate policer called ‘policer1’.

```
Console# show qos aggregate-policer policer1
aggregate-policer policer1 96000 4800 exceed-action drop
not used by any policy map
```

show qos interface

The **show qos interface** Privileged EXEC mode command displays Quality of Service (QoS) information on the interface.

Syntax

```
show qos interface [ethernet interface-number | port-channel number | port-channel number] [buffers | queueing | policers | shapers]
```

Parameters

- *interface-number* — Valid Ethernet port number.
- *number* — Valid port-channel number.
- **buffers** – Displays the buffer setting for the interface’s queues. Displays the queue depth for each queue and the thresholds for the WRED.
- **queueing** — Displays the queue strategy (WRR or EF), the weight for WRR queues, the CoS to queue map and the EF priority.
- **policers** — Displays the shaper of the specified interface and the shaper for the queue on the specified interface.
- **shapers** — Displays all the policers configured for this interface, their setting and the number of policers currently unused.

Default Configuration

There is no default configuration for this command.

Command Mode

Privileged EXEC mode

User Guidelines

If no keyword is specified, port QoS mode (for example., DSCP trusted, CoS trusted, untrusted), default CoS value, DSCP-to-DSCP-mutation map attached to the port, and policy map attached to the interface are displayed.

If no interface is specified, QoS information about all interfaces is displayed.

Example

The following example displays the buffer settings for queues on Ethernet port1.

```
Console# show qos interface ethernet 1 buffers
Ethernet 1
Notify Q depth

qid      Size
1        125
2        125
3        125
4        125
5        125
6        125
7        125
8        125

qid                      Threshold
1                         100
2                         100
3                         100
4                         100
5                         N/A
6                         N/A
```

7										N/A
8										N/A
qid	Min DP0	Max DP0	Prob DP0	Min DP1	Max DP1	Prob DP1	Min DP2	Max DP2	Prob DP2	Weight
1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
3	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
4	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
5	50	60	13	65	80	6	85	95	4	2
6	50	60	13	65	80	6	85	95	4	2
7	50	60	13	65	80	6	85	95	4	2
8	50	60	13	65	80	6	85	95	4	2

show qos map

The show qos map User EXEC mode command displays all QoS maps.

Syntax

show qos map [dscp-queue]

Parameters

- **dscp-queue** — Indicates the DSCP to queue map.

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the DSCP port-queue map.

Console> show qos map												
Dscp-queue map:												
d1	:	d2	0	1	2	3	4	5	6	7	8	9
--	:	--	--	--	--	--	--	--	--	--	--	--
0	:		01	01	01	01	01	01	01	01	01	01
1	:		01	01	01	01	01	01	02	02	02	02
2	:		02	02	02	02	02	02	02	02	02	02
3	:		02	02	03	03	03	03	03	03	03	03
4	:		03	03	03	03	03	03	03	03	04	04
5	:		04	04	04	04	04	04	04	04	04	04
6	:		04	04	04	04						

The following table describes the significant fields shown above.

Column	Description
d1	Decimal Bit 1 of DSCP
d2	Decimal Bit 2 of DSCP
01 - 04	Queue numbers

class-map

The **create-map** Global Configuration mode command creates or modifies a class map and enters the Class-map Configuration mode. To delete a class map, use the **no** form of this command.

Syntax

class-map *class-map-name* [**match-all** | **match-any**]

no class-map *class-map-name*

Parameters

- *class-map-name* — Specifies the name of the class map.
- **match-all** — Checks that the packet matches all classification criteria in the class map match statement.

- **match-any** — Checks that the packet matches one or more classification criteria in the class map match statement.

Default Configuration

By default, the **match-all** parameter is selected.

Command Mode

Global Configuration mode

User Guidelines

The **class-map** Global Configuration mode command is used to define packet classification, marking and aggregate policing as part of a globally named service policy applied on a per-interface basis.

The Class-Map Configuration mode enables entering up to two **match** Class-map Configuration mode commands to configure the classification criteria for the specified class. If two **match** Class-map Configuration mode commands are entered, each should point to a different type of ACL (e.g., one to an IP ACL and one to a MAC ACL). Since packet classification is based on the order of the classification criteria, the order in which the **match** Class-Map Configuration mode commands are entered is important.

If there is more than one match statement in a **match-all** class map and the same classification field appears in the participating ACLs, an error message is generated.

Note: A class map in match-all mode cannot be configured if it contains both an IP ACL and a MAC ACL with an ether type that is not 0x0800.

Example

The following example creates a class map called class1 and configures it to check that packets match all classification criteria in the class map match statement.

```
Console(config)# class-map class1 match-all
Console(config-cmap) #
```

show class-map

The **show class-map** User EXEC mode command displays all class maps.

Syntax

show class-map [*class-map-name*]

Parameters

- *class-map-name* — Specifies the name of the class map to be displayed.

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example shows the class map for class1.

```
Console> show class-map class1
Class Map match-any class1 (id4)
Match Ip dscp 11 21
```

match

The **match** Class-map Configuration mode command defines the match criteria for classifying traffic. To delete the match criteria, use the **no** form of this command.

Syntax

```
match access-group acl-name
no match access-group acl-name
```

Parameters

- *acl-name* — Specifies the name of an IP or MAC ACL.

Default Configuration

No match criterion is supported.

Command Mode

Class-map Configuration mode.

User Guidelines

There are no user guidelines for this command.

Example

The following example defines the match criterion for classifying traffic as an access group called enterprise in a class map called class1..

```
Console (config)# class-map class1
Console (config-cmap)# match access-group enterprise
```

policy-map

The **policy-map** Global Configuration mode command creates a policy map and enters the Policy-map Configuration mode. To delete a policy map, use the **no** form of this command.

Syntax

```
policy-map policy-map-name
no policy-map policy-map-name
```

Parameters

- *policy-map-name* — Specifies the name of the policy map.

Default Configuration

If the packet is an IP packet, the DCSP value of the policy map is 0.

If the packet is tagged, the CoS value is 0.

Command Mode

Global Configuration mode

User Guidelines

Before configuring policies for classes whose match criteria are defined in a class map, use the **policy-map** Global Configuration mode command to specify the name of the policy map to be created or modified.

Class policies in a policy map can only be defined if match criteria has already been defined for the classes. Use the **class-map** Global Configuration and **match** Class-map Configuration commands to define the match criteria of a class.

Only one policy map per interface per direction is supported. A policy map can be applied to multiple interfaces and directions.

Example

The following example creates a policy map called policy1 and enters the Policy-map Configuration mode.

```
Console (config)# policy-map policy1  
Console (config-pmap) #
```

class

The **class** Policy-map Configuration mode command defines a traffic classification and enters the Policy-map Class Configuration mode. To remove a class map from the policy map, use the **no** form of this command.

Syntax

```
class class-map-name [access-group acl-name]
```

```
no class class-map-name
```

Parameters

- *class-map-name* — Specifies the name of an existing class map. If the class map does not exist, a new class map will be created under the specified name.
- *acl-name* — Specifies the name of an IP or MAC ACL.

Default Configuration

No policy map is defined.

Command Mode

Policy-map Configuration mode

User Guidelines

Before modifying a policy for an existing class or creating a policy for a new class, use the **policy-map** Global Configuration mode command to specify the name of the policy map to which the policy belongs and to enter the Policy-map Configuration mode.

Use the **service-policy** (Ethernet, Port-channel) Interface Configuration mode command to attach a policy map to an interface. Use an existing class map to attach classification criteria to the specified policy map and use the **access-group** parameter to modify the classification criteria of the class map.

If this command is used to create a new class map, the name of an IP or MAC ACL must also be specified.

Example

The following example defines a traffic classification called class1 with an access-group called enterprise. The class is in a policy map called policy1.

```
Console(config)# policy-map policy1
Console (config-pmap)# class class1 access-group enterprise
```

show policy-map

The **show policy-map** User EXEC command displays the policy maps.

Syntax

show policy-map [policy-map-name [class class-name]]

Parameters

- *policy-map-name* — Specifies the name of the policy map to be displayed.
- *class-name* — Specifies the name of the class whose QoS policies are to be displayed.

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays all policy maps.

```
Console> show policy-map
Policy Map policy1
  class class1
    set Ip dscp 7

Policy Map policy2
  class class 2
    police 96000 4800 exceed-action drop
  class class3
    police 124000 96000 exceed-action policed-dscp-transmit
```

trust cos-dscp

The **trust cos-dscp** Policy-map Class Configuration mode command configures the trust state. The trust state determines the source of the internal DSCP value used by Quality of Service (QoS). To return to the default configuration, use the **no** form of this command.

Syntax

trust cos-dscp

no trust cos-dscp

Default Configuration

The port is not in the trust mode.

If the port is in trust mode, the internal DSCP value is derived from the ingress packet.

Command Mode

Policy-map Class Configuration mode

User Guidelines

Action serviced to a class, so that if an IP packet arrives, the queue is assigned per DSCP. If a non-IP packet arrives, the queue is assigned per CoS (VPT).

Example

The following example configures the trust state for a class called class1 in a policy map called policy1.

```
Console (config)# policy-map policy1
Console (config-pmap)# class class1
Console (config-pmap-c)# trust cos-dscp
```

set

The **set** Policy-map Class Configuration mode command sets new values in the IP packet.

Syntax

set {dscp new-dscp | queue queue-id | cos new-cos}

no set

Parameters

- *new-dscp* — Specifies a new DSCP value for the classified traffic. (Range: 0-63)
- *queue-id* — Specifies an explicit queue ID for setting the egress queue.
- *new-cos* — Specifies a new user priority for marking the packet. (Range: 0-7)

Default Configuration

This command has no default configuration.

Command Mode

Policy-map Class Configuration mode

User Guidelines

This command is mutually exclusive with the **trust** Policy-map Class Configuration command within the same policy map.

Policy maps that contain **set** or **trust** Policy-map Class Configuration commands or that have ACL classifications cannot be attached to an egress interface by using the **service-policy** (Ethernet, Port-channel) Interface Configuration mode command.

To return to the Policy-map Configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Example

The following example sets the dscp value in the packet to 56 for classes in policy map called policy1.

```
Console (config)# policy-map policy1
Console (config-pmap)# set dscp 56
Console (config-if)# service-policy input policy1
```

police

The **police** Policy-map Class Configuration mode command defines the policer for classified traffic. To remove a policer, use the **no** form of this command.

Syntax

```
police committed-rate-bps committed -burst-byte [exceed-action {drop | policed-dscp-transmit}]
no police
```

Parameters

- *committed-rate-bps* — Specifies the average traffic rate (CIR) in bits per second (bps).
- *committed -burst-byte* — Specifies normal burst size (CBS) in bytes.
- **drop** — Indicates that when the rate is exceeded, the packet is dropped.
- **policed-dscp-transmit** — Indicates that when the rate is exceeded, the DSCP of the packet is remarked according to the policed-DSCP map as configured by the **qos map policed-dscp** Global Configuration mode command.

Default Configuration

This command has no default configuration.

Command Mode

Policy-map Class Configuration mode

User Guidelines

Policing uses a token bucket algorithm. CIR represents the speed with which the token is removed from the bucket. CBS represents the depth of the bucket.

Example

The following example defines a policer for classified traffic. When the traffic rate exceeds 124,000 bps or the normal burst size exceeds 96000 bps, the packet is dropped. The class is called class1 and is in a policy map called policy1..

```
Console (config)# policy-map policy1
Console (config-pmap)# class class1
Console (config-pmap-c)# police 124000 9600 exceed-action drop
```

service-policy

The **service-policy** Interface Configuration (Ethernet, port-Channel) mode command applies a policy map to the input of a particular interface. To detach a policy map from an interface, use the **no** form of this command.

Syntax

```
service-policy {input policy-map-name}
no service-policy {input}
```

Parameters

- *policy-map-name* — Specifies the name of the policy map to be applied to the input interface.

Default Configuration

This command has no default configuration.

Command Mode

Interface Configuration (Ethernet, port-Channel) mode

User Guidelines

Only one policy map per interface per direction is supported.

Example

The following example attaches a policy map called policy1 to the input interface.

```
Console(config-if)# service-policy input policy1
```

qos aggregate-policer

The **qos aggregate-policer** Global Configuration mode command defines the policer parameters that can be applied to multiple traffic classes within the same policy map. To remove an existing aggregate policer, use the **no** form of this command.

Syntax

```
qos aggregate-policer aggregate-policer-name committed-rate-bps excess-burst-byte  
exceed-action {drop | policed-dscp-transmit} [dscp dscp]  
no qos aggregate-policer
```

Parameters

- *aggregate-policer-name* — Specifies the name of the aggregate policer.
- *committed-rate-bps* — Specifies the average traffic rate (CIR) in bits per second (bps).
- *excess-burst-byte* — Specifies the normal burst size (CBS) in bytes.
- **drop** — Indicates that when the rate is exceeded, the packet is dropped.
- **policed-dscp-transmit** — Indicates that when the rate is exceeded, the DSCP of the packet is remarked.
- *dscp* — Specifies the value that the DSCP would be remarked. If unspecified, the DSCP would be remarked according to the policed-DSCP map as configured by the **qos map policed-dscp** Global Configuration mode command.

Default Configuration

No aggregate policer is define.

Command Mode

Global Configuration mode

User Guidelines

Policers that contain **set** or **trust** Policy-map Class Configuration commands or that have ACL classifications cannot be attached to an output interface.

Define an aggregate policer if the policer is shared with multiple classes.

Policers in one port cannot be shared with other policers in another device; traffic from two different ports can be aggregated for policing purposes.

An aggregate policer can be applied to multiple classes in the same policy map; An aggregate policer cannot be applied across multiple policy maps.

This policer can also be used in Cascade police to make a cascade policer.

An aggregate policer cannot be deleted if it is being used in a policy map. The **no police aggregate** Policy-map Class Configuration command must first be used to delete the aggregate policer from all policy maps.

Policing uses a token bucket algorithm. CIR represents the speed with which the token is removed from the bucket. CBS represents the depth of the bucket.

Example

The following example defines the parameters of a policer called **policer1** that can be applied to multiple classes in the same policy map. When the average traffic rate exceeds 124,000 bps or the normal burst size exceeds 96000 bps, the packet is dropped..

```
Console (config)# qos aggregate-policer policer1 124000 96000
exceed-action drop
```

show qos aggregate-policer

The **show qos aggregate-policer** User EXEC mode command displays the aggregate policer parameter.

Syntax

show qos aggregate-policer [aggregate-policer-name]

Parameters

- *aggregate-policer-name* — Specifies the name of the aggregate policer to be displayed.

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines.

Example

The following example displays the parameters of the aggregate policer called policer1.

```
Console> show qos aggregate-policer policer1
aggregate-policer policer1 96000 4800 exceed-action drop
not used by any policy map
```

police aggregate

The **police aggregate** Policy-map Class Configuration mode command applies an aggregate policer to multiple classes within the same policy map. To remove an existing aggregate policer from a policy map, use the **no** form of this command.

Syntax

```
police aggregate aggregate-policer-name
no police aggregate aggregate-policer-name
```

Parameters

- *aggregate-policer-name* — Specifies the name of the aggregate policer.

Default Configuration

This command has no default configuration.

Command Mode

Policy-map Class Configuration mode

User Guidelines

An aggregate policer can be applied to multiple classes in the same policy map; An aggregate policer cannot be applied across multiple policy maps or interfaces.

To return to the Policy-map Configuration mode, use the **exit** command. To return to the Privileged EXEC mode, use the **end** command.

Example

The following example applies the aggregate policer called `policer1` to a class called `class1` in policy map called `policy1`.

```
Console(config)# policy-map policy1
Console(config-pmap)# class class1
Console(config-pmap-c)# police aggregate policer1
```

wrr-queue cos-map

The **wrr-queue cos-map** Global Configuration mode command maps Class of Service (CoS) values to a specific egress queue. To return to the default configuration, use the **no** form of this command.

Syntax

wrr-queue cos-map *queue-id cos1...cos8*

no wrr-queue cos-map [*queue-id*]

Parameters

- *queue-id* — Specifies the queue number to which the CoS values are mapped.
- *cos1...cos8* — Specifies CoS values to be mapped to a specific queue. (Range: 0-7)

Default Configuration

CoS values are mapped to 8 queues as follows:

Cos0 is mapped to queue 3.

Cos1 is mapped to queue 1.

Cos2 is mapped to queue 2.

Cos3 is mapped to queue 4.

Cos4 is mapped to queue 5.

Cos5 is mapped to queue 6.

Cos6 is mapped to queue 7.

Cos7 is mapped to queue 8.

Command Mode

Global Configuration mode

User Guidelines

This command can be used to distribute traffic into different queues, where each queue is configured with different Weighted Round Robin (WRR) and Weighted Random Early Detection (WRED) parameters.

It is recommended to specifically map a single VPT to a queue, rather than mapping multiple VPTs to a single queue. Use the **priority-queue out** Interface Configuration (Ethernet, Port-channel) mode command to enable expedite queues.

Example

The following example maps CoS 7 to queue 2.

```
Console(config)# wrr-queue cos-map 2 7
```

wrr-queue bandwidth

The **wrr-queue bandwidth** Interface Configuration (Ethernet, port-channel) mode command assigns weights to each Weighted Round Robin (WRR) queue. The weight ratio determines the frequency by which the packet scheduler dequeues packets from each queue. To return to the default configuration, use the **no** form of this command.

Syntax

wrr-queue bandwidth *weight1 weight2 ... weight_n*

no wrr-queue bandwidth

Parameters

- *weight1 weight2 ... weight_n* — Sets the ratio of the bandwidth assigned by the WRR packet scheduler for the packet queues. Separate each value by a space. (Range: 6-255)

Default Configuration

The default WRR weight ratio is one-eighth of the sum of all queue weights (each weight is set to 6).

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

Use the **priority-queue out num-of-queues** Global Configuration mode command to configure a queue as WRR or Strict Priority. Use this command to define a WRR weight per interface.

The weight ratio for each queue is defined by the queue weight divided by the sum of all queue weights (i.e., the normalized weight). This sets the bandwidth allocation for each queue.

A queue can be assigned a WRR weight of 0, in which case no bandwidth is allocated to the queue and the shared bandwidth is divided among the remaining queues.

All eight queues participate in the WRR, excluding the queues that are assigned as expedite queues. The weights of the expedite queues are ignored in the ratio calculation.

An expedite queue is a priority queue, and it is serviced before the other queues are serviced. Use the **priority-queue out** Interface Configuration (Ethernet, port-channel) mode command to enable expedite queues.

Example

The following example assigns a weight of 6 to each of the 8 WRR queues.

```
Console(config-if)# wrr-queue bandwidth 6 6 6 6 6 6 6 6
```

priority-queue out num-of-queues

The **priority-queue out num-of-queues** Global Configuration mode command configures the number of expedite queues. To return to the default configuration, use the **no** form of this command.

Syntax

priority-queue out num-of-queues *number-of-queues*

no priority-queue out num-of-queues

Parameters

- *number-of-queues* — Specifies the number of expedite queues. Expedite queues have higher indexes. (Range: 0-8)

Default Configuration

All queues are expedite queues.

Command Mode

Global Configuration mode

User Guidelines

Configuring the number of expedite queues affects the Weighted Round Robin (WRR) weight ratio because fewer queues participate in the WRR.

Example

The following example configures the number of expedite queues as 0.

```
Console(config)# priority-queue out num-of-queues 0
```

traffic-shape

The **traffic-shape** Interface Configuration (Ethernet, port-channel) mode command configures the shaper of the egress port/queue. To disable the shaper, use the **no** form of this command.

Syntax

```
traffic-shape {committed-rate committed-burst}  
traffic-shape [queue-id]  
no traffic-shape [queue-id]
```

Parameters

- *committed-rate* — Specifies the average traffic rate (CIR) in bits per second (bps). (Range: 6510-64-10000000)

- *excess-burst* — Specifies the excess burst size (CBS) in bytes.(Range: 4096-16769020)
- *queue-id* — Specifies the queue number to which the shaper is assigned. (Range: 0-8)

Default Configuration

No shape is defined.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

This command activates the shaper on a specified egress port or egress queue.

To activate the shaper on an egress port, enter the Interface Configuration mode and specify the port number. Then run this command without the **queue-id** parameter. The CIR and the CBS will be applied to the specified port.

To activate the shaper for specific queue, run this command with the **queue-id** parameter.

Example

The following example sets a shaper on Ethernet port 5 when the average traffic rate exceeds 124000 bps or the normal burst size exceeds 96000 bps.

```
Console(config)# interface ethernet ext.5
Console(config-if) traffic-shape 124000 96000
```

show qos interface

The **show qos interface** User EXEC mode command displays Quality of Service (QoS) information on the interface.

Syntax

```
show qos interface [ethernet interface-number | port-channel number | port-channel number] [buffers | queueing | policers | shapers]
```

Parameters

- *interface-number* — Valid Ethernet port number.
- *number* — Valid port-channel number.

- **buffers** – Displays the buffer setting for the interface's queues. Displays the queue depth for each queue and the thresholds for the WRED.
- **queuing** — Displays the queue strategy (WRR or EF), the weight for WRR queues, the CoS to queue map and the EF priority.
- **policers** — Displays the shaper of the specified interface and the shaper for the queue on the specified interface.
- **shapers** — Displays all the policers configured for this interface, their setting and the number of policers currently unused.

Default Configuration

There is no default configuration for this command.

Command Mode

User EXEC mode

User Guidelines

If no keyword is specified, port QoS QoS mode (e.g., DSCP trusted, CoS trusted, untrusted), default CoS value, DSCP-to-DSCP-mutation map attached to the port, and policy map attached to the interface are displayed.

If no interface is specified, QoS information about all interfaces is displayed.

Example

The following example displays the buffer settings for queues on Ethernet port 1.

```
Console# show qos interface ethernet 1 buffers
Ethernet 1
Notify Q depth

qid    Size
1      125
2      125
3      125
4      125
5      125
6      125
7      125
8      125
```

qid	Threshold									
qid	Min DP0	Max DP0	Prob DP0	Min DP1	Max DP1	Prob DP1	Min DP2	Max DP2	Prob DP2	Weight
1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
3	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
4	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
5	50	60	13	65	80	6	85	95	4	2
6	50	60	13	65	80	6	85	95	4	2
7	50	60	13	65	80	6	85	95	4	2
8	50	60	13	65	80	6	85	95	4	2

qos wrr-queue threshold

The **wrr-queue threshold** Global Configuration mode command assigns queue thresholds globally. To return to the default configuration, use the **no** form of this command.

Syntax

qos wrr-queue threshold *queue-id threshold-percentage0 threshold-percentage1, threshold-percentage2*

no qos wrr-queue threshold *queue-id*

qos wrr-queue threshold gigabitether net *queue-id threshold-percentage0 threshold-percentage1, threshold-percentage2*

no qos wrr-queue threshold gigabitether net *queue-id*

qos wrr-queue threshold tengigabitethernet queue-id threshold-percentage0 threshold-percentage1, threshold-percentage2

no qos wrr-queue threshold tengigabitethernet queue-id

Parameters

- **gigabitethernet** — Indicates that the thresholds are to be applied to Gigabit Ethernet ports.
- **tengigabitethernet** — Indicates that the thresholds are to be applied to 10 Gigabit Ethernet ports.
- *queue-id* — Specifies the queue number to which the threshold is assigned.
- *threshold-percentage0,1,2* — Specifies the queue threshold percentage value. Each value is separated by a space. (Range: 0-100)

Default Configuration

80 percent for all thresholds.

Command Mode

Global Configuration mode.

User Guidelines

The packet refers to a certain threshold by the conformance level. If threshold 0 is exceeded, packets with the corresponding DP are dropped until the threshold is no longer exceeded. However, packets assigned to threshold 1 or 2 continue to be queued and sent as long as the second or third threshold is not exceeded.

Example

The following example assigns a threshold of 80 percent to WRR queue 1.

```
Console (config)# qos wrr-queue threshold gigabitethernet 1 80
```

qos map policed-dscp

The **qos map policed-dscp** Global Configuration mode command modifies the policed-DSCP map for remarking purposes. To return to the default map, use the **no** form of this command.

Syntax

```
qos map policed-dscp dscp-list to dscp-mark-down
no qos map policed-dscp
```

Parameters

- *dscp-list* — Specifies up to 8 DSCP values separated by a space. (Range: 0-63)
- *dscp-mark-down* — Specifies the DSCP value to mark down. (Range: 0-63)

Default Configuration

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

Command Mode

Global Configuration mode.

User Guidelines

DSCP values 3,11,19... cannot be remapped to other values.

Example

The following example marks down incoming DSCP value 3 as DSCP value 43 on the policed-DSCP map.

```
Console(config)# qos map policed-dscp 3 to 43
Reserved DSCP. DSCP 3 was not configured.
```

qos map dscp-queue

The **qos map dscp-queue** Global Configuration mode command modifies the DSCP to CoS map. To return to the default map, use the **no** form of this command.

Syntax

```
qos map dscp-queue dscp-list to queue-id
no qos map dscp-queue
```

Parameters

- *dscp-list* — Specifies up to 8 DSCP values separated by a space. (Range: 0 - 63)
- *queue-id* — Specifies the queue number to which the DSCP values are mapped.

Default Configuration

The following table describes the default map.

DSVP value	0-7	8-15	16-23	24-31	32-39	40-47	48-56	57-63
Queue-ID	1	2	3	4	5	6	7	8

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example maps DSCP values 33, 40 and 41 to queue 1.

```
Console(config)# qos map dscp-queue 33 40 41 to 1
```

qos trust (Global)

The **qos trust** Global Configuration mode command configures the system to the basic mode and trust state. To return to the untrusted state, use the **no** form of this command.

Syntax

```
qos trust {cos | dscp}
```

```
no qos trust
```

Parameters

- **cos** — Indicates that ingress packets are classified with packet CoS values. Untagged packets are classified with the default port CoS value.
- **dscp** — Indicates that ingress packets are classified with packet DSCP values.

Default Configuration

CoS is the default trust mode.

Command Mode

Global Configuration mode

User Guidelines

Packets entering a quality of service (QoS) domain are classified at the edge of the QoS domain. When packets are classified at the edge, the switch port within the QoS domain can be configured to one of the trusted states because there is no need to classify the packets at every device in the domain.

A switch port on an inter-QoS domain boundary can be configured to the DSCP trust state, and, if the DSCP values are different between the QoS domains, the DSCP to DSCP mutation map can be applied.

Use this command to specify whether the port is trusted and which fields of the packet to use to classify traffic.

When the system is configured as trust DSCP, traffic is mapped to a queue according to the DSCP-queue map.

Example

The following example configures the system to the DSCP trust state.

```
Console(config)# qos trust dscp
```

qos trust (Interface)

The **qos trust** Interface Configuration (Ethernet, port-channel) mode command enables each port trust state while the system is in the basic QoS mode. To disable the trust state on each port, use the **no** form of this command.

Syntax

qos trust

no qos trust

Default Configuration

qos trust is enabled on each port when the system is in basic mode.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures Ethernet port 15 to the default trust state.

```
Console(config)# interface ethernet Ext.15
Console(config-if) qos trust
```

qos cos

The **qos cos** Interface Configuration (Ethernet, port-channel) mode command defines the default CoS value of a port. To return to the default configuration, use the **no** form of this command.

Syntax

qos cos default-cos

no qos cos

Parameters

- *default-cos* — Specifies the default CoS value of the port. (Range: 0-7)

Default Configuration

Default CoS value of a port is 0.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

If the port is trusted, the default CoS value of the port is used to assign a CoS value to all untagged packets entering the port.

Example

The following example configures port 15 default CoS value to 3.

```
Console(config)# interface ethernet ext. 15
Console(config-if) qos cos 3
```

qos dscp-mutation

The **qos dscp-mutation** Global Configuration mode command applies the DSCP Mutation map to a system DSCP trusted port. To return to the trust state with no DSCP mutation, use the **no** form of this command.

Syntax

qos dscp-mutation

no qos dscp-mutation

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode.

User Guidelines

The DSCP to DSCP mutation map is applied to a port at the boundary of a Quality of Service (QoS) administrative domain.

If two QoS domains have different DSCP definitions, use the DSCP to DSCP mutation map to match one set of DSCP values with the DSCP values of another domain.

Apply the DSCP to DSCP mutation map only to ingress and to DSCP-trusted ports. Applying this map to a port causes IP packets to be rewritten with newly mapped DSCP values at the ingress ports.

If the DSCP to DSCP mutation map is applied to an untrusted port, class of service (CoS) or IP-precedence trusted port, this command has no immediate effect until the port becomes DSCP-trusted.

Example

The following example applies the DSCP Mutation map to system DSCP trusted ports.

```
Console(config)# qos dscp-mutation
```

qos map dscp-mutation

The **qos map dscp-mutation** Global Configuration mode command modifies the DSCP to DSCP mutation map. To return to the default DSCP to DSCP mutation map, use the **no** form of this command.

Syntax

```
qos map dscp-mutation in-dscp to out-dscp  
no qos map dscp-mutation
```

Parameters

- *in-dscp* — Specifies up to 8 DSCP values separated by spaces. (Range: 0-63)
- *out-dscp* — Specifies up to 8 DSCP values separated by spaces. (Range: 0-63)

Default Configuration

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

Command Mode

Global Configuration mode.

User Guidelines

This is the only map that is not globally configured. it is possible to have several maps and assign each one to different ports.

Example

The following example changes DSCP values 1, 2, 4, 5 and 6 to DSCP mutation map value 63.

```
Console config)# qos map dscp-mutation 1 2 4 5 6 to 63
```


QoS Commands

18 RMON Commands

show rmon statistics

The **show rmon statistics** Privileged EXEC mode command displays RMON Ethernet statistics.

Syntax

```
show rmon statistics {ethernet interface number | port-channel port-channel-number}
```

Parameters

- *interface number* — Valid Ethernet port.
- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays RMON Ethernet statistics for Ethernet port 1.

```
Console# show rmon statistics ethernet ext.1

Port: 1
Octets: 878128          Packets: 978
Broadcast: 7              Multicast: 1
CRC Align Errors: 0      Collisions: 0
Undersize Pkts: 0        Oversize Pkts: 0
```

Fragments: 0	Jabbers: 0
64 Octets: 98	65 to 127 Octets: 0
128 to 255 Octets: 0	256 to 511 Octets: 0
512 to 1023 Octets: 491	1024 to 1518 Octets: 389

The following table describes the significant fields shown in the display.

Field	Description
Octets	The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets).
Packets	The total number of packets (including bad packets, broadcast packets, and multicast packets) received.
Broadcast	The total number of good packets received and directed to the broadcast address. This does not include multicast packets.
Multicast	The total number of good packets received and directed to a multicast address. This number does not include packets directed to the broadcast address.
CRC Align Errors	The total number of packets received with a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but with either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Collisions	The best estimate of the total number of collisions on this Ethernet segment.
Undersize Pkts	The total number of packets received, less than 64 octets long (excluding framing bits, but including FCS octets) and otherwise well formed.
Oversize Pkts	The total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets) and otherwise well formed.
Fragments	The total number of packets received, less than 64 octets in length (excluding framing bits but including FCS octets) and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Jabbers	The total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets), and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
64 Octets	The total number of packets (including bad packets) received that are 64 octets in length (excluding framing bits but including FCS octets).
65 to 127 Octets	The total number of packets (including bad packets) received that are between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
128 to 255 Octets	The total number of packets (including bad packets) received that are between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
256 to 511 Octets	The total number of packets (including bad packets) received that are between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

Field	Description
512 to 1023 Octets	The total number of packets (including bad packets) received that are between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
1024 to 1518 Octets	The total number of packets (including bad packets) received that are between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

rmon collection history

The **rmon collection history** Interface Configuration (Ethernet, port-channel) mode command enables a Remote Monitoring (RMON) MIB history statistics group on an interface. To remove a specified RMON history statistics group, use the **no** form of this command.

Syntax

rmon collection history index [owner ownername] [buckets bucket-number] [interval seconds]

no rmon collection history index

Parameters

- *index* — Specifies the statistics group index . (Range: 1-65535)
- *ownername* — Specifies the RMON statistics group owner name. (Range: 0-160 characters)
- *bucket-number* — Number of buckets specified for the RMON collection history group of statistics. If unspecified, defaults to 50. (Range:1-65535)
- *seconds* — Number of seconds in each polling cycle. (Range: 1-3600)

Default Configuration

RMON statistics group owner name is an empty string.

Number of buckets specified for the RMON collection history statistics group is 50.

Number of seconds in each polling cycle is 1800.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

Cannot be configured for a range of interfaces (Range context).

Example

The following example enables a Remote Monitoring (RMON) MIB history statistics group on Ethernet port 1 with index number 1 and a polling interval period of 2400 seconds.

```
Console(config)# interface ethernet ext.1
Console(config-if)# rmon collection history 1 interval 2400
```

show rmon collection history

The **show rmon collection history** Privileged EXEC mode command displays the requested RMON history group statistics.

Syntax

```
show rmon collection history [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)
- *port-channel-number* — Valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays all RMON history group statistics.

Console# show rmon collection history					
Index	Interface	Interval	Requested Samples	Granted Samples	Owner
1	1	30	50	50	CLI
2	1	1800	50	50	Manager

The following table describes the significant fields shown in the display.

Field	Description
Index	An index that uniquely identifies the entry.
Interface	The sampled Ethernet interface
Interval	The interval in seconds between samples.
Requested Samples	The requested number of samples to be saved.
Granted Samples	The granted number of samples to be saved.
Owner	The entity that configured this entry

show rmon history

The **show rmon history** Privileged EXEC mode command displays RMON Ethernet history statistics.

Syntax

show rmon history *index {throughput | errors | other}* [*period seconds*]

Parameters

- *index* — Specifies the requested set of samples. (Range: 1-65535)
- **throughput** — Indicates throughput counters.
- **errors** — Indicates error counters.
- **other** — Indicates drop and collision counters.
- *seconds* — Specifies the period of time in seconds. (Range: 1-4294967295)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays RMON Ethernet history statistics for index 1.

Console# show rmon history 1 throughput					
Sample Set: 1			Owner: CLI		
Interface: 1			Interval: 1800		
Requested samples: 50			Granted samples: 50		
Maximum table size: 500					
Time	Octets	Packets	Broadcast	Multicast	Util
-----	-----	-----	-----	-----	-----
Jan 18 2005 21:57:00	303595962	357568	3289	7287	19%
Jan 18 2005 21:57:30	287696304	275686	2789	5878	20%
Console# show rmon history 1 errors					
Sample Set: 1			Owner: Me		
Interface: 1			Interval: 1800		
Requested samples: 50			Granted samples: 50		
Maximum table size: 500 (800 after reset)					
Time	CRC Align	Undersize	Oversize	Fragments	Jabbers
-----	-----	-----	-----	-----	-----
Jan 18 2005 21:57:00	1	1	0	49	0
Jan 18 2005 21:57:30	1	1	0	27	0

```

Console# show rmon history 1 other

Sample Set: 1          Owner: Me
Interface:1           Interval: 1800
Requested samples: 50  Granted samples: 50

Maximum table size: 500

Time                Dropped    Collisions
-----
Jan 18 2005 21:57:00 3          0
Jan 18 2005 21:57:30 3          0

```

The following table describes significant fields shown in the example:

Field	Description
Time	Date and Time the entry is recorded.
Octets	The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets).
Packets	The number of packets (including bad packets) received during this sampling interval.
Broadcast	The number of good packets received during this sampling interval that were directed to the broadcast address.
Multicast	The number of good packets received during this sampling interval that were directed to a multicast address. This number does not include packets addressed to the broadcast address.
Util	The best estimate of the mean physical layer network utilization on this interface during this sampling interval, in hundredths of a percent.
CRC Align	The number of packets received during this sampling interval that had a length (excluding framing bits but including FCS octets) between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Undersize	The number of packets received during this sampling interval that were less than 64 octets long (excluding framing bits but including FCS octets) and were otherwise well formed.
Oversize	The number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets) but were otherwise well formed.

Field	Description
Fragments	The total number of packets received during this sampling interval that were less than 64 octets in length (excluding framing bits but including FCS octets) had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error), or a bad FCS with a non-integral number of octets (AlignmentError). It is normal for etherHistoryFragments to increment because it counts both runts (which are normal occurrences due to collisions) and noise hits.
Jabbers	The number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Dropped	The total number of events in which packets were dropped by the probe due to lack of resources during this sampling interval. This number is not necessarily the number of packets dropped, it is just the number of times this condition has been detected.
Collisions	The best estimate of the total number of collisions on this Ethernet segment during this sampling interval.

rmon alarm

The **rmon alarm** Global Configuration mode command configures alarm conditions. To remove an alarm, use the **no** form of this command.

Syntax

```
rmon alarm index variable interval rthreshold fthreshold revent [type type]
[startup direction] [owner name]

no rmon alarm index
```

Parameters

- *index* — Specifies the alarm index. (Range: 1-65535)
- *variable* — Specifies the object identifier of the variable to be sampled.
- *interval* — Specifies the interval in seconds during which the data is sampled and compared with rising and falling thresholds. (Range: 0-2147483647)
- *rthreshold* — Specifies the rising threshold. (Range: 0-2147483647)
- *fthreshold* — Specifies the falling threshold. (Range: 0-2147483647)
- *revent* — Specifies the event index used when a rising threshold is crossed. (Range: 1-65535)
- *fevent* — Specifies the event index used when a falling threshold is crossed. (Range: 1-65535)

- *type* — Specifies the method used for sampling the selected variable and calculating the value to be compared against the thresholds. Possible values are **absolute** and **delta**.
- If the method is **absolute**, the value of the selected variable is compared directly with the thresholds at the end of the sampling interval. If the method is **delta**, the selected variable value of the last sample is subtracted from the current value, and the difference is compared with the thresholds.
- *direction* — Specifies the alarm that may be sent when this entry is first set to valid. Possible values are **rising**, **rising-falling** and **falling**.
- If the first sample (after this entry becomes valid) is greater than or equal to *rthreshold* and *direction* is equal to **rising** or **rising-falling**, a single rising alarm is generated. If the first sample (after this entry becomes valid) is less than or equal to *fthreshold* and *direction* is equal to **falling** or **rising-falling**, a single falling alarm is generated.
- *name* — Specifies the name of the person who configured this alarm. If unspecified, the name is an empty string.

Default Configuration

The type is **absolute**.

The startup direction is **rising-falling**.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the following alarm conditions:

- Alarm index — 1000
- Variable identifier — Intel
- Sample interval — 360000 seconds
- Rising threshold — 1000000
- Falling threshold — 1000000
- Rising threshold event index — 10
- Falling threshold event index — 20

```
Console(config)# rmon alarm 1000 Intel 360000 1000000 1000000 10 20
```

show rmon alarm-table

The **show rmon alarm-table** Privileged EXEC mode command displays the alarms table.

Syntax

```
show rmon alarm-table
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the alarms table.

Console# show rmon alarm-table		
Index	OID	Owner
1	1.3.6.1.2.1.2.2.1.10.1	CLI
2	1.3.6.1.2.1.2.2.1.10.1	Manager
3	1.3.6.1.2.1.2.2.1.10.9	CLI

The following table describes significant fields shown in the example:

Field	Description
Index	An index that uniquely identifies the entry.
OID	Monitored variable OID.
Owner	The entity that configured this entry.

show rmon alarm

The **show rmon alarm** Privileged EXEC mode command displays alarm configuration.

Syntax

show rmon alarm *number*

Parameters

- *number* — Specifies the alarm index. (Range: 1-65535)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays RMON 1 alarms.

```
Console# show rmon alarm 1
Alarm 1
-----
OID: 1.3.6.1.2.1.2.2.1.10.1
Last sample Value: 878128
Interval: 30
Sample Type: delta
Startup Alarm: rising
Rising Threshold: 8700000
Falling Threshold: 78
Rising Event: 1
Falling Event: 1
Owner: CLI
```

The following table describes the significant fields shown in the display:

Field	Description
Alarm	Alarm index.
OID	Monitored variable OID.
Last Sample Value	The statistic value during the last sampling period. For example, if the sample type is delta , this value is the difference between the samples at the beginning and end of the period. If the sample type is absolute , this value is the sampled value at the end of the period.
Interval	The interval in seconds over which the data is sampled and compared with the rising and falling thresholds.
Sample Type	The method of sampling the variable and calculating the value compared against the thresholds. If the value is absolute , the value of the variable is compared directly with the thresholds at the end of the sampling interval. If the value is delta , the value of the variable at the last sample is subtracted from the current value, and the difference compared with the thresholds.
Startup Alarm	The alarm that may be sent when this entry is first set. If the first sample is greater than or equal to the rising threshold, and startup alarm is equal to rising or rising and falling, then a single rising alarm is generated. If the first sample is less than or equal to the falling threshold, and startup alarm is equal falling or rising and falling, then a single falling alarm is generated.
Rising Threshold	A sampled statistic threshold. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval is less than this threshold, a single event is generated.
Falling Threshold	A sampled statistic threshold. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval is greater than this threshold, a single event is generated.
Rising Event	The event index used when a rising threshold is crossed.
Falling Event	The event index used when a falling threshold is crossed.
Owner	The entity that configured this entry.

rmon event

The **rmon event** Global Configuration mode command configures an event. To remove an event, use the **no** form of this command.

Syntax

rmon event *index type* [**community** *text*] [**description** *text*] [**owner** *name*]

no rmon event *index*

Parameters

- *index* — Specifies the event index. (Range: 1-65535)
- *type* — Specifies the type of notification generated by the device about this event. Possible values: **none**, **log**, **trap**, **log-trap**.

- **community** *text* — If the specified notification type is **trap**, an SNMP trap is sent to the SNMP community specified by this octet string. (Range: 0-127 characters)
- **description** *text* — Specifies a comment describing this event. (Range: 0-127 characters)
- **name** — Specifies the name of the person who configured this event. If unspecified, the name is an empty string.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

If **log** is specified as the notification type, an entry is made in the log table for each event. If **trap** is specified, an SNMP trap is sent to one or more management stations.

Example

The following example configures an event identified as index 10 and for which the device generates a notification in the log table.

```
Console(config)# rmon event 10 log
```

show rmon events

The **show rmon events** Privileged EXEC mode command displays the RMON event table.

Syntax

show rmon events

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the RMON event table.

Console# show rmon events					
Index	Description	Type	Community	Owner	Last time sent
1	Errors	Log		CLI	Jan 18 2006 23:58:17
2	High Broadcast	Log-Trap	device	Manager	Jan 18 2006 23:59:48

The following table describes significant fields shown in the example:

Field	Description
Index	An index that uniquely identifies the event.
Description	A comment describing this event.
Type	The type of notification that the device generates about this event. Can have the following values: none , log , trap , log-trap . In the case of log, an entry is made in the log table for each event. In the case of trap, an SNMP trap is sent to one or more management stations.
Community	If an SNMP trap is to be sent, it is sent to the SNMP community specified by this octet string.
Owner	The entity that configured this event.
Last time sent	The time this entry last generated an event. If this entry has not generated any events, this value is zero.

show rmon log

The **show rmon log** Privileged EXEC mode command displays the RMON log table.

Syntax

show rmon log [event]

Parameters

- *event* — Specifies the event index. (Range: 0-65535)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the RMON log table.

```
Console# show rmon log
Maximum table size: 500
Event      Description      Time
-----  -----
1          Errors           Jan 18 2006 23:48:19
1          Errors           Jan 18 2006 23:58:17
2          High Broadcast   Jan 18 2006 23:59:48

Console# show rmon log
Maximum table size: 500 (800 after reset)
Event      Description      Time
-----  -----
1          Errors           Jan 18 2006 23:48:19
1          Errors           Jan 18 2006 23:58:17
2          High Broadcast   Jan 18 2006 23:59:48
```

The following table describes the significant fields shown in the display:

Field	Description
Event	An index that uniquely identifies the event.
Description	A comment describing this event.
Time	The time this entry was created.

rmon table-size

The **rmon table-size** Global Configuration mode command configures the maximum size of RMON tables. To return to the default configuration, use the **no** form of this command.

Syntax

```
rmon table-size {history entries | log entries}  
no rmon table-size {history | log}
```

Parameters

- **history entries** — Maximum number of history table entries. (Range: 20 -32767)
- **log entries** — Maximum number of log table entries. (Range: 20-32767)

Default Configuration

History table size is 270.

Log table size is 200.

Command Mode

Global Configuration mode

User Guidelines

The configured table size takes effect after the device is rebooted.

Example

The following example configures the maximum RMON history table sizes to 100 entries.

```
Console(config) # rmon table-size history 100
```

19 RADIUS Commands

radius-server host

The **radius-server host** Global Configuration mode command specifies a RADIUS server host. To delete the specified RADIUS host, use the **no** form of this command.

Syntax

```
radius-server host {ip-address | hostname} [auth-port auth-port-number] [timeout timeout] [retransmit retries] [deadtime deadtime] [key key-string] [source source] [priority priority] [usage type]  
no radius-server host {ip-address | hostname}
```

Parameters

- *ip-address* — IP address of the RADIUS server host.
- *hostname* — Hostname of the RADIUS server host. (Range: 1-158 characters)
- *auth-port-number* — Port number for authentication requests. The host is not used for authentication if the port number is set to 0. (Range: 0-65535)
- *timeout* — Specifies the timeout value in seconds. (Range: 1-30)
- *retries* — Specifies the retransmit value. (Range: 1-10)
- *deadtime* — Length of time in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0-2000)
- *key-string* — Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. To specify an empty string, enter "". (Range: 0-128 characters)
- *source* — Specifies the source IP address to use for communication. 0.0.0.0 is interpreted as request to use the IP address of the outgoing IP interface.
- *priority* — Determines the order in which servers are used, where 0 has the highest priority. (Range: 0-65535)
- *type* — Specifies the usage type of the server. Possible values: **login**, **dot.1x**, **wireless** or **all**.

Default Configuration

No RADIUS server host is specified.

The port number for authentication requests is 1812.

The usage type is **all**.

Command Mode

Global Configuration mode

User Guidelines

To specify multiple hosts, multiple **radius-server host** commands can be used.

If no host-specific timeout, retries, deadtime or key-string values are specified, global values apply to each RADIUS server host.

The address type of the source parameter must be the same as the **ip-address** parameter.

Example

The following example specifies a RADIUS server host with IP address 192.168.10.1, authentication request port number 20 and a 20-second timeout period.

```
Console(config) # radius-server host 192.168.10.1 auth-port 20 timeout 20
```

radius-server key

The **radius-server key** Global Configuration mode command sets the authentication and encryption key for all RADIUS communications between the device and the RADIUS daemon. To restore the default configuration, use the **no** form of this command.

Syntax

radius-server key [key-string]

no radius-server key

Parameters

- *key-string* — Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon.
(Range: 0-128 characters)

Default Configuration

The key-string is an empty string.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example defines the authentication and encryption key for all RADIUS communications between the device and the RADIUS daemon.

```
Console(config)# radius-server key enterprise-server
```

radius-server retransmit

The **radius-server retransmit** Global Configuration mode command specifies the number of times the software searches the list of RADIUS server hosts. To reset the default configuration, use the **no** form of this command.

Syntax

radius-server retransmit *retries*

no radius-server retransmit

Parameters

- *retries* — Specifies the retransmit value. (Range: 1-10)

Default Configuration

The software searches the list of RADIUS server hosts 3 times.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the number of times the software searches all RADIUS server hosts to 5 times.

```
console(config)# radius-server retransmit 5
```

radius-server source-ip

The **radius-server source-ip** Global Configuration mode command specifies the source IP address used for communication with RADIUS servers. To restore the default configuration, use the **no** form of this command.

Syntax

radius-server source-ip *source*

no radius-source-ip *source*

Parameters

- *source* — Specifies a valid source IP address.

Default Configuration

The source IP address is the IP address of the outgoing IP interface.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the source IP address used for communication with all RADIUS servers to 10.1.1.1.

```
console(config)# radius-server source-ip 10.1.1.1
```

radius-server timeout

The **radius-server timeout** Global Configuration mode command sets the interval during which the device waits for a server host to reply. To restore the default configuration, use the **no** form of this command.

Syntax

```
radius-server timeout timeout  
no radius-server timeout
```

Parameters

- *timeout* — Specifies the timeout value in seconds. (Range: 1-30)

Default Configuration

The timeout value is 3 seconds.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the timeout interval on all RADIUS servers to 5 seconds.

```
Console(config)# radius-server timeout 5
```

radius-server deadtime

The **radius-server deadtime** Global Configuration mode command improves RADIUS response time when servers are unavailable. The command is used to cause the unavailable servers to be skipped. To restore the default configuration, use the **no** form of this command.

Syntax

```
radius-server deadtime deadtime
no rhadius-server deadtime
```

Parameters

- *deadtime* — Length of time in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0-2000)

Default Configuration

The deadtime setting is 0.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets all RADIUS server deadtimes to 10 minutes.

```
Console(config)# radius-server deadtime 10
```

show radius-servers

The **show radius-servers** Privileged EXEC mode command displays the RADIUS server settings.

Syntax

show radius-servers

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays RADIUS server settings.

Console# show radius-servers								
IP address	Port Auth	TimeOut	Retransmit	DeadTime	Source IP	Priority	Usage	
-----	----	-----	-----	-----	-----	-----	-----	-----
172.16.1.1	1645	Global	Global	Global	-	1	All	
172.16.1.2	1645	11	8	Global	Global	2	All	
 Global values								

TimeOut: 3								
Retransmit: 3								
Deadtime: 0								
Source IP: 172.16.8.1								

RADIUS Commands

20 Web Server Commands

ip http server

The **ip http server** Global Configuration mode command enables configuring the device from a browser. To disable this function, use the **no** form of this command.

Syntax

```
ip http server  
no ip http server
```

Default Configuration

HTTP server is enabled.

Command Mode

Global Configuration mode

User Guidelines

Only a user with access level 15 can use the Web server.

Example

The following example enables configuring the device from a browser.

```
Console(config)# ip http server
```

ip http port

The **ip http port** Global Configuration mode command specifies the TCP port to be used by the Web browser interface. To return to the default configuration, use the **no** form of this command.

Syntax

```
ip http port port-number
```

no ip http port

Parameters

- *port-number* — Port number for use by the HTTP server. (Range: 0-65535)

Default Configuration

The default port number is 80.

Command Mode

Global Configuration mode

User Guidelines

Use the **crypto certificate generate** Global Configuration mode command to generate an HTTPS certificate.

Specifying 0 as the port number effectively disables HTTP access to the device.

Example

The following example configures the http port number to 100.

```
Console(config)# ip http port 100
```

ip http exec-timeout

The **ip http exec-timeout** command allows users to define the interval that the system waits for user input in http sessions before automatic logoff. To return to default, use the **no** form of this command.

Syntax

ip http exec-timout *minutes [seconds]*

no ip http exec-timout

Parameters

- *minutes* — Specifies the number of minutes to wait.
- *seconds* — Specifies the number of seconds to wait.

Default Configuration

The default timeout is 10 minutes.

Command Mode

Global Configuration mode

User Guidelines

This command also configures the exec-timeout for HTTPS in case the the HTTPS timeout was not set. To specify no timeout, enter the ip https exec-timeout 0 0 command.

ip https server

The **ip https server** Global Configuration mode command enables configuring the device from a secured browser. To return to the default configuration, use the **no** form of this command.

Syntax

ip https server

no ip https server

Default Configuration

Disabled.

Command Mode

Global Configuration mode

User Guidelines

Use the **crypto certificate generate** Global Configuration mode command to generate an HTTPS certificate.

Example

The following example enables configuring the device from a secured browser.

```
Console(config)# ip https server
```

ip https port

The **ip https port** Global Configuration mode command specifies the TCP port used by the server to configure the device through the Web browser. To return to the default configuration, use the **no** form of this command.

Syntax

ip https port *port-number*

no ip https port

Parameters

- *port-number* — Port number to be used by the HTTP server. (Range: 0-65535)

Default Configuration

The default port number is 443.

Command Mode

Global Configuration mode

User Guidelines

Specifying 0 as the port number effectively disables HTTP access to the device.

Example

The following example configures the https port number to 100.

```
Console(config)# ip https port 100
```

ip https exec-timeout

The **ip https exec-timeout** command allows users to define the interval that the system waits for user input in https sessions before automatic logoff. To return to default, use the **no** form of this command.

Syntax

ip https exec-timout *minutes [seconds]*

no ip https exec-timout

Parameters

- *minutes* — Specifies the number of minutes to wait.
- *seconds* — Specifies the number of seconds to wait.

Default Configuration

The default timeout is 10 minutes.

Command Mode

Global Configuration mode

User Guidelines

To specify no timeout, enter the ip https exec-timeout 0 0 command.

crypto certificate generate

The **crypto certificate generate** Global Configuration mode command generates a self-signed HTTPS certificate.

Syntax

crypto certificate [number] generate [key-generate length] [cn common- name] [ou organization-unit] [or organization] [loc location] [st state] [cu country] [duration days]

Parameters

- *number* — Specifies the certificate number. (Range: 1-2)
- **key-generate** — Regenerate the SSL RSA key.
- *length* — Specifies the SSL RSA key length. (Range: 512-2048)
- *common- name* — Specifies the fully qualified URL or IP address of the device. (Range: 1-64)
- *organization* — Specifies the organization name. (Range: 1-64)
- *organization-unit* — Specifies the organization-unit or department name.(Range: 1-64)
- *location* — Specifies the location or city name. (Range: 1-64)
- *state* — Specifies the state or province name. (Range: 1-64)

- *country* — Specifies the country name. (Range: 2-2)
- *days* — Specifies number of days certification is valid. (Range: 30-3650)

Default Configuration

The Certificate and SSL's RSA key pairs do not exist.

If no certificate number is specified, the default certificate number is 1.

If no RSA key length is specified, the default length is 1024.

If no URL or IP address is specified, the default common name is the lowest IP address of the device at the time that the certificate is generated.

If the number of days is not specified, the default period of time that the certification is valid is 365 days.

Command Mode

Global Configuration mode

User Guidelines

The command is not saved in the device configuration; however, the certificate and keys generated by this command are saved in the private configuration (which is never displayed to the user or backed up to another device).

Use this command to generate a self-signed certificate for the device.

If the RSA keys do not exist, parameter **key-generate** must be used.

Example

The following example regenerates an HTTPS certificate.

```
Console(config)# crypto certificate 1 generate key-generate
```

crypto certificate request

The **crypto certificate request** Privileged EXEC mode command generates and displays certificate requests for HTTPS.

Syntax

```
crypto certificate number request [cn common-name][ou organization-unit] [or organization] [loc location] [st state] [cu country]
```

Parameters

- *number* — Specifies the certificate number. (Range: 1-2)
- *common-name* — Specifies the fully qualified URL or IP address of the device. (Range: 1- 64)
- *organization-unit* — Specifies the organization-unit or department name. (Range: 1- 64)
- *organization* — Specifies the organization name. (Range: 1-64)
- *location* — Specifies the location or city name. (Range: 1-64)
- *state* — Specifies the state or province name. (Range: 1-64)
- *country* — Specifies the country name. (Range: 1-2)

Default Configuration

There is no default configuration for this command.

Command Mode

Privileged EXEC mode

User Guidelines

Use this command to export a certificate request to a Certification Authority. The certificate request is generated in Base64-encoded X.509 format.

Before generating a certificate request you must first generate a self-signed certificate using the **crypto certificate generate** Global Configuration mode command. Be aware that you have to reenter the certificate fields.

After receiving the certificate from the Certification Authority, use the **crypto certificate import** Global Configuration mode command to import the certificate into the device. This certificate replaces the self-signed certificate.

Example

The following example generates and displays a certificate request for HTTPS.

```
Console# crypto certificate 1 request
-----BEGIN CERTIFICATE REQUEST-----
MIwTCCASoCAQAwYjELMAkGA1UEBhMCUFAXCzAJBgNVBAgTAkNDMQswCQYDVQQH
EwRDEMMAoGA1UEChMDZGxkMQwwCgYDVQQLEwNkbGQxCzAJBgNVBAMTAmxkMRAw
DgKoZIhvcNAQkBFgFsmIGfMA0GCSqGSIb3DQEBAQUAA4GNADCBiQKBgQC8ecwQ
HdML0831i0fh/F0MV/Kib6Sz5p+3nUUembfHp/igVPmFM+1nbqtDekb2ymCu6K
aKvEbVLF9F2LmM7VPjDBb9bb4jnxkvwW/wzDLvW2rsy5NPmH1QV1+8Ubx3GyCm
/oW93BSOFwxwEsP58kf+sPYPy+/8wmmoNtDwIDAQABoB8wHQYJKoZIhvcNAQkH
MRDjEyMwgICCAgICAICAgIMA0GCSqGSIb3DQEBAUAA4GBAGb8UgIx7rB05m+2
m5ZZPhIwl8ARSPXwhVdJexFjbmvcacqjPG8pIiRV6LkxryGF2bVU3jKEipcza
g+uNpyTkDt3ZVU72pjz/fa8TF0n3
-----END CERTIFICATE REQUEST-----
CN= router.gm.com
O= General Motors
C= US
```

crypto certificate import

The **crypto certificate import** Global Configuration mode command imports a certificate signed by the Certification Authority for HTTPS.

Syntax

```
crypto certificate number import
```

Parameters

- *number* — Specifies the certificate number. (Range: 1-2)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Use this command to enter an external certificate (signed by Certification Authority) to the device. To end the session, enter an empty line.

The imported certificate must be based on a certificate request created by the **crypto certificate request** Privileged EXEC mode command.

If the public key found in the certificate does not match the device's SSL RSA key, the command fails.

This command is not saved in the device configuration; however, the certificate imported by this command is saved in the private configuration (which is never displayed to the user or backed up to another device).

Example

The following example imports a certificate signed by Certification Authority for HTTPS.

```
Console(config)# crypto certificate 1 import

-----BEGIN CERTIFICATE-----
dHmUgUm9vdCBDZXJ0aWZpZXIwXDANBgkqhkiG9w0BAQEFAANLADBIkEAp4HS
nnH/xQSGA2ffkRBwU2XIxb7n8VPsTm1xyJ1t11a1GaqchfMqqe0kmfhcoHSWr
yf1FpD0MWOTgDAwIDAQABo4IBojCCA2Z4wEwYJKwYBBAGCNxQCBAYeBABDAEEw
CwR0PBAQDAGFGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVR0OBBYEFAf4MT9BRD47
ZvKBAEL9Ggp+6MIIBNgYDVR0fBIIBLTCCASkwgdKggc+ggcyGgc1sZGFwOi8v
L0VByb3h5JTIwU29mdHdcmUlMjBSB290JTIwQ2VydGlmaWVyLENOPXNlcnZl
-----END CERTIFICATE-----

Certificate imported successfully.
Issued to: router.gm.com
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
```

ip https certificate

The **ip https certificate** Global Configuration mode command configures the active certificate for HTTPS. To return to the default configuration, use the **no** form of this command.

Syntax

```
ip https certificate number
no ip https certificate
```

Parameters

- *number* — Specifies the certificate number. (Range: 1-2)

Default Configuration

Certificate number 1.

Command Mode

Global Configuration mode

User Guidelines

The **crypto certificate generate** command should be used to generate HTTPS certificates.

Example

The following example configures the active certificate for HTTPS.

```
Console(config)# ip https certificate 1
```

show crypto certificate mycertificate

The **show crypto certificate mycertificate** Privileged EXEC mode command displays the SSH certificates of the device.

Syntax

show crypto certificate mycertificate [number]

Parameters

- *number* — Specifies the certificate number. (Range: 1-2)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the certificate.

```
Console# show crypto certificate mycertificate 1
-----BEGIN CERTIFICATE-----
dHmUgUm9vdCBDZXJ0aWZpZXIwXDANBgkqhkiG9w0BAQEFAANLADBIKEAp4HS
nnH/xQSGA2ffkRBwU2XIxb7n8VPsTm1xyJ1t11a1GaqchfMqqe0kmfhcoHSWr
yf1FpD0MWOTgDAwIDAQABo4IBojCCA24wEwYJKwYBBAGCNxQCBAYeBABDAEEw
CwR0PBAQDAgFGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVR0OBYEFAf4MT9BRD47
ZvKBAEL9Ggp+6MIIBNgYDVR0fBIIIBLTCCASKwgdKggc+ggcyGgcclsZGFwOi8v
L0VByb3h5JTIwU29mdHdcmUlMjBSb290JTIwQ2VydGlmaWVyLENOPXNlcnZl
-----END CERTIFICATE-----

Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
```

show ip http

The **show ip http** Privileged EXEC mode command displays the HTTP server configuration.

Syntax

show ip http

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the HTTP server configuration.

```
Console# show ip http
HTTP server enabled. Port: 80
```

show ip https

The **show ip https** Privileged EXEC mode command displays the HTTPS server configuration.

Syntax

```
show ip https
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the HTTP server configuration.

```
Console# show ip https
HTTPS server enabled. Port: 443

Certificate 1 is active
Issued by: www.verisign.com
Valid from: 8/9/2004 to 8/9/2005
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
```

```
Certificate 2 is inactive
Issued by: self-signed
Valid from: 8/9/2004 to 8/9/2005
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: 1873B936 88DC3411 BC8932EF 782134BA
```

Web Server Commands

21 SNMP Commands

snmp-server community

The **snmp-server community** Global Configuration mode command configures the community access string to permit access to the SNMP protocol. To remove the specified community string, use the **no** form of this command.

Syntax

```
snmp-server community community [ro | rw | su] [ip-address] [view view-name]  
snmp-server community-group community group-name [ip-address] [type {router |  
oob}]  
no snmp-server community community [ip-address]
```

Parameters

- *community* — Community string that acts like a password and permits access to the SNMP protocol.
(Range: 1-20 characters)
- **ro** — Indicates read-only access (default).
- **rw** — Indicates read-write access.
- **su** — Indicates SNMP administrator access.
- *ip-address* — Specifies the IP address of the management station.
- *group-name* — Specifies the name of a previously defined group. A group defines the objects available to the community. (Range: 1-30 characters)
- *view-name* — Specifies the name of a previously defined view. The view defines the objects available to the community. (Range: 1-30 characters).

Default Configuration

No communities are defined.

Command Mode

Global Configuration mode

User Guidelines

The **view-name** parameter cannot be specified for **su**, which has access to the whole MIB.

The **view-name** parameter can be used to restrict the access rights of a community string. When it is specified:

An internal security name is generated.

The internal security name for SNMPv1 and SNMPv2 security models is mapped to an internal group name.

The internal group name for SNMPv1 and SNMPv2 security models is mapped to a view-name (read-view and notify-view always, and for **rw** for write-view also)

The **group-name** parameter can also be used to restrict the access rights of a community string. When it is specified:

An internal security name is generated.

The internal security name for SNMPv1 and SNMPv2 security models is mapped to the group name.

Example

The following example defines community access string **public** to permit administrative access to SNMP protocol at an administrative station with IP address 192.168.1.20.

```
Console(config) # snmp-server community public su 192.168.1.20
```

snmp-server view

The **snmp-server view** Global Configuration mode command creates or updates a Simple Network Management Protocol (SNMP) server view entry. To remove a specified SNMP server view entry, use the **no** form of this command.

Syntax

```
snmp-server view view-name oid-tree {included | excluded}  
no snmp-server view view-name [oid-tree]
```

Parameters

- *view-name* — Specifies the label for the view record that is being created or updated. The name is used to reference the record. (Range: 1-30 characters)

- *oid-tree* — Specifies the object identifier of the ASN.1 subtree to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as system. Replace a single subidentifier with the asterisk (*) wildcard to specify a subtree family; for example 1.3.*.4.
- **included** — Indicates that the view type is included.
- **excluded** — Indicates that the view type is excluded.

Default Configuration

No view entry exists.

Command Mode

Global Configuration mode

User Guidelines

This command can be entered multiple times for the same view record.

The number of views is limited to 64.

No check is made to determine that a MIB node corresponds to the "starting portion" of the OID until the first wildcard.

Example

The following example creates a view that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interface group.

```
Console(config)# snmp-server view user-view system included
Console(config)# snmp-server view user-view system.7 excluded
Console(config)# snmp-server view user-view ifEntry.*.1 included
```

snmp-server group

The **snmp-server group** Global Configuration mode command configures a new Simple Management Protocol (SNMP) group or a table that maps SNMP users to SNMP views. To remove a specified SNMP group, use the **no** form of this command.

Syntax

```
snmp-server group groupname {v1 | v2 | v3 {noauth | auth | priv} [notify notifyview]}
[read readview] [write writeview]
```

no snmp-server group *groupname* {v1 | v2 | v3 [noauth | auth | priv]}

Parameters

- *groupname*—Specifies the name of the group (Range: 1-30 characters).
- **v1** — Indicates the SNMP Version 1 security model.
- **v2** — Indicates the SNMP Version 2 security model.
- **v3** — Indicates the SNMP Version 3 security model.
- **noauth** — Indicates no authentication of a packet. Applicable only to the SNMP Version 3 security model.
- **auth** — Indicates authentication of a packet without encrypting it. Applicable only to the SNMP Version 3 security model.
- **priv** — Indicates authentication of a packet with encryption. Applicable only to the SNMP Version 3 security model.
- *name* — Specifies the context of a packet. The following context is supported: Router. If the context name is unspecified, all contexts are defined.
- *readview* — Specifies a string that is the name of the view that enables only viewing the contents of the agent. If unspecified, all objects except for the community-table and SNMPv3 user and access tables are available.
- *writeview* — Specifies a string that is the name of the view that enables entering data and configuring the contents of the agent. If unspecified, nothing is defined for the write view.
- *notifyview* — Specifies a string that is the name of the view that enables specifying an inform or a trap. If unspecified, nothing is defined for the notify view. Applicable only to the SNMP Version 3 security model.

Default Configuration

No group entry exists.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example attaches a group called user-group to SNMPv3 and assigns to the group the privacy security level and read access rights to a view called user-view.

```
Console(config)# snmp-server group user-group v3 priv read user-view
```

snmp-server user

The **snmp-server user** Global Configuration mode command configures a new SNMP Version 3 user. To remove a user, use the **no** form of this command.

Syntax

```
snmp-server user username groupname [remote engineid-string] [auth-md5 password |  

auth-sha password | auth-md5-key md5-des-keys | auth-sha-key sha-des-keys]  
  

no snmp-server user username [remote engineid-string]
```

Parameters

- *username* — Specifies the name of the user on the host that connects to the agent. (Range: 1-30 characters)
- *groupname* — Specifies the name of the group to which the user belongs. (Range: 1-30 characters)
- *engineid-string* — Specifies the engine ID of the remote SNMP entity to which the user belongs. The engine ID is a concatenated hexadecimal string. Each byte in the hexadecimal character string is two hexadecimal digits. Each byte can be separated by a period or colon. (Range: 5-32 characters)
- **auth-md5 password** — Indicates the HMAC-MD5-96 authentication level. The user should enter a password for authentication and generation of a DES key for privacy. (Range: 1-32 characters)
- **auth-sha password** — Indicates the HMAC-SHA-96 authentication level. The user should enter a password for authentication and generation of a DES key for privacy. (Range: 1-32 characters)
- **auth-md5-key md5-des-keys** — Indicates the HMAC-MD5-96 authentication level. The user should enter a concatenated hexadecimal string of the MD5 key (MSB) and the privacy key (LSB). If authentication is only required, 16 bytes should be entered; if authentication and privacy are required, 32 bytes should be entered. Each byte in the hexadecimal character string is two hexadecimal digits. Each byte can be separated by a period or colon. (16 or 32 bytes)
- **auth-sha-key sha-des-keys** — Indicates the HMAC-SHA-96 authentication level. The user should enter a concatenated hexadecimal string of the SHA key (MSB) and the privacy key (LSB). If authentication is only required, 20 bytes should be entered;

if authentication and privacy are required, 36 bytes should be entered. Each byte in the hexadecimal character string is two hexadecimal digits. Each byte can be separated by a period or colon. (20 or 36 bytes)

Default Configuration

No group entry exists.

Command Mode

Global Configuration mode

User Guidelines

If auth-md5 or auth-sha is specified, both authentication and privacy are enabled for the user.

When a **show running-config** Privileged EXEC mode command is entered, a line for this user will not be displayed. To see if this user has been added to the configuration, type the **show snmp users** Privileged EXEC mode command.

An SNMP EngineID has to be defined to add SNMP users to the device. Changing or removing the SNMP EngineID value deletes SNMPv3 users from the device's database.

The remote engineid designates the remote management station and should be defined to enable the device to receive informs.

Example

The following example configures an SNMPv3 user John in a group called user-group.

```
Console(config)# snmp-server user John user-group
```

snmp-server engineID local

The **snmp-server engineID local** Global Configuration mode command specifies the Simple Network Management Protocol (SNMP) engineID on the local device. To remove the configured engine ID, use the **no** form of this command.

Syntax

```
snmp-server engineID local {engineid-string | default}  
no snmp-server engineID local
```

Parameters

- *engineid-string*—Specifies a character string that identifies the engine ID. (Range: 5-32 characters)
- **default**—The engine ID is created automatically based on the device MAC address.

Default Configuration

The engine ID is not configured.

If SNMPv3 is enabled using this command, and the default is specified, the default engine ID is defined per standard as:

First 4 octets — first bit = 1, the rest is IANA Enterprise number = 674.

Fifth octet — set to 3 to indicate the MAC address that follows.

Last 6 octets — MAC address of the device.

Command Mode

Global Configuration mode

User Guidelines

To use SNMPv3, you have to specify an engine ID for the device. You can specify your own ID or use a default string that is generated using the MAC address of the device.

If the SNMPv3 engine ID is deleted or the configuration file is erased, SNMPv3 cannot be used. By default, SNMPv1/v2 are enabled on the device. SNMPv3 is enabled only by defining the Local Engine ID.

If you want to specify your own ID, you do not have to specify the entire 32-character engine ID if it contains trailing zeros. Specify only the portion of the engine ID up to the point where just zeros remain in the value. For example, to configure an engine ID of 12340000000000000000000000000000, you can specify `snmp-server engineID local 1234`.

Since the engine ID should be unique within an administrative domain, the following is recommended:

For a this device, use the `default` keyword to configure the engine ID.

Changing the value of the engine ID has the following important side-effect. A user's password (entered on the command line) is converted to an MD5 or SHA security digest. This digest is based on both the password and the local engine ID. The user's command line password is then destroyed, as required by RFC 2274. As a result, the security digests of SNMPv3 users become invalid if the local value of the engine ID change, and the users will have to be reconfigured.

You cannot specify an engine ID that consists of all 0x0, all 0xF or 0x000000001.

The **show running-config** Privileged EXEC mode command does not display the SNMP engine ID configuration. To see the SNMP engine ID configuration, enter the **snmp-server engineID local** Global Configuration mode command.

Example

The following example enables SNMPv3 on the device and sets the local engine ID of the device to the default value.

```
Console(config) # snmp-server engineID local default
```

snmp-server enable traps

The **snmp-server enable traps** Global Configuration mode command enables the device to send SNMP traps. To disable SNMP traps, use the **no** form of the command.

Syntax

```
snmp-server enable traps  
no snmp-server enable traps
```

Default Configuration

SNMP traps are enabled.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables SNMP traps.

```
Console(config) # snmp-server enable traps
```

snmp-server filter

The **snmp-server filter** Global Configuration mode command creates or updates a Simple Network Management Protocol (SNMP) server filter entry. To remove the specified SNMP server filter entry, use the **no** form of this command.

Syntax

```
snmp-server filter filter-name oid-tree {included | excluded}  
no snmp-server filter filter-name [oid-tree]
```

Parameters

- *filter-name* — Specifies the label for the filter record that is being updated or created. The name is used to reference the record. (Range: 1-30 characters)
- *oid-tree* — Specifies the object identifier of the ASN.1 subtree to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as system. Replace a single subidentifier with the asterisk (*) wildcard to specify a subtree family; for example, 1.3.*.4.
- **included** — Indicates that the filter type is included.
- **excluded** — Indicates that the filter type is excluded.

Default Configuration

No filter entry exists.

Command Mode

Global Configuration mode

User Guidelines

This command can be entered multiple times for the same filter record. Later lines take precedence when an object identifier is included in two or more lines.

Example

The following example creates a filter that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interfaces group.

```
Console(config)# snmp-server filter filter-name system included
Console(config)# snmp-server filter filter-name system.7 excluded
Console(config)# snmp-server filter filter-name ifEntry.*.1 included
```

snmp-server host

The **snmp-server host** Global Configuration mode command specifies the recipient of Simple Network Management Protocol Version 1 or Version 2 notifications. To remove the specified host, use the **no** form of this command.

Syntax

```
snmp-server host {ip-address | hostname} community-string [traps | informs] [1 | 2]
[udp-port port] [filter filtername] [timeout seconds] [retries retries]

no snmp-server host {ip-address | hostname} [traps | informs]
```

Parameters

- *ip-address* — Specifies the IP address of the host (targeted recipient).
- *hostname* — Specifies the name of the host. (Range:1-158 characters)
- *community-string* — Specifies a password-like community string sent with the notification operation. (Range: 1-20)
- **traps** — Indicates that SNMP traps are sent to this host. If unspecified, SNMPv2 traps are sent to the host.
- **informs** — Indicates that SNMP informs are sent to this host. Not applicable to SNMPv1.
- **1** — Indicates that SNMPv1 traps will be used.
- **2** — Indicates that SNMPv2 traps will be used. If
- *port*—Specifies the UDP port of the host to use. If unspecified, the default UDP port number is 162. (Range:1-65535)
- *filtername* — Specifies a string that defines the filter for this host. If unspecified, nothing is filtered. (Range: 1-30 characters)
- *seconds* — Specifies the number of seconds to wait for an acknowledgment before resending informs. If unspecified, the default timeout period is 15 seconds. (Range: 1-300)
- *retries* — Specifies the maximum number of times to resend an inform request. If unspecified, the default maximum number of retries is 3. (Range: 0-255)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

When configuring an SNMPv1 or SNMPv2 notification recipient, a notification view for that recipient is automatically generated for all the MIB.

When configuring an SNMPv1 notification recipient, the **Inform** option cannot be selected.

If a trap and inform are defined on the same target, and an inform was sent, the trap is not sent.

Example

The following example enables SNMP traps for host 10.1.1.1 with community string "management" using SNMPv2.

```
Console(config)# snmp-server host 10.1.1.1 management 2
```

snmp-server v3-host

The **snmp-server v3-host** Global Configuration mode command specifies the recipient of Simple Network Management Protocol Version 3 notifications. To remove the specified host, use the **no** form of this command.

Syntax

```
snmp-server v3-host {ip-address | hostname} username [traps | informs] {noauth | auth | priv} [udp-port port] [filter filtername] [timeout seconds] [retries retries]
no snmp-server host {ip-address | hostname} username [traps | informs]
```

Parameters

- *ip-address* — Specifies the IP address of the host (targeted recipient).
- *hostname* — Specifies the name of the host. (Range:1-158 characters)
- *username* — Specifies the name of the user to use to generate the notification. (Range: 1-24)
- **traps** — Indicates that SNMP traps are sent to this host.
- **informs** — Indicates that SNMP informs are sent to this host.
- **noauth** — Indicates no authentication of a packet.

- **auth** — Indicates authentication of a packet without encrypting it.
- **priv** — Indicates authentication of a packet with encryption.
- **port** — Specifies the UDP port of the host to use. If unspecified, the default UDP port number is 162.
(Range: 1-65535)
- **filtername**—Specifies a string that defines the filter for this host. If unspecified, nothing is filtered.
(Range: 1-30 characters)
- **seconds** — Specifies the number of seconds to wait for an acknowledgment before resending informs. If unspecified, the default timeout period is 15 seconds. (Range: 1-300)
- **retries** — Specifies the maximum number of times to resend an inform request. If unspecified, the default maximum number of retries is 3. (Range: 0-255)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

A user and notification view are not automatically created. Use the **snmp-server user**, **snmp-server group** and **snmp-server view** Global Configuration mode commands to generate a user, group and notify group, respectively.

Example

The following example configures an SNMPv3 host.

```
Console(config)# snmp-server v3-host 192.168.0.20 john noauth
```

snmp-server trap authentication

The **snmp-server trap authentication** Global Configuration mode command enables the device to send SNMP traps when authentication fails. To disable SNMP failed authentication traps, use the **no** form of this command.

Syntax

snmp-server trap authentication

no snmp-server trap authentication

Default Configuration

SNMP failed authentication traps are enabled.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables SNMP failed authentication traps.

```
Console(config)# snmp-server trap authentication
```

snmp-server contact

The **snmp-server contact** Global Configuration mode command configures the system contact (sysContact) string. To remove system contact information, use the **no** form of the command.

Syntax

snmp-server contact *text*

no snmp-server contact

Parameters

- *text* — Specifies the string that describes system contact information. (Range: 1-160 characters)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Do not include spaces in the text string or place text that includes spaces inside quotation marks.

Example

The following example configures the system contact point called **Intel_Technical_Support**.

```
console(config) # snmp-server contact Intel_Technical_Support
```

snmp-server location

The **snmp-server location** Global Configuration mode command configures the system location string. To remove the location string, use the **no** form of this command.

Syntax

snmp-server location *text*

no snmp-server location

Parameters

- *text* — Specifies a string that describes system location information. (Range: 1-160 characters)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Do not include spaces in the text string or place text that includes spaces inside quotation marks.

Example

The following example defines the device location as **New_York**.

```
Console(config)# snmp-server location New_York
```

snmp-server set

The **snmp-server set** Global Configuration mode command defines the SNMP MIB value.

Syntax

snmp-server set *variable-name name1 value1 [name2 value2 ...]*

Parameters

- *variable-name* — MIB variable name (Range 1-160 characters).
- *name value* — List of name and value pairs. In the case of scalar MIBs, only a single pair of name values. In the case of an entry in a table, at least one pair of name and value followed by one or more fields (Range 1-160 characters).

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Although the CLI can set any required configuration, there might be a situation where a SNMP user sets a MIB variable that does not have an equivalent command. In order to generate configuration files that support those situations, the **snmp-server set** command is used.

This command is case-sensitive.

Example

The following example configures the scalar MIB sysName with the value **Intel**.

```
Console(config)# snmp-server set sysName sysname Intel
```

show snmp

The **show snmp** Privileged EXEC mode command displays the SNMP status.

Syntax

show snmp

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the SNMP communications status.

Console# show snmp			
Community-String	Community-Access	View name	IP address
-----	-----	-----	-----
public	read only	user-view	All
private	read write	Default	172.16.1.1
private	su	DefaultSuper	172.17.1.1
Community-string			

public		user-group	all
Traps are enabled.			
Authentication trap is enabled.			

Version 1,2 notifications							
Target Address	Type	Community	Version	UDP Port	Filter Name	TO Sec	Retries
-----	-----	-----	-----	---	-----	---	-----
192.122.173.42	Trap	public	2	162		15	3
192.122.173.42	Inform	public	2	162		15	3
Version 3 notifications							
Target Address	Type	Username	Security Level	UDP Port	Filter Name	TO Sec	Retries
-----	-----	-----	-----	---	-----	---	-----
192.122.173.42	Inform	Bob	Priv	162		15	3
System Contact: Robert							
System Location: Marketing							

The following table describes the significant fields shown in the display.

Field	Description
Community-string	Community access string to permit access to the SNMP protocol.
Community-access	Type of access - read-only, read-write, super access
IP Address	Management station IP Address.
Trap-Rec-Address	Targeted Recipient
Trap-Rec-Community	Statistics sent with the notification operation.
Version	SNMP version for the sent trap 1 or 2.

show snmp engineid

The **show snmp engineID** Privileged EXEC mode command displays the ID of the local Simple Network Management Protocol (SNMP) engine. Syntax

show snmp engineID

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the SNMP engine ID.

```
Console# show snmp engineID  
Local SNMP engineID: 08009009020C0B099C075878
```

show snmp views

The **show snmp views** Privileged EXEC mode command displays the configuration of views.

Syntax

```
show snmp views [viewname]
```

Parameters

- *viewname* — Specifies the name of the view. (Range: 1-30)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the configuration of views.

Name	OID Tree	Type
user-view	1.3.6.1.2.1.1	Included
user-view	1.3.6.1.2.1.1.7	Excluded
user-view	1.3.6.1.2.1.2.2.1.*.1	Included

show snmp groups

The **show snmp groups** Privileged EXEC mode command displays the configuration of groups.

Syntax

show snmp groups [groupname]

Parameters

- *groupname*—Specifies the name of the group. (Range: 1-30)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the configuration of views.

Console# show snmp groups					
Name	Security			Views	
	Model	Level	Read	Write	Notify
user-group	V3	priv	Default	""	""
managers-group	V3	priv	Default	Default	""
managers-group	V3	priv	Default	""	""

The following table describes significant fields shown above.

Field		Description
Name		Name of the group.
Security Model		SNMP model in use (v1, v2 or v3).
Security Level		Authentication of a packet with encryption. Applicable only to SNMP v3 security.
Views	Read	Name of the view that enables only viewing the contents of the agent. If unspecified, all objects except the community-table and SNMPv3 user and access tables are available.
	Write	Name of the view that enables entering data and managing the contents of the agent.
	Notify	Name of the view that enables specifying an inform or a trap.

show snmp filters

The **show snmp filters** Privileged EXEC mode command displays the configuration of filters.

Syntax

show snmp filters [filtername]

Parameters

- *filtername*—Specifies the name of the filter. (Range: 1-30)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the configuration of filters.

Console# show snmp filters		
Name	OID Tree	Type
user-filter	1.3.6.1.2.1.1	Included
user-filter	1.3.6.1.2.1.1.7	Excluded
user-filter	1.3.6.1.2.1.2.2.1.*.1	Included

show snmp users

The **show snmp users** Privileged EXEC mode command displays the configuration of users.

Syntax

show snmp users [username]

Parameters

username—Specifies the name of the user. (Range: 1-30)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.Example

The following example displays the configuration of users.

Console# show snmp users			
Name	Group name	Auth Method	Remote
John	user-group	md5	
John	user-group	md5	08009009020C0B099C075879

22 Spanning-Tree Commands

spanning-tree

The **spanning-tree** Global Configuration mode command enables spanning-tree functionality. To disable the spanning-tree functionality, use the **no** form of this command.

Syntax

```
spanning-tree  
no spanning-tree
```

Default Configuration

Spanning-tree is enabled.

Command Modes

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables spanning-tree functionality.

```
Console(config)# spanning-tree
```

spanning-tree mode

The **spanning-tree mode** Global Configuration mode command configures the spanning-tree protocol. To restore the default configuration, use the **no** form of this command.

Syntax

```
spanning-tree mode {stp | rstp| mstp}
```

no spanning-tree mode

Parameters

- **stp** — Indicates that the Spanning Tree Protocol (STP) is enabled.
- **rstp** — Indicates that the Rapid Spanning Tree Protocol (RSTP) is enabled.
- **mstp** — Indicates that the Multiple Spanning Tree Protocol (RSTP) is enabled.

Default Configuration

STP is enabled.

Command Modes

Global Configuration mode

User Guidelines

In RSTP mode, the device uses STP when the neighbor device uses STP.

In MSTP mode, the device uses RSTP when the neighbor device uses RSTP and uses STP when the neighbor device uses STP.

Example

The following example configures the spanning-tree protocol to RSTP.

```
console(config)# spanning-tree mode rstp
```

spanning-tree forward-time

The **spanning-tree forward-time** Global Configuration mode command configures the spanning-tree bridge forward time, which is the amount of time a port remains in the listening and learning states before entering the forwarding state. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree forward-time seconds

no spanning-tree forward-time

Parameters

- *seconds* — Time in seconds. (Range: 4-30)

Default Configuration

The default forwarding time for the IEEE Spanning Tree Protocol (STP) is 15 seconds.

Command Modes

Global Configuration mode

User Guidelines

When configuring the forwarding time, the following relationship should be kept:

$$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$$

Example

The following example configures the spanning tree bridge forwarding time to 25 seconds.

```
Console(config)# spanning-tree forward-time 25
```

spanning-tree hello-time

The **spanning-tree hello-time** Global Configuration mode command configures the spanning tree bridge hello time, which is how often the device broadcasts hello messages to other devices. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree hello-time *seconds*

no spanning-tree hello-time

Parameters

- *seconds* — Time in seconds. (Range: 1-10)

Default Configuration

The default hello time for IEEE Spanning Tree Protocol (STP) is 2 seconds.

Command Modes

Global Configuration mode

User Guidelines

When configuring the hello time, the following relationship should be kept:

$$\text{Max-Age} \geq 2 * (\text{Hello-Time} + 1)$$

Example

The following example configures spanning tree bridge hello time to 5 seconds.

```
Console(config) # spanning-tree hello-time 5
```

spanning-tree max-age

The **spanning-tree max-age** Global Configuration mode command configures the spanning tree bridge maximum age. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree max-age *seconds*

no spanning-tree max-age

Parameters

- *seconds* — Time in seconds. (Range: 6-40)

Default Configuration

The default maximum age for IEEE Spanning Tree Protocol (STP) is 20 seconds.

Command Modes

Global Configuration mode

User Guidelines

When configuring the maximum age, the following relationships should be kept:

$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$

$\text{Max-Age} \geq 2 * (\text{Hello-Time} + 1)$

Example

The following example configures the spanning tree bridge maximum-age to 10 seconds.

```
Console(config)# spanning-tree max-age 10
```

spanning-tree priority

The **spanning-tree priority** Global Configuration mode command configures the spanning tree priority of the device. The priority value is used to determine which bridge is elected as the root bridge. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree priority *priority*

no spanning-tree priority

Parameters

- *priority* — Priority of the bridge. (Range: 0-61440 in steps of 4096)

Default Configuration

The default bridge priority for IEEE Spanning Tree Protocol (STP) is 32768.

Command Modes

Global Configuration mode

User Guidelines

The bridge with the lowest priority is elected as the root bridge.

Example

The following example configures spanning tree priority to 12288.

```
Console(config)# spanning-tree priority 12288
```

spanning-tree disable

The **spanning-tree disable** Interface Configuration mode command disables spanning tree on a specific port. To enable spanning tree on a port, use the **no** form of this command.

Syntax

```
spanning-tree disable  
no spanning-tree disable
```

Default Configuration

Spanning tree is enabled on all ports.

Command Modes

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example disables spanning-tree on Ethernet port 5.

```
Console(config)# interface ethernet ext.5  
Console(config-if)# spanning-tree disable
```

spanning-tree cost

The **spanning-tree cost** Interface Configuration mode command configures the spanning tree path cost for a port. To restore the default configuration, use the **no** form of this command.

Syntax

```
spanning-tree cost cost  
no spanning-tree cost
```

Parameters

- *cost* — Path cost of the port (Range: 1-200,000,000)

Default Configuration

Default path cost is determined by port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
Gigabit Ethernet (1000 Mbps)	20,000	4
Fast Ethernet (100 Mbps)	200,000	19
Ethernet (10 Mbps)	2,000,000	100

Command Modes

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The path cost method is configured using the **spanning-tree pathcost method** Global Configuration mode command.

Example

The following example configures the spanning-tree cost on Ethernet port 15 to 35000.

```
Console(config)# interface ethernet ext.15
Console(config-if)# spanning-tree cost 35000
```

spanning-tree port-priority

The **spanning-tree port-priority** Interface Configuration mode command configures port priority. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree port-priority *priority*

no spanning-tree port-priority

Parameters

- *priority* — The priority of the port. (Range: 0-240 in multiples of 16)

Default Configuration

The default port priority for IEEE Spanning TreeProtocol (STP) is 128.

Command Modes

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the spanning priority on Ethernet port 15 to 96.

```
Console(config)# interface ethernet ext.15
Console(config-if)# spanning-tree port-priority 96
```

spanning-tree portfast

The **spanning-tree portfast** Interface Configuration mode command enables PortFast mode. In PortFast mode, the interface is immediately put into the forwarding state upon linkup without waiting for the standard forward time delay. To disable PortFast mode, use the **no** form of this command.

Syntax

spanning-tree portfast [auto]

no spanning-tree portfast

Parameters

- **auto** — Specifies that the software waits for 3 seconds (With no BPDUs received on the interface) before putting the interface into the PortFast mode.

Default Configuration

PortFast mode is disabled.

Command Modes

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

This feature should be used only with interfaces connected to end stations. Otherwise, an accidental topology loop could cause a data packet loop and disrupt device and network operations.

Example

The following example enables PortFast on Ethernet port 15.

```
Console(config)# interface ethernet ext.15
Console(config-if)# spanning-tree portfast
```

spanning-tree link-type

The **spanning-tree link-type** Interface Configuration mode command overrides the default link-type setting determined by the duplex mode of the port and enables Rapid Spanning Tree Protocol (RSTP) transitions to the forwarding state. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree link-type {point-to-point | shared}

no spanning-tree spanning-tree link-type

Parameters

- **point-to-point** —Indicates that the port link type is point-to-point.
- **shared** — Indicates that the port link type is shared.

Default Configuration

The device derives the port link type from the duplex mode. A full-duplex port is considered a point-to-point link and a half-duplex port is considered a shared link.

Command Modes

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables shared spanning-tree on Ethernet port 15.

```
Console(config)# interface ethernet ext.15
Console(config-if)# spanning-tree link-type shared
```

spanning-tree pathcost method

The **spanning-tree pathcost method** Global Configuration mode command sets the default path cost method. To return to the default configuration, use the **no** form of this command.

Syntax

spanning-tree pathcost method {long | short}

no spanning-tree pathcost method

Parameters

- *long* — Specifies port path costs with a range of 1-200,000,000 .
- *short* — Specifies port path costs with a range of 0-65,535.

Default Configuration

Short path cost method.

Command Mode

Global Configuration mode

User Guidelines

This command is only operational with the device in Interface mode.

This command applies to all spanning tree instances on the device.

The cost is set using the **spanning-tree cost** command.

Example

The following example sets the default path cost method to **long**.

```
Console(config)# spanning-tree pathcost method long
```

spanning-tree bpdu

The **spanning-tree bpdu** Global Configuration mode command defines BPDU handling when the spanning tree is disabled globally or on a single interface. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree bpdu {filtering | flooding}

no spanning-tree bpdu

Parameters

- **filtering** — Filter BPDU packets when the spanning tree is disabled on an interface.
- **flooding** — Flood BPDU packets when the spanning tree is disabled on an interface.

Default Configuration

The default setting is flooding.

Command Modes

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example defines BPDU packet flooding when the spanning-tree is disabled on an interface.

```
Console(config)# spanning-tree bpdu flooding
```

clear spanning-tree detected-protocols

The **clear spanning-tree detected-protocols** Privileged EXEC mode command restarts the protocol migration process (forces renegotiation with neighboring devices) on all interfaces or on a specified interface.

Syntax

```
clear spanning-tree detected-protocols [ethernet interface | port-channel port-channel-number]
```

Parameters

- *interface* — A valid Ethernet port.
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

This feature should be used only when working in RSTP or MSTP mode.

Example

The following example restarts the protocol migration process on Ethernet port 11.

```
Console# clear spanning-tree detected-protocols ethernet ext.11
```

spanning-tree mst priority

The **spanning-tree mst priority** Global Configuration mode command configures the device priority for the specified spanning-tree instance. To restore the default configuration, use the **no** form of this command.

Syntax

```
spanning-tree mst instance-id priority priority
```

no spanning-tree *mst instance-id priority***Parameters**

- *instance -id*—ID of the spanning -tree instance (Range: 1-15).
- *priority*—Device priority for the specified spanning-tree instance (Range: 0-61440 in multiples of 4096).

Default Configuration

The default bridge priority for IEEE Spanning Tree Protocol (STP) is 32768.

Command Mode

Global Configuration mode

User Guidelines

The device with the lowest priority is selected as the root of the spanning tree.

Example

The following example configures the spanning tree priority of instance 1 to 4096.

```
Console (config) # spanning-tree mst 1 priority 4096
```

spanning-tree *mst max-hops*

The **spanning-tree *mst priority*** Global Configuration mode command configures the number of hops in an MST region before the BDPU is discarded and the port information is aged out. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree *mst max-hops hop-count*

no spanning-tree *mst max-hops*

Parameters

- *hop-count*—Number of hops in an MST region before the BDPU is discarded .(Range: 1-40)

Default Configuration

The default number of hops is 20.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the maximum number of hops that a packet travels in an MST region before it is discarded to 10.

```
Console (config) # spanning-tree mst max-hops 10
```

spanning-tree mst port-priority

The **spanning-tree mst port-priority** Interface Configuration mode command configures port priority for the specified MST instance. To restore the default configuration, use the **no** form of this command.

Syntax

```
spanning-tree mst instance-id port-priority priority  
no spanning-tree mst instance-id port-priority
```

Parameters

- *instance-ID*—ID of the spanning tree instance. (Range: 1-15)
- *priority*—The port priority. (Range: 0-240 in multiples of 16)

Default Configuration

The default port priority for IEEE Multiple Spanning Tree Protocol (MSTP) is 128.

Command Modes

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the port priority of port g1 to 144.

```
Console(config)# interface ethernet ext.1
Console(config-if)# spanning-tree mst 1 port-priority 144
```

spanning-tree mst cost

The **spanning-tree mst cost** Interface Configuration mode command configures the path cost for multiple spanning tree (MST) calculations. If a loop occurs, the spanning tree considers path cost when selecting an interface to put in the forwarding state. To restore the default configuration, use the **no** form of this command.

Syntax

spanning-tree mst *instance-id* cost *cost*

no spanning-tree mst *instance-id* cost

Parameters

- *instance-ID*—ID of the spanning -tree instance (Range: 1-16).
- *cost*—The port path cost. (Range: 1-200,000,000)

Default Configuration

Default path cost is determined by port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
Gigabit Ethernet (1000 Mbps)	20,000	4
Fast Ethernet (100 Mbps)	200,000	19
Ethernet (10 Mbps)	2,000,000	100

Command Modes

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the MSTP instance 1 path cost for Ethernet port 9 to 4.

```
Console(config) # interface ethernet ext.9  
Console(config-if) # spanning-tree mst 1 cost 4
```

spanning-tree mst configuration

The **spanning-tree mst configuration** Global Configuration mode command enables configuring an MST region by entering the Multiple Spanning Tree (MST) mode.

Syntax

spanning-tree mst configuration

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

All devices in an MST region must have the same VLAN mapping, configuration revision number and name.

Example

The following example configures an MST region.

```
Console(config)# spanning-tree mst configuration  
Console(config-mst) #
```

instance (mst)

The **instance** MST Configuration mode command maps VLANS to an MST instance.

Syntax

```
instance instance-id {add | remove} vlan vlan-range
```

Parameters

- *instance-ID*—ID of the MST instance (Range: 1-15).
- *vlan-range*—VLANS to be added to or removed from the specified MST instance. To specify a range of VLANs, use a hyphen. To specify a series of VLANs, use a comma. (Range: 1-4094).

Default Configuration

VLANs are mapped to the common and internal spanning tree (CIST) instance (instance 0).

Command Modes

MST Configuration mode

User Guidelines

All VLANs that are not explicitly mapped to an MST instance are mapped to the common and internal spanning tree (CIST) instance (instance 0) and cannot be unmapped from the CIST.

For two or more devices to be in the same MST region, they must have the same VLAN mapping, the same configuration revision number, and the same name.

Example

The following example maps VLANs 10-20 to MST instance 1.

```
Console(config)# spanning-tree mst configuration
Console(config-mst)# instance 1 add vlan 10-20
```

name (mst)

The **name** MST Configuration mode command defines the configuration name. To restore the default setting, use the **no** form of this command.

Syntax

name *string*

Parameters

- *string* — MST configuration name. The name is case-sensitive. (Range: 1-32 characters)

Default Configuration

The default name is a radlan_guest.

Command Mode

MST Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example defines the configuration name as region1.

```
Console(config) # spanning-tree mst_configuration  
Console(config-mst) # name region1
```

revision (mst)

The **revision** MST Configuration mode command defines the configuration revision number. To restore the default configuration, use the **no** form of this command.

Syntax

revision *value*

no revision

Parameters

- *value* — Configuration revision number (Range: 0-65535).

Default Configuration

The default configuration revision number is 0.

Command Mode

MST Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets the configuration revision to 1.

```
Console(config) # spanning-tree mst configuration  
Console(config-mst) # revision 1
```

show (mst)

The **show** MST Configuration mode command displays the current or pending MST region configuration.

Syntax

```
show {current | pending}
```

Parameters

- **current**—Indicates the current region configuration.
- **pending**—Indicates the pending region configuration.

Default Configuration

This command has no default configuration.

Command Mode

MST Configuration mode

User Guidelines

The pending MST region configuration takes effect only after exiting the MST Configuration mode.

Example

The following example displays a pending MST region configuration.

```
Console(config-mst)# show pending
Pending MST configuration
Name: Region1
Revision: 1
Instance          Vlans Mapped      State
-----          -----
0                1-9,21-4094    Enabled
1                10-20          Enabled
```

exit (mst)

The **exit** MST Configuration mode command exits the MST Configuration mode, and applies all configuration changes.

Syntax

exit

Default Configuration

This command has no default configuration.

Command Mode

MST Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example exits the MST Configuration mode and saves changes.

```
Console(config) # spanning-tree mst configuration
Console(config-mst) # exit
Console(config) #
```

abort (mst)

The **abort** MST Configuration mode command exits the MST Configuration mode without applying the configuration changes.

Syntax

abort

Default Configuration

This command has no default configuration.

Command Mode

MST Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example exits the MST Configuration mode without saving changes.

```
Console(config) # spanning-tree mst configuration
Console(config-mst) # abort
```

spanning-tree guard root

The **spanning-tree guard root** Interface Configuration (Ethernet, port-channel) mode command enables root guard on all spanning tree instances on the interface. Root guard prevents the interface from becoming the root port of the device. To disable root guard on the interface, use the **no** form of this command.

Syntax

```
spanning-tree guard root  
no spanning-tree guard root
```

Default Configuration

Root guard is disabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

Root guard can be enabled when the device operates in STP, RSTP and MSTP.

When root guard is enabled, the port changes to the alternate state if spanning-tree calculations selects the port as the root port.

Example

The following example prevents Ethernet port 1 from being the root port of the device.

```
Console(config) # interface ethernet ext.1  
Console(config-mst) # spanning-tree guard root
```

show spanning-tree

The **show spanning-tree** Privileged EXEC mode command displays spanning-tree configuration.

Syntax

```
show spanning-tree [ethernet interface -number| port-channel port-channel-number]  
[instance instance-id]  
  
show spanning-tree [detail] [active | blockedports] [instance instance-id]  
  
show spanning-tree mst-configuration
```

Parameters

- *interface -number*— A valid Ethernet port.

- *port-channel-number* — A valid port channel number.
- **detail** — Indicates detailed information.
- **active** — Indicates active ports only.
- **blockedports** — Indicates blocked ports only.
- **mst-configuration** — Indicates the MST configuration identifier.
- *instance-id*—Specifies ID of the spanning tree instance.

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays spanning-tree information.

```
Console# show spanning-tree

Spanning tree enabled mode MSTP
Default port cost method: short

CST Root ID  Priority          32768
              Address           00:01:42:97:e0:00
              Path Cost          20000
              Root Port          1 (1/1)
This switch is the IST master
Hello Time 2 sec      Max Age 20 sec      Forward Delay 15 sec

Bridge ID   Priority          36864
              Address           00:02:4b:29:7a:00
              Hello Time 2 sec    Max Age 20 sec      Forward Delay 15 sec
              Max hops          20
```

Spanning-Tree Commands

Interfaces							
Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
---	-----	-----	-----	---	----	-----	-----
1	Enabled	128.1	20000	FWD	Root	No	P2p bound (RSTP)
2	Enabled	128.2	20000	FWD	Desg	No	Shared (STP)
3	Disabled	128.3	20000	-	-	-	-
4	Enabled	128.4	20000	BLK	ALTN	No	Shared (STP)
5	Enabled	128.5	20000	DIS	-	-	-

Console# show spanning-tree							
Spanning tree enabled mode RSTP							
Default port cost method: long							
Root ID Priority 36864							
Address 00:02:4b:29:7a:00							
This switch is the root.							
Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec							
Interfaces							
Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
---	-----	-----	-----	---	----	-----	-----
1	Enabled	128.1	20000	FWD	Desg	No	P2p (RSTP)
2	Enabled	128.2	20000	FWD	Desg	No	Shared (STP)
3	Disabled	128.3	20000	-	-	-	-
4	Enabled	128.4	20000	FWD	Desg	No	Shared (STP)
5	Enabled	128.5	20000	DIS	-	-	-

```
Console# show spanning-tree

Spanning tree disabled (BPDU filtering) mode RSTP
Default port cost method: long

Root ID      Priority          N/A
              Address           N/A
              Path Cost         N/A
              Root Port        N/A
              Hello Time N/A   Max Age N/A   Forward Delay N/A

Bridge ID    Priority          36864
              Address           00:02:4b:29:7a:00
              Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

Interfaces
Name       State     Prio.Nbr  Cost   Sts    Role    PortFast  Type
----       -----     -----    ----  ---    ----    -----    -----
1          Enabled   128.1    20000  -      -      -      -
2          Enabled   128.2    20000  -      -      -      -
3          Disabled  128.3    20000  -      -      -      -
4          Enabled   128.4    20000  -      -      -      -
5          Enabled   128.5    20000  -      -      -      -

Console# show spanning-tree active

Spanning tree enabled mode RSTP
Default port cost method: long

Root ID      Priority          32768
              Address           00:01:42:97:e0:00
              Path Cost         20000
              Root Port        1 (1/1)
              Hello Time 2 sec  Max Age 20 sec  Forward Delay 15 sec

Bridge ID    Priority          36864
```

Spanning-Tree Commands

	Address	00:02:4b:29:7a:00									
	Hello Time 2 sec	Max Age 20 sec			Forward Delay 15 sec						
Interfaces											
Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type				
---	-----	-----	----	---	-----	-----	-----				
1	Enabled	128.1	20000	FWD	Root	No	P2p (RSTP)				
2	Enabled	128.2	20000	FWD	Desg	No	Shared (STP)				
4	Enabled	128.4	20000	BLK	ALTN	No	Shared (STP)				
Console# show spanning-tree blockedports											
Spanning tree enabled mode RSTP											
Default port cost method: long											
Root ID	Priority		32768								
	Address		00:01:42:97:e0:00								
	Path Cost		20000								
	Root Port		1 (1/1)								
	Hello Time 2 sec		Max Age 20 sec			Forward Delay 15 sec					
Bridge ID	Priority		36864								
	Address		00:02:4b:29:7a:00								
	Hello Time 2 sec		Max Age 20 sec			Forward Delay 15 sec					
Interfaces											
Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type				
---	-----	-----	----	---	-----	-----	-----				
4	Enabled	128.4	20000	BLK	ALTN	No	Shared (STP)				

```

Console# show spanning-tree detail

Spanning tree enabled mode RSTP
Default port cost method: long

Root ID      Priority      32768
              Address       00:01:42:97:e0:00
              Path Cost     20000
              Root Port     1 (1/1)
              Hello Time   2 sec    Max Age 20 sec    Forward Delay 15 sec

Bridge ID    Priority      36864
              Address       00:02:4b:29:7a:00
              Hello Time   2 sec    Max Age 20 sec    Forward Delay 15 sec

Number of topology changes 2 last change occurred 2d18h ago
Times:      hold 1, topology change 35, notification 2
            hello 2, max age 20, forward delay 15

Port 1 (1/1) enabled
State: Forwarding          Role: Root
Port id: 128.1              Port cost: 20000
Type: P2p (configured: auto) RSTP  Port Fast: No (configured:no)
Designated bridge Priority: 32768  Address: 00:01:42:97:e0:00
Designated port id: 128.2      Designated path cost: 0
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 2 enabled
State: Forwarding          Role: Designated
Port id: 128.2              Port cost: 20000
Type: Shared (configured: auto) STP  Port Fast: No (configured:no)
Designated bridge Priority: 32768  Address: 00:02:4b:29:7a:00
Designated port id: 128.2      Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

Spanning-Tree Commands

```
Port 3 disabled
State: N/A                               Role: N/A
Port id: 128.3                            Port cost: 20000
Type: N/A (configured: auto)             Port Fast: N/A (configured:no)
Designated bridge Priority: N/A          Address: N/A
Designated port id: N/A                  Designated path cost: N/A
Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A

Port 4 enabled
State: Blocking                           Role: Alternate
Port id: 128.4                            Port cost: 20000
Type: Shared (configured:auto) STP       Port Fast: No (configured:no)
Designated bridge Priority: 28672         Address: 00:30:94:41:62:c8
Designated port id: 128.25                Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 5 enabled
State: Disabled                           Role: N/A
Port id: 128.5                            Port cost: 20000
Type: N/A (configured: auto)             Port Fast: N/A (configured:no)
Designated bridge Priority: N/A          Address: N/A
Designated port id: N/A                  Designated path cost: N/A
Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A
```

```

Console# show spanning-tree ethernet ext.1

Port 1 (1/1) enabled

State: Forwarding           Role: Root
Port id: 128.1               Port cost: 20000
Type: P2p (configured: auto) RSTP   Port Fast: No (configured:no)
Designated bridge Priority: 32768   Address: 00:01:42:97:e0:00
Designated port id: 128.25      Designated path cost: 0
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Console# show spanning-tree mst-configuration

Name: Region1
Revision: 1

Instance          Vlans mapped       State
-----            -----
0                1-9, 21-4094     Enabled
1                10-20           Enabled

Console# show spanning-tree

Spanning tree enabled mode MSTP
Default port cost method: long

##### MST 0 Vlans Mapped: 1-9, 21-4094
CST Root ID        Priority  32768
                      Address   00:01:42:97:e0:00
                      Path      20000
                      Cost
Root              1 (1/1)
Port
Hello Time 2 sec   Max Age 20 sec   Forward Delay 15 sec

IST Master ID       Priority  32768
                      Address   00:02:4b:29:7a:00
This switch is the IST master.
Hello Time 2 sec   Max Age 20 sec   Forward Delay 15 sec

```

Spanning-Tree Commands

	Max hops	20					
Interfaces							
Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
---	-----	-----	-----	---	-----	-----	-----
1	Enabled	128.1	20000	FWD	Root	No	P2p Bound (RSTP)
2	Enabled	128.2	20000	FWD	Desg	No	Shared Bound (STP)
3	Enabled	128.3	20000	FWD	Desg	No	P2p
4	Enabled	128.4	20000	FWD	Desg	No	P2p
# ##### MST 1 Vlans Mapped: 10-20							
CST Root ID	Priority	24576					
	Address	00:02:4b:29:89:76					
	Path Cost	20000					
	Root Port	4 (1/4)					
	Rem hops	19					
Bridge ID	Priority	32768					
	Address	00:02:4b:29:7a:00					
Interfaces							
Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
---	-----	-----	-----	---	-----	-----	-----
1	Enabled	128.1	20000	FWD	Boun	No	P2p Bound (RSTP)
2	Enabled	128.2	20000	FWD	Boun	No	Shared Bound (STP)
3	Enabled	128.3	20000	BLK	Altn	No	P2p
4	Enabled	128.4	20000	FWD	Desg	No	P2p

```

Console# show spanning-tree detail

Spanning tree enabled mode MSTP
Default port cost method: long

##### MST 0 Vlans Mapped: 1-9, 21-4094
CST Root ID          Priority    32768
                           Address    00:01:42:97:e0:00
                           Path      20000
                           Cost
                           Root      1 (1/1)
                           Port
                           Hello Time 2 sec     Max Age 20 sec     Forward Delay 15 sec

IST Master ID          Priority    32768
                           Address    00:02:4b:29:7a:00
                           This switch is the IST master.
                           Hello Time 2 sec     Max Age 20 sec     Forward Delay 15 sec
                           Max hops   20
                           Number of topology changes 2 last change occurred 2d18h ago
                           Times: hold 1, topology change 35, notification 2
                           hello 2, max age 20, forward delay 15

Port 1 (1/1) enabled
State: Forwarding           Role: Root
Port id: 128.1               Port cost: 20000
Type: P2p (configured: auto) Boundary RSTP
Designated bridge Priority: 32768
Designated port id: 128.25
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 2 (enabled)
State: Forwarding           Role: Designated
Port id: 128.2               Port cost: 20000
Type: Shared (configured: auto) Boundary STP
Designated bridge Priority: 32768
Address: 00:02:4b:29:7a:00

```

Spanning-Tree Commands

Designated port id: 128.2	Designated path cost: 20000
Number of transitions to forwarding state: 1	
BPDU: sent 2, received 170638	
Port 3 enabled	
State: Forwarding	Role: Designated
Port id: 128.3	Port cost: 20000
Type: Shared (configured: auto) Internal	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:02:4b:29:7a:00
Designated port id: 128.3	Designated path cost: 20000
Number of transitions to forwarding state: 1	
BPDU: sent 2, received 170638	
Port 4 enabled	
State: Forwarding	Role: Designated
Port id: 128.4	Port cost: 20000
Type: Shared (configured: auto) Internal	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:02:4b:29:7a:00
Designated port id: 128.2	Designated path cost: 20000
Number of transitions to forwarding state: 1	
BPDU: sent 2, received 170638	
##### MST 1 Vlans Mapped: 10-20	
Root ID	Priority 24576
	Address 00:02:4b:29:89:76
	Path 20000
	Cost
	Port 4 (1/4)
	Cost
	Rem hops 19
Bridge ID	Priority 32768
	Address 00:02:4b:29:7a:00
	Number of topology changes 2 last change occurred 1d9h ago
	Times: hold 1, topology change 2, notification 2
	hello 2, max age 20, forward delay 15

Port 1 (1/1) enabled	
State: Forwarding	Role: Boundary
Port id: 128.1	Port cost: 20000
Type: P2p (configured: auto) Boundary RSTP	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:02:4b:29:7a:00
Designated port id: 128.1	Designated path cost: 20000
Number of transitions to forwarding state: 1	
BPDU: sent 2, received 120638	
Port 2 (1/2) enabled	
State: Forwarding	Role: Designated
Port id: 128.2	Port cost: 20000
Type: Shared (configured: auto) Boundary STP	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:02:4b:29:7a:00
Designated port id: 128.2	Designated path cost: 20000
Number of transitions to forwarding state: 1	
BPDU: sent 2, received 170638	
Port 3 disabled	
State: Blocking	Role: Alternate
Port id: 128.3	Port cost: 20000
Type: Shared (configured: auto) Internal	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:02:4b:29:1a:19
Designated port id: 128.78	Designated path cost: 20000
Number of transitions to forwarding state: 1	
BPDU: sent 2, received 170638	
Port 4 enabled	
State: Forwarding	Role: Designated
Port id: 128.4	Port cost: 20000
Type: Shared (configured: auto) Internal	Port Fast: No (configured:no)
Designated bridge Priority: 32768	Address: 00:02:4b:29:7a:00
Designated port id: 128.2	Designated path cost: 20000
Number of transitions to forwarding state: 1	
BPDU: sent 2, received 170638	

Spanning-Tree Commands

```
Console# show spanning-tree

Spanning tree enabled mode MSTP
Default port cost method: long

##### MST 0 Vlans Mapped: 1-9, 21-4094
CST Root ID          Priority  32768
                        Address   00:01:42:97:e0:00
                        Path      20000
                        Cost
                        Root      1 (1/1)
                        Port
                        Hello Time 2 sec    Max Age 20 sec    Forward Delay 15 sec

IST Master ID         Priority  32768
                        Address   00:02:4b:19:7a:00
                        Path      10000
                        Cost
                        Rem hops 19

Bridge ID            Priority  32768
                        Address   00:02:4b:29:7a:00
                        Hello Time 2 sec    Max Age 20 sec    Forward Delay 15 sec
                        Max hops  20

Console# show spanning-tree

Spanning tree enabled mode MSTP
Default port cost method: long

##### MST 0 Vlans Mapped: 1-9, 21-4094
CST Root ID          Priority  32768
                        Address   00:01:42:97:e0:00
                        This switch is root for CST and IST master.
                        Root      1 (1/1)
                        Port
```

Hello Time 2 sec	Max Age 20 sec	Forward Delay 15 sec
Max hops 20		

Spanning-Tree Commands

23 SSH Commands

ip ssh port

The **ip ssh port** Global Configuration mode command specifies the port to be used by the SSH server. To restore the default configuration, use the **no** form of this command.

Syntax

```
ip ssh port port-number
no ip ssh port
```

Parameters

- *port-number* — Port number for use by the SSH server (Range: 1-65535).

Default Configuration

The default port number is 22.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example specifies the port to be used by the SSH server as 8080.

```
Console(config)# ip ssh port 8080
```

ip ssh server

The **ip ssh server** Global Configuration mode command enables the device to be configured from a SSH server. To disable this function, use the **no** form of this command.

Syntax

```
ip ssh server  
no ip ssh server
```

Default Configuration

Device configuration from a SSH server is disabled.

Command Mode

Global Configuration mode

User Guidelines

If encryption keys are not generated, the SSH server is in standby until the keys are generated. To generate SSH server keys, use the **crypto key generate dsa**, and **crypto key generate rsa** Global Configuration mode commands.

Example

The following example enables configuring the device from a SSH server.

```
Console(config) # ip ssh server
```

crypto key generate dsa

The **crypto key generate dsa** Global Configuration mode command generates DSA key pairs.

Syntax

```
crypto key generate dsa
```

Default Configuration

DSA key pairs do not exist.

Command Mode

Global Configuration mode

User Guidelines

DSA keys are generated in pairs: one public DSA key and one private DSA key. If the device already has DSA keys, a warning and prompt to replace the existing keys with new keys are displayed.

This command is not saved in the device configuration; however, the keys generated by this command are saved in the private configuration, which is never displayed to the user or backed up on another device.

DSA keys are saved to the backup master.

This command may take a considerable period of time to execute.

Example

The following example generates DSA key pairs.

```
Console(config)# crypto key generate dsa
```

crypto key generate rsa

The **crypto key generate rsa** Global Configuration mode command generates RSA key pairs.

Syntax

crypto key generate rsa

Default Configuration

RSA key pairs do not exist.

Command Mode

Global Configuration mode

User Guidelines

RSA keys are generated in pairs: one public RSA key and one private RSA key. If the device already has RSA keys, a warning and prompt to replace the existing keys with new keys are displayed.

This command is not saved in the device configuration; however, the keys generated by this command are saved in the private configuration which is never displayed to the user or backed up on another device.

RSA keys are saved to the backup master.

This command may take a considerable period of time to execute.

Example

The following example generates RSA key pairs.

```
Console(config) # crypto key generate rsa
```

ip ssh pubkey-auth

The **ip ssh pubkey-auth** Global Configuration mode command enables public key authentication for incoming SSH sessions. To disable this function, use the **no** form of this command.

Syntax

```
ip ssh pubkey-auth
```

```
no ip ssh pubkey-auth
```

Default Configuration

Public Key authentication for incoming SSH sessions is disabled.

Command Mode

Global Configuration mode

User Guidelines

AAA authentication is independent.

Example

The following example enables public key authentication for incoming SSH sessions.

```
Console(config) # ip ssh pubkey-auth
```

crypto key pubkey-chain ssh

The **crypto key pubkey-chain ssh** Global Configuration mode command enters the SSH Public Key-chain Configuration mode. The mode is used to manually specify other device public keys such as SSH client public keys.

Syntax

```
crypto key pubkey-chain ssh
```

Default Configuration

No keys are specified.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enters the SSH Public Key-chain Configuration mode and manually configures the RSA key pair for SSH public key-chain **bob**.

```
Console(config)# crypto key pubkey-chain ssh
Console(config-pubkey-chain)# user-key bob
Console(config-pubkey-key)# key-string rsa
AAAAAB3NzaC1yc2EAAAQABAAQCVnRwPw1
A14kpqIw9GBRonZQZxjHKcqKL6rMlQ+
ZNxfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJJk67IOU/zfw0l1g
kTwm175QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu081icglk02LYciz
+z4TrEU/9FJxwPiVQOjc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkmlshRE7Di71+w3fNioA
6w9o44t6+AINEICBCCA4YcF6zMzaT1wefWwX6f+
Rmt5nhhqdAtN/4oJfce166DqVX1gWmN
zNR4DYDvSzg01DnwCAC8Qh

Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9
```

user-key

The **user-key** SSH Public Key-string Configuration mode command specifies which SSH public key is manually configured. To remove an SSH public key, use the **no** form of this command.

Syntax

```
user-key username {rsa | dsa}  
no user-key username
```

Parameters

- *username* — Specifies the username of the remote SSH client. (Range: 1-48 characters)
- **rsa** — Indicates the RSA key pair.
- **dsa** — Indicates the DSA key pair.

Default Configuration

No SSH public keys exist.

Command Mode

SSH Public Key-string Configuration mode

User Guidelines

Follow this command with the **key-string** SSH Public Key-String Configuration mode command to specify the key.

Example

The following example enables manually configuring an SSH public key for SSH public key-chain **bob**.

```
Console(config)# crypt\o key pubkey-chain ssh  
Console(config-pubkey-chain)# user-key bob rsa  
Console(config-pubkey-key)# key-string row  
AAAAB3NzaC1yc2EAAAQABAAQCvTnRwPWl
```

key-string

The **key-string** SSH Public Key-string Configuration mode command manually specifies an SSH public key.

Syntax

```
key-string  
key-string row key-string
```

Parameters

- **row** — Indicates the SSH public key row by row.
- *key-string* — Specifies the key in UU-encoded DER format; UU-encoded DER format is the same format in the authorized_keys file used by OpenSSH. (Range:0-160)

Default Configuration

No keys exist.

Command Mode

SSH Public Key-string Configuration mode

User Guidelines

Use the **key-string** SSH Public Key-string Configuration mode command to specify which SSH public key is to be interactively configured next. To complete the command, you must enter a row with no characters.

Use the **key-string row** SSH Public Key-string Configuration mode command to specify the SSH public key row by row. Each row must begin with a **key-string row** command. This command is useful for configuration files.

Example

The following example enters public key strings for SSH public key client **bob**.

```
Console(config) # crypto key pubkey-chain ssh
Console(config-pubkey-chain) # user-key bob rsa
Console(config-pubkey-key) # key-string
AAAAB3NzaC1yc2EAAAQABAAQCVnRwPw1
A14kpqIw9GBRonZQZxjHKcqKL6rMlQ+
ZNxfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJjk67IOU/zfwOllg
kTwml75QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licglk02LYciz
+Z4TrEU/9FJxwPiVQOjc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tmkmlshRE7Di71+w3fNiOA
6w9o4t6+AINEICBCCA4YcF6zMzaT1weFWwX6f+
Rmt5nhqdAtN/4oJfce166DqVX1gWmN
zNR4DYDvSzg01DnwCAC8Qh

Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9

Console(config) # crypto key pubkey-chain ssh
Console(config-pubkey-chain) # user-key bob rsa
Console(config-pubkey-key) # key-string row AAAAB3Nza
Console(config-pubkey-key) # key-string row C1yc2
```

show ip ssh

The **show ip ssh** Privileged EXEC mode command displays the SSH server configuration.

Syntax

show ip ssh

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the SSH server configuration.

```
Console# show ip ssh
SSH server enabled. Port: 22
RSA key was generated.
DSA (DSS) key was generated.
SSH Public Key Authentication is enabled.
Active incoming sessions:
IP address      SSH username      Version      Cipher      Auth Code
-----          -----          -----          -----          -----
172.16.0.1      John Brown      2.0 3        DES        HMAC-SHA1
```

The following table describes the significant fields shown in the display.

Field	Description
IP address	Client address
SSH username	User name
Version	SSH version number
Cipher	Encryption type (3DES, Blowfish, RC4)
Auth Code	Authentication Code (HMAC-MD5, HMAC-SHA1)

show crypto key mypubkey

The **show crypto key mypubkey** Privileged EXEC mode command displays the SSH public keys on the device.

Syntax

show crypto key mypubkey [rsa | dsa]

Parameters

- **rsa** — Indicates the RSA key.
- **dsa** — Indicates the DSA key.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the SSH public RSA keys on the device.

```
Console# show crypto key mypubkey rsa
RSA key data:
005C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C5E23B 55D6AB22
04AEF1BA A54028A6 9ACC01C5 129D99E4 64CAB820 847EDAD9 DF0B4E4C 73A05DD2
BD62A8A9 FA603DD2 E2A8A6F8 98F76E28 D58AD221 B583D7A4 71020301 87685768
Fingerprint(Hex) : 77:C7:19:85:98:19:27:96:C9:CC:83:C5:78:89:F8:86
Fingerprint(Bubble Babble): yteriuwt jgkljhglk yewiury hdskjfryt gfhkjglk
```

show crypto key pubkey-chain ssh

The **show crypto key pubkey-chain ssh** Privileged EXEC mode command displays SSH public keys stored on the device.

Syntax

```
show crypto key pubkey-chain ssh [username username] [fingerprint {bubble-babble | hex}]
```

Parameters

- *username* — Specifies the remote SSH client username.
- **bubble-babble** — Fingerprint in Bubble Babble format.
- **hex** — Fingerprint in Hex format.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays SSH public keys stored on the device.

```
Console# show crypto key pubkey-chain ssh
Username      Fingerprint
-----
bob          9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86
john         98:F7:6E:28:F2:79:87:C8:18:F8:88:CC:F8:89:87:C8

Console# show crypto key pubkey-chain ssh username bob
Username: bob
Key: 005C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C5E23B 55D6AB22 04AEF1BA
A54028A6 9ACC01C5 129D99E4
Fingerprint: 9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86
```

SSH Commands

24 Syslog Commands

logging on

The **logging on** Global Configuration mode command controls error message logging. This command sends debug or error messages to a logging process, which logs messages to designated locations asynchronously to the process that generated the messages. To disable the logging process, use the **no** form of this command.

Syntax

logging on

no logging on

Default Configuration

Logging is enabled.

Command Mode

Global Configuration mode

User Guidelines

The logging process controls the distribution of logging messages at various destinations, such as the logging buffer, logging file or syslog server. Logging on and off at these destinations can be individually configured using the **logging buffered**, **logging file**, and **logging** Global Configuration mode commands. However, if the **logging on** command is disabled, no messages are sent to these destinations. Only the console receives messages.

Example

The following example enables logging error messages.

```
Console(config)# logging on
```

logging

The **logging** Global Configuration mode command logs messages to a syslog server. To delete the syslog server with the specified address from the list of syslogs, use the **no** form of this command.

Syntax

```
logging {ip-address | hostname} [port port] [severity level] [facility facility]  
[description text]  
  
no logging {ip-address | hostname}
```

Parameters

- *ip-address* — IP address of the host to be used as a syslog server.
- *hostname* — Specifies the host name of the syslog server. (Range: 1-158 characters)
- *port* — Specifies the port number for syslog messages. (Range: 1-65535)
- *level* — Specifies the severity level of logged messages sent to the syslog servers. Possible values: **emergencies**, **alerts**, **critical**, **errors**, **warnings**, **notifications**, **informational** and **debugging**.
- *facility* — Specifies the facility that is indicated in the message. Possible values: **local0**, **local1**, **local2**, **local3**, **local4**, **local5**, **local 6**, **local7**.
- *text* — Syslog server description. (Range: 1-64 characters)

Default Configuration

The default port number is 514.

The default logging message level is **informational**.

The default facility is local7.

Command Mode

Global Configuration mode

User Guidelines

Up to 8 syslog servers can be used.

If no specific severity level is specified, the global values apply to each server.

Example

The following example limits logged messages sent to the syslog server with IP address 10.1.1.1 to severity level **critical**.

Console(config)# logging 10.1.1.1 severity critical
--

logging buffered

The **logging buffered** Global Configuration mode command limits syslog messages displayed from an internal buffer based on severity. To cancel using the buffer, use the **no** form of this command.

Syntax

logging buffered *level*

no logging buffered

Parameters

- *level* — Specifies the severity level of messages logged in the buffer. The possible values are: **emergencies**, **alerts**, **critical**, **errors**, **warnings**, **notifications**, **informational**, **debugging**.

Default Configuration

The default severity level is **informational**.

Command Mode

Global Configuration mode

User Guidelines

All the syslog messages are logged to the internal buffer. This command limits the messages displayed to the user.

Example

The following example limits syslog messages displayed from an internal buffer based on severity level **debugging**.

Console(config)# logging buffered debugging
--

logging buffered size

The **logging buffered size** Global Configuration mode command changes the number of syslog messages stored in the internal buffer. To restore the default configuration, use the **no** form of this command.

Syntax

logging buffered size *number*

no logging buffered size

Parameters

- *number* — Specifies the maximum number of messages stored in the history table. (Range: 20-400)

Default Configuration

The default number of messages is 200.

Command Mode

Global Configuration mode

User Guidelines

This command takes effect only after Reset.

Example

The following example changes the number of syslog messages stored in the internal buffer to 300.

```
Console(config)# logging buffered size 300
```

clear logging

The **clear logging** Privileged EXEC mode command clears messages from the internal logging buffer.

Syntax

clear logging

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example clears messages from the internal logging buffer.

```
Console# clear logging
Clear Logging File [y/n]
```

logging file

The **logging file** Global Configuration mode command limits syslog messages sent to the logging file based on severity. To cancel using the buffer, use the **no** form of this command.

Syntax

logging file *level*

no logging file

Parameters

- *level* — Specifies the severity level of syslog messages sent to the logging file. Possible values are: **emergencies**, **alerts**, **critical**, **errors**, **warnings**, **notifications**, **informational** and **debugging**.

Default Configuration

The default severity level is **errors**.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example limits syslog messages sent to the logging file based on severity level **alerts**.

```
Console(config)# logging file alerts
```

clear logging file

The **clear logging file** Privileged EXEC mode command clears messages from the logging file.

Syntax

```
clear logging file
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example clears messages from the logging file.

```
Console# clear logging file
Clear Logging File [y/n]
```

aaa logging

The **aaa logging** Global Configuration mode command enables logging AAA login events. To disable logging AAA login events, use the **no** form of this command.

Syntax

aaa logging login

no aaa logging login

Parameters

- **login** — Indicates logging messages related to successful login events, unsuccessful login events and other login-related events.

Default Configuration

Logging AAA login events is enabled.

Command Mode

Global Configuration mode

User Guidelines

Other types of AAA events are not subject to this command.

Example

The following example enables logging messages related to AAA login events.

```
Console(config)# aaa logging login
```

file-system logging

The **file-system logging** Global Configuration mode command enables logging file system events. To disable logging file system events, use the **no** form of this command.

Syntax

file-system logging copy

```
no file-system logging copy  
file-system logging delete-rename  
no file-system logging delete-rename
```

Parameters

- **copy** — Indicates logging messages related to file copy operations.
- **delete-rename** — Indicates logging messages related to file deletion and renaming operations.

Default Configuration

Logging file system events is enabled.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables logging messages related to file copy operations.

```
Console(config)# file-system logging copy
```

management logging

The **management logging** Global Configuration command enables logging management access list (ACL) events. To disable logging management access list events, use the **no** form of this command.

Syntax

```
management logging deny  
no management logging deny
```

Parameters

- **deny** — Indicates logging messages related to deny actions of management ACLs.

Default Configuration

Logging management ACL events is enabled.

Command Mode

Global Configuration mode

User Guidelines

Other types of management ACL events are not subject to this command.

Example

The following example enables logging messages related to deny actions of management ACLs.

```
Console(config)# management logging deny
```

show logging

The **show logging** Privileged EXEC mode command displays the state of logging and the syslog messages stored in the internal buffer.

Syntax

```
show logging
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the state of logging and the syslog messages stored in the internal buffer.

```
Console# show logging

Logging is enabled.
Console logging: level debugging. Console Messages: 0 Dropped (severity).
Buffer logging: level debugging. Buffer Messages: 11 Logged, 200 Max.
File logging: level notifications. File Messages: 0 Dropped (severity).
Syslog server 192.180.2.27 logging: errors. Messages: 6 Dropped (severity).
Syslog server 192.180.2.28 logging: errors. Messages: 6 Dropped (severity).
2 messages were not logged (resources)

Application filtering control

Application          Event           Status
-----              ----
AAA                  Login           Enabled
File system          Copy            Enabled
File system          Delete-Rename   Enabled
Management ACL      Deny            Enabled

Buffer log:
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface FastEthernet ext.0, changed state to up
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.0, changed state to up
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.1, changed state to up
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.2, changed state to up
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.3, changed state to up
11-Aug-2004 15:41:43: %SYS-5-CONFIG_I: Configured from memory by console

11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet ext.0 , changed state to up

11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.0, changed state to down

11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.1, changed state to down
11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.2, changed state to down
11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.3, changed state to down
```

show logging file

The **show logging file** Privileged EXEC mode command displays the state of logging and the syslog messages stored in the logging file.

Syntax

show logging file

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the logging state and the syslog messages stored in the logging file.

```
Console# show logging file

Logging is enabled.
Console logging: level debugging. Console Messages: 0 Dropped (severity).
Buffer logging: level debugging. Buffer Messages: 11 Logged, 200 Max.
File logging: level notifications. File Messages: 0 Dropped (severity).
Syslog server 192.180.2.27 logging: errors. Messages: 6 Dropped (severity).
Syslog server 192.180.2.28 logging: errors. Messages: 6 Dropped (severity).
2 messages were not logged (resources)

Application filtering control

Application          Event           Status
-----              -----
AAA                  Login           Enabled
File system          Copy            Enabled
File system          Delete-Rename   Enabled
Management ACL      Deny            Enabled
```

```
|  
Buffer log:  
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface FastEthernet ext.0, changed state to up  
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.0, changed state to up  
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.1, changed state to up  
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.2, changed state to up  
11-Aug-2004 15:41:43: %LINK-3-UPDOWN: Interface Ethernet ext.3, changed state to up  
11-Aug-2004 15:41:43: %SYS-5-CONFIG_I: Configured from memory by console  
11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet ext.0,  
changed state to up  
11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.0,  
changed state to down  
11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.1,  
changed state to down  
11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.2,  
changed state to down  
11-Aug-2004 15:41:39: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet ext.3,  
changed state to down
```

show syslog-servers

The **show syslog-servers** Privileged EXEC mode command displays the settings of the syslog servers.

Syntax

show syslog-servers

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the settings of the syslog servers.

```
Console# show syslog-servers

Device Configuration

IP address          Port      Severity        Facility      Description
-----              ----      -----          -----
192.180.2.27       514       Informational   local7
192.180.2.28       514       Warning        local7
```

Syslog Commands

25 System Management Commands

ping

The **ping** User EXEC mode command sends ICMP echo request packets to another node on the network.

Syntax

```
ping {ip-address | hostname}[size packet_size] [count packet_count] [timeout time_out]
```

Parameters

- *ip-address* — IP address to ping.
- *hostname* — Host name to ping. (Range: 1-158 characters)
- *packet_size* — Number of bytes in a packet. The actual packet size is eight bytes larger than the specified size specified because the device adds header information. (Range: 56-1472 bytes)
- *packet_count* — Number of packets to send. If 0 is entered, it pings until stopped. (Range: 0-65535 packets)
- *time_out* — Timeout in milliseconds to wait for each reply. (Range: 50-65535 milliseconds)

Default Configuration

Default packet size is 56 bytes.

Default number of packets to send is 4.

Default timeout value is 2000 milliseconds.

Command Mode

User EXEC mode

User Guidelines

Press **Esc** to stop pinging.

Following are examples of unsuccessful pinging:

Destination does not respond. If the host does not respond, a “no answer from host” appears in ten seconds.

Destination unreachable. The gateway for this destination indicates that the destination is unreachable.

Network or host unreachable. The device found no corresponding entry in the route table.

Example

The following example displays pinging results:

```
Console> ping 10.1.1.1
Pinging 10.1.1.1 with 64 bytes of data:

64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms

----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11

Console> ping yahoo.com
Pinging yahoo.com 66.218.71.198 with 64 bytes of data:

64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms

----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11
```

traceroute

The **traceroute** User EXEC mode command discovers routes that packets actually take when traveling to their destination.

Syntax

```
traceroute {ip-address |hostname}[size packet_size] [ttl max-ttl] [count packet_count]
[timeout time_out] [source ip-address] [tos tos]
```

Parameters

- *ip-address* — IP address of the destination host.
- *hostname* — Host name of the destination host. (Range: 1-158 characters)
- *packet_size* — Number of bytes in a packet. (Range: 40-1500)
- *max-ttl* — The largest TTL value that can be used. The **traceroute** command terminates when the destination is reached or when this value is reached. (Range:1-255)
- *packet_count* — The number of probes to be sent at each TTL level. (Range:1-10)
- *time_out* — The number of seconds to wait for a response to a probe packet. (Range:1-60)
- *ip-address* — One of the device's interface addresses to use as a source address for the probes. The device normally selects what it feels is the best source address to use.
- *tos* — The Type-Of-Service byte in the IP Header of the packet. (Range: 0-255)

Default Configuration

The default number of bytes in a packet is 40.

The default maximum TTL value is 30.

The default number of probes to be sent at each TTL level is 3.

The default timeout interval in seconds is 3.

Command Mode

User EXEC mode

User Guidelines

The **traceroute** command takes advantage of the error messages generated by the devices when a datagram exceeds its time-to-live (TTL) value.

The **traceroute** command starts by sending probe datagrams with a TTL value of one. This causes the first device to discard the probe datagram and send back an error message. The **traceroute** command sends several probes at each TTL level and displays the round-trip time for each.

The **traceroute** command sends out one probe at a time. Each outgoing packet may result in one or two error messages. A "time exceeded" error message indicates that an intermediate device has seen and discarded the probe. A "destination unreachable" error message indicates that the destination node has received the probe and discarded it because it could not deliver the packet. If the timer goes off before a response comes in, the **traceroute** command prints an asterisk (*).

The **traceroute** command terminates when the destination responds, when the maximum TTL is exceeded or when the user interrupts the trace by pressing **Esc**.

Example

The following example discovers the routes that packets will actually take when traveling to their destination.

```
Console> traceroute umaxp1.physics.lsa.umich.edu
Type Esc to abort.
Tracing the route to umaxp1.physics.lsa.umich.edu (141.211.101.64)
1 i2-gateway.stanford.edu (192.68.191.83) 0 msec 0 msec 0 msec
2 STAN.POS.calren2.NET (171.64.1.213) 0 msec 0 msec 0 msec
3 SUNV--STAN.POS.calren2.net (198.32.249.73) 1 msec 1 msec 1 msec
4 Abilene--QSV.POS.calren2.net (198.32.249.162) 1 msec 1 msec 1 msec
5 kscyng-snvang.abilene.ucaid.edu (198.32.8.103) 33 msec 35 msec 35 msec
6 iplsng-kscyng.abilene.ucaid.edu (198.32.8.80) 47 msec 45 msec 45 msec
7 so-0-2-0x1.aa1.mich.net (192.122.183.9) 56 msec 53 msec 54 msec
8 atm1-0x24.michnet8.mich.net (198.108.23.82) 56 msec 56 msec 57 msec
9 * * *
10 A-ARB3-LSA-NG.c-SEB.umnet.umich.edu (141.211.5.22) 58 msec 58 msec 58 msec
11 umaxp1.physics.lsa.umich.edu (141.211.101.64) 62 msec 63 msec 63 msec
```

The following table describes significant fields shown above.

Field	Description
1	Indicates the sequence number of the device in the path to the host.
i2-gateway.stanford.edu	Host name of this device.
192.68.191.83	IP address of this device.
1 msec 1 msec 1 msec	Round-trip time for each probe sent.

The following table describes characters that may appear in the **traceroute** command output.

Field	Description
*	The probe timed out.
?	Unknown packet type.
A	Administratively unreachable. Usually, this output indicates that an access list is blocking traffic.
F	Fragmentation is required and DF is set.

H	Host unreachable.
N	Network unreachable.
P	Protocol unreachable.
Q	Source quench.
R	Fragment reassembly time exceeded.
S	Source route failed.
U	Port unreachable.

telnet

The **telnet** User EXEC mode command enables logging on to a host that supports Telnet.

Syntax

telnet {ip-address | hostname} [port] [keyword1.....]

Parameters

- *ip-address* — IP address of the destination host.
- *hostname* — Host name of the destination host. (Range: 1-158 characters)
- *port* — A decimal TCP port number, or one of the keywords listed in the Ports table in the User Guidelines.
- *keyword* — One or more keywords listed in the Keywords table in the User Guidelines.

Default Configuration

The default port is the Telnet port (decimal23) on the host.

Command Mode

User EXEC mode

User Guidelines

Telnet software supports special Telnet commands in the form of Telnet sequences that map generic terminal control functions to operating system-specific functions. To enter a Telnet sequence, press the escape sequence keys (Ctrl-shift-6) followed by a Telnet command character.

Special Telnet Sequences

Telnet Sequence	Purpose
Ctrl-shift-6-b	Break
Ctrl-shift-6-c	Interrupt Process (IP)
Ctrl-shift-6-h	Erase Character (EC)
Ctrl-shift-6-o	Abort Output (AO)
Ctrl-shift-6-t	Are You There? (AYT)
Ctrl-shift-6-u	Erase Line (EL)

At any time during an active Telnet session, Telnet commands can be listed by pressing the Ctrl-shift-6-? keys at the system prompt.

A sample of this list follows. Note that the Ctrl-shift-6 sequence appears as ^^ on the screen.

```
Console> 'Ctrl-shift-6' ?
[Special telnet escape help]
^^ B sends telnet BREAK
^^ C sends telnet IP
^^ H sends telnet EC
^^ O sends telnet AO
^^ T sends telnet AYT
^^ U sends telnet EL
Ctrl-shift-6 x suspends the session (return to system command prompt)
```

Several concurrent Telnet sessions can be opened and switched. To open a subsequent session, the current connection has to be suspended by pressing the escape sequence keys (Ctrl-shift-6) and x to return to the system command prompt. Then open a new connection with the **telnet** User EXEC mode command.

Keywords Table

Options	Description
/echo	Enables local echo.
/quiet	Prevents onscreen display of all messages from the software.
/source-interface	Specifies the source interface.
/stream	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does not process Telnet options and can be appropriate for connections to ports running UNIX-to-UNIX Copy Program (UUCP) and other non-Telnet protocols.
Ctrl-shift-6 x	Return to System Command Prompt

Ports Table

Keyword	Description	Port Number
BGP	Border Gateway Protocol	179
chargen	Character generator	19
cmd	Remote commands	514
daytime	Daytime	13
discard	Discard	9
domain	Domain Name Service	53
echo	Echo	7
exec	Exec	512
finger	Finger	79
ftp	File Transfer Protocol	21
ftp-data	FTP data connections	20
gopher	Gopher	70
hostname	NIC hostname server	101
ident	Ident Protocol	113
irc	Internet Relay Chat	194
klogin	Kerberos login	543
kshell	Kerberos shell	544
login	Login	513
lpd	Printer service	515
nntp	Network News Transport Protocol	119
pim-auto-rp	PIM Auto-RP	496
pop2	Post Office Protocol v2	109
pop3	Post Office Protocol v3	110
smtp	Simple Mail Transport Protocol	25
sunrpc	Sun Remote Procedure Call	111
syslog	Syslog	514
tacacs	TAC Access Control System	49
talk	Talk	517
telnet	Telnet	23
time	Time	37
uucp	Unix-to-Unix Copy Program	540
whois	Nickname	43
www	World Wide Web	80

This command lists concurrent telnet connections to remote hosts that were opened by the current telnet session to the local device. It does not list telnet connections to remote hosts that were opened by other telnet sessions.

Example

The following example displays connecting to 176.213.10.50 via Telnet.

```
Console> telnet 176.213.10.50
Esc U sends telnet EL
```

resume

The **resume** User EXEC mode command enables switching to another open Telnet session.

Syntax

```
resume [connection]
```

Parameters

- *connection* — The connection number. (Range: 1-4 connections)

Default Configuration

The default connection number is that of the most recent connection.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following command switches to open Telnet session number 1.

```
Console> resume 1
```

reload

The **reload** Privileged EXEC mode command reloads the operating system.

Syntax

reload

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

Caution should be exercised when resetting the device, to ensure that no other activity is being performed. In particular, the user should verify that no configuration files are being downloaded at the time of reset.

Example

The following example reloads the operating system.

```
Console# reload
This command will reset the whole system and disconnect your current session. Do
you want to continue (y/n) [n]?
```

hostname

The **hostname** Global Configuration mode command specifies or modifies the device host name. To remove the existing host name, use the **no** form of the command.

Syntax

hostname *name*

no hostname

Parameters

- *name* — The host name. of the device. (Range: 1-158 characters)

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example specifies the device host name.

```
Console(config)# hostname enterprise  
enterprise(config) #
```

show users

The **show users** User EXEC mode command displays information about the active users.

Syntax

```
show users
```

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays information about the active users.

```
Console show users  
  
Username        Protocol      Location  
-----          -----  
-----
```

Bob	Serial	
John	SSH	172.16.0.1
Robert	HTTP	172.16.0.8
Betty	Telnet	172.16.1.7

show sessions

The **show sessions** User EXEC mode command lists open Telnet sessions.

Syntax

show sessions

Default Configuration

There is no default configuration for this command.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example lists open Telnet sessions.

Console> show sessions				
Connection	Host	Address	Port	Byte
-----	-----	-----	-----	---
1	Remote device	172.16.1.1	23	89
2	172.16.1.2	172.16.1.2	23	8

The following table describes significant fields shown above.

Field	Description
Connection	Connection number.
Host	Remote host to which the device is connected through a Telnet session.

Field	Description
Address	IP address of the remote host.
Port	Telnet TCP port number
Byte	Number of unread bytes for the user to see on the connection.

show system

The **show system** User EXEC mode command displays system information.

Syntax

show system

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the system information.

```
Console# show system

Unit      Type
-----
1         enterprise

Unit      Main Power Supply      Redundant Power Supply
-----
1         OPERATIONAL          NOT OPERATIONAL

Unit      Fan1        Fan2        Fan3        Fan4        Fan5
-----
```

---	---	---	---	---	---
1	OK	OK	OK	OK	OK

show system id

The **show system id** Privileged EXEC mode command displays the system identity information.

Syntax

```
show system id [unit unit]
```

Parameters

- **unit *unit*** — Unit number.

Default Configuration

This command has no default configuration.

Command Modes

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

```
Console> show system id
Service Tag: 89788978
Serial number: 8936589782
Asset tag: 7843678957
The following is relevant for stackable systems only
Unit          Service tag      Serial number      Asset tag
-----
1            89788978        8936589782        7843678957
2            34254675        3216523877        5621987728
```

show system flowcontrol

The **show system flowcontrol** Interface Configuration mode command displays the flow control state on cascade ports.

Syntax

```
show system flowcontrol
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

```
Flow control for internal cascade ports: Enabled  
Flow control for Stack ports: Enabled  
Flow control rx-only: Enabled.
```

show system mode

The **show system mode** Privileged EXEC mode command displays information on features control.

Syntax

show system mode

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays information on features control.

```
Console> show system mode  
  
Mode: Router  
QoS: Inactive
```

show version

The **show version** User EXEC mode command displays system version information.

Syntax

show version

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays system version information (only for demonstration purposes).

```
Console> show version

SW version 1.0.0.0          (date 23-Jul-2004 time 17:34:19)
Boot version 1.0.0.0         (date 11-Jan-2004 time 11:48:21)
HW version 1.0.0

Unit      SW version       Boot version       HW version
----      -----           -----           -----
1        1.0.0.0          2.178            1.0.0
```

service cpu-utilization

The **service cpu-utilization** Global Configuration mode command enables measuring CPU utilization. To return to the default configuration, use the **no** form of this command.

Syntax

service cpu-utilization

no service cpu-utilization

Default Configuration

Disabled.

Command Mode

Global Configuration mode

User Guidelines

Use the **show cpu utilization** Privileged EXEC command to view information on CPU utilization.

Example

This example enables measuring CPU utilization.

```
Console(config)# service cpu-utilization
```

show cpu utilization

The **show cpu utilization** Privileged EXEC mode command displays information about CPU utilization.

Syntax

show cpu utilization

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

Use the **service cpu-utilization** Global Configuration mode command to enable measuring CPU utilization.

Example

The following example configures the CPU utilization information display.

```
Console# show cpu utilization

CPU utilization service is on.

CPU utilization
-----
five seconds: 5%; one minute: 3%; five minutes: 3%
```

26 TACACS+ Commands

tacacs-server host

The **tacacs-server host** Global Configuration mode command specifies a TACACS+ host. To delete the specified name or address, use the **no** form of this command.

Syntax

```
tacacs-server host {ip-address | hostname} [single-connection] [port port-number]
[timeout timeout] [key key-string] [source source] [priority priority]

no tacacs-server host {ip-address | hostname}
```

Parameters

- *ip-address* — IP address of the TACACS+ server.
- *hostname* — Host name of the TACACS+ server. (Range: 1-158 characters)
- **single-connection** — Indicates a single-connection. Rather than have the device open and close a TCP connection to the daemon each time it must communicate, the single-connection option maintains a single open connection between the device and the daemon.
- *port-number* — Specifies a server port number. (Range: 0-65535)
- *timeout* — Specifies the timeout value in seconds. (Range: 1-30)
- *key-string* — Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. To specify an empty string, enter "". (Range: 0-128 characters)
- *source* — Specifies the source IP address to use for the communication. 0.0.0.0 indicates a request to use the IP address of the outgoing IP interface.
- *priority* — Determines the order in which the TACACS+ servers are used, where 0 is the highest priority. (Range: 0-65535)

Default Configuration

No TACACS+ host is specified.

If no port number is specified, default port number 49 is used.

If no host-specific timeout, key-string or source value is specified, the global value is used.

If no TACACS+ server priority is specified, default priority 0 is used.

Command Mode

Global Configuration mode

User Guidelines

Multiple **tacacs-server host** commands can be used to specify multiple hosts.

Example

The following example specifies a TACACS+ host.

```
Console(config)# tacacs-server host 172.16.1.1
```

tacacs-server key

The **tacacs-server key** Global Configuration mode command sets the authentication encryption key used for all TACACS+ communications between the device and the TACACS+ daemon. To disable the key, use the **no** form of this command.

Syntax

tacacs-server key *key-string*

no tacacs-server key

Parameters

- *key-string* — Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. (Range: 0-128 characters)

Default Configuration

Empty string.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets the authentication encryption key.

```
Console(config)# tacacs-server key enterprise
```

tacacs-server timeout

The **tacacs-server timeout** Global Configuration mode command sets the interval during which the device waits for a TACACS+ server to reply. To return to the default configuration, use the **no** form of this command.

Syntax

tacacs-server timeout *timeout*

no tacacs-server timeout

Parameters

- *timeout* — Specifies the timeout value in seconds. (Range: 1-30)

Default Configuration

5 seconds

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets the timeout value to 30.

```
Console(config)# tacacs-server timeout 30
```

tacacs-server source-ip

The **tacacs-server source-ip** Global Configuration mode command configures the source IP address to be used for communication with TACACS+ servers. To return to the default configuration, use the **no** form of this command.

Syntax

```
tacacs-server source-ip source
no tacacs-server source-ip source
```

Parameters

- *source* — Specifies the source IP address.

Default Configuration

The source IP address is the address of the outgoing IP interface.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example specifies the source IP address.

```
Console(config)# tacacs-server source-ip 172.16.8.1
```

show tacacs

The **show tacacs** Privileged EXEC mode command displays configuration and statistical information about a TACACS+ server.

Syntax

```
show tacacs [ip-address]
```

Parameters

- *ip-address* — Name or IP address of the TACACS+ server.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays configuration and statistical information about a TACACS+ server.

```
Console# show tacacs

Device Configuration
-----
IP address      Status       Port      Single          TimeOut      Source IP      Priority
-----          -----       ----      Connection
-----          -----       ----      -
172.16.1.1     Connected    49        No            Global       Global        1

Global values
-----
TimeOut: 3
Device Configuration
-----
Source IP: 172.16.8.1
```

TACACS+ Commands

27 User Interface Commands

enable

The **enable** User EXEC mode command enters the Privileged EXEC mode.

Syntax

enable [*privilege-level*]

Parameters

- *privilege-level* — Privilege level to enter the system. (Range: 1-15)

Default Configuration

The default privilege level is 15.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enters Privileged EXEC mode:

```
Console> enable  
enter password:  
Console#
```

disable

The **disable** Privileged EXEC mode command returns to the User EXEC mode.

Syntax

disable [*privilege-level*]

Parameters

- *privilege-level* — Privilege level to enter the system. (Range: 1-15)

Default Configuration

The default privilege level is 1.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example return to Users EXEC mode.

```
Console# disable
Console>
```

login

The **login** User EXEC mode command changes a login username.

Syntax

login

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enters Privileged EXEC mode and logs in with username **admin**.

```
Console> login
User Name:admin
Password:*****
Console#
```

configure

The **configure** Privileged EXEC mode command enters the Global Configuration mode.

Syntax

configure

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enters Global Configuration mode.

```
Console# configure
Console(config)#
```

exit (Configuration)

The **exit** command exits any configuration mode to the next highest mode in the CLI mode hierarchy.

Syntax

exit

Default Configuration

This command has no default configuration.

Command Mode

All configuration modes

User Guidelines

There are no user guidelines for this command.

Example

The following example changes the configuration mode from Interface Configuration mode to Privileged EXEC mode.

```
Console(config-if)# exit  
Console(config)# exit  
Console#
```

exit

The **exit** Privileged/User EXEC mode command closes an active terminal session by logging off the device.

Syntax

exit

Default Configuration

This command has no default configuration.

Command Mode

Privileged and User EXEC modes

User Guidelines

There are no user guidelines for this command.

Example

The following example closes an active terminal session.

```
Console> exit
```

end

The **end** command ends the current configuration session and returns to the Privileged EXEC mode.

Syntax

end

Default Configuration

This command has no default configuration.

Command Mode

All configuration modes.

User Guidelines

There are no user guidelines for this command.

Example

The following example changes from Global Configuration mode to Privileged EXEC mode.

```
Console(config)# end
Console#
```

help

The **help** command displays a brief description of the help system.

Syntax

help

Default Configuration

This command has no default configuration.

Command Mode

All command modes

User Guidelines

There are no user guidelines for this command.

Example

The following example describes the help system.

```
Console# help

Help may be requested at any point in a command by entering a question mark '?'. If nothing matches the currently entered incomplete command, the help list is empty. This indicates that for a query at this point, there is no command matching the current input. If the request is within a command, enter backspace and erase the entered characters to a point where the request results in a display.

Help is provided when:
1. There is a valid command and a help request is made for entering a parameter or argument (e.g. 'show ?'). All possible parameters or arguments for the entered command are displayed.
2. An abbreviated argument is entered and a help request is made for arguments matching the input (e.g. 'show pr?').
```

terminal datadump

The **terminal datadump** User EXEC mode command enables dumping all the output of a show command without prompting. To disable dumping, use the **no** form of this command.

Syntax

terminal datadump

no terminal datadump

Default Configuration

Dumping is disabled.

Command Mode

User EXEC mode

User Guidelines

By default, a **More** prompt is displayed when the output contains more lines than can be displayed on the screen. Pressing the **Enter** key displays the next line; pressing the Spacebar displays the next screen of output. The data-dump command enables dumping all output immediately after entering the show command.

This command is relevant only for the current session.

Example

This example dumps all output immediately after entering a show command.

```
Console> terminal datadump
```

show history

The **show history** User EXEC mode command lists the commands entered in the current session.

Syntax

show history

Default Configuration

This command has no default configuration.

Command Mode

User EXEC mode

User Guidelines

The buffer includes executed and unexecuted commands.

Commands are listed from the first to the most recent command.

The buffer remains unchanged when entering into and returning from configuration modes.

Example

The following example displays all the commands entered while in the current Privileged EXEC mode.

```
Console# show version
SW version 3.131 (date 23-Jul-2005 time 17:34:19)
HW version 1.0.0

Console# show clock
15:29:03 Jun 17 2005

Console# show history
show version
show clock
show history
3 commands were logged (buffer size is 10)
```

show privilege

The **show privilege** Privileged/User EXEC mode command displays the current privilege level.

Syntax

```
show privilege
```

Default Configuration

This command has no default configuration.

Command Mode

Privileged and User EXEC modes

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the current privilege level for the Privileged EXEC mode.

```
Console# show privilege  
Current privilege level is 15
```

do

The **do** command executes an EXEC-level command from global configuration mode or any configuration submode..

Syntax

do *command*

Parameters

- *command* — The command to be executed

Default Configuration

This command has no default configuration.

Command Mode

All configuration modes

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the current privilege level for the Privileged EXEC mode.

```
Console (Config)# do show vlan
```

VLAN	Name	Ports	Type	Authorization
1	default	1/1-2 2/1-4	Other	Required
10	VLAN0010	1/3-4	dynamic	Required
11	VLAN0011	1/1-2	static	Required
20	VLAN0020	1/3-4	static	Required
21	VLAN0021		static	Required
30	VLAN0030		static	Required
31	VLAN0031		static	Required
91	VLAN0011	1/1-2	static	Not Required
3978	Guest VLAN	1/17	static	Guest

28 VLAN Commands

vlan database

The **vlan database** Global Configuration mode command enters the VLAN Configuration mode.

Syntax

vlan database

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enters the VLAN database mode.

```
Console(config)# vlan database  
Console(config-vlan)#
```

vlan

Use the **vlan** VLAN Configuration mode command to create a VLAN. To delete a VLAN, use the **no** form of this command.

Syntax

vlan *vlan-range*

no vlan *vlan-range*

Parameters

- *vlan-range* — Specifies a list of VLAN IDs to be added. Separate nonconsecutive VLAN IDs with a comma and no spaces; a hyphen designates a range of IDs.

Default Configuration

This command has no default configuration.

Command Mode

VLAN Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example VLAN number 1972 is created.

```
Console(config)# vlan database  
Console(config-vlan)# vlan 1972
```

interface vlan

The **interface vlan** Global Configuration mode command enters the Interface Configuration (VLAN) mode.

Syntax

interface vlan *vlan-id*

Parameters

- *vlan-id* — Specifies an existing VLAN ID.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0.

```
Console(config)# interface vlan 1
Console(config-if)# ip address 131.108.1.27 255.255.255.0
```

interface range vlan

The **interface range vlan** Global Configuration mode command enables simultaneously configuring multiple VLANs.

Syntax

interface range vlan {*vlan-range* | all}

Parameters

- *vlan-range* — Specifies a list of VLAN IDs to be added. Separate nonconsecutive VLAN IDs with a comma and no spaces; a hyphen designates a range of IDs.
- **all** — All existing static VLANs.

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

Commands under the interface range context are executed independently on each interface in the range. If the command returns an error on one of the interfaces, an error message is displayed and execution of the command continues on the other interfaces.

Configuring all ports may consume an excessive amount of time. Define only the required ports to save time.

Example

The following example groups VLANs 221, 228 and 889 to receive the same command.

```
Console(config)# interface range vlan 221-228,889  
Console(config-if)#
```

name

The **name** Interface Configuration mode command adds a name to a VLAN. To remove the VLAN name, use the **no** form of this command.

Syntax

name *string*

no name

Parameters

- *string* — Unique name to be associated with this VLAN. (Range: 1-32 characters)

Default Configuration

No name is defined.

Command Mode

Interface Configuration (VLAN) mode. Cannot be configured for a range of interfaces (range context).

User Guidelines

The name string may include numbers and other characters (#,@,% etc.) but no spaces.

Example

The following example gives VLAN number 19 the name **Marketing**.

```
Console(config)# interface vlan 19  
Console(config-if)# name Marketing
```

switchport protected

The **switchport protected** Interface Configuration mode command overrides the FDB decision, and sends all Unicast, Multicast and Broadcast traffic to an uplink port. To disable overriding the FDB decision, use the no form of this command..

Syntax

```
switchport protected {ethernet port | port-channel port-channel-number}
no switchport protected
```

Parameters

- *port*— Specifies the uplink Ethernet port.
- *port-channel-number* — Specifies the uplink port-channel.

Default Configuration

Switchport protected is disabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

Private VLAN Edge (PVE) supports private communication by isolating PVE-defined ports and ensuring that all Unicast, Broadcast and Multicast traffic from these ports is only forwarded to uplink port(s).

PVE requires only one VLAN on each device, but not on every port; this reduces the number of VLANs required by the device. Private VLANs and the default VLAN function simultaneously in the same device.

Example

This example configures ethernet port 8 as a protected port, so that all traffic is sent to its uplink (ethernet port 1).

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport forbidden vlan add 234-256
Console(config-if)# exit
Console(config)# interface ethernet ext.1
Console(config-if)# switchport protected ethernet ext.1
```

switchport mode

The **switchport mode** Interface Configuration mode command configures the VLAN membership mode of a port. To return to the default configuration, use the **no** form of this command.

Syntax

```
switchport mode {access | trunk | general}
```

```
no switchport mode
```

Parameters

- **access** — Indicates an untagged layer 2 VLAN port.
- **trunk** — Indicates a trunking layer 2 VLAN port.
- **general** — Indicates a full 802.1q supported VLAN port.

Default Configuration

All ports are in access mode, and belong to the default VLAN (whose VID=1).

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines.

Example

The following example configures Ethernet port 1 as an untagged layer 2 VLAN port.

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport mode access
```

switchport access vlan

The **switchport access vlan** Interface Configuration mode command configures the VLAN ID when the interface is in access mode. To return to the default configuration, use the **no** form of this command.

Syntax

```
switchport access vlan {vlan-id | dynamic}
no switchport access vlan
```

Parameters

- *vlan-id*—Specifies the ID of the VLAN to which the port is configured.
- **dynamic**—Indicates that the port is assigned to a VLAN based on the source MAC address of the host connected to the port.

Default Configuration

All ports belong to VLAN 1.

Command Mode

Interface configuration (Ethernet, port-channel) mode

User Guidelines

The command automatically removes the port from the previous VLAN and adds it to the new VLAN.

Example

The following example configures a VLAN ID of 23 to the untagged layer 2 VLAN Ethernet port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport access vlan 23
```

switchport trunk allowed vlan

The **switchport trunk allowed vlan** Interface Configuration mode command adds or removes VLANs to or from a trunk port.

Syntax

```
switchport trunk allowed vlan {add vlan-list | remove vlan-list}
```

Parameters

- **add *vlan-list*** — List of VLAN IDs to be added. Separate nonconsecutive VLAN IDs with a comma and no spaces. A hyphen designates a range of IDs.
- **remove *vlan-list*** — List of VLAN IDs to be removed. Separate nonconsecutive VLAN IDs with a comma and no spaces. A hyphen designates a range of IDs.

Default Configuration

This command has no default configuration.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example adds VLANs 1, 2, 5 to 6 to the allowed list of te Ethernet port 1

```
Console(config)# interface ethernet ext.1
console(config-if)# switchport trunk allowed vlan add 1-2,5-6
```

switchport trunk native vlan

The **switchport trunk native vlan** Interface Configuration mode command defines the native VLAN when the interface is in trunk mode. To return to the default configuration, use the **no** form of this command.

Syntax

switchport trunk native vlan *vlan-id*

no switchport trunk native vlan

Parameters

- *vlan-id*— Specifies the ID of the native VLAN.

Default Configuration

VID=1.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The command adds the port as a member in the VLAN. If the port is already a member in the VLAN (not as a native), it should be first removed from the VLAN.

Example

The following example configures VLAN number 123 as the native VLAN when Ethernet port 1 is in trunk mode.

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport trunk native vlan 123
```

switchport general allowed vlan

The **switchport general allowed vlan** Interface Configuration mode command adds or removes VLANs from a general port.

Syntax

switchport general allowed vlan add *vlan-list* [tagged** | **untagged**]**

switchport general allowed vlan remove *vlan-list*

Parameters

- **add *vlan-list*** — Specifies the list of VLAN IDs to be added. Separate nonconsecutive VLAN IDs with a comma and no spaces. A hyphen designates a range of IDs.
- **remove *vlan-list*** — Specifies the list of VLAN IDs to be removed. Separate nonconsecutive VLAN IDs with a comma and no spaces. A hyphen designates a range of IDs.
- **tagged** — Indicates that the port transmits tagged packets for the VLANs.
- **untagged** — Indicates that the port transmits untagged packets for the VLANs.

Default Configuration

If the port is added to a VLAN without specifying tagged or untagged, the default setting is tagged.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

This command enables changing the egress rule (for example from tagged to untagged) without first removing the VLAN from the list.

Example

The following example adds VLANs 2, 5, and 6 to the allowed list of Ethernet port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport general allowed vlan add 2,5-6 tagged
```

switchport general pvid

The **switchport general pvid** Interface Configuration mode command configures the PVID when the interface is in general mode. To return to the default configuration, use the **no** form of this command.

Syntax

```
switchport general pvid vlan-id
no switchport general pvid
```

Parameters

- *vlan-id* — Specifies the PVID (Port VLAN ID).

Default Configuration

If the default VLAN is enabled, PVID = 1. Otherwise, PVID=4095.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the PVID for Ethernet port 1, when the interface is in general mode.

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport general pvid 234
```

switchport general ingress-filtering disable

The **switchport general ingress-filtering disable** Interface Configuration mode command disables port ingress filtering. To return to the default configuration, use the **no** form of this command.

Syntax

```
switchport general ingress-filtering disable
no switchport general ingress-filtering disable
```

Default Configuration

Ingress filtering is enabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example disables port ingress filtering on Ethernet port 1

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport general ingress-filtering disable
```

switchport general acceptable-frame-type tagged-only

The **switchport general acceptable-frame-type tagged-only** Interface Configuration mode command discards untagged frames at ingress. To return to the default configuration, use the **no** form of this command.

Syntax

```
switchport general acceptable-frame-type tagged-only  
no switchport general acceptable-frame-type tagged-only
```

Default Configuration

All frame types are accepted at ingress.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures Ethernet port 1 to discard untagged frames at ingress.

```
Console(config)# interface ethernet ext.1  
Console(config-if)# switchport general acceptable-frame-type tagged-only
```

switchport forbidden vlan

The **switchport forbidden vlan** Interface Configuration mode command forbids adding specific VLANs to a port. To return to the default configuration, use the **remove** parameter for this command.

Syntax

```
switchport forbidden vlan {add vlan-list | remove vlan-list}
```

Parameters

- **add *vlan-list*** — Specifies the list of VLAN IDs to be added. Separate nonconsecutive VLAN IDs with a comma and no spaces. A hyphen designates a range of IDs.
- **remove *vlan-list*** — Specifies the list of VLAN IDs to be removed. Separate nonconsecutive VLAN IDs with a comma and no spaces. A hyphen designates a range of IDs.

Default Configuration

All VLANs are allowed.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

This command can be used to prevent GVRP from automatically making the specified VLANs active on the selected ports.

Example

The following example forbids adding VLAN IDs 234 to 256 to Ethernet port 1.

```
Console(config)# interface ethernet ext.1
Console(config-if)# switchport forbidden vlan add 234-256
```

ip internal-usage-vlan

The **ip internal-usage-vlan** Interface Configuration mode command reserves a VLAN as the internal usage VLAN of an interface. To return to the default configuration, use the **no** form of this command.

Syntax

```
ip internal-usage-vlan vlan-id
no ip internal-usage-vlan
```

Parameters

- *vlan-id* — Specifies the ID of the internal usage VLAN.

Default Configuration

The software reserves a VLAN as the internal usage VLAN of an interface.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

An internal usage VLAN is required when an IP interface is configured on an Ethernet port or port-channel.

This command enables the user to configure the internal usage VLAN of a port. If an internal usage VLAN is not configured and the user wants to configure an IP interface, an unused VLAN is selected by the software.

If the software selected a VLAN for internal use and the user wants to use that VLAN as a static or dynamic VLAN, the user should do one of the following:

- Remove the IP interface.
- Create the VLAN and recreate the IP interface.
- Use this command to explicitly configure a different VLAN as the internal usage VLAN.

Example

The following example reserves an unused VLAN as the internal usage VLAN of ethernet port 1.

```
Console# config
Console(config)# interface ethernet ext.1
Console(config-if)# ip internal-usage-vlan
```

show vlan

The **show vlan** Privileged EXEC mode command displays VLAN information.

Syntax

```
show vlan [id vlan-id | name vlan-name]
```

Parameters

- *vlan-id* — specifies a VLAN ID

- *vlan-name* — Specifies a VLAN name string. (Range: 1-32 characters)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays all VLAN information.

Console# show vlan				
VLAN	Name	Ports	Type	Authorization
---	-----	-----	----	-----
1	default	1, 2	other	Required
10	VLAN0010	1	dynamic	Required
11	VLAN0011	1	static	Required
20	VLAN0020	1	static	Required
21	VLAN0021		static	Required
30	VLAN0030		static	Required
31	VLAN0031		static	Required
91	VLAN0011	1	static	Not Required
3978	Guest VLAN	1	guest	-

show vlan internal usage

The **show vlan internal usage** Privileged EXEC mode command displays a list of VLANs used internally by the device.

Syntax

show vlan internal usage

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays VLANs used internally by the device.

Console# show vlan internal usage			
VLAN	Usage	IP address	Reserved
1007	Eth 1	Active	No
1008	Eth 1	Inactive	Yes
1009	Eth 1	Active	Yes

show interfaces switchport

The **show interfaces switchport** Privileged EXEC mode command displays the switchport configuration.

Syntax

show interfaces switchport {ethernet *interface* | port-channel *port-channel-number*}

Parameters

- *interface* — A valid Ethernet port number.
- *port-channel-number* — A valid port-channel number.

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the switchport configuration for Ethernet port 1.map

```
Console# show interface switchport ethernet ext.1

Port 1:

VLAN Membership mode: General

Operating parameters:

PVID: 1 (default)

Ingress Filtering: Enabled

Acceptable Frame Type: All

GVRP status: Enabled

Protected: Enabled, Uplink is 1.

Port 1 is member in:

Vlan      Name          Egress rule    Type
----      -----        -----
1         default       untagged      System
8         VLAN008      tagged        Dynamic
11        VLAN011      tagged        Static
19        IPv6 VLAN    untagged     Static
72        VLAN0072     untagged     Static

Static configuration:

PVID: 1 (default)

Ingress Filtering: Enabled

Acceptable Frame Type: All

Port 1 is statically configured to:

Vlan      Name          Egress rule
```

VLAN Commands

VLAN	Name	Type
1	default	untagged
11	VLAN011	tagged
19	IPv6 VLAN	untagged
72	VLAN0072	untagged

Forbidden VLANS:

VLAN	Name
73	out

Console# **show interface switchport ethernet ext.1**

Port 1:

VLAN Membership mode: General

Operating parameters:

PVID: 4095 (discard vlan)

Ingress Filtering: Enabled

Acceptable Frame Type: All

Port 1 is member in:

Vlan	Name	Egress rule	Type
91	IP Telephony	tagged	Static

Static configuration:

PVID: 8

Ingress Filtering: Disabled

Acceptable Frame Type: All

Port 1 is statically configiured to:

Vlan	Name	Egress rule
8	VLAN0072	untagged
91	IP Telephony	tagged

```

Forbidden VLANS:
VLAN      Name
----      ---
73        out

Port 29

Static configuration:
PVID: 2922
Ingress Filtering: Enabled
Acceptable Frame Type: Untagged
GVRP status: Disabled

```

map protocol protocols-group

The **map protocol protocols-group** VLAN database command adds a special protocol to a named group of protocols, which may be used for protocol-based VLAN assignment. To delete a protocol from a group, use the **no** form of this command.

Syntax

```

map protocol protocol [encapsulation] protocols-group group
no map protocol protocol encapsulation

```

Parameters

- *protocol* — The protocol is a protocol number or one of the reserved names. The format is Hex format.
- *encapsulation* — One of the following values: **ethernet**, **rfc1042**, **llcOther**. If no option is indicated the default is **ethernet**.
- *group* — Group number of group of protocols associated together. (Range: 1-2147483647)

Default Configuration

This command has no default configuration.

Command Mode

VLAN Database mode

User Guidelines

The following protocol names are reserved:

- ip-arp
- ipx

Example

The following example maps protocol ip-arp to the group named "213".

```
Console (config)# vlan database
Console (config-vlan)# map protocol ip-arp protocols-group 213
```

switchport general map protocols-group vlan

The **switchport general map protocols-group vlan** interface configuration command sets a protocol-based classification rule. To delete a classification, use the **no** form of this command.

Syntax

```
switchport general map protocols-group group vlan vlan-id
no switchport general map protocols-group group
```

Parameters

- *group* — Group number as defined in the **map protocol protocols-group** command. (Range: 1-2147483647)
- *vlan-id* — Define the VLAN ID in the classifying rule.

Default Configuration

This command has no default configuration.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets a protocol-based classification rule of protocol group 1 to VLAN 8.

```
Console (config)# interface ethernet ext.8
Console (config-if)# switchport general map protocols-group 1 vlan 8
```

map mac macs-group

Use the **map mac macs-group** VLAN configuration command to map a MAC address or range of MAC addresses to a group of MAC addresses. Use the **no** form of this command to delete the map.

Syntax

```
map mac mac-address {prefix-mask | host} macs-group group
no map mac mac-address {prefix-mask | host}
```

Parameters

- *mac-address* - Specify MAC address to be entered to the group.
- *prefix-mask* - Mask bits. The format is “/n”, where *n* is an integer number that specifies the number of 1's in the mask.
- **host** - All 1's mask.
- *group* - Group number

Default Configuration

This command has no default configuration.

Command Mode

VLAN Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example maps the MAC address 00:13:20:95:21:AA to macs group 4.

```
Console(config-vlan)# map mac 00:13:20:95:21:AA host macs-group 4
```

switchport general map macs-group vlan

Use the **switchport general map macs-group vlan** interface configuration command to set a mac-based classification rule. Use the **no** form of this command to delete a classification.

Syntax

```
switchport general map macs-group group vlan vlan-id
no switchport general map macs-group group
```

Parameters

- *group* - Group number. Range:1 - 2147483647
- *vlan-id* - Define the VLAN ID that is associated with the rule.

Default Configuration

This command has no default configuration.

Command Mode

Interface configuration (Ethernet, port-channel)

User Guidelines

MAC based VLAN rules can't contain overlapping ranges on the same interface.

The priority between VLAN classification rules is:

1. MAC based VLAN (Best match between the rules)
2. Subnet based VLAN (Best match between the rules)
3. Protocol based VLAN
4. PVID

.

Example

The following example sets a mac-based classification rule.

```
Console (config-if)# switchport general map macs-group 1 vlan 8
```

map subnet subnets-group

Use the **map subnet subnets-group** VLAN configuration command to map IP subnet to a group of IP subnets. Use the **no** form of this command to delete the map.

Syntax

```
map subnet ip-address prefix-mask subnets-group group
no map subnet ip-address prefix-mask
```

Parameters

- **ip-address**Specify the IP address prefix of the subnet to be entered to the group.
- **prefix-mask**Mask bits. The format is IP address format.
- **group** Group number

Default Configuration

This command has no default configuration.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example configures the device as a virtual terminal for remote console access.

```
Console(config)# line telnet
Console(config-line) #
```

switchport general map subnets-group vlan

Use the **switchport general map subnets-group vlan** interface configuration command to set a subnet-based classification rule. Use the **no** form of this command to delete a classification.

Syntax

```
switchport general map subnets-group group vlan vlan-id
```

VLAN Commands

no switchport general map subnets-group *group*

Parameters

- *group* - Group number. Range: 1 - 2147483647
- *vlan-id* - Define the VLAN ID that is associated with the rule.

Default Configuration

This command has no default configuration.

Command Mode

Interface configuration (Ethernet, port-channel)

User Guidelines

The priority between VLAN classification rules is:

1. MAC based VLAN (Best match between the rules)
2. Subnet based VLAN (Best match between the rules)
3. Protocol based VLAN
4. PVID

Example

The following example sets the subnets-based classification rule.

```
Console (config-if)# switchport general map subnets-group 1 vlan 8
```

show vlan protocols-groups

The **show vlan protocols-groups** Privileged EXEC command displays protocols-groups information.

Syntax

show vlan protocols-groups

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays protocols-groups information.

Console# show vlan protocols-groups		
Encapsulation	Protocol	Group Id
-----	-----	-----
ethernet	08 00	213
ethernet	08 06	213
ethernet	81 37	312
ethernet	81 38	312
rfc1042	08 00	213
rfc1042	08 06	213

show vlan macs-groups

Use the **show vlan protocols-groups** EXEC command to show protocols-groups information.

Syntax

show vlan protocols-groups

Default Configuration

This command has no default configuration.

Command Mode

EXEC

User Guidelines

There are no user guidelines for this command.

Example

The following example displays protocols-groups information.

```
Console> show vlan protocols-groups
Protocol    EncapsulationGroup
-----
0x800  (IP)Ethernet    1
0x806  (ARP)Ethernet   1
0x86dd (IPv6)Ethernet  2
0x8898    Ethernet     3#
```

show vlan subnets-groups

Use the **show vlan subnets-groups** EXEC command to show subnets-groups information.

Syntax

```
show vlan subnets-groups
```

Parameters

- **console** — Console terminal line.
- **telnet** — Virtual terminal for remote console access (Telnet).
- **ssh** — Virtual terminal for secured remote console access (SSH).

Default Configuration

This command has no default configuration.

Command Mode

EXEC

User Guidelines

There are no user guidelines for this command.

Example

The following example shows subnets-groups information.

```
onsole> show vlan subnets-groups
MAC          Prefix        Group
-----
172.16.1.0  255.255.255.01
172.16.2.0  255.255.255.02#
```

VLAN Commands

29 802.1x Commands

aaa authentication dot1x

The **aaa authentication dot1x** Global Configuration mode command specifies one or more authentication, authorization, and accounting (AAA) methods for use on interfaces running IEEE 802.1x. To return to the default configuration, use the **no** form of this command.

Syntax

aaa authentication dot1x default method1 [method2...]

no aaa authentication dot1x default

Parameters

- *method1 [method2...]* — At least one from the following table:

Keyword	Description
RADIUS	Uses the list of all RADIUS servers for authentication
None	Uses no authentication

Default Configuration

No authentication method is defined.

Command Mode

Global Configuration mode

User Guidelines

Additional methods of authentication are used only if the previous method returns an error and not if the request for authentication is denied. To ensure that authentication succeeds even if all methods return an error, specify **none** as the final method in the command line.

The RADIUS server must support MD-5 challenge and EAP type frames.

Example

The following example uses the **aaa authentication dot1x default** command with no authentication.

```
Console# configure
Console(config)# aaa authentication dot1x default none
```

dot1x system-auth-control

The **dot1x system-auth-control** Global Configuration mode command enables 802.1x globally. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x system-auth-control
no dot1x system-auth-control
```

Default Configuration

802.1x is disabled globally.

Command Modes

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

Example

The following example enables 802.1x globally.

```
Console(config)# dot1x system-auth-control
```

dot1x port-control

The **dot1x port-control** Interface Configuration mode command enables manually controlling the authorization state of the port. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x port-control {auto | force-authorized | force-unauthorized}
no dot1x port-control
```

Parameters

- **auto** — Enables 802.1x authentication on the interface and causes the port to transition to the authorized or unauthorized state based on the 802.1x authentication exchange between the port and the client.
- **force-authorized** — Disables 802.1x authentication on the interface and causes the port to transition to the authorized state without any authentication exchange required. The port resends and receives normal traffic without 802.1x-based authentication of the client.
- **force-unauthorized** — Denies all access through this interface by forcing the port to transition to the unauthorized state and ignoring all attempts by the client to authenticate. The device cannot provide authentication services to the client through the interface.

Default Configuration

Port is in the force-authorized state

Command Mode

Interface Configuration (Ethernet)

User Guidelines

It is recommended to disable spanning tree or to enable spanning-tree PortFast mode on 802.1x edge ports (ports in **auto** state that are connected to end stations), in order to get immediately to the forwarding state after successful authentication.

Example

The following example enables 802.1x authentication on Ethernet port 16.

```
Console(config)# interface ethernet ext.16
Console(config-if)# dot1x port-control auto
```

dot1x re-authentication

The **dot1x re-authentication** Interface Configuration mode command enables periodic re-authentication of the client. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x re-authentication  
no dot1x re-authentication
```

Default Configuration

Periodic re-authentication is disabled.

Command Mode

Interface Configuration (Ethernet)

User Guidelines

There are no user guidelines for this command.

Example

The following example enables periodic re-authentication of the client.

```
Console(config)# interface ethernet ext.16  
Console(config-if)# dot1x re-authentication
```

dot1x timeout re-authperiod

The **dot1x timeout re-authperiod** Interface Configuration mode command sets the number of seconds between re-authentication attempts. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x timeout re-authperiod seconds  
no dot1x timeout re-authperiod
```

Parameters

- **seconds** — Number of seconds between re-authentication attempts. (Range: 300-4294967295)

Default Configuration

Re-authentication period is 3600 seconds.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

There are no user guidelines for this command.

Example

The following example sets the number of seconds between re-authentication attempts, to 300.

```
Console(config)# interface ethernet ext.16
Console(config-if)# dot1x timeout re-authperiod 300
```

dot1x re-authenticate

The **dot1x re-authenticate** Privileged EXEC mode command manually initiates a re-authentication of all 802.1x-enabled ports or the specified 802.1x-enabled port.

Syntax

dot1x re-authenticate [ethernet *interface*]

Parameters

- **interface** — Valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following command manually initiates a re-authentication of 802.1x-enabled Ethernet port 16.

```
Console# dot1x re-authenticate ethernet ext.16
```

dot1x timeout quiet-period

The **dot1x timeout quiet-period** Interface Configuration mode command sets the number of seconds that the device remains in the quiet state following a failed authentication exchange (for example, the client provided an invalid password). To return to the default configuration, use the **no** form of this command.

Syntax

dot1x timeout quiet-period *seconds*

no dot1x timeout quiet-period

Parameters

- *seconds* — Specifies the time in seconds that the device remains in the quiet state following a failed authentication exchange with the client. (Range: 0-65535 seconds)

Default Configuration

Quiet period is 60 seconds.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

During the quiet period, the device does not accept or initiate authentication requests.

The default value of this command should only be changed to adjust for unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

To provide a faster response time to the user, a smaller number than the default value should be entered.

Example

The following example sets the number of seconds that the device remains in the quiet state following a failed authentication exchange to 3600.

```
Console(config)# interface ethernet ext.16
Console(config-if)# dot1x timeout quiet-period 3600
```

dot1x timeout tx-period

The **dot1x timeout tx-period** Interface Configuration mode command sets the number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP)-request/identity frame from the client before resending the request. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x timeout tx-period seconds
no dot1x timeout tx-period
```

Parameters

- *seconds* — Specifies the time in seconds that the device waits for a response to an EAP-request/identity frame from the client before resending the request. (Range: 1-65535 seconds)

Default Configuration

Timeout period is 30 seconds.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The default value of this command should be changed only to adjust for unusual circumstances, such as unreliable links or specific behavioral problems with certain clients. and authentication servers

Example

The following command sets the number of seconds that the device waits for a response to an EAP-request/identity frame, to 3600 seconds.

```
Console(config)# interface ethernet ext.16
Console(config-if)# dot1x timeout tx-period 3600
```

dot1x max-req

The **dot1x max-req** Interface Configuration mode command sets the maximum number of times that the device sends an Extensible Authentication Protocol (EAP)-request/identity frame (assuming that no response is received) to the client, before restarting the authentication process. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x max-req count
no dot1x max-req
```

Parameters

- *count* — Number of times that the device sends an EAP-request/identity frame before restarting the authentication process. (Range: 1-10)

Default Configuration

The default number of times is 2.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The default value of this command should be changed only to adjust for unusual circumstances, such as unreliable links or specific behavioral problems with certain clients. and authentication servers

Example

The following example sets the number of times that the device sends an EAP-request/identity frame to 6 .

```
Console(config)# interface ethernet ext.16
Console(config-if)# dot1x max-req 6
```

dot1x timeout supp-timeout

The **dot1x timeout supp-timeout** Interface Configuration mode command sets the time for the retransmission of an Extensible Authentication Protocol (EAP)-request frame to the client. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x timeout supp-timeout seconds
no dot1x timeout supp-timeout
```

Parameters

- *seconds* — Time in seconds that the device waits for a response to an EAP-request frame from the client before resending the request. (Range: 1- 65535 seconds)

Default Configuration

Default timeout period is 30 seconds.

Command Mode

Interface configuration (Ethernet) mode

User Guidelines

The default value of this command should be changed only to adjust for unusual circumstances, such as unreliable links or specific behavioral problems with certain clients. and authentication servers

Example

The following example sets the timeout period before retransmitting an EAP-request frame to the client to 3600 seconds.

```
Console(config-if)# dot1x timeout supp-timeout 3600
```

dot1x timeout server-timeout

The **dot1x timeout server-timeout** Interface Configuration mode command sets the time that the device waits for a response from the authentication server. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x timeout server-timeout seconds  
no dot1x timeout server-timeout
```

Parameters

- *seconds* — Time in seconds that the device waits for a response from the authentication server. (Range: 1-65535 seconds)

Default Configuration

The timeout period is 30 seconds.

Command Mode

Interface configuration (Ethernet) mode

User Guidelines

The actual timeout can be determined by comparing the **dot1x timeout server-timeout** value and the result of multiplying the **radius-server retransmit** value with the **radius-server timeout** value and selecting the lower of the two values.

Example

The following example sets the time for the retransmission of packets to the authentication server to 3600 seconds.

```
Console(config-if)# dot1x timeout server-timeout 3600
```

show dot1x

The **show dot1x** Privileged EXEC mode command displays the 802.1x status of the device or specified interface.

Syntax

show dot1x [ethernet *interface*]

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays the status of 802.1x-enabled Ethernet ports.

```
Console# show dot1x
```

802.1x is enabled

Port	Admin Mode	Oper Mode	Reauth Control	Reauth Period	Username
---	-----	-----	-----	-----	-----
1	Auto	Authorized	Ena	3600	Bob
2	Auto	Authorized	Ena	3600	John
3	Auto	Unauthorized	Ena	3600	Clark
4	Force-auth	Authorized	Dis	3600	n/a
5	Force-auth	Unauthorized*	Dis	3600	n/a

802.1x Commands

```
* Port is down or not present.
```

```
Console# show dot1x ethernet ext.3
```

```
802.1x is enabled.
```

Port	Admin Mode	Oper Mode	Reauth Control	Reauth Period	Username
---	-----	-----	-----	-----	-----
3	Auto	Unauthorized	Ena	3600	Clark

```
Quiet period: 60 Seconds
```

```
Tx period:30 Seconds
```

```
Max req: 2
```

```
Supplicant timeout: 30 Seconds
```

```
Server timeout: 30 Seconds
```

```
Session Time (HH:MM:SS): 08:19:17
```

```
MAC Address: 00:08:78:32:98:78
```

```
Authentication Method: Remote
```

```
Termination Cause: Supplicant logoff
```

```
Authenticator State Machine
```

```
State: HELD
```

```
Backend State Machine
```

```
State: IDLE
```

```
Authentication success: 9
```

```
Authentication fails: 1
```

The following table describes significant fields shown above:

Field	Description
Port	The port number.
Admin mode	The port admin mode. Possible values: Force-auth, Force-unauth, Auto.
Oper mode	The port oper mode. Possible values: Authorized, Unauthorized or Down.
Reauth Control	Reauthentication control.
Reauth Period	Reauthentication period.

Field	Description
Username	The username representing the identity of the Supplicant. This field shows the username in case the port control is auto. If the port is Authorized, it shows the username of the current user. If the port is unauthorized it shows the last user that was authenticated successfully.
Quiet period	The number of seconds that the device remains in the quiet state following a failed authentication exchange (for example, the client provided an invalid password).
Tx period	The number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP)-request/identity frame from the client before resending the request.
Max req	The maximum number of times that the device sends an Extensible Authentication Protocol (EAP)-request frame (assuming that no response is received) to the client before restarting the authentication process.
Supplicant timeout	Time in seconds the switch waits for a response to an EAP-request frame from the client before resending the request.
Server timeout	Time in seconds the switch waits for a response from the authentication server before resending the request.
Session Time	The amount of time the user is logged in.
MAC address	The supplicant MAC address.
Authentication Method	The authentication method used to establish the session.
Termination Cause	The reason for the session termination.
State	The current value of the Authenticator PAE state machine and of the Backend state machine.
Authentication success	The number of times the state machine received a Success message from the Authentication Server.
Authentication fails	The number of times the state machine received a Failure message from the Authentication Server.

show dot1x users

The **show dot1x users** Privileged EXEC mode command displays active 802.1x authenticated users for the device.

Syntax

```
show dot1x users [username username]
```

Parameters

- *username* — Supplicant username (Range: 1-160 characters)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays 802.1x users.

Console# show dot1x users				
Port	Username	Session Time	Auth Method	MAC Address
1	Bob	1d:03:08.58	Remote	0008:3b79:8787
2	John	08:19:17	None	0008:3b89:3127
Console# show dot1x users username Bob				
Username: Bob				
Port	Username	Session Time	Auth Method	MAC Address
1	Bob	1d:03:08.58	Remote	0008:3b79:8787

The following table describes significant fields shown above:

Field	Description
Port	The port number.
Username	The username representing the identity of the Supplicant.
Session Time	The period of time the Supplicant is connected to the system.
Authentication Method	Authentication method used by the Supplicant to open the session.
MAC Address	MAC address of the Supplicant.

show dot1x statistics

The **show dot1x statistics** Privileged EXEC mode command displays 802.1x statistics for the specified interface.

Syntax

show dot1x statistics ethernet *interface*

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays 802.1x statistics for the specified interface.

```
Console# show dot1x statistics ethernet ext.1

EapolFramesRx: 11
EapolFramesTx: 12
EapolStartFramesRx: 12
EapolLogoffFramesRx: 1
EapolRespIdFramesRx: 3
EapolRespFramesRx: 6
EapolReqIdFramesTx: 3
EapolReqFramesTx: 6
InvalidEapolFramesRx: 0
EapLengthErrorFramesRx: 0
```

LastEapolFrameVersion: 1
LastEapolFrameSource: 00:08:78:32:98:78

The following table describes the significant fields shown in the display:

Field	Description
EapolFramesRx	The number of valid EAPOL frames of any type that have been received by this Authenticator.
EapolFramesTx	The number of EAPOL frames of any type that have been transmitted by this Authenticator.
EapolStartFramesRx	The number of EAPOL Start frames that have been received by this Authenticator.
EapolLogoffFramesRx	The number of EAPOL Logoff frames that have been received by this Authenticator.
EapolRespldFramesRx	The number of EAP Resp/Id frames that have been received by this Authenticator.
EapolRespFramesRx	The number of valid EAP Response frames (other than Resp/Id frames) that have been received by this Authenticator.
EapolReqldFramesTx	The number of EAP Req/Id frames that have been transmitted by this Authenticator.
EapolReqFramesTx	The number of EAP Request frames (other than Rq/Id frames) that have been transmitted by this Authenticator.
InvalidEapolFramesRx	The number of EAPOL frames that have been received by this Authenticator in which the frame type is not recognized.
EapLengthErrorFramesRx	The number of EAPOL frames that have been received by this Authenticator in which the Packet Body Length field is invalid.
LastEapolFrameVersion	The protocol version number carried in the most recently received EAPOL frame.
LastEapolFrameSource	The source MAC address carried in the most recently received EAPOL frame.

ADVANCED FEATURES

dot1x auth-not-req

The **dot1x auth-not-req** Interface Configuration mode command enables unauthorized devices access to the VLAN. To disable access to the VLAN, use the **no** form of this command.

Syntax

dot1x auth-not-req

no dot1x auth-not-req

Default Configuration

Access is enabled.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

An access port cannot be a member in an unauthenticated VLAN.

The native VLAN of a trunk port cannot be an unauthenticated VLAN.

For a general port, the PVID can be an unauthenticated VLAN (although only tagged packets would be accepted in the unauthorized state.)

Example

The following example enables access to the VLAN to unauthorized devices.

```
Console(config-if)# dot1x auth-not-req
```

dot1x multiple-hosts

The **dot1x multiple-hosts** Interface Configuration mode command enables multiple hosts (clients) on an 802.1x-authorized port, where the authorization state of the port is set to **auto**. To return to the default configuration, use the **no** form of this command.

Syntax

dot1x multiple-hosts

no dot1x multiple-hosts

Default Configuration

Multiple hosts are disabled.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

This command enables the attachment of multiple clients to a single 802.1x-enabled port. In this mode, only one of the attached hosts must be successfully authorized for all hosts to be granted network access. If the port becomes unauthorized, all attached clients are denied access to the network.

For unauthenticated VLANs, multiple hosts are always enabled.

Multiple-hosts must be enabled to enable port security on the port.

Example

The following command enables multiple hosts (clients) on an 802.1x-authorized port.

```
Console(config-if)# dot1x multiple-hosts
```

dot1x single-host-violation

The **dot1x single-host-violation** Interface Configuration mode command configures the action to be taken, when a station whose MAC address is not the supplicant MAC address, attempts to access the interface. Use the **no** form of this command to return to default.

Syntax

```
dot1x single-host-violation {forward | discard | discard-shutdown} [trap seconds]
no port dot1x single-host-violation
```

Parameters

- **forward** — Forwards frames with source addresses that are not the supplicant address, but does not learn the source addresses.
- **discard** — Discards frames with source addresses that are not the supplicant address.
- **discard-shutdown** — Discards frames with source addresses that are not the supplicant address. The port is also shut down.
- **trap** — Indicates that SNMP traps are sent.
- **seconds** — Specifies the minimum amount of time in seconds between consecutive traps. (Range: 1- 1000000)

Default Configuration

Frames with source addresses that are not the supplicant address are discarded.

No traps are sent.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The command is relevant when multiple hosts is disabled and the user has been successfully authenticated.

Example

The following example forwards frames with source addresses that are not the supplicant address and sends consecutive traps at intervals of 100 seconds.

```
Console(config-if)# dot1x single-host-violation forward trap 100
```

dot1x guest-vlan

The **dot1x guest-vlan** Interface Configuration mode command defines a guest VLAN. To return to the default configuration, use the **no** form of this command.

Syntax

```
dot1x guest-vlan  
no dot1x guest-vlan
```

Default Configuration

No VLAN is defined as a guest VLAN.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Use the **dot1x guest-vlan enable** Interface Configuration mode command to enable unauthorized users on an interface to access the guest VLAN.

If the guest VLAN is defined and enabled, the port automatically joins the guest VLAN when the port is unauthorized and leaves it when the port becomes authorized. To be able to join or leave the guest VLAN, the port should not be a static member of the guest VLAN.

Example

The following example defines VLAN 2 as a guest VLAN.

```
Console#  
Console# configure  
Console(config)# vlan database  
Console(config-vlan)# vlan 2  
Console(config-vlan)# exit  
Console(config)# interface vlan 2  
Console(config-if)# dot1x guest-vlan
```

dot1x guest-vlan enable

The **dot1x vlans guest-vlan enable** Interface Configuration mode command enables unauthorized users on the interface access to the Guest VLAN. To disable access, use the **no** form of this command

Syntax

```
dot1x guest-vlan enable  
no dot1x guest-vlan enable
```

Default Configuration

Disabled.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

A device can have only one global guest VLAN. The guest VLAN is defined using the **dot1x guest-vlan** Interface Configuration mode command.

Example

The following example enables unauthorized users on Ethernet port 1 to access the guest VLAN.

```
Console# configure
Console(config)# interface ethernet ext.1
Console(config-if)# dot1x guest-vlan enable
```

show dot1x advanced

The **show dot1x advanced** Privileged EXEC mode command displays 802.1x advanced features for the device or specified interface.

Syntax

show dot1x advanced [ethernet *interface*]

Parameters

- *interface* — Valid Ethernet port. (Full syntax: *unit/port*)

Default Configuration

This command has no default configuration.

Command Mode

Privileged EXEC mode

User Guidelines

There are no user guidelines for this command.

Example

The following example displays 802.1x advanced features for the device.

```
Console# show dot1x advanced

Guest VLAN: 2
Unauthenticated VLANs: 91,92
```

802.1x Commands

Interface	Multiple Hosts	Guest VLAN
-----	-----	-----
1	Disabled	Enabled
2	Enabled	Disabled

```
Console# show dot1x advanced ethernet ext.1
```

Interface	Multiple Hosts	Guest VLAN
-----	-----	-----
1	Disabled	Enabled

Single host parameters

Violation action: Discard

Trap: Enabled

Trap frequency: 100

Status: Single-host locked

Violations since last trap: 9

Appendix A: Getting Help

World Wide Web

<http://support.intel.com/support/motherboards/server/blade.htm>.

Telephone

All calls are billed US \$25.00 per incident, levied in local currency at the applicable credit card exchange rate plus applicable taxes. (Intel reserves the right to change the pricing for telephone support at any time without notice).

Before calling, fill out an *Intel Server Issue Report Form* available from <http://support.intel.com/support>. For the fastest service, please submit your form via the Internet.

For an updated support contact list, see <http://www.intel.com/support/9089.htm>

U.S. and Canada

1-800-404-2284

Europe

Belgium 02 714 3182

Denmark ... 38 487077

Finland 9 693 79297

France..... 01 41 918529

Germany ... 069 9509 6099

Holland 020 487 4562

Italy..... 02 696 33276

Norway 23 1620 50

Spain 91 377 8166

Sweden..... 08 445 1251

UK..... 870 6072439

In Asia-Pacific Region

Australia.... 1800 649931

Cambodia.. 63 2 636 9797 (via Philippines)

China 800 820 1100 (toll-free)

..... 8 621 33104691 (not toll-free)

Hong Kong 852 2 844 4456

India..... 0006517 2 68303634 (manual toll-free. You need an IDD-equipped telephone)

Indonesia... 803 65 7249

Korea 822 767 2595

Malaysia 1 800 80 1390

Myanmar... 63 2 636 9796 (via Philippines)

New Zealand 0800 444 365

Pakistan..... 632 63684 15 (IDD via Philippines)

Philippines 1 800 1 651 0117

Singapore .. 65 6213-1311

Taiwan 2 2545-1640

Thailand 1 800 631 0003

Vietnam 632 6368416 (IDD via Philippines)

Japan

Domestic.... 0120 868686

Outside country 81 298 47 0800

Latin America

Argentina .. Contact AT&T USA at 0-800 222 1288. Once connected, dial 800 843 4481

Brazil 001-916 377 0180

Chile

Easter Island. Contact AT&T USA at 800 800 311. Once connected, dial 800 843 4481

Mainland and Juan .. Contact AT&T USA at 800 225 288. Once connected, dial 800 843 4481

Colombia... Contact AT&T USA at 01 800 911 0010. Once connected, dial 800 843 4481

Costa Rica . Contact AT&T USA at 0 800 0 114 114. Once connected, dial 800 843 4481

Ecuador

(**Andimate**) Contact AT&T USA at 1 999 119. Once connected, dial 800 843 4481

(**Pacifictel**) Contact AT&T USA at 1 800 225 528. Once connected, dial 800 843 4481

Guatemala. Contact AT&T USA at 99 99 190. Once connected, dial 800 843 4481

Mexico Contact AT&T USA at 001 800 462 628 4240. Once connected, dial 800 843 4481

Miami 1 800 621 8423

Panama..... Contact AT&T USA at 00 800 001 0109. Once connected, dial 800 843 4481

Paraguay ... 001 916 377 0114

Peru 001 916 377 0114

Uruguay.... 001 916 377 0114

Venezuela... Contact AT&T USA at 0 800 2255 288. Once connected, dial 800 843 4481

