



BY APPOINTMENT TO
HER MAJESTY QUEEN ELIZABETH II
MANUFACTURERS OF DAIMLER AND JAGUAR CARS
JAGUAR CARS LIMITED COVENTRY




BY APPOINTMENT TO
HER MAJESTY QUEEN ELIZABETH
THE QUEEN MOTHER
MANUFACTURERS OF DAIMLER AND JAGUAR CARS
JAGUAR CARS LIMITED COVENTRY



BY APPOINTMENT TO
HIS ROYAL HIGHNESS THE PRINCE OF WALES
MANUFACTURERS OF DAIMLER AND JAGUAR CARS
JAGUAR CARS LIMITED COVENTRY

JAGUAR S-TYPE

2002 Model Year Electrical Guide



Published by Parts and Service Communications
Jaguar Cars Limited

Publication Part Number – JJM 10 38 16/25





| | |
|----------------------------------|--|
| Table of Contents: Figures | 2 – 3 |
| Abbreviations and Acronyms | 4 |
| Introduction | 5 |
| Symbols and Codes | 6 – 8 |
| Network Configuration | 9 |
| Fuse Box Location | 10 |
| Relay and Fuse Location | 11 |
| Harness In-Line Connectors | 12 – 13 |
| Control Module Location | 14 – 15 |
| Ground Point Location | 16 |
| Electrical Guide Figures | follows after page 16 (pages are numbered by Figure number) |

**FIGURES**

| Fig. | Description | Variant |
|---|--|---|
| 01 Power Distribution | | |
| Fig. 01.1 | Main Power Distribution | All Vehicles |
| Fig. 01.2 | Battery Power Distribution: Part 1 | All Vehicles |
| Fig. 01.3 | Battery Power Distribution: Part 2 | All Vehicles |
| Fig. 01.4 | Ignition Switched Power Distribution: I (Accessory) | All Vehicles |
| Fig. 01.5 | Ignition Switched Power Distribution: II (Run) | All Vehicles |
| Fig. 01.6 | Switched System Power Distribution | All Vehicles |
| Fig. 01.7 | Engine Management System Switched Power Distribution | All Vehicles |
| 02 Battery; Starter; Generator | | |
| Fig. 02.1 | Battery; Starter; Generator: V6 | V6 Vehicles |
| Fig. 02.2 | Battery; Starter; Generator: V8 | V8 Vehicles |
| 03 Engine Management | | |
| Fig. 03.1 | Engine Management: V6 – Part 1 | V6 Vehicles |
| Fig. 03.2 | Engine Management: V6 – Part 2 | V6 Vehicles |
| Fig. 03.3 | Engine Management: V8 N/A – Part 1 | V8 N/A Vehicles |
| Fig. 03.4 | Engine Management: V8 N/A – Part 2 | V8 N/A Vehicles |
| Fig. 03.5 | Engine Management: V8 SC – Part 1 | V8 SC Vehicles |
| Fig. 03.6 | Engine Management: V8 SC – Part 2 | V8 SC Vehicles |
| 04 Transmission | | |
| Fig. 04.1 | Transmissions | All Vehicles |
| 05 Chassis | | |
| Fig. 05.1 | Dynamic Stability Control | All Vehicles |
| Fig. 05.2 | Electronic Parking Brake; Variable Assist Power Steering | All Vehicles |
| Fig. 05.3 | Adaptive Speed Control | Adaptive Speed Control Vehicles |
| Fig. 05.4 | Suspension Adaptive Damping | Adaptive Damping Vehicles |
| 06 Climate Control | | |
| Fig. 06.1 | Climate Control System; Windshield Heaters | All Vehicles |
| 07 Instrumentation | | |
| Fig. 07.1 | Instrument Cluster; Audible Warnings | All Vehicles |
| 08 Exterior Lighting | | |
| Fig. 08.1 | Exterior Lighting: Front | Non HID Headlamp Vehicles |
| Fig. 08.2 | Exterior Lighting: Front – HID | HID Headlamp Vehicles |
| Fig. 08.3 | Exterior Lighting: Rear | All Vehicles |
| Fig. 08.4 | Exterior Lighting: Rear – Trailer Towing | Trailer Towing Vehicles |
| Fig. 08.5 | Headlamp Leveling | Headlamp Leveling Vehicles |
| 09 Interior Lighting | | |
| Fig. 09.1 | Interior Lighting | All Vehicles |
| Fig. 09.2 | Dimmer-Controlled Lighting | All Vehicles |
| 10 Steering Column; Pedals; Mirrors; Heaters | | |
| Fig. 10.1 | Steering Column Adjust; Pedal Adjust | All Vehicles |
| Fig. 10.2 | Door Mirrors: Movement and Heaters; Heated Rear Window | All Vehicles |
| Fig. 10.3 | Electrochromic Rear View Mirror; Fold-Back Mirrors | All Vehicles; Fold-Back Mirror Vehicles |

**FIGURES**

| Fig. | Description | Variant |
|-----------------|--|--|
| 11 | Seat Systems | |
| Fig. 11.1 | Driver Seat: 10-Way Movement with Memory | 10-Way Driver Seat Memory Vehicles |
| Fig. 11.2 | Driver Seat: 16-Way Movement with Memory | 16-Way Driver Seat Memory Vehicles |
| Fig. 11.3 | Driver Seat: Non Memory | Non Memory Driver Seat Vehicles |
| Fig. 11.4 | Passenger Seat | 6 / 8 / 10-Way Passenger Seat Vehicles |
| Fig. 11.5 | Passenger Seat: 16-Way Movement | 16-Way Passenger Seat Vehicles |
| Fig. 11.6 | Seat Heaters | Heated Seat Vehicles |
| 12 | Central Locking; Security | |
| Fig. 12.1 | Central Locking: Double Locking | Double Locking Vehicles |
| Fig. 12.2 | Central Locking: Non Double Locking | Non Double Locking Vehicles |
| Fig. 12.3 | Security System | All Vehicles |
| 13 | Wash / Wipe | |
| Fig. 13.1 | Wash / Wipe System | All Vehicles |
| 14 | Powered Windows; Sliding Roof | |
| Fig. 14.1 | Powered Windows; Sliding Roof | All Vehicles |
| 15 | In-Car Entertainment | |
| Fig. 15.1 | In-Car Entertainment: Standard | Standard ICE Vehicles |
| Fig. 15.2 | In-Car Entertainment: Premium | Premium ICE Vehicles |
| 16 | Telematics | |
| Fig. 16.1 | Telephone System: ROW | ROW Vehicles |
| Fig. 16.2 | Telephone System: NAS | NAS Vehicles |
| Fig. 16.3 | Telephone System with Voice: ROW | ROW Vehicles |
| Fig. 16.4 | Telephone System with Voice: NAS | NAS Vehicles |
| Fig. 16.5 | Voice Control System | Voice Only Vehicles |
| Fig. 16.6 | Navigation System (except Japan) | Navigation Vehicles (except Japan) |
| Fig. 16.7 | Navigation System with TV (except Japan) | Navigation Vehicles with TV (except Japan) |
| Fig. 16.8 | Navigation System: Japan | Japan Navigation Vehicles |
| 17 | Occupant Protection | |
| Fig. 17.1 | Advanced Restraint System: Part 1 | All Vehicles |
| Fig. 17.2 | Advanced Restraint System: Part 2 | All Vehicles |
| 18 | Driver Assist | |
| Fig. 18.1 | Parking Aid System | Parking Aid Vehicles |
| 19 | Ancillaries | |
| Fig. 19.1 | Ancillaries: Horn, Cigar Lighter, Power Point, Accessory Connector, Sun Shade, Singapore Road Pricing | All Vehicles |
| 20 | Vehicle Multiplex Systems | |
| Fig. 20.1 | Controller Area Network | All Vehicles |
| Fig. 20.2 | Standard Corporate Protocol Network; Serial Data Link | All Vehicles |
| Fig. 20.3 | D2B Network: Part 1 | All Vehicles |
| Fig. 20.4 | D2B Network: Part 2 | All Vehicles |
| Fig. 20.5 | D2B Network: Part 3 | All Vehicles |



The following abbreviations and acronyms are used throughout this Electrical Guide:

| | |
|---------------------------|---|
| A/C | Air Conditioning |
| A/CCM | Air Conditioning Control Module |
| APP SENSOR | Accelerator Pedal Position Sensor |
| APP1 | Accelerator Pedal Position Sensor Element 1 |
| APP2 | Accelerator Pedal Position Sensor Element 2 |
| AUTO | Automatic Transmission |
| B+ | Battery Voltage |
| BANK 1 | RH Cylinder Bank (Cylinders 1, 3, 5, 7) |
| BANK 2 | LH Cylinder Bank (Cylinders 2, 4, 6, 8) |
| CAN | Controller Area Network |
| CKP SENSOR | Crankshaft Position Sensor |
| CM | Control Module |
| CMP SENSOR / 1 | Camshaft Position Sensor / RH Bank |
| CMP SENSOR / 2 | Camshaft Position Sensor / LH Bank |
| D2B | D2B Network |
| DSC | Dynamic Stability Control |
| ECM | Engine Control Module |
| ECT SENSOR | Engine Coolant Temperature Sensor |
| EFT SENSOR | Engine Fuel Temperature Sensor |
| EGT SENSOR | Exhaust Gas Temperature Sensor |
| EOT SENSOR | Engine Oil Temperature Sensor |
| EVAP CANISTER CLOSE VALVE | Evaporative Emission Canister Close Valve |
| EVAP CANISTER PURGE VALVE | Evaporative Emission Canister Purge Valve |
| FTP SENSOR | Fuel Tank Pressure Sensor |
| GECM | General Electronic Control Module |
| GPS | Global Positioning System |
| HID | High Intensity Discharge |
| HO2 SENSOR 1 / 1 | Heated Oxygen Sensor – RH Bank / Upstream |
| HO2 SENSOR 1 / 2 | Heated Oxygen Sensor – RH Bank / Downstream |
| HO2 SENSOR 2 / 1 | Heated Oxygen Sensor – LH Bank / Upstream |
| HO2 SENSOR 2 / 2 | Heated Oxygen Sensor – LH Bank / Downstream |
| IAT SENSOR | Intake Air Temperature Sensor |
| IC | Instrument Cluster |
| ICE | In-Car Entertainment System |
| IMT VALVE / 1 | Intake Manifold Tuning Valve / Top |
| IMT VALVE / 2 | Intake Manifold Tuning Valve / Bottom |
| IP SENSOR | Injection Pressure Sensor |
| KS / 1 | Knock Sensor / RH Bank |
| KS / 2 | Knock Sensor / LH Bank |
| LH | Left Hand |
| LHD | Left Hand Drive |
| MAF SENSOR | Mass Air Flow Sensor |
| MAN | Manual Transmission |
| MAP SENSOR | Manifold Absolute Pressure Sensor |
| N/A | Normally Aspirated |
| NAS | North American Specification |
| PATS | Passive Anti-Theft System |
| PWM | Pulse Width Modulated |
| RH | Right Hand |
| RHD | Right Hand Drive |
| ROW | Rest of World |
| SCP | Standard Corporate Protocol Network |
| TCM | Transmission Control Module |
| TP SENSOR | Throttle Position Sensor |
| TP1 | Throttle Position Sensor Element 1 |
| TP2 | Throttle Position Sensor Element 2 |
| TURN | Turn Signal |
| TV | Television |
| V6 | V6 Engine |
| V8 | V8 Engine |
| VICS | Vehicle Information Control System |
| VVT VALVE / 1 | Variable Valve Timing Valve / Bank 1 |
| VVT VALVE / 2 | Variable Valve Timing Valve / Bank 2 |
| +ve | Positive |
| -ve | Negative |



Provisional Electrical Guide Format

This Provisional Electrical Guide is an abridged version made up of two sections. The first section provides general information for and about the use of the book and information and illustrations to aid in the location of components.

The Figure section illustrates detailed electrical circuit information for each system on the vehicle. Each Figure is identified by a Figure Number (i.e. Fig. 01.1) and Title. The data that normally accompanies each Figure is not included in this Provisional version.

It is recommended that the user read through the front section of the book to develop a familiarity with the layout of the book and with the system of symbols and abbreviations used. The Table of Contents should help to guide the user.

Jaguar S-TYPE Electrical System Architecture

Power Supplies

The Jaguar S-TYPE electrical system is a supply-side switched system. The ignition switch directly carries much of the ignition switched power supply load. Power supply is provided via three methods: direct battery power supply, ignition switched power supply, and "Switched System Power Supply". The "Switched System Power Supply" circuit is controlled via the GECM (General Electronic Control Module) and the RECM (Rear Electronic Control Module). Refer to Figure 01.6 for circuit activation details.

Fuse Boxes

The electrical harness incorporates two hard-wired power distribution fuse boxes: the Front Power Distribution Fuse Box located in the engine compartment and the Rear Power Distribution Fuse Box located in the trunk. A serviceable Primary Junction Fuse Box is located in the front right-hand foot well. All fuses and relays (except the trailer towing accessory kit) are located in the two fuse boxes.


Vehicle Networks

The New Jaguar S-TYPE employs three different networks: a CAN (Controller Area Network) for high-speed power train communications, an SCP (Standard Corporate Protocol) network for slower speed body systems communications, and a D2B (Optical) Network for very high-speed "real-time" audio data transfer. The D2B Network is a fiber optic network with a gateway to the remaining vehicle networks via the Audio Unit. Technician access to the three networks and the Serial Data Link is via the Data Link Connector.

Ground Studs

Circuit ground connections are made at body studs located throughout the vehicle. There are no separate power and logic grounding systems; however, there are a certain number of components that use unique ground points.

S-TYPE INSTRUMENT PANEL





NOTE: In the examples on this page, an 'X' is used where a number would appear on an actual Figure.

Reference Symbols

| |
|--|
| Battery power supply |
| Ignition switched auxiliary power supply (key I, II) |
| Ignition switched power supply (key II, III) |
| Switched System Power Supply power supply |
| Engine Management System power supply |
| Figure number reference |
| Controller Area Network |
| Standard Corporate Protocol network |
| D2B network |


Control Module Pin Symbols

| | |
|--------------------------|-------------------------|
| Input | CAN network |
| Output | SCP network |
| Battery voltage | D2B network |
| Power ground | Serial and encoded data |
| Sensor/signal supply V * | |
| Sensor/signal ground ** | |

* May also indicate Reference Voltage.

** May also indicate Reference Ground or Logic Ground.
Refer to Control Module Pin-Out Information.

Wiring Symbols





Harness Codes

| | |
|----|----------------------------|
| AC | Climate Control Link |
| AT | Alarm Link |
| BF | Front Fog Lamp Harness |
| BR | Rear Bumper Harness |
| CA | Cabin Harness |
| CP | Intercooler Pump Link |
| CV | Canister Vent Link |
| DD | Driver Door Harness |
| DM | Driver Memory Seat Harness |
| DT | Driver Door Trim Link |
| FC | Fascia Harness |
| FH | Front Harness |
| FL | LH Front Headlamp Link |
| FP | Fuel Pump Harness |
| FR | RH Front Headlamp Link |
| GB | Transmission Harness |
| IL | Fuel Injector Link |
| PD | Passenger Door |
| PI | Engine Harness |
| PN | Passenger Seat Harness |
| PT | Passenger Door Trim Link |
| RA | D2B Network Harness |
| RF | Roof Harness |
| SL | Solar Sensor Link |
| SR | Sliding Roof Harness |
| SW | Subwoofer Link |
| TT | Trailer Tow Harness |

Wiring Color Codes

| | | | |
|---|--------|-----|---------------------------------|
| N | Brown | O | Orange |
| B | Black | S | Slate |
| W | White | L | Light |
| K | Pink | U | Blue |
| G | Green | P | Purple |
| R | Red | BRD | Braid |
| Y | Yellow | BOF | Black fiber optic (D2B Network) |

Code Numbering


When numbering connectors, grounds and splices, Jaguar Engineering uses a three-position format: CA001, CA002, etc. Because space is limited in this Electrical Guide the codes have, in most cases, been shortened. Thus CA001-001 becomes CA1-1, CA002-001 becomes CA2-1, etc.




Grounds

On figures where LHD and RHD circuits are combined and the ground designation differs from LHD to RHD, the RHD ground code is shown in parentheses. If the ground designation is the same for LHD and RHD, only one ground code is used, with no parentheses.

EXAMPLE:



LHD Vehicles
RHD Vehicles




Same for LHD and RHD Vehicles


Relays

All relays are located in the Front and Rear Power Distribution Boxes and the Primary Junction Fuse Box. Relays do not have a separate relay connector (base). All relays use the ISO pin numbering system (1, 2, 3, 4, 5). Each relay is identified by an "R" number unique only to the fuse box in which it is located.

EXAMPLE:



CHANGE-OVER RELAY



NORMALLY OPEN RELAY

Fuses

All fuses are located in the Front and Rear Power Distribution Boxes and the Primary Junction Fuse Box. Each fuse is identified by an "F" number unique only to the fuse box in which it is located.


EXAMPLE:

F19 15A

Networks

In most instances, networks are shown as a broken grey line to indicate that there is network communication between the depicted control modules. Refer to Figures 20.1, 20.2, 20.3, 20.4 and 20.5 for circuit details.

EXAMPLE:



Component Depictions

EXAMPLE:




COMPLETE COMPONENTS
AND CONTROL MODULES




INCOMPLETE COMPONENTS
(EXCEPT CONTROL MODULES)



ASSEMBLIES AND
POWER DISTRIBUTION FUSE BOXES





COMPONENTS WITH
INTERNAL ELECTRONIC CIRCUIT




CAN NETWORK
SCP NETWORK
D2B NETWORK
SERIAL DATA LINK


NOTE: TYPICAL S-TYPE NETWORK CONFIGURATION
(AUTOMATIC TRANSMISSION; FULL OPTION SET).
REFER TO FIGURES 20.1, 20.2, 20.3, 20.4 AND 20.5 FOR CIRCUIT DETAILS.



FRONT POWER DISTRIBUTION BOX




PRIMARY JUNCTION FUSE BOX



REAR POWER DISTRIBUTION BOX




FRONT POWER DISTRIBUTION BOX




- R2 HEATED OXYGEN SENSOR RELAY
- R3 IGNITION COIL RELAY
- R4 THROTTLE MOTOR RELAY
- R5 EMS CONTROL RELAY
- R7 AUXILIARY COOLANT PUMP RELAY
- R8 A/C COMPRESSOR CLUTCH RELAY
- R10 LH HID RELAY
- R11 FRONT FOG LAMP RELAY
- R12 HORN RELAY
- R13 RH HID RELAY
- R15 WIPER HIGH / LOW RELAY
- R16 WIPER PARK RELAY
- R17 LH WINDSHIELD HEATER RELAY
- R18 POWER WASH RELAY
- R20 STARTER RELAY
- R21 WIPER PARK HEATER RELAY OR RH WINDSHIELD HEATER RELAY

R1 CIGAR LIGHTER / POWER POINT RELAY




PRIMARY JUNCTION FUSE BOX



REAR POWER DISTRIBUTION BOX




LHD



NOTE: WHERE THE INFORMATION IS AVAILABLE, THE NUMBER OF PINS CONTAINED IN A CONNECTOR IS SHOWN IN PARENTHESES.




RHD



NOTE: WHERE THE INFORMATION IS AVAILABLE, THE NUMBER OF PINS CONTAINED IN A CONNECTOR IS SHOWN IN PARENTHESES.




LHD




NOTE: THE TRANSMISSION CONTROL MODULE IS CONTAINED WITHIN THE TRANSMISSION.





RHD





NOTE: THE TRANSMISSION CONTROL MODULE IS CONTAINED WITHIN THE TRANSMISSION.





















SCP NOTE: The switched system power relays are activated by the GECM or the RECM whenever messages are present on the SCP network. After the ignition is switched off, the relays remain activated until all SCP messages are removed.































**MANUAL TRANSMISSION****MANUAL TRANSMISSION**








ELECTRONIC PARKING BRAKE





VARIABLE ASSIST POWER STEERING



























DRIVER-CONTROLLED HEADLAMP LEVELING





AUTOMATIC HEADLAMP LEVELING














* NOTE: Includes compass, when fitted.


ELECTROCHROMIC REAR VIEW MIRRORS





FOLD-BACK MIRRORS
































* NOTE: Rain sensing system – rain sensing vehicles only.

























NOTE: Japan vehicles with voice activation control – Refer to Fig. 16.8.





















**HORNS****CIGAR LIGHTER; POWER POINT****SUN SHADE****GARAGE DOOR OPENER****ELECTRONIC ROAD PRICING**


**NOTES:**

* Adaptive Speed Control Control Module and circuit – adaptive speed control vehicles only.

** Automatic Headlamp Leveling Control Module – HID vehicles only.


*** FC41 – A/CCM with panel controls; FC28 – remote A/CCM with navigation.




**** FCS33 and FCS34 – A/CCM with panel controls; FCS1 and FCS20 – remote A/CCM with navigation.


**NOTES:**

* Adaptive Speed Control Control Module and circuit – adaptive speed control vehicles only.


** CA245 and circuit – fitted to certain vehicles only.

**MANUAL TRANSMISSION VEHICLES**












D2B NETWORK WAKE-UP; 6-MODULE NETWORK



2-MODULE NETWORKS

NOTES:

Figures 20.3, 20.4 and 20.5 show all possible combinations of D2B networks.
D2B network diagnostics via SCP – Refer to Fig. 20.2.



3-MODULE NETWORKS

1 → 3
Fig. 01.1

4 → 76
Fig. 01.2

77 → 92
Fig. 01.3

1 → 14
Fig. 01.4

15 → 45
Fig. 01.5

46 → 80
Fig. 01.6

81 → 118
Fig. 01.7

Input
Battery Voltage
Power Ground

Sensor/Signal Supply V
CAN
SCP


D2B Network
D
Serial and Encoded Data

4-MODULE NETWORKS

NOTES:

Figures 20.3, 20.4 and 20.5 show all possible combinations of D2B networks.
D2B network diagnostics via SCP – Refer to Fig. 20.2.

VARIANT: All Vehicles
VIN RANGE: All
DATE OF ISSUE: March 2002 (PROVISIONAL)



5-MODULE NETWORKS

NOTES:

Figures 20.3, 20.4 and 20.5 show all possible combinations of D2B networks.
D2B network diagnostics via SCP – Refer to Fig. 20.2.