



# Spinning Tunes Activity Table™



Model Number 73540

Please keep this instruction sheet for future reference,  
as it contains important information.

Requires three "C" (LR14) **alkaline** batteries (not included).


Adult assembly is required.

Tool required for assembly: Phillips screwdriver (not included).

**Fisher-Price®**

Discover what's possible™... [www.fisher-price.com](http://www.fisher-price.com)


# Battery Installation



- Locate the battery compartment door on the table top.
- Loosen the screws in the battery compartment door with a Phillips screwdriver. Remove the battery compartment door.
- Insert three "C" (LR14) alkaline batteries, as indicated inside the battery compartment.

**Hint:** We recommend using **alkaline** batteries for longer life.

- Replace the battery compartment door and tighten the screws with a Phillips screwdriver. Do not over-tighten.
- When sounds or movements on this toy become faint or stop, it's time for an adult to change the batteries!




**Shown Actual Size**

## Battery Tips

- Do not mix old and new batteries.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries during long periods of non-use. Always remove exhausted batteries from the toy. Battery leakage and corrosion can damage this toy. Dispose of batteries safely.
- Do not dispose of batteries in a fire. The batteries may explode or leak.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended in the "Battery Installation" instructions are to be used.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before they are charged.
- If you use a battery charger, it should be examined regularly for damage to the cord, plug, enclosure and other parts. Do not use a damaged battery charger until it has been properly repaired.

# Assembly


1



- Lift the table top off the table base and remove the legs from the tray area.
- Position the table base upside-down on a flat surface.
- Position a leg upside down with the "X" and swirl patterns facing you.
- Fit the end of the leg into the corner of the table base, as shown.
- Press firmly to fit the raised circle on the end of the leg into the large hole in the table base.

# Assembly


## 2



- Position another leg upside down with the star and heart facing you.
- Fit the end of the leg into the corner of the table base, as shown.
- Press firmly to fit the raised circle on the end of the leg into the large hole in the table base.
- Repeat this step one and two to assemble the other legs to the table base.


## Assembly

3




- Stand the base assembly upright.
- Fit the table top on the base assembly.

## Power/Volume Switch



- Locate the power/volume switch on the table top.
- The switch has three positions: off , on with low volume  and on with high volume .
- Slide the switch to off  position when the toy is not in use.

## Music and Motion



**The table top is two sided with spinning disks on one side or building block fun on the other!**

- Stack the blocks on any of the pegs on the table top.
- Press the “action” button for spinning disks and fun music.

**Note:** *If this toy does not respond when the action button is pressed, it's time to replace the batteries!*

## Care

- Wipe this toy with a clean cloth dampened with a mild soap and water solution. Do not immerse this toy.
- This toy has no consumer serviceable parts. Do not take this toy apart.

## FCC Note (United States Only)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION:** Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

## Consumer Information

### Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-KIDS**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

For other countries, outside the United States:

**Canada:** call **1-800-567-7724**, or write to: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2. **Great Britain:** telephone **01628 500302**.

**Australia:** Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

**New Zealand:** 16-18 William Pickering Drive, Albany 1331, Auckland.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.

© 2002 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.