



HOME AUTOMATION, INC.

Model 87A00-1



Camera Server Installation and User Guide

Document Number 87100-1 Rev. A
July, 2008

DISCLAIMER

- While every effort has been made to ensure that the information contained in this guide is accurate and complete, no liability can be accepted for any errors or omissions.
- HAI reserves the right to change the specifications of the hardware and software described herein at any time without prior notice.
- No part of this guide may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without prior written permission of HAI.
- HAI makes no warranties for damages resulting from corrupted or lost data due to mistaken operation or malfunction of the Camera Server recording functions, the software, personal computers, peripheral devices, or unapproved/unsupported devices.

SAFETY PRECAUTIONS

Users are strongly advised to adhere to the directions and recommendations offered in this manual. Failure to do so may result in problems during operation.

- Make sure the correct voltage is being supplied before turning the power on.
 - Do not install with the power turned on. Doing so may cause an electric shock.
 - Do not install in a very humid environment. Doing so may cause an electric shock.
 - Do not install in an area exposed to sunlight or heat. Doing so may cause deformation or damage.
 - Do not remove the product cover. Doing so may expose you to a hazard like electric shock.
 - Do not use in areas containing flammable materials like propane gas and gasoline or in areas that generate dust. Doing so may cause an explosion or fire.
 - Do not dismantle, repair, or modify the product. Doing so may cause damage or an electric shock. Refer all servicing to qualified personnel.
 - Do not use water, thinner, or organic solvent for cleaning the product exterior. Doing so may cause damage or an electric shock. Use a dry cloth instead and turn off the power before cleaning.
-

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions;

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experience radio/TV technician for help.

Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment.

Home Automation, Inc.
4330 Michoud Blvd.
New Orleans, LA 70129
Tel: (504) 736-9810

The Privacy act of 1974 (5 U.S.C. § 552a)

Please note that the HAI Camera Server is intended for monitoring and surveillance use and should never be used in a manner that invades other people's privacy or contravenes international or domestic privacy act and its regulations. Please be advised that in certain cases the recording of individuals, private properties, or commercial properties by means of camera or other devices may contravene legal rights of such individuals even if the images were recorded for personal use.

Table of Contents

1. Introduction	1
1.1. Model 87A00-1 Camera Server	1
1.1.1. About the Camera Server	1
1.1.2. Main Features	1
1.2. Package Contents	2
1.3. Factory Default Settings	2
2. Operation	3
2.1. Front Panel	3
2.2. Rear Panel	4
3. Web Interface	9
3.1. Accessing the Web Interface	9
User Login	9
3.2. ActiveX Installation	11
4. Main Page Configuration	12
4.1. Single View	12
4.2. Multi View	14
4.3. Setup	14
5. Setup Configuration	15
5.1. Video Setup	16
5.1.1. Video Settings	16
5.1.2. OSD Settings	18
5.1.3. Advanced	20
5.2. Audio Setup	21
5.2.1. Audio Input Settings	21
5.2.2. Audio Output Settings	22
5.3. Network Setup	23
5.3.1. General Settings	23
5.3.2. QoS Settings	24
5.3.3. Multicast Settings	25
5.3.4. DDNS Settings	26
5.3.5. Advanced Settings	27
5.4. Event Setup	28
5.4.1. Event Server Settings	28
5.4.1.1. SMTP Server Settings	29
5.4.1.2. FTP Server Settings	30
5.4.1.3. TCP Server Settings	31
5.4.2. Motion Detection Settings	32
5.4.3. Event Settings	33

5.5. Record Setup	37
5.5.1. Recording on USB Flash Drive	37
5.5.2. Recording on FTP server	40
5.5.3. Playback the recorded data on the USB device	41
5.6. System Setup	42
5.6.1. System Date	42
5.6.2. System Update	43
5.6.3. User Management	44
5.6.4. PTZ Protocol	45
5.6.5. System Information	46
5.6.6. Reboot	47
5.7. IO Setup	48
5.7.1. Serial Port Setting	48
5.7.2. DI/DO Setting	49
5.7.3. PTZ	50
5.7.4. External Video out Setting	51
6. Resetting the Camera Server	52
6.1. Rebooting	52
6.2. Reset to Factory Default	52

1. Introduction

1.1. Model 87A00-1 Camera Server

The 87A00-1 Camera Server is a device that transmits video and audio data via network in real-time. The server converts the analog video signals and audio signals into digital data and compresses them for on-line transmission. Cameras can then be viewed at home or over the Internet on a PC, OmniTouch 5.7e, OmniTouch 10p, or handheld mobile device, such as PDA, Smartphone, or other device running Windows® Mobile operating system, using HAI Snap-Link Mobile (1120M) or HAI WL3 (1112). Additionally, these cameras can be viewed on an iPhone™ when HAI WL3 is used.

Since the server has a built-in web server and network interface, it may not require additional hardware, software, or programming (besides configuring IP address) to view live video transmissions. After connecting all the cameras to the Camera Server and configuring its IP address, the Camera Server can be accessed from anywhere with an Internet connection.

1.1.1. About the Camera Server

The 87A00-1 Camera Server is a 4-channel Camera Server that transmits video in high resolution with bi-directional audio in real-time via the network. The 87A00-1 supports various network environments such as high-speed Internet, cable, DSL, LAN, or WAN.

The 87A00-1 Camera Server provides high quality MJPEG encoding at D1 in real time and de-interlacing by the hardware.

The 87A00-1 Camera Server provides the high-performance interactive two-way audio.

1.1.2. Main Features

The 87A00-1 is designed for various applications, such as viewing cameras on an OmniTouch 5.7e, OmniTouch 10p, or handheld mobile device, remote monitoring, and Internet broadcasting with the user friendly interface.

Interface to External Equipment

The 87A00-1 Camera Server supports pan/tilt/zoom camera devices, alarm sensors, as well as other security equipment to customize the monitoring system.

Interactive Audio

In addition to the real-time motion picture and audio transmission, the 87A00-1 provides an interactive audio transmission function. To provide more precise information at the location, the 87A00-1 Camera Server allows users to hear audio and to watch video images simultaneously from the remote location where the 87A00-1 server is installed.

1.2. Package Contents

Before installing the Camera Server, please make sure that the following items are included in the box:

1. Camera Server
2. 12VDC Power Adapter with Power Cord
3. 2 Terminal Block
4. 2 Audio Cables
5. Mounting Hardware
6. Software Utility and Manual CD

1.3. Factory Default Settings

Factory default settings are as follows:

IP address: 192.168.xx.yy

Mask: 255.255.0.0

Gateway: 192.168.0.1


User ID: root

Password: pass

The last two bytes of the MAC address represents the “xx” and “yy” for the default IP address of the Camera Server. The last two bytes must be converted from hexadecimal to a decimal number.



MAC address = 00-13-23-01-23-45 → IP address = 192.168.35.69




Convert the Hexadecimal number to Decimal number

After installation, the default IP address can be changed using one of the following methods:

- Using the built-in web interface.
- Using the “IPAdminTool” Software Utility included on the Software Utilities and Manual CD.

2. Operation

2.4. Front Panel



- ① Status LED
- ② Network LED

Status (Orange) and Network (Green) LED indicators display the following system information:

	Status (Orange)	Network (Green)
Power Off	Off	Off
Booting in progress	On	Off
Successful Network Connection	On	Blinking
Failed Network Connection	On	Off
Data Transmission in Progress	Blinking (Slow)	Blinking (Fast)

1. System initialization and booting

When power is supplied to Camera Server, it is initialized for approximately 1 second. During this time, the orange Status LED is turned on. After completion of booting, for a successful network connection, the green Network LED blinks indicating that data is being transmitted. If network connection fails, please verify that the LAN cable is connected or restart Camera Server.

2. Video streaming service

When an application runs, the Status LED blinks once per second. The Network LED blinks at a rate proportional to the amount of data being transmitted.

③ and ④ **Video Input BNC Connectors (Vin 1, Vin 2, Vin 3 and Vin 4)**

Used for video inputs. Video input type: NTSC or PAL

⑤ **Termination Resistor DIP Switch (75Ω ON)**

A switch to turn On/Off a 75Ω termination resistor is provided for each video input. Factory default setting is ON.


⑥ **Video Output BNC Connector**

Vout is used to display quad or single channel composite output to an external monitor.

⑦ **Reset Switch (Reset)**


The Reset Switch is used for restarting the Camera Server or resetting the Camera Server to Factory Default (FD). Refer to **Factory Default Settings** for detailed procedures.

2.5. Rear Panel



① **Audio Input Jack (Ain 1,2 and Ain 3,4)**


The Camera Server has mono audio input channels using stereo audio sockets. Therefore, a special cable is needed to connect audio devices. See the **Audio Input Connector** diagram.



Audio Input Connector

② **Audio Output Jack (Aout)**

The Camera Server has one mono audio output using the stereo socket. Even if a stereo speaker is connected, both sides will have the same sound (mono output). The Camera Server audio output is very low-wattage, therefore it requires amplified speakers (do not use headphone/earphone directly).




Audio Output Connector

③ Digital Input (DI 1-4)


The Camera Server has 4 Digital Inputs as shown. Each input can be connected either a voltage type sensor or relay type sensor (dry contact).



Do not use voltage and relay type sensors together.




Voltage Type Digital Input Connections



Relay Type Digital Input Connections

④ Digital Output (DO 1-4)


The Camera Server has 4 12VDC Digital Outputs. The Digital Outputs can be connected as shown:



Digital Output Connections

⑤ RS-232C Terminal Blocks (RS-232C)


The RS-232C Terminal Blocks are used to connect an RS-232 serial device. The RS-232C serial port consists of Transmit (Tx), Receive (Rx), and GND.



RS-232C Connection

⑥ **RS-485 Terminal Blocks (RS-485)**

The RS-485 Terminal Blocks are used to connect RS-485 serial devices such as PTZ cameras. The RS-485 serial port consists of DATA+, DATA-, and GND.



⑦ **LAN Connector (Ethernet)**

This is a RJ45 LAN connector for 10/100 Base-T Ethernet.

⑧ **Power Adaptor Connector (DC 12V)**

Power connector input for the 12VDC, 3A power supply.

⑨ **USB Port**

This USB port is used for recording images to a USB storage device such as a USB flash drive.

3. Web Interface

3.1. Accessing the Web Interface

To access the web interface of the HAI Camera Server, open Internet Explorer and enter the IP address of the 87A00-1 into the address bar.

Enter the IP address in the address bar of the browser as shown below:

http://(IP address)

For example:

http://192.168.1.2

User Login

The 87A00-1 user's log in page will be displayed.




The default login credentials are as follows:

User name: root

Password: pass

When initially accessing the 87A00-1 web interface, the client viewer software is automatically downloaded and installed.


The first time you access the web interface, the Active-X Control Plug-In must be installed. If the Active-X Control is not currently installed or if you are accessing the web interface for the first, following prompt will appear.



NOTE: The 87A00-1 browser interface requires the Active-X Control Plug-In for Internet Explorer. If the Active-X Control Plug-In is not installed, you will be prompted to install the plug-in before the 87A00-1 interface is launched. You must answer “YES” to the questions about installation of the plug-in. After installation, the 87A00-1 browser web interface should be displayed.

3.2. ActiveX Installation

You will need to install ActiveX for displaying images. Click “Pop-up Blocked” and then “Install Active X Control” as shown below.



At the Security Warning, click the “Install” button.




4. Main Page Configuration

4.1. Single View

When the installation of the client program is complete and your login is accepted, the 87A00-1 Viewer is automatically connected and begins displaying video.

SingleView shows only one camera on a page.

Video 1 is set as the default channel and other channels are chosen from the drop-down combo box.



- **PLAY:** Play the current camera.
- **STOP:** Stop the current camera.

-
- **SNAPSHOT:** Save a snapshot of current video image.

Note: The file is saved in **My Documents\Screenshot** folder


- **Full Screen:** Stretches the camera image to fill the full screen.
- **PTZ:** Virtual PTZ control keyboard is displayed. This is used to control PTZ cameras.



- **Motion View:** When motion detection is set on the Event menu, you can see the detection status on the current image screen.
- **OSD View:** Shows the current image information, RTSP address, Channel number, FPS, Frame type, Frame Size, and Date and time on the image view screen.
- **Audio Enable** – Allows you to listen to the audio sound. To enable this function, the audio connection cable should be connected to IP Products from the video source.
- **MIC Enable** – Allows you to send the audio through a microphone from your PC to the site where the camera is installed. The audio input from the microphone will be transmitted via network.

4.2. Multi View

MultiView displays all 4 cameras on one page. Individual **Play**, **Stop**, and **Snapshot** button are available for each camera in MultiView mode.



4.3. Setup

Setup allows users to completely configure the Camera Server. See **5. Setup Configuration** for an explanation of each option and how to set and change the values.

5. Setup Configuration

The Setup Configuration pages allow you to completely configure the Camera Server.

Click **Setup** on the main page of web interface. On the left side of the main page, you can see the following categories:

Video

- Video Setting
- OSD Setting
- Advanced

Audio

- Audio Input
- Audio Output

Network

- General
- QOS Setting
- Multicast
- DDNS
- Advanced

Event

- Motion
- Event
- Event Server

Record

- Record
- USB Data

System

- System Data
- System Update
- User Management
- PTZ control
- System Information
- Reboot

IO

- Serial Prot Setting
- DI/DO
- PTZ
- External Video Out

5.1. Video Setup

5.1.1. Video Settings

Select **Video Settings** from the **Video** menu to select the Video Type, Codec, Resolution, FPS, Bitrate Mode, Bitrate, Quant, GOP size, Brightness, Contrast, Saturation, and Hue.



Whenever a camera is viewed on an OmniTouch 5.7e or OmniTouch 10p, the Resolution, FPS, Bitrate Mode, and Bitrate of the camera on the Camera Server will automatically change based on the settings of the camera in the OmniTouch touchscreen.

HAI Camera Server
<http://www.homeauto.com>

SingleView | MultiView | Setup

▼ Video
Video Setting →
OSD Setting
Advanced
▶ Audio
▶ Network
▶ Event
▶ Record
▶ System
▶ IO

video 1 video 2 video 3 video 4

Image Configuration

Video Type	AUTO	
Codec	MJPEG	
Resolution	QVGA	
FPS	5	
Bitrate Mode	CBR	
Bitrate(bits)	1000000	(32000~10000000)
Quant	100	(0~255)
GOP size	15	
Brightness	128	(0~255)
Contrast	128	(0~255)
Saturation	128	(0~255)
Hue	128	(0~255)

Save

Video Type

Select the video type from the Video Type box. The video format is detected automatically when the device boots up. If you change the video type manually to a certain type, it will only affect the FPS.

Video Codec

The video codec in the Camera Server is MJPEG.

Resolution

Select the desired resolution from the Resolution box. Refer to the table below.

	NTSC	PAL
D1	720x480	720x576
VGA	640x480	640x480
QVGA	320x240	320x240
4CIF	704x480	704x576
2CIF	704x240	704x288
CIF	352x240	352x288
QCIF	176x112	176x144

FPS (Frames per Second)

Select the desired FPS from the FPS box. This value represents the number of encoded frames you want to get per 1 second.

Video Format	Available frame rate
NTSC	30, 15, 7.5, 10, 6, 3.75, 2, 1
PAL	25, 12.5, 8, 6.25, 5, 4, 3, 1

Bitrate Mode

Select the desired bitrate mode from the Bitrate Mode box.

The following bitrates are supported: *CBR*, *VBR* and *HVBR*. The default mode is CBR. If you set as *HVBR*, both *Bitrate* and *Quant* values can be set.

Bitrate

Enter a bitrate in the Bitrate box. The default value 1.5Mbps. Bitrate is only adjustable when the bitrate mode is CBR or HVBR. The range is from 32 Kbps to 10Mbps.



Since the maximum bitrate is 10Mbps, you should distribute the bitrate between the number of installed cameras within 10 Mbps.

Quant

Enter a quant value in the Quant box. The default value is 128. Quant is only available when the Bitrate mode is VBR. The range is from 0 to 255. The Quant value is related to the image quality of VBR setting. The lower value makes high quality images.

GOP Size

Select the desired GOP size from the GOP box. GOP is an abbreviation for “Group of Pictures”. The GOP number represents a frame interval.

If the GOP size is 1, only I frame is generated in 1 second. If the GOP is set to 15, 15 frames are captured per 1 second.

The GOP can be a number from 1 to 255. The default value is 15.

Brightness/Saturation/Contrast/Hue

The range of each value is 0 to 255. The default value for each is 128.

5.1.2. OSD Settings

SingleView | MultiView | Setup

video 1 video 2 video 3 video 4

OSD String Configuration

Enabled	NO	
Color	255	(0~255)
String	1	(Max.32byte)
X	0	(Max.44)
Y	0	(Max.29)

OSD Time Configuration

Enabled	NO	
Format	YYMMDD:hhmmss	(YYMMDD:hhmmss)
X	0	(Max.32)
Y	0	(Max.29)

The coordinate value of OSD is absolute points and it is subject to image resolution.

Save

NOTE: The coordinate value of OSD is absolute points and it is subject to image resolution. If your OSD setting position is not as you expected, you may need to adjust the image resolution.

OSD String Configuration

Enable

Select **Yes** in the Enabled box to enable the OSD (On Screen Display).

Color

The color is in grayscale from 0 to 255. This value applies to OSD Time as well. “0” is black and “255” is white.

String

Enter the maximum length of OSD text (ASCII character string).

X/Y

Type the location of the string by entering the X and Y coordinates.

For example, if the coordinates are **(0, 0)**, the time stamp will be shown on the top left of image.

Input range of coordinate value:

X: 0 - 44

Y: 0 - 29

OSD Time configuration



Note

The OSD time setting is available only on the 1st camera and the other cameras do not support the Time OSD setting.

The OSD time is refreshed every 1 second.

Enable

Select **Yes** in the Enabled box to enable the Time OSD.

Format

The time information is synchronized with a NTP server (this can be configured under **System** in the **System Data** menu). Even though the box is open, it's not available to correct the time manually.

X/Y

Type the location of the string by entering the X and Y coordinates.

For example, if the coordinates are **(0, 0)**, the time stamp will be shown on the top left of image.

Input range of coordinate value:

X: 0 - 32

Y: 0 - 29

5.1.3. Advanced

The screenshot shows the HAI Camera Server web interface. At the top left is the HAI logo. At the top right, it says "HAI Camera Server" and provides the URL "http://www.homeauto.com". Below this is a navigation bar with "SingleView", "MultiView", and "Setup" (which is highlighted). On the left side, there is a vertical menu with the following items: "Video" (expanded), "Video Setting", "OSD Setting", "Advanced" (with a right-pointing arrow), "Audio", "Network", "Event", "Record", "System", and "IO". The main content area is titled "Image Source Configuration" and has tabs for "video 1", "video 2", "video 3", and "video 4". The configuration table is as follows:

horizontal delay	<input type="text" value="0"/>	(-32~32)
vertical delay	<input type="text" value="0"/>	(-4~4)
Copying a image to shared memory	<input type="text" value="YES"/>	▼
Deinterlace Mode	<input type="text" value="YES"/>	▼

Below the table is a "Save" button.

Horizontal delay

A higher setting moves the image towards the left. The setting ranges from 32 to -32

Vertical delay

A higher setting moves the image towards the top. The setting ranges from 4 to -4

Copying an image to shared memory

This setting allows the Camera Server make the best use of the source.

De-interlace Mode

Select **Yes** to enable de-interlacing. Select **No** to disable de-interlacing.

5.2. Audio Setup

The Audio Setup page provides the options for the audio input and the audio output.

5.2.1. Audio Input Settings

The screenshot shows a web interface for configuring audio input. On the left is a vertical navigation menu with items: Video, Audio (expanded), Audio Input (selected), Audio Output, Network, Event, Record, System, and IO. The main panel is titled 'Audio Input Configuration' and has tabs for 'video 1', 'video 2', 'video 3', and 'video 4'. The settings are as follows:

Setting	Value
Enabled	YES
Name	
Stream Type	PCM
Sample rate	16000
Data bit	16
Gain	128 (0-255)

A 'Save' button is positioned at the bottom right of the configuration area.

The Audio Input Configuration settings are required to listen to the sound from the location where the camera is installed. In order to test and use this feature, the microphone should be connected to the audio port of 87A00-1 Camera Server.

Enable

Enables or disables the audio input.

Name

Enter a nickname for the audio input.

Stream Type

Select an audio input format. Supported formats are: PCM, uLaw, and aLaw.

Sample Rate

Select sampling frequency. Supported frequencies are: 16 KHz. and 8 KHz.

Data bit

Select the number of data bits per sample. If the stream type is PCM, 8bit and 16bit is available. If the stream type is aLaw or uLaw, only 8bit is available.

Gain

Gain ranges from 0 to 255. The default value is 128.

5.2.2. Audio Output Settings

SingleView | MultiView | Setup

▶ Video
▼ Audio
Audio Input
Audio Output →
▶ Network
▶ Event
▶ Record
▶ System
▶ IO

Audio Output Configuration

Name

Stream Type

Sample rate

Data bit

Gain (0~255)

Save

The Audio Output Configuration settings are required to talk to people at the location where the camera is installed. Configure the values and click the Save button. This feature enables your PC to send audio to the speakers on the Camera Server. In order to test and use this feature, the microphone should be connected to the audio port of your PC. Likewise, the speakers should be connected to the 87A00-1 Camera Server.

Name

Type a nickname for the audio output.

Stream Type

Select an audio input format. Supported formats are: PCM, uLaw, and aLaw.

Sample Rate

Select sampling frequency. Supported frequencies are: 16 KHz. and 8 KHz.

Data bit

Select the number of data bits per sample. If the stream type is PCM, 8bit and 16bit is available. If the stream type is aLaw or uLaw, only 8bit is available.

Gain

Gain ranges from 0 to 255. The default value is 128.

5.3. Network Setup

The Network Setup page is used to configure various network and operational settings of the 87A00-1 Camera Server.

5.3.1. General Settings

The screenshot shows the 'IP Address Configuration' page. At the top right, there are links for 'SingleView', 'MultiView', and 'Setup'. On the left, a navigation menu lists: Video, Audio, Network (expanded), General (selected), QoS Setting, Multicast, DDNS, Advanced, Event, Record, System, and IO. The main content area is titled 'IP Address Configuration' and contains the following fields:

Network mode	static
IP address	192.168.1.2
Subnet mask	255.0.0.0
Gateway	192.168.1.1
DNS Server	0.0.0.0
PPPoE ID	
PPPoE Password	*****

Below the configuration fields is a 'Save' button.

IP Address Configuration

If the Network mode is set to DHCP, the IP address, Subnet mask, Gateway and DNS Server settings will be received from a DHCP server. If Network mode is set to Static, the IP address, Subnet mask, Gateway, and DNS Server settings must be manually configured.

The PPPoE feature can be used by entering the PPPoE ID and password provided by your Internet Service Provider.

Note: You can obtain and modify the default network settings of the 87A00-1 Camera Server using the **IPAdminTool** Software Utility (IPAdminTool.exe) included on the Software Utilities and Manual CD.

5.3.2. QoS Settings

SingleView | MultiView | Setup

▶ Video
▶ Audio
▼ Network
General
QoS Setting →
Multicast
DDNS
Advanced
▶ Event
▶ Record
▶ System
▶ IO

QoS Configuration

Video DSCP	<input type="text" value="0"/>	(0~255)
Audio DSCP	<input type="text" value="0"/>	(0~255)
Event DSCP	<input type="text" value="0"/>	(0~255)

Save

The 87A00-1 Camera Server uses a DSCP model for implementing QoS. Additionally, video, audio, and event classes are available for that.

What is DSCP?

It is short for Differential Services Code Point, which is a field in the header of IP Packets for packet classification purposes.

Video DSCP:

DSCP of video packet

Audio DSCP:

DSCP of audio packet

Event DSCP:

DSCP of event packet

DHCP values should be specified in a decimal number converted from original 6 bit binary digit. The default value is “0”, which means 000000 for DSCP value. To set the device available of supporting Expedited Forwarding, the recommended value for DSCP is 46 (101110).

5.3.3. Multicast Settings

[SingleView](#) | [MultiView](#) | [Setup](#)

	Ch 1	Ch 2	Ch 3	Ch 4
Multicast Configuration				
Enabled	NO			
Video Address	224.10.10.10			
Video Port	8000			
Video TTL	128			
Audio Address	224.10.10.10			
Audio Port	8002			
Audio TTL	128			
Event Address	224.10.10.10			
Event Port	8004			
Event TTL	128			

This page provides the multicast configuration of each channel. The addresses are a group of address which is required to receive data from the router.

The values in the boxes are default. You can set the values according to your network requirement.

The Camera Server supports only RTSP multicast (UDP/RTP Multicast is not supported).

5.3.4. DDNS Settings

SingleView | MultiView | Setup

▶ Video
▶ Audio
▼ Network
General
QOS Setting
Multicast
DDNS →
Advanced
▶ Event
▶ Record
▶ System
▶ IO

DDNS Configuration

Server Enable	NO
Server Type	DynDNS
Address	
User ID	
User PassWord	
DNS Name	
Update Time	0
Port	
IP Type	REAL

Save

For DDNS configuration setup, you must first create a DDNS account with dyndns.com.

- Server Enable: Select YES to use DDNS.
- Server Type : DynDNS (no other settings allowed at this time).
- Address: www.dyndns.com (no other servers allowed at this time).
- User ID: your user ID created at the Dyndns.com.
- User PW: your password registered at the Dyndns.com (case-sensitive).
- DNS name: your dynamic domain host server name.
- Update time: Specify how often the dynamic domain server is updated (unit: minutes).
- Port: Default value is -1. This means the DDNS feature is disabled as a default. If you use DDNS, you can type the required port number for DDNS.
- IP Type (Real/Local):
 - Real* represent the device's public IP seen by DDNS server.
 - Local* represents the private IP address of device.



Note: Only one dynamic host name is saved.

5.3.5. Advanced Settings

SingleView | MultiView | Setup

▶ Video
▶ Audio
▼ Network
General
QOS Setting
Multicast
DDNS
Advanced →
▶ Event
▶ Record
▶ System
▶ IO

Port Configuration

RTSP Port	<input type="text" value="554"/>
Web Port	<input type="text" value="80"/>
User RTSP Port	<input type="text" value="554"/> (PortForward)

* You should reboot the device for applying the new network configurations.

Save

RTSP Port

This is the port number for first channel for RTSP. If a device has more than one channel, the port number of next channel succeeds the port number of the first channel.

For example, if the port number of first channel is 554, the second channel would be 555.

Web Port

This is the port number for HTTP.

User RTST Port

This setting is required ONLY when you have set 'port forwarding' on router device. If your network does not require port forwarding, just leave the "User RTSP Port" value empty or set it to the same value as the RTSP Port.

When "port forwarding" is done on a network router, the ActiveX viewer on the client side can't find the port number and ActiveX image may not be seen. Because ActiveX is operated only on a client and not able to get the network setting values.

5.4. Event Setup

This manual assumes that Motion Detection is an event action trigger. So, consider this carefully and follow the setting step as the order below. If your event factor is not Motion Detection, you can just skip **Step2: Motion setting**.

Step 1: Event Server setting

Step 2: Motion setting

Step 3: Event setting (related to the event setting and motion detection setting you configure)

The event server supports SMTP, TCP, and FTP servers.

Select **Motion** from the **Event** menu. Select the **Event Server** tab.

To apply this event function, configure the Event server first, and then enter the Motion settings.



Before configuring the event server, the following should be configured first:

- Go to the **Video -> Advanced** menu on the left of this page and turn on **Copying a image to shared memory** by setting it to **Yes**

5.4.1. Event Server Settings

SingleView | MultiView | Setup

Event Server Configuration

Event Server	SMTP	
		<input type="button" value="Add TCP"/> <input type="button" value="Add FTP"/> <input type="button" value="Modify"/> <input type="button" value="Delete"/>

5.4.1.1. SMTP Server Settings

To register **the** SMTP server, click on the **SMTP** in the box and press the **Modify** button on the right.

The screenshot shows a software interface for configuring an event server. On the left is a vertical navigation menu with items: Video, Audio, Network, Event (expanded), Motion, Event, Event Server (selected with a right arrow), Record, System, and IO. The main content area is titled 'Event server' and contains the following fields:

FromEmail	<input type="text"/>
MailServer	<input type="text"/>
MailServer port	25 (base port 25)
ID	<input type="text"/>
Password	<input type="password"/>

At the bottom right of the form are two buttons: 'Add' and 'Cancel'.

FromEmail

Enter the email address of a sender.

MailServer1

Enter the SMTP server address.

MailServer1 Port

Enter the SMTP server port number (default port number 25).

ID

Enter the ID of the sender's email account.

Password

Enter the password of the sender's mail account (case-sensitive).

5.4.1.2. FTP Server Settings

To register the FTP server, press the **Add FTP** button.

SingleView | MultiView | Setup

Event FTP server

Name	<input type="text"/>
Address	<input type="text"/>
Port	21 (base port 21)
User ID	<input type="text"/>
User PW	<input type="text"/>
Upload path	/
timeout	100000 (microsecond)

Add Cancel

Name

Enter a descriptive name for the FTP server.

Address

Enter the IP address or domain name of FTP server

NOTE: To use domain name of FTP server, make sure if the DNS setting is enabled.

Port

Enter the port number of FTP server (0 – 65535).

User ID / User PW

Enter the FTP Server log-in ID and Password (case-sensitive).

Upload path

Type the path of uploaded files

For example: /home/

Timeout

Enter the timeout value for FTP connection and data transfer (Unit: μ s).

The default value is set as 100000 (0.1 sec).

5.4.1.3. TCP Server Settings

To add a TCP server, press **Add TCP** button.

The screenshot shows a web-based configuration interface. At the top right, there are links for 'SingleView', 'MultiView', and 'Setup'. On the left, a vertical menu contains several categories: 'Video', 'Audio', 'Network', 'Event' (expanded), 'Motion', 'Event', 'Event Server' (selected with a right-pointing arrow), 'Record', 'System', and 'IO'. The main area is titled 'Event TCP server' and contains three input fields: 'Name', 'Address', and 'Port'. Below these fields are two buttons: 'Add' and 'Cancel'.

Name

Enter a descriptive name for the TCP server.

Address


Enter the IP address of TCP server.

Port

Enter the port number of TCP server (0 – 65535).

5.4.2. Motion Detection Settings

After all of the settings have been entered for the **Event Server**, select the **Motion** tab to enter the settings for the motion detection functions.



How to register Motion Detection

Step 1: Select a camera from the **Image Source** combo box and then press **Play** button.

Step 2: Select a layer from the **Layer ID** combo box.

Step 3: Check the **Motion Enable** checkbox.

Step 3: Right-click anywhere on the camera display to make an **Area** rectangle.

Step 4: Adjust the size of the **Area** rectangle by dragging the edges.

Step 5: Press **SAVE** and then **RUN** to test the motion detection settings.

You can set up to 3 **layers**. Each layer can have up to 8 **areas**.

The **Object size** and **Sensitivity** values of each **Layer** applies to all of the **Areas** on that **Layer**.

- **Sensitivity** – sensitivity of each macro block (16 x 16 pixels).
- **ObjectSize** – proportion of the exceeded **Sensitivity** of macro block in the respective **Area**.

Sensitivity and **ObjectSize** range from 1 to 255. A lower value means the higher sensitivity.


5.4.3. Event Settings

To register an **Event**, follow Steps 1-3 below.



Step 1

1. Click **Add** to create an **Event**.



Name

Enter a descriptive name for the event

Event Type

- Software – device boots, motion detection, video losses, etc.
- Hardware – Digital Input activation (such as sensor).

Hardware Mode

If the event type is a Hardware type, use the following convention: Nnnn = where n = {x, 1}
x = do not trigger
1 = trigger on activation

For example: “1xxx” means to trigger when first Digital Input is activated.
“1x1” means to trigger when the first and fourth Digital Input are activated.

Software Mode

Select one of the following event modes: **Motion Detection**, **Video Loss**, and **Boot**.

Motion Detection: Event occurs when the motion is detected.


Video Loss: Event occurs when there is loss of video (disconnected or connected).

BOOT: Event occurs when the Camera Server is rebooted.

MD

Enable only if software mode is set to **Motion Detection**.

To set the MD value, press the **View CGI** button on the **Motion** setting page to see the **MD** values.



The screenshot shows a web browser window with the address bar displaying 'http://192.168.20.106/enc-cgi/admin/...'. The main content area displays a list of motion detection settings for three layers (M0, M1, and M2). A red box highlights the 'MD' field in the first row, which is set to 'M0'. The settings are as follows:

```
root.Motion MD.ImageSource=0
root.Motion MD.Left=3109
root.Motion MD.Right=4499
root.Motion MD.Top=3359
root.Motion MD.Bottom=5099
root.Motion MD.Sensitivity=105
root.Motion MD.ObjectSize=150
root.Motion M1.ImageSource=0
root.Motion M1.Left=2929
root.Motion M1.Right=4309
root.Motion M1.Top=2509
root.Motion M1.Bottom=4249
root.Motion M1.Sensitivity=127
root.Motion M1.ObjectSize=128
root.Motion M2.ImageSource=0
root.Motion M2.Left=5439
root.Motion M2.Right=6829
root.Motion M2.Top=4609
root.Motion M2.Bottom=6349
root.Motion M2.Sensitivity=127
root.Motion M2.ObjectSize=128
```

For example, if **MD** is set to “M0,” it means motion detection is triggered from Layer1. In the same manner, M1 means Layer 2 and M2 means Layer 3.

Video Loss

Enter camera number for triggering the event.

Image Number

Enter camera number to connect with event

Trigger Interval

1 second ('00:00:01') is set as the default value. Assuming the value is '00:00:05,' even if the event happens several times for 5 sec, the Camera Server will trigger only once per 5 seconds.

Step 2

1. Click on the **Event** tab on the left menu and then select the event that you created in the box.
2. Click the **Modify** button.
3. Click the **Action** button.

SingleView | MultiView | Setup

▶ Video
▶ Audio
▶ Network
▼ Event
Motion
Event →
Event Server
▶ Record
▶ System
▶ IO

Event Configuration

Name	test
Event Type	Software
Hardware Mode	(1111/0000/cccc)
Software Mode	BOOT
MD	M0
Video Loss	Video loss 1
Image Number	1
Trigger Interval	00:00:01 (hh:mm:ss)

Save Cancel Action

Step 3

1. Select the proper server from the **Server** list and set the respective values.

SingleView | MultiView | Setup

▶ Video
▶ Audio
▶ Network
▼ Event
Motion
Event →
Event Server
▶ Record
▶ System
▶ IO

Event Action Configuration

Event Action	
Server	SMTP
Message	
EmailTo	(SMTP)
Subject	(SMTP)
ImagesPerMail	(0,no, 1,yes)

* To enable ImagesPerMail & FTP, go to 'Video -> Advanced' and turn on 'Copying a image to shared memory' to 'YES'

Add Modify Delete Cancel

Event Action

The actions that are created are listed. Select an **Event Action** from the list.

Server

Select the appropriate server from the list.

TCP, SMTP, FTP, DO and USB recording server are available. If the desired server is not shown in this list, registration of the server was not successful. Go back to the **Event Server Setting** section and follow the instruction for adding a server.

Message

Enter an email message that will be sent.

EmailTo

Enter an email address of the recipient.

Subject

Enter the subject of the email.

ImagePerMail

Enter “1” to send a captured image with the email message. Otherwise, enter “0” for no image.

When you set the values on the **Event Action Configuration** page, depending on the **Server**, the required values may be different.

- SMTP: Set all of the values
- FTP: Only **Server** and **Message** are required
- TCP: Only **Server** and **Message** are required
- DO: No values are required
- USB recording: No values are required

5.5. Record Setup

5.5.1. Recording on USB Flash Drive



Before removing the USB flash drive from the Camera Server after recording...change the **USB Mount** value to **No** first. Otherwise, the recording may not work properly.

[SingleView](#) | [MultiView](#) | [Setup](#)

- ▶ Video
- ▶ Audio
- ▶ Network
- ▶ Event
- ▼ Record
- Record →
- USB Data
- ▶ System
- ▶ IO

Record Configuration

Record Enable	YES
Port	2100 (100~10000)
USB Mount	NO
Record Recycle	Rotate
Default File Size	16 (Mbyte)

video 1 video 2 video 3 video 4

Recording	NO	record	stop
Record Device	FTP		
Record Mode	Passive		
FTP Server	F0		
Prebuffer Enable	No		
Prebuffer Memory	1 (Mbyte) 8 (sec) 1000000/(1000000/(bitrate*8))		
PostTime	30 (sec)		
Skip Frame	0		
Record Frame	0		

Preparation before recording

Step 1: Insert the USB flash drive into the USB port on the Camera Server.

Step 2: Click **Record** from the **Record** menu and set the value of **USB Mount** to **YES** as above.

Step 3: Select **USB** for the value of **Record Device**.

Select which recording mode you want between **Passive** mode and **Schedule** mode.

For details, refer to the following explanations.

How to record video NOW (Passive mode)

Step 1: Set the **Record Enable** as **YES**

Step 2: Set the **Record Mode** as **Passive**

Step 3: Enter the **Port Number** and **Record Recycle**

- *Port number:* Used for playback. **2100** is set as the default.
- *Record Recycle:* **Rotate** lets the new files overwrite existing files when USB memory is full. **None** lets the recording stop if the USB memory is full.

Step 4: **PostTime** is set in seconds. If you want to record for 30 minutes, type 1800 for the value of **PostTime**. The recording will continue for 30 minutes on when the **Record** button is presses.

Step 5: Set the **Skip Frame** and **Record Frame** as described below:

- *Skip Frame:*

This is the number of frames to skip between **Record Frame**. Refer to the examples below.

- *Record Frame*

This is the number of recorded frames. For example, if the value is 0, only 1 frame is recorded after skipping the number of **Skip Frame** set above.

For example:

If “149” is set for **Skip Frame**, “0” for **Record Frame**, and “30” for **FPS**, you will get 1 frame every 5 seconds.

If “5” is set for **Skip Frame** and “1” for **Record Frame**, you will get the frames as below.

F#	0	1	2	3	4	5	6	7	8	9	10	11	12	13

 Recording Frame

 Skip Frame

Step 6: Click the **Record** button to start the recording.

How to record on SCHEDULE (Schedule mode)

If you want to record the video according to the specific date and time, follow the instructions below.

Step 1: Follow the same steps of *How to record Video NOW* except for Step 2.

Step 2: Set the **Record Mode** to **Schedule**.

Step 3: Set **Record Weekdays**, **Start Time** and **End Time** as described below:

- *Record Weekdays*

Assign days for recording. The first digit corresponds to Sunday and last digit corresponds to Saturday. For example, if **0111110** is set, the recording runs only from Monday to Friday.

- *Start Time*

Enter the time to start recording (time format - 00:00).

- *End Time*

Enter the time to end recording (time format - 00:00).

Step 4: Click the **Record** button to start the recording.


5.5.2. Recording on FTP server

Step 1: In order to record the video on an FTP server, the FTP server must be added in advance. Refer to section **5.4.1.2 FTP Server Settings**.

Step 2: Set **Record Device** as **FTP**.

Step 3: Set **Record Mode** as desired. Refer to section **4.5.1 Recording on USB flash drive**.

Step 4: Set the **FTP Server Number**. This is available only after Step 1 has been completed.



Step 5: **PostTime** is set in seconds. If you want to record for 30 minutes, type 1800 for the value of **PostTime**. The recording will continue for 30 minutes on when the **Record** button is presses.

Step 6: Set the **Skip Frame** and **Record Frame** as described below:

- **Skip Frame:**
This is the number of frames to skip between **Record Frame**. Refer to the examples below.
- **Record Frame**
This is the number of recorded frames. For example, if the value is 0, only 1 frame is recorded after skipping the number of **Skip Frame** set above.

For example:

If “149” is set for **Skip Frame**, “0” for **Record Frame**, and “30” for **FPS**, you will get 1 frame every 5 seconds.

If “5” is set for **Skip Frame** and “1” for **Record Frame**, you will get the frames as below.


F#	0	1	2	3	4	5	6	7	8	9	10	11	12	13

-  Recording Frame
-  Skip Frame

5.5.3. Playback the recorded data on the USB device

If the USB recording steps have been completed, the recording status can be viewed on the **USB Record List** page.

- **Record List:** Show the created recording files
- **Play/Stop:** Select a file from the **Record List** and click **Play** or **Stop** to display the control
- **Delete:** Select the file to be removed and then click the **Delete** button



5.6. System Setup

5.6.1. System Date

The screenshot shows a web interface for system configuration. At the top right, there are links for 'SingleView' and 'Setup'. On the left is a navigation menu with items: Video, Audio, Network, Event, Record, System (expanded), System Date, System Update, User Management, PTZ protocol, System Information, Reboot, and IO. The main content area is titled 'Device Time' and contains a 'Time' section with 'Date' (2008-08-08) and 'Time' (08:25:51) fields. Below this is the 'Date Configuration' section, which includes a 'TimeZone' dropdown set to 'GMT' and three radio button options: 'Client Time' (unselected), 'NTP server' (selected), and 'User Setting' (unselected). The 'NTP server' option has a sub-label 'NTP server: time.nist.gov'. The 'Client Time' and 'User Setting' options each have 'Date' and 'Time' input fields. A note at the bottom states: '* It takes about 10 seconds for synchronizing system time with NTP server if changing time mode to NTP server'. A 'Save' button is located at the bottom right of the configuration area.

Device Time

Displays the date and time of Caners Server

Time Zone

Select your time zone

Time Mode

You can select a time mode with 3 options.

- **Client Time:** Synchronized with your current PC time.
- **NTP Server:** Synchronized with a NTP server. By default 'time.nist.gov' is the selected server; however any NTP server can be selected from the list or one can be manually entered.
- **User Setting:** The time and date will be manually entered.

5.6.2. System Update

SingleView | MultiView | Setup

▶ Video
▶ Audio
▶ Network
▶ Event
▶ Record
▼ System
System Date
System Update →
User Management
PTZ protocol
System Information
Reboot
▶ IO

System Update

Force update

Current Version

Bootloader	U-Boot 1.0.4.jb16m.35
Firmware	FW V1.5.662.14432
Webpage	2.15.4
OCX	1.10.27.48
Dome firmware	

This page is used to update of the software in the Camera Server and to display the current version for various software modules.

System Update


You can upload firmware files and update your Camera Server. Click the **Search** button and choose the file you want to upload. Then click the **Upgrade** button.

Current Version

- **Bootloader:** Current bootloader version
- **Firmware:** Current FW version
- **Webpage:** Current Webpage version
- **OCX:** Current ActiveX version

5.6.3. User Management

User Management is used to add user login accounts to the Camera Server.



There are two user types provided by default:

User	Password	Security Level
root	pass	Admin
guest	guest	Guest

Accounts can be created up to 10 including two default users.

- **ID:** Up to 32 characters with the combination of alphabets and digits. First character must be an alphabet (case-sensitive).
- **Password:** From 3 to 8 characters with the combination of alphabets and digits (case-sensitive).

How to add a user

1. Click **Add**.
2. Type **User & Password** and select **Security Level** on “User add” dialog.
3. Select **Add** button on the “User add” dialog.
4. Click **Close** on the “User add” dialog.

How to delete a user

1. Select a user to delete from the **User List**.
2. Click **Delete**.
3. Click **OK** on confirmation dialog.
4. Click **Close** on the “Remove user” dialog.

How to modify a user

1. Select a user to modify from the **User List**
2. Click **Modify**.
2. Modify the password or security level.
3. Select **Modify** on the “User Modify” dialog.
4. Click **Close** on the “User Modify” dialog.

5.6.4. PTZ Protocol

This page shows the list of current PTZ protocols built-in the Camera Server and also allows you to upload a new PTZ protocol.

Protocol Name	FileName	Type	Version	Description
American dynamics	american_dynamics.ptzs	built-in	1.1.0.0	American dynamics ptz protocol for SpeedDome series
Bosch(ltc856x)	bosch(ltc856x).ptzs	built-in	1.0.0.0	Bosch(LTC 856x) protocol
Custom02	custom02.ptzs	built-in	1.1.2.0	PTZ Protocol
Kalatei(ascii)	kalatei(ascii).ptzs	built-in	1.0.0.0	Kalatei ascii protocol
Panasonic(CS850)	panasonic(CS850).ptzs	built-in	1.1.0.0	Panasonic(WV-CS850) protocol
Pelco-D(probe)	pelco-d(probe).ptzs	built-in	1.1.0.0	Pelco-D protocol for probe
Pelco-D	pelco-d.ptzs	built-in	1.1.1.0	Pelco-D protocol
Pelco-P	pelco-p.ptzs	built-in	1.1.0.0	Pelco-P ptz protocol
Samsung-elec	samsung.ptzs	built-in	1.1.2.0	PTZ Protocol for samsung elec

Upload new protocol

* Please refresh the page if the ptz list is not shown properly after uploading or deleting the PTZ driver.

How to add PTZ protocol manually

1. Click the **Browse** button.
2. Choose the required file and click the **Upload** button.
3. The protocol will be added to the list

Click **PTZ** from the **IO** menu to choose the PTZ protocol.

Refer to section **4.7.3 PTZ** to learn how to apply the newly added protocol to the Camera Server.

5.6.5. System Information

This page shows the system information as described below:

SingleView | MultiView | Setup

▶ Video
▶ Audio
▶ Network
▶ Event
▶ Record
▼ System
System Date
System Update
User Management
PTZ protocol
System Information →
Reboot
▶ IO

87A00-1 Information

MAC	00:13:23:03:4C:D0
TIME	2009-07-01 21:07:40

Version Information

Bootloader	U-Boot 1.0.4.jb16m.35
Firmware	FW V1.5.662.14432
Webpage	2.15.4
OCX	1.10.27.48
Dome firmware	

Server report

87A00-1 Information


- **MAC:** MAC Address
- **TIME:** Date and time information on the Camera Server
-

Version Information

- **Bootloader:** Bootloader version.
- **Firmware:** Current firmware version
- **Webpage:** Current web page version
- **OCX:** Current ActiveX version

5.6.6. Reboot

The Camera Server can be rebooted from the web interface without physically touching the device.



Click the **OK** button. As confirmation dialog is displayed.



Select **OK** to reboot the Camera Server.

It will take about 1-2 minutes to complete the rebooting process.

5.7. IO Setup

5.7.1. Serial Port Setting

This page provides the configuration of **RS-232C** and **RS485**.

The screenshot shows a web interface for configuring serial ports. At the top right, there are links for 'SingleView', 'MultiView', and 'Setup'. On the left, a navigation menu is expanded to 'IO', with 'Serial Port Setting' selected. The main content area is titled 'RS-485 Configuration' and has two tabs: 'RS232' and 'RS485'. The configuration fields are as follows:


Parameter	Value
Baudrate	9600
Parity	none
Flow Control	none
Stopbit	1

Below the configuration fields, there is a note: '* You should reboot the device for applying the new serial configurations.' and a 'Save' button.

- **Baudrate:** 9600
- **Parity:** none
- **Flow Control:** none
- **Stopbit:** 1

5.7.2. DI/DO Setting

This page is used to see the status of the Digital Inputs (DI) and Digital Outputs (DO) on the Camera Server. It also allows you to control the state of the Digital Outputs.



This page is refreshed every 3 seconds to update the status of each Digital Input and Digital Output.

5.7.3. PTZ

This page allows you to select the PTZ Protocol for each camera.

	Enable	PtzDriver	Addr	CommPort(0-1)
PTZ1	<input type="checkbox"/>	None	1	1
PTZ2	<input type="checkbox"/>	None	1	1
PTZ3	<input type="checkbox"/>	None	1	1
PTZ4	<input type="checkbox"/>	None	1	1

Apply

PTZ protocol options are shown in the drop down combo box.

You can choose a protocol for each camera.

1. Check **Enable** in the check box and choose the desired protocol.
2. Set the **Addr** and **CommPort** for each camera input.
3. Click the **Apply** button.

PtzDriver

Select the desired protocol from the list.

Addr

Set the **Addr** value according to the ID set by dip switch on the PTZ camera.

CommPort(0-1)

0 = RS232C

1 = RS485C

5.7.4. External Video out Setting

This page provides the external video output settings and video loopback function settings.

The screenshot shows a web interface for configuring external video output. At the top right, there are links for 'SingleView', 'MultiView', and 'Setup'. On the left is a navigation menu with options: Video, Audio, Network, Event, Record, System, IO (expanded), Serial Port Setting, DI/DO, PTZ, and External Video Out (selected). The main content area is titled 'Video Out' and features a 'Select' dropdown menu currently set to 'Quad'. Below this is the 'Video Loopback' section, which contains two rows: '0-1' and '2-3', each with a 'No' dropdown menu. A 'Save' button is located at the bottom right of the settings area.

Video Out

You can choose either single view or multi-view for the stream on the external output. **Quad** displays 4 channels as a quad multi-view on the external video out.

Video Loopback

Video Loopback is not currently implemented on the 87A00-1 Camera Server.

6. Resetting the Camera Server

6.1. Rebooting

The camera server can be rebooted as follows:

1. Press the **Reset** button for 1 second.
 - The **Status LED** and **Network LED** will blink together, twice. Stop pressing the **Reset** button.
2. When the reset function has been completed, The **Status LED** and **Network LED** will stop blinking.

6.2. Reset to Factory Default

The camera server can be initialized to factory default settings as follows:

1. If the Camera Server is powered-up, disconnect the power removing the power input.
2. Apply power to the Camera Server.
3. When the **Status LED** starts blinking rapidly, press the **Reset** button.
4. When the **Status LED** starts blinking slowly (about 5 seconds after booting), release the **Reset** button.

