



IMPORTANT:

This radio is set to USA frequency by factory, if European frequency is required please flip the frequency step switch on the side of the unit.

After the switchover of the frequency switch, the frequency convert function will not be valid until the RESET button has been pressed.

REMOTE CONTROL BASICS BATTERY REPLACEMENT:

- 1.Remove the battery holder as the direction indicated by the arrow.
- 2.Replace the battery Set a new battery properly with (+)side up as illustrated.
- 3.Insert the battery holder. Push in the holder to the original position.

NOTE ON BATTERIES:

Old batteries must immediately be removed and disposed.


BATTERY INFORMATION:

Designated Battery: CR2025 3V.

Battery Life: 6 months with normal use (in normal room temperature)




CAUTION:

Improper use of batteries may cause overheating, explosion or ignition. Resulting in jury or fire .Battery leakage may cause damage to the unit.
Do not disassemble or short the batteries. Do not throw the batteries into the fire.
To avoid the risk of accident, keep the batteries out of reach of children.



LEGACY

INSTRUCTION MANUAL



**ANTI-THEFT FLIP DOWN DETACHABLE SYSTEM
AUTO-LOADING COMPACT DISC PLAYER
AM/FM STEREO WITH DIGITAL TUNING RADIO**

MODEL:LCD69DSX

www.legacycaraudio.com

INSTALLATION

DEAR CUSTOMER

Selecting fine audio equipment such as the unit you have just purchased is only the start of your musical enjoyment. Now it is time to consider how you can maximize the fun and excitement your equipment offers.

We want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion - and, most importantly, without affecting your sensitive hearing.

Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So what sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level BEFORE your hearing adapts.

To establish a safe level:

- . Start your volume control at a low setting
- . Slowly increase the sound until you can hear it comfortably and clearly, and without distortion we want you listening for a lifetime.

Once you have established a comfortable sound level:

- . Set the dial and leave it there.

Taking a minute to do this now will help to prevent hearing damage or loss in the future. After all, we want you listening for a lifetime.

ABOUT THIS MANUAL




This product features a number of sophisticated functions ensuring superior reception and operation. All are designed for the easiest possible use, but many are not self-explanatory. This operation manual is intended to help you benefit fully from their potential and to maximize your listening enjoyment.

We recommend that you familiarize yourself with the functions and their operation by reading through the manual before you begin using this product. It is especially important that you read and observe the "precaution" on the next page and in other sections.

In this operation manual, the Basic Operation for each sound source is outlined at the beginning of its explanation, covering simple operation for that source, such as merely playing music.

IMPORTANT:

THE FOLDABLE SPEAKER SHOULD BE OPENED BEFORE LOADING OR UNLOADING THE DISC.



TROUBLE SHOOTING

Before going through the check list, wiring connection, should any of the problem persist after check list has been made, consult your nearest service dealer.

Symptom	Cause	Solution
No power	The car ignition is not on.	If the power supply is properly connected to the car accessory switch the ignition key to " ACC "
	The fuse is blown	Replace the fuse
Disc cannot be loaded or ejected	Presence of CD disc inside the player	Remove the disc in the player then put a new upward
	Inserting the disc in upside down	Insert the compact disc with the label facing upward
	Compact disc is extremely dirty or defective	Clean the disc or try to play a new one
	Temperature inside the car is too high	Cool off until the ambient temperature returns to normal
	Condensation	Leave the player off for an hour or so, then try again
No sound	Volume is in minimum	Adjust volume to a desired level
	Wiring is not properly connected	Check wiring connection
The operation keys do not work	The built-in microcomputer is not operating properly due to noise	Press the RESET button front panel is not properly fix into its place
Sound skips	The installation angle is more than 30 degrees	Adjust the installation angle to less than 30 degrees
	The disc is extremely dirty or defective	Clean the compact disc/try to play a new one
The radio does not work the radio station automatic selection does not work	The antenna cable is not connected the signals are too weak	Insert the antenna cable firmly select a station manually

DISC PLAY:

Cleaning discs


Before playing, clean the disc with a clean, lint-free.

Flip the disc in the direction of the arrow.




NOTE:

- . Do not use so solvents such as benzene, thinners. Commercially available cleaners or anti static spray damage the unit.
- Insert a disc with the label surface down. Doing so may damage the unit.



NOTE:


- . Do not try to insert another disc when one has been already inserted. Doing so may damage the unit.
- .Handle the disc by its edge. And to keep the disc clean, do not touch the surface.



.Do not stick paper or tape on the disc.

.Do not expose the disc to direct sunlight or heat sources such as hot air ducts. Or leave it in a car parked in direct sunlight where there can be a considerable rise in temperature.

LOCATION AND FUNCTION OF CONTROL



1. FOLDABLE SPEAKER

2. [TUNE/SEEK DOWN] BUTTON and TRACK DOWN BUTTON

- The frequency scans down by one step when pressing button once. Hold it for more than 2 seconds to seek for a station of lower frequency.
- During CD mode, press button allow you to track forwards. Hold the button allow you to skip forwards.
- To set minutes at time setting mode.

[TUNE/SEEK UP] BUTTON and TRACK UP BUTTON

- The frequency scans up by one step when pressing button once. Hold it for more than 2 seconds to seek for a station of higher frequency.
- During CD mode, press button allow you to track backwards. Hold the button allow you to skip backwards.
- To set hour at time setting mode.

SPECIFICATION

GENERAL

Power requirement.....	DC 13.8V.
Current consumption.....	7A MAX.
POWER OUTPUT.....	4 X 40W.

FM SECTION

Frequency range.....	87.5MHz -108.0MHz.
Usable sensitivity.....	3uV.
I.F Frequency.....	10.7MHz.

AM SECTION

Frequency range.....	522KHz - 1620KHz.
Frequency range.....	530KHz - 1710KHz.

LINE - OUT [OPTION]

Output.....	1000mV @ FM 10% THD POWER.
Impedance.....	600 ohm.

CD PLAYER


System.....	compact disc audio system.
Usable disc.....	compact disc.
Signal format.....	sampling frequency 44.1KHz. No of quantization bits 1bit.
Frequency characteristics.....	5-40Hz ≤ 5dB 10K-20KHz ≤ 5dB.

Signal to noise ratio.....	70dB [1KHz] [IEC - A net work].
----------------------------	---------------------------------

Number of channels.....	2 STEREO.
-------------------------	-----------

Chassis dimensions.....	178[W] X 50[H] X 165[D].
-------------------------	--------------------------

Speaker Connection



Note:

Make sure use a 4-ohms impedance speaker in spite of having any kinds of speaker system. So that reduce the distortion during high volume level.

NOTE: SOMETIMES THE DISC CANNOT BE LOADED WHEN THE YOU CONNECT THE MEMORY WIRE AT THE FIRST TIME AND THE DISC MARK WILL BE DISPLAYED ON LCD. PLEASE PRESS RESET BUTTON AND RESTART THE UNIT, THE UNIT WILL RESTORE TO NORMAL STATE.

3. SEL(AUDIO MODE SELECT)/VOLUME +/- BUTTON

Press SEL button to change the mode in the sequence of



- a. The volume level can be adjusted at any time by pressing the audio level+ or - button as select mode has been initially defaulted at volume mode.
- b. The volume level is also obtained by stepping through the SEL button until the function VOL is displayed and then press + or - button to adjust the sound level.
- c. Press and hold the + or - button to adjust the sound level.

BASS CONTROL

- a. Press the SEL button to select the bass mode until BAS appears on the display.
- b. Press + or - to adjust the bass effect.

TREBLE CONTROL

- a. Press the SEL button to select the treble mode until TRE appears on the display.
- b. Press + or - to adjust the treble effect.

BALANCE CONTROL

- a. Press the SEL button to select the balance mode until BAL appears on the display.
- b. Press the + button or - button to increase or decrease the sound level of left or right speaker.

FADER CONTROL

- a. Press the SEL button to select the fader mode until FAD appears on the display.
- b. Press the + button or - button to increase or decrease the sound level of front or rear speaker.

4. INFRA-RED RECEIVE WINDOW

5. LCD (LIQUID CRYSTAL DISPLAY)

6. MUTE BUTTON

Press it to reduce the volume level temporarily.

7. POWER BUTTON

Press the button to turn on or off the unit.

8. OPEN(EJECT) BUTTON

Push it to slide the panel then you can insert or eject the disc from the compartment.

9. RELEASE BUTTON

Press it to flip down the front panel when you want to take away.

10. LOUDNESS BUTTON

Press it to enhance the bass effect.

11. CLOCK ADJUSTMENT BUTTON

During frequency display, press it to change to clock function.

Press the button for more than 2 seconds, until time flashes. and you can adjust time now.

To adjust hour:

with time on display, push the tune **▶▶** button adjust hour, when adjustment is completed, release the button.

To adjust minute:

with time on display, push the tune **◀◀** button adjust minute. When adjustment is completed, release the button.

12. MONO/STEREO BUTTON

Press it to select mono/stereo mode.

13. LOCAL/DISTANCE BUTTON

When in the radio mode, press them to select local or distance broadcast station receive sensitivity. The word LOC will appear on LCD during local state.

14. BAND BUTTON

Press it to select your desired radio band.

15. AS/PS [AUTOMATIC STORE AND PRESET MEMORY] BUTTON

Press it to perform all stations memory for 5 seconds each time. While memory digital and frequency will flash on LCD. If the button is pressed for more than 2 seconds, it will seek station on current band, then write to the preset memories and word ART will appear on LCD. When the auto-storage operation is completed, it will automatically perform for 5 seconds each time, during the memory station performing, press 1-6 digital buttons to select and stop scanning function.

16. CD **▶|** [CD PLAY, PAUSE] BUTTON

At tuner mode, press **▶|** button to switch to CD mode. At CD mode, press it to pause the CD program and press it again to resume CD playback.

17. PRESET STATION [1-6] / 2RPT, 3INT, 4RDM.

A]. To memorize the current frequency, press and any one of the six preset buttons for more than 2 seconds.

B]. To recall the preset memory, press one of the preset button [1-6].

C]. REPEAT BUTTON

During CD mode. Press 2 RPT button to repeat a single track.

D]. During CD mode press 3 " INTRO "button.


It play individually tune for 10 seconds.

If this key is pressed in intro scan mode, it display " INTRO ".

E]. During CD mode press 4 " RDM " button.

If this key is pressed, and at the end of the tune random tuning function performs.

If this key is pressed, in random play mode, it display " RDM ".



a. SCAN BUTTON

Press it to scan the memorized stations 10 seconds each. Stop scanning function and return to playback as long as your desired station has been found.

b. POWER BUTTON

Press it to turn on or off the unit.