



User Manual / Configuration Guide

for the



BASIC IP Pan-Tilt Control System

Version 1.0 December 2007
Copyright © 2007-2009

J-Systems, Inc.

1 South 678 School Ave.
Lombard, IL 60148
Tel: 630-627-3458
Fax: 630-620-0960
E-Mail: info@J-Systems.com

TABLE OF CONTENTS

1.0	Introduction	1
1.1	Concept	1
1.2	Unpacking	2
1.3	System Components.....	2
1.4	Before You Start	2
2.0	Initial Setup	3
2.1	Connecting the PT Head	4
2.2	Connecting AC Power	4
3.0	Configuration	5
4.0	Installation	9
4.1	Mounting the Pan-Tilt Head	9
4.2	Mounting the Control Enclosure	10
4.3	Adjusting Pan-Tilt Head Limit Switches	11
5.0	Setup Interface	12
6.0	HTML API - Web Page Interface.....	14
7.0	Technical Support	15
8.0	Support Information	15
8.1	Warranty Policy	15
8.2	Specifications	16

DISCLAIMER

J-Systems, Inc. makes no warranties, either express or implied, regarding the enclosed IP Pan-Tilt Controller System, its merchantability or its fitness for any particular purpose.

Further, J-Systems, Inc. assumes no responsibility for any damages, losses or claims resulting from the use or misuse of this equipment. The extent of any liability is expressly limited to the original purchase price of the equipment.

1.0 - INTRODUCTION

Congratulations on your purchase of the BASIC IP Pan-Tilt Control System (IP-PT). This unique harsh environment system was built to the highest quality standards and, with proper use and installation, will provide many years of service. It is STRONGLY recommend that you read this manual carefully and completely to fully understand the capabilities of this system before attempting installation.

CAUTION

The installation and setup of the IP-PT system involves a number of potentially dangerous operations such as climbing, using man lifts, working with 120 or 220VAC power, handling heavy items above ground and working with a device that can be remotely controlled by others.

The installation of the IP-PT system should ONLY be done by those that are qualified to perform the needed work.

1.1 - Concept

The IP-PT system is an IP based, position control system. It was specifically designed to allow the positioning of a remote IP camera across IP based networks (wired or wireless including cellular). Further, all the equipment that makes up this system has been designed for harsh duty environments (NEMA 4X enclosure, -30C to +70C operation).

The IP-PT system was designed to provide BASIC positional control across any IP based network. The IP-PT system's built-in web browser interface is simple allowing for left-right and up-down control. Custom web pages can easily be designed to display both an IP camera's live video as well as graphical controls which allow simple pan and tilt camera movement. Examples of this type of web page are included on the CD.

The IP-PT system provides all the necessary power for the control board and pan-tilt head using a built in 12VDC, 15W encapsulated power supply that is both TUV approved and CE marked. As the pan-tilt head operates from 12VDC, an optional 12VDC or 24VDC version of the IP-PT system is available which uses a 15 watt, 10 to 40VDC DC-DC converter which provides stable 12VDC for the pan-tilt head. This option is ideal for both mobile and solar powered applications.

A special high flexibility cable (flexible down to -40C) is provided to connect the pan-tilt head to the control enclosure. A waterproof RJ45 jack is also provided for connection to a LAN, wireless radio or cellular router to allow TCP/IP connection to the controller board. The standard main power connection is through a 1/2" metal liquid tight fitting on the bottom of the NEMA 4X fiberglass enclosure. The enclosure is furnished with universal stainless steel mounting brackets.

Finally, the IP-PT system is completely Web browser based allowing easy setup and configuration. A simple HTML based API is built in which can be incorporated into any web page to make the controller's functions appear as if they have been custom designed for your specific web site.

1.2 - Unpacking

The IP-PT system has been carefully packaged to provide protection during shipment. We suggest that you keep this packaging in the event that factory warranty service is ever required.

Please inspect and note the condition of the shipping containers before opening them. Punctures, tears, and crushed ends are indications of abusive treatment by the shipping company and should be photographed and reported to the carrier in the event any damage is found inside to file a claim.

1.3 - System Components

Your IP-PT system may have shipped to you in more than one carton depending upon the items purchased.

Standard Items

- Qty 1 - JPTH-13 Pan-Tilt Head
- Qty 1 - Fiberglass NEMA 4X Control Enclosure
- Qty 1 - 7ft Highly Flexible Interconnect Cable with Military Style Connectors
- Qty 2 - Stainless Steel Universal Mounting Brackets for the Control Enclosure
- Qty 1 - RJ45 Quick Connect Mating Connector
- Qty 1 - User Manual / Configuration Guide CD

Optional Items

- Wall Mount with 3" Pedestal for JPTH-13 Pan-Tilt Head
- Corner Mount for Wall Mount above
- Pole Mount for Wall Mount above

1.4 - Before You Start

A successful installation assumes you have the necessary skills or qualified support personnel to accomplish the following tasks:

- Mount the JPTH-13 pan-tilt head and arm to a structure or a mast
- Ability to crimp and test RJ45 modular jacks to the end of a CAT5 cable
- A method to test CAT5 cables
- Ability to wire 120/220VAC power to the IP-PT System control enclosure (per local electrical code)
- Ability to provide a good earth ground via the 1/2" liquid tight fitting (or ground lug on the side of the enclosure for DC powered systems)

CAUTION

Always exercise extreme caution when working near power lines or live circuits to ensure that you, your ladder or other equipment does NOT come in contact with the power lines. Fatal shocks can occur.

2.0 - INITIAL SETUP

Before mounting all your equipment, it is highly recommended that the entire system be setup and tested completely before pieces of equipment are mounted in difficult to reach locations. This initial setup and test step will help to ensure a smooth, trouble free installation.

CAUTION

Always exercise extreme caution when working near power lines or live circuits to ensure that you, your ladder or other equipment does NOT come in contact with these power lines. Fatal shocks can occur.

If you are not qualified to install the wiring for this unit, please secure qualified help.



Shown above is the JPTH-13 pan-tilt head to the left, the special 7 foot interconnect cable and NEMA 4X control enclosure to the right. The connectors on the bottom of the control enclosure are from left to right the pan-tilt head connector, waterproof RJ45 jack and 1/2" liquid tight fitting for AC power.

2.1 Connecting the Pan-Tilt Head

Once all of the parts have been identified proceed to connect the supplied special (high flexibility) cable to the Military style connector on the rear of the pan-tilt head. The other end of the cable connects to the pan-tilt control enclosure. Make sure the Military style connector shell is fully engaged and locked in place.

This cable is specially designed to be utilized where constant flexing is required. Additionally, the cable has been selected to maintain its flexibility at extremely cold temperatures. Do not replace this cable with ordinary cable. If longer sections of cable are required, please consult the factory for pricing and delivery (the maximum length is 20ft).

CAUTION

Always exercise extreme caution when working near power lines or live circuits to ensure that you, your ladder or other equipment does NOT come in contact with these power lines. Fatal shocks can occur.

If you are not qualified to install the wiring for this unit, please secure qualified help.

2.2 Connecting AC Power

The PTZ controller is supplied with a metal, 1/2" liquid tight fitting. A special grounding ring has been attached to this fitting on the inside of the fiberglass enclosure. This ground ring is connected to the back panel and provides the necessary ground for the entire system.

AC power should be run to the IP-PT controller from an appropriate disconnect which includes a ground fault interrupt function. Local electrical codes should be followed for outdoor AC wiring. The cover of the IP-PT control enclosure will have to be opened to make all internal connections.

The AC power fitting provided is for 1/2" liquid tight flexible **steel** conduit; DO NOT USE PLASTIC LIQUID TIGHT CONDUIT WHICH HAS NO STEEL GROUNDING ELEMENT.

Proper grounding of the liquid tight flexible steel conduit at the power source must be accomplished in accordance with local electrical codes. Failure to provide an adequate ground may result in diminished surge and lightning protection for the PTZ controller.


AC power is brought to the enclosure and terminated in the 3-position terminal block directly adjacent to the 1/2" liquid tight fitting.

The Black wire is Phase A or the hot leg

The White wire is Neutral

The Green wire is earth ground

NOTE: 10-40VDC powered versions of the IP-PT system are available - consult factory.



3.0 - CONFIGURATION

The following paragraphs will lead you through the setup and configuration of the IP-PT control system.

3.1 - Install, Setup and Testing

The following sections will cover initial configuration of the controller's software and testing. It is recommended that all this configuration be done BEFORE the PT head and enclosure are mounted outside.

3.1.1 - Initial Power Up and Testing

At this point, the following items should be connected:

- The pan-tilt head should be connected to the IP-PT control enclosure with the special 7-ft cable. It would be beneficial to secure the pan-tilt head to the mount it will be ultimately attached to. This will allow the head to be fully operational during initial setup testing.
- Connect a CAT5 cable to the RJ45 jack on the bottom of the IP-PT control enclosure. The other end goes to your computer.
- AC power should also now be applied.


Here are the steps you will follow to gain access to the IP-PT controller:




1. Set your computer's network adapter IP address to 192.168.1.100 . To accomplish this in Windows XP or 2000, click on Start, Settings then Control Panel. Once inside Control Panel double click on the Network Connections icon as shown to the left.




2. Once you have clicked on Network Connections, you will see the icon to the left.
3. Double click on the Local Area Connection icon; you will see the following screen.



4. Select Internet Protocol (TCP/IP) and click on the Properties button. Once you have done this, you will see the next screen shown below.
NOTE: if your computer has been configured with manually entered static IP address, be sure to document this before you change it.



5. Now select "Use the following IP address". Enter an IP address of 192.168.1.10 . Enter a Subnet mask of 255.255.255.0 as shown below.



6. Click OK on this screen and then Close on the next screen.

Your computer is now on the same network as the IP-PT controller's default network settings which will allow you to access the IP-PT controller's configuration web pages. To do this, open the IE browser and type in the IP address of 192.168.1.2 and depress Enter. The following screen will appear.

Basic IP Controller		
Pan Right	Stopped	GO
Pan Left	Panning	GO
Tilt Up	Stopped	GO
Tilt Down	Stopped	GO

NOTE: All center indicators will show "Stopped"

NOTE: The PT Head is shipped in its electrical center position for both Pan and Tilt. If you Pan-Right twice during testing, be sure to Pan-Left twice to re-center the head. The same applies for Tilt.

At this point, you should be able to use your computer's mouse and click on anyone of the "GO" buttons to make the pan-tilt head move.

You will now want to set the IP address of the IP-PTZ controller to your local area network so you can set your computer's network adapter back to where it was originally. Enter the following URL into your browser <http://192.168.1.2/setup.html> and depress ENTER.

BASIC IP Controller

J-Systems, Inc.

Setup

NetworkPasswordRelay 1Relay 2Relay 3Relay 4Control Page

Model: BASIC IP-1

Product Revision: 2.5a

Serial Number: 00:0C:C8:02:05:C7

For product support go to www.J-Systems.com

J-Systems, Inc.

Click the “Network” tab. You will be prompted for a UserName and Password. This system does not accept a Username so tab over that field and enter the default password of “password”. The following screen should appear in a second or two.

The screenshot shows the BASIC IP Controller Setup page. At the top, there is a logo for BASIC IP Controller by J-Systems, Inc. and a title "Setup". Below the title is a navigation bar with tabs: Network, Password, Relay 1, Relay 2, Relay 3, Relay 4, and Control Page. The "Network" tab is selected. The main content area is divided into two sections. The left section, titled "Network:", contains fields for IP Address, Netmask, Broadcast, Gateway, TCP Port, and Modbus Port. The right section contains a message: "Network parameters require reboot before they take effect." Below the fields, there are radio buttons for Speed (10 Mbps and 100 Mbps) and Mode (Half Duplex and Full Duplex). At the bottom, there are "Submit" and "Reset" buttons.

Field	Value
IP Address:	192 . 168 . 1 . 2
Netmask:	255 . 255 . 255 . 0
Broadcast:	192 . 168 . 1 . 255
Gateway:	192 . 168 . 1 . 1
TCP Port:	80
Modbus Port:	502
Speed:	10 Mbps <input checked="" type="radio"/> 100 Mbps <input type="radio"/>
Mode:	Half Duplex <input checked="" type="radio"/> Full Duplex <input type="radio"/>

Change the IP Address, Netmask and Gateway to match your local area network and click on “Submit”. Leave Speed set to 10Mbps and Mode to Half Duplex.

After completing this, reset your computer back to your original network settings and make sure you can still control the PT head by entering its IP address into your browser to obtain the screen shown on Pg 7 “BASIC IP Controller”.

4.0 - INSTALLATION

At this point, all the hardware should have been tested and proved to be functional.

IMPORTANT - Prior to final installation, you should learn how to adjust the PT head mechanical limit switches while the PT head is within reach. Final adjustments can of course be done after the PT head is mounted. Please refer to Para 4.3 before mounting the PT head.

Mount your camera enclosure to the top of the PT Head .

4.1 Mounting the Pan-Tilt Head

The unit has a base which requires 3 x 1/4-20 bolts and washers (supplied) in a 120 degree bolt-hole pattern. When mounting the head, please remember that a fully loaded pan-tilt camera enclosure assembly may weigh considerably more than 13 lbs.

The pan-tilt head assembly is electrically and mechanically centered before being shipped and the connector is located at what we define to be the rear of the pan-tilt head.

Substantial mounting brackets (strong and rigid) will be required to handle this mechanical load and allow for adverse weather conditions. Bad weather can result in ice and snow build up as well as high wind loading. Consult the factory if you are unsure as to what type of bracket to use or to purchase factory available brackets

Stability and rigidity are important as the pan-tilt head with camera and enclosure exerts inertia when it starts and stops. If the mounting mechanism is not rigid enough, some back and forth motion may be seen when the head starts and stops.

Once the camera location has been determined, the mounting bracket should be attached to the mounting surface with suitable heavy duty hardware to assure a safe and secure installation. Make sure the mounting surface is in good condition; crumbling bricks or cracked concrete are not to be used.

The camera enclosure must also be given sufficient clearance to ensure that it does not hit any obstructions when rotated. The motor and gearbox assemblies of the pan-tilt head are designed to be “stalled” but continuous abuse will cause damage which is not covered under the warranty.

The pan-tilt head and camera enclosure are very heavy and difficult to hold in one hand. This equipment should be secured by a safety line to prevent it from falling on someone below if dropped by the installer.

Also, once operational, this equipment is subject to remote control and may be operated at any time while you are working on it. Persons working on this equipment should take appropriate precautions to ensure that any unexpected movement does not occur as this could lead to finger / hand injury or startle you causing you to fall or slip.

Always leave the power off to the control system and make sure someone is at the control who will make certain it is not activated without your express knowledge.

A pair of wireless radios are beneficial during installation and / or maintenance so the installer and the operator can communicate directly.

4.2 Mounting the Control Enclosure

The control enclosure has been supplied with rugged, stainless steel mounting brackets. These brackets can be used to mount the control enclosure to a flat wall, a small mast or larger pole such as a wooden telephone pole or metal light pole.

The brackets accept lag screws or bolts, stainless steel band clamps / straps and U-bolts. None of this hardware has been supplied as each installation's mounting requirements are different.

CAUTION

Always exercise extreme caution when working near power lines or live circuits to ensure that you, your ladder or other equipment does NOT come in contact with these power lines. Fatal shocks can occur.

If you are not qualified to install the wiring for this unit, please secure qualified help.

AC power should be connected as described in Para 2.2 . Again, only liquid tight conduit that supplies an earth ground should be used.

If you have purchased a DC powered system, then a 1/2" plastic bulkhead fitting will be supplied which can replace the 1/2" metal liquid tight fitting if you like. Also, your enclosure will have a small copper ground lug on the side of the enclosure. This ground lug MUST be tied to earth ground following NEC code.

You have also been supplied with the mating half of the water proof RJ45 connector. Follow the supplied directions for inserting your CAT5 cable into this connector.

4.3 Adjusting the Pan-Tilt Head Limit Switches

Once the system is operational and the pan-tilt head can be panned and tilted, it is important to set the mechanical limit switches that control the absolute pan and tilt limits.

For the purposes of identification, the rear of the pan-tilt head is defined as the connector location. When viewed from the top, clockwise movement is Pan-Right and counter-clockwise movement is Pan-Left.


The head contains internal pan and tilt limit switches that are controlled by shaft mounted actuators (2-per shaft). As the head rotates, one actuator trips an externally mounted switch level arm which causes the pan-tilt head to stop moving in that direction. This system provides an accurate and simple method of applying pan and tilt limit stops. It is not necessary to power down or gain access to the inside of the unit to set the limit switches.

Setting the Pan Limit Switch

Drive the pan-tilt head to the left hand position you require. Slide the top actuator until it engages and trips the switch lever arm. This is best done using a flat blade screwdriver (**keep your fingers out of this area**). This limit is now set.

In a similar manner, drive the unit to the extreme right hand position required and slide the bottom actuator until it engages and trips the switch lever arm. This limit is now set. Drive the pan-tilt unit to the extreme limits of travel in both directions and check operation for the limit switches. Re-adjust if necessary.

Photo shows two limit switch actuators mounted on the pan shaft.



Setting the Tilt Limit Switch

Drive the pan-tilt head to the upper most position required (camera would be pointed upward). Slide the rear actuator until it engages and trips the switch lever arm. This is best done using a flat blade screwdriver (**keep your fingers out of this area**). This limit is now set. Drive the unit to the lowest point required (camera pointed downward) and slide the front actuator until it engages and trips the switch lever arm. This limit is now set. Drive the pan-tilt unit to the extreme limits of travel in both directions and check operation for the limit switches. Re-adjust if necessary.

Photo shows tilt actuator tripping the switch lever arm.



The IP-PT Control System installation and test should now be complete.

5.0 - SETUP INTERFACE

If changes are required to the BASIC IP PT control's default setting, they can be made by accessing the built in web interface of the control. This is accomplished by entering the IP address of the control as follows:

`http://192.168.1.2/setup.html`

Note: the controls IP address may have been changed during Configuration.

Once entered, the following screen will appear:




The screenshot shows the BASIC IP Controller Setup interface. At the top, there is a logo for "BASIC IP Controller" and "J-Systems, Inc." to its right. Below the logo is a navigation bar with tabs: "Network", "Password", "Relay 1", "Relay 2", "Relay 3", "Relay 4", and "Control Page". The "Network" tab is currently selected. The main content area is blue and displays the following information: "Model: BASIC IP-1", "Product Revision: 2.5a", "Serial Number: 00:0C:C8:02:05:C7", and "For product support go to www.J-Systems.com". At the bottom of the blue area, it says "J-Systems, Inc."

In the Configuratio section of this manual, you saw how to change the IP address of the controller; that was done by selecting the "Network" tab.

PASSWORD

The "Password" tab will allow you to change the password (note that User Names are never used). The Setup Password by default is " password ". If you change this, MAKE SURE YOU WRITE IT DONE FOR FUTURE USE !!! The Setup Password controls access to the setup.html web page.

The Control Pasword is by default set to OFF. This controls access to the main Pan Tilt control page.



The screenshot shows the BASIC IP Controller Setup interface with the "Password" tab selected. The navigation bar at the top is the same as in the previous screenshot. The main content area is blue and displays the following fields: "Setup Password:" with a password input field, "Re-enter Setup Password:" with a password input field, "Enable Control Password:" with radio buttons for "Yes" and "No" (the "No" button is selected), "Control Password:" with a password input field, and "Re-enter Control Password:" with a password input field. At the bottom of the blue area, there are "Submit" and "Reset" buttons.

RELAY 1

Clicking on the “Relay 1” tab will bring up the following screen:

The screenshot shows the BASIC IP Controller Setup interface. At the top, the logo "BASIC IP Controller" is displayed, followed by "J-Systems, Inc." and the word "Setup". Below this is a navigation bar with tabs: "Network", "Password", "Relay 1", "Relay 2", "Relay 3", "Relay 4", and "Control Page". The "Relay 1" tab is selected. The main content area is divided into two sections: "Control Page Setup:" and "Relay 1 Setup:". The "Control Page Setup:" section includes fields for "Main Header Text" (Basic IP Controller), "Auto Refresh Page" (Yes ☐ No ☒) with a "Duration" of 3 sec. The "Relay 1 Setup:" section includes fields for "Relay Description" (Pan Right), "Display Relay Status" (Yes ☒ No ☐) with "Status ON Color" (Gr ☒ Rd ☐ Yllw ☐ Bl ☐) and "Status ON Text" (Panning), "Status OFF Color" (Gr ☐ Rd ☐ Yllw ☒ Bl ☐) and "Status OFF Text" (Stopped), "ON/OFF Buttons" (0 ☒ 1 ☐ 2 ☐) with "Button1 Label" (Pan-RIGHT) and "Button2 Label" (OFF), "Pulse Button" (Yes ☒ No ☐) with "Pulse Button Label" (GO) and "Pulse Duration" (1.0 secs). At the bottom are "Submit" and "Reset" buttons.

Control Page Setup:	Relay 1 Setup:
Main Header Text: Basic IP Controller	Relay Description: Pan Right
Auto Refresh Page: Yes <input type="radio"/> No <input checked="" type="radio"/>	Display Relay Status: Yes <input checked="" type="radio"/> No <input type="radio"/>
Duration: 3 sec	Status ON Color: Gr <input checked="" type="radio"/> Rd <input type="radio"/> Yllw <input type="radio"/> Bl <input type="radio"/>
	Status ON Text: Panning
	Status OFF Color: Gr <input type="radio"/> Rd <input type="radio"/> Yllw <input checked="" type="radio"/> Bl <input type="radio"/>
	Status OFF Text: Stopped
	ON/OFF Buttons: 0 <input checked="" type="radio"/> 1 <input type="radio"/> 2 <input type="radio"/>
	Button1 Label: Pan-RIGHT
	Button2 Label: OFF
	Pulse Button: Yes <input checked="" type="radio"/> No <input type="radio"/>
	Pulse Button Label: GO
	Pulse Duration: 1.0 secs

Submit Reset

The only setting on this page that you may want to adjust is the default “Pulse Duration” time. The default is 1 second and the useful range is 0.1 to 1.5 seconds. If you change the value, click Submit to save it.


Relay 2 through Relay 4 are similar pages and again only Pulse Duration should be changed - no other settings.

Clicking on the Control Page tab will take you back to the main BASIC IP PT Control System screen where you can control the PT Head position.

6.0 HTML API - WEB PAGE INTERFACE

Designing custom web pages is very simple assuming you have a basic knowledge of HTML programming.

Please refer to the BASIC IP PT Control System API file located on the included CD.



Internal Layout View

7.0 TECHNICAL SUPPORT

Technical support is available for no charge during normal business hours.

Business Hours:

Monday - Friday 9:00AM to 4:00PM CST

Contact Information:

Tele: 630-627-3458

Fax: 630-620-0960

E-Mail: info@J-Systems.com

Technical support will not be able to help you design custom web pages. These are all questions best handled by a qualified web programmer.

8.0 SUPPORT INFORMATION

8.1 Warranty Policy

The PTZ Controller carries a 2-year manufacturer's warranty. This warranty applies to failure of the product under normal operating conditions. Situations that are not covered by this warranty include, but are not limited to the following stresses:

- Lightning Strikes
- Repeated Mechanical Stalling of the Head
- Damage Due to Bullets or Other Projectiles
- Cable Damage Due to Animals
- Encasement in Ice
- Applied Voltage Greater Than 264VAC
- Overloading the PTZ Head
- Attempted Repair By An Unauthorized Individual

Any other damage that in J-Systems, Inc.'s opinion have been caused as a result of abnormal or abusive use will also void the warranty.

To return a unit for repair, an RMA (Return Material Authorization) must be obtained prior to sending the unit back. Units received without a prior RMA being issued will be returned to the sender unopened.

When returning a unit for warranty or out of warranty repair, the cost of shipping back to the factory will be borne by the customer. Warranty repaired items will be returned to the customer postage free.

Call 630-627-3458 during normal business hours to obtain an RMA.

8.2 Specifications

The following are general specifications for the IP-PT Control System. These specifications are subject to change at any time. Detailed specifications are found on the IP-PT Control System literature piece located on the CD.

Pan-Tilt Head

Height:	5.800 in	Connector:	Nickel Plated MIL-C-26482 14-15
Width:	6.210 in	Speed:	Pan = 28 Deg/Sec. Tilt = 8 Deg/Sec.
Depth:	5.08 in with connector	Capacity:	13 lbs or less
Materials:	Machined Alu w/ Stainless Fasteners Anodized Alu Mounting Ring Polymer Bearings for Quiet Operation Ball Bearings on Major Axes	Rotation Limits:	Pan = 0 to 350 Deg Tilt = -90 Deg Down to +30 Deg Up
Paint:	Powder Coat	Color:	Light Grey similar to RAL 9018
Mounting Plate:	Width = 5.820 in Depth = 4.730 in Slots = 1/4 in Hardware or Smaller	Backlash:	< 0.15 Deg
Weight:	5 lbs	Maintenance:	None Required
Voltage:	12VDC +/- 5%	Operating Temp:	-30C to +70C No Heating or Cooling Required
Power:	Less than 1.5 W per Axis	Braking:	Regenerative
		Weatherproof:	IP68
		Warranty:	2-Years

BASIC IP Controller

Height:	9.500 in
Width:	7.2500 in
Depth:	5.000 in
Materials:	Fiberglass Enclosure - NEMA 4X Stainless Steel Mounting Brackets
Connectors:	Nickel Plated MIL-C-26482 14-15 Waterproof RJ-45 1/2" Liquid Tight Conduit Fitting
Color:	Light Gray - RAL 7036
Weight:	3 lbs
Voltage:	110/220 VAC, 50-60 Hz (TUV & CE)
Power:	1.5 Watts Max
Operating Temp:	-30C to +70C
Warranty:	2-Years