USER MANUAL

SurgeX SX-1115ip-X SX-1120ip-X

Web-Enabled Power Conditioning Management System

Software Version: vQ110630G.123 Firmware Version: Q110630G.285



ICOINTOI Manual

INTRODUCTION	
INITIAL SET-UP	5
SETUP AND CONTROL UTILITY (SCU)	
COMMAND LINE INTERFACE (CLI)	
SETTING THE IP ADDRESS	
INSTALLATION	9
120 VOLT CONNECTIONS	
ETHERNET CONNECTION	
RS232 (SERIAL) PORT CONNECTION	
DIAL LINE	
EXPANSION	
LEDINDICATODS	10
LED INDICATORS	
WEB SERVER	
Header	
Control	
STATUS	
Device View	
OUTLET STATUS	
GROUP VIEW	
GLOBAL VIEW	
AUTOPING VIEW	
COMMAND LINE INTERFACE (CLI) PROTOCOL	
OUTLET COMMANDS	
USER COMMANDS	
DEVICE COMMANDS	
GROUP COMMANDS	
NETWORK COMMANDS	
WEB SERVER COMMANDS	
TELNET COMMANDS	
AUTOPING COMMANDS	
EVENT COMMANDS	
EMAIL COMMANDS	
TIME COMMANDS	
FIRMWARE UPLOAD COMMANDS	
1	



ADVANCED OPERATION	
DTMF Control Timed Events AutoPing SSL Security	23 24 25 26
CERTIFICATE UPLOAD UTILITY	
EMAIL NOTIFICATION	
SNMP	
FIRMWARE UPGRADES	
FRONT PANEL RESET BUTTON	
SETUP AND CONTROL UTILITY (SCU)	
SNMP MIB	
COMPLIANCE STATEMENTS	
SPECIFICATIONS	



INTRODUCTION

The SurgeX[®] iControl SX-1115ip-X (SX-1120ip-X) is a single rack-space, 120V, 15 (20) amp, AC power conditioner that can be controlled over a network or the internet. The iControl incorporates SurgeX Advanced Series Mode[®] power conditioning and surge elimination, as well as SurgeX Impedance Tolerant[®] EMI/RFI filtering. The simple web server structure allows basic control of the outlets (and groups of outlets) and viewing of status information all from the home page. The extensive programming and setup capabilities are accessed by a Setup and Control Utility (SCU) or through a Command Line Interface (CLI).

Telnet and serial access use the same Command Line Interface (CLI) structure and syntax to completely configure the iControl, or multiple iControls in a cluster configuration.

Up to 16 iControls can be linked together and controlled from a single web or CLI interface. One master iControl provides the communication to the users and continuously receives status information from the rest of the iControls in the cluster. Up to 128 outlets can be controlled in this manner from one IP address.

Multiple outlets, across multiple iControls in clustered configurations, can be linked together in named groups and managed together. This allows, for example, power cycling all devices of a certain type together.

Up to 16 systems can be continuously monitored with AutoPing, with automatic power control upon loss of contact. Reboot crashed systems, or provide auto power-up or –down for environmental controls and notification systems.

Up to 16 users can be assigned administrator or user only rights, plus access to specific outlets and groups. Users only see the outlets and groups they are assigned to.



Located on the rear panel are the input power cord, circuit breaker (15A or 20A), 8 NEMA 5-15 AC outlets, Serial connection (DCE, 9 pin D-subminiature), Network connection (RJ-45), Phone connection (RJ-11), and Expansion Ports for cluster configurations.





The two front panel LEDs provide indication of AC power (red) and surge protection status (green). Also located on the front panel is a recessed Reset button (used to reset the Administrator password).

The extensive programming capabilities of the iControl allow sequencing and scheduling to be set up, not just for the host unit, but also for other iControl units on the same network.

The internal modem (for models with internal modem option) supports data calls from terminal devices using the CLI, and direct dial from a tone telephone for simple On/Off control when more sophisticated means are not available.

Setup and Control functions can be linked to any SNMP v1 compatible manager. The iControl MIB is available at surgex.com.

All activity can be reported to a syslog compatible server.

The iControl's internal web server is secured with Secure Sockets Layer (SSL) encryption.

The iControl's Certificate Utility can be used to create, manage, and upload SSL certificates.





INITIAL SET-UP

Setup and Control Utility (SCU)

The iControl Setup and Control Utility (SCU) utility provides the easiest means to find and configure your iControl for use. The SCU can:

- 1. Automatically discover multiple iControls on a local network.
- 2. Add additional iControls not on the local network.
- 3. Download existing configurations from installed iControls.
- 4. Save existing configurations for later use or as backup.
- 5. Open saved configurations for change management.
- 6. Clone saved configurations for replication of similar configurations in multiple iControls.
- 7. Upload modified configurations to iControls.
- 8. Control outlets on one or more iControls throughout the network.

The iControl Setup and Control utility is available on the iControl CD or on the SurgeX website at http://www.surgex.com

😲 iControl Setup		😲 iControl Setup	
<u>File H</u> elp		<u>File H</u> elp	
iControl Select:	Connect Control Setup	iControl Select:	Connect Control Setup
iControl	SNMP Agent Email Time Syslog Timed Events AutoPing Device Outlets Users Groups IP Address Web Server Teinet Server File: iControl-10. 1.2.61./bbcfg Name: Control Cycle Time: 10 Seconds Delay Time: 1 Seconds Delay Time: 1 Seconds Current Alarm: High 15.0 Low 0.0 Main A Voltage Alarm: High 15.0 Low 90 Console Timeout: 120 Seconds Baud Rate: 11520	iControl	On © Outlet1 On © Outlet2 On © Outlet3 On © Outlet4 On © Outlet5 On © Outlet5 On © Outlet6 On © Outlet7 On © Outlet8 Delay Time: 1 Seconds Current 1-8 Cycle Time: 10 Seconds Voltage
Add iControl	Upload Enable:	<u>A</u> dd iControl	Query On Off Cyde
<u>C</u> lear List		<u>C</u> lear List	

Note: The Setup and Control Utility only operates with iControls attached to the network. iControls in a cluster configuration can be configured using the setup and control utility, if they are attached to the network.



Command Line Interface (CLI)

All configuration parameters are set using the Command Line Interface (CLI). The CLI is accessed through the network, using a telnet client, or through the serial port, or data modem (for models with internal modem option) using a terminal client. In iControl clusters, all remote iControls can be configured and managed through the connection to the Master iControl. It is also possible to access, configure and control any Expansion iControls directly.

Open a telnet client and point it to the current IP Address of the iControl. (Factory Default is **192.168.0.254**, telnet **Port 23**)

Connect to the Serial port or via PSTN connection to the modem. (Factory Default is **115200,8,n,1**)

Upon connection, press Enter, and then enter the username and password when prompted. (Factory Default for username and password is **admin**)

Setting the IP Address

iControls come with factory default IP address 192.168.0.254.

There are three techniques to setting the IP address of the iControl:

- 1. Terminal Client software via Telnet, Serial, Modem.
- 2. Automatically from a DHCP Server
- 3. ARP / Ping (factory default)

To configure the mode to set the IP address, access the iControl's command line interface (CLI) and use the set ipmode command as indicated below.



Setting the IP address using CLI

These are the basic commands to set the network parameters. After setting these parameters, the iControl will need to be rebooted for the settings to take effect. Any command that requires rebooting of the iControl will provide a prompt to do so. All commands may be entered as required before rebooting.

Example: Telnet to default IP address 192.168.0.254 on Port 23.

iControl Rev Q101124G.272 User Name: admin Password: ***** iControl > set ipaddress 192.168.1.3 Reboot Required! OK iControl > set subnet 255.255.255.0 Reboot Required! OK iControl > set gateway 192.168.1.7 Reboot Required! OK iControl > reboot IP Address = 192.168.1.3

Once the IP address is set, the following command can be used to prevent DHCP or ARP-Ping from altering it: set ipmode static

Setting the IP address from a DHCP Server

A DHCP server will automatically assign an IP address (dynamic address) as well as Subnet Mask and Gateway to the iControl.

To enable this feature, configure the iControl with the command **set ipmode dhcp** Then reboot the iControl, or enter the command **reboot**

To find the IP address of the iControl, you will need to query your DHCP server and locate the MAC address of the iControl in the DHCP server's IP / MAC table. You can also access the CLI and use the **get network** command, or use the Discover provision of the iControl Setup and Control Utility (SCU).



Setting the IP address using ARP / Ping

The ARP / Ping technique uses a PC running a command line (DOS Window) to set the IP Address. To set the IP address using ARP, connect the iControl to your local network and apply power. The IP address to be assigned to the iControl must use the same subnet as the computer assigning the address. ARP does not work across routed or switched networks.

Windows (98 and Later)

- 1. Access the iControl CLI and enter the set ipmode arp-ping command.
- 2. On a PC, open a DOS window. (Run: Command)
- Type the following command: arp -s <IP Address> <MAC Address> Where <IP Address> is the desired IP address (in dotted decimal) for the iControl and the <MAC address> is the MAC Address of the iControl. The MAC Address of the iControl is located on the rear of the unit.

Example: **arp -s 63.211.86.165 00-50-c2-05-01-c1 <enter>** |**new IP addr**| |---**MAC addr**----|

4. Ping the iControl to program the IP address into the iControl. Type: ping <IP Address>

Note: If the ping command returns "host not responding" 4 times then the address has not been programmed properly. Check the IP or MAC Address for typographical errors. Repeat step 2.

- 5. Delete the entry from the ARP cache by typing: arp -d <IP Address>
- 6. Ping the iControl to confirm that it has been programmed.

Note: If the iControl fails to respond, repeat steps 2-4 above.

Unix, Linux, MAC and others

Consult your systems administrator for information on how to set an IP Address. The unit should be pinged after the IP Address has been set to confirm proper operation.



INSTALLATION

The SurgeX iControl is designed to be installed in a 19 inch equipment rack and requires one unit (1-U) of rack space. Use the four screws provided with the product to secure the rack ears to the rack rails. These screws can be tightened by hand and do not require tools. Connect power to the unit by plugging the cord into a 120V AC, 20 amp wall or floor receptacle. Do not plug the unit into a relocatable power tap.

120 Volt Connections

The iControl has a total of 8 receptacles. Each receptacle is rated for a maximum load of 15 amps, but the total load of the SX-1115ip-X (SX-1120ip-X) must not exceed 15 (20) amps. Plug the equipment cords into the receptacles as needed. The receptacles are numbered 1 through 8. This same numbering is used in the control interface.

Ethernet Connection

The RJ45 connector for Ethernet is situated on the rear panel between the Serial and Modem connectors. The default IP Address is 192.168.0.254.

RS232 (Serial) Port Connection

The iControl has a 9 pin D subminiature connector for RS-232 serial control. The connector is configured as DCE for direct connection to a laptop or other terminal device. Default serial parameters are 115,200 bps, 8 data, no parity, 1 stop bit (115200,8,n,1).

Serial Port Pinout			
Pin Number	Description		
1	Data Carrier Detect		
2	Receive Data		
3	Transmit Data		
4	Data Terminal Ready		
5	Signal Ground		
6	Data Set Ready		
7	Request To Send		
8	Clear To Send		
9	Ring Indicator		

Dial Line

The internal modem (for models with internal modem option) supports both data and DTMF control. The modem is approved for use in 36 countries. See Appendix for complete modem certifications.

Expansion

The dual Expansion ports allow multiple iControls to be linked together and managed from a single point. The expansion connector is a 6 wire RJ-11 modular jack. iControls can be connected together in a daisy-chain or ring configuration. Up to 16 iControls can be clustered together and managed from a single web page or console session. Use 6 conductor data cable to connect iControls for cluster configurations. Configuration settings determine whether the iControl is the Master or Expansion.



LED INDICATORS

There are two LED indicators located on the front panel. Their function is as follows:

Self Test (Green): When illuminated, the surge suppression circuitry is functioning correctly.

Power (Red): When illuminated, the iControl is connected to a live wall or floor outlet.

WEB SERVER

The iControl web interface provides the easiest means of operating the outlets and monitoring

the current status of the units. One or more outlets can be simultaneously controlled with a few mouse clicks. In cluster configurations, all 128 outlets can be managed from the web pages.

The interface is divided into three sections: Header, Control, and Status.

Each user will only be able to view and control the outlets, devices, and groups that have been assigned to that particular user.

	Attac	hed to:		Control: Monitor:	
	Con	trol Ro	om A	Control Room Select Group Global AutoPing Sensors	
ontrol				Control Room A	
On	Devic	e View			
Off	Contro	Room A	lue.		
Orde	1	On	Г	Ion Control	
Cycle	2	On	Π	Bridge	
cle 10 Sec.	3	On	Г	Outlet3	
lay 1 Sec.	4	On	Г	Outlet4	
and the second	5	On	Г	OutletS	
Select All	6	On	Г	Outlet6	
	7	On	Г	Outlet7	
Select None	8	On		Outlet6	
Refresh	Total C	urrent = 0).1 amp	E Line Voltage = 120 volts	
	Lunana				
Logout					

Header

The header identifies the iControl currently being accessed. If multiple iControls are deployed in a cluster configuration, this will be the master iControl.

Attached to:	Control:	Monitor:		
Control Room A	Control Room Select Group Global	AutoPing Sensors		

The header allows the selection of various status views. To select an individual iControl, or predefined group of outlets, click on the one of the two dropdown lists. To select the global view, click on Global. To see the status of the AutoPing feature, click on AutoPing.



Control

The Control panel provides the clickable buttons to change the status of one or more outlets. Once one or more outlets have been selected, click on the On, Off, or Cycle button. Cycle will perform a timed change in outlet state; either Reboot (On-Off-On), or Cycle (Off-On-Off), depending on the current state of the outlet.

The Cycle timer box allows specification of the length, in seconds, of all cycle or reboot operations. Entries of 1 to 99 seconds are valid.

The Delay timer box allows specification of the delay time, in seconds, between the powering on of each outlet whenever more than one outlet is turned on from the same command. This can be used to prevent over-current draw on initial power up of devices. Entries of 0 to 99 seconds are valid.

The Select All and Select None buttons allow selection or de-selection of all outlets.

Refresh provides an update of the status page to display current conditions. Web pages are static moments in time, so use the Refresh button to obtain the latest status.

Logout terminates the session.

Status

The Status window displays the current view, controllable outlets, or other outlet information. Buttons in the header select the current view.

Device View

The Device View displays the status of a single device. It shows the current status of each outlet of the device, and allows selection of one or more outlets for control. It also displays the line voltage, total current draw, and any alarms.

Use the checkboxes to select or de-select any outlet for control.







Outlet Status

Outlet Status is displayed by a colored text box. The color indicates the current status of the outlet, and the text indicates the function being performed.

High current or voltage alarms are highlighted in red; low current or voltage alarms are highlighted in yellow.

On	Outlet is On
Cycle	Outlet is On during Cycle. It will turn off when cycle time is complete
Off	Outlet is Off
Reboot	Outlet is Off during Cycle. It will turn on when cycle time is complete
On / Pend	Outlet is Off . It has been commanded to turn on and will do so in its turn based on the delay time.

Group View

The Group View displays the status of a single group. Groups are two or more outlets linked together for simultaneous control. In the group view, each device containing a member of the group is displayed on a line, with the status of the outlets that are group members. Control the group by clicking on the appropriate button in the Control section.



Global View

The Global View displays all iControls in one view. Each outlet has a checkbox, allowing multiple outlets to be simultaneously controlled without the need to establish a group. Only outlets that the user has rights to will have status and control checkbox displayed.





AutoPing View

The AutoPing View displays the 16 AutoPing channels, their programmed action, and current status.

The status column will display the current status of the AutoPing. The numeric column will display the number of times the AutoPing has been triggered.

A numeric counter other than 0, with the status reporting OK, indicates that there have been previous AutoPing triggers, but the current status is OK.

To reset the trigger count, click on the Reset button.

 ☐ iControl ver Q101124G.272 ← → C ☆ ◎ 10.1 	× (⊕						
SURGEX.	Atta Co	ached to: ntrol Room A	Select Device	Control: Select Group Global	Ma AutoPing	nitor:	ensors	
Control Autoping View								
Off	No.	IP Address	Action	Assigned	Sta	tus		
Cycle	1	10.1.2.12	None	Control Room A Ion Control	ОК	0	Reset	
	2	192.168.1.2	Off-Latch	Control Room A Bridge	x	1	Reset	
Cycle 10 Sec.	3	0.0.0.0	None	Unassigned	ОК	0	Reset	
Delay 1 Sec.	4	0.0.0.0	None	Unassigned	ОК	0	Reset	
	5	0.0.0.0	None	Unassigned	ОК	0	Reset	
Select All	6	0.0.0.0	None	Unassigned	ОК	0	Reset	
Select None	7	0.0.0.0	None	Unassigned	ОК	0	Reset	
Refresh	8	0.0.0.0	None	Unassigned	ОК	0	Reset	
Kenesii	9	0.0.0.0	None	Unassigned	ОК	0	Reset	
Logout	10	0.0.0.0	None	Unassigned	ОК	0	Reset	
	11	0.0.0.0	None	Unassigned	ОК	0	Reset	
	12	0.0.0	None	Unassigned	ОК	0	Reset	
	13	0.0.0.0	None	Unassigned	ОК	0	Reset	
	14	0.0.0	None	Unassigned	ОК	0	Reset	
	15	0.0.0	None	Unassigned	ОК	0	Reset	
	16	0.0.0.0	None	Unassigned	ОК	0	Reset	



COMMAND LINE INTERFACE (CLI) PROTOCOL

The Command Line Interface provides complete setup of all functions of the iControl. The CLI may be accessed either via the network interface using Telnet, or via the modem (for models with internal modem option) or serial port using a terminal emulator program. Some commands of the CLI require administrative rights; these are indicated in the following tables.

Command	Description	Admin	Fact Def
get outlets	Returns the status of ALL the outlets the user has rights to. Displays all devices and outlets in a cluster configuration.	No	
get outlet <1-8>	Returns the status of the iControl. This command is for iControls not used in a cluster configuration. If used in a cluster, it is the same as device #1. The user must have rights to the selected outlet.	No	
set outlet <1-8> <on cycle="" off=""></on>	Sets the selected outlet to the selected state. The user must have rights to the selected outlet. This command is for iControls not used in a cluster configuration. If used in a cluster, it is the same as device #1.	No	
get device <#1-#16/devname> outlet <1-8>	Returns the status of the selected outlet on the selected iControl. Device is either the number of the device <#1 to #16> or the name of the device, as set. Number sign (#) required. The user must have rights to the selected outlet.	No	
set device <#1-#16/devname> outlet <1-8> <on cycle="" off=""></on>	Sets the selected outlet on the selected iControl to the selected state. The user must have rights to the selected outlet.	No	
set device <#1-#16/devname> outlet <1-8> name <name></name>	Sets the name of the selected outlet of the selected iControl. 20 characters max.	Yes	Outlet <#>
get device <#1-#16/devname> outlet <1-8> initial.state set device <#1-#16/devname> outlet <1-8> initial.state <on last="" off=""></on>	Get or set the initial state of the selected outlet of the currently selected iControl. Initial state is the condition of the outlet when the iControl is powered up.	Yes	Last

Outlet Commands



User Commands

Command	Description	Admin	Fact Def
get users	Return a list of all current users.	Yes	
get user <username></username>	Returns the selected user's details.	Yes	
add user <username></username>	Added a user to the root iControl's user table. 16 users maximum. 20 Characters max.	Yes	
	Note: the new user's password will default to the same as the username.		
	Users default to no rights to any outlets. Add user rights to outlets and groups.		
del user <username></username>	Deletes the selected user from the root iControl's user table.	Yes	
ren user <username> <newname></newname></username>	Renames the selected user in the root iControl's user table. 20 character max.	Yes	
set user <username> device <#1-#16/devname/all> outlet <1-8/all> <yes no=""></yes></username>	Sets the user's right to the selected outlet on a specific device.	Yes	No Rights
set user <username> group <name> <yes no=""></yes></name></username>	Sets the user's rights to the selected group.	Yes	No Rights
set user <username> role <admin user=""></admin></username>	Sets the user's role.	Yes	User
set user <username> password <password> <confirm></confirm></password></username>	Sets the user's password. 20 characters max.	Yes	User's Name
set user <username> email <address></address></username>	Sets the user's email address for the root iControl to send alerts to. 64 characters max.	Yes	
set user <username> sendmail <yes no=""></yes></username>	Enables or disables the user's receipt of email alerts.	Yes	No
set user <username> pin <pin></pin></username>	Sets the user PIN for DTMF control. $4 - 10$ digits.	Yes	



Device Commands

Command	Description	Admin	Fact Def
get devices / get all / get outlets	This command displays a list of connected devices, and their current status.	No	
get device <#1-#16/devname>	Get device information. Displays the device name, and all outlet names and current status.	Yes	iControl
set device <#1-#16 > name <name></name>	Set the name of the selected iControl. 20 characters max.		
get cycle	Get or set the cycle time in seconds.	No	10
set cycle <1-99>			
get delay	Get or set the delay time in seconds.	No	1
set delay <1-99>			
get power	Get the current power draw and energy used since the last counter reset. The energy counter can be reset via SCU or web page, and will also reset after a reboot.		
get current	Get the measured current of the local iControl.	Yes	
get device <#1-#16/devname> current	Get the measured current of the selected iControl.		
get current alarm	High and Low alarms are used to monitor current conditions and send	Yes	Highalarm:
get device <#1-#16/devname> current alarm	an alert by email, SNMP and syslog when the high or low thresholds are exceeded.		1702 17
set main a hcalarm <nn.n></nn.n>	From 0.0 to 10.0/15.0/20.0 (depending on max current for device) in		15.0 for 15 Amp Models
set device <#1-#16/devname> main a	0.1 amp increments.		1
hcalarm <nn.n></nn.n>			20.0 for 20
set main a lcalarm <nn.n></nn.n>			Amp Models
set device <#1-#16/devname> main a lcalarm <nn.n></nn.n>			Lowalarm: 0.0 Amp



get voltage	Get the measured voltage of the local iControl.	Yes	
get device <#1-#16/devname> voltage	Get the measured voltage of the selected iControl.		
set main a vcalibration <nnn.nn></nnn.nn>	Set the voltmeter calibration. From 105.00 to 150.00 in 0.01 V increments.	Yes	
get voltage alarm	High and Low alarms are used to monitor voltage conditions and send	Yes	Highalarm:
get device <#1-#16/devname> voltage alarm	an alert by email, SNMP and syslog when the high or low thresholds		
set main a hvalarm <nnn></nnn>	are exceeded.		135-150 V
set device <#1-#16/devname> main a hvalarm <nnn></nnn>	Adjustable in 1 V increments.		Lowalarm:
set main a lvalarm <nnn></nnn>			00 105 V
set device <#1-#16/devname> main a lvalarm <nnn></nnn>			90-105 V
get console	Displays the current console configuration, Timeout, and Baud Rate.	Yes	
set console timeout <30-3600/disable>	Console can be set to automatically logout with no activity for 30 seconds to 1 hr in seconds, or disabled.	Yes	120
set console baudrate <400/4800/9600/19200/38400/57600/115200>	The baud rate of the serial port. 400,4800,9600,19200,38400,57600,115200 bps	Yes	115200
get modem	Gets the current settings of the modem. (modem models only)	Yes	
set modem countrycode <countrycode></countrycode>	Sets the modem country code. (modem models only) See Appendix for a list of country codes.	Yes	181 (USA)
set device <0-16>	Get / Set the device ID for cluster applications. Set a device ID of 0 for	Yes	0
get device	and a device ID of 2-16 makes the iControl a remote in cluster configurations. These commands are only valid when directly connected to the iControl, rather than as remote units in a cluster.		



set unit <hwkey> device <2-16></hwkey>	Sets the ID of a remote device in cluster configurations. The hardware key <hwkey></hwkey> is the last 2 bytes of the MAC address with NO spaces, dashes or colons.	Yes
	In this example, the <hwkey> is 38A2.</hwkey>	
set factory defaults	Resets all parameters to their factory settings including the IP Address. Only available on the serial port. Confirmation is required. Note: This command can take up to 30 seconds to execute.	Yes
logout	Ends the session.	No
reboot	Reboots the selected iControl. This will not change the status of the outlets of standalone or Master of cluster configuration (device ID 0 or 1). May cause outlet changes in expansion units (device ID 2-16).	Yes

Group Commands

Command	Description	Admin	Fact Def
get groups	Returns a list of the groups that the current user has rights to.	No	
get group <groupname></groupname>	Returns the details of the selected group.	No	
set group <groupname> <on cycle="" off=""></on></groupname>	Controls the selected group.	No	
add group <groupname></groupname>	Adds a new group. 20 characters max. Up to 8 groups maximum.	Yes	
set group <groupname> device <#1-#16/devname/all> outlet <1-8/all> <yes no=""></yes></groupname>	Adds or deletes a specific outlet on a specific device from the selected group.	Yes	
ren group <groupname> <newname></newname></groupname>	Renames the selected group. 20 characters max.	Yes	
del group <groupname></groupname>	Deletes the selected group.	Yes	



Network Commands

Command	Description	Admin	Fact Def
get network	Returns the network settings.	Yes	
set ipmode <arp-ping dhcp="" static=""></arp-ping>	Set the IP Mode of the root iControl.	Yes	ARP-Ping
set ipaddress <dotted decimal=""></dotted>	Set the root iControl's IP Address in dotted decimal.	Yes	192.168.0.254
set subnet <dotted decimal=""></dotted>	Set the root iControl's subnet mask in dotted decimal.	Yes	255.255.255.0
set gateway <dotted decimal=""></dotted>	Set the root iControl's gateway in dotted decimal.	Yes	0.0.0.0

Web Server Commands

Command	Description	Admin	Fact Def
get web	Returns the root iControl's current web server settings.	Yes	
set web enable <yes no=""></yes>	Enable or disable the root iControl's web server.	Yes	Yes
set web port <1-65535>	Set the root iControl's web server's port. Web standard port is 80. If changed, access the iControl using http://xxx.xxx.xxx.eport> SurgeX recommends changing the web port on all iControls that are	Yes	80
	accessible from the internet.		
set web ssl <yes no=""></yes>	Enable or disable the root iControl's web server's SSL capabilities.	Yes	No

Telnet Commands

Command	Description	Admin	Fact Def
get telnet	Returns the current settings of the root iControl's telnet server.	Yes	
set telnet enable <yes no=""></yes>	Enable or disable the root iControl's telnet server.	Yes	Yes
set telnet port <1-65535>	Set the port of the root iControl's telnet server. SurgeX recommends changing the telnet port on all iControls that are accessible from the internet.	Yes	23



Autoping Commands

Command	Description	Admin	Fact Def
get autoping <1-16>	Returns the settings and state of the selected autoping.	Yes	
set autoping <1-16> ipaddress <dotted decimal=""></dotted>	Set the IP address of the selected autoping in dotted decimal.	Yes	0.0.0.0
set autoping <1-16> action <action></action>	Set the action of the selected autoping. On-Follow, On- Latch, Off-Follow, Off-Latch, Cycle, Cycle-Once, or None.	Yes	None
set autoping <1-16> frequency <1-999>	Set the frequency of the selected autoping in seconds.	Yes	10
set autoping <1-16> count <1-99>	Set the number of failures the selected autoping requires before it triggers its action.	Yes	3
set autoping <1-16> device <name #1-16=""> outlet <1-8></name>	Assign an autoping to either a device/outlet or group.	Yes	
set autoping <1-16> group <name></name>	Each autoping can be assigned to one or the other.	Yes	

Event Commands

Command	Description	Admin	Fact Def
get events	Returns a list of all pending events.	Yes	
get event <eventname></eventname>	Returns the details of the selected event.	Yes	
add event <eventname></eventname>	Creates a new event. Up to 16 events can be created. The default time and date will be the time and date that the event is added. The default action is none, and the default repeat is never.	Yes	
del event <eventname></eventname>	Deletes the selected event.	Yes	
ren event <eventname> <new name=""></new></eventname>	Renames the event.	Yes	
set event <eventname> year <2007 - 2050></eventname>	Sets the year of the event.	Yes	



set event < eventname> month <1-12>	Sets the month of the event.	Yes
set event <eventname> day <1-31></eventname>	Sets the day of the event.	Yes
set event <eventname> hour <0-23></eventname>	Sets the hour of the event.	Yes
set event <eventname> minute <0-59></eventname>	Sets the minute of the event.	Yes
set event <enentname> action <on cycle="" off=""></on></enentname>	Sets the event action.	Yes
<pre>set event <eventname> repeat < never / daily / weekly / monthly / annually></eventname></pre>	Sets the event repeat.	Yes
set event <eventname> control outlet <1-8></eventname>	Sets the outlet that will be controlled on the local device.	Yes
set event <eventname> control device <#1-#16/devname> outlet <1-8></eventname>	Assigns the event to either a device/outlet or group. Each event can be assigned to one or the other.	Yes
set event <eventname> control group <groupname></groupname></eventname>		Yes

Email Commands

Command	Description	Admin	Fact Def
set email enable <yes no=""></yes>	Turns on or off the email reporting system.	Yes	No
get email	Returns the current settings of the root iControl's email client.	Yes	
set email server <dotted decimal=""></dotted>	Set the IP address of an SMTP or ESMTP server.	Yes	0.0.0.0
set email address <return address=""></return>	Set the return address of the root iControl's email client.	Yes	0.0.0.0
set email username <username></username>	Set the user name for the mail server.	Yes	0.0.0.0
set email password <password></password>	Set the password for the mail server.	Yes	0.0.0.0
set email retry <1-999>	Set the number of retries for failed email reporting.	Yes	3
send test mail <username></username>	Send a test email to user.	Yes	



Time Commands

Command	Description	Admin	Fact Def
get time	Returns the current time and NTS settings.	Yes	
set time server <ip address=""></ip>	Sets the address of an NTS server for the root iControl to query.	Yes	129.6.15.29
set time usents <yes no=""></yes>	Enables or disables the root iControl's ability to connect to an NTS.	Yes	Yes
set time zone <-12 to 12>	Sets the time zone the root iControl is in.	Yes	-4
set time hour <0-23>	Sets the hour of the root iControl's RTC. Only valid if NTS is disabled.	Yes	
set time minute <0-59>	Sets the minute of the root iControl's RTC. Only valid if NTS is disabled.	Yes	
set time day <1-31>	Sets the day of the root iControl's RTC. Only valid if NTS is disabled.	Yes	
set time month <1-12>	Sets the month of the root iControl's RTC. Only valid if NTS is disabled.	Yes	
set time year <2006-20047>	Sets the year of the root iControl's RTC. Only valid if NTS is disabled.	Yes	

Firmware Upload Commands

Command	Description	Admin	Fact Def
get upload enable	Get or set the ability for the root iControl to accept a firmware upload.	Yes	
set upload enable <yes no=""></yes>		Yes	No



ADVANCED OPERATION

DTMF Control

The iControl can be controlled from dial up connections using handset dialing tones (touch tones). Use of DTMF control requires a unique PIN number set for each user. This PIN is set using the command line interface, and must be 4 to 10 digits long. Program a PIN code of 0 to disable a user's ability to use DTMF control.

DTMF Call Sequence

- 1. Dial the phone number connected to the iControl. Upon connection a prompt tone will be heard.
- 2. Enter the PIN followed by the # key. Upon successful entry, a ready tone will be heard. If no PIN (or incorrect PIN) is received, an error tone and new prompt tone will be issued. After three unsuccessful attempts, the iControl will hang up.
- 3. At the ready tone, enter an outlet number 1-8. The current status of that outlet will be stated in English: i.e. "one on" or "six off".
- 4. The # key is used to change the state of the outlet. The * key is used to reboot (or power cycle) the outlet for the time configured with the CLI command cycle time. The new status of the outlet is stated. If the * key is used, the iControl will also state 'begin' to indicate the reboot or cycle has begun.
- 5. A new prompt tone will indicate that new commands can be entered. While a reboot is in progress, additional outlets can be addressed and commanded.
- 6. The caller can hang up at any time to disconnect the call. Any reboots in progress will finish their cycle time as programmed.

NOTE: Not issuing a command for 5 seconds will cause the iControl to hang up.

Notes

- 1. The only outlets that a caller has access to are determined by the CLI command set user outlet.
- 2. While prompts and voice responses are being played, the iControl will not process DTMF tones. Wait for the status and prompts to complete before issuing new commands.
- 3. Address an outlet with a number command before entering a control command (# or *). If unsure which outlet is being addressed, send the outlet number again.
- 4. Factory Default user admin has default PIN 23646. Change to desired PIN if maintaining this account. Resetting to factory defaults will restore this user and PIN.



Timed Events

The iControl provides the ability to turn On, Off, or Cycle outlets based on time and date. Each individual outlet or group can be set to operate a selected command at a specific time and date. The Timed Events are programmed through the Setup & Control Utility or the CLI interface. Up to 16 events can be created.

Each event can be assigned to one outlet or group and repeated on a regular basis.

Administrative rights are required to set up and manage any event. To add an event, create the event, assign the event to a specific outlet or group, and then configure the initial occurrence of the event, the action to be performed, and the repeat frequency, if desired.

To configure the timed events, use the following commands:

get events

get event <eventname>

add event <eventname>

dev event <eventname>

ren event <eventname> <new name>

set event <eventname> year <2007 - 2050>

set event < eventname> month <1-12>

set event <eventname> day <1-31>

set event <eventname> hour <0-23>

set event <eventname> minute <0-59>

set event <enentname> action <on/off/cycle>

set event <eventname > repeat < never / daily / weekly / monthly / annually>

set event <eventname> control outlet <1-8>

set event <eventname> control device <#1-#16/devname> outlet <1-8>

set event <eventname> control group <groupname>



AutoPing

The AutoPing feature allows the iControl to automatically detect failed equipment and perform a timed reboot or other power control function (like turning on an indicator or siren). Set any IP address to be periodically pinged. When the iControl no longer detects a response from the address, the programmed power control function is actuated.

Up to 16 AutoPing channels are available, and each AutoPing can be assigned to an outlet or group. In cluster configurations, any of the 16 AutoPing channels can be assigned to any outlet on any device in the cluster.

Ping Address: Enter the IP address of the device to be pinged.

Ping Frequency: Enter 1 to 999 seconds. The ping will go out to the selected device this often. **Fail Counter:** Enter 1-99 times the ping needs to fail consecutively before the selected action is taken. When the fail count has been reached, the AutoPing action will be triggered.

None	AutoPing not used			
On – Latch	Upon triggering, the iControl will power on the assigned outlet and remain so			
	until changed via the web or telnet/serial interface.			
On – Follow	Upon triggering, the iControl will power on the assigned outlet. When the			
	ping response returns, the iControl will power off the outlet.			
Off – Latch	Upon triggering, the iControl will power off the assigned outlet and remain so			
	until changed via the web or telnet/serial interface.			
Off – Follow	Upon triggering, the iControl will power off the assigned outlet. When the			
	ping response returns, the iControl will power the outlet on.			
Cycle	Upon triggering, the iControl will cycle the power to the assigned outlet. The			
	iControl will wait an amount of time equal to the (Ping Frequency x Fail			
	Count); if the response does not return, the power will be recycled again. This			
	will continue until the ping response returns, or AutoPing is turned off. Make			
	sure your (Ping Frequency x Fail Count) is longer than the time required to			
	reboot your device.			
Cycle Once	Upon triggering, the iControl will cycle power one time. It will not cycle			
	again automatically until the ping response returns and is lost again.			

Action: Select From

Web Operation:

With AutoPing operational, the AutoPing Status page will display the current status of this feature. The status will be OK to indicate that the iControl is receiving responses to the ping, or that the fail counter has not yet been exceeded.

If the fail count has been exceeded, the status will change to Triggered. The counter will indicate the number of times the AutoPing has been triggered since the last reset. Click on the Reset button to reset the counter.



CLI Operation and Setup

To view the status of any of the AutoPing channels, issue the **get autoping <1-16>** command.

iControl > get autoping 1 IP Address: 192.168.1.7 Action: Cycle Frequency: 30 Count: 3 Outlet: Cabinet_1 - Firewall Status: OK OK iControl >

To configure the AutoPing, use the following commands:

set autoping <1-16> ipaddress <dotted decimal>

set autoping <1-16> action <action>

set autoping <1-16> frequency <1-999>

set autoping <1-16> count <1-99>

set autoping <1-16> device <name/#1-16> outlet <1-8>

set autoping <1-16> group <name>

SSL Security

The iControl can provide Secure Socket Layer (SSL) encryption on the web interface. Enable this feature using the **set web ssl yes** command from the Telnet / Serial interface.



CERTIFICATE UPLOAD UTILITY

The Certificate Utility (CUU.exe) is designed to create and distribute Secure Socket Layer (SSL) certificates to iControls and the PCs that communicate with them. Although the iControl comes from the factory with a certificate installed, this certificate will generate a warning message when connecting to the iControl when using SSL. For most customers, this error message can be easily ignored and secure connection to the iControl continues. For customers with special circumstances, the CU was designed to facilitate creation and distribution of SSL Certificates tailored to a specific iControl, eliminating the error message entirely. There are two methods that can be used to create and distribute the certificates:

<u>1. Self Signed Certificates.</u> A Self-signed certificate is the most common approach. In this approach, the CU generates multiple certificates, each unique and based on the IP address, or DNS name of each iControl. The CU also provides the means to install the certificate on the iControl, making it easy to generate and distribute. Upon initial connection to the iControl, the user will be offered an opportunity to install the certificate from the iControl. This is done once for each browser on the PC and each iControl.



Self Sign Method

Step 1: Using the CU, create one unique Certificate based on the IP Address of each iControl.

Step 2: Use the CU to upload the Certificates to each iControl.

Step 3: Upon connecting to the iControl, each PC accepts the certificate installed in the iControl.

<u>2. Root Certificate Authority.</u> The Root Certificate Authority method pre-installs the certificates required in both the PC and the iControl. This eliminates the need for accepting the certificate from each iControl on each PC. The Root Certificate is generated and installed in each PC prior to communication with the iControl. The Root Certificate also is used, along with the IP address or domain of the iControl, to generate the certificates that are installed in the iControl.



Root Certificate Authority Method

Step 1: Create A Root Certificate Authority (CA) using the Certificate Upload Utility (CU).

Step 2: Install the CA into any PCs that need to communicate with the iControls.

Step 3: Create certificates for each iControl using the CU. Each certificate is unique and based on the C/A and the iControl's IP Address or domain name.

Step 4: Install the certificate into the iControl(s) using the CU.



EMAIL NOTIFICATION

Email can be automatically sent for outlet changes, AutoPing triggers, voltage alarms, and current alarms. The necessary parameters for email are set using the Telnet / Serial Interface:

set email server <dotted decimal> set email address <return address 64 char max> set email username <user name 128 char max> set email password <password 128 char max>

Each user is assigned an email address, and email can be turned on or off for that user:

set user <name> email <email address 64 char max> set user <name> sendmail <yes/no>

Emails generated by the iControl will display the device, outlet(s) command, and the user and method of control.

Examples:

Subject : Power Switch: Cabinet_1Date: Mon, 7 Jul 2008 09:41:00 - 0500From: <iControl@surgex.com>To: networkadmin@yourco.com

Location: Cabinet_1 Outlets: 5 Server_B Command: Cycle User: admin Source: Telnet

Subject : Power Switch: Cabinet_3

- **Date** : Mon, 7 Jul 2008 09:46:00 0500
- From :<iControl@surgex.com>
- To :<networkadmin@yourco.com> Location: Cabinet_1 Outlets: 3 Router_A 6 Router_B Command: Off User: admin Source: Web



SNMP

Up to four SNMP managers can be set. Each manager will receive Trap notifications for outlet changes, autoping, voltage alarms, and current alarms. Set the SNMP manager IP addresses using the **set snmp <n> ipaddress <dotted decimal>** command. Enable or Disable SNMP for any manager with the **set snmp <n> enable <yes/no>** command. Also see "iControl q110630.285.mib" for more information.

The iControl also supports the following elements of MIB-II:

mgmt [1	.3.6.1.2]				
->	[1]-BR-m	ib-2			
	-> [1]-BR	- system			
	 -> [1] -> [2] -> [3] -> [4] -> [5] -> [6] -> [7]	*RO* *RO* *RW* *RW* *RW* *RW*	DisplayString OBJECT IDENTIFIER TimeTicks DisplayString DisplayString DisplayString INTEGER	sysDescr sysObjectID sysUpTime sysContact sysName sysLocation sysServices	Truncated to 128 Char Truncated to 128 Char Truncated to 128 Char

FIRMWARE UPGRADES

The iControl can be upgraded via the network if the upload feature has been enabled using the **set upload enable yes** command on the console interface. To upgrade the iControl, download the latest version of the firmware and upgrade utility from the SurgeX website. http://www.surgex.com

FRONT PANEL RESET BUTTON

The recessed reset pushbutton located on the front panel below the Self Test LED performs two functions: CPU Reboot and Password Reset.

Pressing the reset button once quickly will reboot the iControl's CPU. Outlet states are not affected.

Holding the reset button on the front panel of the iControl for 5 seconds or longer will initiate a password recovery mode. Once the reset button is released, the user has 30 seconds to log in to the CLI using the username **admin** and password **admin**. Upon accessing the CLI, change the username and password for User 1 as desired.



SETUP AND CONTROL UTILITY (SCU)

The iControl Setup and Control Utility (SCU) is designed to facilitate installation, configuration, and management of one or more iControls. With the Setup Utility, users can:

- 1. Automatically discover multiple iControls on a local network.
- 2. Add additional iControls not on the local network.
- 3. Download existing configurations from installed iControls.
- 4. Save existing configurations for later use or as backup.
- 5. Open saved configurations for change management.
- 6. Clone saved configurations for replication of similar configurations in multiple iControls.
- 7. Upload modified configurations to iControls.
- 8. Control outlets on one or more iControls throughout the network.

The iControl Setup and Control Utility works securely through the network connection between a PC running Windows 98 or higher and the iControl. Administrator rights are required on the iControl to properly use the Utility. All communication between the program and the iControl is encrypted using AES.

The iControl Setup and Control Utility is available on the iControl CD or on the SurgeX website at <u>http://www.surgex.com</u>.

😲 iControl Setup	
<u>File</u> <u>H</u> elp	
iControl Select:	Connect Control Setup
iControl	SNMP Agent Email Time Syslog Timed Events AutoPing
	Device Outlets Users Groups IP Address Web Server Teinet Server
	File: iControl-10.1.2.61.ibbcfg
	Name: Control
	Cycle Time: 10 Seconds
	Delay Time: 1 Seconds
	Main A
	Current Alarm: High 15.0 Low 0.0
	Main A
	Voltage Alarm: High 150 Low 90
	Console Timeout: 120 Seconds
	Baud Rate: 115200 💌
<u>A</u> dd iControl	Upload Enable: 🗖
Delete iControl	
<u>C</u> lear List	

SNMP MIB



```
enterprises [1.3.6.1.4.1]
                                                                        Legend :
  -> [1418] -MI- surgex
                                                                        BR - Branch
    -> [4] -BR- iControlAgent
       -> [1] -BR- systemSettings
         -> [1] *RW* DisplayString
                                                deviceName
         -> [ 2] *RW* INTEGER(Enum)
                                                ipMode
         -> [3] *RW* DisplayString
                                                ipAddress
         -> [4] *RW* DisplayString
                                                subnetMask
                                                                        TB - Table
         -> [ 5] *RW* DisplayString
                                                gateway
         -> [ 6] *RW* INTEGER(Enum)
                                                webEnable
         -> [ 7] *RW* Integer32
                                                webPort
         -> [ 8] *RW* INTEGER(Enum)
                                                sslEnable
         -> [ 9] *RW* INTEGER(Enum)
                                                telnetEnable
         -> [10] *RW* Integer32
                                                telnetPort
         -> [11] *RW* INTEGER(Enum)
                                                updateEnable
         -> [12] *RW* Integer32
                                                cycleTime
         -> [13] *RW* Integer32
                                                delayTime
       -> [2] -TB- snmpManagerTable
         -> [1] -TE- snmpManagerEntry
           -> [ 1] *RO* Integer32
                                                snmpManagerIndex
           -> [2] *RW* DisplayString
                                                snmpManagerIPAddress
           -> [ 3] *RW* INTEGER(Enum)
                                                snmpManagerEnable
       -> [3] -TB- outletTable
         -> [1] -TE- outletEntry
           -> [ 1] *RO* Integer32
                                                outletIndex
           -> [2] *RW* OCTET STRING
                                                outletName
           -> [ 3] *RO* INTEGER(Enum)
                                                outletStatus
           -> [ 4] *RW* INTEGER(Enum)
                                                outletCommand
           -> [ 5] *RO* INTEGER(Enum)
                                                outletAPStatus
      -> [4] -BR- info
        -> [ 1] *RO* Integer32
                                                currentLC1
        -> [ 2] *RO* Integer32
                                                currentLC2
        -> [3] *RO* INTEGER(Enum)
                                                numberOfLineCords
       -> [5] -NT- outletChange
      -> [6] -NT- autoPingFailed
      -> [7] -NT- currentAlarm
      -> [8] -NT- emailError
      -> [9] -NT- autopingTrigger
     -> [10] -NT- autopiResponding
```

Legend : AC - Agent Capabilities AN - Accessible for Notify BR - Branch MC - Module Compliance MI - Module Identity NA - Not Accessible NG - Notification Group NT - Notification Type OG - Object Group OI - Object Identity RO - Read Only RC - Read Only RC - Read Write TB - Table TE - Table



COMPLIANCE STATEMENTS FCC Part 15 Regulation

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the equipment into an outlet on a circuit that is different from the one used by the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC rules. Operation of this device is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Modem Certifications

The following countries have certified the internal modem (for models with internal modem option). In order to comply with local regulations, the countrycode must be set to the country of installation. To set the modem for the desired country, use the CLI command set modem countrycode <countrycode>. Use the get modem command to display the current country setting.

Country	countrycode	Country	countrycode	Country	countrycode	Country	countrycode
Argentina	07	France	253	Liechtenstein	253	Slovak	253
						Republic	
Australia	09	Germany	253	Lithuania	253	Slovenia	253
Austria	253	Greece	253	Luxembourg	253	South Africa	159
Belgium	253	Hong Kong	153	Malaysia	108	Spain	253
Brazil	22	Hungary	253	Malta	253	Sweden	253
Bulgaria	253	Iceland	253	Mexico	181	Switzerland	253
Canada	181	India	153	Netherlands	253	Taiwan	254
Chile	153	Indonesia	153	New Zealand	126	Thailand	181
China	181	Ireland	253	Norway	253	Turkey	253
Cyprus	253	Israel	181	Philippines	181	United	253
						Kingdom	
Czech	253	Italy	253	Poland	253	United States	181
Republic							
Denmark	253	Japan	00	Portugal	253		
Estonia	253	Korea	181	Russia	253		
Finland	253	Latvia	253	Singapore	156		

Note: Use of the wrong countrycode violates local laws and the warranty of this product.



SPECIFICATIONS

Load Rating: 15/20 Amps at 120 Volts (SX-1115ip-X/SX-1120ip-X)

Power Requirement (no load): 4 Watts

Surge Let-through Voltage (6000 Volt surge): 0 Volts

UL 1449 Adjunct Classification Test Results: 1000 surges, 6000 Volts, 3000 Amps, B3 pulse; measured suppressed voltage, 170 Volts; no failures

Federal Guidelines: Grade A, Class 1, Mode 1 (CID A-A-55818)

EMI/RFI Filter, Normal Mode (50 Ohm load): 40 dB @ 100 KHz, 50dB @ 300 KHz, 50 dB @ 3 MHz, 50 dB @ 30 MHz

EMI/RFI Filter, Common Mode (50 Ohm load): 18dB @ 300 KHz, 30 dB @ 1 MHz, 50 dB @ 5 MHz, 50 dB @ 20 MHz

Maximum Applied Surge Voltage: 6000 Volts *

Maximum Applied Surge Current: Unlimited (due to current limiting) *

Maximum Applied Surge Energy: Unlimited (due to current limiting) *

Endurance (C62.41-1991 category B3 pulses): 1 KV > 500,000; 3 KV > 10,000; 6 KV > 1000

Undervoltage Shutdown: Adjustable from 90 Volts to 105 Volts

Overvoltage Shutdown: Adjustable from 135 Volts to 150 Volts

Network Port: 10/100 Base T Ethernet connection on Female RJ-45

Modem Port: V.92 and below on Female RJ-11 (for models with internal modem option)

Serial Port: 115,200 bps on Female 9-pin D-subminiature

Dimensions: 19" W x 12.25" D x 1.75" H (Single Rack Space)

Weight: 13.0 lb.

Temperature Range: 5C to 35C

Humidity Range: 0% to 95% R.H. Non-condensing

Agency Listings: ETL and cETL (UL 1449, 3rd Edition; CSA C22.2 No.8-M1986, R2000)

* 1.2 x 50 microsecond industry standard combination wave surge as per IEEE C62.41

*****CAUTION: Do not install this device if there is not at least 10 meters (30 feet) or more between the electrical outlet and the electrical service panel.