



Polytronics Engineering Ltd.

***BtmGlobal* SYSTEM**

CONTROLLER

User Manual

Version 3.1.6

POLYTRONICS ENGINEERING
Referred to as PENG
Copyright PENG
©2006 All Rights Reserved

Table Of Contents

INTRODUCTION.....	4
REQUIREMENTS.....	5
HARDWARE OVERVIEW.....	5
HARDWARE INSTALLATION.....	6
INSTALLATION.....	7
1. CURRENT TRANSDUCER INSTALLATION.....	7
2. CONCENTRATOR INSTALLATION	8
3. SENSING AND POWER HARNESS INSTALLATION.....	8
4. CONDUIT.....	10
5. COMMUNICATION PATH INSTALLATION.....	10
HARDWARE VERIFICATION AND CONFIGURATION.....	11
6. VERIFICATION.....	12
SYSTEM SETUP AND OPERATION.....	13
SYSTEM OPERATION.....	13
ACCESSING BATTERY DATA.....	13
DATA ACCESS	14
SUMMARY PAGE	14
STATUS PAGE.....	15
PRESENT DATA PAGE (BAR GRAPH).....	17
SINGLE JAR VOLTAGE PROFILE	18
DETAIL DATA PAGE (NUMERIC TABLE).....	19
PRESENT DATA PAGE (NUMERIC TABLE)	20
HISTROY LOG PAGE.....	21
REQUEST DATA FORM	22
STRING PERFORMANCE (PROFILE) GRAPH	27
SYSTEM ALARM LOG PAGE.....	28
MONITOR STATUS PAGE	29
MAINTENANCE PAGE.....	30
VOLTAGE ADJUSTMENT	31
MAINTENANCE SYSTEM PAGE.....	32
NETWORK PAGE.....	33
STRING CFG	34
BATTERY SERVICE	37
ADVANCED PAGE.....	38
TIME AND DATE PAGE.....	39
MAINTENANCE ACTIVATION PAGE	40

APPENDIX A	42
HARDWARE INSTALLATION SITE NOTES	42
APPENDIX B	43
CONNECTING YOUR PC TO THE CONTROLLER USING A CROSS-OVER NETWORK CABLE	43
APPENDIX C	46
CONTROLLER ALARMS AND STRING STATUSES	46
APPENDIX D	477
SAMPLE CONTROLLER SYSTEM.....	477

Introduction

The controller is a real-time, stand-alone battery monitor with full networking support. It is used for storing individual cells/jars and full string data, detecting abnormalities coming from the battery measurements, warning about the changes in the battery condition and alarming when critical conditions occur on an individual Jar(s) or the entire string. Based on the collected data, the controller generates various comprehensive reports for assessing the operational conditions and the health of the battery. The generated reports are presented in Hyper Text Markup Language (HTML) and in Portable Network Graphics formats (various graphs and plots) to utilize the Internet based World Wide Web browsers.

The controller's network support facilitates TCP/IP protocol over Ethernet and the PSTN (built-in modem). The system is easily accessible (locally or remotely) over PSTN for report viewing, data downloading, configuration and system upgrading. The system can also be configured to automatically upload the report-pages to a predefined Web Site and use Email for the remote enunciation of alarms (local ISP access point or local network Gateway access is required).

Note: When required, the controller system can be augmented with a local monitor, keyboard and mouse for on-site data viewing. As a standard, the controller system installs without a monitor. Also, Modbus and Open Modbus can be used as optional Interface protocols.

The controller system is composed of one or many measuring device(s) such as: concentrators, RS232/485 to Optical converter, optical link or combined optical and twisted pair link (Fiber-Optical Network) and data analyzing and storage device (Controller/Modbus Console). The controller console controls the system and interfaces it to the upper network layer.

The Modbus console controls the system and interfaces with the Modbus based higher level monitoring system

The Controller console supports the following services over TCP/IP network:

- Http: serves battery report pages for WEB-browser
- Ftp: file transfer service (for remote configuration, or other file exchanges)
- Ssh: secure shell for remote system configuration/upgrade (replaces telnet)
- SNMP: higher level network management protocol (eg. interface to Openview)
- Mail: electronic mail agent (configured to send alarm messages)

Requirements

On site, you need at least one RS232/485 optical converter, fiber optical cable, and a portable computer (running Dos 6.2 or Windows XX) to check individual parts of the system and verify the system is up and running correctly.

The Ethernet interface to the controller console is an asset, which will provide additional interfacing capabilities.

A direct telephone line is required for remote access capability, data upload for global access and support by PENG.

REQUIREMENTS FOR SITE

- Ethernet access (optional)
- Direct telephone line (optional if remote access/support is required)
- Uninterruptible power supply 500VA or UPS protected AC outlet
- RS232/RS485 optical service converter (for setup and troubleshooting)

Hardware Overview

The concentrators are configured either as low voltage or high voltage devices. The high voltage concentrators can serve up to 15 Jars if the intercell resistance and internal impedance of the Jar are measured together, and the low voltage concentrator can serve up to 30 Jars if the intercell resistance and internal impedance of the Jar are measured together. See Figure 1.

Warning: The total input voltage cannot exceed 280Vdc or fall below 18Vdc.

There are a few small differences in the equipment depending on whether the system is monitoring 2V or 12V Jars. Although concentrators may look the same, it is important to check the nameplate to tell whether the concentrator has the proper voltage for your application.

All concentrators are powered from the battery monitored. However, the data acquisition module (Controller) uses a 120/220 Vac outlet for power.

Note: In order to maintain data acquisition during a power failure, the AC outlet must be UPS protected or have an emergency generator as a backup. The Fiber Optical Converter(s) and line driver is powered from the Controller Console.

Hardware Installation




Diagram of Controller Back End Connections

Figure 1: System Connectivity

Installation

1. Current Transducer Installation

If a current transducer is used, install the transducer coil around a battery lead. It can be placed anywhere in the battery string. Make sure the arrow is facing the positive post of the battery as shown in the diagram below in Figure 2. Make certain to re-torque all the bolts loosened after connecting the transducer.

Warning: Before installing the transducer, make sure that proper steps have been taken with the critical load so that when the string is open, the system will not be affected.

You must also connect the current transducer into the optical loop as shown in Figure 1.




Fig 2: Current transducer core installation

2. Concentrator Installation

Typically, the concentrators are installed as a wall mount or under the upper battery rack at 30 Jar intervals as shown in Fig. 3. It is recommended that the concentrator be placed in the middle of the battery segment it is monitoring in order to reduce the amount of wire needed. If there were a more suitable location for the concentrators other than the wall inside the battery room or the battery racks, this would also be acceptable. Make sure that wherever the concentrator is installed, it is held in place firmly.

Each concentrator is uniquely identified by the concentrator number, which is displayed on the nameplate. Concentrators must be installed sequentially and in accordance with the wiring chart.

All the jar numbers noted here (and on the wiring chart) are in reference to the most positive end of the string. The jar at the most positive end of the string will be called Jar #1 and counted sequentially.

Check the wiring diagram for the concentrator ID number that is designated to be connected to the transducer. Install this concentrator first.




Fig. 3: Concentrator installation under battery rack (side view)

3. Sensing and Power Harness Installation.

Starting from the concentrator, run sensing wires in accordance with the concentrator wiring diagram Fig 4. It is recommended to use AWG 18 wire for the hookup. When the concentrator wiring diagram specifies separate wire, you must install it even if there is more than 1 wire going to the same point. For a connection to the battery, the wire should be stripped and crimped to the appropriate battery clip (black or red as specified). Next, connect the battery clip to the post as shown in Figure 5.

Note: Make sure the wire is terminated at the battery post with the appropriate clip as specified in the concentrator wiring diagram (black clip is fused, red clip is resistive current limiter).

Connect the other end of the sensing wire to the specified terminal connector using the labels on the faceplate as shown in Figure 4 as your reference. Typically, the first block of 4 is not connected unless the pilot jar temperature monitoring option is requested.




Figure 4: Concentrator Wiring Diagram

Note: Before you connect the sensing wires to the terminal block, make sure to remove the terminal blocks from the concentrator.

It is highly advisable that all wires should be labeled at each end of the cable. These labels are provided with each system.




Figure 5: Typical battery sensing clip connection to a battery post

4. Conduit

Run the plastic wiring duct along the battery rack rail with the outlets positioned at each battery cell or use other means (cable ties) to bundle and hide the sensing harness (wires).

5. Communication Path Installation

Layout the communication loop, and measure the distances between the connection points. Run the twisted pair cable, if necessary, and the fiber optical cable next. The devices are connected in a daisy chain format - from the Fiber Optics Output (White) of one device and then connected to the Fiber Optics Input (black) of the next.

Warning: The fiber optical loop must be planned very carefully before cutting the fiber optic cable because there are no way to join cut pieces of fiber optic cable together without any extra equipment. Also, neither the sequence nor the total length of the cable is important. The only important aspect is the length of the longest piece of the cable is. The longest fiber optic cable must not exceed 60 meters.

The Fiber Optics Output of the last Concentrator of the fiber optical link is connected to the RS232/485 to Optical converter input (black). The Fiber Optics Output (white) of the Optical Converter is connected to the closest device Fiber Optical Input. Plan your connections of fiber optical cable to minimize the length of the longest fiber optical cable run. If multiple strings are connected to the single optical loop, then fiber-optical cable must connect across strings (sometimes in an other battery room). Take care to keep the radius on all bends at least 2 inches or 40 mm. Fiber optic cables cannot be joined. Care should be taken to run all lengths prior to cutting.

Terminating Fiber Optic Cables

The fiber optic cable from the concentrators should be terminated in the appropriate socket in the RS-232 converter unit. The converter should be located close to the computer and modem. Prepare the end of the fiber optic cable by cutting it at a right angle with a sharp utility knife. The outer covering should then be stripped back for a length of 0.15 inches or 3 mm. To smooth off the fiber optic for better light transfer, heat the blade of the utility knife for a few seconds and then place it on the end of the fiber cable for about 1 second. This will leave a shiny flat end on the cable. Position the prepared end of the fiber optic cable in the input (or output) of the special fiber optic's connector, be sure the connector is loosened. Push the end of fiber optics cable into the housing, tighten the connector with finger force as would be used to close a toothpaste container.

Hardware Verification and Configuration




Diagram of Controller Front end connectivity.

Figure 6: Connecting Portable PC to the Fiber Optical Network.

6. Verification

Verify the installation by testing the connections to the terminal blocks before actually connecting the terminal blocks to the concentrators.

With the help of a voltmeter (range 0 – 300V), measure the potential between terminals B+ and B-. The value should be equal to:

$$V = \text{Number Of Jars Monitored By Concentrator} * \text{Average Jar Voltage}$$

(E.g. 2.2V average jar * 24 = 52.8V)

Warning: Under no circumstances should the total voltage be:

Below 18V or above 200V (low voltage range device);

Below 60V or above 280V (high voltage range device);

Measure the potential between the connector labeled at BC and B1+. This value should be the average Jar voltage. Next, move the voltmeter lead to the next connector (1). The voltage reading should be two times the average Jar voltage. Continue this method until reaching connector 29. Each new connector should have an increase in potential, over the previous Jar, of the average Jar voltage.

If the voltage verification checks out, connect the terminal blocks of every Concentrator.

The red LED on the left side of the faceplate should start to blink approximately once every second to verify everything was done correctly.

System Setup and Operation

The controller you have received has been pre-configured for your installation. Reconfiguration of the controller box can be performed remotely over the telephone-line (dial in), Ethernet or locally.

SYSTEM OPERATION

The standard controller console operates without a local interface. The basic system information is displayed on the numeric LED-display. The local display (monitor) can be easily connected at any time.

To activate the battery monitor, make sure that the hardware is installed and functional, the fiber optical loop is connected to the optical converter and the optical converter is connected to the COM 1 (9-pin male connector on the controller console).

Verify that the network is connected to the Console and the line is active. Turn the controller console power switch on, and within approximately 30 – 60 seconds, the console should boot up and start functioning.

ACCESSING BATTERY DATA

The controller system facilitates several means to access data. All necessary battery data is stored in the controller and is also presented in an HTML formatted report file. Any graphics are produced in the PNG (Portable Network graphics) format. All report files will be periodically uploaded by the System to a pre-configured website from where the data can be viewed using any internet-browser.


The global data access is restricted and protected with password. Contact PENG for account and password information for accessing data on the Internet. Complete access to all data (including raw data) can be achieved by establishing a dial-in network connection, or by connecting the Controller Console to a local Ethernet network. The Console has a built-in web-server capability and, all HTML report pages can be browsed using a local network connection or over a dial-in network. Raw data, ASCII text tables and other relevant files, can be retrieved using an FTP site.

NOTE. The Controller Console is configured for dynamic IP address and should work with any existing network. The Ethernet interface is configured to be active.

Data Access

This section describes all of the html pages, which are used to access data from the controller. From these pages, you can see the battery conditions and alarms, make changes to your system setup and configuration and calibrate your system.

SUMMARY PAGE




The screenshot shows a Netscape browser window displaying the BtmGlobal Summary page. The browser address bar shows `http://btmgloba00/cgi-bin/index.pl`. The page header includes the Polytronics Engineering Ltd. logo and the text "BtmGlobal". Below the header is a navigation menu with "SUMMARY", "DETAILS", and "MAINTAINANCE" tabs. The main content area is divided into several sections:

- INFORMATION:** Summarizes monitoring HW, SW and all string statuses. It lists various error types: DSP - data storage space, CRC & Lost packets, communication errors, unreliable internal com-link, and CHGLEV - battery charge level. A legend indicates: RED : critical, YELLOW : warning, and GREEN : normal.
- System Status:** Displays "BtmGlobal: DEMO @ 15:34:33 on 03/09/07" and "System Serial Number: DEMO_01".
- Software:** RUNNING-DSP OK (Green)
- Optical link:** NORMAL (Green)
- DEVICES (2):** NORMAL (Green)
- Device Details:** Two devices are listed: ID#1 (CC) and ID#31 (FC), both in green boxes.
- BATTERY:** A table showing battery parameters for String #1.

Str Name	Status	Alarm	TV	I	Ripple I	Ambient T	Pilot T	Other
String #1	FLT (1,21,07)	WARN (128)	23 V	0.00 A	NA	23 °C	24 °C	CHGLEV: 100.0%

The Summary page summarizes data and provides links to all the other areas of the system. The first (or upper) section of the page displays the status of the Software, Disk Space (DSP), and optical link. These areas are displayed in green when operating normally and red when they are not operating properly. The middle section displays all the devices in the system, their ID number, and their status. The lower section displays information about the batteries themselves: the status, alarms, and charge level (CHGLEV) out of 100%. Also, the voltages, current, ripple current, and room ambient temperature of the batteries are displayed.

STATUS PAGE



Polytronics Engineering Ltd.

COMPANY
Polytronics Engineering
431 Alden Road
Markham
Ontario

Service Contractor
Telephone
Fax
Contract Termination

Custom Service
(905) 305 8204
905 305 8216
NA


DEMO: PRESENT STATUS REPORT
13:51:09 03/09/2007
System Serial Number: DEMO_01
TOTAL of 1 STRING MONITORED
MONITOR STATUS: NORMAL

[Devices](#) [System](#) [Summary Page](#) [Maintenance](#)

[Present Data](#) [Data Profile](#) [Hi/Lo Data](#) [Alarms](#) [History](#)

(Str#1) String #1 : Lead-Acid (VLR)		Installed:	08/2005
Reference:	Battery Bank #1	Total Jars:	9
Nominal Rating:	120 Ahrs at 10.0A to 1.67 V/cell	Model:	CB56
Rated Capacity:	N/A	Physical:	x12.25
		Load:	Load bank
STATUS (DURATION) :			FLOATING (01:34)
ALARM :			NONE
CHARGE LEVEL :			100.0 %
BATTERY FACTORY RATED / EFFECTIVE CAPACITY :			120.0 / 120 AHrs
ESTIMATED TIME REMAINING :			NA
TOTAL VOLTAGE (RIPPLE)			23.4 (0.01) V
DC (RIPPLE) CURRENT			0.000 (0.0) A
AMBIENT (PILOT) T:			23.1 (23.2) °C
String Maintained by: None Next service visit: April 2007			
String Condition: GREEN. String OK.			

The status page summarizes all the strings configured for the site. This page displays string descriptions and current status. It also displays the active alarm(s), charge level (% of rated capacity), currently restored Ahs, rated Ahs, time left when string is discharging, total string voltage, string current (and its fluctuation) and ambient temperature.

HI/LO DATA PAGE.


COMPANY
Polytronics Engineering
431 Alden Road
Markham
Ontario

Service Contractor
Telephone
Fax
Contract Termination

[Custom Service](#)
(905) 305 8204
905 305 8216
NA


DEMO : Str #1
ORDERED OVERALL BATTERY DATA REPORT
(Highest to lowest)
13:52:31 03/09/07
(Higher number indicates weaker battery)
[Back to Status Table](#)

Jar #	Overall Idx 03/09/2007 13:52:32
1 <input type="checkbox"/>	111
2 <input type="checkbox"/>	107
3 <input type="checkbox"/>	103
9 <input type="checkbox"/>	101
8 <input type="checkbox"/>	101
7 <input type="checkbox"/>	101
6 <input type="checkbox"/>	100
4 <input type="checkbox"/>	100
5 <input type="checkbox"/>	100

The Hi/Lo report page gives you overall battery health summary. The individual calculated parameters used to calculate the Overall Index are available in the Detail data table. The Jars will be ordered from weakest to strongest. If a Jar overall index value is close to the pre-configured limit value, the jar will be displayed in yellow. If the jar exceeds the pre-configured limit, it will be displayed in red.

Note: For a more accurate battery analysis, detailed battery data studies may be required.

PRESENT DATA PAGE (bar graph)




The present data page shows all Jar readings in graph form. This page can be accessed from the status page.

If values are close to the pre-configured limit, they will be displayed in yellow. Any values that are outside the pre-configured limits will appear in red. The total string voltage, average Jar and voltage standard deviation are displayed on the left side of the header of the page. The voltage ripple and slow changes are displayed on the right.

Selecting a single bar and clicking on it will produce a single Jar voltage profile for last six months (see below).

SINGLE JAR VOLTAGE PROFILE



DETAIL DATA PAGE (numeric table)


COMPANY
Polytronics Engineering
431 Alden Road
Markham
Ontario

Service Contractor
Telephone
Fax
Contract Termination

[Custom Service](#)
(905) 305 8204
905 305 8216
NA

DEMO : Str #1
BATTERY DETAILED DATA REPORT
13:55:00 03/09/07
[Back to Status Table](#)

Jar #	Delta Flt V 03/09/2007 13:45:46	Normal Int R 03/05/2007 13:09:40	Normal End V 03/05/2007 13:09:49	Ripple V 03/09/2007 13:45:46	Disch Idx NA	Disch Slope NA	Chrg Idx NA	Open Volt NA	Overall Idx 03/09/2007 13:55:00
1 <input type="checkbox"/>	100	106	111	108	NA	NA	NA	NA	111
2 <input type="checkbox"/>	100	103	106	108	NA	NA	NA	NA	107
3 <input type="checkbox"/>	100	100	102	105	NA	NA	NA	NA	103
4 <input type="checkbox"/>	100	100	100	100	NA	NA	NA	NA	100
5 <input type="checkbox"/>	100	100	100	100	NA	NA	NA	NA	100
6 <input type="checkbox"/>	100	100	100	100	NA	NA	NA	NA	100
7 <input type="checkbox"/>	101	100	100	100	NA	NA	NA	NA	101
8 <input type="checkbox"/>	101	100	100	100	NA	NA	NA	NA	101
9 <input type="checkbox"/>	102	100	100	100	NA	NA	NA	NA	101

The Detail report page gives an overview of all the individual parameters used in the overall battery index calculation.

If the parameters are available, the column header will have the date and time the string's parameter was last calculated. If the parameter is not available or a calculation is not possible, NA will be displayed.

Note: All parameters are normalized and expressed in percentage of normalizing value (100%). Calculation algorithms are constructed such that an increase in the value correlates to the degradation of the battery.

Only the latest calculated parameter set is available in this table.

PRESENT DATA PAGE (numeric table)

		COMPANY Polytronics Engineering 431 Alden Road Markham Ontario		Service Contractor Telephone Fax Contract Termination		Custom Service (905) 305 8204 905 305 8216 NA			
DEMO: String #1 READINGS 13:55:49 03/09/2007									
Status Details Bar Graph									
JAR#	Reading (Ripple) V	JAR#	Reading (Ripple) V	JAR#	Reading (Ripple) V	JAR#	Reading (Ripple) V	JAR#	Reading (Ripple) V
1	2.36 (0.01NA)	3	2.55 (0.02NA)	5	2.66 (0.01NA)	7	2.68 (0.01NA)	9	2.67 (0.01NA)
2	2.42 (0.02NA)	4	2.62 (0.01NA)	6	2.66 (0.01NA)	8	2.67 (0.01NA)		
Status: FLOATING		Total String: 23.3 V		Averag Jar: 2.587 V		Current 0.0 A		Temperature: 23.3° C	

The present data numeric table gives an overview of the current battery voltages, terminal ripple and slow voltage changes during float operation.

HISTROY LOG PAGE



COMPANY
Polytronics Engineering
431 Aiden Road
Markham
Ontario

Service Contractor
Telephone
Fax
Contract Termination

[Custom Service](#)
(905) 305 8204
905 305 8216
NA

DEMO: String #1 RECENT EVENT LISTING
13:56:59 03/09/2007

[Status](#) [Request Data](#)

NR	EVENT	START TIME DATE	DURATION	AVERAGE CURRENT	REMAINING CAPACITY
1	FLOATING	13:09:50 03/05/2007	4 Day(s) 00:47:09(NOW)	0.0	100.0%
2	OPEN	13:09:49 03/05/2007	00:00:01	0.0	100.0
3	DISCHARGING	13:09:36 03/05/2007	00:00:13	N/A	100.0
4	FLOATING	13:09:31 03/05/2007	00:00:05	0.0	100.0

This page gives an up to date overview of all activities on the system such as: their start time, duration, average current during an event, and remaining capacity percentage.

Note: Events are listed from the most recent to latest.

REQUEST DATA FORM

BTM REPORT FORM FOR DEMO	
<small>Year can be omitted</small> START DATE (MMDDYY): <input type="text" value="090906"/>	<small>Minutes and seconds can be omitted</small> TIME (hhmmss): <input type="text" value="000000"/>
END DATE (MMDDYY): <input type="text" value="030907"/>	TIME (hhmmss): <input type="text" value="135829"/>
EVENT TYPE: <input checked="" type="radio"/> ALL <input type="radio"/> or SELECTED <input type="checkbox"/> DISCHARGE <input type="checkbox"/> CHARGE <input type="checkbox"/> FLOAT	
STRING #: <input type="text" value="1"/> TOTAL JARS <input type="text" value="9"/>	JAR LIST 1: <input type="text" value="*"/>
ALL <input checked="" type="radio"/> or SELECTED JARS <input type="radio"/>	JAR LIST 2: <input type="text" value="*"/>
LIMITS AUTO <input checked="" type="radio"/> or CONFIGURED LIMITS <input type="radio"/>	HIGH VOLTAGE LIMIT: <input type="text" value="*"/> LOW VOLTAGE LIMIT: <input type="text" value="*"/>
PRIMARY Y-SCALE: AVR <input checked="" type="checkbox"/> JAR VOLTS <input type="checkbox"/> TEMPERATURE <input type="checkbox"/> CURRENT <input type="checkbox"/> FLT CURRENT <input type="checkbox"/> IMPEDANCE Average Factor <input type="text" value="3"/>	
X-SCALE: <input checked="" type="radio"/> TIME SCALE <input type="radio"/> EVENT POINTS	
Report Method: <input checked="" type="radio"/> Graphical <input type="radio"/> Text	
Back to Status Table <input type="button" value="Clear"/> <input type="button" value="Submit"/>	

Multiple entries can be selected
 SELECTED EVENTS
RECENT EVENTS LIST

Currently Not Available

This form allows you to specify the voltage profile parameters for selected jars, current, and temperature. The form is displayed when accessing data through the local network, or over the Internet.

To generate a report, you must select a start date and time and an end date and time for the reporting period. If multiple strings are configured for the site, you must select string number.

If you would like to generate a report for a few selected jars, you can fill in Jar list 1 and Jar List 2 (both lists are appended to each other, however, if List 1 is empty then List 2 is ignored). Lists can be comma separated as shown below.

E.g. List 1: 5,9,15..20,33,69..71 will produce report for jars 5,9,15,16,17,18,19,20,33,69, 70 and 71.

Note: Do not forget to check selected jars radio-button, when requesting reports for limited jars.

The graphical report Y-scale is the battery terminal voltage. Its minimum and maximum values are defined automatically by min and max values measured for the reporting time period. Also, filling in the HIGH VOLTAGE and LOW VOLTAGE LIMIT values can configure these values. Do not forget to check the Configured Limits radio-button, when using user-defined limits. Any value can be used as long as the HIGH VOLTAGE is greater than LOW VOLTAGE


Following report pages can be requested:

Average jar and individual jars, battery current and ambient temperature.


In addition, if Float Current Monitor (optional) device is included in the monitoring system, the battery float current and ripple current profiles are available.

Report graphs are produced in time-domain(x-axis). However, sometimes it is more informative to plot the profile-date in event-points (to evaluate emerging trends in terminal voltages). See sample graphs on the next page.

Report data can be presented as graphical plot, or data can be received as ASCII text table. The latter can be imported into MS-Excel or any other spreadsheet program for further analysis.



Battery Profile Report in Time-Domain





The same as above Battery Profile Report in event-points




BTM REPORT ON REQUEST

[Back to Status](#)

Total of 26 Graph(s)



Requested String Current Profile.




Requested ambient temperature profile



Requested Jar Voltage profile

STRING PERFORMANCE (profile) GRAPH



The string performance profile graph displays string current, ambient temperature, and jar voltage (average, minimum and maximum) behavior over last 2 months (depends on configuration). The maximum jar ripple voltage and slow change difference is also graphed. This page helps the operator to evaluate battery current status.

SYSTEM ALARM LOG PAGE.

			
COMPANY Polytronics Engineering 431 Alden Road Markham Ontario		Service Contractor Telephone Fax Contract Termination	
		Custom Service (905) 305-8204 905-305-8216 NA	
DEMO: All Strings ALARM LIST 14:13:53 03/09/2007 Status History			
STRING STATUS	Alarm Type	Activation Time and Date	IDs & VALUES
Total:	2		
1. Str#1: FLOATING	Jar Voltage Above Set Limit	14:13:41 03/09/2007	#6. 9.2.68(2.68),

The alarm log file lists all the alarms recorded, their activation time and pairs of Ids with their values. If the alarm is String related, ID#0 denotes average voltage and ID#1 denotes string current. Otherwise, the ID is jar ID number that is counted from the most positive end (facing charger positive) of the String.

For detailed description of alarms for Controller, see Appendix C.

MONITOR STATUS PAGE

 Polytronics Engineering Ltd.

COMPANY
Polytronics Engineering
431 Alden Road
Markham
Ontario

Service Contractor
Telephone
Fax
Contract Termination

Custom Service
(905) 305 8204
905 305 8216
NA

DEMO BTM MONITOR STATUS
14:14:43 03/09/2007
System Serial Number: DEMO_01
Version 3.1.7 (P08 7 2007)
 DIN: 06.00.0E.C4.FA.9E


[Status](#)

DEVICE ID #	DEVICE TYPE	DEVICE STATUS	Comments
1	CONCENTRATOR	OK	Acquisition Time: 391 ms
31	FLOAT CURRENT	OK	Acquisition Time: 131 ms

The monitor status page displays information about all the installed concentrators.

In this table, all configured devices are listed by their type (Concentrator, Float Current Monitor, Loader, etc.), data acquisition status (OK, OFF-LINE) and a device data acquisition time. If some devices have observed intermittent communication problems, the device will appear in yellow on the table, and the number of lost packages and/or CS-errors will be displayed.

MAINTENANCE PAGE



MAINTENANCE FUNCTIONS

ACTIVATE FUNCTION
Go to selected function page

Back to Status
Escape maintenance functions
(no changes)

Maintenance Functions For DEMO Site
14:41:51 03/09/07

SERVICE PASSWORD:

BTM CONFIGURATION:

VOLTAGE ADJUSTMENT:

For Str #

This page will take you to the configuration and setup section. There is a password in order to get in and change the configuration of the system. It is important that only experienced personnel work on the maintenance page. The password is “dixie” and is case sensitive. Once you type in the password you will select the string you wish to edit.

After that, you will chose either the BTM configuration screen or the Voltage Adjustment screen. The BTM configuration page will allow you to make changes to the setup of your system, and the Voltage adjustment will allow you to easily calibrate your devices.


VOLTAGE ADJUSTMENT

Voltage Adjustment Table for String #1					
Back to Status Table					
Jar #	Present Reading	New Reading	Jar #	Present Reading	New Reading
AMBIENT T	23.7 °C	<input type="text" value="23.7"/>	PILOT T	24.3 °C	<input type="text" value="24.3"/>
1	2.37 V	<input type="text" value="2.37"/> V	5	NA	NA
2	NA	NA	6	NA	NA
3	NA	NA	7	NA	NA
4	NA	NA	8	NA	NA
5	NA	NA	9	NA	NA

Force Adjustment

As a part of the controller maintenance program, the concentrators need to be verified periodically against a calibrated voltmeter. If any of the voltage readings need correcting, the controller offers a convenient way to adjust every individual input reading. This page allows you to make calibration changes to the specified string. The jars are listed in columns with the present reading beside them. The new reading column allows you to enter the new value. If another string needs to be adjusted, you must go back to the Maintenance page and enter the next string number and the corresponding password. It is not necessary to adjust every value, just the values that read inaccurately.

MAINTENANCE SYSTEM PAGE



BtmGlobal Configuration - Netscape

http://btmgloba00/cgi-bin/maintenance1.pl

Polytronics Engineering Ltd. *BtmGlobal*

SYSTEM NETWORK STRING CFG SITE SERVICE INFO ADVANCED DATE & TIME

SYSTEM

Overall Monitoring system configuration, site information

To add new string, define its nominal jar voltage and number of jars

To add multiple strings with different topologies, add one string at time

To activate Alarm Contacts (AL 1 and 2), enter 2 for Enable Alarm Contacts

Company Name: Polytronics Engineering

Site Name: DEMO

Description: Battery Room

Address: 431 Alden Road

City: Markham

State/Province: Ontario

Enable Alarm Contacts: 2

New String Nominal V: 2.2 V


NR of Jars for New STR: 30

Number of Strings: 1

Number of Devices: 2

The System page allows you to edit site information and most importantly the system configuration. This screen is where you enter the number of strings and total number of devices in your system. These values must be entered in order for you system to detect all of your devices properly. For the changes to take effect, you must click ‘Submit’ and then ‘Maintenance’. The next step is described in the Maintenance Activation Page.

NETWORK PAGE



http://btmglobal00/cgi-bin/btmconf.pl1

Polytronics Engineering Ltd. *BtmGlobal*

SYSTEM NETWORK STRING CFG SITE SERVICE INFO ADVANCED DATE & TIME

NETWORK

Network configuration:
dhcp (dynamic) or static.

IP PROTOCOL: dhcp or static

If static is defined then Static IP, Gateway IP, Network and Broadcast must be also defined

Generally it is recommended to use dynamic addressing(dhcp)

GATEWAYDEV can be left undefined.
IF DNS is not known, leave it undefined


If direct crossover cable between System Controller and PC is used, static IP may be required.

INTERFACE DEVICE	eth0
NETWORK ACTIVE	yes
IP PROTOCOL	dhcp
STATIC IP	0.0.0.0
NETMASK	0.0.0.0
BROADCAST IP	0.0.0.0
NETWORK IP	0.0.0.0
GATEWAY	0.0.0.0
GATEWAY DEV	0.0.0.0
DNS1	0.0.0.0
DNS2	0.0.0.0

Submit Maintenance

The Network page allows you to make adjustments to the network configuration. For the changes to take effect, you must click 'Submit' and then 'Maintenance'. The next step is described in the Maintenance Activation Page.

STRING CFG



STRING CFG #01

String related parameters, string maintenance information, data storage configuration and alarm limits

Current shunt is optional when float-current transducer is installed. In such a case, enter 0 for Current device.

Device list: comma separated values and/or sequences
Sequence: 3..7 all number from 3 to 7
EG. 1,3..8,11,15..18

Float-current dev is typically 31, if it is not installed, enter 0 for device ID.

Exclude inputs:
PORT ID#;(chans to exclude list)
List is comma separated vals or slice (a..b)
Concentrator odd number inputs starting from 5 to 33 are Jar V measurements
A Concentrator has 15 jar V inputs.
Devices configured for more than 15 inputs (NO INTERCELL) are logically splitting into 2 adjacent ID's, eg. 1 and 2.
EG. 0(2(15..33)) => excludes from physical device #1 10 last inputs (the device monitors 20 jars).

String name	String #1
String reference	Battery Bank #1
Other notes	Battery tested OEM prior to st
Battery Load	Load bank
Battery Installed	08/2005
Battery Model	CB56
Number of Jars	12
Nominal voltage	12.2 V
Battery Capacity	120 Ahr
At current Rating	10 A
Maximum (Shunt) Current	100 A
Current device	0 ID#
Float-current device	31 ID#
Ambient T device	31 ID#
Ambient T Conversion Factor	1.0 Unit
Pilot T device	1 ID#
Pilot T Conversion Factor	30 Unit
Concentrator list	0:1 ID#s
Exclude Inputs	CH#s

String Maintenance Group: None
String Maintenance Group E-Mail: xxx@hotmail.com
Next Battery Service Date: March 2007

Max floating current	1 A
Max transducer current	350 A
Low Temperature limit	12 C
High Temperature limit	35 C
High Ripple Current limit	6 A
Jar Disch End V	6.67 V
String Disch End V	390 V
String Profile Recording Period	36 Sec
NA, OPN, FL, FCH, CHG, EQL, DIS	
Jar V Per Status	2,0,2,1,2,2,2,2,2,2,3,2,06 V
Jar Low V Limits	1,0,2,0,2,14,1,7,1,7,1,7,1,7 V
Jar High V Limits	3,0,3,0,2,34,2,4,2,4,2,4,2,5 V
Significant Jar V Delta	0,1,0,05,0,12,0,12,0,12,0,15,0,08 V
Significant Average V Delta	0,1,0,03,0,10,0,10,0,10,0,12,0,06 V
Significant Current Delta	10 1/10A
Time Based Recording	0,600,3600,1800,300,300,60 Sec
Times to Record at the Beginning of Event	0,1,1,1,5,3,5

Submit Maintenance

The String CFG page allows you to edit the detailed aspects of the configuration.

Important areas included:

Shunt device: Must always be a device (concentrator), which is part of the string you are editing.

Float-Current Device: Is the Float Current Device ID number that is connected to the current string. If there is no Float Current Device, this value should be zero.

Temperature Device: Is the Float Current Device ID number that is connected to the current string. IF there is no Float Current Device then this value must be a concentrator unit ID that is within the string.

Concentrator List: This list must include all the concentrator ID numbers, which are within the current string. You can list them individually with commas, ex. 1,2,3,4,5 or you can select a sequence by using two periods, ex. 1..5, which would indicate units 1 to 5. You can also use a combination of these methods.

The limits allow you to set where the alarms become activated.

After entering all the changes to be made, you must click ‘Submit’ and then click Maintenance. The next step is described in the Maintenance Activation Page.

Exclude Inputs: This section requires knowledge of the internal input mapping of a physical concentrator. The key point here is that in every ‘physical’ Concentrator, there are two ‘logical’ concentrators inside. That means for every one physical concentrator, there are actually two logical concentrators.

That being said, it is also important to realize that not all the input are used. With one concentrator, you can monitor up to 30 jars. As the figure below shows, jars 1-15 are on the first logical concentrator, and jars 16-30 are on the second logical concentrator. When excluding inputs, the first five are not used and all intercell inputs can be ignored. However, if you do exclude the intercell inputs along with the jar inputs, this is acceptable as well.

Internal Input Mapping Structure of a Concentrator




Figure 7: Internal Input Mapping

Here is an example:

Jar Inputs 1-18 and 29 are to be used. The line in the Exclude Inputs section will be as follows:

0:2:(10..29,32..33)

or could be looked at as:

0:2:(10..29,32..33)

This is the convention. The first 0: is simply used to open the section. The 2: is the logical concentrator number 2. The (10..29,32..33) are excluding jars 19-28, leaving 29, and excluding 30. You should be able to see the values with the corresponding input values in the Internal Input Mapping figure. You must use a comma ',' to separate values, or two periods '..' to include a range of values.

Now, if you wanted to exclude the last 3 jar inputs (jars 28, 29, 30) on all three concentrators in String 2, you would use the following line:


0:2:(28..33),4:(28..33),6:(28..33)

or could be looked at as:

0:2:(28..33),4:(28..33),6:(28..33)

In this example, remember that you are excluding the last 3 jar inputs on three separate concentrators. Therefore, you are excluding the last 3 jars on the second logical concentrator of each of the three. You must place a comma between each concentrator you decide to excluding inputs on. The initial 0: does not need to be repeated.

BATTERY SERVICE



File Edit View Go Bookmarks Tools Window Help
http://btmglobal00/cgi-bin/btmconf.pl?3

Polytronics Engineering Ltd. *BtmGlobal*

SYSTEM NETWORK STRING CFG **SITE SERVICE INFO** ADVANCED DATE & TIME

SITE SERVICE INFO

Site Maintained by Custom Service
Site Maintenance Contact Info Other
Telephone (905) 305 8204
Fax 905 305 8216
E-Mail info@polytronicseng.com
Next scheduled service NA
Contract expiration NA
Alarm E-Mail 1 one@somewhere.com
Alarm E-Mail 2 info@polytronicseng.com

Site service provider contact information
If different Service providers for different strings are used, fill in this information in STRING CFG


Alarm recipient over e-mail. In order to enable e-mail alarm notification, a network access point to valid mail-server must be provided. No password(s).

Email configuration / activation is not supported through Maintenance Interface.

Submit Maintenance

The Battery Service Section allows you to enter the battery servicing information. For changes to take effect, you must click ‘Submit’, and then ‘Maintenance’. The next step is described in the Maintenance Activation Page.

ADVANCED PAGE



http://btmglobal00/cgi-bin/btmconf.pl?4

Polytronics Engineering Ltd. *BtmGlobal*

SYSTEM NETWORK STRING CFG SITE SERVICE INFO **ADVANCED** DATE & TIME

ADVANCED


System fine tuning.

IMPORTANT! Do not modify unless well familiar with the system!

Packet Timeout	<input type="text" value="1200"/>	ms
Wait after transmit	<input type="text" value="75"/>	ms
Wait after scan cycle	<input type="text" value="120"/>	ms
Wait After Read	<input type="text" value="600"/>	ms
Command Byte Delay	<input type="text" value="8"/>	ms
Reset Packet Errors	<input type="text" value="1"/>	


This section deals with the advanced communication settings. Do not edit these values unless you are very familiar with their functions due to the fact that incorrect settings will cause the system to lose communications. For the changes to take effect, you must click 'Submit', and then 'Maintenance'. The next step is described in the Maintenance Activation Page.

TIME AND DATE PAGE



This page simply sets the time and date of the controller. This is very important to set accurately so that when data and/or alarms are recorded, they display the correct time.

MAINTENANCE ACTIVATION PAGE



The Maintenance Activation Page will cause all changes made in the Maintenance pages to take effect. There are several functions that can be made which are related to Activation.

Clear All: This clears all recorded data and will not be unrecoverable from the system. This function is destructive and must be used with care. However, it should be used when starting a new setup (possibly after installing a new concentrators) in order for the displayed data (Graphs etc.) to display the correct data. Before the Clear All function is used in this situation, the 'Dump CSV' and/or 'Dump Binary' should be used first.

Dump CSV: This function allows you to save all the recorded data your remote computer. It will be saved as a CSV file.

Dump Binary: The system records all data in binary form and converts it to a useable (.csv) format for viewing. Technically, the Dump Binary and Dump CSV are very similar. However, the Dump CSV is the data in a usable form. If you want the binary files, click on the Dump Binary icon.

Reactivate BTM: This function is used when changes have been made to the configuration of the device in the maintenance section. This will cause all changes to take effect.

Reactivate Network: This restarts the network in order to have Network changes take effect.

Reboot System: This performs a soft OS reboot of the system. It is suggested that your IT department backup all recorded data before using this function (Dump Binary/CSV)

Clear CSV's: This is used to recover hard drive space. It is similar to Clear All function, but it does not clear the Binary files and the data is recoverable.

Appendix B

Connecting your PC to the Controller using a Cross-Over Network Cable

1. Requirements.

- ❑ Ethernet Cross-Over cable to link 2 Ethernet cards together or 2 CAT-5 cables
- ❑ A portable computer with Ethernet card with RJ45 connector or USB to Ethernet adaptor with an RJ45 connector. The computer must also be configured for networking using the TCP/IP protocol.
- ❑ Small 2 or 4 port router (optional)

Option: Instead of connecting 2 network cards directly using Ethernet Cross-Over Cable, it is also possible to use a small network router with at least 2 ethernet ports and 2 direct Ethernet cables with RJ45 plugs. By default, BtmGlobal device has DHCP service enabled, which means that the device acquires IP address at its boot time from the network (dynamic IP), therefore the router is required to act as DHCP server. In this case, you can skip step 2 and go directly to step 3.




Figure 8: Connecting Portable PC to Controller Console

2. Setup

- Connect your portable computer to the controller box's Ethernet port connector using the crossover cable (or use 2 direct cables and a small hub). (see figure above)

Warning: The BtmGlobal Controller must have Static IP defined. If this is not the case, direct connection with cross-over cable is not possible. Only connection using small network router will work.

- Modify (or verify) your network card TCP/IP settings. This can be done by going to the <Start> menu, select <Settings> and <Control Panel>. From the <Control Panel> window, you double click on the <Network> icon. In the icon <Network>, click on the <Configuration Tab> dialog box and then the <Installed Component List box>. Highlight the entry TCP/IP-> Ethernet-card (connected to Modbus Box). If your computer has multiple network cards configured, make sure that you select is the right one. After highlighting the entry, click <Properties>. Next, select the <IP ADDRESS> tab. Write down the existing settings. To modify the settings, select the <SPECIFY an IP Address:>. See Figure 9.




Figure: 9 TCP/IP Protocol Settings




Figure: 10 Network Settings

If the OS requires an installation CD after closing the <Network> dialog, specify the location as your windows directory (For example: C:\WINDOWS). For Windows 98: **You must restart the computer after completing this step.**

3. Connecting to Controller

- Start your Microsoft Internet Explorer or Netscape Internet Browser.
- In the address bar, type <http://BtmGlobalXX>, where XX is digits 01 – 99. The Controller name is recorded on the front-label.
- The Battery Index page should be displayed. Now, navigate through battery data as desired.

4. Restoring your Computer TCP/IP settings

After finishing the upgrade, disconnect the network cable and restore your original TCP/IP settings as you recorded from step 2. If you do not restore to your original settings, some of your applications or network connections may not work properly. The Modbus Translator Box must remain operational (you will see changing scan-codes on the LED display).

Appendix C

Controller Alarms and String Statuses

Alarm	Description
String Exhausted	Battery total voltage is below discharge end voltage (during discharge)
String Open	String is at open potential, charger not connected or malfunctioning
Pending Jar Reversal	A jar terminal voltage is near its end voltage during discharge. This jar does not support the load any longer.
Low Capacity	String capacity near exhaustion, a few minutes reserve time remaining
Jar Internal resistance High	The internal resistance of a jar has increased drastically.
Jar Voltage Below set limit	During float operation, the jar terminal voltage is below preset limit.
Jar voltage Above set limit	During float operation, the jar terminal voltage is above preset limit.
Jar High Float Mobility	Jar terminal voltage drifts significantly during battery floating
Jar High Noise during Float	High ripple voltage during float operation
Temperature Abnormalities	Ambient/Pilot temperature outside limits
Discharge Warning	String is discharging
Charge Warning	String is charging
Equalization Warning	String is at Equalization potential
Jar Parameters Degraded	Jar calculated parameters during discharge, charge or Float have been degrading.

Note: Each alarm can be individually enabled/disabled. The controller can send an e-mail when an alarm is detected if it is connected to the LAN or has a dial-out to the ISP capabilities enabled.

String Status	Description
NA	String status unknown. During a system start-up or communication failure
OPEN	String is at open potential
FLOATING	String is fully charged and floating at its nominal voltage
FLOAT-CHARGING	Charge current is not detected, battery not at open potential but its capacity is not fully restored.
CHARGING	Charging current to the battery detected.
EQUALIZING	Battery at equalizing potential (prolonged application will be harmful to the battery).
DISCHARGING	Load is on the battery.

Appendix D. Sample Controller System

