
www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual

Flexible LED Curtain Display Manual



Contents


Safety information	••••••	2
Product information		3
Control case	•••••	4
Essential connection cable		5
Connection diagram		6
Transom assembly		7
Module installation	••••	8
Control case installation		9
Package information	•••••	9
Product maintenance	•••••	10
Installation maintenance		11

- Please check up that the unit has not been damaged during transport.
- Read all cautions and warnings prior to operation of this equipment.

www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual

■ Technical specification

Product model	UNIT-FSWI-P6D8
	Indoor
Usage	
LED type	(SMD3528) 3 in 1
Pixel Pitch (PH)	6mm
Module resolution	192Dots x 64Dots
Brightness (CD/M²)	≥2200 CD/m²
Transparency	%3
Refresh rate (Hz)	≥2000HZ
Pixel density (dot/ M ²)	27778Dots/m ²
Grey level	≥65536
Working voltage	DC24V
Power consumption (W)	240W (MAX)
Viewing angel	130°
Operating temperature (°C)	-30∼+50°C
Control mode	Synchronic
LED lifespan	50000
IP rating	IP61
Size (L*W*H) (mm)	384*1152*33mm
Weight (KG)	5. 82kg
Dimension	$0.4425{ m M}^2$
Certificate	CE RoHS



■Mechanical specification

	· · · · · · · · · · · · · · · · · · ·		
1	Small module		
2	16pins signal cable		
3	2 pins DC24V power cable		
4	Small power case		
5	Left chain (dual)		
6	Right chain (single)		
A mod	dule is made of 12 small power cases;		
A sma	all module is drived by a small power case;		
There	are totally 1024 pixels in every small module;	5	
Left chain and right chain of aluminum alloy are			
eauipi	ped at two side of every small module.	am 1	

www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual

Master controller



Information	
Product model	UNIT-T7-BOX
Input voltage	AC:100V~240V
Total power consumption	18W
Data input base	DVI & USB
Data output base	Ethernet
Material	spcc
Size/weight	L280*W180*H50mm/1.4kg

2 U control case



Specifications	
Information	UNIT-STD-201A
Input voltage	AC110V/220V (internal
	option)
Output power consumption	2000W
Data input base	Ethernet entrance
Output voltage	DC24V
Data output transmission distance	3M
Material	spcc
Size/weight	582*264*175mm/14.5kg
Attention: A 2U control case is in charge of 4 piece UNIT-FSWI-P6D8 module. (4 pieces side by side)!	


www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual


1 U control case





Information	
Product model	UNIT-STD-101A
Input voltage	AC110V/220V (internal
	option)
Output power consumption	1000W
Data input base	Ethernet entrance
Output voltage	DC24V
Data output transmission distance	3M
Material	spcc
Size/weight	L553*W223*70mm/6.08kg
Attention: A 1U control case is	in charge of 2 pieces of
UNIT-FSWI-P6D8 module. (2 pieces side by side)!	

Connection cable information










www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual

Connection diagram



Item number		
A	PC	
В	Master controller	
C	1U control case	
D	GL-FSWI-P6D8 module	

Connection information	
→	AC exchange current line
→	Network line
→	DC24 direct current line
→	Signal line

▲Attention: It is a 1U control case connection diagram!


▲Attention: A 1U control case is in charge of 4 pieces of UNIT-FSWI-P6D8 module. (4 pieces side by side)!

www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual

Beam components


Name	Model	Load-bearing	Net weight	Size
Beam component	P6-360	50≤kg	2. 5kg	L 360mm
Beam component	P6-745	145≤kg	3. 5kg	L 745mm

P6-360



▲6 pieces of P6 module at most (1 array ,6 rows)


P6-745



▲12 pieces of P6module at most (2 arrays,6 rows)

www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual


Module installation





Item number

- 1 Steel frame/pipe (made by client)
- **2** Beam component
- **3** A module
- **4** M4*24inner hexagonal machine silk
- **5** M4 nut
- 6 M4 self-locking nut
- **7** Self-locking fastening
- **8** M4*16 inner hexagonal machine silk
- **9** 16P signal cable female socket
- **10** 2P DC24V cable female socket
- 11 16P signal cable male socket
- 12 2P DC24V cable male sockt




No. 1		Picture No.1(Beam & module installation): 2 installed firmly into $1\rightarrow 3$ installed into 2 insert $4\rightarrow twist 5\rightarrow twist$ firmly and fix 6;	
	No. 2	Picture No.2(left & right module installation): 7 insert 3 left & right chain hole;	
	No. 3 Picture No.3 (up & down module installation): 3 and the third chain but join up and down—insert firmly and fix $6\rightarrow9$ & 11 but join $\rightarrow10$ & 12 but join;		
	Attention: Check up on the firmness of installation!		

www.unit-led.com Flexible LED Display, LED Curtain, Soft LED Display User Manual

Control case installation




Package



www.unit-led.com Flexible LED Display,LED Curtain,Soft LED Display User Manual

Product maintenance



www.unit-led.com Flexible LED Display, LED Curtain, Soft LED Display User Manual

Installation maintenance

▲ The following points have to be considered during the inspection:

Check up on the device and electron once every two years to make sure product secure use;

All screws used for installing the device or part of the device have to be tightly connected and must not be corroded;

There must not be any deformation on the housing, fixation and installation spots (ceiling, suspension, trussing);

The electronic power supply cables must not show any damages, material fatigue (e.g. porous cables) or sediments;

Make sure signal cables and FCS-driver and FCS-PD8 are not placed near any magnetic interference;

▲ Advice

Clean the device frequently. Please use a moist, lint free cloth. Never use alcohol or solvents!

Environment with foggers will require more periodic cleaning as fog fluid tends to build up residues, reducing the light output.

The plastic enclosure will require periodic cleaning according to usage and environment

▲ Attention

Power cable replacement: If the power cable is damaged, it has to be replaced by electrical safety regulations only in order to avoid hazards

Only exchanging light bar or lamp is included in maintenance range;

Other maintenance and service are to be carried out by authorize dealers.

Should you have further questions, please contact your dealer.

▲ Please keep this user manual properly for further use in any case after being read.

After-sale service contact information

Contact unit: Robby Email: robby@unit-led.com Website: www.unit-led.com

Support: Tel: 13787050055 Msn: <u>leddisplays@hotmail.com</u> Skype: leddisplays