

Spraying boom

user manual

Serial number

Edition 2
07 - 2008

INDEX

| <i>title</i> | <i>page</i> | <i>title</i> | <i>page</i> |
|--|-------------|---|-------------|
| TECHNICAL INFORMATION | 2 | INFORMATION ABOUT | |
| equipment general description | 2 | ADJUSTMENTS | 16 |
| technical specifications | 2 | instructions for adjustments | 16 |
| Technical specification diagram | 2 | adjustment of arm alignment | 17 |
| safety devices..... | 3 | INFORMATION ABOUT USE | 18 |
| Safety distance table..... | 3 | operating advice..... | 18 |
| Safety distance diagram..... | 3 | boom folding and unfolding..... | 18 |
| identification plate position | 4 | INFORMATION ABOUT | |
| position of signals..... | 4 | MAINTENANCE | 19 |
| INFORMATION ABOUT HANDLING AND | | maintenance schedule table | 19 |
| INSTALLATION | 4 | lubrication points diagram | 20 |
| handling instructions..... | 4 | cleaning nozzles | 20 |
| packing and unpacking | 4 | prolonged inactivity | 21 |
| loading and transportation | 5 | TROUBLESHOOTING | 21 |
| handling and lifting | 5 | troubles, causes, remedies | 21 |
| installation instructions | 5 | INFORMATION ABOUT | |
| installation of disassembled parts | 5 | REPLACEMENTS | 23 |
| equipment installation | 6 | replacement of spring and terminal joint | |
| installation of arm..... | 6 | pin | 23 |
| installation of the hydraulic system | 7 | replacement of self-levelling tilting ram | |
| 3-function hydraulic system (with electric | | bushing | 24 |
| switch and control panel) | 8 | disposing of the equipment..... | 24 |
| installation of line filters (if required) and | | | |
| jets | 11 | | |
| number of jets on each boom section | | | |
| Jet number diagram for each boom section | | | |
| (500 mm pitch) | 12 | | |
| installation of water hoses | 13 | | |
| 5-supply water connection diagram | 15 | | |
| installation of rear light kit | 16 | | |

IMPORTANT SAFETY NOTE

The information published in this booklet regards the pointed out with relevant symbols in order to safeguard operational aspects of the operator unit installed on the people from risks. Remember that prudence is irreplaceable. machine. It is however

necessary that you carefully read the Safety is also in the hands of all the operators who interact general safety regulations published in Booklet 1 and those with the machine.

TECHNICAL INFORMATION

EQUIPMENT GENERAL DESCRIPTION

The spraying boom, from now on called equipment, was designed and built to be installed on a machine for spraying chemical products on tilled land and/or products.

It is to be put on the height adjustment device and on the self-levelling device so that it remains perfectly

parallel with the ground, even in the event the ground is uneven.


The equipment is divided into folding boom sections in order to adapt it to the spraying width and so as to reduce the space occupied during transfer.

TECHNICAL SPECIFICATIONS

| Width (m) W | Size | | | (*) Weight (kg) | Qty. Jets (500 mm) |
|-------------|------|------|------|-----------------|--------------------|
| | A mm | B mm | C mm | | |
| 15 | 2500 | 600 | 2800 | 440 | 30 |
| 16 | 2500 | 600 | 2800 | 442 | 32 |
| 18 | 2500 | 600 | 2900 | 447 | 36 |

(*) Boom with self-levelling devices on maximum configuration.

Technical specification diagram




SAFETY DEVICES

- **Extension articulation:** to allow the end of the extension to turn so as to get past obstacles. In order to get past the obstacle without damaging the equipment, it is necessary to keep a distance higher than the value (**D**) given in the table.
- **Stop valve:** it allows to stop movements of the various boom sections during use and/or transport of the equipment and to prevent accidental movements in the event of an hydraulic hose failure.

Safety distance table

| Width <i>W</i> | Width <i>W1</i> | Safety distance <i>D</i> |
|-------------------|--------------------|--------------------------------|
| 15 | 7,5 | 6,8 |
| 16 | 8 | 7,2 |
| 18 | 9 | 8,1 |

Safety distance diagram




332.068

233001002

IDENTIFICATION PLATE POSITION


The figure points out the positions of the identification plates of the components.



POSITION OF SIGNALS

The figure shows the location of all safety plates, while their meaning is explained in booklet 1.

The plates (A and B) supplied with the manual have to be placed inside the tractor cab, in a visible position.



INFORMATION ABOUT HANDLING AND INSTALLATION

HANDLING INSTRUCTIONS

Comply with the information provided by the manufacturer, found on the equipment and in the instruction

manual, when carrying out handling and loading operations.


PACKING AND UNPACKING

- The equipment is to be placed on a loading platform, protected and adequately secured. To make transport easier, it can be shipped with several components disassembled.

- When unpacking, check that all the components are intact and in the exact quantities.
- The packing material is to be disposed of properly, in observance of the laws in force.

LOADING AND TRANSPORTATION

Depending on the destination, loading and transport can be carried out with different means. The diagram shows the most commonly used solutions. Secure the means properly during transportation in order to prevent untimely shifting.




HANDLING AND LIFTING

The equipment can be handled with a lifting device with forks or hooks having a sufficient capacity. Position the lifting device as shown in the figure. Avoid sudden manoeuvres.



Danger - Warning

Lifting and handling operations must be carried out by using appropriate means and by skilled staff specialized in this kind of manoeuvres.



INSTALLATION INSTRUCTIONS

Whoever performs the installation must prepare satisfactory safety conditions in advance in order to ensure their own safety and that of the operators involved.


INSTALLATION OF DISASSEMBLED PARTS

Follow the instructions given below so as to install and assemble the spraying boom properly.

EQUIPMENT INSTALLATION

Keep to the following instructions.

- 1 - Position sliding blocks (F) as shown in the figure
- 2 - Lift the equipment and insert it into guides (A) of the lifting device.
- 3 - Fasten the equipment to lifting cylinder (B) by means of screws (C).
- 4 - Adjust screws (D) and tighten counter-nut (E) so that the frame can slide along the entire lifting length without excessive play.




233001007.TIF

INSTALLATION OF ARM


Keep to the following instructions.

- 1 - Unscrew dowels (C) and screw (D) so that pin (E) can be inserted without obstructions.
- 2 - Lift arm (A) and fasten it to central frame (B) by means of its pins (E) after lubricating the parts and their seats.
- 3 - Tighten dowels (C) and screw (D) by means of their counter-nut.



233001008.TIF

- 4 - Remove the rod of cylinder **(H)** and fasten it to arm **(L)** and tie-rod **(M)** by means of screw **(N)**.
- 5 - Install cable **(O)** as shown in the figure.
- 6 - Install the opposite arm by following the same instructions.



INSTALLATION OF THE HYDRAULIC SYSTEM


Proceed in the way indicated.

- 1 - Connect the hoses to the cylinders (see the hydraulic diagram).




Important

Do not tighten the unions too much so as to damage the sealing taper fit.



3-function hydraulic system (with electric switch and control panel)



233001011.TIF

The control is performed from the control panel and is activated from the tractor's driver's seat.

The control panel is installed so that the driver can easily activate it.

Electric switch with control panel



How to use the controls

1 - Select the function by means of switches (E). Activate the selected function by means of lever (C) of the tractor's control unit

E1 Pos. 0 / **E2** Pos. 0 = Correction of position

E1 Pos. 1 / **E2** Pos. 0 = Unfolding / folding of left arm

E1 Pos. 0 / **E2** Pos. 1 = Unfolding / folding of right arm




233001012.TIF

Boom unfolding and folding

The figure indicates the procedure to follow when unfolding and folding the boom.


Please note: the two arms can be folded or unfolded independently of each other.



332.068


233001013.TIF

4-function hydraulic system (with double effect solenoid valves)




CGA CONTROL PANEL

- A) Unfolding of left arm
- B) Unfolding of right arm
- C) Lifting
- D) Correction of hydraulic tilt



MÜLLER CONTROL PANEL


- A) Unfolding of left arm
- B) Unfolding of right arm
- C) Lifting
- D) Correction of hydraulic tilt



INSTALLATION OF LINE FILTERS (IF REQUIRED) AND JETS

Proceed in the way indicated.

- 1 - Install the line filters (A) as shown in the figure.




233001016.TIF

- 2 - Mount the jets (B) next to the outlet holes of the stainless steel pipes (C) (see the "Jet Layout" diagram, page 12).



Important

Properly mount the seals (D).



233001017.TIF

NUMBER OF JETS ON EACH BOOM SECTION

Position the nozzle holder hoses depending on the boom length (see diagram).


The diagram shows as well position and number of supports on each hose and installation instructions, depending on the number of supplies.

If the equipment is supplied disassembled, the diagram is enclosed with the small items of the boom.




Important

For hoses with up to four jets use two pairs of clamps (A); for hoses with more than four jets use three pairs of clamps (B).




Jet number diagram for each boom section (500 mm pitch)




INSTALLATION OF WATER HOSES

Proceed in the way indicated.

- 1 - Lay the hoses down on the boom linearly (see the figure).



- 2 - Leave sufficient length so as to not impede the movements at the articulation points of the boom.
- 3 - Connect the hoses (see "water connection diagram").




- 4 - Secure the hoses to the boom with clamps spaced out ~ 20 cm.




Important


Do not tighten the clamps too much so as to avoid throttling.



- 5 - Use the Teflon seal (A) and tighten the stainless steel clamps (B) in order to ensure tightness in the joints.



5-supply water connection diagram




233001024.TIFF


INSTALLATION OF REAR LIGHT KIT

Install the rear light kit (A) and fasten it with U bolts (B).

Rear light kits for mounted units with rear-reflecting panels



Rear light kits for trailed tanks with rear-reflecting panels



233001025.TIFF

INFORMATION ABOUT ADJUSTMENTS

INSTRUCTIONS FOR ADJUSTMENTS


Whoever makes the adjustments must prepare satisfactory safety conditions in advance in order to ensure

their own safety and that of the operators involved.


ADJUSTMENT OF ARM ALIGNMENT

Proceed in the way indicated.

- 1 - Unfold boom completely
- 2 - Loosen counter-nuts **(A)** and align the arms by means of screws **(B)**. If necessary, increase the cylinder thrust by means of tie-rods **(C)**.
- 3 - Tighten counter-nuts **(A)**.



- 4 - Make the same adjustment on the other arm.
- 5 - Adjust the horizontal position of the complete arm so that it is parallel to the ground by means of nut **(D)**.



INFORMATION ABOUT USE

OPERATING ADVICE



Important

Information on hydraulic connections is to be found in the "Hydraulic system" diagram. The boom unfolding and folding procedure, variable depending

on the type of control installed, is described in "Boom Unfolding and Folding".

The information mentioned is not published in the manual if the equipment is installed on units belonging to other manufacturers.

BOOM FOLDING AND UNFOLDING




Important

The environmental and territorial conditions of the area where you plan to operate have to be checked every time the equipment is set up for spraying.

Evaluate the following requirements.

- Check whether or not there are electric lines and assess the risks of contact with the spraying boom.
- Check the gradient of the land so as to evaluate the most suitable conditions for operating in safety. Always bear in mind the maximum gradient limits allowed.
- In the event of spraying with progress transversal to the gradient, carefully follow the instructions given:
 - 1) **Boom unfolding stage:** always unfold the one uphill first, and then the one downhill.
 - 2) **Boom folding stage:** always fold the one downhill first, and then the one uphill.
- Never work if just the downhill arm is open.
- Keep the forward speed moderate (8-10 km/h max) so as to prevent the boom from swinging and getting uneven spraying.



Important

If it is windy, also stay below the maximum allowed limits (5 m/sec) so as to prevent the product from being dispersed in the surrounding environment. Keep the boom at a lower height and increase the volume of the droplets.




Caution - Warning

Prevent strangers from approaching the working area when the machine is in use. Should it become necessary, stop it immediately and make the people found in the risk area move away.

INFORMATION ABOUT MAINTENANCE

MAINTENANCE SCHEDULE TABLE


| Interval | Component | Type of intervention | Operation | Page |
|--|---|---|---|--|
| Each working day and with each interval higher than one hour | Jets and nozzles | Clean and rinse the water supply | Make the clean water come out of the nozzles | |
| | Jets and nozzles | Check operation | Clean and replace if necessary | See "nozzle cleaning", page 20 |
| Each working day | Jets, nozzles antidrip valve | Check installation | Install properly | |
| | Complete equipment | Clean and wash | Use a clean jet of water | |
| Every 40 hours of work | Complete equipment | Check the greased parts | Grease if necessary | See "Lubrication points diagram" page 20 |
| | Complete equipment | Check the condition and tightness of the screws | Tighten and replace if necessary | |
| | Complete equipment | Check the painted surfaces | Touch up the parts the paint has come off of if necessary | |
| | Boom limit stop bumper (A) (see figure below) | Check its condition | Replace if necessary | |
| | Endpiece articulation springs | Check its effectiveness | Replace if necessary | See "Replacement of spring and terminal joint pin" page 23 |



332.068

233001028.TIFF

LUBRICATION POINTS DIAGRAM



233001029.TIFF


Use *PERSIAN POLIGREASE 2* grease

CLEANING NOZZLES

- 1 - Wear protective gloves for this operation. Disassemble the bayonet (A) and nozzle (B).
- 2 - Clean the nozzle with a jet of air and a small soft-bristle brush.

i Important

Do not use pointed or sharp objects so as to not damage the hole of the nozzle.



233001030.TIF

PROLONGED INACTIVITY

If the equipment is not used for a long time, adopt the procedures given below.

- 1 - Perform the scheduled maintenance (see page 27).
- 2 - Perform the general cleaning (see page 29).
- 3 - Put in antifreeze fluid or completely empty the hoses in order to prevent the components (pump, control unit, filters, hoses, etc.) from breaking in the case of severe temperatures.
- 4 - Disconnect the hoses from the pressure gauges.
- 5 - Grease all the components provided with a grease nipple.
- 6 - Place the equipment in a sheltered place accessible only to the operators.


TROUBLESHOOTING

TROUBLES, CAUSES, REMEDIES

Trouble: the boom unfolds halfway and then stops.

Cause: impurities in the calibrated joints of the jacks.

Cures: disassemble the joints and clean them.




233001031.TIF

Trouble: the boom is not aligned when unfolded.

Cause: unfolding cylinder not adjusted.

Cures: adjust the alignment of the arms (see "arm alignment adjustment")




233001036.TIF

Trouble: when the boom is unfolded and / or folded, the complete extension moves in relation with the primary arm

Cause: anomaly in the adjustment of tie-rods.


Cures: adjust the tie-rods so that the arms stop against the adjusting screws.



Trouble: the endpiece extension is not steady enough with the boom unfolded.

Cause: the articulation is loose.

Cures: replace pin (D) and / or spring (E) (see "Replacement of spring and terminal joint pin").




INFORMATION ABOUT REPLACEMENTS

REPLACEMENT OF SPRING AND TERMINAL JOINT PIN

Proceed in the way indicated.

- 1 - Unscrew screws (A) and remove terminal joint (B).
- 2 - Remove pin (C) and spring (D).
- 3 - Insert the new spring and pin (C).




- 4 - When terminal joint (B) is rotated by 90° in relation with the primary arm, insert first screw (A).
- 5 - Align the terminal joint and the primary arm and insert second screw (A).



Important


Screws (A) must not be tightened because the terminal joint must be free to rotate.



REPLACEMENT OF SELF-LEVELLING TILTING RAM BUSHING

Proceed in the way indicated.

- 1 - Unscrew the screws (A)
- 2 - Remove the supports (B)
- 3 - Unthread the bushings (C)
- 4 - Replace the bushings.
- 5 - Reassemble the supports (B)



DISPOSING OF THE EQUIPMENT



Important

This intervention has to be carried out by skilled technicians and in accordance with the current safety regulations. Do not disperse in the environment non-biodegradable products, lubricating oils and non-ferrous components (rubber, PVC, resins, etc.).

Dispose of them according to the local regulations in force.