

# SIEMENS

## SIMOTION

Supplement to  
SIMODRIVE POSMO A  
Positioning Motor

Function Manual

Introduction

Description

1

Function blocks

2

Application example

3

Appendix

A

## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

#### DANGER

indicates that death or severe personal injury **will** result if proper precautions are not taken.

#### WARNING

indicates that death or severe personal injury **may** result if proper precautions are not taken.

#### CAUTION

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

#### CAUTION

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

#### NOTICE

indicates that an unintended result or situation can occur if the corresponding information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The device/system may only be set up and used in conjunction with this documentation. Commissioning and operation of a device/system may only be performed by **qualified personnel**. Within the context of the safety notes in this documentation qualified persons are defined as persons who are authorized to commission, ground and label devices, systems and circuits in accordance with established safety practices and standards.

### Proper use of Siemens products

Note the following:

#### WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be adhered to. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of the Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# ntroduction

## Contents of the function manual

This document is part of the **SIMOTION Programming - References** documentation package.

This documentation serves as a supplement to the documentation on SIMODRIVE POSMO A in the *Distributed Positioning Motor on PROFIBUS DP* user manual.

This documentation is included in the SIMOTION SCOUT scope of delivery as electronic documentation!

This manual describes how you can use function blocks to control and assign parameters for a POSMO A drive from a SIMOTION program.

This manual describes differences in handling that arise when controlling and assigning parameters for a POSMO A drive from the SIMOTION system as compared to the SIMATIC system.

## Function block

The function blocks for communication between the SIMOTION system and the distributed SIMODRIVE POSMO A positioning motor are part of the program library of the "SIMOTION SCOUT" engineering system.

## SIMOTION Documentation

An overview of the SIMOTION documentation can be found in a separate list of references.

This documentation is included as electronic documentation with the supplied SIMOTION SCOUT.

The SIMOTION documentation consists of 9 documentation packages containing approximately 80 SIMOTION documents and documents on related systems (e.g. SINAMICS).

The following documentation packages are available for SIMOTION V4.1 SP3:

- SIMOTION Engineering System
- SIMOTION System and Function Descriptions
- SIMOTION Diagnostics
- SIMOTION Programming
- SIMOTION Programming - References
- SIMOTION C
- SIMOTION P350
- SIMOTION D4xx
- SIMOTION Supplementary Documentation

## Hotline and Internet addresses

### Technical support

If you have any technical questions, please contact our hotline:

Europe / Africa	
Phone	+49 180 5050 222 (subject to charge)
Fax	+49 180 5050 223
Internet	<a href="http://www.siemens.com/automation/support-request">http://www.siemens.com/automation/support-request</a>

Americas	
Phone	+1 423 262 2522
Fax	+1 423 262 2200
E-mail	<a href="mailto:techsupport.sea@siemens.com">mailto:techsupport.sea@siemens.com</a>

Asia / Pacific	
Phone	+86 1064 719 990
Fax	+86 1064 747 474
E-mail	<a href="mailto:adsupport.asia@siemens.com">mailto:adsupport.asia@siemens.com</a>

---

### Note

Country-specific telephone numbers for technical support are provided under the following Internet address:

<http://www.siemens.com/automation/service&support>

Calls are subject to charge, e.g. 0.14 €/min. on the German landline network. Tariffs of other phone companies may differ.

---

## Questions about this documentation

If you have any questions (suggestions, corrections) regarding this documentation, please fax or e-mail us at:

Fax	+49 9131- 98 63315
E-mail	<a href="mailto:docu.motioncontrol@siemens.com">mailto:docu.motioncontrol@siemens.com</a>

## **Siemens Internet address**

The latest information about SIMOTION products, product support, and FAQs can be found on the Internet at:

- General information:
  - <http://www.siemens.de/simotion> (German)
  - <http://www.siemens.com/simotion> (international)
- Product support:
  - <http://support.automation.siemens.com/WW/view/en/10805436>

## **Additional support**

We also offer introductory courses to help you familiarize yourself with SIMOTION.

Please contact your regional training center or our main training center at D-90027 Nuremberg, phone +49 (911) 895 3202.

Information about training courses on offer can be found at:

[www.sitrain.com](http://www.sitrain.com)



# Table of contents

Introduction.....	3
<b>1 Description.....</b>	<b>9</b>
1.1 General .....	9
1.2 Installation and startup .....	11
1.3 Inserting a SIMODRIVE POSMO A positioning motor into a SIMOTION project.....	12
1.4 Integrating the function blocks in the user project .....	13
1.5 Creating I/O Variables.....	14
<b>2 Function blocks.....</b>	<b>15</b>
2.1 Overview of function blocks .....	15
2.2 Function block _POSMOA_control .....	16
2.3 Function block _POSMOA_nControl.....	22
2.4 Function block _POSMOA_rwParameter.....	28
2.5 Function block _POSMOA_rwAllParameter.....	31
2.6 Calling function blocks .....	38
<b>3 Application example.....</b>	<b>41</b>
3.1 General information on the application example .....	41
3.2 Operator control and monitoring of the application example in the detail view .....	43
3.3 Variables used in application example .....	48
<b>A Appendix.....</b>	<b>51</b>
A.1 SIMOTION and SIMATIC names.....	51
A.2 List of abbreviations .....	56
<b>Index.....</b>	<b>57</b>



# Description

## 1.1 General

### Overview

SIMODRIVE POSMO A is an intelligent distributed positioning drive on the PROFIBUS DP field bus (DP standard slave).

The power unit and all of the motion control are located in the motor.

All of the signals and data for commissioning and operating the drive are transferred via the PROFIBUS DP.

The operating energy is supplied by a 24 VDC connection (for a 75 W motor) or a 48 VDC connection (for a 300 W motor).

The integrated positioning functionality is suitable for a variety of simple single-axis applications, such as adjusting endstops and formats.

---

### Note

#### Hardware and software requirements

The following requirements apply for the functionalities described in this manual:

- Hardware release POSMO A 75 W: As of O
- Software release POSMO A 75 W: As of V3.0
- Hardware release POSMO A 300 W: As of G
- Software release POSMO A 300 W: As of V3.0

POSMO A positioning motors with different hardware and software requirements can be controlled with function blocks integrated in SIMOTION SCOUT V4.1. The functionality is restricted by the hardware/software release of the POSMO A positioning motor used.

---

### Requirement

The following software versions are required for the standard functions described in this documentation:

- SIMOTION SCOUT V4.1 or higher
- SIMOTION Kernel V4.1 or higher
- SIMOTION technology packages V4.1 or higher

### Communication

The PROFIBUS DP field bus allows rapid cyclical data exchange between the DP slave (POSMO A) and the higher-level DP master (SIMOTION hardware platform, such as SIMOTION C2xx).

## Description

### 1.1 General

## Further information

### Note

For more information, refer to the "Product brief" section of the *Distributed Positioning Motor on PROFIBUS DP* user manual.

This documentation is included in the SIMOTION SCOUT scope of delivery as electronic documentation!

## Installation and connection

For a description of how to install and connect a SIMODRIVE POSMO A and points you must be aware of when doing so, refer to the "Installation and connection" section of the *Distributed Positioning Motor on PROFIBUS DP* user manual. On the SIMOTION device (hardware platform), connect SIMODRIVE POSMO A to one of the PROFIBUS DP interfaces.

The following figure shows how to connect a SIMODRIVE POSMO A drive to a SIMOTION hardware platform (such as SIMOTION C2xx).




Figure 1-1 Connection of SIMODRIVE POSMO A to the SIMOTION C2xx hardware platform

## 1.2 Installation and startup

### Overview

You must perform the following steps to commission the SIMODRIVE POSMO A and control it from the SIMOTION system:

1. Mount and wire the SIMODRIVE POSMO A positioning motor.
2. Set the PROFIBUS DP node address on the connection cover of the SIMODRIVE POSMO A.
3. Switch on the terminating resistor at the first and last bus node.

---

#### Note

For steps 1 to 3, refer to *Section "Installation and Connection"* of the *Distributed Positioning Motor on PROFIBUS DP* user manual.

4. You can use any of the following to commission the SIMODRIVE POSMO A:
  - C1 master "SIMODRIVE POSMO A PROFIBUS MASTER"
  - Commissioning tool "SimoCom A"

---

#### Note

Refer to the *Distributed Positioning Motor on PROFIBUS DP* user manual, *Section "Commissioning of DP Master"*.

- 
- "Drive ES" tool. This tool includes "SimoCom A"
- 

#### Note

Refer to the *Drive ES Basic* function description.

5. Insert the SIMODRIVE POSMO A into the SIMOTION project (refer to *Section Inserting a SIMODRIVE POSMO A positioning motor into a SIMOTION project (Page 12)*).
6. Control the SIMODRIVE POSMO A from the SIMOTION system using function blocks, see *Section Function blocks (Page 15)*.

---

#### Note

Refer to the *Distributed Positioning Motor on PROFIBUS DP* user manual for more information on the following topics:

- Axis commissioning
- Communication via PROFIBUS DP
- Description of functions
- Error handling and diagnostics
- Assembly and service

## Description

---

### 1.3 Inserting a SIMODRIVE POSMO A positioning motor into a SIMOTION project

## 1.3 Inserting a SIMODRIVE POSMO A positioning motor into a SIMOTION project

### Requirement

The following requirements must be met:

1. You have created a project in SIMOTION SCOUT and have inserted a rack with a SIMOTION hardware platform in the hardware configuration.
2. You have configured a PROFIBUS subnet.

---

### Note

For information on creating a project and configuring a PROFIBUS subnet, refer to the online help for SIMOTION SCOUT.

---

### Inserting SIMODRIVE POSMO A

To integrate the SIMODRIVE POSMO A into the PROFIBUS subnet of your project, proceed as follows:

1. In SIMOTION SCOUT, open the **User Projects** dialog box with the **Project > Open** menu command. In this dialog box, select your project and confirm your choice with **OK**.
2. Open **HW Config** (by double-clicking the SIMOTION device in the project navigator of SIMOTION SCOUT).
3. In the **HW Config** window, open the **hardware catalog** with the **View > Catalog** menu command.
4. In the hardware catalog, open the **PROFIBUS DP** folder and the **SIMODRIVE** subfolder and select **SIMODRIVE POSMO A**.
5. Use a drag-and-drop operation to move the SIMODRIVE POSMO A onto the PROFIBUS subnet of your project.

The **Properties - PROFIBUS Interface SIMODRIVE POSMO A** dialog box is displayed. In this dialog box, you select the address you set in the connection cover of POSMO A (see *Section "Installation and Connection" of the Distributed Positioning Motor on PROFIBUS DP user manual*) and confirm with **OK**.

The SIMODRIVE POSMO A positioning motor you have selected is inserted into the project.

6. Input and output addresses of the POSMO A.

When you insert the POSMO A into your SIMOTION project, the input and output addresses are assigned default values. You can see these values when you select the inserted POSMO A. You can read the input and output addresses in the lower part of the **HW Config** window.

You must create these addresses as I/O variables in the symbol browser before calling the function blocks; see Section Creating I/O Variables (Page 14).

## 1.4 Integrating the function blocks in the user project

### Creating the instance of the FBs in the user project

The function blocks are part of the program library of the SIMOTION SCOUT engineering system. For working with the blocks, an instance has to be created in the user project for each function block used and if using the `_POSMOA_rwAllParameter` function block, a variable of type `Struct_POSMOA_params`.

**Example:**

```
VAR_GLOBAL
...
myPosmoAControl      : _POSMOA_control;           // FB for controlling of POSMO A
myPosmoArwParameter   : _POSMOA_rwParameter;        // FB for handling single parameter
myPosmoArwAllParameter : _POSMOA_rwAllParameter;     // FB for handling parameterset
myAllParaPosmoA       : Struct_POSMOA_params;       // Variable for structure of all
                                                       // parameters POSMO A
...
END_VAR
```

### Call (LAD representation)

The LAD representation of the individual function blocks can be found in the respective function block descriptions.

### Example of an application

The application example is contained on the "SIMOTION Utilities & Applications" CD-ROM and is available for various SIMOTION hardware platforms.

The "SIMOTION Utilities & Applications" CD-ROM is provided free of charge and part of the SIMOTION SCOUT scope of delivery.

## Description

### 1.5 Creating I/O Variables

## 1.5 Creating I/O Variables

### Overview

Communication between the SIMOTION hardware platform and the SIMODRIVE POSMO A takes place through direct access to the I/O. I/O variables are used to address the direct read/write access to the I/O.

You can freely assign the names of I/O variables in SIMOTION SCOUT. You must define the I/O variables as ARRAY [0..7] and [0..3] of BYTE. You assign the address settings in the hardware configuration to these I/O variables.

The names of the I/O inputs must be transferred to the function blocks as call parameters. The prepared data for the I/O outputs are provided by the function block as in/out parameters. The in/out parameters must be supplied with variables of type ARRAY [0..7] of BYTE and [0..3] of BYTE. Once the block has been called, these variables must be assigned to the I/O variables for the I/O outputs; see call example in Section Calling function blocks (Page 38).

---

### Note

The variable for supplying the in/out parameters must not be created as a temporary variable (VAR\_TEMP or local variable of a function).

---

The following example shows how to assign the module addresses to the I/O variables in SIMOTION SCOUT.

	Name	I/O address	Read only	Data type	Field length
1	[+] mypkwin	PIB 256		Array	8
2	[+] mypzdin	PIB 264		Array	4
3	[+] mypkwout	PQW 256	<input type="checkbox"/>	Array	8
4	[+] mypzdout	PQW 264	<input type="checkbox"/>	Array	4

Figure 1-2 Address assignment in SIMOTION SCOUT

Each input and output address has a range of 8 bytes (which corresponds to the parameter identifier value (PKW) range of POSMO A) and a range of 4 bytes (which corresponds to the process data (PZD) range of POSMO A).

---

### Note

For additional information, refer to:

- *SIMOTION SCOUT* online help
- Programming Manual of the corresponding programming language, e.g.:
  - *SIMOTION ST, Structured Text Programming Manual*
  - *SIMOTION MCC, Motion Control Chart Programming Manual*
  - *SIMOTION LAD/FBD, Ladder Diagram and Function Block Diagram Programming Manual*

These documents are shipped with SIMOTION SCOUT in electronic form!

---

# Function blocks

## 2.1 Overview of function blocks

This section contains a description of all of the function blocks (FBs) and the data structure you need for communication between a SIMOTION hardware platform and the SIMODRIVE POSMO A.

The function blocks form the software interface between the SIMOTION system and the SIMODRIVE POSMO A positioning motor.

These function blocks make it easier to control and assign parameters for a SIMODRIVE POSMO A positioning motor from the SIMOTION program.

For example, you can assign parameters for a POSMO A without being familiar with PROFIBUS parameter formats and request specifiers.

The function blocks must be called repeatedly (in cycles) from the user program.

The following function blocks are available:

- Function block `_POSMOA_control` (Page 16)
- Function block `_POSMOA_nControl` (Page 22) (V4.1 and higher):
- Function block `_POSMOA_rwParameter` (Page 28)
- Function block `_POSMOA_rwAllParameter` (Page 31)

---

### Note

For the complete control and communication of the SIMODRIVE POSMO A from the SIMOTION program, an instance must be created for each `_POSMOA_rwParameter` and `_POSMOA_rwAllParameter` function block and, depending on the parameterized operating mode (speed or position control mode), an instance of the `_POSMOA_control` or `_POSMOA_nControl` function block.

---

---

### Note

If the SIMODRIVE POSMO A is disconnected and then reconnected to the power system, any MDI traversing block data (see the table titled "Parameters of the `_POSMOA_control` function block") that had been transferred previously must be transferred to the POSMO A again.

---

## 2.2 Function block \_POSMOA\_control

### Task

You can control the connected SIMODRIVE POSMO A with the **\_POSMOA\_control** function block.

The functions are as follows:

- Initialize
  - Sets the drive in "ready to operate" mode.
- Requirements:
  - A drive fault has not been signaled (**driveError** = FALSE)
  - Fault acknowledgement is not active (**resetError** = FALSE)
- Referencing
  - Sets the home position for the drive.
- Tippen
  - The drive travels at a controlled speed in a plus or minus direction.
- Program execution
  - Starts, stops, or aborts a single block addressed by **blockNumber** or a block within the program.
- MDI
  - The drive travels at the assigned speed and acceleration to an assigned position.
  - The MDI parameters are transferred in block 3.
  - The MDI block can be started with **blockNumber** = 3 and **start** = TRUE.
- Fault acknowledgement
  - Acknowledges a fault in the drive.

---

### Note

A fault must be acknowledged before the drive can move. This requires that parameter **enable** = TRUE.

- 
- Automatic single-block operation/automatic control

Checkback signals are as follows:

- Current traversing block
- Data Set Ready
- Warning and fault information
- Complete status (status word and checkback signal byte)
- Data transfer status

### Call (LAD representation)

<u>_POSMOA_control</u>			
	EN <sup>1)</sup>	ENO <sup>1)</sup>	
ARRAY [0..7] of BYTE	pkwIn	ready	BOOL
ARRAY [0..3] of BYTE	pzdIn	active	BOOL
BOOL	enable	dataReady	BOOL
BOOL	homing	statusWord	WORD
BOOL	releaseBrake	actBlockNumber	BYTE
BOOL	jog1	statusInformation	BYTE
BOOL	jog2	error	BOOL
INT	jogOverride	errorID	WORD
BOOL	start	driveWarning	BOOL
BOOL	singleBlock	driveWarnId	WORD
BOOL	enableRdIn	driveWarnInfo	WORD
BOOL	extBlockChange	driveError	BOOL
BOOL	noStopIntermediate	driveErrorId	WORD
BOOL	noStop		
BOOL	resetError		
BYTE	blockNumber		
INT	veloOverride		
BYTE	setStartInformation		
BOOL	mdiMode		
INT	mdiVelocity		
INT	mdiAcceleration		
REAL	mdiPosition		
BOOL	reqControl		
BOOL	busy	busy	BOOL
ARRAY [0..7] of BYTE	pkwOut	pkwOut	ARRAY [0..7] of BYTE
ARRAY [0..3] of BYTE	pzdOut	pzdOut	ARRAY [0..3] of BYTE

1) LAD-specific parameters

### Parameter description

---

#### Note

The SIMOTION identifiers have changed as of V4.0.

You can find a comparison of SIMOTION and SIMATIC names in the Appendix SIMOTION and SIMATIC names (Page 51).

The **busy** parameter must **not** be overwritten by the user. It is supplied and checked by the function block, and must be supplied with a global variable created by the user only when the respective function block is called. This parameter coordinates the individual function blocks for the POSMO A. This ensures that no more than one function block can access a POSMO A at the same time.

---

## Function blocks

### 2.2 Function block \_POSMOA\_control

Table 2- 1 Parameters of the \_POSMOA\_control function block

Name	P type <sup>1)</sup>	Data type	Default	Meaning
<b>pkwIn</b>	IN	ARRAY [0..7] of BYTE	8(16#00)	Transfer I/O inputs of POSMO A to FB
<b>pzdIn</b>	IN	ARRAY [0..3] of BYTE	4(16#00)	Transfer I/O inputs of POSMO A to FB
<b>enable</b>	IN	BOOL	FALSE	Sets drive to ready for operation The drive is now ready for operation provided there are no faults.
<b>homing</b>	IN	BOOL	FALSE	Sets the home position This signal must be present for at least 50 ms.
<b>releaseBrake <sup>4)</sup></b>	IN	BOOL	FALSE	= TRUE: Release holding brake = FALSE: Brake sequence control effective
<b>jog1</b>	IN	BOOL	FALSE	Selection of jog 1 If jog 1 and 2 are set simultaneously, a warning is issued and the drive does not move.
<b>jog2</b>	IN	BOOL	FALSE	Selection of jog 2 If jog 1 and 2 are set simultaneously, a warning is issued and the drive does not move.
<b>jogOverride <sup>3)</sup></b>	IN	INT	20	Speed override of jogging (0 to 100%) The override can also be changed during travel.
<b>veloOverride <sup>3)</sup></b>	IN	INT	20	Velocity override (0 to 100%) This override can also be changed during travel.
<b>start</b>	IN	BOOL	FALSE	= edge FALSE → TRUE: The traversing block specified in <b>blockNumber</b> is started. Once a block has been selected in <b>blockNumber</b> , the <b>start</b> parameter cannot be set until the next block call.
<b>singleBlock<sup>4)</sup></b>	IN	BOOL	FALSE	= TRUE: Automatic single block. Each block has to be re-started. = FALSE: AUTOMATIC mode
<b>enableRdIn<sup>4)</sup></b>	IN	BOOL	TRUE	= TRUE: Read-in enable. Next block is enabled for execution. = FALSE: Read-in disable
<b>extBlockChange <sup>4)</sup></b>	IN	BOOL	FALSE	= Edge FALSE → TRUE: The active block is interrupted and the next block is selected. = FALSE: No external block change
<b>noStopIntermediate</b>	IN	BOOL	FALSE	= TRUE: No intermediate stop or block in intermediate stop is resumed = FALSE: Intermediate stop Interruption of current travel request <b>start</b> is not accepted
<b>noStop</b>	IN	BOOL	FALSE	= TRUE: No stop = FALSE: Stop Abort of current travel request If <b>start</b> parameter is set at the same time, <b>start</b> is not accepted.

Name	P type <sup>1)</sup>	Data type	Default	Meaning
<b>blockNumber</b>	IN	BYTE	16#00	Traversing block numbers 3 to 27 Single block or program <b>blockNumber</b> = 3 → MDI operation
<b>resetError</b>	IN	BOOL	FALSE	Acknowledges fault 1. Remedy cause of fault. 2. FALSE → TRUE edge 3. Parameter must remain set to TRUE until <b>driveError</b> = FALSE.
<b>setStartInformation</b>	IN	BYTE	16#00	Start byte Bit combination transmitted to the drive as an additional start requirement. <sup>2)</sup>
<b>mdiMode</b> <sup>3)</sup>	IN	BOOL	FALSE	= TRUE: MDI relative The value in the <b>mdiPosition</b> parameter is evaluated relative to the current position = FALSE: MDI absolute The value in the <b>mdiPosition</b> parameter is evaluated in absolute terms relative to the drive zero position set by homing.
<b>mdiVelocity</b> <sup>3)</sup>	IN	INT	0	Velocity of MDI travel (0 to 100%)
<b>mdiAcceleration</b> <sup>3)</sup>	IN	INT	0	Acceleration of MDI travel (0 to 100%)
<b>mdiPosition</b> <sup>3)</sup>	IN	REAL	0	Target position of MDI travel Value range: -2 • 10 <sup>5</sup> to 2 • 10 <sup>5</sup>
<b>reqControl</b> <sup>4)</sup>	IN	BOOL	FALSE	Control requested by the open-loop control p701 = 1: Message frame substitution active = TRUE: PROFIBUS data are taken over by the POSMO A = FALSE: Data from the PROFIBUS are frozen; the data last received are used p701 = 0: Message frame substitution inactive. Behavior as for POSMO A before software version V3.0
<b>pkwOut</b>	IN/OUT	ARRAY [0..7] of BYTE	-	Prepared FB data for I/O outputs of the POSMO A
<b>pzdOut</b>	IN/OUT	ARRAY [0..3] of BYTE	-	Prepared FB data for I/O outputs of the POSMO A
<b>busy</b>	IN/OUT	BOOL	-	Coordination of the FBs
<b>ready</b>	OUT	BOOL	FALSE	Drive ready for operation Logic operation: Status word bits 2 to 0 <sup>2)</sup>
<b>active</b>	OUT	BOOL	FALSE	= TRUE: Axis in motion
<b>dataReady</b> <sup>4)</sup>	OUT	BOOL	FALSE	Several cycles are required for the transfer , for example, of <b>mdiPosition</b> and <b>jogOverride</b> = TRUE: Data transfer completed (e.g. <b>mdiPosition</b> , <b>jogOverride</b> ,...) = FALSE: Data transfer in progress (ramp-up time) or data transfer not yet started
<b>statusWord</b>	OUT	WORD	16#0000	Read out of status word <sup>2)</sup>
<b>actBlockNumber</b>	OUT	BYTE	16#00	Readout of current block number

## Function blocks

### 2.2 Function block \_POSMOA\_control

Name	P type <sup>1)</sup>	Data type	Default	Meaning
statusInformation	OUT	BYTE	16#00	Checkback signal byte Bit combination as additional status signal. <sup>2)</sup>
driveWarning	OUT	BOOL	FALSE	A drive warning is pending (refer to parameter <b>driveWarnId</b> ).
driveWarnId	OUT	WORD	16#0000	Reason for the warning Bit format Value corresponds to parameter 953 (warnings) <sup>2)</sup>
driveWarnInfo <sup>4)</sup>	OUT	WORD	16#0000	Warnings or supplementary information, corresponds to p954 of the POSMO A
driveError	OUT	BOOL	FALSE	A drive error is pending (refer to the <b>driveErrorId</b> parameter)
driveErrorId	OUT	WORD	16#0000	Reason for the error Bit format Value corresponds to parameter 947 (errors) <sup>2)</sup>
error	OUT	BOOL	FALSE	= TRUE: Request completed with error (refer to the <b>errorID</b> parameter)
errorID	OUT	WORD	16#0000	Number of the parameter assignment error signaled by the drive (parameter identifier value (PKW) range) <sup>2)</sup>

<sup>1)</sup> Parameter types: IN = input parameter, OUT = output parameter, IN/OUT = in/out parameter

<sup>2)</sup> See *Distributed Positioning Motor on PROFIBUS DP* User manual

<sup>3)</sup> This parameter is only transferred when the value of the parameter changes.

<sup>4)</sup> As of SIMOTION V4.1, this parameter is part of the **\_POSMOA\_controlFB** and can only be operated with POSMO A as of software version V3.0.

## Message frame substitution (POSMO A as of software version V3.0)

For specific applications it is necessary that under no circumstances the drive comes undesirably to a standstill or the drive state can be configured to "freeze" to run-down the master (SIMOTION device).

The "Message frame substitution" function can be activated with the **reqControl** input parameter using software version V3.0 or higher of the POSMO A, with parameter **p701 = TRUE** set.

The process data sent by the SIMOTION device are taken over by the POSMO A with **reqControl = TRUE**. When the transition from **TRUE** to **FALSE** occurs on the **reqControl** input parameter, the POSMO A uses the process data received most recently (control word, block selection and start byte). If parameter **P701 = FALSE**, the status of the **reqControl** input parameter is not evaluated.

### Note

The "Message frame substitution" function takes immediate effect when **p701 = 1**.

Make sure that it is possible to shut down the drive at any time using an EMERGENCY STOP.

For additional information, refer to the SIMODRIVE POSMO A user manual, *Distributed Positioning Motor on PROFIBUS DP*.

## Task integration (call)

The **\_POSMOA\_control** function block must be called cyclically in the **BackgroundTask** or in the **TimerInterruptTask**. Calling in the **SystemInterruptTask** is not permitted. Calling the function block in synchronous tasks (e.g. **IPOSynchronousTask**) is not recommended for runtime reasons.

### Note

The functionality of the **\_POSMOA\_control** FB has been expanded with V4.1. To enable you to use the newly implemented functions, you must add the new input parameters when calling the **\_POSMOA\_control** FB. If you want to work with the previous functions (< V4.1), you can leave out the new input parameters with a detailed notation when calling the FB.

## Error messages, faults and warnings

The **TRUE** value at the **error** output parameter indicates a parameterization error. The **errorId** output parameter provides more detailed information on the parameterization error that has occurred or has been signaled by POSMO A. Parameterization errors do not need to be acknowledged. Changed parameters (e.g. ramp-up time) can be transferred again.

Faults on the POSMO A are signaled in the **driveError** output parameter with the value **TRUE**. The reason for the fault can be read out in the **driveErrorId** output parameter (value corresponds to P947). Drive faults have to be acknowledged and must be reset in the **resetError** input parameter with the rising edge!

Warnings pending from the POSMO A and the associated information are output in the **driveWarning**, **driveWarnId** (value corresponds to P953) and **driveWarnInfo** (value corresponds to P954) output parameters.

## 2.3 Function block \_POSMOA\_nControl

### Task

You can control the connected SIMODRIVE POSMO A in speed-controlled mode with the **\_POSMOA\_nControl** function block.

#### Note

The **\_POSMOA\_nControl** function block is contained in SIMOTION SCOUT as of V4.1. The technology objects (TOs) cannot be used to operate the POSMO A via the speed setpoint interface.

### Call (LAD representation)

_POSMOA_nControl	
EN 1)	ENO 1)
ARRAY [0..7] of BYTE	pkwIn
ARRAY [0..3] of BYTE	pzdIn
BOOL	init
BOOL	enable
BOOL	releaseBreak
DINT	accelTime
BOOL	releaseRamp
BOOL	startRamp
DINT	setpoint
BOOL	releaseSetpoint
BOOL	resetError
BOOL	reqControl
BOOL	busy
ARRAY [0..7] of BYTE	pkwOut
ARRAY [0..3] of BYTE	pzdOut
	busy
	pkwOut
	pzdOut

1) LAD-specific parameters

### Parameter description

#### Note

The **busy** parameter must **not** be overwritten by the user. It is supplied and checked by the function block, and must be supplied with a global variable created by the user only when the respective function block is called. This parameter coordinates the individual function blocks for the POSMO A. This ensures that no more than one function block can access a POSMO A at the same time.

Table 2- 2 Parameters of the \_POSMOA\_nControl function block

Name	P type <sup>1)</sup>	Data type	Default	Meaning
<b>pkwIn</b>	IN	ARRAY[0..7] of BYTE	8(16#00)	Transfer I/O inputs of POSMO A to _POSMOA_nControl FB
<b>pzdIn</b>	IN	ARRAY[0..3] of BYTE	4(16#00)	Transfer I/O inputs of POSMO A to FB
<b>init</b>	IN	BOOL	FALSE	= TRUE: Sets the drive to "Ready to start" STW = 0x040E
<b>enable</b>	IN	BOOL	FALSE	= TRUE: Sets the drive to "Ready for operation" The drive is now ready for operation (provided there are no errors).
<b>releaseBrake</b>	IN	BOOL	FALSE	= TRUE: Release holding brake = FALSE: Brake sequence control effective
<b>accelTime</b>	IN	DINT	0	Ramp-up/ramp-down time [ms] During this time, the setpoint is adjusted in speed-controlled mode as follows: <ul style="list-style-type: none"><li>• Ramp-up: From zero to the maximum permissible actual speed</li><li>• Ramp-down: From the maximum permissible actual speed to zero</li></ul>
<b>releaseRamp</b>	IN	BOOL	FALSE	= TRUE: Release ramp-function generator output
<b>startRamp</b>	IN	BOOL	FALSE	= Edge FALSE → TRUE: Start ramp-function generator
<b>setpoint</b>	IN	INT	0	Speed setpoint
<b>releaseSetpoint</b>	IN	BOOL	FALSE	Setpoint release = TRUE: Setpoint released
<b>resetError</b>	IN	BOOL	FALSE	Acknowledge error <ul style="list-style-type: none"><li>1. Remedy cause of error</li><li>2. FALSE → TRUE edge</li><li>3. Parameter must remain set to TRUE until <b>driveError</b> = FALSE.</li></ul>
<b>reqControl</b>	IN	BOOL	FALSE	Control requested by the open-loop control <p>p701 = 1: Message frame substitution active = TRUE: PROFIBUS data are taken over by the POSMO A = FALSE: Data from the PROFIBUS are frozen; the most recent data received are used</p> <p>p701 = 0: Message frame substitution inactive. Behavior as with POSMO A before software version V3.0</p>
<b>busy</b>	IN/OUT	BOOL	-	Coordination of the function blocks
<b>pkwOut</b>	IN/OUT	ARRAY[0..7] of BYTE	-	Prepared FB data for I/O outputs of the POSMO A (parameter identifier value interface)
<b>pzdOut</b>	IN/OUT	ARRAY[0..3] of BYTE	-	Prepared FB data for I/O outputs of the POSMO A (process data interface)
<b>ready</b>	OUT	BOOL	FALSE	Drive ready for operation, AND operation: Status word bit 2, bit 1, bit 0
<b>active</b>	OUT	BOOL	FALSE	= TRUE: Drive traveling (n > 0)

## Function blocks

### 2.3 Function block \_POSMOA\_nControl

Name	P type <sup>1)</sup>	Data type	Default	Meaning
<b>dataReady</b>	OUT	BOOL	FALSE	Several cycles are required for transferring the ramp-up time, for example. Completion of the data transfer is indicated by a rising edge. = TRUE: Data transfer finished, data have been transferred = FALSE: Data transfer in progress (e.g. ramp-up time)
<b>statusWord</b>	OUT	WORD	16#0000	Display of status word
<b>actValue</b>	OUT	DINT	0	Actual speed
<b>error</b>	OUT	BOOL	FALSE	= TRUE: Request completed with error (refer to the <b>errorID</b> parameter)
<b>errorID</b>	OUT	WORD	16#0000	Number of the parameter assignment error signaled by the drive (parameter identifier value (PKW) range) <sup>2)</sup>
<b>driveError</b>	OUT	BOOL	FALSE	Drive error is pending
<b>driveErrorId</b>	OUT	WORD	16#0000	Reason for the error Bit format Value corresponds to parameter 947 (errors) <sup>2)</sup>
<b>driveWarning</b>	OUT	BOOL	FALSE	A drive warning is pending (refer to parameter <b>driveWarnId</b> ).
<b>driveWarnId</b>	OUT	WORD	16#0000	Reason for the warning Bit format Value corresponds to parameter 953 (warnings) <sup>2)</sup>
<b>driveWarnInfo</b>	OUT	WORD	16#0000	Supplementary information for warnings (for POSMO A, firmware version 1.4 and higher) Bit format The value corresponds to P954, (supplementary information for warnings)

<sup>1)</sup> Parameter types: IN = input parameter, OUT = output parameter, IN/OUT = in/out parameter

<sup>2)</sup> See *Distributed Positioning Motor on PROFIBUS DP* User manual

## Function description

The POSMO A is set to the "ready to start" state (control word 0x040E) with the **TRUE** level on the **init** input parameter. The "ready to start" state is displayed in the output parameter **statusWord**, bit 0 = **TRUE**. When the transition from **FALSE** to **TRUE** level occurs at the input parameter **enable**, the drive is set to "ready for operation". The POSMO A changes to the "ready for operation" state, which can be read out on the output parameter **ready** = **TRUE**. Traversing is started when the input parameters **enableSetpoint** = **TRUE**, **enableRamp** = **TRUE**, (enable ramp-function generator) **execRamp** = **TRUE** (start ramp-function generator) with a positive edge, and **setpoint** > 0.

The order in which the input parameters **enable**, **enableSetpoint**, **enableRamp**, and **execRamp** are set for starting traversing is at the user's discretion. The input parameters specified above have equal status. Traversing stops when the input parameters **enable**, **enableSetpoint**, **enableRamp**, and **execRamp** are reset.

Transferring parameters (e.g. ramp-up time - input parameter **accelTime**) requires several task cycles. If a new value is parameterized at the **accelTime** input parameter, the output parameter **dataReady** is set to **FALSE**. Any pending parameter errors (output parameter **error** = **TRUE**) are reset. Data transfer is performed as soon as the in/out parameter **busy** = **FALSE**. If data transmission was active when the **accelTime** input parameter was newly parameterized (e.g. read parameter with **\_POSMOA\_rwParameter** FB), data transfer is suspended until **busy** = **FALSE**. The value which was parameterized when **busy** = **TRUE** changed to **busy** = **FALSE** at the input parameter **accelTime** is transferred. Completion of data transfer is displayed with a rising edge at the output parameter **dataReady** and stays at **TRUE** until the next data transfer is started.

## Message frame substitution (POSMO A, software version V3.0 and higher)

With certain applications, it is essential that the drive be prevented from coming to an undesirable standstill under all circumstances, or that "freezing" of the drive status can be configured for the purpose of shutting down the master (SIMOTION device).

The "Message frame substitution" function can be activated with the **reqControl** input parameter as of software version V3.0 of the POSMO A with set parameter **p701** = **TRUE**.

The process data sent by the SIMOTION device are taken over by the POSMO A with **reqControl** = **TRUE**. With the transition from **TRUE** to **FALSE** on the **reqControl** input parameter, the POSMO A uses the process data received last (control word, block selection and start byte). If parameter **P701** = **FALSE**, the status of the **reqControl** input parameter is not evaluated.

---

### Note

The "Message frame substitution" function takes effect immediately with **p701** = 1!

Make sure that the drive can be shut down at any time by an EMERGENCY STOP.

For more information, refer to the SIMODRIVE POSMO A user manual, *Distributed Positioning Motor on PROFIBUS DP*.

---

## Function blocks

### 2.3 Function block \_POSMOA\_nControl

#### Graphical overview of the functionality




Figure 2-1 Signal propagation diagram

## Task integration (call)

The \_POSMOA\_nControl function block must be called cyclically in the **BackgroundTask** or in the **TimerInterruptTask**. Calling in the **SystemInterruptTask** is not permitted. Calling the function block in synchronous tasks (e.g. **IPOSynchronousTask**) is not recommended for runtime reasons.

## Error messages, errors, and warnings

The **TRUE** value at the **error** output parameter indicates a parameterization error. The **errorID** output parameter provides more detailed information on the parameterization error that has occurred. Parameterization errors do not need to be acknowledged. Parameters that have been changed (e.g. ramp-up time) can be transferred again.

Errors in the POSMO A are signaled in the **driveError** output parameter with the value **TRUE**. The reason for the error can be read out in the **driveErrorId** output parameter (value corresponds to P947). Drive errors have to be acknowledged and must be reset in the **resetError** input parameter with a rising edge.

Warnings from the POSMO A that are pending, and their associated information, are output in the **driveWarning**, **driveWarnId** (value corresponds to P953), and **driveWarnInfo** (value corresponds to P954) output parameters.

## 2.4 Function block \_POSMOA\_rwParameter

### Task

The **\_POSMOA\_rwParameter** function block enables parameters to be assigned for the connected SIMODRIVE POSMO A.

The functions are as follows:


- Reading a parameter: Provides the value of the specified parameter.
- Writing a parameter value: Sets the specified parameter to the specified value.
- Loading factory settings: Resets the parameter configuration to the factory settings.
- Saving a parameter: Saves the current parameter configuration in non-volatile memory.

The following parameters can be read/written with this function block:

Parameter numbers	Read from POSMO A	Write to POSMO A (positioning mode)	Write to POSMO A (speed-controlled mode)
1...5	Yes	Yes	Yes
6...7	Yes	Yes	No
9...23	Yes	Yes	Yes
24	Yes	Yes	No
25...38	Yes	Yes	Yes
39...53	Yes	No	No
54	Yes	Yes	Yes
55	Yes	No	No
56...61	Yes	Yes	Yes
62	Yes	No	No
80:28...87:28	Yes	Yes	Yes
99:21	Yes	Yes	Yes
100	Yes	Yes	No
101:11	Yes	Yes	No
700 <sup>1)</sup>	Yes	Yes	Yes
701 <sup>1)</sup>	Yes	Yes	Yes
880 <sup>1)</sup>	Yes	Yes	Yes
918...928	No	No	No
930	Yes	No	No
947...954	No	No	No
964:8	Yes	No	No
967...990:78	No	No	No
1426 <sup>1)</sup>	Yes	Yes	Yes
1427 <sup>1)</sup>	Yes	Yes	Yes

<sup>1)</sup> This parameter is new or extended with SIMOTION V4.1.

## Call (LAD representation)



<sup>1)</sup> LAD-specific parameters

## Parameter description

### Note

The SIMOTION identifiers have changed as of V4.0.

You can find a comparison of SIMOTION and SIMATIC names in the Appendix SIMOTION and SIMATIC names (Page 51).

The **busy** parameter must **not** be overwritten by the user. It is supplied and checked by the function block, and must be supplied with a global variable created by the user only when the respective function block is called. This parameter coordinates the individual function blocks for the POSMO A. This ensures that no more than one function block can access a POSMO A at the same time.

## Function blocks

### 2.4 Function block \_POSMOA\_rwParameter

Table 2- 3 Parameters of the \_POSMOA\_rwParameter function block

Name	P type 1)	Data type	Default	Meaning
<b>pkwIn</b>	IN	ARRAY [0..7] of BYTE	8(16#00)	Transfer I/O inputs of POSMO A to FB
<b>paraNumber</b>	IN	UINT	0	Parameter number to be read or written
<b>subindex</b>	IN	USINT	0	Subindex = 0 for parameters with no index This value is the array index for parameters with an array. <sup>2)</sup>
<b>enableRead</b>	IN	BOOL	FALSE	= TRUE: Reads parameter cyclically = edge FALSE → TRUE: Reads parameter one time
<b>execWrite</b>	IN	BOOL	FALSE	= edge FALSE → TRUE: Writes parameter When set simultaneously with <b>enableRead</b> , read is executed.
<b>setDefault</b>	IN	BOOL	FALSE	= edge FALSE → TRUE: Loads factory settings When set simultaneously with <b>enableRead</b> , read is executed.
<b>saveParameter</b>	IN	BOOL	FALSE	= edge FALSE → TRUE: Saves parameter When set simultaneously with <b>enableRead</b> , read is executed.
<b>pkwOut</b>	IN/OUT	ARRAY [0..7] of BYTE	-	Prepared FB data transferred to the I/O outputs of the POSMO A
<b>busy</b>	IN/OUT	BOOL	-	Coordination of the FBs
<b>realValue</b>	IN/OUT	REAL	-	Write → value to be written (data types C4 and N2) <sup>2)</sup> Read → value to be read (data types C4 and N2) <sup>2)</sup>
<b>dintValue</b>	IN/OUT	DINT	-	Write → value to be written (data types I2, T2, V2 and T4) <sup>2)</sup> Read → value to be read (data types I2, T2, V2 and T4) <sup>2)</sup>
<b>done</b>	OUT	BOOL	FALSE	= TRUE: When current request has been completed = FALSE: There is no request pending, or a request is being executed.
<b>error</b>	OUT	BOOL	FALSE	= TRUE: Request completed with error (refer to the <b>errorID</b> parameter)
<b>errorID</b>	OUT	WORD	16#0000	Number of the parameter assignment error signaled by the drive (parameter identifier value (PKW) range) <sup>2)</sup>

<sup>1)</sup> Parameter types: IN = input parameter, OUT = output parameter, IN/OUT = in/out parameter

<sup>2)</sup> See *Distributed Positioning Motor on PROFIBUS DP* User manual

### Task integration (call)

The **\_POSMOA\_rwParameter** function block must be called cyclically in the **BackgroundTask** or in the **TimerInterruptTask**. Calling in the **SystemInterruptTask** is not permitted. Calling the function block in synchronous tasks (e.g. **IPOSynchronousTask**) is not recommended for runtime reasons.

### Fault messages

The **TRUE** value at the **error** output parameter indicates a parameterization error. The **errorID** output parameter provides more detailed information on the parameterization error that has occurred or has been signaled by POSMO A. Parameterization errors do not need to be acknowledged. Changed parameters (e.g. ramp-up time) can be transferred again.

## 2.5 Function block \_POSMOA\_rwAllParameter

### Task

The **\_POSMOA\_rwAllParameter** function block enables reading and writing of the parameter block of the connected SIMODRIVE POSMO A.


The data to be read or written are saved in a variable created by the user with the **Struct\_POSMOA\_params** data structure when the associated function block instance is called.

The following parameters are read/written with this function block:

Parameter numbers	Read from POSMO A	Write to POSMO A (positioning mode)	Write to POSMO A (speed-controlled mode)
1...5	Yes	Yes	Yes
6...7	Yes	Yes	No
9...23	Yes	Yes	Yes
24	Yes	Yes	No
25...38	Yes	Yes	Yes
39...53	Yes	No	No
54	Yes	Yes	Yes
55	Yes	No	No
56...61	Yes	Yes	Yes
62	Yes	No	No
80:28...87:28	Yes	Yes	Yes
99:21	Yes	Yes	Yes
100	Yes	Yes	No
101:11	Yes	Yes	No
700 <sup>1)</sup>	Yes	Yes	Yes
701 <sup>1)</sup>	Yes	Yes	Yes
880 <sup>1)</sup>	Yes	Yes	Yes
918...928	No	No	No
930	Yes	No	No
947...954	No	No	No
964:8	Yes	No	No
967...990:116	No	No	No
1426 <sup>1)</sup>	Yes	Yes	Yes
1427 <sup>1)</sup>	Yes	Yes	Yes

<sup>1)</sup> This parameter is new or extended with SIMOTION V4.1.

## Call (LAD representation)



1) LAD-specific parameters

## Parameter description

## Note

The SIMOTION identifiers have changed as of V4.0.

You can find a comparison of SIMOTION and SIMATIC names in the Appendix SIMOTION and SIMATIC names (Page 51).

The **busy** parameter must **not** be overwritten by the user. It is supplied and checked by the function block, and must be supplied with a global variable created by the user only when the respective function block is called. This parameter coordinates the individual function blocks for the POSMO A. This ensures that no more than one function block can access a POSMO A at the same time.

Table 2- 4 Parameters of the \_POSMOA\_rwAllParameter function block

Name	P type 1)	Data type	Default	Meaning
<b>pkwIn</b>	IN	ARRAY [0..7] of BYTE	8(16#00)	Transfer I/O inputs of POSMO A to FB
<b>execRead</b>	IN	BOOL	FALSE	= edge FALSE → TRUE: Reads all data one time The start takes place on a positive edge.
<b>execWrite</b>	IN	BOOL	FALSE	= edge FALSE → TRUE: Writes all data one time The start takes place on a positive edge.
<b>posMode</b> <sup>3)</sup>	IN	BOOL	TRUE	= TRUE: Positioning mode of the POSMO A = FALSE: Speed-controlled mode
<b>pkwOut</b>	IN/OUT	ARRAY [0..7] of BYTE	-	Prepared FB data for I/O outputs of the POSMO A
<b>allParaPosmoA</b>	IN/OUT	Struct_POSMOA_params	-	Data structure for all parameters of the POSMO A
<b>busy</b>	IN/OUT	BOOL	-	Coordination of the FBs
<b>done</b>	OUT	BOOL	FALSE	= TRUE: When current request has been completed = FALSE: There is no request pending, or a request is being executed.
<b>error</b>	OUT	BOOL	FALSE	= TRUE: Request completed with error (refer to the <b>errorID</b> parameter)
<b>errorID</b>	OUT	WORD	16#0000	Number of the parameter assignment error signaled by the drive (parameter identifier value (PKW) range) <sup>2)</sup>
<b>errorParaNumber</b>	OUT	INT	0	Number of the parameter that caused the error <sup>2)</sup>

<sup>1)</sup> Parameter types: IN = input parameter, OUT = output parameter, IN/OUT = in/out parameter

<sup>2)</sup> See *Distributed Positioning Motor on PROFIBUS DPUser manual*

<sup>3)</sup> As of SIMOTION V4.1, this parameter is part of the **\_POSMOA\_rwAllParameter** FB and can only be operated with POSMO A software version 3.0 and higher.

### Data structure of Struct\_POSMOA\_params

The data structure of type **Struct\_POSMOA\_params** contains all of the parameters for controlling the SIMODRIVE POSMO A.

This data structure is used by the **\_POSMOA\_rwAllParameter** function block. Self-defined variables of data type **Struct\_POSMOA\_params** are used to access data structure elements.

The following table contains the **Struct\_POSMOA\_params** data structure.

---

#### Note

The SIMOTION identifiers have changed as of V4.0.

You can find a comparison of SIMOTION and SIMATIC names in the Appendix SIMOTION and SIMATIC names (Page 51).

---

## Function blocks

### 2.5 Function block \_POSMOA\_rwAllParameter

Table 2- 5 Data structure of Struct\_POSMOA\_params

Name	Type	Initial value	Comment	r/w <sup>1)</sup>
p1	REAL	0.0	Linear/rotary axis	r/w
p2	REAL	10.0	Travel per gear revolution	r/w
p3	REAL	1.0	Gear reduction factor	r/w
p4	INT	0	Unit of measure	r/w
p5	REAL	0.0	Position at home position	r/w
p6	REAL	-200000.0	Start of software limit switch	r/w
p7	REAL	200000.0	End of software limit switch	r/w
p8	REAL	3000.0	Maximum rotation speed	r/w
p9	INT	10	Rampup time	r/w
p10	DINT	30000	Maximum velocity	r/w
p11	REAL	2.0	Target area	r/w
p12	REAL	20000.0	Maximum following error	r/w
p13	DINT	50	Monitoring time	r/w
p14	REAL	20000.0	Zero speed area	r/w
p15	REAL	0.0	Backlash on reversal compensation	r/w
p16	REAL	9.0	Maximum overcurrent	r/w
p17	DINT	20	P-gain of speed controller	r/w
p18	INT	22	Integral time of speed controller	r/w
p19	REAL	1.0	K <sub>v</sub> factor	r/w
p20	REAL	30.0	Current setpoint smoothing	r/w
p21	REAL	2.0	Rotation speed setpoint smoothing	r/w
p22	REAL	1000.0	Maximum acceleration	r/w
p23	DINT	0	Jerk time constant	r/w
p24	INT	100	Override	r/w
p25	INT	100	Acceleration override	r/w
p26	INT	20	Rotation speed override for jogging	r/w
p27	INT	50	Acceleration override for jogging	r/w
p28	REAL	9.0	Maximum current	r/w
p29	DINT	12000	Electronics temperature tolerance time	r/w
p30	INT	0	Interference suppression	r/w
p31	INT	0	Terminal 1 function	r/w
p32	INT	0	Terminal 2 function	r/w
p33	DINT	0	Address for measurement output 1	r/w
p34	INT	7	Shift factor for measurement output 1	r/w
p35	INT	128	Offset for measurement output 1	r/w
p36	DINT	0	Address for measurement output 2	r/w
p37	INT	0	Shift factor for measurement output 2	r/w
p38	INT	128	Offset for measurement output 2	r/w
p39	REAL	0.0	Position reference value	r
p40	REAL	0.0	Actual position value	r
p41	REAL	0.0	Speed setpoint	r

Name	Type	Initial value	Comment	r/w <sup>1)</sup>
p42	REAL	0.0	Actual speed	r
p43	REAL	0.0	Current setpoint	r
p44	REAL	0.0	Actual current value	r
p45	DINT	0	Timer status	r
p46	REAL	0.0	Following error	r
p47	REAL	0.0	Electronics temperature	r
p48	INT	0	Current traversing block number	r
p49	INT	0	Subsequent block number	r
p50	DINT	0	Speed setpoint	r
p51	DINT	0	Actual velocity value	r
p52	DINT	0	HW version	r
p53	DINT	0	Firmware version	r
p54	DINT	5	P-gain of speed controller zero speed	r/w
p55	REAL	0.0	Signal position	r
p56	INT	0	Operating position	r/w
p57	DINT	20	P-gain of stop controller zero speed (HW Version F and higher)	r/w
p58	DINT	100	Holding brake release time	r/w
p59	REAL	10.0	Holding brake closure speed	r/w
p60	DINT	400	Holding brake deceleration time	r/w
p61	DINT	100	Holding brake controller disable time	r/w
p62	REAL	0.0	Measuring position	r
p80	ARRAY[0..27] of Array_POSMOA_prgCtrlInfo		Traversing blocks 1 to 27 see Table "Structure of Array_POSMOA_prgCtrlInfo"	r/w
p81	ARRAY[0..27] of REAL	28(0.0)	Target position for traversing blocks 1 to 27	r/w
p82	ARRAY[0..27] of INT	28(100)	Velocity or speed for traversing blocks 1 to 27	r/w
p83	ARRAY[0..27] of INT	28(100)	Acceleration for traversing blocks 1 to 27	r/w
p84	ARRAY[0..27] of DINT	28(0)	Timer value for traversing blocks 1 to 27	r/w
p85	ARRAY[0..27] of REAL	28(0.0)	Signaling position for traversing blocks 1 to 27	r/w
p86	ARRAY[0..27] of INT	28(0)	SMStart MMStart for traversing blocks 1 to 27	r/w
p87	ARRAY[0..27] of INT	28(0)	MMStop MMPos for traversing blocks 1 to 27	r/w
p99	ARRAY[0..20] of INT	13,18,23,0,0,0,0,0, 0,0,0,0,0,0,0,0,0,0,0,0	Program management (see <i>Distributed Positioning Motor on PROFIBUS DP</i> user manual)	r/w
p100	INT	0	Control word simulation	r/w
p101	ARRAY[0..10] of INT	10(0)	Blocks 1 to 10 of the data structure for the POSMO A parameters	r/w
p700 <sup>2)</sup>	INT	2	Operating mode 1 = speed-controlled mode 2 = positioning mode	r/w
p701 <sup>2)</sup>	INT	0	Message frame substitution	r/w
p880 <sup>2)</sup>	REAL	4096	Normalizing of the speed at the gear output when a setpoint of 4096 decimal is specified via the control word (STW)	r/w

## Function blocks

### 2.5 Function block \_POSMOA\_rwAllParameter

Name	Type	Initial value	Comment	r/w <sup>1)</sup>
p930	INT	0	Current mode 1 = speed-controlled mode 2 = positioning mode	r
p964	ARRAY[0..7] of INT	8(0)	Drive identification	r
p1426 <sup>2)</sup>	REAL	100	Tolerance band for actual speed value	r/w
p1427 <sup>2)</sup>	INT	0	Delay time for "Ramp-up completed" signal	r/w

<sup>1)</sup> r - read, w - write

<sup>2)</sup> This parameter is new or extended with SIMOTION V4.1.

### Structure of "Array\_POSMOA\_prgCtrlInfo"

"Array\_POSMOA\_prgCtrlInfo" contains the program control word. Here, you can define the behavior of a traversing block (see *Distributed Positioning Motor on PROFIBUS DP user manual*).

Table 2- 6 Structure of Array\_POSMOA\_prgCtrlInfo

Array element	Data type	Initial value	Comment
0	BOOL	TRUE	Type of motion
1	BOOL	TRUE	Type of positioning
2	BOOL	FALSE	Type of timer
3	BOOL	FALSE	Connection between timer and start byte
4	BOOL	FALSE	Program return
5	BOOL	FALSE	Type of traversing
6	BOOL	FALSE	Invert start byte condition
7	BOOL	FALSE	SM start type
8	BOOL	FALSE	Program stop
9	BOOL	FALSE	Set actual value

### Task integration (call)

The **\_POSMOA\_rwAllParameter** function block must be called cyclically in the **BackgroundTask** or in the **TimerInterruptTask**. Calling in the **SystemInterruptTask** is not permitted. Calling the function block in synchronous tasks (e.g. **IPOSynchronousTask**) is not recommended for runtime reasons.

---

#### Note

The functionality of the **\_POSMOA\_rwAllParameter** FB has been expanded with V4.1. To enable you to use the newly implemented functionality, you must add the new **posMode** input parameter when calling the **\_POSMOA\_rwAllParameter** FB.

If you want to work with the previous functionality (< V4.1), you can leave out the new input parameter with a detailed notation when calling the FB.

---

### Fault messages

The **TRUE** value at the **error** output parameter indicates a parameterization error. The **errorID** output parameter contains more detailed information on the parameterization error that has occurred or has been signaled by POSMO A. The **errorParaNumber** output parameter supplies the number of the parameter that has caused the error.

Parameterization errors do not need to be acknowledged. Changed parameters (e.g. ramp-up time) can be transferred again.

## 2.6 Calling function blocks

In order to be able to work with the function blocks in your user program, proceed as follows (The numbers shown in the following program segment correspond to the steps below.):

1. Create the function block instances (see the following program segment, e.g. create instance for the **\_POSMOA\_control** function block).
2. Create a variable for the data structure (for FB **\_POSMOA\_rwAllParameter** only).
3. Create an array for the in/out parameters of the FB.
4. Call instance of the function block.
5. Transfer input parameters.
6. The output parameters of the FB are accessed with <instance name of FB>. <name of output parameter>.
7. Data prepared by the FB for the I/O outputs are assigned to the I/O variables from the array created in step 3 (see the following program segment).

---

### Note

If you want to control more than one SIMODRIVE POSMO A, you must create a new variable for the data structure (FB **\_POSMOA\_rwAllParameter**) and FB instances with new names for each POSMO A you use.

---

## Call example

```

UNIT E_posmoA;
INTERFACE

// Definition of global variables for demo program
VAR_GLOBAL
    myPosmoAControl : _POSMOA_control;      // create "_POSMOA_control" instance (1)
    myEnable         : BOOL;                  // enable posmoA
    myHoming         : BOOL;                  // homing posmoA
    myJogPositive   : BOOL;                  // jog positive posmoA
    myJogNegative   : BOOL;                  // jog negative posmoA
    myBusy           : BOOL;                  // coordination bit
    myError          : BOOL;                  // variable created by user for accessing
                                              // an output variable of the function block
END_VAR

PROGRAM ExamplePosmoA;                      // Program of BackgroundTask
END_INTERFACE
IMPLEMENTATION

PROGRAM ExamplePosmoA                      // Program of BackgroundTask
VAR
    // temporary array for outputs of FBs
    tmpPkwOutput : ARRAY[0..7] of BYTE;
    tmpPzdOutput : ARRAY[0..3] of BYTE;
END_VAR

// INSTANCE CALL of FB _POSMOA_control        (4)
myPosmoAControl (  pkwIn      := myPkwIn,      (5)
                    pzdIn      := myPzdIn,
                    enable     := myEnable,
                    homing    := myHoming,
                    jog1      := myJogNegative,
                    jog2      := myJogPositive,
                    busy      := myBusy,
                    pkwOut    := tmpPkwOutput,
                    pzdOut    := tmpPzdOutput
);
// an output variable in the "_POSMOA_control" function block is assigned to a (6)
// "myError" variable created by the user.
myError := myPosmoAControl.error;

// Assignment of intermediate buffer byte arrays to I/O addresses
myPkwOut := tmpPkwOutput;                   (7)
myPzdOut := tmpPzdOutput;

END_PROGRAM                                // ExamplePosmoA
END_IMPLEMENTATION

```

---

### Note

The ExamplePosmoA program must be assigned in the execution system.

---



# Application example

## 3.1 General information on the application example

### Task

The application example shows how POSMO A can be controlled with the help of the function blocks and how POSMO A drive parameters can be read and written.

There is a command interface **enumCommands** for starting the desired action, e.g. jogging.

The **Struct\_checkbacks** data structure shows the status of the actions and additional information.

The following operating modes and functionalities are implemented:

- Homing
  - Option: "Approach using visual axis marking and assign actual value"
- Jogging
  - Move in positive or negative direction
- MDI
  - Travel to the required position
- Parameter handling
  - Write or read individual parameters
  - Save all parameters in the EEPROM of the POSMO A
- Read out current actual position
- The current actual position of the POSMO A is read cyclically in jog mode and in MDI and stored in a variable.

### Hardware platform

The application example is available for various SIMOTION hardware platforms.

---

#### Note

If the application example is not available for your SIMOTION hardware platform, you must adapt the hardware configuration.

---

## *Application example*

---

### *3.1 General information on the application example*

#### **Adapting the application example**

The configuration in the example and its available hardware must be adapted.

The following options are available:

1. The configuration in the example can be adapted to suit the available hardware (commission drive, PROFIBUS DP address).
2. The hardware configuration can be adapted to the example (commission drive, PROFIBUS DP address).

---

#### **Note**

Please observe the drive documentation when commissioning the drive.

This documentation is included in the SIMOTION SCOUT scope of delivery in electronic format.

---

#### **Calling the application example**

The application example can be found on the "SIMOTION Utilities & Applications" CD-ROM. The "SIMOTION Utilities & Applications" CD-ROM is provided free of charge and part of the SIMOTION SCOUT scope of delivery.

1. De-archive and open the project containing the application example.
2. Check the hardware configuration: PROFIBUS DP addresses.
3. Save and compile the example project. You can then download the example to the SIMOTION device and switch to **RUN** mode.

Additional handling steps for the example are carried out using the Enums in the symbol browser within the **myCommand** structure. This requires that the "E\_posmoA" element be selected from the **Programs** container in the project navigator. Values from the "Control value" column are assigned to the corresponding variables by clicking **Immediate control**.

#### **Error messages**

Pending errors and warnings (for example, reading during jogging or of individual parameter) are displayed in the following variables:

- myCheckbacks.error = TRUE  
An error has occurred (request canceled; a POSMO A error is pending).
- myCheckbacks.ctrlErrorID  
Error specification of the **\_POSMOA\_control** function block. Number of the parameter assignment error signaled by POSMO A.
- myCheckbacks.driveErrorID  
Error specification of POSMO A  
Reason for an error signaled by POSMO A
- myCheckbacks.rwErrorID  
Error specification of the **\_POSMOA\_rwParameter** function block. Error has occurred during reading or writing.
- myCheckbacks.driveWarning = TRUE  
POSMO A warning is pending.
- myCheckbacks.driveWarningID = TRUE  
Warning number of an alarm signaled by POSMO A.

## 3.2 Operator control and monitoring of the application example in the detail view

POSMO A will be automatically initialized when your SIMOTION hardware platform changes from STOP to RUN mode. The POSMO A provides feedback that the drive is ready to operate with the following variable:

- myCheckbacks.driveReady = TRUE

### Select operating mode

You can choose between "Jog", "Homing", "MDI", or "Parameter handling" modes. This is done via the **myCommand** variable.

#### "Jog" mode

In the "Jog" mode, the POSMO A can be moved in positive and negative direction. "Jogging" is implemented with the following parameter settings on the instance created of the \_POSMOA\_control function block:

- jogOverride = 100
- veloOverride = 100
- noStopIntermediate = TRUE                              No intermediate stop
- noStop = TRUE    No stop

In the "Control value" column of the symbol browser, select the check boxes for the following variables and select the values to be assigned.

- myCommand = START\_JOG\_POSITIVE                      Jogging in positive direction
- myCommand = START\_JOG\_NEGATIVE                      Jogging in negative direction

Clicking on **Immediate control** assigns the value to the variable, and the POSMO A is moved in the respective direction.

The current "Jog" state can be read in the symbol browser as follows:

- myCheckbacks.actCommand = JOG\_POSITIVE\_ACTIVE  
Jogging in positive direction activated
- myCheckbacks.actCommand = JOG\_NEGATIVE\_ACTIVE  
Jogging in negative direction activated
- myCheckbacks.jogPositiveBusy = TRUE  
POSMO A moves in position direction
- myCheckbacks.jogNegativeBusy = TRUE  
POSMO A moves in negative direction

The current actual position of POSMO A can be read in the symbol browser in the **myCheckbacks.actPosition** variable.

---

#### Note

The "Jog" mode may be terminated only after the POSMO A is stopped (myCommand = STOP)!

---

## *Application example*

---

### *3.2 Operator control and monitoring of the application example in the detail view*

#### **"Homing" mode**

The "approach using visual axis marking and assign actual value" options have been implemented. For homing, POSMO A must be switched to closed-loop control and zero speed. The actual value (parameter 40 of POSMO A) can be set via the "Parameter handling", write individual parameter operating mode.

In the "Control value" column of the symbol browser, select the check boxes for the following variables and select the values to be assigned.

- myCommand = START\_HOMING

Clicking **Immediate control** assigns the value to the variable, and the POSMO A is homed to the value set in parameter 40 of POSMO A.

---

#### **Note**

For more information on the homing of the POSMO A, refer to the *Distributed Positioning Motor on PROFIBUS DP* user manual.

This documentation is included in the SIMOTION SCOUT scope of delivery as electronic documentation!

---

The current "Homing" state can be read in the symbol browser as follows:

- myCheckbacks.actCommand = HOMING\_ACTIVE  
Homing activated
- myCheckbacks.actCommand = NO\_COMMAND\_ACTIVE  
myCheckbacks.done = TRUE  
Homing completed without error

## "MDI" mode

**Requirement:** The POSMO A is homed!

In the "MDI" mode, one MDI block absolute can be moved.

"Jogging" of the MDI block is implemented with the following parameter settings on the instance created of the `_POSMOA_control` function block:

- `mdiMode = FALSE` MDI absolute
- `mdiVelocity = 100`
- `mdiAcceleration = 100`
- `veloOverride = 100`
- `noStopIntermediate = TRUE` No intermediate stop
- `noStop = TRUE` No stop

The target position of the MDI block is specified in the `myAbsolutePosition` variable.

In the "Control value" column of the symbol browser, select the check boxes for the following variables and select the values to be assigned.

- `myCommand = START_MDI_BLOCK_ABSOLUTE`
- `myAbsolutePosition = ...` The target position of the MDI block is specified here.  
(Default = 0.0)

Clicking on **Immediate control** assigns the values to the variables, and the POSMO A moves the MDI block absolute.

The current state of the "MDI" mode can be read in the symbol browser as follows:

- `myCheckbacks.actCommand = MDI_BLOCK_ACTIVE`  
Move MDI block absolute activated
- `myCheckbacks.actCommand = NO_COMMAND_ACTIVE`
- `myCheckbacks.done = TRUE`
- `myCheckbacks.positionReached = TRUE`  
MDI block traversed without error

The current actual position of POSMO A can be read in the symbol browser, from the `myCheckbacks.actPosition` variable.

---

### Note

The "MDI" mode may be terminated only after the POSMO A is stopped (`myCommand = STOP`)!

---

### "Parameter handling" mode

In the "Parameter handling" mode you can read and write individual parameters and save all parameters in the EEPROM of POSMO A.

#### Read individual parameter

In the **myRdParaNumber** variable you state the parameter you want to read. In the **myRdSubIndex** variable, you state the subindex for the parameter you wish to read (indexed parameters only). In the "Control value" column of the symbol browser, select the check boxes for the following variables and select the values to be assigned.

- myCommand = READ\_ONE\_PARAMETER  
    Read individual parameter
- myRdParaNumber = ...  
    You state the number of the parameter to be read here.
- myRdSubIndex = ...  
    You state the subindex of the parameter to be read here (for indexed parameters only)

The value read is saved in the **myReadValue** variable.

#### Write individual parameter

In the **myWrParaNumber** variable you state the parameter you want to write. In the **myWrSubIndex** variable, you state the subindex for the parameter you wish to write (indexed parameters only). In the **myWrRealValue** variable (data types C4 and N2)<sup>2)</sup> or **myWrDintValue** (data types I2, T2, V2, and T4)<sup>2)</sup>, you state the value for the parameter to be written. In the "Control value" column of the symbol browser, select both the check boxes for the following variables and the values to be assigned.

- myCommand = WRITE\_ONE\_PARAMETER  
    Write individual parameter
- myWrParaNumber = ...  
    You state the number of the parameter to be written here.
- myWrSubIndex = ...  
    You state the subindex of the parameter to be written here (for indexed parameters only)
- myWrRealValue = ...  
    You state the value of the parameter to be written here (data types C4 and N2)<sup>2)</sup>.
- myWrDintValue = ...  
    Here, you state the value of the parameter to be written (data types I2, T2, V2, and T4)<sup>2)</sup>.

<sup>2)</sup> Refer to the *Distributed Positioning Motor on PROFIBUS DP* user manual.

This documentation is included in the SIMOTION SCOUT scope of delivery as electronic documentation!

### Saving all parameters in the EEPROM

In the "Control value" column of the symbol browser, select the check boxes for the following variables and select the values to be assigned.

Clicking **Immediate control** assigns the value to the variable; this activates saving of all parameters in the EEPROM.

- myCommand = SAVE\_PARAMETER Saving all parameters in the EEPROM

The current "Parameter handling" state can be read in the symbol browser as follows:

- myCheckbacks.actCommand = READ\_PARA\_ACTIVE  
Read individual parameter activated
- myCheckbacks.actCommand = WRITE\_PARA\_ACTIVE  
Write individual parameter activated
- myCheckbacks.actCommand = SAVE\_PARAMETER\_ACTIVE  
Save all parameters of the POSMO A activated
- myCheckbacks.actCommand = NO\_COMMAND\_ACTIVE  
myCheckbacks.done = TRUE  
Parameter handling completed without error

### Acknowledging faults on POSMO A

Faults on POSMO A are acknowledged as follows:

- myCommand = RESET\_ERRORS

The current fault acknowledgement state can be read in the symbol browser as follows:

- myCheckbacks.actCommand = RESET\_ERRORS\_ACTIVE  
Fault acknowledgement active
- myCheckbacks.actCommand = NO\_COMMAND\_ACTIVE  
myCheckbacks.done = TRUE  
Fault acknowledgement completed

---

#### Note

A POSMO A fault can only be acknowledged successfully when the cause of the error no longer exists.

---

## *Application example*

### *3.3 Variables used in application example*

## **3.3 Variables used in application example**

Table 3- 1 Overview of the variables used

Symbol	Data type	Initial value	Meaning
myCommand	enumCommands	NO_COMMAND	Command interface
myCheckbacks	Struct_Checkbacks	NO_COMMAND_ACTIVE	Command status Additional information

Table 3- 2 Overview of the enums enumCommands

Symbol	Enum Value	Meaning
START_HOMING	0	Start homing of POSMO A
START_JOG_NEGATIVE	1	Start jogging in negative direction
START_JOG_POSITIVE	2	Start jogging in positive direction
START_MDI_BLOCK_ABSOLUTE	3	Start moving MDI block absolute
STOP	4	Stop all actions
RESET_ERRORS	5	Acknowledge faults on POSMO A
READ_ONE_PARAMETER	6	Start reading individual parameter
WRITE_ONE_PARAMETER	7	Start writing individual parameter
SAVE_PARAMETER	8	Save all parameters in the EEPROM of POSMO A
NO_COMMAND	9	No action to be carried out

Table 3- 3 Overview of the enums enumActCommand

Symbol	Enum Value	Meaning
HOMING_ACTIVE	0	Homing of POSMO A activated
JOG_NEGATIVE_ACTIVE	1	Jogging in negative direction activated
JOG_POSITIVE_ACTIVE	2	Jogging in positive direction activated
MDI_BLOCK_ACTIVE	3	Moving MDI block absolute activated
STOP_ACTIVE	4	Stop all actions activated
RESET_ERRORS_ACTIVE	5	Acknowledge faults on POSMO A active
READ_PARA_ACTIVE	6	Read individual parameter active
WRITE_PARA_ACTIVE	7	Write individual parameter active
SAVE_PARAMETER_ACTIVE	8	Save all parameters in the EEPROM of POSMO A active
NO_COMMAND_ACTIVE	9	No action active

Table 3- 4 Data structure Struct\_checkbacks

Symbol	Data type	Meaning
actCommand	enumActCommand	Enums active actions
done	BOOL	Action completed
driveReady	BOOL	Drive (POSMO A) ready for operation
jogPositiveBusy	BOOL	Jogging positive active
jogNegativeBusy	BOOL	Jogging negative active
actPosition	REAL	Current actual position of POSMO A
positionReached	BOOL	Position when moving MDI block absolute reached
error	BOOL	Error has occurred (request canceled; a POSMO A error is pending)
ctrlErrorID	WORD	Error specification of the <b>_POSMOA_control</b> block. Number of the parameter assignment error signaled by POSMO A
driveErrorID	WORD	Error specification of the POSMO A Reason for an error signaled by POSMO A
rwErrorID	WORD	Error specification of the <b>_POSMOA_rwParameter</b> block. Error during reading or writing has occurred
driveWarning	BOOL	POSMO A warning is pending
driveWarningID	WORD	Warning number

*Application example*

---

*3.3 Variables used in application example*

# A

## Appendix

### A.1 SIMOTION and SIMATIC names

The table below contains a comparison of SIMOTION and SIMATIC names.

Table A- 1 SIMOTION and SIMATIC names for SIMODRIVE POSMO A

Name in the SIMOTION system as of V4.1 (command library in SCOUT)	Name in the SIMATIC system	Name in the SIMOTION system up to V3.2 (SIMOTION function library)
<b>Function block parameters</b>		
_POSMOA_control	FB 10	_FB_posmoA_control
pkwIn	I_O_address	PKWInputInterface
pzdIn	I_O_address	PZDInputInterface
enable	Initialization	initialize
homing	Referencing	homing
releaseBrake	Brake_release	-
jog1	Jogging_1	jog1
jog2	Jogging_2	jog2
jogOverride	Jogging_override	jogOverride
start	Start	start
singleBlock	Automatic_operation	-
enableRdIn	Read_in_enable	-
extBlockChange	External_blockchange	-
noStopIntermediate	No_intermediate_stop	intermediateStop
noStop	No_stop	stop
resetError	Fault_acknowledgement	resetError
blockNumber	Block_number	blockNumber
veloOverride	Override	velocityOverride
setStartInformation	Start_byte	setStartInformation
mdiMode	MDI_type	MDIMode
mdiVelocity	MDI_velocity	MDIVelocity
mdiAcceleration	MDI_acceleration	MDIAcceleration
mdiPosition	MDI_position	MDIPosition
reqControl	Ctrl_Req	-
pkwOut	I_O_address	PKWOutputInterface
pzdOut	I_O_address	PZDOutputInterface
busy	FB_coordination	busy
ready	Ready	ready
active	-	-

## Appendix

### A.1 SIMOTION and SIMATIC names

Name in the SIMOTION system as of V4.1 (command library in SCOUT)	Name in the SIMATIC system	Name in the SIMOTION system up to V3.2 (SIMOTION function library)
dataReady	Data_transfer_ready	-
statusWord	Status_word	statusWord
actBlockNumber	Actual_block	actualBlockNumber
statusInformation	Checkback_signal_byte	statusInformation
driveWarning	Warning	driveWarning
driveWarnId	Warn_number	driveWarningNumber
driveWarnInfo	Warn_info	-
driveError	-	driveError
driveErrorId	-	driveErrorNumber
error	Fault	error
errorID	Fault_number	errorNumber
<hr/>		
_POSMOA_nControl	<b>FB 9</b>	-
enable	-	-
pkwIn	-	-
pzdIn	-	-
init	Initialization	-
releaseBrake	Brake_release	-
accelTime	Acc_Time	-
releaseRamp	Ramp_en	-
startRamp	Ramp_on	-
setpoint	Sp	-
releaseSetpoint	Sp_en	-
resetError	Fault_acknowledgement	-
reqControl	Ctrl_req	-
busy	FB_coordination	-
pkwOut	-	-
pzdOut	-	-
ready	Ready	-
active	-	-
dataReady	Data_transfer_ready	-
statusWord	Status_word	-
actValue	Pv	-
error	-	-
errorID	-	-
driveError	Fault	-
driveErrorId	Fault_number	-
driveWarning	Warning	-
driveWarnId	Warn_number	-
driveWarnInfo	Warn_info	
<hr/>		

Name in the SIMOTION system as of V4.1 (command library in SCOUT)	Name in the SIMATIC system	Name in the SIMOTION system up to V3.2 (SIMOTION function library)
_POSMOA_rwParameter	FB 11	_FB_posmoA_readWriteParameter
pkwln	I_O_address	PKWInputInterface
paraNumber	Number	parameterNumber
subindex	Index	subindex
enableRead	Read	read
execWrite	Write	write
setDefault	Factory_default	setFactorySettings
saveParameter	Parameter_save	saveParameter
pkwOut	I_O_address	PKWOutputInterface
busy	FB_coordination	busy
realValue	Value	REALValue
dintValue	Value	DINTValue
done	Task_completed	done
error	Fault_present	error
errorID	Fault_number	errorNumber
<hr/>		
_POSMOA_rwAllParameter	FB 12	_FB_posmoA_readWriteAllParameter
pkwln	I_O_address	PKWInputInterface
execRead	Read_all	read
execWrite	Write_all	write
posMode	Pos_en	-
pkwOut	I_O_address	PKWOutputInterface
allParaPosmoA	-	allPosmoAParameter
busy	FB_active	busy
done	Task_complete	done
error	Fault_present	error
errorID	Fault_number	errorNumber
errorParaNumber	Fault_parameter_number	errorParameterNumber
<hr/>		
<b>Data structure elements</b>		
<b>Struct_POSMOA_params</b>		<b>Struct_posmoA_parameter</b>
p1	p1	parameter1
p2	p2	parameter2
p3	p3	parameter3
p4	p4	parameter4
p5	p5	parameter5
p6	p6	parameter6
p7	p7	parameter7
p8	p8	parameter8
p9	p9	parameter9

## Appendix

### A.1 SIMOTION and SIMATIC names

Name in the SIMOTION system as of V4.1 (command library in SCOUT)	Name in the SIMATIC system	Name in the SIMOTION system up to V3.2 (SIMOTION function library)
p10	p10	parameter10
p11	p11	parameter11
p12	p12	parameter12
p13	p13	parameter13
p14	p14	parameter14
p15	p15	parameter15
p16	p16	parameter16
p17	p17	parameter17
p18	p18	parameter18
p19	p19	parameter19
p20	p20	parameter20
p21	p21	parameter21
p22	p22	parameter22
p23	p23	parameter23
p24	p24	parameter24
p25	p25	parameter25
p26	p26	parameter26
p27	p27	parameter27
p28	p28	parameter28
p29	p29	parameter29
p30	p30	parameter30
p31	p31	parameter31
p32	p32	parameter32
p33	p33	parameter33
p34	p34	parameter34
p35	p35	parameter35
p36	p36	parameter36
p37	p37	parameter37
p38	p38	parameter38
p39	p39	parameter39
p40	p40	parameter40
p41	p41	parameter41
p42	p42	parameter42
p43	p43	parameter43
p44	p44	parameter44
p45	p45	parameter45
p46	p46	parameter46
p47	p47	parameter47
p48	p48	parameter48
p49	p49	parameter49
p50	p50	parameter50

Name in the SIMOTION system as of V4.1 (command library in SCOUT)	Name in the SIMATIC system	Name in the SIMOTION system up to V3.2 (SIMOTION function library)
p51	p51	parameter51
p52	p52	parameter52
p53	p53	parameter53
p54	p54	parameter54
p55	p55	parameter55
p56	p56	parameter56
p57	p57	parameter57
p58	p58	parameter58
p59	p59	parameter59
p60	p60	parameter60
p61	p61	parameter61
p62	p62	parameter62
p80	p80	parameter80
p81	p81	parameter81
p82	p82	parameter82
p83	p83	parameter83
p84	p84	parameter84
p85	p85	parameter85
p86	p86	parameter86
p87	p87	parameter87
p99	p99	parameter99
p100	p100	parameter100
p101	p101	parameter101
p700	p700	-
p701	p701	-
p880	p880	-
p930	p930	parameter930
p964	p964	parameter964
p1426	p1426	-
p1427	p1427	-
<b>Program control word</b>		
Array_POSMOA_prgCtrlInfo		Array_posmoA_programControllInformation

## *Appendix*

### *A.2 List of abbreviations*

## **A.2 List of abbreviations**

Table A- 2 Abbreviations

<b>Abbreviation</b>	<b>Meaning</b>
DC	Direct current
DP	Distributed I/O
EEPROM	Electrically Erasable Programmable Read-Only Memory
ES	SIMOTION SCOUT
FB	Function block
FW	Firmware
HW	Hardware
IN	Input parameters
IN/OUT	In/out parameter
LAD	Ladder diagram
MDI	<b>M</b> anual <b>D</b> ata <b>I</b> nput
OUT	Output parameters
PIV	Parameter identification value: Parameter part of a PPO
POSMO A	<b>P</b> ositioning <b>M</b> otor <b>A</b> ctuator
PPO	<b>P</b> arameter <b>P</b> rocess <b>O</b> bject: Cyclic data message frame when transferring data with PROFIBUS DP and the "variable-speed drives" profile
PZD	Process data: Process data part of a PPO
ST	Structured text
STW	Control word
SW	Software
TO	Technology object

# Index

## C

Calling function blocks  
POSMO A, 38

## D

Data structure of Struct\_POSMOA\_params, 33

## I

I/O variable  
Creating, 14  
Installation and startup, 11  
Integrating the function blocks, 13

## M

Message frame substitution  
FB\_POSMOA\_control, 21  
FB\_POSMOA\_nControl, 25

## P

POSMO A application example, 41  
POSMO A function blocks  
\_POSMA\_control, 16  
\_POSMA\_nControl, 22  
\_POSMA\_rwAllParameter, 31  
\_POSMA\_rwParameter, 28  
Call example, 38  
Overview, 15

## R

References, 3

## S

SIMOTION and SIMATIC names, 51