

---

**User's  
Manual**

**WX1  
GateCONTROL**

---

**vigilantplant®**

---

This manual describes the functions and operating procedures of GateCONTROL. To ensure correct use, please read this manual thoroughly before beginning operation. After reading the manual, keep it in a convenient location for quick reference in the event a question arises.

GateCONTROL is a software driver that uses the Modbus/RTU or Modbus/TCP protocol to acquire data from Yokogawa temperature controllers, signal conditioners, and other instruments, and then transfer that data to DAQLOGGER or Remote Monitor.

## Note

- The contents of this manual are subject to change without prior notice as a result of improvements in the software's performance and functions.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact the dealer from whom you purchased the software.
- Copying or reproducing all or any part of the contents of this manual without the permission of Yokogawa Electric Corporation is strictly prohibited.
- Use of this software on more than one computer at the same time is prohibited. Use by more than one user is also prohibited.
- Transfer or lending of this software to any third party is prohibited.
- Yokogawa Electric Corporation provides no guarantees other than for physical deficiencies found on the original disk or this manual upon opening the product package.
- **License numbers will not be reissued. Please keep the license number in a safe place.**

## Copyrights

- Copyrights for the programs included on the CD-ROM are attributable to Yokogawa Electric Corporation.

## Trademarks

- DAQWORX, DAQLOGGER, and DAQEXPLORER are registered trademarks or trademarks of Yokogawa Electric Corporation.
- Microsoft, Windows, and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are registered trademarks or trademarks of Adobe Systems Incorporated.
- Company and product names that appear in this manual are registered trademarks or trademarks of their respective holders.
- The company and product names used in this manual are not accompanied by the registered trademark or trademark symbols (® and ™).

## Revisions

- 1st Edition February 2005
- 2nd Edition August 2005
- 3rd Edition June 2007
- 4th Edition January 2009
- 5th Edition June 2009
- 6th Edition June 2010
- 7th Edition January 2011
- 8th Edition October 2011

---

# Software License Agreement

## **IMPORTANT - PLEASE READ CAREFULLY BEFORE INSTALLING OR USING:**

THANK YOU VERY MUCH FOR SELECTING SOFTWARE OF YOKOGAWA ELECTRIC CORPORATION ("YOKOGAWA"). BY INSTALLING OR OTHERWISE USING THE SOFTWARE PRODUCT, YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE, DO NOT INSTALL NOR USE THE SOFTWARE PRODUCT AND PROMPTLY RETURN IT TO THE PLACE OF PURCHASE FOR A REFUND, IF APPLICABLE.

## **Software License Agreement**

### 1. Scope

This Agreement applies to the following software products and associated documentation of Yokogawa (collectively, "Software Product"). Unless otherwise provided by Yokogawa, this Agreement applies to the updates and upgrades of the Software Product which may be provided by Yokogawa.

Software Product: DAQWORX (It is limited to each software that you bought).

### 2. Grant of License

2.1 Subject to the terms and conditions of this Agreement, Yokogawa hereby grants to you a non-exclusive and non-transferable right to use the Software Product on a single or, the following specified number of, computer(s) and solely for your internal operation use, in consideration of full payment by you to Yokogawa of the license fee separately agreed upon.

Granted number of License: 1 (one)

2.2 Unless otherwise agreed or provided by Yokogawa in writing, the following acts are prohibited:

- a) to reproduce the Software Product, except for one archival copy for backup purpose, which shall be maintained with due care subject to this Agreement;
- b) to sell, lease, distribute, transfer, pledge, sublicense, make available via the network or otherwise convey the Software Product or the license granted herein to any other person or entity;
- c) to use the Software Product on any unauthorized computer via the network;
- d) to cause, permit or attempt to dump, disassemble, decompile, reverse-engineer, or otherwise translate or reproduce the Software Product into source code or other human readable format, or to revise or translate the Software Product into other language and change it to other formats than that in which Yokogawa provided;
- e) to cause, permit or attempt to remove any copy protection used or provided in the Software Product; or
- f) to remove any copyright notice, trademark notice, logo or other proprietary notices or identification shown in the Software Product.

2.3 Any and all technology, algorithms, know-how and process contained in the Software Product are the property or trade secret of Yokogawa or licensors to Yokogawa. Ownership of and all the rights in the Software Product shall be retained by Yokogawa or the licensors and none of the rights will be transferred to you hereunder.

2.4 You agree to maintain the aforementioned property and trade secret of Yokogawa or licensors and key codes in strict confidence, not to disclose it to any party other than your employees, officers, directors or similar staff who have a legitimate need to know to use the Software Product and agreed in writing to abide by the obligations hereunder.

2.5 Upon expiration or termination of this Agreement, the Software Product and its copies, including extracts, shall be returned to Yokogawa and any copies retained in your computer or media shall be deleted irretrievably. If you dispose of media in which the Software Product or its copy is stored, the contents shall be irretrievably deleted.

2.6 The Software Product may contain software which Yokogawa is granted a right to sublicense or distribute by third party suppliers, including affiliates of Yokogawa ("Third Party Software"). If suppliers of the Third Party Software ("Supplier") provide special terms and conditions for the Third Party Software which differ from this Agreement, the special terms and conditions separately provided by Yokogawa shall prevail over this Agreement. Some software may be licensed to you directly by Supplier.

2.7 The Software Product may contain open source software ("OSS"), for which the special terms and conditions separately provided by Yokogawa shall take precedence over this Agreement.

### 3. Restrictions on Application

3.1 Unless otherwise agreed in writing between you and Yokogawa, the Software Product is not intended, designed, produced or licensed for use in relation to aircraft operation or control, ship navigation or marine equipment control, or ground facility or device for support of the aforesaid operation or control, or for use in relation to rail facility, nuclear related facility, radiation-related equipment, or medical equipment or facility, or under any other circumstances which may require high safety standards.

3.2 If the Software Product is used for the abovementioned purposes, neither Yokogawa nor Supplier assumes liability for any claim or damage arising from the said use and you shall indemnify and hold Yokogawa, Supplier, their affiliates, subcontractors, officers, directors, employees and agents harmless from any liability or damage whatsoever, including any court costs and attorney's fees, arising out of or related to the said use.

### 4. Limited Warranty

4.1 The Software Product shall be provided to you on an "as is" basis at the time of delivery and except for physical damage to the recording medium containing the Software Product, Yokogawa and Supplier shall disclaim all of the warranties whatsoever, express or implied, and all liabilities therefrom. If any physical defect is found on the recording medium not later than twelve (12) months from delivery, Yokogawa shall replace such defective medium free of charge, provided that the defective medium shall be returned to the service office designated by Yokogawa at your expense within the said twelve (12) months. THIS LIMITED WARRANTY PROVIDED IN THIS CLAUSE IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND WHATSOEVER AND YOKOGAWA HEREBY DISCLAIMS ALL OTHER WARRANTIES RELATING TO THE SOFTWARE PRODUCT, WHETHER EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, NON-INFRINGEMENT, QUALITY, FUNCTIONALITY, APPROPRIATENESS, ACCURACY, RELIABILITY AND RECENCY. IN NO EVENT SHALL YOKOGAWA WARRANT THAT THERE IS NO INCONSISTENCY OR INTERFERENCE BETWEEN THE SOFTWARE PRODUCT AND OTHER SOFTWARE NOR SHALL BE LIABLE THEREFOR. The warranty provisions of the applicable law are expressly excluded to the extent permitted.

4.2 At the sole discretion of Yokogawa, Yokogawa may upgrade the Software Product to the new version number ("Upgrade") and make it available to you at your expense or free of charge as Yokogawa deems fit. In no event shall Yokogawa be obliged to upgrade the Software Product or make the Upgrade available to you.

4.3 Certain maintenance service may be available for some types of Software Product at Yokogawa's current list price. Scope and terms and conditions of the maintenance service shall be subject to those separately provided by Yokogawa. Unless otherwise provided in Yokogawa catalogues or General Specifications, maintenance services will be available only for the latest version and the immediately preceding version. In no event will service for the immediately preceding version be available for more than 5 years after the latest version has been released. In addition, no service will be provided by Yokogawa for the Software Product which has been discontinued for more than 5 years. Notwithstanding the foregoing, maintenance service may not be available for non-standard Software Product. Further, in no event shall Yokogawa provide any service for the Software Product which has been modified or changed by any person other than Yokogawa.

### 5. Infringement

- 5.1 If you are warned or receive a claim by a third party that the Software Product in its original form infringes any third party's patent (which is issued at the time of delivery of the Software Product), trade mark, copyright or other intellectual property rights ("Claim"), you shall promptly notify Yokogawa thereof in writing.
- 5.2 If the infringement is attributable to Yokogawa, Yokogawa will defend you from the Claim at Yokogawa's expense and indemnify you from the damages finally granted by the court or otherwise agreed by Yokogawa out of court. The foregoing obligation and indemnity of Yokogawa shall be subject to that i) you promptly notify Yokogawa of the Claim in writing as provided above, ii) you grant to Yokogawa and its designees the full authority to control the defense and settlement of such Claim and iii) you give every and all necessary information and assistance to Yokogawa upon Yokogawa's request.
- 5.3 If Yokogawa believes that a Claim may be made or threatened, Yokogawa may, at its option and its expense, either a) procure for you the right to continue using the Software Product, b) replace the Software Product with other software product to prevent infringement, c) modify the Software Product, in whole or in part, so that it become non-infringing, or d) if Yokogawa believes that a) through c) are not practicable, terminate this Agreement and refund you the paid-up amount of the book value of the Software Product as depreciated.
- 5.4 Notwithstanding the foregoing, Yokogawa shall have no obligation nor liability for, and you shall defend and indemnify Yokogawa and its suppliers from, the Claim, if the infringement is arising from a) modification of the Software Product made by a person other than Yokogawa, b) combination of the Software Product with hardware or software not furnished by Yokogawa, c) design or instruction provided by or on behalf of you, d) not complying with Yokogawa's suggestion, or e) any other causes not attributable to Yokogawa.
- 5.5 This section states the entire liability of Yokogawa and its suppliers and the sole remedy of you with respect to any claim of infringement of a third party's intellectual property rights. Notwithstanding anything to the contrary stated herein, with respect to the claims arising from or related to the Third Party Software or OSS, the special terms and conditions separately provided for such Third Party Software or OSS shall prevail.

### 6. Limitation of Liability

- 6.1 EXCEPT TO THE EXTENT THAT LIABILITY MAY NOT LAWFULLY BE EXCLUDED IN CONTRACT, YOKOGAWA AND SUPPLIERS SHALL NOT BE LIABLE TO ANY PERSON OR LEGAL ENTITY FOR LOSS OR DAMAGE, WHETHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES, OR OTHER SIMILAR DAMAGES OF ANY KIND, INCLUDING WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OR DESTRUCTION OF DATA, LOSS OF AVAILABILITY AND THE LIKE, ARISING OUT OF THE USE OR INABILITY TO USE OF THE SOFTWARE PRODUCT, OR ARISING OUT OF ITS GENERATED APPLICATIONS OR DATA, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, WHETHER BASED IN WARRANTY (EXPRESS OR IMPLIED), CONTRACT, STRICT LIABILITY, TORT (INCLUDING NEGLIGENCE), OR ANY OTHER LEGAL OR EQUITABLE GROUNDS. IN NO EVENT YOKOGAWA AND SUPPLIER'S AGGREGATE LIABILITY FOR ANY CAUSE OF ACTION WHATSOEVER (INCLUDING LIABILITY UNDER CLAUSE 5) SHALL EXCEED THE DEPRECIATED VALUE OF THE LICENSE FEE PAID TO YOKOGAWA FOR THE USE OF THE CONCERNED PART OF THE SOFTWARE PRODUCT. If the Software Product delivered by Yokogawa is altered, modified or combined with other software or is otherwise made different from Yokogawa catalogues, General Specifications, basic specifications, functional specifications or manuals without Yokogawa's prior written consent, Yokogawa shall be exempted from its obligations and liabilities under this Agreement or law.
- 6.2 Any claim against Yokogawa based on any cause of action under or in relation to this Agreement must be given in writing to Yokogawa within three (3) months after the cause of action accrues.

### 7. Export Control

You agree not to export or provide to any other countries, whether directly or indirectly, the Software Product, in whole or in part, without prior written consent of Yokogawa. If Yokogawa agrees such exportation or provision, you shall comply with the export control and related laws, regulations and orders of Japan, the United States of America, and any other applicable countries and obtain export/import permit and take all necessary procedures under your own responsibility and at your own expense.

### 8. Audit; Withholding

- 8.1 Yokogawa shall have the right to access and audit your facilities and any of your records, including data stored on computers, in relation to the use of the Software Product as may be reasonably necessary in Yokogawa's opinion to verify that the requirements of this Agreement are being met.
- 8.2 Even after license being granted under this Agreement, should there be any change in circumstances or environment of use which was not foreseen at the time of delivery and, in Yokogawa's reasonable opinion, is not appropriate for using the Software Product, or if Yokogawa otherwise reasonably believes it is too inappropriate for you to continue using the Software Product, Yokogawa may suspend or withhold the license provided hereunder.

### 9. Assignment

If you transfer or assign the Software Product to a third party, you shall expressly present this Agreement to the assignee to ensure that the assignee comply with this Agreement, transfer all copies and whole part of the Software Product to the assignee and shall delete any and all copy of the Software Product in your possession irretrievably. This Agreement shall inure to the benefit of and shall be binding on the assignees and successors of the parties.

### 10. Termination

Yokogawa shall have the right to terminate this Agreement with immediate effect upon notice to you, if you breach any of the terms and conditions hereof. Upon termination of this Agreement, you shall promptly cease using the Software Product and, in accordance with sub-clause 2.5, return or irretrievably delete all copies of the Software Product, certifying the same in writing. In this case the license fee paid by you for the Software Product shall not be refunded. Clauses 2.4 and 2.5, 3, 5, 6 and 11 shall survive any termination of this Agreement.

### 11. Governing Law; Disputes

This Agreement shall be governed by and construed in accordance with the laws of Japan.

Any dispute, controversies, or differences which may arise between the parties hereto, out of, in relation to or in connection with this Agreement ("Dispute") shall be resolved amicably through negotiation between the parties based on mutual trust. Should the parties fail to settle the Dispute within ninety (90) days after the notice is given from either party to the other, the Dispute shall be addressed in the following manner:

- (i) If you are a Japanese individual or entity, the Dispute shall be brought exclusively in the Tokyo District Court (The Main Court) in Japan.
- (ii) If you are not a Japanese individual or entity, the Dispute shall be finally settled by arbitration in Tokyo, Japan in accordance with the Commercial Arbitration Rules of the Japan Commercial Arbitration Association. All proceedings in arbitration shall be conducted in the English language, unless otherwise agreed. The award of arbitration shall be final and binding upon both parties, however, each party may make an application to any court having jurisdiction for judgment to be entered on the award and/or for enforcement of the award.

### 12. Miscellaneous

- 12.1 This Agreement supersedes all prior oral and written understandings, representations and discussions between the parties concerning the subject matter hereof to the extent such understandings, representations and discussions should be discrepant or inconsistent with this Agreement.
- 12.2 If any part of this Agreement is found void or unenforceable, it shall not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms and conditions. The parties hereby agree to attempt to substitute for such invalid or unenforceable provision a valid or enforceable provision that achieves to the greatest extent possible the economic, legal and commercial objectives of the invalid or unenforceable provision.
- 12.3 Failure by either party to insist on performance of this Agreement or to exercise a right when entitled does not prevent such party from doing so at a later time, either in relation to that default or any subsequent one.

End of document

---

# Overview of This Manual

## Structure of The Manual

This user's manual consists of the following chapters.

Chapter	Title	Description
1	<b>Overview</b>	Gives an overview of the GateCONTROL software. Lists the PC requirements for running GateCONTROL and gives information about system configuration.
2	<b>Operating</b>	Gives procedures for entering environment and data acquisition. Procedures interval settings, and how to monitor the operational status of the software.
3	<b>Functions</b>	Provides a detailed description of the functions of GateCONTROL. Lists error messages, their causes, and their corrective actions.
<b>Index</b>		An alphabetical index of the manual's contents.

## Scope of the Manual

This manual does not explain the basic operations of your PC's operating system (OS). For information regarding the basic operations of Windows, see the Windows user's manual.

## Conventions Used in This Manual

- Units
  - K Denotes 1024. Example: 10 KB
  - M Denotes 1024K. Example: 10 MB
  - G Denotes 1024M. Example: 2 GB
- Boldface Type
  - Hardware and software controls that the user manipulates such as dialog boxes, buttons, and menu commands are often set in boldface type.
- Subheadings
  - On pages in chapters 1 through 3 that describe operating procedures, the following subheadings are used to distinguish the procedure from their explanations.

### **Procedure**

This subsection contains the operating procedure used to carry out the function described in the current section. All procedures are written with inexperienced users in mind; experienced users may not need to carry out all the steps.

### **Note**

Calls attention to information that is important for proper operation of the instrument.

# Contents

Software License Agreement .....	ii
Overview of This Manual .....	iv
<b>Chapter 1 Overview</b>	
1.1 Overview of GateCONTROL Functions .....	1-1
1.2 System Overview .....	1-2
<b>Chapter 2 Operating</b>	
2.1 Running and Exiting GateCONTROL .....	2-1
Running the Software .....	2-1
Exiting the Software .....	2-1
2.2 Entering Environment Settings .....	2-2
Serial Port Settings (When the Communication Mode is COM) .....	2-2
Data Acquisition Conditions .....	2-5
TCP/IP Settings for the Monitor Server Port .....	2-6
Tag Settings .....	2-7
2.3 Saving and Restoring Environment Settings .....	2-12
Saving Environment Settings .....	2-12
Restoring Environment Settings .....	2-12
2.4 Starting/Stopping Data Acquisition .....	2-13
Starting Data Acquisition .....	2-13
Stop data acquisition .....	2-14
2.5 Performing Communication Tests of Connected Devices .....	2-15
Performing the Loop Back Test .....	2-15
Performing Read and Write Tests .....	2-16
2.6 Checking the Client Connection Status and Communication Status of Connected Instruments, and Reconnecting Connected Instruments .....	2-18
Checking the Client Connection Status and Communication Status of Connected Instruments .....	2-18
Reconnecting Connected Instruments .....	2-19
2.7 Viewing Version Information .....	2-20
<b>Chapter 3 Functions</b>	
3.1 Modbus Communication Device Settings .....	3-1
Settings for Connected Modbus Devices .....	3-1
3.2 Meanings of Tags of Connected Devices .....	3-2
3.3 Details on Functions .....	3-4
Time Out Operation .....	3-4
Error Status .....	3-5
Processing Alarm Statuses .....	3-6
Output Processing .....	3-8
3.4 Notes When Performing Communications with Software on Other PCs .....	3-9
Communications with DAQLOGGER .....	3-9
Communications with DAQLOGGER Client Package .....	3-9
GateCONTROL Settings .....	3-9

## Contents

---

3.5 Error Messages and Corrective Actions .....	3-10
Error .....	3-10
Message .....	3-10
Messages during (When Executing) Data Acquisition .....	3-10

## Index

## 1.1 Overview of GateCONTROL Functions

GateCONTROL is a software driver that acquires data from temperature controllers and signal conditioners that support data input/output via the Modbus/RTU and Modbus/TCP protocols, and in addition to transferring the data to Yokogawa's DAQLOGGER or Remote Monitor software, can write output requests from AddObserver to temperature controllers. Using GateCONTROL allows you to easily monitor data on DAQLOGGER or Remote Monitor that is input for measurement on temperature controllers and signal conditioners. Also, it is now possible to operate a controller from AddObserver through GateCONTROL.

DAQLOGGER is application software for the PC that enables communication between the PC and various types of recorders as well as monitoring of data logged by those recorders. A direct connection can be made for communications between DAQLOGGER and the  $\mu$ R1000/ $\mu$ R1800, VR, DARWIN, DX, MV, and CX recorders by Yokogawa.

Remote Monitor is application software that enables monitoring of data logged by recorders or data logging software.

AddObserver is a software program that allows the user to create original screens for displaying measured data, and for operating instruments.

### Features

- Up to thirty-two temperature controllers and signal conditioners can be connected.
- The main registers of each instrument are automatically assigned as tag information using the Automatic Model Determination function.
- Arbitrary registers can be registered as tags.



## 1.2 System Overview

### System

This software can open communication with Yokogawa temperature controllers and signal conditioners, perform data acquisition, and write the data.

The supported temperature controllers and signal conditioners are the ones below that support the Modbus/RTU or Modbus/TCP protocol. The product may not support GateCONTROL depending on its firmware revision number. For information on how to check the firmware revision number of your MODBUS instrument, and whether or not a connection with GateCONTROL can be made, please contact the dealer from which you purchased the instrument.

Temperature controllers	UT130, UT150, UT152, UT155, UP150
Digital indicating controllers	UT320, UT321, UT350, UT351, UT420, UT450, UT520, UT550, UT551, UT750, US1000, UT55A*, UT52A*, UT35A*, UT32A*
Program controllers	UP350, UP351, UP550, UP750, UP55A*, UP35A*
Digital indicators with alarms	UM330, UM331, UM350, UM351, UM33A*
Signal conditioners and conditioners	VJA7, VJH7, VJP8, VJQ7, VJQ8, VJS7, VJU7, VJX7
Digital alarm configurators	MVHK, MVRK, MVTK

\* Can only be connected when C.GRN=ON on the UT55A, UT52A, UT35A, UT32A, UP55A, UP35A or UM33A. For information on the C.GRN setting, see the respective user's manuals.

### Supported Operating Systems

Run DAQWORX under any of the following operating systems.

- Windows 2000 Professional SP4
- Windows XP Home Edition SP3
- Windows XP Professional SP3 (excluding Windows XP Professional x64 Editions)
- Windows Vista Home Premium SP2 (excluding the 64-bit editions)
- Windows Vista Business SP2 (excluding the 64-bit editions)
- Windows 7 Home Premium, SP1 (32-bit and 64-bit editions)
- Windows 7 Professional, SP1 (32-bit and 64-bit editions)

The language displayed by the software under different language versions of the OS are as follows.

OS Language	Software Language
Japanese	Japanese
Other	English

## Hardware Requirements


The following hardware and software are required to use GateCONTROL.

- PC: A PC that runs one of the OS above, and that meets the following CPU and memory requirements.
  - When Using Windows 2000 or Windows XP**  
Pentium 4, 1.6 GHz or faster Intel x64 or x86 processor;  
512 MB or more of memory
  - When Using Windows Vista**  
Pentium 4, 3 GHz or faster Intel x64 or x86 processor; 2 GB or more of memory
  - When Using Windows 7**  
32-bit edition: Intel Pentium 4, 3 GHz or faster x64 or x86 processor; 2 GB or more of memory  
64-bit edition: Intel x64 processor that is equivalent to Intel Pentium 4, 3 GHz or faster; 2 GB or more of memory
- Free disk space: 200 MB or more
- Communication interface: An Ethernet (when connecting to DAQLOGGER or Remote Monitor) or RS-232 port that is recognized by the operating system.
- CD-ROM drive: Used to install the software.
- Peripheral devices: A mouse supported by the operating system.
- Monitor: A video card that is recommended for the OS and a display that is supported by the OS, has a resolution of 1024×768 or higher, and that can show 65,536 colors (16-bit, high color) or more.

### **Note**

An RS-232 to RS-485 converter is required to perform communications between the software and another Modbus/RTU (RS-485) device (Yokogawa ML2 RS232C/RS485 converter recommended).

## System Configuration




## 2.1 Running and Exiting GateCONTROL

### Running the Software

#### Procedure

1. From the Windows Start menu, choose **Programs > YOKOGAWA DAQWORX > GateCONTROL > GateCONTROL**.

GateCONTROL starts.



### Note

- When you start GateCONTROL it is restored to the same status that was active during the previous session.
- If the program is closed while a process or service is running, the license will be considered to be "in use." If the message, "Invalid license number. Please reinstall." appears when restarting the program, it may indicate that the user is attempting to run a Gate program in excess of the number of available licenses.

### Exiting the Software

#### Procedure

1. Choose **File > Exit** from the menu bar, or click the **X** button at the right end of the title bar.

GateCONTROL closes.

## 2.2 Entering Environment Settings

This software includes an automatic model determination function, enabling automatic acquisition of the connected devices' (temperature controllers and signal conditioners) model names, tag information, and Modbus address when you enter the appropriate serial port settings, IP addresses, and/or port numbers.


The following environment settings are entered.

- Serial port settings (when the communication mode is COM)
- Settings for the connected devices
- Data acquisition condition
- TCP/IP port settings for the monitor server
- Tag settings (enter the tag name and decimal place as needed)

### Serial Port Settings (When the Communication Mode is COM)

#### Procedure

1. Click the **Serial Setting** tab or choose **View > Serial Setting** from the menu bar. The Serial Setting page is displayed.



2. Turn ON the port numbers to be used, and set the baud rate, and parity.  
Port number: ON (blue)/OFF (gray)  
Baud rate: 4800, 9600, 19200, 38400  
Parity: NONE, ODD, EVEN

## Settings for the Connected Devices

Register all devices that you will operate and from which you will acquire data.


### Procedure

1. Click the **Model** tab or choose **View > Model** from the menu bar. The **Model Setting** tab is displayed.

When Ether communication is selected, clicking here displays a dialog box for setting the IP address, port number, and Modbus address.

If COM1-COM9 is selected, a dialog box for setting the Modbus address appears.

Click to display a list box for selecting a communication port  
Only enabled COM ports (specified in serial port settings) are displayed



Drag to select a range of items

Copies the setting in the first item of the selection to all of the items in the selection


2. Select the port to be used from the Communication Method list box.

If using an Ethernet port: Ether

If using a COM port: COM1–COM9

## IP Address and Port Number (If Ethernet Is Selected for the Port)

3. Click an address. The **Address Setting** dialog box opens.



4. Enter the IP address (or host name) and port number.

IP address: Enter the IP address or host name set on the device to which you wish to connect.

Port no.: 502

Modbus address: 1–9


**(If you will perform automatic model determination, including for the Modbus address, select Unknown.)**

### Note

The default port number for Modbus/TCP is 502. If no particular specification has been made on the device, use this number.

### Modbus Address (for Ports Set to COM)

- Click an address. The **Address Selection** dialog box opens.



- Enter the Modbus address.


Modbus address: 1–99

**If you will perform automatic model determination including for the Modbus address, choose Unknown.**

### Automatic Model Determination

- After specifying the communication methods and addresses, drag numbers to specify the range for automatic model determination.

#### Automatic detection button



Drag to select a range for automatic model determination.

Clears the contents of the status boxes.

- Click the **Automatic detection** button at the bottom of the screen, click the **Automatic determination** button in the toolbar, or choose **Communication > Automatic detection** from the menu bar.

Model name, control mode, control output, option functions, and tag information is automatically acquired. A loop back test is also executed at the same time. If the test concludes without errors, a status of “OK” is displayed. (“Not OK” is displayed if an abnormality occurred.)


**Note**

- If you connect to an unsupported devices, "Unknown" is displayed for the model.
- It is not supported in the UP55A's remote-mode operation. If the operation mode is REMOTE, it is handled as LOCAL.
- If the result, model name, control mode, control output or option functions found by automatic model determination differ, the tag list in the tag settings dialog box is initialized. If the tag list was modified from the initial condition, the message, "OK to initialize tag list?" is displayed. Click the Yes button to implement the search results and initialize the tag list. Click the Cancel button to quit without applying the results of automatic model determination to the model settings page.
- The automatic model determination function registers the UT55A as the UT551, the UT52A as the UT520, the UT35A as the UT351, the UT32A as the UT321, UP55A as the UP550 and the UM33A as the UM331. The position proportional type UT35A, UT32A, UP55A and UP35A are registered as the standard type UT351, UT321, UP550 and UP35A, respectively. Heating / cooling type UT52A are registered as the Heating / cooling type UT551. From the above, the one actually connected may differ from the one displayed on screen, as follows.

Displayed	Actually connected model
UT551	UT55A, UT52A
UT520	UT52A
UT351	UT35A
UT321	UT32A
UP550	UP55A
UM331	UM33A

**Data Acquisition Conditions****Procedure**

1. Click the **Scan Interval Setting** tab or choose **View > Scan Interval Setting** from the menu bar.



2. Set the scan interval, access timeout, retray use, and retry interval.

Scan interval: 0.5–60 s (or 500–60000 ms: initial value is 1000 ms)

Access timeout: 1–10 sec (or 1000–10000 ms: initial value is 5000 ms)

Retry Use: Select whether or not to retry communications (ON/OFF).

Retry interval: The interval between communication retries (30–3600 sec).

**Note**

- Retries are performed every scan interval at the specified retry interval until communication is restored. Retries are also performed on instruments with which a communication error occurred during the first communication. At the point that communication is restored, alarm values and other information are retrieved from the connected temperature controllers or signal conditioners and data is acquired.
- If Retry is turned OFF, you can retry the connection manually by clicking the Retry Connection button on the Monitor/Status tab.




### TCP/IP Settings for the Monitor Server Port

The port number need not be changed unless desired.

#### Procedure

1. Choose **File > Port No.** from the menu bar.


The **Port No.** for the internal communication dialog box opens.



2. Enter the port number used to transfer data loaded from a connected device to DAQLOGGER, Remote Monitor or AddObserver.

## Tag Settings Procedure

1. Click the Detail Settings in the tag information column of the model you wish to set in the Model Settings page.




Click to Tag Setting dialog box

The Tag Setting dialog box opens.

One of the following tag names that was reserved is displayed.

PV1	A/M1	R/P1/P2	TME1	TME11	C.A.M1
PV2	A/M2	HOLD	TME2	TME12	C.A.M2
SP1	C.A.M	PVE1	TME3	TME13	O/C
SP2	R/L1	PVE2	TME4	TME14	INPUT
OUT1	R/L2	PVE3	TME5	TME15	ADVANCE
OUT2	SPNO	PVE4	TME6	TME16	RUN
HOUT1	PIDNO1	PVE5	TME7	PTNO	
HOUT2	PIDNO2	PVE6	TME8	SEGNO	
COUT1	R/S	PVE7	TME9	TIME	
COUT2	R/P/L	PVE8	TME10	LSP/CAS	



The tag settings include an input tab page and an output tab page.

Maximum number of input tags: 48

Maximum number of output tags: 32

The active page is surrounded by a red frame. You can click anywhere on an input/output tab page to move the red frame.

The list of registered tags is determined by the model, control mode, control output, and option functions. Default tag list items displayed in gray cannot be changed. Also, the default tag list cannot be deleted.

## 2.2 Entering Environment Settings

- If you performed automatic model determination, the tag information acquired from the connected devices is displayed.

If links are set, the edited contents are reflected on the linked channels.

### Note

The UT55A, UT52A, UT35A, UT32A, UP55A and UP35A's numbers of PID and SP groups correspond to GateCONTROL's PIDNO and SPNO span maximum values, respectively.

The numbers of PID and SP groups can be set separately on the UT55A and UT52A, but in GateCONTROL's Tag setting dialog box, the same SP group is used as the PIDNO and SPNO span maximum.

On the UT35A and UT32A, you can set the number of PID groups and SP groups to a number from 1 to 4, but the SPNO and PIDNO span maximum values are set to 4.


On the UP55A, you can set the number of PID groups to a number from 1 to 8, but the PIDNO1 and PIDNO2 span maximum values are set to 8. On the UP35A, you can set the number of PID groups to a number from 1 to 4, but the PIDNO1 span maximum values are set to 4.

### Editing the Input Tag Page

If the tag numbers are selected (blue), they are displayed as tag numbers in the Remote Monitor display groups

Select/clear all rows

The tab page to be set is surrounded by a red frame



Delete input tags  
Create input tags

- Tag No.: Select to use (blue) or not use (gray) the selected tag numbers.
- Register number: Shows the reference location of each register.  
Setting range: 40001 to 49999  
When Same on the Output tab page is ON (blue), the edited results are reflected on the output tab page. Register numbers cannot be duplicated (duplicate register numbers are allowed for the default tags because the bit position of the referenced value is different).
- Tag name: Specify using eight alphanumeric characters or fewer. In the Remote Monitor, this is displayed as a channel name.  
Tag names cannot be duplicated. Also, tags to which reserved tag names have been added cannot be used.
- Tag comment: Specify using sixteen alphanumeric characters or fewer.  
In the Remote Monitor, this is displayed as a tag comment.
- Decimal point: Set the decimal place to offset the register value. Select 0, 1, 2, 3, 4, or 5. The initial values vary depending on the type of tag. If automatic model determination is performed, the decimal point of the connected device is displayed.

Span minimum/maximum:

Setting range:  $-1E16$  to  $1E16$

The initial values vary depending on the type of tag. If automatic model determination is performed, the setting value of the connected device is displayed.

On the client side this is handled as the minimum/maximum of scale.

Units:

Specify using six alphanumeric characters or fewer. The initial values vary depending on the type of tag. If automatic model determination is performed, the units set on the connected device are displayed.

Color:

Click the colored part to open the Color Settings dialog box. An arbitrary color can be entered.

Output link:

Displayed in the format xx:tag name where xx is the output tag number. Displays the tag for output that is linked to the input tag. This cannot be changed.

Loaded value:

Displays the tag name value loaded from the connected device when the monitor is executed. "Error" is displayed if a communication error occurs.

### Note

The tag number use/do not use settings are those of the ON/OFF display conditions of the Remote Monitor.

The color setting is the display color of the Remote Monitor.

## Editing the Output Tab Page

Select/clear all rows

Used as the Tag No. in AddObserver

The tab page to be set is surrounded by a red frame

Tag No.	Same	Register		Tag Name	Tag Comment	Point	Span		Unit	Input Link	Output Value	Input Value
		No.					Lower	Upper				
TAG01	OFF		SP1	01U7750 SP1		1	-100.0	100.0		02:SP1		0.0
TAG02	OFF	40206	C.A.M	01U7750 C.A.M		0	0	2		03:C.A.M		0
TAG03	OFF	40207	SPNO	01U7750 SPNO		0	1	6		04:SPNO		0
TAG04	OFF		SP2	01U7750 SP2		1	-100.0	100.0		08:SP2		0.0
TAG05	OFF	40219	OUT2	01U7750 OUT2		1	0.0	100.0		09:OUT2		0.0
TAG06	ON	40006	TAG13	01U7750 TAG13		1	-10.0	10.0		13:TAG13		0.0
TAG07	OFF	40007	TAG14	01U7750 TAG14		1	-10.0	10.0		14:TAG14		0.0

Click to display the Tag selection dialog box

Click here (blue) to apply the edited register numbers to the input tab page, or apply the edited register numbers to the input tab page.

Create output tags

Tag No.: Used as Tag No. in AddObserver

Registers: Same:When selected (ON), the output register number is applied to the input register number.

No.:Shows the location of the tag write register. However, since in the case of SP there are multiple registers to be written, a register number is not displayed. Register numbers cannot be duplicated.

Tag name: Specify using eight alphanumeric characters.

Used as Channel Name in AddObserver.

Tag names cannot be duplicated. Also, tags to which reserved tag names have been added cannot be used.

Tag comment: Specify using sixteen alphanumeric characters or fewer.

In AddObserver, this is displayed as a tag comment.

## 2.2 Entering Environment Settings

Decimal point: Set the offsetting decimal place for writing to registers. Select 0, 1, 2, 3, 4, or 5.

Span minimum/maximum:

Setting range:  $-1E9$  to  $1E9$

If the value requested by AddObserver is outside of the span range, it is not output.


Units: Specify using six alphanumeric characters or fewer.

### Note

Registers 41280 (UTM, USM, UPM) and 41281 (SMP) of the UT520, UT550, UT551, UT750, US1000, UP550, and UP750 cannot be written using the Modbus/RTU, Modbus/TCP protocol. Please make note of this.

Input link: Displays and selects the tag for input that is linked to the output tag. Displayed in the format xx:tag name where xx is the input tag name. When you click an input select button, the tag selection dialog box is displayed.

**Display the tag that links are not set of registered tags of the input tab page**



**Input select button**

Click here to display the Tag Selection dialog box.

**Click here (blue) to apply the edited register numbers in the input tag to the output tag**

Output value: Specifies an output value for the output test.

Range:  $-1E9$  to  $1E9$

Loaded value: The output register value is displayed after the output test.

If the output value is outside of the output span, "Out range" is displayed. If a communication error occurs during output, "Com error" is displayed.

**Tag Setting Execution Button**

Insert input tags, insert output tags:

Insert a tag in the last line of the tag numbers.

Cannot be performed during testing.

Delete input tags, delete output tags:

Deletes the selected tag. If a tag is deleted, the tag numbers are refreshed.

With deletion of input tags, the linked output tags are also deleted.

With deletion of output tags, the linked input tags are not deleted but the link is cleared.

Default tags cannot be deleted.

Cannot be performed during testing.

Initialization:

Added tags are all deleted, and the tag list returns to the default condition.

OK:

The settings in the tag settings dialog box are saved, and the dialog box closes.

When testing, the settings are saved after the test is completed, and the dialog box closes.

If register or tag names are duplicated, the dialog box below is displayed.



Duplicate register numbers and tag names are displayed in yellow.

Tag No.	Register		Tag Name	Tag Comment
	Same	No.		
TAG04	<input type="checkbox"/> OFF	40209	HOLD	02UP750:HOLD
TAG05	<input type="checkbox"/> OFF	40214	PTNO	02UP750:PTNO
TAG06	<input type="checkbox"/> OFF	40210	ADVANCE	02UP750:ADVANCE
TAG07	<input checked="" type="checkbox"/> ON	40210	TAG41	02UP750:TAG41


## 2.3 Saving and Restoring Environment Settings

### Saving Environment Settings

#### Procedure

1. Click the **Save** button or choose **File > Save** from the menu bar.

#### Save button




The current settings are saved.

### Restoring Environment Settings

This procedure clears all settings currently being entered and restores the most recently saved settings.

#### Procedure

1. Choose **File > Revert** from the menu bar.



## 2.4 Starting/Stopping Data Acquisition

When you start data acquisition using this software, data from connected devices (temperature controllers and signal conditioners) is loaded, transferred to DAQLLOGGER or Remote Monitor, and output requests from AddObserver are written to connected devices.

### **Note**

The maximum number of DAQLLOGGERS, Remote Monitors, or AddObservers that can be connected at once is sixteen.

### Starting Data Acquisition

#### Procedure

1. Enter environment settings. (See section 2.2, “Entering Environment Settings.”)

### Running from the Toolbar/Menu Bar

2. Click the **Start** button or choose **Monitor > Start** from the menu bar.




The status of communication with the device is displayed in the **Monitor/Status** tab under Communication status. Under Client status, the name of the connected client, connection status, and the address of any disconnected DAQLLOGGERS, Remote Monitors, and AddObserver is displayed.



### Starting (Executing) from the Monitor/Status Tab

2. Click the **Start** button on the **Monitor/Status** tab.

The name of connected clients and their communication statuses are displayed. Maximum number of display of clients communication statuses is 48.



- Start button  
Click to start data acquisition
- Stop button  
Click to stop data acquisition
- Turn ON (blue) to start data acquisition simultaneously upon software startup

### Starting the Software and Data Acquisition at the Same Time

3. When you turn ON “Start monitor at startup” in the **Monitor/Status** tab, data acquisition starts at the same time that the software is started.

### Stop data acquisition

#### Procedure

#### Stopping Acquisition from the Toolbar/Menu Bar

1. Click the **Stop** button or choose **Monitor > Stop** from the menu bar. Nothing is displayed for the communication of connected devices.



Data acquisition Stop button

#### Stopping Acquisition from the Monitor/Status Tab

1. Click the **Stop** button on the **Monitor/Status** tab. Nothing is displayed for the communication of connected devices.

## 2.5 Performing Communication Tests of Connected Devices

Before starting data acquisition, you can perform a loop back test, read test, and write test between connected devices.

### Performing the Loop Back Test

Using the loop back test you can check the specified communication method and connection status with the device at the specified address.

#### Note

The loop back test can not be performed during data acquisition.

### Procedure

1. Click the **Model** tab or choose **View > Model** from the menu bar.  
The **Model** tab is displayed.

**Select/clear all items**

**Result appears**  
OK: Normal  
Not OK: No response

No.	Model	Controller Mode	Control Output		Option	Tag Info	Comm.	Address	Status
			Loop 1	Loop 2					
01	UT130	Single	Normal			Detail Info.	Ether	localhost,01	
02	UT150	Single	Normal			Detail Info.	COM1	01	
03	UT150	Single	Normal			Detail Info.	COM1	02	
04	UT351	Single	Normal			Detail Info.	COM1	03	OK
05	UT351	Single	Normal			Detail Info.	COM1	04	OK
06	UT351	Single	Normal			Detail Info.	COM1	05	OK
07	UT351	Single	Normal			Detail Info.	COM1	06	OK
08	UT351	Single	Normal			Detail Info.	COM1	07	OK
09	UT351	Single	Normal			Detail Info.	COM1	08	OK
10	Not Connected						NONE		
13	Not Connected						NONE		
20	Not Connected						NONE		
21	Not Connected						NONE		

**Drag to select a range for collective setting or the loop back test**

**Click to clear the contents of the status**

2. Drag to select the numbers on which you wish to perform the loop back test.
3. Click the Loop Back Test button.  
The result appears in the status column.  
OK: Normal  
Not OK: No response

#### Note

- If the result is Not OK, check whether the communication settings of the software and target device match.
- If the loop back test will be performed on multiple devices, individual tests are performed even if a communication error occurs part way through.

## 2.5 Performing Communication Tests of Connected Devices

### Performing Read and Write Tests

You can check the data of the registers specified in the input tab page (monitor execution) by performing a read test.

Also, you can perform a write test to the registers specified in the output tab page during monitor execution.

#### Note


The Read and Write tests cannot be performed during data acquisition.

### Procedure


#### Performing a Read Test

1. Click the Detail Settings button in the **Model** Settings tab page of the model on which you wish to perform the read test.

The **Tag Setting** dialog box opens.



Click to display the Tag Settings dialog box



Monitor execution results

Output test results

Specifies the output values during the output test

Drag to select the tag on which to perform the output test

Monitor start button

Monitor Stop and Output Test Buttons

2. Click the **Start monitor** button.

The value of each tag from the instrument is loaded, and displayed in the loaded value column of the input tab sheet.

To quit monitor execution, proceed to step 6.

### Performing a Write Test

3. Specify the **Output Values** of the tags on which you wish to perform the **output test** in the output tab page.
4. Select the tags on which to perform the **output test**
5. Click the **Output Test** button.

The output values are written to registers, then the values are acquired from the write registers and the loaded results are displayed in the loaded value column in the output tab page.

### Stopping the Read Test

6. Click the **Stop monitor** button.  
The Read Test is concluded.

## 2.6 Checking the Client Connection Status and Communication Status of Connected Instruments, and Reconnecting Connected Instruments


### Checking the Client Connection Status and Communication Status of Connected Instruments

#### Procedure

#### Checking the Connection Status

1. Click the **Monitor/Status** tab or choose **View > Monitor/Status** from the menu bar. The Monitor/Status tab is displayed.

The client connection status and communication status of connected devices is displayed.



Indicator for the communication status with the connected device  
Green: Normal (comm. open)  
Red: Communication error  
Yellow: Data dropout occurred and communication is retried (communication paused)  
No display: Communication error (comm. paused)  
Double-click to display the Error Indicator dialog box

Displays the names of connected clients

#### Note


- If the communication status of a connected device is red, check whether a model, control mode, control output, or option in the Model Setting tab have the same settings as the connected device, and whether the communication method is correct.
- Data acquisition cannot be performed when the status is red.

### Viewing Error Detail

2. Double-click the status indicator under Communication Status. The **Error Indicator** dialog box opens.

Up to 100 of the most recent errors are displayed for each connection.

Errors are displayed in the order date/time of occurrence, error number, error contents, affected number, and affected system number.



See section 3.4 for error messages.

### **Note**

If a connected instrument experiences an error during communications, attempts are made to restore communications at the specified retry interval. If communication cannot be restored, the status indicator turns red. Retries are performed until communication is restored. To start communication manually, click the Retry Connection button.

### Reconnecting Connected Instruments


1. Select the instrument to reconnect.
2. Click the **Retry Connection** button.  
Communication with the selected device is reopened.

---

## 2.7 Viewing Version Information

### Procedure

1. Click the **About** button or choose **Help > About** from the menu bar.  
The **Version** dialog box opens.



## 3.1 Modbus Communication Device Settings

The default tag list in the Tag Settings dialog box that is displayed when you click the detail settings in the Model Settings tab determines the model, control mode, control output, and option function contents of the Model Settings tab.

The following describes the meanings of each tag that may appear in the Tag Settings dialog box.

Also, the tag names listed here are reserved. Arbitrarily added tags cannot be used. therefore the same serial and model settings as the connected device must be set on GateCONTROL.

- **Serial Port Settings (as Needed)**
  - Port number
  - Baud rate
  - Parity
- **Settings for the Connected Devices (Temperature Controllers and Signal conditioners)**
  - Serial Communications
    - Communication protocol
    - Baud rate
    - Parity
    - Stop bit
    - Data length
    - Communication Address
  - Ethernet Communications
    - IP address
    - Subnet mask
    - Default gateway

Enter communication parameters on devices connected to GateCONTROL in advance. For instructions, see the user's manual of the connected device.

### **Note**

The PC is connected to the instrument via an RS-232C/RS-485 converter. The connection can be made using a 4-wire or 2-method. When using the 2-wire method, disable echo back on the Converter.

### Settings for Connected Modbus Devices

Enter settings on the connected devices as follows.

Setting	Green Series UTAdvanced Series	UT1000 Series	US100	VJ Series	M Series
Baud rate	4800, 9600, 19200 or 38400				
Parity	ODD, EVEN, or NONE				
Stop bit	1	1	1	1	1
Data length	8	8	8	8	8
Communication protocol	8	4	1	MODBUS, RTU mode	4



## 3.2 Meanings of Tags of Connected Devices

The default tag list in the Tag Settings dialog box that is displayed when you click the detail settings in the Model Settings tab determines the model, control mode, control output, and option function contents of the Model Settings tab.

The following describes the meanings of each tag that may appear in the Tag Settings dialog box.

Also, the tag names listed here are reserved. Arbitrarily added tags cannot be used.

Tag Name	Meaning
PV1	Measurement input value on loop 1, or the measurement input value. The error status and alarm status of PV1 or the measurement input value is added. (See section 3.3 for information on handling error and alarm statuses.)
PV2	Measurement input value on loop 2. The error status and alarm status of PV2 is added.
SP1	Target setting value used on loop 1. SP1 related alarm statuses are added.
SP2	Target setting value used on loop 2. SP2 related alarm statuses are added.
OUT1	Control output value on loop 1. Control output value on loop 1. OUT1 related alarm statuses are added.
OUT2	Control output value on loop 2. Control output value on loop 2. OUT2 related alarm statuses are added.
HOUT1	For heating/cooling control on loop 1, or the control output value for heating. HOUT1 related alarm statuses are added.
HOUT2	For heating/cooling control on loop 2, or the control output value for heating. HOUT2 related alarm statuses are added.
COU1	For heating/cooling control on loop 1, or the control output value for cooling. COU1 related alarm statuses are added.
COU2	For heating/cooling control on loop 2, or the control output value for cooling. COU2 related alarm statuses are added.
A/M1	Auto/manual mode for loop 1 0: AUTO (automatic) mode, 1: MAN (manual) mode
A/M2	Auto/manual mode for loop 2 0: AUTO (automatic) mode, 1: MAN (manual) mode
C.A.M	Switch between manual/automatic/cascade 0: AUTO (automatic) mode, 1: MAN (manual) mode, 2: CAS (cascade) mode
R/L1	Remote/local mode on loop 1. 0: Local, 1: Remote
R/L2	Remote/local mode on loop 2. 0: Local, 1: Remote
SPNO	Target setting value number currently used
PIDNO1	PID number used on loop 1
PIDNO2	PID number used on loop 2
R/S	Running/Stopped status 0: Running, 1: Stopped
R/P/L	Program run reset/program mode 0: Program operation reset, 1: Program operation, 2: Local operation
R/P1/P2	Program run reset/program mode 1: Program operation reset, 2: Program 1 operation, 3: Program 2 operation
HOLD	Program operation pause mode 0: Program operation, 1: Program operation pause
PVEx	PV event status. x is the event number 0: Event OFF, 1: Event ON
TMEx	Time event status. x is the event number 0: Event OFF, 1: Event ON
PTNO	Number of currently operating program pattern
SEGNO	Number of currently operating segment

(Cont. on next page.)

### 3.2 Meanings of Tags of Connected Devices

Tag Name	Meaning
TIME	Remaining time of currently operating segment, or time elapsed during WAIT The units are seconds.
LSP/CAS	Local/Cascade mode 0: CAS (cascade) mode, 1: LSP (local) mode
C.A.M1	Cascade/auto/manual mode for loop 1 0: AUTO (automatic) mode, 1: MAN (manual) mode, 2: CAS (cascade) mode
C.A.M2	Cascade/auto/manual mode for loop 2 0: AUTO (automatic) mode, 1: MAN (manual) mode, 2: CAS (cascade) mode
O/C	CLOSE/OPEN mode 0: CLOSE mode, 1: OPEN mode
INPUT	Input value. The error status and alarm status are added. (See specific items for information on handling error and alarm statuses.)
ADVANCE	Segment forced transition 0: End of forced transition or not executed, 1: Segment forced transition
RUN	Program run/stop status 0: Stopped, 1: Running

---

## 3.3 Details on Functions

### Time Out Operation

When reading tag data, after sending a register value request message to the Modbus device, if the message is not received within the specified time out time that tag is considered to have timed out. If Use Retry is set to ON, for tags on which a timeout occurred, retries are attempted starting from the next acquisition interval at the specified retry interval until communication is restored.

If Retry is turned OFF, a retry is not performed on the tag on which a timeout occurred, and data reading is not performed for that tag thereafter.

To reopen communications after loading stops, choose the target device for communication in the Acquisition/Status tab, then click the Reconnect button.

#### **Note**

---

Using GateCONTROL, data can be acquired concurrently on each COM port. Therefore data is logged more efficiently when connecting each device to a separate port rather than connecting several devices to a single port.

---

## Error Status

The following shows the error statuses supported by each model. Also, the statuses are modified as shown before transfer to DAQLOGGER and Remote Monitor.

### UTAdvanced Series, Green Series, UT100 Series, US1000

Device Data Status	Data Display after Change
PV1 A/D converter error	ILLEGAL
PV1 RJC error	ILLEGAL
PV1 overscale	+OVER
PV1 underscale	-OVER
PV2 A/D converter error	ILLEGAL
PV2 RJC error	ILLEGAL
PV2 overscale	+OVER
PV2 underscale	-OVER

### VJ Series

Device Data Status	Data Display after Change
EEP error	ILLEGAL
EEP sum error	ILLEGAL
Low cut status	-OVER
A/D burnout	ILLEGAL
RJC error	ILLEGAL

### M Series

Device Data Status	Data Display after Change
Low cut status	-OVER
Input over	+OVER
Input under	-OVER
EEP sum error	ILLEGAL
Parameter error	ILLEGAL
RJC error	ILLEGAL
EEP error	ILLEGAL

### Note

- When connected to a UT52A or UT55A, if a PV1 A/D converter error occurs, the PV1 value is displayed instead of ILLEGAL.
- When connected to a UT52A or UT55A, if a PV2 A/D converter error or a PV2 RJC error occurs, the PV2 value is displayed instead of ILLEGAL.
- When connected to a UT32A, UT35A, UT52A, or UT55A, if a PV1 RJC error occurs, the PV1 value is displayed instead of ILLEGAL.
- A/D converter and RJC errors (PV1 and PV2 ) of the UP55A are not supported.

### 3.3 Details on Functions

## Processing Alarm Statuses

Each model's alarm types are changed as follows before being sent to DAQLOGGER and Remote Monitor.

Alarm Type on Device Side	Alarm Type after Change		
	PV	SP	OUT, HOUT, COUT
PV high limit	PV high limit [H]	—	—
PV low limit	PV low limit [L]	—	—
Deviation high limit	Deviation high limit [DH]	—	—
Deviation low limit	Deviation low limit [DL]	—	—
De-energized on deviation high limit alarm	Deviation high limit [DH]	—	—
De-energized on deviation low limit alarm	Deviation low limit [DL]	—	—
Deviation high and low limit	Other [ETC]	—	—
Deviation within high and low limit	Other [ETC]	—	—
De-energized on PV high limit	PV high limit [H]	—	—
De-energized on PV low limit	PV low limit [L]	—	—
PV high limit (with idle mode)	PV high limit [H]	—	—
PV low limit (with idle mode)	PV low limit [L]	—	—
Deviation high limit (with idle mode)	Deviation high limit [DH]	—	—
Deviation low limit (with idle mode)	Deviation low limit [DL]	—	—
De-energize on deviation high limit alarm (with idle mode)	Deviation high limit [DH]	—	—
De-energize on deviation low limit alarm (with idle mode)	Deviation low limit [DL]	—	—
Deviation high and low limit (with idle mode)	Other [ETC]	—	—
Deviation within high and low limit (with idle mode)	Other [ETC]	—	—
De-energized on PV high limit (with idle mode)	PV high limit [H]	—	—
De-energized on PV low limit (with idle mode)	PV low limit [L]	—	—
Timer function upward (hour/minute)	Other [ETC]	—	—
Timer function downward (hour/minute)	Other [ETC]	—	—
Timer function upward (minute/second)	Other [ETC]	—	—
Timer function downward (minute/second)	Other [ETC]	—	—
Sensor grounding alarm	Other [ETC]	—	—
Fault diagnosis output	Other [ETC]	—	—
FAIL output	Other [ETC]	—	—
Timer function	Other [ETC]	—	—
De-energized on timer function	Other [ETC]	—	—
Heater burnout alarm 1	Other [ETC]	—	—
Heater burnout alarm 2	Other [ETC]	—	—
Heater burnout	Other [ETC]	—	—
SP high limit	Other [ETC]	SP high limit [H]	—
SP low limit	Other [ETC]	SP low limit [L]	—
Output high limit	Other [ETC]	—	Output high limit [H]
Output low limit	Other [ETC]	—	Output low limit [L]
PV velocity alarm	Other [ETC]	—	—
PV velocity alarm passive	Other [ETC]	—	—
Self-diagnostic alarm	Other [ETC]	—	—
Self-diagnostic alarm passive	Other [ETC]	—	—
FAIL passive	Other [ETC]	—	—
Deviation high limit for target setpoint	Other [ETC]	Deviation high limit [DH]	—
Deviation low limit for target setpoint	Other [ETC]	Deviation low limit [DL]	—

(cont. on next page)

Alarm Type on Device Side	Alarm Type after Change		
	PV	SP	OUT, HOUT, COUT
De-energized on deviation high limit alarm for target setpoint	Other [ETC]	Deviation high limit [DH]	—
De-energized on deviation low limit alarm for target setpoint	Other [ETC]	Deviation low limit [DL]	—
De-energized on deviation high and low limits for target setpoint	Other [ETC]	Other [ETC]	—
Deviation within high and low limits for target setpoint	Other [ETC]	Other [ETC]	—
Deviation high limit with stand-by actions for setpoint	Other [ETC]	Deviation high limit [DH]	—
Deviation low limit with stand-by actions for setpoint	Other [ETC]	Deviation low limit [DL]	—
De-energized on deviation high limit alarm with stand-by actions for target setpoint	Other [ETC]	Deviation high limit [DH]	—
De-energized on deviation low limit alarm with stand-by actions for target setpoint	Other [ETC]	Deviation low limit [DL]	—
Deviation high or low limit with stand-by actions for setpoint	Other [ETC]	Other [ETC]	—
Deviation within high and low limits with stand-by actions for target setpoint	Other [ETC]	Other [ETC]	—
Target SP high limit	Other [ETC]	SP high limit [H]	—
Target SP low limit	Other [ETC]	SP low limit [L]	—
Cooling-side control output high limit	Other [ETC]	—	Output high limit [H]
Cooling-side control output low limit	Other [ETC]	—	Output low limit [L]
Analog input PV high limit	Other [ETC]	—	—
Analog input PV low limit	Other [ETC]	—	—
Analog input RSP high limit	Other [ETC]	—	—
Analog input RSP low limit	Other [ETC]	—	—
Analog input AIN2 high limit	Other [ETC]	—	—
Analog input AIN2 low limit	Other [ETC]	—	—
Analog input AIN4 high limit	Other [ETC]	—	—
Analog input AIN4 low limit	Other [ETC]	—	—
Feedback input high limit	Other [ETC]	—	—
Feedback input low limit	Other [ETC]	—	—

Displayed in brackets ([ ]) on DAQLOGGER and Remote Monitor.

Furthermore, for the VJ series, all alarm types are Other [ETC].

Alarm types are loaded from each connected device upon start of acquisition by GateCONTROL. Even if alarm types are changed on the connected device after acquisition starts, the alarm types valid upon start of acquisition are used.


The number of UT551 and UT520 alarms is four (fixed). To ensure compatibility, also set the number of UT55A and UT52A alarms to four.

The number of UT351 and UT321 alarms is three (fixed). To ensure compatibility, also set the number of UT35A and UT32A alarms to three.

The number of UP550 and UM331 alarms is four (fixed). To ensure compatibility, also set the number of UP55A and UM33A alarms to four.

The number of UP35A alarms is two (fixed).

## Output Processing



### Function

- The output request from the client is stored in the output request storage buffer.
- The output request storage buffer is checked for an output execution every second, and output is executed on the instrument if an output request is found. Then, the output request storage buffer is cleared.
- Output request storage buffer is set to hold the most recent value, so if multiple writings to the same tag occur during the confirmation interval, the written value becomes the most recent one.
- An instrument is either outputting or acquiring, and acquisition execution is put on hold until output execution is finished, and vice versa. Therefore, acquisition or output execution may be delayed.  
Also, time may be required for output execution. If so, it can occur more slowly than the one-second confirmation interval.

### Writing of the SP Value

During output execution, SPNO is acquired from the instrument. SP value output is executed on the register corresponding to this SPNO.

## 3.4 Notes When Performing Communications with Software on Other PCs

### Communications with DAQLOGGER

- When performing communications with DAQLOGGER, set the IP address of the device with which DAQLOGGER will connect on the address of the PC that GateCONTROL is operating, then execute automatic model determination.
- On DAQLOGGER, all devices connected to GateCONTROL (temperature controllers and signal conditioners) are considered a single system. Therefore, the following should be noted.
  - DAQLOGGER's automatic model determination determines only the lowest-numbered device if multiple devices are connected to GateCONTROL (temperature controllers and signal conditioners). For determination of the other devices, specify the port number and system number (a number that is 1 less than the number in the GateCONTROL's Model Settings tab) in the DAQLOGGER settings, then execute the automatic model determination function.
  - When connecting all devices connected to GateCONTROL to DAQLOGGER as one system, specify "No system number" in the address setting screen, then execute automatic model determination.

### Communications with DAQLOGGER Client Package

Check the port number (initial value is 50299) and system number set in GateCONTROL, then reconnect. The logic behind the system numbers is the same as that for DAQLOGGER.

### GateCONTROL Settings

Set the same serial and model settings as the connected device on GateCONTROL.



## 3.5 Error Messages and Corrective Actions

A message (such as an error message) may appear during operation. The following describes the meanings of the messages and their corrective actions.

### Error

Code	Description	Corrective Action
E211	Cannot write to the file.	Confirm that the disc capacity and file system are correct.
E212	Cannot read file.	Confirm that a file exists, that the software supports it, and whether the file system is correct.
E213	Cannot open the file.	Confirm that a file exists, that the software supports it, and whether the file system is correct.
E501	Invalid license number. Please reinstall.	With the Gate series, the number of licenses purchased is the limit for the number of programs run at the same time. Reinstall the software.
E1010	Execution failed.	Confirm that the file is not corrupt. If this error appears repeatedly, reinstall the software.

### Message

Code	Description
M1210	Save the setting changes and try again.

### Messages during (When Executing) Data Acquisition

Code	Description	Cause/Corrective Actions
W[631]	Data Lack	Data was unexpectedly lost. Reduce the number of acquired data points or connected instruments, or lengthen the scan interval.
E[674]	Communication error	Communication Errors Check whether the power to the connected measuring instruments with which you wish to open communications is ON, and whether the cables are connected correctly. Also check the following. <ul style="list-style-type: none"><li>• For Ethernet Is the address correct, is the TCP/IP protocol installed in Windows, and is the Ethernet card installed correctly?</li><li>• For RS-232 and RS-422-A Are the baud rate, port numbers (COM1–COM9), and addresses (RS422) correct? Is the PC serial port valid? Is the cable type correct?</li></ul>
E[675]	Communication time out	Communication timeout Same as E[674].
E[800]	CRC check error	CRC check error A CRC error was detected. Check the communication status.
E[801]	Invalid handle	Failed to get communication handle. Check the communication status.
E[802]	Error respond	Invalid data received. Check the communication status.
W[880]	Do not specify communication port	Specify the communication parameters.
W[881]	Current connecting model configuration is mismatch! The model is:	Change the parameters for the main unit.
W[884]	Retry connection	Connection recovered.

# Index

## A

alarm statuses ..... 3-6  
 automatic model determination ..... 2-4

## C

client connection status ..... 2-18  
 communication device settings ..... 3-1

## E

error messages ..... 3-10  
 error status ..... 3-5  
 exiting the software ..... 2-1

## H

hardware requirements ..... 1-3

## I

IP address ..... 2-3

## L

loop back test ..... 2-15

## M

meanings of tags ..... 3-2  
 Modbus address ..... 2-4

## O

output processing ..... 3-8  
 overview ..... 1-1

## P

port number ..... 2-3, 2-6

## R

read tests ..... 2-16  
 running the software ..... 2-1

## S

saving environment settings ..... 2-12  
 serial port settings ..... 2-2  
 server port ..... 2-6  
 settings for connected Modbus devices ..... 3-1  
 software license ..... ii  
 software requirements ..... 1-3  
 starting data acquisition ..... 2-13  
 system ..... 1-2  
 system configuration ..... 1-4

## T

tag settings ..... 2-7  
 TCP/IP settings ..... 2-6  
 time out operation ..... 3-4

## V

version information ..... 2-20

## W

write tests ..... 2-16