

PCAN-ExpressCard 34

CAN Interface for the
ExpressCard/34 Slot

User Manual



Document version 1.1.0 (2015-06-16)

PEAK
System

Products taken into account

Product Name	Model	Part Number
PCAN-ExpressCard 34	One CAN channel	IPEH-003004

CANopen® and CiA® are registered community trade marks of CAN in Automation e.V.

All other product names mentioned in this document may be the trademarks or registered trademarks of their respective companies. They are not explicitly marked by "™" and "®".

Copyright © 2015 PEAK-System Technik GmbH

Duplication (copying, printing, or other forms) and the electronic distribution of this document is only allowed with explicit permission of PEAK-System Technik GmbH. PEAK-System Technik GmbH reserves the right to change technical data without prior announcement. The general business conditions and the regulations of the license agreement apply. All rights are reserved.

PEAK-System Technik GmbH
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

Phone: +49 (0)6151 8173-20
Fax: +49 (0)6151 8173-29

www.peak-system.com
info@peak-system.com

Document version 1.1.0 (2015-06-16)

Contents

1	Introduction	5
1.1	Properties at a Glance	5
1.2	Prerequisites for Operation	6
1.3	Scope of Supply	6
2	Installing the Software and the Card	7
3	Connecting the CAN Bus	8
3.1	D-Sub Connector	8
3.2	Cabling	8
3.2.1	Termination	8
3.2.2	Example of a Connection	9
3.2.3	Maximum Bus Length	9
4	Operation	10
4.1	Status LED	10
4.2	Removing the Adapter	10
5	Software and API	11
5.1	Monitor Software PCAN-View	11
5.1.1	Receive/Transmit Tab	14
5.1.2	Trace Tab	16
5.1.3	PCAN-ExpressCard 34 Tab	17
5.1.4	Status Bar	17
5.2	Linking Own Programs with PCAN-Basic	18
5.2.1	Features of PCAN-Basic	19
5.2.2	Principle Description of the API	20
5.2.3	Notes about the License	21
6	Technical specifications	22

Appendix A	CE Certificate	24
Appendix B	Dimension Drawing	25
Appendix C	Quick Reference	26

1 Introduction

The CAN adapter PCAN-ExpressCard 34 allows the connection of a CAN bus to embedded PCs and laptops with ExpressCard slots. A galvanic isolation of up to 300 Volts decouples the PC from the CAN bus. Device drivers and programming interfaces exist for different operating systems, so programs can easily access a connected CAN bus.



Tip: At the end of this manual (Appendix C) you can find a Quick Reference with brief information about the installation and operation of the PCAN-ExpressCard 34.

1.1 Properties at a Glance

- └ Card for ExpressCard slot
- └ Type ExpressCard/34 (compatible with ExpressCard/54 slots)
- └ 1 High-speed CAN channel (ISO 11898-2)
- └ Compliant with CAN specifications 2.0A (11-bit ID) and 2.0B (29-bit ID)
- └ Bit rates from 5 kbit/s up to 1 Mbit/s
- └ CAN bus connection via D-Sub, 9-pin (in accordance to CiA® 102)
- └ FPGA implementation of the CAN controller (SJA1000 compatible)
- └ NXP PCA82C251 CAN transceiver
- └ Galvanic isolation on the CAN connection up to 300 V
- └ Extended operating temperature range from -40 to 85 °C (-40 to 185 °F)



Note: This manual describes the use of the PCAN-ExpressCard 34 with **Windows**. You can find device drivers for **Linux** and the corresponding application information on the provided DVD in the directory branch `Develop` and on our website under www.peak-system.com/linux.

1.2 Prerequisites for Operation

- ExpressCard slot in the computer, type ExpressCard/34
- Operating system Windows 8.1, 7, Vista (32/64-bit) or Linux (32/64-bit)

1.3 Scope of supply

- PCAN-ExpressCard 34 CAN interface
- Device drivers for Windows 8.1, 7, Vista and Linux (32/64-bit)
- PCAN-View CAN monitor for Windows 8.1, 7, Vista (32/64-bit)
- PCAN-Basic programming interface consisting of an interface DLL, examples, and header files for all common programming languages
- Manual in PDF format

2 Installing the Software and the Card

This chapter covers the software setup for the PCAN-ExpressCard 34 under Windows and the installation in the computer.

Setup the driver before connecting the PCAN-ExpressCard 34 for the first time.

▶ Do the following to install the driver:

1. Insert the supplied DVD into the appropriate drive of the computer. Usually a navigation program appears a few moments later. If not, start the file `Intro.exe` from the root directory of the DVD.
2. In the main menu, select **Drivers**, and then click on **Install now**.
3. Confirm the message of the User Account Control regarding the "Installer Database of PEAK Drivers".

The setup program for the driver is started.

4. Follow the instructions of the program.

▶ Do the following to connect the PCAN-ExpressCard 34 to the computer and complete the initialization:

1. Insert the PCAN-ExpressCard 34 into an ExpressCard slot of your computer. The computer can remain powered on.

Windows notifies that new hardware has been detected. The drivers are found and installed by Windows.

After the initialization process is finished successfully the red LED on the PCAN-ExpressCard 34 is illuminated. Furthermore, you can find the entry "PCAN-ExpressCard 34" in the branch "CAN-Hardware" of the Windows Device Manager.

3 Connecting the CAN Bus

3.1 D-Sub Connector

A High-speed CAN bus (ISO 11898-2) is connected to the 9-pin D-Sub connector. The pin assignment corresponds to the specification CiA® 102.




Figure 1: Pin assignment High-speed CAN

3.2 Cabling

3.2.1 Termination

A High-speed CAN bus (ISO 11898-2) must be terminated on both ends with 120 Ohms. Otherwise, there are interfering signal reflections and the transceivers of the connected CAN nodes (CAN interface, control device) will not work.

The PCAN-ExpressCard 34 does not have an internal termination. Use the adapter on a terminated CAN bus.

3.2.2 Example of a Connection




Figure 2: Simple CAN connection

In this example, the PCAN-ExpressCard 34 is connected with a control unit by a cable that is terminated at both ends.

3.2.3 Maximum Bus Length

High-Speed-CAN networks may have bit rates of up to 1 Mbit/s. The maximum bus length depends primarily on the bit rate.

The following table shows the maximum possible CAN bus length at different bit rates:

Bit rate	Bus length
1 Mbit/s	40 m
500 kbit/s	110 m
250 kbit/s	240 m
125 kbit/s	500 m
50 kbit/s	1.3 km
20 kbit/s	3.3 km
10 kbit/s	6.6 km
5 kbit/s	13.0 km

The listed values have been calculated on the basis of an idealized system and can differ from reality.

4 operation

4.1 Status LED

The PCAN-ExpressCard 34 has a status LED which may be in one of the following conditions:

Status LED	Meaning
On	There's a connection to a driver of the operating system.
Slow blinking	A software application is connected to the CAN channel.
Quick blinking	Data is transmitted via the connected CAN bus.

4.2 Removing the Adapter

Under Windows the icon for removing hardware safely is not used with the PCAN-ExpressCard 34. You may remove the card from the computer without any preparation under Windows.

5 software and API

This chapter covers the provided software PCAN-View and the programming interface PCAN-Basic.

5.1 Monitor Software PCAN-View

PCAN-View is simple Windows software for viewing, transmitting, and logging CAN- and CAN FD messages.



Note: This chapter describes the use of PCAN-View with a CAN adapter.




Figure 3: PCAN-View for Windows

▶ Do the following to start and initialize PCAN-View:

1. Open the Windows Start menu or the Windows Start page and select the entry **PCAN-View**.

The dialog box for selecting the hardware and for setting the parameters appears.




Figure 4: Selection of the specific hardware and parameters

2. From the list **Available PCAN hardware**, select the desired interface to be used.
3. Select the bit rate that is used by all nodes on the CAN bus from the drop-down list **Bit rate**. Use the button to the right of the drop-down list to create User-defined bit rates.
4. Under **Filter settings** you can limit the range of CAN IDs to be received, either for standard frames (11-bit IDs) or for extended frames (29-bit IDs).

5. Activate the **Listen-only mode** if you do not actively participate in the CAN traffic and just want to observe. This also avoids an unintended disruption of an unknown CAN environment (e.g. due to different bit rates).
6. Finally, confirm the settings in the dialog box with **OK**. The main window of PCAN-View appears (see Figure 5).

5.1.1 Receive/Transmit Tab




Figure 5: Receive/Transmit tab

The Receive/Transmit tab is the main element of PCAN-View. It contains two lists, one for received messages and one for the transmit messages. Representation of CAN data is in hexadecimal format.

Do the following to transmit a CAN message with PCAN-View:

1. Select the menu command **Transmit > New Message** (alternatively  or **Ins**).

The dialog box **New Transmit Message** is shown.




Figure 6: Dialog box new transmit message

2. Enter the ID and the data for the new CAN message.
3. The field **Cycle Time** indicates if the message shall be transmitted manually or periodically. If you want to transmit the message periodically, you must enter a value greater than 0. For a manual-only transmission enter 0.
4. Confirm the entries with **OK**.

The created transmit message appears on the **Receive/Transmit** tab.

5. You trigger selected transmit messages manually with the menu command **Transmit > Send** (alternatively **Space** bar). The manual transmission for CAN messages being transmitted periodically is carried out additionally.



Tip: Using the menu command **File > Save** the current transmit messages can be saved to a list and loaded for reuse later on.

5.1.2 Trace Tab




Figure 7: Trace tab

On the Trace tab the data tracer of PCAN-View is used for logging the communication on a CAN bus. During this process the CAN messages are cached in the working memory of the PC. Afterwards they can be saved to a file.

The tracer can be configured to run in linear or in ring buffer mode. In linear buffer mode the logging is stopped as soon as the buffer is filled completely. In ring buffer mode the oldest messages are overwritten by incoming ones.

5.1.3 PCAN-ExpressCard 34 Tab




Figure 8: PCAN-PCI tab (example)

On the PCAN-ExpressCard 34 tab various information about your hardware is displayed, like the current device driver version.

5.1.4 Status Bar



Figure 9: Example of the status bar

The status bar shows information about the current CAN connection, about error counters (Overruns, QXmtFull), and shows error messages.

You can find further information about the use of PCAN-View in the help which you can invoke in the program via the **Help** menu or with the **F1** key.

5.2 Linking Own Programs with PCAN-Basic




Figure 10: PCAN-Basic

On the provided DVD you can find files of the programming interface PCAN-Basic in the directory branch `Develop`. This API provides basic functions for linking own programs to CAN- and CAN FD interfaces by PEAK-System and can be used for the following operating systems:

- └ Windows 8.1, 7, Vista (32/64-bit)
- └ Windows CE 6.x (x86/ARMv4)
- └ Linux (32/64-bit)

The API is designed for cross-platform use. Therefore software projects can easily be ported between platforms with low efforts. For all common programming languages examples are available.

Beginning with version 4, PCAN-Basic supports the new CAN FD standard (CAN with Flexible Data Rate) which is primarily characterized by higher bandwidth for data transfer.

5.2.1 Features of PCAN-Basic

- └ API for developing applications with CAN and CAN FD connection
- └ Access to the CAN channels of a PCAN-Gateway via the new PCAN-LAN device type
- └ Supports the operating systems Windows 8.1, 7, Vista (32/64-bit), Windows CE 6.x, and Linux (32/64-bit)
- └ Multiple PEAK-System applications and your own can be operated on a physical channel at the same time
- └ Use of a single DLL for all supported hardware types
- └ Use of up to 16 channels for each hardware unit (depending on the PEAK CAN interface used)
- └ Simple switching between channels of a PEAK CAN interface
- └ Driver-internal buffer for 32,768 messages per CAN channel
- └ Precision of time stamps on received messages up to 1 μ s (depending on the PEAK CAN interface used)
- └ Supports PEAK-System's trace formats version 1.1 and 2.0 (for CAN FD applications)
- └ Access to specific hardware parameters, such as listen-only mode
- └ Notification of the application through Windows events when a message is received
- └ Extended system for debugging operations
- └ Multilingual debugging output
- └ Output language depends on operating system
- └ Debugging information can be defined individually

An overview of the API functions is located in the header files. You can find detailed information about the PCAN-Basic API on the provided DVD in the text and help files (file name extensions `.txt` and `.chm`).

5.2.2 Principle Description of the API

The PCAN-Basic API is the interface between the user application and device driver. In Windows operating systems this is a DLL (Dynamic Link Library).

The sequence of accessing the CAN interface is divided into three phases:

1. Initialization
2. Interaction
3. Completion

Initialization

A channel must be initialized before using it. This is done by the simple call of the function `CAN_Initialize` for CAN and `CAN_InitializeFD` for CAN-FD. Depending on the type of the CAN hardware, up to 16 CAN channels can be opened at the same time. After a successful initialization the CAN channel is ready for communication with the CAN hardware and the CAN bus. No further configuration steps are required.

Interaction

For receiving and transmitting messages the functions `CAN_Read` and `CAN_Write` as well as `CAN_ReadFD` and `CAN_WriteFD` are available. Additional settings can be made, e.g. setting up message filters to confine to specific CAN IDs or setting the CAN controller to listen-only mode.

When receiving CAN messages, events are used for an automatic notification of an application (client). This offers the following advantages:

- └ The application no longer needs to check for received messages periodically (no polling).
- └ The response time at reception is reduced.

Completion

To end the communication the function `CAN_Uninitialize` is called in order to release the reserved resources for the CAN channel, among others. In addition the CAN channel is marked as "Free" and is available to other applications.

5.2.3 Notes about the License

Device drivers, the interface DLL, and further files needed for linking are property of the PEAK-System Technik GmbH and may be used only in connection with a hardware component purchased from PEAK-System or one of its partners. If a CAN hardware component of third-party suppliers should be compatible to one of PEAK-System, then you are not allowed to use or to pass on the driver software of PEAK-System.

If a third-party supplier develops software based on the PCAN-Basic and problems occur during the use of this software, consult the software provider.

6 Technical specifications

Connectors

Computer	ExpressCard slot, type ExpressCard/34
CAN	D-Sub (m), 9 pins Pin assignment according to specification CiA® 102

CAN

Specification	ISO 11898-2, High-speed CAN 2.0A (standard format) and 2.0B (extended format)
Bit rates	5 kbit/s - 1 Mbit/s
Controller	FPGA implementation (SJA1000 compatible)
Transceiver	NXP PCA82C251
Galvanic isolation	Up to 300 V
Termination	none

Supply

Supply voltage	1.5 V und 3.3 V
Current consumption	1.5 V: max. 180 mA 3.3 V: max. 330 mA

Measures

Size	108 x 37 x 20 mm (L x W x D) See also dimension drawing in Appendix B on page 25
Weight	32 g

Environment

Operating temperature	-40 - 85 °C (-40 - 185 °F)
Temperature for storage and transport	-40 - 85 °C (-40 - 185 °F)
Relative humidity	15 - 90 %, not condensing
EMC	EN 55024:2011-09 EN 55022:2011-12 EC directive 2004/108/EG
Ingress protection (IEC 60529)	IP30

Appendix A CE Certificate

PCAN-ExpressCard 34 IPEH-003004 – EC Declaration of Conformity
PEAK-System Technik GmbH



Notes on the CE Symbol

The following applies to the "PCAN-ExpressCard 34" product with the item number(s) IPEH-003004.

EC Directive This product fulfills the requirements of EU EMC Directive 2004/108/EG (Electromagnetic Compatibility) and is designed for the following fields of application as for the CE marking:

Electromagnetic Immunity

DIN EN 55024, publication date 2011-09
Information technology equipment – Immunity characteristics – Limits and methods of measurement (CISPR 24:2010);
German version EN 55024:2010

Electromagnetic Emission

DIN EN 55022, publication date 2011-12
Information technology equipment – Radio disturbance characteristics – Limits and methods of measurement (CISPR 22:2008, modified);
German version EN 55022:2010

Declarations of Conformity In accordance with the above mentioned EU directives, the EC declarations of conformity and the associated documentation are held at the disposal of the competent authorities at the address below:

PEAK-System Technik GmbH

Mr. Wilhelm
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

Phone: +49 (0)6151 8173-20
Fax: +49 (0)6151 8173-29
E-mail: info@peak-system.com

A handwritten signature in black ink, appearing to read "U. Wilhelm".

Signed this 2nd day of June 2014

Appendix B Dimension Drawing




Figure 11: Side view and top view of the PCAN-ExpressCard 34

The figure does not show the actual size of the product.

Appendix C Quick Reference

Software/Hardware Installation under windows

Before connecting the PCAN-ExpressCard 34 to the computer set up the corresponding software package from the supplied DVD (with administrator privileges). Afterwards insert the card into a ExpressCard slot of the computer. The card is recognized by Windows and the driver is initialized. After the installation process is finished successfully, an LED is on for each CAN channel of the card. After the installation process is finished successfully you can find the entry "PCAN-ExpressCard 34" in the branch "CAN-Hardware" of the Windows Device Manager.

Getting Started under windows

Run the CAN monitor PCAN-View from the Windows Start menu as a sample application for accessing the PCAN-ExpressCard 34. For initialization of the card select the CAN connection and the CAN bit rate.

Status LED	Meaning
On	There's a connection to a driver of the operating system.
Slow blinking	A software application is connected to the CAN channel.
Quick blinking	Data is transmitted via the connected CAN bus.

High-speed CAN connector (D-Sub, 9 pins)

