Programmable DC Power Supply

PSU Series

PROGRAMMING MANUAL

Revision 1.4 October 2015





This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance

Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

procedures at any time without notice.



Table of Contents

SAFETY INS	TRUCTIONS	4
GETTING S	TARTED	8
	PSU Series Overview	9
	Appearance	13
	Configuration Settings	21
REMOTE CO	ONTROL	30
	Interface Configuration	31
	Command Syntax	
	Command List	58
	Status Register Overview	113
	Error List	124
APPENDIX .		133
	PSU Default Settings	133
	Error Messages & Messages	
	LED ASCII Table Character Set	136
INDEX		137



SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to insure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the instrument.

<u></u>	WARNING
---------	---------

Warning: Identifies conditions or practices that could result in injury or loss of life.



Caution: Identifies conditions or practices that could result in damage to the PSU or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Earth (ground) Terminal





Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline



- Do not place any heavy object on the PSU.
- Avoid severe impact or rough handling that leads to damaging the PSU.
- Do not discharge static electricity to the PSU.
- Use only mating connectors, not bare wires, for the terminals.
- Do not block the cooling fan opening.
- Do not disassemble the PSU unless you are qualified.

(Measurement categories) EN61010-1:2010 and EN61010-2-030 specifies the measurement categories and their requirements as follows. The PSU falls under category II.

- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.
- 0 is for measurements performed on circuits not directly connected to Mains.

Power Supply



- AC Input voltage range: 85Vac~265Vac
- Frequency: 47Hz to 63Hz
- To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.



- Cleaning the PSU Disconnect the power cord before cleaning.
 - Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
 - Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone.

Operation **Environment**

- Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)
- Relative Humidity: 20%~ 85% (no condensation)
- Altitude: < 2000m
- Temperature: 0°C to 50°C

(Pollution Degree) EN61010-1:2010 and EN61010-2-030 specifies the pollution degrees and their requirements as follows. The PSU falls under degree 2.

Pollution refers to "addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity".

- Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
- Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
- Pollution degree 3: Conductive pollution occurs, or dry, nonconductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.

Storage environment

- Location: Indoor
- Temperature: -25°C to 70°C
- Relative Humidity: ≤90%(no condensation)

Disposal



Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.



Power cord for the United Kingdom

When using the power supply in the United Kingdom, make sure the power cord meets the following safety instructions.

NOTE: This lead/appliance must only be wired by competent persons

 $extstyle{!}$ WARNING: THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in this lead are coloured in accordance with the

following code:

Green/ Yellow: Earth
Blue: Neutral
Brown: Live (Phase)



As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol \oplus or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.



GETTING STARTED

This chapter describes the power supply in a nutshell, including its main features and front / rear panel introduction. After going through the overview, please read the theory of operation to become familiar with the operating modes, protection modes and other safety considerations.



PSU Series Overview		c
Series lineup		
Main Features	10	
Accessories	11	
Appearance	•••••	13
PSU Series Front Panel		
PSU Series Display and Operation Panel	16	
Rear Panel		



PSU Series Overview

Series lineup

The PSU series consists of 5 models, covering a number of different current, voltage and power capacities:

Model name	Voltage Rating ¹	Current Rating ²	Power
PSU 6-200	6V	200A	1200W
PSU 12.5-120	12.5V	120A	1500W
PSU 20-76	20V	76A	1520W
PSU 40-38	40V	38A	1520W
PSU 60-25	60V	25A	1500W

¹Minimum voltage guaranteed to 0.2% of rating voltage.

²Minimum current guaranteed to 0.4% of rating current.



Main Features

Performance

- High power density: 1500W in 1U
- Universal input voltage 85~265Vac, continuous operation.
- Output voltage up to 60V, current up to 200A.

Features

- · Active power factor correction.
- Parallel master/slave operation with active current sharing.
- Remote sensing to compensate for voltage drop in load leads.
- 19" rack mounted ATE applications.
- A built-in Web server.
- OVP, OCP and OHP protection.
- Preset memory function.
- Adjustable voltage and current slew rates.
- Bleeder circuit ON/OFF setting.
- CV, CC priority start function. (prevents overshoot with output ON)
- Supports test scripts.

Interface

- Built-in RS-232/485, LAN and USB interface.
- Analog output programming and monitoring.
- Optional interfaces: GPIB, Isolated Voltage (0-5V/0-10V) and Isolated Current (4-20mA) programming and monitoring interface. (Factory options)



Accessories

Before using the PSU power supply unit, check the package contents to make sure all the standard accessories are included.

Standard Accessories	Part ni	umber	Descri	ption	Qty.
			Outpu	t terminal cover	1
			Analog	g connector plug kit	1
			Outpu	t terminal M8 bolt set	1
			Input 1	terminal cover	1
	62SB-8	3K0HD101	1U Ha	ndle, ROHS	2
	62SB-8	3K0HP101	1U BR	ACKET (LEFT), RoHS	1
	62SB-8	3K0HP201	1U BR	ACKET (RIGHT), RoHS	1
	CD RC	DΜ	User n	nanual, Programming al	1 set
			Quick	start guide	1
	82SU-	062H0K01	Packin	g list	
	82GW	-00000C01	* CTC USE ,F	GW/INSTEK JAPAN RoHS	1
Factory Insta Options	ılled	Part number		Description	
		PSU-GPIB		GPIB interface	
		PSU-ISO-V		Voltage programming is analog interface	olated
		PSU-ISO-I		Current programming is analog interface	olated




Optional Accessories	Part number	Description
	PSU-01C	Cable for 2 units of PSU-Series in parallel mode connection
	PSU-01B	Bus Bar for 2 units of PSU-Series in parallel mode connection
	PSU-02C	Cable for 3 units of PSU-Series in parallel mode connection
	PSU-02B	Bus Bar for 3 units of PSU-Series in parallel mode connection
	PSU-03C	Cable for 4 units of PSU-Series in parallel mode connection
	PSU-03B	Bus Bar for 4 units of PSU-Series in parallel mode connection
	PSU-232	RS232 cable with DB9 connector kit
	PSU-485	RS485 cable with DB9 connector kit
	GRM-001	Rack-mount slides (General Devices P/N: C-300-S-116-RH-LH)
	GTL-246	USB Cable 2.0-A-B Type, Approx. 1.2M
	GPW-001	Power Cord SJT 12AWG/3C, 3m MAX Length, 105 °C, RNB5-5*3P UL/CSA type
	GPW-002	Power Cord H05W-F 1.5mm ² /3C, 3m MAX Length, 105 °C, RNB5-5*3P VDE type
	GPW-003	Power Cord VCTF 3.5mm ² /3C, 3m MAX Length, 105 °C, RNB5-5*3P PSE type
Download	Name	Description
	psu_cdc.inf	PSU USB driver
Other	Name	Description
	0	

Certificate of traceable calibration

Appearance

PSU Series Front Panel



1. Power Switch



Used to turn the power on/off.

2. USB A Port



USB A port for data transfer, loading test scripts etc.

3. Air Inlet

Air inlet for cooling the inside of the PSU series.

4. Voltage Knob



Used to set the voltage value or select a parameter number in the Function settings.

Display Area The display area shows setting values, output values and parameter settings. The function LEDs below show the current status and mode of the power supply. See page 16 for details.

5. Current Knob



Displays the current or the value of a Function parameter.



6.	Lock/Local Button	Lock/Local Unlock	Used to lock all front panel buttons other than the Output Button or it switches to local mode.
	Unlock Button		(Long push) Used to unlock the front panel buttons.
7.	PROT Button	PROT	Used to set and display OVP, OCP and UVL.
	ALM_CLR Button	ALM_CLR	(Long push) Used to release protection functions that have been activated.
8.	Function Button	Function	Used to configure the various function.
	M1 Button	М1	(+Shift) Used to recall the M1 setup. (+Shift and hold) Used to save the current setup to M1.
9.	Test Button	TEST	Used to run customized scripts for testing.
	M2 Button	M2	(+Shift) Used to recall the M2 setup. (+Shift and hold) Used to save the current setup to M2.
10.	Set Button	SET	Used to set and confirm the output voltage and output current.
	M3 Button	МЗ	(+Shift) Used to recall the M3 setup. (+Shift and hold) Used to save the current setup to M3.




LED

Shift Button Shift Used to enable the functions that are written in blue characters below the button.
 Output Button Used to turn output on and off.
 Output ON Lights in green during output ON.



PSU Series Display and Operation Panel

Display Area




- 14. Voltage Displays the voltage or the parameter number of a Meter Function parameter.
- 15. Current Displays the current or the value of a Function Meter parameter.
- 16. CV LED Lights in green during constant voltage mode.
- 17. CC LED Lights in green during constant current mode.
- 18. VSR LED The voltage slew rate enable.
- 19. LAN LED Lights up when the LAN interface is connected.
- 20. RMT LED Lights in green during remote control.
- 21. ERR LED Lights in red when an error has occurred.
- 22. DLY LED The output on/off delay enable.
- 23. ALM LED Lights in red when a protection function has been activated.




24. ISR LED	The current slew rate enable.
25. M1 LED	Lights in green when the memory value are being recalled or saved.
26. M2 LED	Lights in green when the memory value are being recalled or saved.
27. M3 LED	Lights in green when the memory value are being recalled or saved.
28. RUN LED	Auto sequence has been activated.
Note	Only the ERR and ALM LED's are red. All the others are green.



Rear Panel



1. AC Input



Wire clamp connector.

2. DC Output



Output terminals for 6V to 60V models.

3. USB



USB port for controlling the PSU remotely.

4. LAN



Ethernet port for controlling the PSU remotely.



5. Remote-IN





Two different types of cables can be used for RS232 or RS485-based remote control.

PSU-232: RS232 cable with DB9 connector kit.

PSU-485: RS485 with DB9 connector kit.

Remote-OUT



RJ-45 connector that is used to daisy chain power supplies with the Remote-IN port to form a communication bus.

PSU-485S: Serial link cable with RJ-45 shielded connector.

Analog Control



External analog control connector.

8. Remote Sense



Compensation of load wire drop.

Option Slot




Blank sub-plate for standard units. Isolated Analog connector for units equipped with Isolated Current and Voltage Programming and Monitoring option. GPIB connector for units equipped

with IEEE programming option.

10. Ground Connector for grounding the output (two Screw positions, shown in red).





Configuration Settings

Setting Normal Function Settings

The normal function settings, F-01~F-61, F-70~F-76, F-88~F-89 and F100~F122 can be easily configured with the Function key.

- Ensure the load is not connected.
- Ensure the output is off.
- Function settings F-90~97 can only be viewed.



Function setting F-89 (Show Version) can only be viewed, not edited.

Configuration settings F-90~ F-97 cannot be edited in the Normal Function Settings. Use the Power On Configuration Settings. See page 23 for details.

Steps

1. Press the Function key. The function key will light up.



2. The display will show F-01 on the left and the configuration setting for F-01 on the right.



3. Rotate the voltage knob to change the F setting.



Range F-00~F-61, F-70~F-76,

F-88~F-97, F100~F122



4. Use the current knob to set the parameter for the chosen F setting.



Press the Voltage knob to save the configuration setting. ConF will be displayed when it is configuring.





Exit

Press the Function key again to exit the configuration settings. The function key light will turn off.



Setting Power On Configuration Settings

Background

The Power On configuration settings can only be changed during power up to prevent the configuration settings being inadvertently changed.

- Ensure the load is not connected.
- Ensure the power supply is off.

Steps

1. Hold the Function key whilst turning the power on.



2. The display will show F-90 on the left and the configuration setting for F-90 on the right.



3. Rotate the voltage knob to change the F setting.

Range $F-90 \sim F-97$



4. Use the current knob to set the parameter for the chosen F setting.





Press the Voltage knob to save the configuration setting. ConF will be displayed when it is configuring.





Exit

Cycle the power to save and exit the configuration settings.



Configuration Table

Please use the configuration settings listed below when applying the configuration settings.

Normal Function		
Settings	Setting	Setting Range
Output ON delay time	F-01	0.00s~99.99s
Output OFF delay time	F-02	0.00s~99.99s
V-I mode slew rate select	F-03	0 = CV high speed priority (CVHS) 1 = CC high speed priority (CCHS) 2 = CV slew rate priority (CVLS) 3 = CC slew rate priority (CVLS)
Rising voltage slew rate	F-04	0.001~0.06V/msec (PSU 6-200) 0.001~0.125V/msec (PSU 12.5-120) 0.001~0.2V/msec (PSU 20-76) 0.001~0.4V/msec (PSU 40-38) 0.001~0.6V/msec (PSU 60-25)
Falling voltage slew rate	F-05	0.001~0.06V/msec (PSU 6-200) 0.001~0.125V/msec (PSU 12.5-120) 0.001~0.2V/msec (PSU 20-76) 0.001~0.4V/msec (PSU 40-38) 0.001~0.6V/msec (PSU 60-25)
Rising current slew rate	F-06	0.001~2A/msec (PSU 6-200) 0.001~1.2A/msec (PSU 12.5-120) 0.001~0.76A/msec (PSU 20-76) 0.001~0.38A/msec (PSU 40-38) 0.001~0.25A/msec (PSU 60-25)
Falling current slew rate	F-07	0.001~2A/msec (PSU 6-200) 0.001~1.2A/msec (PSU 12.5-120) 0.001~0.76A/msec (PSU 20-76) 0.001~0.38A/msec (PSU 40-38) 0.001~0.25A/msec (PSU 60-25)



		0~0.03Ω (PSU 6-200)
		0~0.104Ω (PSU 12.5-120)
Internal resistance	F-08	0~0.263Ω (PSU 20-76)
setting	1 00	0~1.053Ω (PSU 40-38)
		0~1.033Ω (PSU 40-38) 0~2.4Ω (PSU 60-25)
Bleeder circuit control	F-09	0 = OFF, 1 = ON, 2 = AUTO
Buzzer ON/OFF control	F-10	0 = OFF, 1 = ON
OCP Delay Time	F-12	0.1 ~ 2.0 sec
·	1-12	0.1 ~ 2.0 sec
Current Setting Limit (I-Limit)	F-13	0 = OFF, 1 = ON
Voltage Setting Limit (V-Limit)	F-14	0 = OFF, 1 = ON
Display memory		
parameter when recalling	F-15	0 = OFF, 1 = ON
(M1, M2, M3)		S.1, 1 S.1
(,,)		0 = Disable, 1 = Enable, 2 = Execute
Auto Calibration Parallel		Parallel Calibration and set to Enable.
Control	F-16	Note: Must be a short between each
Control		unit before starting.
Measurement Average		
Setting	F-17	0 = Low, 1 = Middle, 2 = High
Alarm Recovery and		
Output Status	F-18	0 = Safe Mode, 1 = Force Mode
•		0:Lock Panel, Allow Output OFF
Lock Mode	F-19	1:Lock Panel, Allow Output ON/OFF
USB/GPIB settings		
Show front panel USB		
status	F-20	0 = None, 1 = Mass Storage
Show rear panel USB		
status	F-21	0 = None, 1 = Linking to PC
		0 = Disable USB, 1 = Full Speed, 2 =
Setup rear USB Speed	F-22	Auto Detect Speed
GPIB Address	F-23	0 ~ 30
GPIB Enable/Disable	F-24	0 = Disable GPIB, 1 = Enable GPIB
Show GPIB available		
status	F-25	0 = No GPIB, 1 = GPIB is available
SCPI Emulation	F-26	0 = GW Instek, 1 = TDK GEN, 2 =
SCFI EIIIUIALIOII		Agilent 5700, 3 = Kikusui PWX
LAN settings		
Show MAC Address-1	F-30	0x00~0xFF



Show MAC Address-2	F-31	0x00~0xFF
Show MAC Address-3	F-32	0x00~0xFF
Show MAC Address-4	F-33	0x00~0xFF
Show MAC Address-5	F-34	0x00~0xFF
Show MAC Address-6	F-35	0x00~0xFF
LAN Enable	F-36	0 = OFF, 1 = ON
DHCP	F-37	0 = OFF, 1 = ON
IP Address-1	F-39	000~255
IP Address-2	F-40	000~255
IP Address-3	F-41	000~255
IP Address-4	F-42	000~255
Subnet Mask-1	F-43	000~255
Subnet Mask-2	F-44	000~255
Subnet Mask-3	F-45	000~255
Subnet Mask-4	F-46	0~255
Gateway-1	F-47	0~255
Gateway-2	F-48	0~255
Gateway-3	F-49	0~255
Gateway-4	F-50	0~255
DNS address -1	F-51	0~255
DNS address -2	F-52	0~255
DNS address-3	F-53	0~255
DNS address-4	F-54	0~255
Socket Server	F-57	0 = Disable, 1 = Enable
Enable/Disable	1-57	
Show Socket Server Port	F-58	No setting
Web Server	F-59	0 = Disable, 1 = Enable
Enable/Disable	1-39	
Web Password	F-60	0 = Disable, 1 = Enable
Enable/Disable		
Web Enter Password	F-61	0000~9999
UART Settings		
UART Mode	F-70	0 = Disable UART, 1 = RS232,
	. , ,	2 = RS485
		0 = 1200, 1 = 2400, 2 = 4800,
UART Baud Rate	F-71	3 = 9600, 4 = 19200, 5 = 38400,
		6 = 57600, 7 = 115200
UART Data Bits	F-72	0 = 7 bits, 1 = 8 bits
UART Parity	F-73	0 = None, 1 = Odd, 2 = Even
UART Stop Bit	F-74	0 = 1 Bit, 1 = 2 Bits



UART TCP	F-75	0 = SCPI, 1 = TDK (emulation mode)
UART Address (For TDK)		00 ~ 30
System Settings	1 70	
System Settings		0 = None
Factory Set Value	F-88	1 = Return to factory default settings
		0, 1 = Version
		2, 3, 4, 5 = Build date (YYYYMMDD)
		6, 7 = Keyboard CPLD
		8, 9 = Analog Board CPLD
		A, B = Analog Board FPGA
Show Version	F-89	C, D, E, F = Kernel Build
		(YYYYMMDD)
		G, H = Test Command Version
		I, J, K, L = Test Command Build
Davier On Configuration	Cattings	(YYYYMMDD)
Power On Configuration	settings^	O Control by Local
		0 = Control by Local
		1 = Control by External Voltage
	F-90	2 = Control by External Resistor -
CV Control		Rising A
		3 = Control by External Resistor -
		Falling
		4 = Control by Isolated Board
		0 = Control by Local
		1 = Control by External Voltage
		2 = Control by External Resistor -
CC Control	F-91	Rising 🔼
		3 = Control by External Resistor -
		Falling 📐
		4 = Control by Isolated Board
		0 = Safe Mode (Always OFF),
Output Status when	F-92	1 = Force Mode (Always ON),
Power ON	1-92	2 = Auto Mode (Status before last
		time power OFF)
		0 = Independent
Master/Clave		1 = Master with 1 slave in parallel
Master/Slave	F-93	2 = Master with 2 slaves in parallel
Configuration		3 = Master with 3 slaves in parallel
		4 = Slave (parallel)
External Output Logic	F-94	0 = High ON, 1 = Low ON



Monitor Voltage Select	F-96	0 = 5V, $1 = 10V$				
Control Range	F-97	$0 = 5V [5k\Omega], 1 = 10V [10k\Omega]$				
External Output Control Function	F-98	0 = OFF, 1 = ON				
Trigger Input and Output Configuration Settings						
Trigger Input Pulse Width	F100	$0\sim60$ ms. $0 = trigger$ controlled by trigger level.				
Trigger Input Action	F101	0 = None 1 = Output ON/OFF (refer to F103) 2 = Setting (refer to F104 & F105) 3 = Memory (refer to F106)				
Output State When Receiving Trigger	F103	0 = OFF 1 = ON				
Apply Voltage Setting on Trigger	F104	$0 \sim \text{rated voltage (only applicable}$ when F101 =2)				
Apply Current Setting on Trigger	F105	0 ~ rated current (only applicable when F101 =2)				
Recall memory number	F106	1 ~ 3 (M1 ~ M3)				
Trigger Output Pulse Width	F120	$0 \sim 60$ ms. $0 = $ trigger output is set to the active level, not pulse width.				
Trigger Output Level	F121	0 = LOW, 1 = HIGH (if F120 = 0)				
Trigger Source	F122	0 = None 1 = Switching the output on or off 2 = Changing a setting 3 = Recalling a memory				
Special Function Settings*						
Calibration	F-00	0000 ~ 9999				

! *Note

Power On configuration settings can only be set during power up. They can, however, be viewed under normal operation.



REMOTE CONTROL

This chapter describes basic configuration of IEEE488.2 based remote control.

Interface Configuration	31
Command Syntax	55
Command List	58
Status Register Overview	112
Error List	124




Interface Configuration

USB Remote Interface

Configuration

USB Configuration		PC side connector	Type A, host	
		PSU side connector	Rear panel Type B, slave	
		Speed	1.1/2.0 (full speed/	high speed)
		USB Class	CDC (communication class)	ons device
Steps	1.	Connect the USB cable to the rear panel USB B port.		•
		Change the Rear panel-USB (F-22) setting to 2 (Auto Detect Speed) or 1 (USB Full Speed).		Page 21
Note		If you are not u USB device por (Disable USB).	sing the rear panel t, set F-22 to 0	Page 21

3. The RMT indicator will turn on when a remote connection has been established.





Function Check	
Functionality	Invoke a terminal application such as Realterm.
-lal	and the second second and the second

check

To check the COM port No., see the Device Manager in the PC. For WinXP; Control panel \rightarrow System \rightarrow Hardware tab.

Run this query command via the terminal application after the instrument has been configured for USB remote control (page 31).

*idn?

This should return the Manufacturer, Model number, Serial number, and Firmware version in the following format.

GW-INSTEK,PSU40-38,TW123456,T0.01.12345678

Manufacturer: GW-INSTEK

Model number: PSU40-38

Serial number: TW123456

Firmware version: T0.01.12345678



GPIB Remote Interface

Configuration

To use GPIB, the optional GPIB option (GW Instek part number: PSU-GPIB) must be installed. This is a factory installed option and cannot be installed by the end-user. Only one GPIB address can be used at a time.

Configure GPIB

- 1. Ensure the PSU is off before proceeding.
- 2. Connect a GPIB cable from a GPIB controller to the GPIB port on the PSU.
- 3. Turn the PSU on.
- 4. Press the Function key to enter the Page 21 Normal configuration settings.
- 5. Set the following GPIB settings.

F-24 = 1 Enable the GPIB port

F-23 = 0~30 Set the GPIB address (0~30)

 Check to see that the GPIB option is detected by the PSU. The F-25 setting indicates the GPIB port status.

F-25 = 1 Indicates that the GPIB port is


available.

F-25 = 0 Indicates that the GPIB port is

not detected.



7. The RMT indicator will turn on when a remote connection has been established.



RMT indicator

GPIB constraints •

- Maximum 15 devices altogether, 20m cable length, 2m between each device
- Unique address assigned to each device
- At least 2/3 of the devices turned On
- No loop or parallel connection

GPIB Function Check

Bac	kground
Dac	Kgiouna

To test the GPIB functionality, National Instruments Measurement and Automation Explorer can be used. This program is available on the NI website, www.ni.com, via a search for the VISA Run-time Engine page, or "downloads" at the following URL, http://www.ni.com/visa/

Requirements

Operating System: Windows XP, 7, 8




Functionality check

1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:

Start>All Programs>National Instruments>Measurement & Automation



- From the Configuration panel access;My System>Devices and Interfaces>GPIB
- 3. Press Scan for Instruments.





- 4. Select the device (GPIB address of PSU) that now appears in the *System>Devices and Interfaces > GPIB-USB-HS "GPIBX"* node.
- 5. Click on the VISA Properties tab on the bottom.
- 6. Click Open Visa Test Panel.



- 7. Click on Configuration.
- 8. Click on the *GPIB Settings* tab and confirm that the GPIB settings are correct.




- 9. Click on the I/O Settings tab.
- 10. Make sure the Enable Termination Character



check box is checked, and the terminal character is \n (Value: xA).

11. Click Apply Changes.



- 12. Click on Input/Output.
- 13. Click on the Basic/IO tab.
- 14. Enter *IDN? in the *Select or Enter Command* drop down box.
- 15. Click Query.
- 16. The *IDN? query will return the Manufacturer, model name, serial number and firmware version in the dialog box.

GW-INSTEK,PSU40-38, TW123456,T0.02.20131205





UART Remote Interface

Configure UART

Overview

The PSU uses the IN & OUT ports for UART communication coupled with RS232 (GW Part number PSU-232) or RS485 adapters (GW part number PSU-485)

The pin outs for the adapters are shown below.

PSU-232 RS232 cable with DB9 connector

DB-9 Connector		Remote II	Remote IN Port	
Pin No.	Name	Pin No.	Name	
Housing	Shield	Housing	Shield	
2	RX	7	TX	Twisted
3	TX	8	RX	pair
5	SG	1	SG	



PSU-485 RS485 cable with DB9 connector

DB-9 Connector		Remote II	Remote IN Port	
Pin No.	Name	Pin No.	Name	
Housing	Shield	Housing	Shield	
9	TXD -	6	RXD -	Twisted
8	TXD +	3	RXD +	pair
1	SG	1	SG	
5	RXD -	5	TXD -	Twisted
4	RXD +	4	TXD +	pair

Steps

1. Connect the RS232 serial cable (included in the PSU-232 kit) or RS485 serial cable (included in the PSU-485 kit) to the (Remote IN port) on the rear panel.



Connect the other end of the cable to the PC.

2. Press the Function key to enter the Page 21 Normal configuration settings.

Set the following UART settings:

F-70 = 1 or 2	Interface: 0= Disable UART, 1= RS232 or 2 = RS485
F-71 = 0 ~ 7	Set the baud rate: 0=1200, 1=2400, 2=4800, 3=9600, 4=19200, 5=38400,
F-72 = 0 or 1	6=57600, 7=115200 Data bits: 0=7 or 1=8
F-73 = 0 ~3	Parity: 0 = none, 1 = odd, 2 = even
F-74 = 0 or 1	Stop bits: $0 = 1$, $1 = 2$
F-75 = 0 or 1	TCP: 0 = SCPI, 1 = TDK (emulation mode)



 $F-76 = 00 \sim 30$

UART address if TDK is selected for F-75.

3. The RMT indicator will turn on when a remote connection has been established.



RMT indicator



If TDK (emulation mode) is selected for F-75, the TDK GENESYS legacy commands should be used for remote commands. See the TDK Genesys user manual for details.



UART Function Check

Functionality check

Invoke a terminal application such as Realterm.

To check the COM port No, see the Device Manager in the PC. For WinXP; Control panel → System → Hardware tab.

Run this query command via the terminal application after the instrument has been configured for either RS232 or RS485 remote control (page 38).

*idn?

This should return the Manufacturer, Model number, Serial number, and Firmware version in the following format:

GW-INSTEK, PSU40-38, TW123456, T0.01.12345678

Manufacturer: GW-INSTEK Model number : PSU40-38 Serial number : TW123456

Firmware version: T0.01.12345678




Multiple Unit Connection Using Local RS485 Bus

The PSU power supplies can have up to 31 units daisy-chained together using the 8 pin connectors (IN OUT ports) on the rear panel. The first unit in the chain is remotely connected to a PC using RS232 or RS485. Each subsequent unit is daisy-chained to the next using an RS485 local bus. The OUT port on the last terminal must be terminated by the end terminal connector.

Only the TDK GENESYS legacy commands can be used when using multiple units over the local RS485 bus, SCPI commands cannot be used. When using the TDK commands, each unit is assigned a unique address and can then be individually controlled from the host PC. When using SCPI commands via RS232/RS485, remote commands can only be used to control the master unit.

Operation

- 1. Connect the first unit's IN port to a PC via RS232 or RS485.
 - Use the serial cables supplied in the PSU-232 or PSU-485 connection kit.
- Connect the OUT port on the first unit to the IN port of the second unit using the serial link cable supplied in the PSU-232 or PSU-485 connection kit.
- Connect all the remaining units in the same fashion until all the units have been daisychained together.





- 4. Terminate the OUT port of the last unit with the end terminal connector included in the PSU-232 or PSU-485 connection kit.
- 5. Press the Function key to enter the Page 21 Normal configuration settings for the master unit.

Set the following settings:

	<u> </u>
F-70 = 1 or 2	Configure the master unit as you normally would for RS232 or RS485 remote control.
F-71 = 0~7	Set the baud rate (set all units the same).
F-72 = 1	Set to 8 data bits.
F-73 = 0	Parity to none.
F-74 = 1	1 Stop bit.
F-75 = 1	Set the UART TCP to TDK (emulation mode).
F-76 = 00~30	Set the address of the master unit. It must be a unique address identifier.

6. Press the Function key to enter the Page 21 Normal configuration settings for the slave(s).

Set the following settings:

F-70 = 2	Set the slave unit to RS485.
	Set the baud rate (make all
$F-71 = 0 \sim 7$	units, including the master, the
	same baud).
F-72 = 1	Set to 8 data bits.
F-73 = 0	Parity to none.
F-74 = 1	1 Stop bit.
F-75 = 1	Set the UART TCP to TDK
r-/3 = 1	(emulation mode).



 $F-76 = 00 \sim 30$

Set the address of each slave to a unique address identifier

7. Multiple units can now be operated at the same time, see the function check below for usage details.

Serial link cable with RJ-45 shielded connectors from PSU-232 or PSU-485 connection kit

8 Pin Connector (IN)		8 Pin Conn	8 Pin Connector (OUT)	
Pin No.	Name	Pin No.	Name	
Housing	Shield	Housing	Shield	
1	SG	1	SG	
6	TXD -	6	TXD -	
3	TXD +	3	TXD +	
5	RXD -	5	RXD -	
4	RXD +	4	RXD +	

Multi-Unit Function Check

Functionality check	Invoke a terminal application such as Realterm.		
CITCON	To check the COM port No, see the Device Manager in the PC. For WinXP; Control panel → System → Hardware tab.		
	Below shows an example using the TDK GENESYS legacy commands.		
TDK Query	When using the TDK GENESYS legacy commands, each unit can be individually controlled using the unique address identifiers. For this function check, we will assume that the master unit is assigned to address 8, while a slave is assigned address 11.		



Run this query command via the terminal application after the instruments have been configured for multi-unit control. See page 42.

ADR 8

The identity string for the Master unit will be returned:

GW-INSTEK, PSU40-38, T0.01.12345678

Type the following:

ADR 11 IDN?

The identity string for the slave with address 11 will be returned:

GW-INSTEK, PSU40-38, ,T0.01.12345678

Note: TDK commands do not use LF (line feed) codes to terminate commands. See the TDK Genesys user manual for further information.



Configure Ethernet Connection

The Ethernet interface can be configured for a number of different applications. Ethernet can be configured for basic remote control or monitoring using a web server or it can be configured as a socket server.

The PSU series supports both DHCP connections so the instrument can be automatically connected to an existing network or alternatively, network settings can be manually configured.

Ethernet configuration Parameters

For details on how to configure the Ethernet settings, please see the configuration chapter on page 21.

MAC Address

LAN Enable/Disable

(display only)

DHCP IP Address

Enable/Disable

Subnet Mask Gateway

DNS Address Sockets Server

Enable/Disable

Web Server Web Password Enable/Disable Enable/Disable

Web Enter Password

Web Server Configuration

Configuration

This configuration example will configure the PSU as a web server and use DHCP to automatically assign an IP address to the PSU.

1. Connect an Ethernet cable from the network to the rear panel Ethernet port.






2. Press the Function key to enter the Page 21 Normal configuration settings.

Set the following LAN settings:

F-36 = 1	Turn LAN on
F-37 = 1	Enable DHCP
F-59 = 1	Turn the web server on
F-60 = 0 or 1	Set to 0 to disable web password, set to 1 to enable web password
F-61 = 0000 ~9999	Set the web password

3. The LAN indicator will turn on when a network cable is plugged in.





It may be necessary to cycle the power or refresh the web browser to connect to a network.

Web Server Remote Control Function Check

Functionality check

Enter the IP address of the power supply in a web browser after the instrument has been configured as a web server (page 46).

The web server allows you to monitor the function settings of the PSU.

You can check the IP address by checking F-39 to F-42.

F-39 = AAA IP Address part 1 of 4 F-40 = BBB IP Address part 2 of 4



F-41 = CCC IP Address part 3 of 4 F-42 = DDD IP Address part 4 of 4

http:// AAA.BBB.CCC.DDD

The web browser interface appears.



Copyright 2011 © Good Will Instrument Co., Ltd All Rights Reserved.

The web browser interface allows you to access the following:

- Network configuration settings
- Analog control pinouts & usage
- PSU dimensions
- Operating area diagram



Sockets Server Configuration

Configuration

This configuration example will configure the PSU socket server.

The following configuration settings will manually assign the PSU an IP address and enable the socket server. The socket server port number is fixed at 2268.

1. Connect an Ethernet cable from the network to the rear panel Ethernet port.



2. Press the Function key to enter the Page 21 Normal configuration settings.

Set the following LAN settings:

	0
F-36 = 1	Enable LAN
F-37 = 0	Disable DHCP
F-39 = 172	IP Address part 1 of 4
F-40 = 16	IP Address part 2 of 4
F-41 = 5	IP Address part 3 of 4
F-42 = 133	IP Address part 4 of 4
F-43 = 255	Subnet Mask part 1 of 4
F-44 = 255	Subnet Mask part 2 of 4
F-45 = 128	Subnet Mask part 3 of 4
F-46 = 0	Subnet Mask part 4 of 4
F-43 = 172	Gateway part 1 of 4
F-44 = 16	Gateway part 2 of 4
F-45 = 21	Gateway part 3 of 4
F-46 = 101	Gateway part 4 of 4
F-57 = 1	Enable Sockets



Socket Server Function Check

Background

To test the socket server functionality, National Instruments Measurement and Automation Explorer can be used. This program is available on the NI website, www.ni.com, via a search for the VISA Run-time Engine page, or "downloads" at the following URL, http://www.ni.com/visa/

Requirements

Operating System: Windows XP, 7, 8

Functionality check

1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:

Start>All Programs>National Instruments>Measurement & Automation



2. From the Configuration panel access;


My System>Devices and Interfaces>Network
Devices

3. Press Add New Network Device>Visa TCP/IP Resource...






4. Select *Manual Entry of Raw Socket* from the popup window.



- 5. Enter the IP address and the port number of the PSU. The port number is fixed at 2268.
- 6. Click the Validate button.
- 7. A popup will appear if a connection is successfully established.
- 8. Click Next.






- Next configure the Alias (name) of the PSU connection. In this example the Alias is: PSU_DC1
- 10. Click finish.



- 11. The IP address of the PSU will now appear under Network Devices in the configuration panel. Select this icon now.
- 12. Click Open VISA Test Panel.





- 13. Click the Configuration icon,
- 14. Click on I/O Settings.
- 15. Make sure the *Enable Termination Character* check box is checked, and the terminal character is \n (Value: xA).
- 16. Click Apply Changes.



- 17. Click the *Input/Output* icon.
- 18. Enter *IDN? in the *Select or Enter Command* dialog box if it is not already.
- 19. Click the Query button.



20. The *IDN? query will return the Manufacturer, model name, serial number and firmware version in the dialog box.

GW-INSTEK,PSU40-38,TW123456,T0.02.20131205






Command Syntax

Compatible	IEEE488.2	Partial compatibility
Standard	SCPI, 1999	Partial compatibility

Command Structure

SCPI commands follow a tree-like structure, organized into nodes. Each level of the command tree is a node. Each keyword in a SCPI command represents each node in the command tree. Each keyword (node) of a SCPI command is separated by a colon (:).

For example, the diagram below shows an SCPI sub-structure and a command example.



Command types

There are a number of different instrument commands and queries. A command sends instructions or data to the unit and a query receives data or status information from the unit.

Command types

Simple	A single command with/without a parameter
Example	*IDN?



Query	A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.
Example	meas:curr:dc?
Compound	Two or more commands on the same command line. Compound commands are separated with either a semicolon (;) or a semi-colon and a colon (;:). A semi-colon is used to join two related commands, with the caveat that the last command must begin at the last node of the first command. A semi-colon and colon are used to combine two commands from different nodes.
Example	meas:volt:dc?;:meas:curr:dc?



Command Forms

Commands and queries have two different forms, long and short. The command syntax is written with the short form of the command in capitals and the remainder (long form) in lower case.

The commands can be written in capitals or lower-case, just so long as the short or long forms are complete. An incomplete command will not be recognized.

Below are examples of correctly written commands.

Long form	STATus:OPERation:NTRansition? STATUS:OPERATION:NTRANSITION?
	status:operation:ntransition?
Short	STAT:OPER:NTR?
form	stat:oper:ntr?

Square Brackets

Commands that contain square brackets indicate that the contents are optional. The function of the command is the same with or without the square bracketed items, as shown below.

Both "DISPlay:MENU[:NAME]?" and "DISPlay:MENU?" are both valid forms.

Command Format



- 1. Command header
- 2. Space
- 3. Parameter 1
- 4. Comma (no space before/after comma)
- 5. Parameter 2

Parameters	Туре	Description	Example
	<boolean></boolean>	Boolean logic	0, 1



	<nr1></nr1>	integers	0, 1, 2, 3
	<nr2></nr2>	decimal numbers	0.1, 3.14, 8.5
	<nr3></nr3>	floating point	4.5e-1, 8.25e+1
	<nrf></nrf>	any of NR1, 2, 3	1, 1.5, 4.5e-1
	<blook data=""></blook>	Definitive lengt data. A single d followed by dat digit specifies h data bytes followed	a. The decimal ow many 8-bit
Message Terminator	LF Li	ne feed code	

Command List

:ABORt	:ABORt	62
:APPLY Commands	:APPLy	62
Display	:DISPlay:MENU[:NAME]	63
Commands	:DISPlay[:WINDow]:TEXT:CLEar	
	:DISPlay[:WINDow]:TEXT[:DATA]	
	:DISPlay:BLINk	64
Initiate	:INITiate:CONTinuous[:TRANsient]	65
Commands	:INITiate[:IMMediate]:NAME	
Communas	:INITiate[:IMMediate][:TRANsient]	
Measure	:MEASure[:SCALar]:ALL[:DC]	67
Commands	:MEASure[:SCALar]:CURRent[:DC]	
Commands	:MEASure[:SCALar]:VOLTage[:DC]	
	:MEASure[:SCALar]:POWer[:DC]	

GW INSTEK

Memory	:MEMory:TRIGgered	69
Output Commands	:OUTPut:DELay:ON :OUTPut:DELay:OFF :OUTPut:MODE :OUTPut[:STATe][:IMMediate] :OUTPut[:STATe]:TRIGgered :OUTPut:PROTection:CLEar	70 71 71 71
Sense Commands	:SENSe:AVERage:COUNt	73
Status Commands	:STATus:OPERation[:EVENt] :STATus:OPERation:CONDition :STATus:OPERation:ENABle :STATus:OPERation:PTRansition :STATus:OPERation:NTRansition :STATus:QUEStionable[:EVENt] :STATus:QUEStionable:CONDition :STATus:QUEStionable:ENABle :STATus:QUEStionable:PTRansition :STATus:QUEStionable:PTRansition :STATus:QUEStionable:NTRansition	74 75 75 75 76 76
Source Commands	[:SOURce]:CURRent:EXTernal:RANGe	79 itude].7980808181828283



System Commands

[:SOURce]:VOLTage[:LEVel][:IMMediate]	
[:AMPLitude]	84
[:SOURce]:VOLTage[:LEVel]:TRIGgered[:AMPLitude] 84
[:SOURce]:VOLTage:LIMit:AUTO	85
[:SOURce]:VOLTage:LIMit:LOW	85
[:SOURce]:VOLTage:PROTection[:LEVel]	86
[:SOURce]:VOLTage:PROTection:TRIPped	
[:SOURce]:VOLTage:SLEWrate:RISing	
[:SOURce]:VOLTage:SLEWrate:FALLing	
:SYSTem:BEEPer[:IMMediate]	89
:SYSTem:CONFigure:BEEPer[:STATe]	
:SYSTem:CONFigure:BLEeder[:STATe]	
:SYSTem:CONFigure:CURRent:CONTrol	
:SYSTem:CONFigure:VOLTage:CONTrol	
:SYSTem:CONFigure:OUTPut:PON[:STATe]	
:SYSTem:CONFigure:PROTection:RECovery	
:SYSTem:CONFigure:PROTection:RECovery :SYSTem:CONFigure:MSLave	
:SYSTem:CONFigure:MSLave: :SYSTem:CONFigure:OUTPut:EXTernal:MODE	
:SYSTem:CONFigure:OUTPut:EXTernal[:STATe]	
:SYSTem:CONFigure:MONitor:RANGe	
:SYSTem:CONFigure:MONITOT:RANGE :SYSTem:CONFigure:TRIGger:INPut:SOURce	
:SYSTem:CONFigure:TRIGger:INPut:SOURCE :SYSTem:CONFigure:TRIGger:INPut:WIDTh	
:SYSTem:CONFigure:TRIGger:INPut:WID1n :SYSTem:CONFigure:TRIGger:OUTPut:SOURce	
:SYSTem:CONFigure:TRIGger:OUTPut:SOURCe :SYSTem:CONFigure:TRIGger:OUTPut:WIDTh	
:SYSTem:CONFigure:TRIGger:OUTPut:LEVel :SYSTem:COMMunicate:ENABle	YO
:SYSTem:COMMunicate:GPIB[:SELF]:ADDRess	
:SYSTem:COMMunicate:LAN:IPADdress	
:SYSTem:COMMunicate:LAN:GATEway: :SYSTem:COMMunicate:LAN:SMASk	
:SYSTem:COMMunicate:LAN:MAC	
:SYSTem:COMMunicate:LAN:DHCP	
:SYSTem:COMMunicate:LAN:DNS	
:SYSTem:COMMunicate:RLSTate	
:SYSTem:COMMunicate:TCPip:CONTrol	
:SYSTem:COMMunicate:SERial:LANGuage[:SELect]	
:SYSTem:COMMunicate:SERial[:RECeive] :TRANsmit	
:BAUD	
:SYSTem:COMMunicate:SERial[:RECeive] :TRANsmit	
:BITS	102
: SYSTem: COMMunicate: SERial [:RECeive]: TRANsmit	
:PARity	102

REMOTE CONTROL



	:SYSTem:COMMunicate:SERial[:RECeive]:TRAN	Ismit
	:SBITs	
	:SYSTem:COMMunicate:USB:FRONt:STATe	103
	:SYSTem:COMMunicate:USB:REAR:MODE	103
	:SYSTem:COMMunicate:USB:REAR:STATe	104
	:SYSTem:ERRor	104
	:SYSTem:KLOCk	104
	:SYSTem:KEYLock:MODE	105
	:SYSTem:ERRor:ENABle	105
	:SYSTem:LANGuage:EMULation	105
	:SYSTem:LANGuage:[:SELect]	105
	:SYSTem:PRESet	106
	:SYSTem:VERSion	106
	:SYSTem:REBoot	106
Trigger	:TRIGger:OUTPut:SOURce	107
Commands	:TRIGger:OUTPut[:IMMediate]	
Communas	:TRIGger[:TRANsient]:SOURce	
	:TRIGger[:TRANsient][:IMMediate]	
Common	*CLS	
Commands	*ESE	
	*ESR	
	*IDN	
	*OPC	
	*RCL	
	*RST	
	*SAV	
	*SRE	
	*STB	
	*TRG	
	*TST	
	*WAI	112



Abort Commands

:ABORt



Description	The :ABORt command will cancel any triggered actions.
Syntax	:ABORt

Apply Commands

:APPLy.....62

Sets the current and voltage to the minimum settings.

:APPLy



Description	The apply command sets the voltage and current at the same time.		
Syntax	:APPLy { <nrf>(V) MINimum MAXimum[,<nrf>(A) MINimu m MAXimum]}</nrf></nrf>		
Query Syntax	:APPLy?		
Parameter/	<nrf>(V)</nrf>	Voltage setting.	
Return parameter	MINimum	Minimum voltage level	
	MAXimum	Maximum voltage level	
	<nrf>(A)</nrf>	Current setting.	
	MINimum	Minimum voltage level	
	MAXimum	Maximum voltage level	
Example	APPL MIN, MIN		



Display Commands

:DISPlay:MENU[:NAME]	63
:DISPlay[:WINDow]:TEXT:CLEar	
:DISPlay[:WINDow]:TEXT[:DATA]	
:DISPlay:BLINk	

:DISPlay:MENU[:NAME]



Description		Play MENU command selects a screen queries the current screen menu.
Syntax	:DISPlay:MENU[:NAME] <nr1></nr1>	
Query Sytax	:DISPlay:	MENU[:NAME]?
Parameter/	<nr1></nr1>	Description
Return parameter	0	Measure voltage & current
	1~2	Not Used
	3	Set Menu
	4	OVP / OCP Menu
	5~99	Not Used.
	100~199	F-00~99 Menu.
	200~229	F100~F129 Menu.
Example	DISP:ME	NU:NAME 0

:DISPlay[:WINDow]:TEXT:CLEar



Description	Clears the text on the main screen from
	the :DISPlay[:WINDow]:TEXT[:DATA] command.
Syntax	·DISPlavI·WINDowl·TFXT·CI Far

Sets the display to the Voltage/Current display screen.



			Set
:DISPlay[:WIN[Dow]:TEX	(I[:DATA]	→ Query
Description	the displ data that display a overwrit in quotes	ueries the data text that ay. Writing to the dispart is currently on the scrarea with a shorter string the screen. The strings: "STRING". Only Asan be used in the <stri< td=""><td>play will overwrite reen. Overwriting a ng may or may not g must be enclosed SCII characters 20H</td></stri<>	play will overwrite reen. Overwriting a ng may or may not g must be enclosed SCII characters 20H
Syntax	:DISPlay[:WINDow]:TEXT[:DATA]	<string></string>
Query Syntax	, .	:WINDow]:TEXT[:DATA]	
Parameter/ Return parameter	<string></string>	ASCII character 20H to the string parameter. The enclosed in quotes: "ST	ne string must be
Example	DISP:WIND:TEXT:DATA "STRING"		
	Writes ST	RING to the display.	
Query Example	DISP:WIND:TEXT:DATA?		
	"STRING	n	
	Returns the text data string on the screen.		
			Set →
:DISPlay:BLINk	(Query
Description	Turns bl	ink on or off for the dis default.	splay. Blink is set to
Syntax	:DISPlay:BLINk { <bool> OFF ON}</bool>		
Query Syntax	:DISPlay:	BLINk?	
Parameter	OFF 0	Turns blink OFF Turns blink ON	
Return parameter	ON 1 <bool></bool>	Returns the blink status	
Example Example	DISP:BLI		*
LABITIPIE	DISF.BLI	IN I	

Turns blink ON.



Initiate Commands

:INITiate:CONTinuous[:TRANsient]	65
:INITiate[:IMMediate]:NAME	
:INITiate[:IMMediate][:TRANsient]	66

:INITiate:CONTinuous[:TRANsient]



Description	This command continuously initiates software triggers for the transient or output triggers.		
Syntax	:INITiate:CONTinuous[:TRANsient] { <bool> OFF ON}</bool>		
Query Syntax	:INITiate:CONTinuous[:TRANsient]?		
Parameter	OFF 0 OFF		
	ON 1	ON	
Return parameter	r O OFF		
	1	ON	
Example	INIT:TRA	AN 1	

Turns on the continuous trigger.

:INITiate[:IMMediate]:NAME



Description	The INITiate command starts the TRANsient or OUTPut trigger.		
Syntax	:INITiate[:IMMediate]:NAME {TRANsient OUTPut}		
Parameter	TRANSient Starts the TRANsient trigger.		
	OUTPut Starts the OUTPut trigger.		
Example	INITiate:NAME TRANient		
	Starts the TRANSient trigger.		



:INITiate[:IMN	Mediate][:TRANsient] Set →
Description	This command controls the enabling of output triggers. When a trigger is enabled, a trigger causes the specified action to occur. If the trigger system is not enabled, all triggers are ignored.
Syntax	:INITiate[:IMMediate][:TRANsient]
Example	INIT



Return

Measure Commands

	:MEASure[:SCALar]:CU: :MEASure[:SCALar]:VO	L[:DC]	
:MEASure[:SCA	.Lar]:ALL[:DC]	— Query	
Description	Takes a measurement output current and vo	and returns the average oltage	
Syntax	:MEASure[:SCALar]:ALL[:DC]?		
Return parameter	"+0.0000,+0.0000"	<pre><voltage>,<current> Returns the voltage (V) and current (A), respectively.</current></voltage></pre>	
:MEASure[:SCA	.Lar]:CURRent[:DC]	→ Query	
Description	Takes a measurement output current	and returns the average	
Syntax	:MEASure[:SCALar]:CURRent[:DC]?		
Return parameter			
:MEASure[:SCA	.Lar]:VOLTage[:DC]	— Query	
Description	Takes a measurement output voltage.	and returns the average	
Syntax	:MEASure[:SCALar]:VOLTage[:DC]?		

Returns the voltage in volts.

"+0.0000"



:MEASure[:SCALar]:POWer[:DC] Description Takes a measurement and returns the average output power. Syntax :MEASure[:SCALar]:POWer[:DC]? Return "+0.0000" Returns the power measured in watts.



Memory Commands

:MEMory:TRIGgered69

:MEMory:TRIGgered



Description	Sets or queries which memory is loaded when a trigger input is received and the trigger input is configured to load a memory setting.		
Related Commands	:SYSTem:CONFigure:TRIGger:INPut:SOURce :SYSTem:CONFigure:TRIGger:OUTPut:SOURce		
Syntax	:MEMory:TRIGgered { <nr1> MINimum MAXimum}</nr1>		
Return Syntax	:MEMory:TRIGgered? [MINimum MAXimum]		
Parameter	<nr1></nr1>	0(M1)~2(M3)	
	MINimum		
	MAXimum		
Return Parameter	<nr1></nr1>	Returns the memory setting	



Output Commands

Catput Communas				
	:OUTPut:DELay:ON 70 :OUTPut:DELay:OFF 70 :OUTPut:MODE 71 :OUTPut[:STATe][:IMMediate] 71 :OUTPut[:STATe]:TRIGgered 71 :OUTPut:PROTection:CLEar 72 :OUTPut:PROTection:TRIPped 72			
	Set →			
:OUTPut:DELa	y:ON	→ Query		
Description	Sets the Delay Time in seconds for turning the output on. The delay is set to 0.00 by default.			
Syntax	:OUTPut:	:DELay:ON { <nr2> MINimum MAXimum</nr2>	1}	
Query Syntax	:OUTPut:DELay:ON?			
Parameter	<nr2> 0.00~99.99 seconds, where 0=no delay.</nr2>			
Return parameter	"0.00"	O" Returns the delay on time in seconds until the output is turned on.		
	Set →			
:OUTPut:DELa	y:OFF	—Query		
Description	Sets the Delay Time in seconds for turning the output off. The delay is set to 0.00 by default.			
Syntax	:OUTPut:DELay:OFF { <nr2> MINimum MAXimum}</nr2>			
Return Syntax	:OUTPut:DELay:OFF?			
Parameter	<nr2></nr2>	0.00~99.99 seconds, where 0=no delay.		
Return parameter	"0.00"	Returns the delay off time in seconds until output is turned off.	the	



:OUTPut:MOD	E		Set → Query
Description	Sets the PSU output mode. This is the equivalent to the F-03 (V-I Mode Slew Rate Select) settings.		
Syntax	:OUTPut:	MODE { <nr1> CVHS C0</nr1>	CHS CVLS CCLS}
Return Syntax	:OUTPut:	MODE?	
Parameter	CCHS 1 CVLS 2	CV high speed priority CC high speed priority CV slew rate priority CC slew rate priority	
Return parameter	<nr1></nr1>	Returns the output mode.	
:OUTPut[:STAT	e][:IMM	ediate]	Set → Query
Description	Turns the	e output on or off.	
Syntax	:OUTPut[:STATe][:IMMediate] { <bool> OFF ON }</bool>		
Query Syntax	:OUTPut[:STATe][:IMMediate]?		
Parameter	OFF 0 ON 1	Turns the output off. Turns the output on.	
Return parameter	<bool></bool>	Returns output status of t	he instrument.
:OUTPut[:STAT	e]:TRIG	gered	Set → Query
Description	Turns the output on or off when a software trigger is generated.		
Syntax	:OUTPut[:STATe]:TRIGgered { <bool> OFF ON }</bool>		
Query Syntax	:OUTPut[:STATe]:TRIGgered?		
Parameter	OFF 0 ON 1	Turns the output off when is generated (*TRG). Turns the output on when is generated (*TRG).	
Return parameter	<bool></bool>	Returns output trigger stainstrument.	atus of the



:OUTPut:PROTection:CLEar			
Description	Clears over-voltage, over-current and over-temperature (OVP, OCP, OTP) protection circuits. It also clears the shutdown and sense protection circuit. The AC failure protection cannot be cleared.		
Syntax	:OUTPut:PROTection:CLEar		
:OUTPut:PROTection:TRIPped → Query			
Description	Queries the unit to see if a protection circuit has been tripped.		
Syntax	:OUTPut:PROTection:TRIPped?		
Return	<pre><boolean> 0 = No protection error 1 = A protection error had occured</boolean></pre>		



Sense Commands

:SENSe:AVERage:COUNt......73

:SENSe:AVERage:COUNt → Query

Description	Sets or queries the level of smoothing for the average setting.		
Syntax	:SENSe:AVERage:COUNt		
Return Syntax	{ <nr1> LOW MIDDle HIGH}</nr1>		
,	:SENSe:AVER	Rage:COUNt?	
Parameter	LOW 0	Low setting	
	MIDDle 1	Middle setting	
	HIGH 2	High setting	
Return Parameter	<nr1></nr1>	Returns the average setting.	

Query



Status Commands

For an overview of all the status registers, their associated register contents and the system diagram, please see the status overview on page 112

age 112		
Mgc 112	:STATus:OPERation[:EVENt] :STATus:OPERation:CONDition :STATus:OPERation:ENABle :STATus:OPERation:PTRansition :STATus:OPERation:NTRansition :STATus:QUEStionable[:EVENt] :STATus:QUEStionable:CONDition :STATus:QUEStionable:ENABle	74 75 75 75 76 76
	:STATus:QUEStionable:PTRansition: :STATus:QUEStionable:NTRansition: :STATus:PRESet	76
STATus:OPER	Ration[:EVENt] → Query	
Description	Queries the Operation Status Event register and	

Description	Queries the Operation Status Event register and		
	clears the contents of the register.		
Syntax	:STATus:OPERation[:EVENt]?		
Return	<nr1></nr1>	Returns the bit sum of the Operation Status Event register.	

Description Queries the Operation Status register. This query will not clear the register. Syntax STATus:OPERation:CONDition? Return Return Condition register.

:STATus:OPERation:CONDition



:STATus:OPERation:ENABle Set → Query			
Description	Sets or queries the bit sum of the Operation Status Enable register.		
Syntax	:STATus:0	OPERation:ENABle <nr1< td=""><td>></td></nr1<>	>
Query Syntax	:STATus:0	OPERation:ENABle?	
Parameter	<nr1></nr1>	0~32767	
Return parameter	<nr1></nr1>	0~32767	
:STATus:OPER	ation:PT	Ransition	Set → Query)
Description Sets or queries the bit sum of the positive transition filter of the Operation Status register.			-
Syntax	:STATus:0	OPERation:PTRansition <	NR1>
	:STATus:0	OPERation:PTRansition?	
Parameter	<nr1></nr1>	0~32767	
Return parameter	<nr1></nr1>	0~32767	
:STATus:OPER	ation:NT	Ransition	Set → Query
Description	Sets or queries the bit sum of the negative transition filter of the Operation Status register.		
Syntax	:STATus:0	OPERation:NTRansition <	:NR1>
Query Syntax	:STATus:0	OPERation: NTRansition?	
Parameter	<nr1></nr1>	0~32767	
Return parameter	<nr1></nr1>	0~32767	
:STATus:QUEStionable[:EVENt] → Query			
Description	Event re	the bit sum of the Quest gister. This query will a of the register.	
Query Syntax	:STATus:0	QUEStionable[:EVENt]?	
Return parameter	<nr1></nr1>	0~32767	



:STATus:QUES	tionable:CONDition — Query		
Description Queries the status (bit sum) of the Questionable Status register. This query will not clear the register.			
Query Syntax	:STATus:QUEStionable:CONDition?		
Return parameter	<nr1> 0~32767</nr1>		
	Set →		
:STATus:QUES	tionable:ENABle — Query		
Description	Sets or queries the bit sum of the Questionable Status Enable register.		
Syntax	:STATus:QUEStionable:ENABle <nr1></nr1>		
Query Syntax	:STATus:QUEStionable:ENABle?		
Parameter	<nr1> 0~32767</nr1>		
Return parameter	<nr1> 0~32767</nr1>		
CTAT OUE	Set →		
:STATUS:QUES	tionable:PTRansition — Query		
Description	Sets or queries the bit sum of the positive transition filter of the Questionable Status register.		
Syntax	:STATus:QUEStionable:PTRansition <nr1></nr1>		
Return Syntax	:STATus:QUEStionable:PTRansition?		
Parameter	<nr1> 0~32767</nr1>		
Return parameter	<nr1> 0~32767</nr1>		
	<u>Set</u> →		
:STATus:QUEStionable:NTRansition ——Query			
Description	Sets or queries the negative transition filter of the Questionable Status register.		
Syntax	:STATus:QUEStionable:NTRansition <nr1></nr1>		
Query Syntax	:STATus:QUEStionable:NTRansition?		



Parameter	<nr1></nr1>	0~32767
Return parameter	<nr1></nr1>	0~32767

:STATus:PRESet



Description

This command resets the ENABle register, the PTRansistion filter and NTRansistion filter on the Operation Status and Questionable Status Registers. The registers/filters will be reset to a default value.

Default Register/Filter Values	Setting
QUEStionable Status Enable	0x0000
QUEStionable Status Positive Transition	0x7FFF
QUEStionable Status Negative Transition	0x0000
Operation Status Enable	0x0000
Operation Status Positive Transition	0x7FFF
Operation Status Negative Transition	0x0000

Summary: The Questionable Status Enable registers and the Operation Status Enable registers are both reset to 0.

The Questionable Status and Operation Status Positive Transition filters are all set high (0x7FFF) and the Negative Transition filters are all set low (0x0000). I.e., only positive transitions will be recognized for the Questionable Status and Operation Status registers.

Syntax

:STATus:PRESet



Source Commands

	:SOURce]:CURRent:EXTernal:RANGe	.78
ĺ	:SOURce]:CURRent[:LEVel][:IMMediate]	
ĺ	:AMPLitude]	
ĺ	:SOURce]:CURRent[:LEVel]:TRIGgered[:AMPLitude].	.79
ĺ	:SOURce]:CURRent:LIMit:AUTO	.80
ĺ	:SOURce]:CURRent:PROTection:DELay	.80
ĺ	:SOURce]:CURRent:PROTection[:LEVel]	.80
ĺ	:SOURce]:CURRent:PROTection:STATe	81
[:SOURce]:CURRent:PROTection:TRIPped	81
[:SOURce]:CURRent:SLEWrate:RISing	82
	:SOURce]:CURRent:SLEWrate:FALLing	82
	:SOURce]:MODE?	.83
	:SOURce]:RESistance[:LEVel][:IMMediate]	
	:AMPLitude]	.83
	:SOURce]:VOLTage:EXTernal:RANGe	.84
	:SOURce]:VOLTage[:LEVel][:IMMediate]	
	:AMPLitude]	
	:SOURce]:VOLTage[:LEVel]:TRIGgered[:AMPLitude]	84
	:SOURce]:VOLTage:LIMit:AUTO	
	:SOURce]:VOLTage:LIMit:LOW	
	:SOURce]:VOLTage:PROTection[:LEVel]	
	:SOURce]:VOLTage:PROTection:TRIPped	.86
[:SOURce]:VOLTage:SLEWrate:RISing	.87
[:SOURce]:VOLTage:SLEWrate:FALLing	.87

[:SOURce]: CURRent: EXTernal: RANGe



Description	Sets or queries the CC or CV control range that is		
	used during external control. Note: the setting will		
	only be valid after the power has been cycled.		
Syntax	[:SOURce]:CURRent:EXTernal:RANGe {LOW HIGH}		
Query Syntax	[:SOURce]:CURRent:EXTernal:RANGe?		
Parameter/Return	LOW	A range of 0 V to 5 V is used.	
parameter	HIGH	A range of 0 V to 10 V is used.	



LOW

Returns LOW range.

[:SOURce]:CURRent[:LEVel][:IMMediate] [:AMPLitude]



Description	Sets or queries the current level in amps.For externally set current levels (from the analog control connector) the set current level is returned.		
Syntax	[:SOURce]:CURRent[:LEVel][:IMMediate][:AMPLitude] { <nr2>(A) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:CURRent[:LEVel][:IMMediate][:AMPLitude]?		
Parameter/Return	<nr2></nr2>	0~105% of the rated current output level.	
parameter	MIN	Minimum current level.	
	MAX	Maximum current level.	
Example	SOUR:CURR:LEV:IMM:AMPL?		
38.000 Returns the current level in			
		ne current level in amps.	

[:SOURce]:CURRent[:LEVel]:TRIGgered [:AMPLitude]



Description	Sets or queries the current level in amps when a software trigger has been generated.		
Syntax	[:SOURce]:CURRent[:LEVel]:TRIGgered[:AMPLitude] { <nr2> (A) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:CURRent[:LEVel]:TRIGgered[:AMPLitude]?		
Parameter	<nr2></nr2>	0%~105% of the rated current output in amps.	
	MIN	Minimum current level.	
	MAX	Maximum current level.	
Return Parameter	<nr2></nr2>	Returns the current level.	



Example SOUR:CURR:LEV:TRIG:AMPL?

38.000

Returns the maximum possible current level in amps.

[:SOURce]:CURRent:LIMit:AUTO

(Set →	
_	Query	

Description	Enables or disables the limit on the current setting.		
Syntax	[:SOURce]:CURRent:LIMit:AUTO { <bool> OFF ON}</bool>		
Query Syntax	[:SOURce]:CURRent:LIMit:AUTO?		
Parameter	OFF 0 Disable the setting current limit		
	ON 1	Enable the setting current limit	
Return parameter	<bool> Returns the setting in <bool> format.</bool></bool>		
Example	SOUR:CURR:LIM:AUTO 0		
	Disables the current limit.		

[:SOURce]:CURRent:PROTection:DELay



Description	Sets the Delay Time for OCP in seconds for turning the output off. The delay is set to 0.1 by default.		
Syntax	[:SOURce]:CURRent:PROTection:DELay { <nr2> MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:CURRent:PROTection:DELay?		
Parameter	<nr2> 0.1~2.0 seconds, where 0=no delay</nr2>		
	MAX The maximum allowed delay time		
	MIN The minimum allowed delay time		
Return parameter	r <nr2> Returns the delay time in seconds</nr2>		
Example	SOUR:CURR:PROT:DEL MAX		

Sets the current protection delay to the maximum.

Description Sets or queries the OCP (over-current protection) level in amps.



Description

Query Syntax Parameter

Return parameter <bool>

Syntax

Syntax	[:SOURce]:CURRent:PROTection[:LEVel] { <nr2>(A) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:CURRent:PROTection[:LEVel]?		
Parameter	<nr2> Current protection level.</nr2>		
		Minimum: Depend on the unit type:	
	if Irated * $0.1 > 5A$, then minimum = $5A$,		
	else minimum = Irated * 0.1		
	Maximum: Irated * 1.1		
	MIN	MIN Minimum current level.	
	MAX	Maximum current level.	
Return parameter	<nr2></nr2>	Returns the current protection level.	
Example	SOUR:CURR:PROT:LEV?		
	+5.000		


Returns the minimum possible current level in amps.

Set

[:SOURce]:CURRent:PROTection:STATe

OFF | 0

ON | 1



→ Query

Query

<bool> format. Example SOUR:CURR:PROT:STAT OFF

{<bool>|OFF|ON}

Turns OCP off.

[:SOURce]:CURRent:PROTection:TRIPped

Description	Returns the state of the current protection circuits.		
Query Syntax [:SOUF]:CURRent:PROTection:TRIPped?	
Return parameter	<bool></bool>	Returns protection status.	

Turns the OCP off. Turns the OCP on.



Example SOUR:CURR:PROT:TRIP?

>0


The protection circuit has not been tripped.

Description	Sets or queries the rising current slew rate. This is only applicable for CC slew rate priority mode.		
Syntax	[:SOURce]:CURRent:SLEWrate:RISing { <nr2>(A) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:CURRent:SLEWrate:RISing?		
Parameter	<nr2></nr2>	NR2> Per step is between 0.001A/msec and rated current divided by 100 msec.	
	MIN Minimum rising current slew rate is 0.001A/msec.		
	MAX	Maximum rising current slew rate is rated current divided by 100msec.	
Return parameter			

Example SOUR:CURR:SLEW:RIS?

0.950

Sets the rising current slew rate to 0.950 A/ms.



Description	Sets or queries the falling current slew rate. This is only applicable for CC slew rate priority mode.			
Syntax	[:SOURce]:CURRent:SLEWrate:FALLing { <nr2>(A) MINimum MAXimum}</nr2>			
Query Syntax	[:SOURce]:CURRent:SLEWrate:FALLing?			
Parameter	<nr2> Per step is between 0.001A/msec and racurrent divided by 100 msec.</nr2>			
	MIN Minimum falling current slew rate is			
		0.001A/msec.		
	MAX	Maximum falling current slew rate is rated		
		current divided by 100msec.		
Return Parameter	<nr2></nr2>	Returns the step current		



Example SOUR:CURR:SLEW:FALL MAX

Sets the falling current slew rate to the maximum.

[:SOURce]:MODE?



Description	Returns the status of the output mode (CC, CV, Off) of the power supply.		
	The interface will return "CV' if the supply is in Constant Voltage Mode, "CC" if the supply is in Constant Current Mode or "OFF" if the supply output is off.		
Query Syntax	[:SOURce]:MODE?		
Return parameter	r <string "cc".<="" a="" as="" output="" returns="" state="" string="" td="" the=""></string>		

"CV", "OFF"

Example :SOUR:MODE?

>CC

The power supply is currently in CC mode.

[:SOURce]:RESistance[:LEVel][:IMMediate] [:AMPLitude]



Description	Sets or queries the internal resistance in ohms.		
Syntax	[:SOURce]:RESistance[:LEVel][:IMMediate][:AMPLitude] { <nr2>(OHM) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:RESistance[:LEVel][:IMMediate][:AMPLitude]?		
Parameter	<nr2></nr2>	Resistance in ohms:	
		0 ohm ~ Rrated = Vrated/Irated	
	MIN	Minimum internal resistance in ohms	
	MAX	Maximum internal resistance in ohms	
Return parameter	<nr2></nr2>	R2> Returns the internal resistance in ohms.	
Example SOUR:RES:LEV:IMM:AM		S:LEV:IMM:AMPL 0.1	
	Sets the internal resistance to $100m\Omega$.		



[:SOURce]:VOL	Tage:EX	Ternal:RANGe	Set → Query
Description	Sets or queries the CC or CV control range that is used during external control. Note: the setting will only be valid after the power has been cycled.		
Syntax	[:SOURce]:VOLTage:EXTernal:RANGe {LOW HIGH}		
Query Syntax	[:SOURce]:VOLTage:EXTernal:RANGe?		
Parameter/Return parameter	LOW HIGH	A range of 0 V to 5 V is to A range of 0 V to 10 V is	
Example	VOLT:EXT	:RANG?	
	LOW		
	Returns L	.OW range.	
[:SOURce]:VOLTage[:LEVel][:IMMediate]			

[:AMPLitude]		→ Query	
Description	Sets or queries the voltage level in volts.		
Syntax	[:SOURce]:VOLTage[:LEVel][:IMMediate][:AMPLitude] { <nr2>(V) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:VOLTage[:LEVel][:IMMediate][:AMPLitude]?		
Parameter	<nrf></nrf>	0~105% of the rated output voltage in volts.	
	MIN	Minimum voltage level	
	MAX	Maximum voltage level	
Return parameter	<nr2></nr2>	Returns the voltage level in volts	
Example	SOUR:VOLT:LEV:IMM:AMPL 10		
	Sets the v	oltage level to 10 volts.	

[:SOURce]:VO [:AMPLitude]	Set → Query	
Description	Sets or queries the voltage leve software trigger has been gene	



Syntax	[:SOURce]:VOLTage[:LEVel]:TRIGgered[:AMPLitude] { <nr2>(V) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:VOLTage[:LEVel]:TRIGgered[:AMPLitude]?		
Parameter	<nr2> 0%~105% of the rated voltage output in volts</nr2>		
	MIN	Minimum current level.	
Determination	MAX	Maximum current level.	
Return parameter			
Example		OLT:LEV:TRIG:AMPL 10	
		voltage level to 10 volts when a software generated.	
		Set →	
[:SOURce]:VOL	Tage:LIN	Mit:AUTO → Query	
Description	Sets whether to limit the voltage setting so that it does not exceed the OVP setting or become lower than the UVL setting.		
	If you enable the limit when the OVP setting is lower than the voltage setting, the OVP setting will be set to 105 % of the voltage setting.		
	higher th	nable the limit when the UVL setting is nan the voltage setting, the UVL setting et equal to the voltage setting.	
Syntax	[:SOURce	e]:VOLTage:LIMit:AUTO { <bool> OFF ON}</bool>	
Query Syntax	f:SOURce	e]:VOLTage:LIMit:AUTO?	
Parameter	OFF 0	Disable the limit setting	
	ON 1	Enable the limit setting	
Return parameter	<bool></bool>	Returns the setting in <bool> format.</bool>	
Example	SOUR:VC	OLT:LIM:AUTO 0	
	Disables	the limit setting.	
		(Set)→	
[:SOURce]:VOL	Tage:LIN		
Description	Sets or qu	ueries the under voltage (UVL) trip point.	
Syntax	-	e]:VOLTage:LIMit:LOW /) MINimum MAXimum	



Query Syntax	[:SOURce]:VOLTage:LIMit:LOW?
Parameter/Return	<nr2> 0 ~ the present setting voltage</nr2>	
	MIN	Minimum allowed voltage level
	MAX	Maximum allowed voltage level
Example	SOUR:VOLT:LIM:LOW MAX	
	Sets the UV> level to its maximum.	

[:SOURce]:VOLTage:PROTection[:LEVel] → Query

Description	Sets or queries the overvoltage protection level.		
Syntax	[:SOURce]:VOLTage:PROTection[:LEVel] { <nr2>(V) MINimum MAXimum}</nr2>		
Query Syntax	[:SOURce]:VOLTage:PROTection[:LEVel]?		
Parameter/Return	<nr2> Minimum: Depends on the unit type:</nr2>		
	if Vrated * 0.1 > 5V, then Minimum = 5V, else Minimum = Vrated * 0.1		
	Maximum: Vrated * 1.1		
	MIN	Minimum OVP level	
	MAX	Maximum OVP level	
Example	SOUR:VOLT:PROT:LEV MAX Sets the OVP level to its maximum.		

[:SOURce]:VOLTage:PROTection:TRIPped \longrightarrow Query

Description	Sets or queries the overvoltage protection level.		
Query Syntax	[:SOURce]:VOLTage:PROTection:TRIPped?		
Return parameter	<bool></bool>		
	0 Protection not tripped		
	1 Protection tripped		
Example	SOUR:VOLT:PROT:TRIP?		
	>0		
	Indicates that the OVP protection has not been tripped.		



[:SOURce]:VOL	.Tage:SLI	EWrate:RISing	Set → Query
Description	Sets or queries the rising voltage slew rate. This is only applicable for CV slew rate priority mode.		
Syntax Query Syntax	{ <nr2>(\</nr2>]:VOLTage:SLEWrate:RI /) MINimum MAXimu	m}
Parameter	[:SOURce <nr2> MIN MAX</nr2>]:VOLTage:SLEWrate:Rl Per step is between 0.00 voltage divided by 100 Minimum rising voltag 0.001V/msec. Maximum rising voltag voltage divided by 100	OIV/msec and rated msec. ge slew rate is ge slew rate is rated
Return parameter	<nr2></nr2>	Returns the slew rate in	
Example	SOUR:VC	LT:SLEW:RIS MAX	
	Sets the rising voltage slew rate to its maximum.		
		ising voltage siew rate	to its maximum.
		ising voltage slew rate	Set →
[:SOURce]:VOL		EWrate:FALLing	
[:SOURce]:VOL	Tage:SLI Sets or qu		Set ————————————————————————————————————
	Tage:SLI Sets or que only app	EWrate:FALLing	Set ——Query age slew rate. This is te priority mode. ALLing
Description	Sets or que only app [:SOURce { <nr2>(\</nr2>	EWrate:FALLing ueries the falling volta licable for CV slew ra]:VOLTage:SLEWrate:FA	Set ——Query age slew rate. This is te priority mode. ALLing m)
Description Syntax	Sets or que only app [:SOURce { <nr2>(\</nr2>	EWrate:FALLing Decries the falling voltalicable for CV slew rand it is in the falling voltage:SLEWrate:FA/) MINimum MAXimum EVOLTage:SLEWrate:FA/Per step is between 0.00 voltage divided by 100 minimum falling voltage 0.001V/msec. Maximum falling voltage voltage voltage divided by 100 Minimum falling voltage 0.001V/msec.	Set ——Query age slew rate. This is te priority mode. ALLing m ALLing? OIV/msec and rated msec. ge slew rate is ge slew rate is rated
Description Syntax Query Syntax	Sets or que only app [:SOURce { <nr2>(\text{NR2>}) MIN MAX</nr2>	EWrate:FALLing Decries the falling voltalicable for CV slew rale:PACITAGE:SLEWrate:PACITAGE:Slewrate:PACITAGE:Slewrate:PACITAGE:Slewrate:PACITAGE:Slewrate:PACITAGE:Slewrate:PACITAGE:Slewrate:PACITAGE:Slewrate:PACITAGE:Slewrate:PACITAGE:PACITAGE:Slewrate:PACITAGE:	Set ——Query age slew rate. This is te priority mode. ALLing m ALLing? OIV/msec and rated msec. ge slew rate is ge slew rate is rated msec.
Description Syntax Query Syntax Parameter	Sets or que only app. [:SOURce { <nr2>(NR2>) MIN MAX <nr2></nr2></nr2>	EWrate:FALLing Decries the falling voltalicable for CV slew rale:VOLTage:SLEWrate:FALLING EVOLTage:SLEWrate:FALLING Per step is between 0.00 voltage divided by 100 Minimum falling voltage 0.001V/msec. Maximum falling voltavoltage divided by 100 voltage divided by 100 vol	Set ——Query age slew rate. This is te priority mode. ALLing m ALLing? OIV/msec and rated msec. ge slew rate is ge slew rate is rated msec.



System Function Command

:SYSTem:BEEPer[:IMMediate]	89
:SYSTem:CONFigure:BEEPer[:STATe]	90
:SYSTem:CONFigure:BLEeder[:STATe]	
:SYSTem:CONFigure:CURRent:CONTrol	
:SYSTem:CONFigure:VOLTage:CONTrol	
:SYSTem:CONFigure:OUTPut:PON[:STATe]	
:SYSTem:CONFigure:PROTection:RECovery	
:SYSTem:CONFigure:MSLave	93
: SYSTem: CONFigure: OUTPut: EXTernal: MODE	93
:SYSTem:CONFigure:OUTPut:EXTernal[:STATe]	94
:SYSTem:CONFigure:MONitor:RANGe	
:SYSTem:CONFigure:TRIGger:INPut:SOURce	
:SYSTem:CONFigure:TRIGger:INPut:WIDTh	
:SYSTem:CONFigure:TRIGger:OUTPut:SOURce	
:SYSTem:CONFigure:TRIGger:OUTPut:WIDTh	96
:SYSTem:CONFigure:TRIGger:OUTPut:LEVel	
:SYSTem:COMMunicate:ENABle	
:SYSTem:COMMunicate:GPIB[:SELF]:ADDRess	
:SYSTem:COMMunicate:LAN:IPADdress	
:SYSTem:COMMunicate:LAN:GATEway	98
:SYSTem:COMMunicate:LAN:SMASk	
:SYSTem:COMMunicate:LAN:MAC	99
:SYSTem:COMMunicate:LAN:DHCP	99
:SYSTem:COMMunicate:LAN:DNS	
:SYSTem:COMMunicate:RLSTate	100
:SYSTem:COMMunicate:TCPip:CONTrol	100
:SYSTem:COMMunicate:SERial:LANGuage[:SELec	
:SYSTem:COMMunicate:SERial[:RECeive]:TRANs:	
:BAUD	101
:SYSTem:COMMunicate:SERial[:RECeive] :TRANs:	mit
:BITS	102
:SYSTem:COMMunicate:SERial[:RECeive]:TRANsr	nit
:PARity	102
:SYSTem:COMMunicate:SERial[:RECeive]:TRANsr	nit
:SBITs	103
:SYSTem:COMMunicate:USB:FRONt:STATe	103
:SYSTem:COMMunicate:USB:REAR:MODE	103
:SYSTem:COMMunicate:USB:REAR:STATe	104
:SYSTem:ERRor	104
·SYSTem·KLOCk	104



	:SYSTem:ER :SYSTem:LA :SYSTem:LA :SYSTem:PRI :SYSTem:VE	YLock:MODE	105 105 105 106
:SYSTem:BEEP	er[:IMMedi	Set → ate] —Query	
Description		and causes an audible tone to be y the instrument. The duration time seconds.	e is
Syntax	:SYSTem:BEEPer[:IMMediate] { <nr1> MINimum MAXimum}</nr1>		
Query Syntax	:SYSTem:BE	EPer[:IMMediate]? [MINimum MAXim	um]
Parameter	<nr1> MINimum MAXimum</nr1>	0 ~ 3600 seconds. Sets the beeper time to the minimum (seconds) Sets the beeper time to the maximum (3600 seconds)	0
Return parameter	<nr1></nr1>	Returns the remaining beeper duration time in seconds or returns the maximu or minimum beeper time in seconds (f the [MINimum MAXimum] query parameters).	ım
Example 1	:SYST:BEEP 10 **after a 2 second wait** :SYST:BEEP? >8		
	The first command turns the beeper on for 10 seconds. After 2 seconds the SYST:BEEP? query returns the remaining beeper time (8 seconds).		
Example 2	:SYST:BEEP? >3600	MAX	
	Returns the maximum settable beeper time in seconds.		



:SYSTem:CON	Figure:BE	EPer[:STATe]	Set → Query	
Description	Sets or queries the buzzer state on/off.			
Syntax	:SYSTem:CONFigure:BEEPer[:STATe] { <bool> OFF ON}</bool>			
Query Syntax	:SYSTem:C	ONFigure:BEEPer[:STA	Ге]?	
Parameter	OFF 0 ON 1	Turns the buzzer off. Turns the buzzer on.		
Return parameter	<bool></bool>	Returns the buzzer state	us.	
:SYSTem:CON		Eeder[:STATe]	Set → Query	
Description	Sets or que	eries the status of the l	oleeder resistor.	
Syntax Query Syntax	:SYSTem:CONFigure:BLEeder[:STATe] { <nr1> OFF ON AUTO}</nr1>			
Q , ,	:SYSTem:CONFigure:BLEeder[:STATe]?			
Parameter	OFF 0 ON 1 AUTO 2	Turns the bleeder resist Turns the bleeder resist Turn the AUTO mode of	or on.	
Return parameter	<nr1></nr1>	Returns bleeder resistor	status.	
$\begin{array}{ccc} & & & & \\ & & \\ & & & \\ & & & \\ & & & \\ & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\$				
Description	Sets or queries the CC control mode (local control (panel), external voltage control, external resistance control). This setting is applied only after the unit is reset.			
Syntax	:SYSTem:CONFigure:CURRent:CONTrol { <nr1> NONE VOLTage RRISing RFALling VISolation }</nr1>			
Query Syntax	:SYSTem:C	ONFigure:CURRent:CC	NTrol?	



Parameter	<nr1></nr1>	Description	
	0 NONE	Local (Panel) control	
	1 VOLTage	External voltage control	
	2 RRISing	External resistance control; $10k\Omega$ or	
		$5kΩ = Io max^*$, $0kΩ = Io min$.	
	3 RFALling	External resistance control; $10k\Omega$ or	
	4 VISolation	5kΩ = Io min*, $0kΩ$ = Io max. External voltage control (isolated)	
	•		
	*The resistance val	ue depends on the nt:EXTernal:RANGe command.	
		, then the resistance is $10k\Omega$, else it is	
	$5k\Omega$. See page 78 fc		
Return Parameter		Returns the current control	
netarri arameter	STATE	configuration.	
		(Set)→	
·SVSTam·CON	Figure:VOLTage		
.5151em.com	i iguie. VOLTage	CONTION — Query	
Description	Sets or queries the CV control mode (local control (panel), external voltage control, external resistance control). This setting is applied only after the unit is reset.		
Syntax	:SYSTem:CONFigure:VOLTage:CONTrol { <nr1> NONE VOLTage RRISing RFALling VISolation }</nr1>		
Query Syntax	:SYSTem:CONFigu	ure:VOLTage:CONTrol?	
Parameter	<nr1></nr1>	Description	
	0 NONE	Local (Panel) control	
	1 VOLTage	External voltage control	
	2 RRISing	External resistance control; $10k\Omega$ or	
	$5k\Omega = Io \max^*, 0k\Omega = Io \min.$		
	3 RFALling	External resistance control; $10k\Omega$ or	
	1 VISolation	5kΩ = Io min*, $0kΩ$ = Io max. External voltage control (isolated)	
4 VISolation			
	*The resistance val		
[:SOURce]:VOLTage:EXTernal:RANGe command If the range is high, then the resistance is $10k\Omega$, el $5k\Omega$. See page 78 for details.			
			one page 70 for details.



Return Parameter	<nr1></nr1>	Returns the current control configuration.		
$\underbrace{Set} \longrightarrow \\ :SYSTem:CONFigure:OUTPut:PON[:STATe] \longrightarrow \underbrace{Query}$				
Description	Sets the output state at power-on. This is the equivalent to the F-92 (Output Status when Power ON) power on configuration settings. These settings only apply after the unit has been reset.			
Syntax Return Syntax	:SYSTem:CONFigure:OUTPut:PON[:STATe] { <nr1> {SAFE OFF} {FORCe ON} AUTO}</nr1>			
	:SYSTem:COI	NFigure:OUTPut:PON[:STATe]?		
Parameter	SAFE OFF	The PSU turns on in the same state the unit was in prior to the previous shut down. The output is set to off (default).		
	FORCe ON			
	AUTO 2	The PSU turns on in the same state the unit was in prior to the previous shut down, but with the same output on/off setting.		
Return parameter	0	The power on output setting is "SAFE" or "OFF".		
	1	The power on output setting is "FORCe" or "ON".		
	2	The power on output setting is "AUTO".		
		(Set)→		
:SYSTem:CON	Figure:PRO	Tection:RECovery → Query		
Description	Sets or queries how the OHP, FAN, AC-FAIL, and SD alarms are cleared.			
Syntax		NFigure:PROTection:RECovery		
Return Syntax	{SAFE AUTO	•		
	:SYSTem:CONFigure:PROTection:RECovery?			
Parameter		he output is not turned on automatically when the cause of the alarm is fixed.		



		•	
	AUTO	The output is turned on when the cause of the al	
$\begin{array}{ccc} & & & & & \\ & & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & \\ & & \\ & & \\ & \\ & & \\ &$			
Description		ueries the unit operation only applied after the u	
Syntax	:SYSTem:	CONFigure:MSLave { <n< td=""><td>R1> }</td></n<>	R1> }
Query Syntax	:SYSTem:	CONFigure:MSLave?	
Parameter/Return :SYSTem:CON :MODE	0 1 2 3 4	Description Master/Local Master/with 1 unit in Par Master/with 2 units in Par Master/with 3 units in Par Slave UTPut:EXTernal	arallel (total: 3 units)
Description	when usi equivaler power or	ogic used to turn the ouing an external contact. Int to the F-94 (External Configuration settings. Ing is only applied after	This is the Output Logic)
Syntax	:SYSTem:	CONFigure:OUTPut:EXTe	ernal:MODF
Return Syntax	{ <nr1> LOW HIGH}</nr1>		
Trestann Synnan	:SYSTem:	CONFigure:OUTPut:EXTe	ernal:MODE?
Parameter	LUCLIA	A ationa lai ala	
	LOW 1	Active high Active low	



:SYSTem:CON [:STATe]	Figure:O	UTPut:EXTernal	Set — Query
Description	externall	ther the output will be y. By default this settir only applied after the	ng is turned off. This
Syntax Return Syntax	:SYSTem:CONFigure:OUTPut:EXTernal[:STATe] { <bool> OFF ON} :SYSTem:CONFigure:OUTPut:EXTernal[:STATe]?</bool>		
Parameter	ON 1 OFF 0	External control is perfo External control is not p	rmed.
Return parameter	<bool></bool>	Returns output status of	the instrument.
:SYSTem:CON	Figure:M	ONitor:RANGe	Set → Query
Description	voltage r	mand is used to select ange. ng is only applied afte	
Syntax		CONFigure:MONitor:R/ .OW HIGH}	ANGe
Return Syntax	:SYSTem:	CONFigure:MONitor:R/	ANGe?
Parameter	HIGH 0 LOW 1		
Return Parameter	<nr1></nr1>	Returns the logic setting	;.
:SYSTem:CON :SOURce	Figure:TF	RIGger:INPut	Set → Query
Description		ueries what action will ; a trigger.	be performed on
Syntax		CONFigure:TRIGger:IN NONE OUTPut SETTing	
Return Syntax	:SYSTem:	CONFigure:TRIGger:IN	Put:SOURce?



Parameter	NONE 0	No input trigger.
	OUTPut 1	Toggles the output on receiving a trigger.
	SETTing 2	Sets the voltage/current on receiving a
		trigger.
	MEMory 3	Loads a memory setting on receiving a
		trigger.
Return Parameter	<nr1></nr1>	Returns the input source.

:SYSTem:CON :WIDTh	Figure:TRIC	iger:INPut Set → Query	
Description	Sets or queries the input trigger pulse width. A setting of 0 indicates that the input trigger is controlled by the trigger input level, rather than a trigger pulse.		
Syntax	:SYSTem:CONFigure:TRIGger:INPut:WIDTh { <nr2> MINimum MAXimum}</nr2>		
Return Syntax	:SYSTem:CONFigure:TRIGger:INPut:WIDTh? [MINimum MAXimum]		
Parameter	<nr2> 0 ~ 60ms.</nr2>		
	MINimum	Minimum width $= 0$.	
	MAXimum	60ms	
Return Parameter	<nr2> Returns the trigger input width.</nr2>		

:SOURce		→ Query	
Description	Sets or quer	ries the output trigger source.	
Syntax		:SYSTem:CONFigure:TRIGger:OUTPut:SOURce { <nr1> NONE OUTPut SETTing MEMory}</nr1>	
Return Syntax	:SYSTem:CO	NFigure:TRIGger:OUTPut:SOURce?	
Parameter	NONE 0	No output trigger.	
	OUTPut 1	Output trigger is generated by a change in	
		the output.	
	SETTing 2	Output trigger is generated when a setting	
		is changed.	
	MEMory 3	Output trigger is generated when a	
		memory setting is loaded.	

: SYSTem: CONFigure: TRIGger: OUTPut



Return Parameter	<nr1></nr1>	Returns the output so	ource.
:SYSTem:CON :WIDTh	Figure:TRIC	iger:OUTPut	Set → Query
Description	setting of 0 i	ies the output trigge indicates that the ou depending on the o	tput trigger will go
Related Commands	:SYSTem:CO	NFigure:TRIGger:OU	TPut:LEVel
Syntax		NFigure:TRIGger:OU Iimum MAXimum}	TPut:WIDTh
Return Syntax	:SYSTem:CO [MINimum N	NFigure:TRIGger:OU [·] //AXimum]	TPut:WIDTh?
Parameter	<nr2> MINimum MAXimum</nr2>	$0 \sim 60 \text{ms}$. Minimum width = 0 60 ms	
Return Parameter	<nr2></nr2>	Returns the trigger or	utput width.
:SYSTem:CON :LEVel	Figure:TRIC	iger:OUTPut	Set → Query
Description	-	arity of the output tr rigger pulse width is	00
Syntax	:SYSTem:CONFigure:TRIGger:OUTPut:LEVel { <nr1> LOW HIGH}</nr1>		
Return Syntax	:SYSTem:CO	NFigure:TRIGger:OU	TPut:LEVel?
Parameter	0 LOW 1 HIGH	Sets the output trigge Sets the output trigge	er to active high.
Return Parameter	<nr1></nr1>	Returns the trigger or	utput width.



:SYSTem:COM	Municate:	ENABle	Set → Query
Description	Enables/Disables GPIB, USB or other remote interfaces such as Sockets and the Web Server.		
	This setting reset.	g is only applied after	r the unit has been
Syntax		DMMunicate:ENABle { PIB USB LAN SOCKet	
Query Syntax		DMMunicate:ENABle? LAN SOCKets WEB SE	-
Parameter 1	OFF 0 ON 1	Disables the selected in Enables the selected in	
Parameter 2	GPIB USB LAN SOCKets WEB SERial	Select GPIB Select USB Select LAN Select Sockets Select the web server Selected Serial (UART	Γ)
Return Parameter	<bool></bool>	Returns the status of t	
Example		И:ENAB 1,USB SB interface on.	
Query Example	SYST:COMM:ENAB? USB 1 Queries the USB state, returns 1 (USB is on).		
:SYSTem:COM :ADDRess	Municate:(GPIB[:SELF]	Set → Query
Description		ries the GPIB address e valid after the powe	0
Syntax	:SYSTem:CC <nr1></nr1>	DMMunicate:GPIB[:SE	LF]:ADDRess
Query Syntax	:SYSTem:COMMunicate:GPIB[:SELF]:ADDRess?		



Parameter/Return	<nr1> 0~30</nr1>		
Example	SYST:COMM:GPIB:SELF:ADDR 15		
	Sets the GPIB address to 15.		
	(Set)→		
:SYSTem:COM	Municate:LAN:IPADdress —Query		
Description	Sets or queries LAN IP address. Note: the setting will only be valid after the power has been cycled.		
Syntax	:SYSTem:COMMunicate:LAN:IPADdress <string></string>		
Query Syntax	:SYSTem:COMMunicate:LAN:IPADdress?		
Parameter/Return	<string> LAN IP address in string format ("address") Applicable ASCII characters: 20H to 7EH</string>		
Example	SYST:COMM:LAN:IPAD "172.16.5.111"		
	Sets the IP address to 172.16.5.111.		
	Set		
:SYSTem:COM	Municate:LAN:GATEway → Query		
Description	Sets or queries the Gateway address. Note: the setting will only be valid after the power has been cycled.		
Syntax	:SYSTem:COMMunicate:LAN:GATEway <string></string>		
Query Syntax	:SYSTem:COMMunicate:LAN:GATEway?		
Parameter/Return	<string> Gateway address in string format ("address") Applicable ASCII characters: 20H to 7EH</string>		
Example	SYST:COMM:LAN:GATE "172.16.0.254" Sets the LAN gateway to 172.16.0.254.		



:SYSTem:COM	Municate:LAN:SMASk ——Query
Description	Sets or queries the LAN subnet mask. Note: the setting will only be valid after the power has been cycled.
Syntax	:SYSTem:COMMunicate:LAN:SMASk <string></string>
Query Syntax	:SYSTem:COMMunicate:LAN:SMASk?
Parameter/Return	<string> Subnet mask in string format ("mask") Applicable ASCII characters: 20H to 7EH</string>
Example	SYST:COMM:LAN:SMASk "255.255.0.0" Sets the LAN mask to 255.255.0.0.
:SYSTem:COM	Municate:LAN:MAC → Query
Description	Returns the unit MAC address as a string. The MAC address cannot be changed.
Query Syntax	:SYSTem:COMMunicate:LAN:MAC?
Return parameter Example	<string> Returns the MAC address in the following format "FF-FF-FF-FF-FF" SYST:COMM:LAN:MAC? 02-80-AD-20-31-B1 Returns the MAC address. Set</string>
:SYSTem:COM	Municate:LAN:DHCP → Query
Description	Turns DHCP on/off. Queries the DHCP status. Note: the setting will only be valid after the power has been cycled.
Syntax	:SYSTem:COMMunicate:LAN:DHCP { <bool> OFF ON}</bool>
Query Syntax	:SYSTem:COMMunicate:LAN:DHCP?
Parameter	OFF 0 DHCP off ON 1 DHCP on
Return parameter	<book> Returns the DHCP status.</book>



:SYSTem:COM	Municate	a·I AN·DNS	Set → Query)
.51516111.66141	iviaineat		, (, , , , , , , , , , , , , , , , , ,
Description	Sets or queries the DNS address. Note: the setting will only be valid after the power has been cycled.		
Syntax	:SYSTem:	COMMunicate:LAN:DNS	<string></string>
Query Syntax	:SYSTem:	COMMunicate:LAN:DNS	;
Parameter/Return	<string></string>	DNS in string format ("m Applicable ASCII charact	
Example		MM:LAN:DNS "172.16.1 DNS to 172.16.1.252.	252"
			Set →
:SYSTem:COM	Municate	e:RLSTate	Query
Description	Enables o	or disables local/remote nt.	e state of the
Syntax	:SYSTem:COMMunicate:RLSTate {LOCal REMote RWLock}		
Query Syntax	:SYSTem:COMMunicate:RLSTate?		
Parameter/Return	LOCal	All keys are valid. This in	
parameter	REMote	controlled by the front pa All keys are invalid, excep and the ability to turn the	ot for the [local] key
	RWLock	All keys are invalid. The ibe controlled remotely.	
Example	:SYST:CO	MM:RLST LOCAL	
	Sets the o	perating mode to local.	
:SYSTem:COM	Municate	e:TCPip:CONTrol	→ Query
Description	Queries t	he socket port number.	
Query Syntax	:SYSTem:	COMMunicate:TCPip:CO	NTrol?
Return parameter	<nr1></nr1>	0000 ~ 9999	
Example	SYST:COM >2268	MM:TCP:CONT?	
	Returns th	ne socket port number.	



:SYSTem:COMMunicate:SERial:LANGuage[Set →
:SELect]	→ Query

Description	Sets or queries the communication protocol for the serial port.	
Syntax	:SYSTem:COMMunicate:SERial:LANGuage[:SELect] {"SCPI" "LEGACY"}	
Query Syntax	:SYSTem:COMMunicate:SERial:LANGuage[:SELect]?	
Parameter/Return parameter	"SCPI"	Sets the communication protocol to SCPI.
	"LEGACY"	Sets the communication protocol to legacy mode. (Emulate TDK Genesys)
Example	SYST:COMM:SER:LANG?	
·	>SCPI	
	Indicates that the communication protocol is set to SCPI.	

:SYSTem:COMMunicate:SERial[:RECeive]	Set →
:TRANsmit:BAUD	→ Query

Description	Sets or queries the UART baud rate. Note: the setting will only be valid after the power has been	
Syntax Query Syntax	cycled. :SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit :BAUD <nr1></nr1>	
(· ·) · · ·	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit :BAUD?	
Parameter/Return	<nr1> 2400, 4800, 9600, 19200, 38400, 57600, 115200</nr1>	
Example	SYST:COMM:SER:TRAN:BAUD? >2400 Returns the baud rate settings.	



:SYSTem:COMMunicate:SERial[:RECeive]
:TRANsmit:BITS



Description	Sets or queries the UART number of data bits. Note: the setting will only be valid after the power has been cycled.		
Syntax	:SYSTem:0	COMMunicate:SERial[:RECeive]:TRANsmit	
Query Syntax	:BITS <nr1></nr1>		
	:SYSTem:0	COMMunicate:SERial[:RECeive]:TRANsmit	
Parameter/Return	<nr1></nr1>		
parameter	0	7 bits	
	1	8 bits	
Example	SYST:CON	MM:SER:TRAN:BITS?	
·	>1		
	Indicates t	hat 8 data bits are used for the UART	
	connection	1.	

RANsmit:PARity

connection.



Description	Sets or queries the parity of the UART connection. Note: the setting will only be valid after the power has been cycled.		
Syntax	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit		
Query Syntax	:PARity <i< td=""><td>NR1></td></i<>	NR1>	
` , ,	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmi :PARity?		
Parameter/Return parameter	n 0 None		
F	1	Odd	
	2	Even	
Example	SYST:COMM:SER:TRAN:PARity?		
	>1		
	Indicates t	that odd parity is used for the UART	



Description	Sets or queries the number of stop bits used for the UART connection. Note: the setting will only be valid after the power has been cycled.		
Syntax	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit		
Query Syntax	:SBITs <nr1></nr1>		
	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit :SBITs?		
Parameter/Return	0 1 stop bit		
parameter	1 2 stop bits		
Example	SYST:COMM:SER:TRAN:SBITs?		
	>1		
	Indicates that one stop bit is used for the UART connection.		

$: SYSTem: COMMunicate: USB: FRONt: STATe \longrightarrow \bigcirc Query$

Description	Queries the front panel USB-A port state.		
Query Syntax	:SYSTem:COMMunicate:USB:FRONt:STATe?		
Return parameter	0 <nr1>Absent</nr1>		
·	1	<nr1>Mass Storage</nr1>	

:SYSTem:COMMunicate:USB:REAR:MODE —Query)

Description	Sets or queries the speed of the rear panel USB B port. This setting is applied only after the unit is reset.
Syntax	:SYSTem:COMMunicate:USB:REAR:MODE { <nr1> DISable AUTO FULL}</nr1>
Query Syntax	:SYSTem:COMMunicate:USB:REAR:MODE?



Parameter	0 DISable	Disable
	1 AUTO	Auto detect speed
	2 FULL	Full speed
Return parameter	<nr1></nr1>	
	0	Disable
	1	Auto detect speed
	2	Full speed

:SYSTem:COMMunicate:USB:REAR:STATe → Query

Description	Queries the rear panel USB-B port state.		
Query Syntax	:SYSTem:COMMunicate:USB:REAR:STATe?		
Return parameter	0 <nr1>Absent</nr1>		
•	1	<nr1>Connected to the PC</nr1>	

:SYSTem:ERRor



Description	Queries the error queue. The last error message is
	returned. A maximum of 32 errors are stored in the
	error allelle

Query Syntax :SYSTem:ERRor?

Return parameter <string> Returns an error code followed by an error message as a single string.

Example SYSTem:ERRor?

-100, "Command error"

:SYSTem:KLOCk



Description	Enables or disables the front panel key lock.		
Syntax	:SYSTem:KLOCk { <bool> OFF ON }</bool>		
Query Syntax	:SYSTem:KLOCk?		
Parameter	OFF 0	Panel keys unlocked	
	ON 1	Panel keys locked	
Return parameter	<bool></bool>	Returns the key lock status.	



:SYSTem:KEYL	ock:MODE		Set → Query
Description	Sets or queries the keylock mode. This setting is the equivalent to the F-19 function setting.		- C
Syntax	:SYSTem:KE	YLock { <bool> OFF C</bool>	N}
Query Syntax	:SYSTem:KE	YLock?	
Parameter/Return parameter		nel lock: allow output nel lock: allow output	
:SYSTem:ERRo	r:ENABle		Set →
Description		error Queue and ena be placed in the Sys	
Syntax	:SYSTem:ERRor:ENABle		
:SYSTem:LANC	Guage:EMU	Lation	Set → Query
Description	Sets or quer	ries the command la	nguage.
Syntax	:SYSTem:LANGuage:EMULation {"NONE" "N5700" "GENSYS" "PWX"}		
Query Syntax	:SYSTem:LAI	NGuage:EMULation?	
Parameter/ Return parameter	"NONE" "N5700" "GENSYS" "PWX"	Emulation is not use setting N5700/N8700 emula GENESYS emulation PAG emulation is use	is used.
			Set →
:SYSTem:LANC	Guage:[:SEL	ect]	—Query
Description	Sets or quer	ies the command la	nguage.
Syntax	:SYSTem:LANGuage[:SELect] {"SCPI" "LEGACY"}		
Query Syntax	:SYSTem:LANGuage[:SELect]?		



Parameter/	"SCPI"	Use the SCPI command language. This the
Return parameter		default language
•	"LEGACY"	Use the GEN command language.

:SYSTem:PRESet



Description	Loads the default settings.

Syntax :SYSTem:PRESet

:SYSTem:VERSion



Description	Returns the version of the PSU SCPI version.	
Query Syntax	:SYSTem:VERSion?	
Return	<string> Returns the SCPI version as a string.</string>	
Query Example	SYST:VERS? >1999.9	

:SYSTem:REBoot



Description	Reboots the PSU system.
Syntax	:SYSTem:REBoot



Trigger Commands

:TRIGger:OUTPut:SOURce	107
:TRIGger:OUTPut[:IMMediate]	
:TRIGger[:TRANsient]:SOURce	
:TRIGger[:TRANsient][:IMMediate]	

:TRIGger:OUTPut:SOURce \longrightarrow Query

Description	Sets or queries the trigger source of the output trigger.	
Syntax	:TRIGger:OUTPut:SOURce {BUS IMMediate EXTernal}	
Query Syntax	:TRIGger:OUTPut:SOURce?	
Parameter/	BUS	Output trigger is generated by the bus.
Return parameter	IMMediate	Output trigger is immediately generated.
	EXTernal	The output trigger is generated when an
		external signal triggers it.
Example	:TRIGger:OUTPut:SOURce?	
	EXT	
	Sets the outp	out trigger source to EXT.

:TRIGger:OUTPut[:IMMediate]



Description	Generates an immediate trigger for the output trigger system.	
Syntax	:TRIGger:OUTPut[:IMMediate]	
Example	:TRIG:OUTP	
Example	:TRIG:MEM	
:TRIGger[:TR	ANsient]:SOURce $\xrightarrow{\text{Set}}$	

Description Sets or queries the source of the transient trigger.



Syntax	:TRIGger[:TRANsient]:SOURce {BUS IMMediate EXTernal}	
Query Syntax	:TRIGger[:TRANsient]:SOURce?	
Parameter/	BUS	Transient trigger is generated by the bus.
Return parameter	IMMediate	Transient trigger is immediately
·		generated.
	EXTernal	The transient trigger is generated when an
		external signal triggers it.
Example	:TRIG:SOUR?	
	EXT	
	Sets the tran	isient trigger source to EXT.

: TRIGger[:TRANsient][:IMMediate]



Description	Generates an immediate trigger for the transient trigger system.
Syntax	:TRIGger[:TRANsient][:IMMediate]
Example	:TRIG



IEEE 488.2 Common Commands

	*ESE *ESR *IDN *OPC *RCL *RST		
	*TRG *TST		112 112
*CLS		Set	
Description		S command clears all the event g the status byte, event status	0
Syntax	*CLS		
*ESE		Set →Q	uery)
Description	Sets or queregister.	ueries the Standard Event Stat	us Enable
Syntax	*ESE <ni< td=""><td>R1></td><td></td></ni<>	R1>	
Query Syntax	*ESE?		
Parameter	<nr1></nr1>	0~255	
Return parameter	<nr1></nr1>	Returns the bit sum of the Standa Status Enable register.	ard Event
*ESR		→ (Q	uery)



Description	Queries the Standard Event Status (Event) register. The Event Status register is cleared after it is read.
Query Syntax	*ESR?
Return parameter	<nr1> Returns the bit sum of the Standard Event Status (Event) register and clears the register.</nr1>
*IDN	→(Query)
Description	Queries the manufacturer, model name, serial number, and firmware version of the PSU.
Query Syntax	*IDN?
Return parameter	string in the following format: GW-INSTEK,PSU-2076,TW123456,01.00.20110101 Manufacturer: GW-INSTEK Model number: PSU-3036 Serial number: TW123456 Firmware version: 01.00.20110101
*OPC	Set → Query
Description	The *OPC command sets the OPC bit (bit0) of the Standard Event Status Register when all current commands have been processed. The *OPC2 Overy returns 1 when all the
	The *OPC? Query returns 1 when all the outstanding commands have completed.
Syntax	*OPC
Query Syntax	*OPC?
Return parameter	Returns 1 when all the outstanding commands have completed.
*RCL	
Description	Recalls the contents stored in memory slot M1, M2 or M3.
Syntax	*RCL { <nr1> MAX MIN}</nr1>



Parameter	<nr1> MIN MAX</nr1>	0, 1, 2 (as memory M1 , M2, M3) Recalls the M1 memory contents. Recalls the M3 memory contents.
*RST		<u>Set</u> →
Description	known c	s a device reset. Configures the unit to a onfiguration (default settings). This onfiguration is independent of the usage
Syntax	*RST	
*SAV		(Set)→
Description	Saves the	e settings into memory slot M1, M2 or M3.
Syntax	*SAV { <n< td=""><td>IR1> MIN MAX}</td></n<>	IR1> MIN MAX}
Return parameter	<nr1> MIN MAX</nr1>	0, 1, 2 (as memory M1 , M2, M3) Saves the M1 memory contents. Saves the M3 memory contents.
*SRE		Set → Query
Description	The Serv which re	ueries the Service Request Enable register. ice Request Enable register determines gisters of the Status Byte register are able ate service requests.
Syntax	*SRE <ni< td=""><td>R1></td></ni<>	R1>
Query Syntax	*SRE?	
Parameter	<nr1></nr1>	0~255
Return parameter	<nr1></nr1>	Returns the bit sum of the Service Request Enable register.



*STB		→ Query
Description	-	the bit sum of the Status Byte register with ster summary Status) replacing the RQS
Query Syntax	*STB?	
Return parameter	<nr1></nr1>	Returns the bit sum of the Status Byte register with the MSS bit (bit 6).
*TRG		Set →
Description	(Group E a trigger	G command is able to generate a "get" Execute Trigger). If the PSU cannot accept at the time of the command, an error is generated (-211, "Trigger ignored").
Syntax	*TRG	
*TST		→ Query
Description	Executes	a self test.
Query Syntax	*TST?	
Return parameter	0	Returns "0" if there are no errors.
·	<nr1></nr1>	Returns an error code <nr1> if there is an error.</nr1>
*WAI		Set →
Description		any other commands or queries from ecuted until all outstanding commands appleted.
Syntax	*WAI	

Status Register Overview

To program the PSU power supply effectively, the Status registers need to be understood. This chapter explains in detail how the Status registers are used and how to configure them.

Introduction to the Status Registers	113
The Status Registers	
Questionable Status Register Group	
Operation Status Register Group	
Standard Event Status Register Group	
Status Byte Register & Service Request Enabl	

Introduction to the Status Registers

Overview

The status registers are used to determine the status of the power supply. The status registers maintain the status of the protection conditions, operation conditions and instrument errors.


The PSU Series have a number of register groups:

- Questionable Status Register Group
- Standard Event Status Register Group
- Operation Status Register Group
- Status Byte Register
- Service Request Enable Register
- Service Request Generation
- Error Queue
- Output Buffer

The next page shows the structure of the Status registers.



The Status Registers






Questionable Status Register Group

Overview

The Questionable Status Register Group indicates if any protection modes or limits have been tripped.



Bit Summary	Event	Bit #	Bit Weight	
	OV (Over-Voltage)	0	1	
	Over voltage protection has been tripped	Over voltage protection has been tripped		
	OC (Over-Current)	1	2	
	Over current protection has been tripped			
	POW (AC Power Off)	3	8	
	AC power switch is off			




	OT (Over Temperature)	4	16
	Over temperature protection ha been tripped	.5	
	VL (Voltage Limit)	8	256
	Voltage limit has been reached		
	CL (Current Limit)	9	512
	Current limit has been reached		
	SD (Shutdown Alarm)	11	2048
	PL (Power-Limit)	12	4096
Condition Register	The Questionable Status Condition Register indicates the status of the power supply. If a bit is set in the Condition register, it indicates that the event is true. Reading the condition register does not change the state of the condition register.		
PTR/NTR Filters	The PTR/NTR (Positive/Negative transition register determines the type of transition conditions that will set the corresponding be the Event Registers. Use the Positive transition filter to view events that change from false positive, and use the negative transition filt view events that change from positive to negative.		
	Positive Transition 0–	→ 1	
	Negative Transition 1–	→ 0	
Event Register	The PTR/NTR Register will dictate the type of transition conditions will set the corresponding bits in the Event Register. If the Event Register is read, it will be cleared to 0.		
Enable Register	The Enable register determines which Events in the Event Register will be used to set the QUES bit in the Status Byte Register.		



Operation Status Register Group

Overview

The Operation Status Register Group indicates the operating status of the power supply.



Bit Summary	Event	Bit #	Bit Weight
	CAL (Calibration mode)	0	1
	Indicates if the PSU is in calibration mode.		
	WTG (Waiting for trigger)	5	32
	Indicates if the PSU is waiting a trigger.	for	



	CV (Constant voltage mode) Indicates if the PSU is in CV mode.	8	256
	CC (Constant current mode)	10	1024
	Indicates if the PSU is in CC mode.		
	OND (Output ON Delay)	11	2048
	Indicates if Output ON delay tile is active	me	
	OFD (Output OFF Delay)	12	4096
	Indicates if Output OFF delay time is active		
	PR (Program Running)	14	16384
	Indicates if a Test is running		
Condition Register	The Operation Status Condition Register indicates the operating status of the power supply. If a bit is set in the Condition register, it indicates that the event is true. Reading the condition register does not change the state of the condition register.		
PTR/NTR Filters	TR/NTR Filters The PTR/NTR (Positive/Negative transition register determines the type of transition conditions that will set the corresponding the Event Registers. Use the Positive transfilter to view events that change from fall positive, and use the negative transition view events that change from positive to negative.		
	Positive Transition 0-	→ 1	
	Negative Transition 1-	→0	




Event Register	The PTR/NTR Register will dictate the type of transition conditions will set the corresponding bits in the Event Register. If the Event Register is read, it will be cleared to 0.
Enable Register	The Enable register determines which registered Events in the Event Register will be used to set the OPER bit in the Status Byte Register.



Standard Event Status Register Group

Overview

The Standard Event Status Register Group indicates if any errors have occurred. The bits of the Event register are set by the error event queue.



Bit	Summary
-----	---------

Event	Bit #	Bit Weight
OPC (Operation complete)	0	1
The OCP bit is set when all selected pending operations are complete. This bit is set in response to the *OPC command.		
RQC (Request control)	1	2
QUE (Query Error)	2	4
The Query Error bit is set in response to an error reading the Output Queue. This can be caused by trying to read the Output Queue when there is no data present.		
DDE (Device Dependent Error)	3	8
Device specific error.		




	EXE (Execution Error)	4	16
	The EXE bit indicates an execution error due to one of the following: illegal command parameter, parameter out of range, invalid parameter, the command didn't execute due to an overriding operation condition.		
	CME (Command Error)	5	32
	The CME bit is set when a syntax error has occurred. The CME bit can also be set when a <get> command is received within a program message.</get>		
	URQ (User Request)	6	64
	PON (Power On)	7	128
	Indicates the power is turned on.		
Event Register	Any bits set in the event register indicate that an error has occurred. Reading the Event register will reset the register to 0.		
Enable Register	The Enable register determines which Events in the Event Register will be used to set the ESB bit in the Status Byte Register.		



Status Byte Register & Service Request Enable Register

Overview

The Status Byte register consolidates the status events of all the status registers. The Status Byte register can be read with the *STB? query and can be cleared with the *CLS command.



Bit Summary

Event	Bit #	Bit Weight
ERR (Error Event/Queue)	2	4
If data is present in the Error queue, the ERR bit will be set.		
QUES (Questionable Status Register)	3	8
The summary bit for the Questionable Status Register group.		
MAV (Message Available) This is set when there is data in the Output Queue waiting to be read.	4	16



	(ESB) Event Summary Bit. The ESB is the summary bit for the Standard Event Status Register group.	5	32
	MSS Bit	6	64
	The MSS Bit is the summary of the Status Byte Register and Service Request register (bits 1-5, 7). This will be set to 1.		
	OPER (Operation Status Register) 7	128
	OPER bit is the summary bit for the Operation Status Register Group.		
Status Byte Register	Any bits set in the Status byte is summary register for all the the registers and indicates if there request, an error in the Error Q the Output Queue. Reading the register will reset the register to	ree other is a serv Jueue or e Status	r status ice data in
Service Request Enable Register	The Service Request Enable Re which bits in the Status Byte Regenerate service requests.	_	



Error List

Command Errors	124
Execution Errors	128
Device Specific Errors	130
Query Errors	131

Command Errors

Overview

An <error/event number> in the range [-199 , -100] indicates that an IEEE 488.2 syntax error has been detected by the instrument's parser. The occurrence of any error in this class shall cause the command error bit (bit 5) in the event status register (IEEE 488.2, section 11.5.1) to be set. One of the following events has occurred:

- An IEEE 488.2 syntax error has been detected by the parser. That is, a controller-to-device message was received which is in violation of the IEEE 488.2 standard. Possible violations include a data element which violates the device listening formats or whose type is unacceptable to the device.
- An unrecognized header was received.
 Unrecognized headers include incorrect device-specific headers and incorrect or unimplemented IEEE 488.2 common commands.

Events that generate command errors shall not generate execution errors, device-specific errors, or query errors; see the other error definitions in this chapter.



Error Code	Description
-100 Command Error	This is the generic syntax error for devices that cannot detect more specific errors. This code indicates only that a Command Error as defined in IEEE 488.2,11.5.1.1.4 has occurred.
-102 Syntax error	An unrecognized command or data type was encountered; for example, a string was received when the device does not accept strings.
-103 Invalid separator	The parser was expecting a separator and encountered an illegal character; for example, the semicolon was omitted after a program message unit, MEAS:VOLT:DC?:MEASCURR:DC?
-104 Data type error	The parser recognized a data element different than one allowed; for example, numeric or string data was expected but block data was encountered.
-108 Parameter not allowed	More parameters were received than expected for the header; for example, the KLOCk command only accepts one parameter, so receiving SYSTem:KLOCk 1,0 is not allowed.
-109 Missing parameter	Fewer parameters were recieved than required for the header; for example, the KLOCk command requires one parameter, so receiving KLOCk is not allowed.
-111 Header separator error	A character which is not a legal header separator was encountered while parsing the header; for example, no white space followed the header, thus *SRE2 is an error.



-112 Program mnemonic too long	The header contains more that twelve characters (see IEEE 488.2, 7.6.1.4.1).
-113 Undefined header	The header is syntactically correct, but it is undefined for this specific device; for example, *XYZ is not defined for any device.
-114 Header suffix out of range	The value of a numeric suffix attached to a program mnemonic, see Syntax and Style section 6.2.5.2, makes the header invalid.
-115 Unexpected number of parameters	The number of parameters received does not correspond to the number of parameters expected. This is typically due an inconsistency with the number of instruments in the selected group.
-120 Numeric data error	This error, as well as errors -121 through -129, are generated when parsing a data element which apprears to be numeric, including the nondecimal numeric types. This particular error message should be used if the device cannot detect a more specific error.
-121 Invalid character in number	An invalid character for the data type being parsed was encountered; for example, an alpha in a decimal numeric or a "9" in octal data.
-128 Numeric data not allowed	A legal numeric data element was received, but the device does not accept one in this position for the header.
-131 Invalid suffix	The suffix does not follow the syntax described in IEEE 488.2, 7.7.3.2, or the suffix is inappropriate for this device.



-141 Invalid character data	Either the character data element contains an invalid character or the particular element received is not valid for the header.
-148 Character data not allowed	A legal character data element was encountered where prohibited by the device.
-151 Invalid string data	A string data element was expected, but was invalid for some reason (see IEEE 488.2, 7.7.5.2); for example, an END message was received before the terminal quote character.
-158 String data not allowed	A string data element was encountered but was not allowed by the device at this point in parsing.
-160 Block data error	This error, as well as errors -161 through -169, are generated when parsing a block data element. This particular error message should be used if the device cannot detect a more specific error.
-161 Invalid block data	A block data element was expected, but was invalid for some reason (see IEEE 488.2, 7.7.6.2); for example, an END message was received before the length was satisfied.
-168 Block data not allowed	A legal block data element was encountered but was not allowed by the device at this point in parsing.
-178 Expression data not allowed	A legal expression data was encountered but was not allowed by the device at this point in parsing.



Execution Errors

Overview

An <error/event number> in the range [-299 , -200] indicates that an error has been detected by the instrument's execution control block. The occurrence of any error in this class shall cause the execution error bit (bit 4) in the event status register (IEEE 488.2, section 11.5.1) to be set. One of the following events has occurred:

- A <PROGRAM DATA> element following a header was evaluated by the device as outside of its legal input range or is otherwise inconsistent with the device's capabilities.
- A valid program message could not be properly executed due to some device condition.

Execution errors shall be reported by the device after rounding and expression evaluation operations have taken place. Rounding a numeric data element, for example, shall not be reported as an execution error. Events that generate execution errors shall not generate Command Errors, device-specific errors, or Query Errors; see the other error definitions in this section.

Error Code

Description

-200 Execution error

This is the generic syntax error for devices that cannot detect more specific errors. This code indicates only that an Execution Error as defined in IEEE 488.2, 11.5.1.1.5 has occurred.



-201 Invalid while in local

Indicates that a command is not executable while the device is in local due to a hard local control (see IEEE 488.2, 5.6.1.5); for example, a device with a rotary switch receives a message which would change the switches state, but the device is in local so the message cannot be executed.

-203 Command protected

Indicates that a legal password-protected program command or query could not be executed because the command was disabled.

-211 Trigger ignored

Indicates that a GET, *TRG, or triggering signal was received and recognized by the device but was ignored because of device timing considerations; for example, the device was not ready to respond. Note: a DT0 device always ignores GET and treats *TRG as a Command Error.

-213 Init ignored

Indicates that a request for a measurement initiation was ignored as another measurement was already in progress.

-220 Parameter error

Indicates that a program data element related error occurred. This error message should be used when the device cannot detect the more specific errors described for errors -221 through -229.

-221 Settings conflict

Indicates that a legal program data element was parsed but could not be executed due to the current device state (see IEEE 488.2, 6.4.5.3 and 11.5.1.1.5.).



-222 Data out of range

Indicates that a legal program data element was parsed but could not be executed because the interpreted value was outside the legal range as defined by the device (see IEEE 488.2, 11.5.1.1.5.).

-224 Illegal parameter value

Used where exact value, from a list of possibles, was expected.

Device Specific Errors

Overview

An <error/event number> in the range [-399 , -300] or [1, 32767] indicates that the instrument has detected an error which is not a command error, a query error, or an execution error; some device operations did not properly complete, possibly due to an abnormal hardware or firmware condition. These codes are also used for self-test response errors. The occurrence of any error in this class should cause the device-specific error bit (bit 3) in the event status register (IEEE 488.2, section 11.5.1) to be set. The meaning of positive error codes is device-dependent and may be enumerated or bit mapped; the <error message>string for positive error codes is not defined by SCPI and available to the device designer.

Note that the string is not optional; if the designer does not wish to implement a string for a particular error, the null string should be sent (for example, 42,""). The occurrence of any error in this class should cause the device-specific error bit (bit 3) in the event status register (IEEE 488.2, section 11.5.1) to be set. Events that generate device-specific errors shall not generate command errors, execution errors,



	or query errors; see the other error definitions in this section.
Error Code	Description
-310 System error	Indicates that some error, termed "system error" by the device, has occurred. This code is device-dependent.
-320 Storage fault	Indicates that the firmware detected a fault when using data storage. This error is not an indication of physical damage or failure of any mass storage element.
Query Errors	
Overview	An <error event="" number=""> in the range [-499 , -400] indicates that the output queue control of the instrument has detected a problem with the message exchange protocol described in IEEE 488.2, chapter 6. The occurrence of any error in this class shall cause the query error bit (bit 2) in the event status register (IEEE 488.2, section 11.5.1) to be set. These errors correspond to message exchange protocol errors described in IEEE 488.2, section 6.5. One of the following is true:</error>
•	An attempt is being made to read data from the output queue when no output is either present or pending;
•	Data in the output queue has been lost.
	Events that generate query errors shall not generate command errors, execution errors, or device-specific errors; see the other error definitions in this section.



Error Code	Description
-400 Query error	This is the generic query error for devices that cannot detect more specific errors. This code indicates only that a Query Error as defined in IEEE 488.2, 11.5.1.1.7 and 6.3 has occurred.



APPENDIX

PSU Default Settings

The following default settings are the factory configuration settings for the power supply (Function settings/Test settings).

Initial Settings	Default S	etting
Output	Off	
LOCK	0 (Disable	ed)
Voltage	0V	
Current	0A	
OVP	1.1 X Vrat	te
ОСР	1.1 X Irat	e
Normal Function		
Settings	Setting	Default Setting
Output ON delay time	F-01	0.00s
Output OFF delay time	F-02	0.00s
V-I mode slew rate select	F-03	0 = CV high speed priority
Internal resistance	F-08	Ω 0000.0
setting		
Bleeder circuit control	F-09	1 = ON
Buzzer ON/OFF control	F-10	1 = ON
OCP Delay Time	F-12	0.1 (seconds)
Current Setting Limit	F-13	0 = OFF
Voltage Setting Limit	F-14	0 = OFF
Display Memory	F-15	0 = OFF
parameter when recalling		0 = 011
Auto parallel Control	F-16	0 = OFF
Measurement Average	F-17	0 = Low
Setting		0 – Low
Alarm Recovery and	F-18	0 = Safe Mode
Output Status		Jaic Midde



Lock Mode	F-19	0:Lock Panel, Allow Output OFF
Setup Rear USB Speed	F-22	2 = Auto detect
GPIB address	F-23	8
GPIB Enable/Disable	F-24	1 = Enable
SCPI Emulation	F-26	0 = GW Instek
LAN setting		
LAN	F-36	1 = Enable
DHCP	F-37	1 = Enable
Power On Configuration		
Socket Server	F-57	1 = Enable
Enable/Disable	1-37	I = LIIdDIE
Web Server	F-59	1 = Enable
Enable/Disable	1-37	I – LIIADIC
Web Password	F-60	1 = Enable
Enable/Disable		
UART Mode	F-70	1 = Enable
UART Baudrate	F-71	7 = 115200
UART Data Bits	F-72	1 = 8 bits
UART Parity	F-73	0 = None
UART Stop Bit	F-74	0 = 1 bit
UART Transmission	F-75	0 = SCPI
Control Protocol	F-/3	0 = 3CPI
UART Address	F-76	30
CV Control	F-90	0= Panel control (local)
CC Control	F-91	0= Panel control (local)
Output Status when	г 02	0 = Safe Mode
Power ON	F-92	U = Safe Mode
Master/Slave	F-93	0 = Independent
External Out Logic	F-94	0= High ON
Monitor Voltage Select	F-96	0 = 5V
Control Range	F-97	$0 = 5V[5k\Omega]$
External Output Control	г ое	
Function	F-98	0 = OFF



Error Messages & Messages

The following error messages or messages may appear on the PSU screen during operation.

Error Messages	Description
ОНР	Master & slave board over temperature protection in PSU
ОНР1	Master board over temperature protection in PSU
OHP2	Slave board over temperature protection in PSU
ALM SENS	Sense Alarm
HW OVP	Hardware over voltage protection
AC	AC fail
OVP	Over voltage protection
OCP	Over current protection
FAN FAIL	Fan failure
SHUT DOWN	Force shutdown
Err 001	USB mass storage is not present
Err 002	No (such)file in USB mass storage
Err 003	Empty memory location
Err 004	Slave PSU error status

Normal Messages	Description
MSG 001	External control of output. Output off (F-94=0, High=on)
MSG 002	External control of output. Output off (F-94=1, Low=on)

Communication	
Interface Messages	Description
USB ON	Rear USB port connected to PC
USB OFF	Rear USB port disconnected from PC
MS ON	Mass storage plugged into front USB port
MS OFF	Mass storage removed from front USB port



LED ASCII Table Character Set

Use the following table to read the LCD display messages.

0	1	2	3	4	5	6	7	8	9	Α	В	C	D
	1	2	3	4	5	8	7	8	9	R	Ь	E	ď
Ε	F	G	Н	-1	J	Κ	L	М	Ν	0	Р	Q	R
E	F	[H	Ĺ	IJ	٢	L	ō	П	o	P	9	
						۲,							



NDEX

Accessories11
Caution symbol4
Cleaning the instrument6
Configuration
normal function settings
operation21
power on configuration operation23
table25
Default settings133
Display diagram16
Display format136
Disposal instructions6
EN61010
measurement category5
pollution degree6
Environment
safety instruction6
Error messages
Ethernet
interface46
sockets49
web server46
Front panel diagram13
Ground
symbol4
LED conversion136
List of features10
Messages135
Model differences9

Optional accessories	11
Package contents	11
Power on/off	
safety instruction	5
Rear panel diagram	
Remote control	
Command list	
Command syntax	
Error list	. 124
Ethernet configuration	
Ethernet function check	
GPIB configuration	
GPIB function check	
interface configuration	31
local bus configuration	42
multi-unit configuration	
mult-unit function check	
sockets configuration	49
sockets function check	
Status registers	113
UART configuration	
UART function check	41
USB configuration	31
USB function check	32
Service operation	
about disassembly	5
Socket server function check .	
UK power cord	
Warning symbol	
Web server function check	