

*DR-500 Series Handheld OTDR
PC Software User Manual*

Reflect.exe

Table of Contents I

1. Software
 - Software Installation
 - Functional Description
 - Trace Screen
2. Menu & Icon Tool bar
 - File Menu
 - Measurement Menu
 - Mode Menu
 - Compare and Trace Menu
 - Zoom Menu
 - Setup Menu
 - Utilities Menu
 - Windows Menu
 - Help Menu
 - Markers Icon
3. Trace
 - Trace
 - Parameter Panel
 - Measurement Parameter Properties Window
4. Taking a Measurement
5. Measurement Modes
 - 2PT Attenuation Mode
 - LSA Attenuation Mode
 - Splice Loss Mode
 - Reflective Coefficient Mode
 - Optical Return Loss
6. Refractive Index
7. Auto Trace Analysis
8. Events Table
 - Events Tab
 - Section Tab
 - Event Move

Table of Contents II

9. Compare and Trace Function
 - Shift Trace
10. Trace Information
 - General Tab
 - Supplier Parameter Tab
 - Measurement Parameters Tab
 - Analysis Parameters Tab
11. Preference Tab
 - General Tab
 - Trace Tab
 - Start & Exit Tab
 - Windows Integration Tab
 - General Options
12. Colors Setup
 - Elements
13. Connecting to Reflect.exe via Windows Mobile Device Center
14. Trouble Shooting
15. Warranty

DR-500 Series PC Software "Reflect"

Reflect.exe is a Windows based application and is compatible with a Windows™ operating system. The software is capable of displaying, storing, reading, printing and analyzing several traces at the same time. **Reflect.exe** is capable of controlling the operation of the DR-500 series OTDR via a USB cable and windows mobile device interface **ActiveSyn** if desired by the OTDR operator.

Software Installation

1. Insert CD in PC
2. In CD drive open SetupAFS_eng
3. Allow PC to run installation

Functional Description

Trace Screen

Table 1.0

The screenshot displays the Reflect software interface. The main window shows an OTDR trace with a blue line representing the signal. The x-axis represents distance in kilometers (km) and the y-axis represents loss in decibels (dB). The trace shows a significant drop in signal at approximately 24 km, indicating a fault or splice. The software interface includes a menu bar (File, Measurement, Mode, Compare, Zoom, Setup, Utilities, Window, Help), a toolbar with icons for Start, Save, Zoom, Contig, Mod, Compare, and Help, and a status bar at the bottom. The status bar displays various parameters such as Wave Length (1310 nm), Distance range (80 km), Pulse width (300 ns), Refr. index (1.475), Resolution (2.5 m), and Average Time (00:38). The legend on the right side of the screen identifies various elements of the interface:


- ✘ Trace Title
- ✘ Menu Drop Downs
- ✘ Active Trace
- ✘ Information Panel
- ✘ Menu Icons
- ✘ Active Trace Panel
- ✘ Displayed Section
- ✘ Trace Parameters

A Trace screen on the Reflect software is illustrated above

Menu Tool Bar


File Menu

Table 2.0

	<p>Shortcut</p> <p>Save As</p> 	<p>File Drop Down Menu</p> <ul style="list-style-type: none"> ✘ Open - Open a saved trace ✘ Close - Close the current trace window ✘ New - Open a New screen ✘ Recent Files - List recently open files <ul style="list-style-type: none"> ✘ Save - Save the current trace ✘ Save As - Save the current trace under another name <ul style="list-style-type: none"> ✘ Save Report As... - Save trace Report as a .pdf file ✘ Print Setup - Print options ✘ Print Preview - Preview print ✘ Print - Print the current trace <ul style="list-style-type: none"> ✘ Exit
---	--	--


Measurement Menu

Table 2.1

	<p>Shortcut</p> <p>Start</p>  <p>Config</p> 	<p>Measurement Drop Down Menu</p> <ul style="list-style-type: none"> ✘ Start (Average) - Run a normal measurement with Averaging ✘ Start (Live) - Run a measurement in the real time mode ✘ Stop - Stops the measurement process ✘ Config - Parameters setup and USB/DR500 Series connection configuration
---	---	---


Mode Menu

Table 2.2

	Shortcut	Mode Drop Down Menu
	<p>Shortcut</p>  <p>2PT</p>  <p>LSA</p>  <p>Splice</p>  <p>Reflect Co</p>  <p>ORL</p> 	<p>Mode Drop Down Menu</p> <ul style="list-style-type: none"> ✘ 2PT attenuation – Attenuation between two points ✘ LSA attenuation – Attenuation by straight line approximation ✘ Splice Loss – Attenuation of an OF event using the 5 marker method ✘ Reflection Coefficient – Reflection measurement mode ✘ ORL – Optical return loss measurement
	<p>Ref Index</p>  <p>Trace Info</p> 	<ul style="list-style-type: none"> ✘ Refractive Index – Enables adjustment of the RI ✘ Backscatter Coefficient – Enable adjustment of the BC ✘ Trace Info – Trace details
	<p>Insert Marks</p>  <p>Delete Marks</p>  <p>Events Table</p>  <p>Analysis</p> 	<ul style="list-style-type: none"> ✘ Insert Mark – Inserts section or events between the two marker into the Events Table ✘ Delete Marks – Deletes section or events between the two markers from the Events Table ✘ Events Table – Opens the Events Table ✘ Analysis - Performs Auto Trace Analysis ✘ Thresholds – Enable adjustment of Auto Trace Threshold values
	<p>Filter</p> 	<ul style="list-style-type: none"> ✘ Filter – Enables adjustment of trace filtration level


Compare and Trace Menu

Table 2.3

	<p>Shortcut</p> 	<p>Compare Drop Down Menu</p>
	<p>Copy Trace</p> 	<ul style="list-style-type: none"> ✘ Copy Trace – Copies trace to clip board ✘ Paste Trace – Insert trace from clip board to current trace ✘ Delete - Deletes inserted trace ✘ Shift Trace - Enable shifting of the trace vertically
	<p>Paste Trace</p> 	
	<p>Delete Trace</p> 	<ul style="list-style-type: none"> ✘ Quick Paste – Enable a shortcut to paste previously opened traces
	<p>Create Template</p> 	<ul style="list-style-type: none"> ✘ Create Template – Stores current trace as template ✘ Apply Template – Applies template to trace ✘ Delete Template – Delete template
<p>Apply Template</p> 		
		<ul style="list-style-type: none"> ✘ Copy Image – Copies image to clip board

Zoom Menu

Table 2.4

	Shortcut 	Zoom Drop Down Menu
	Horizontal Zoom In  Zoom Out 	<ul style="list-style-type: none"> ✘ Select Horizontal Zoom Factor – Select a zoom factor (x1.1, x1.3, x 2, x5, x10) ✘ Horizontal Zoom In – Zoom in Horizontally ✘ Horizontal Zoom Out – Zoom out Horizontally ✘ Restore Horizontal Scale – Restore H scale
	Vertical Zoom In  Zoom Out 	<ul style="list-style-type: none"> ✘ Select Vertical Zoom Factor – Select a zoom factor (x1.1, x1.3, x 2, x5, x10) ✘ Vertical Zoom In – Zoom in Vertically ✘ Vertical Zoom Out – Zoom out Vertically ✘ Restore Vertical Scale – Restore V scale
		<ul style="list-style-type: none"> ✘ Restore Scales - Restore both scales to default settings


Setup Menu

Table 2.5

	Setup Drop Down Menu
	<ul style="list-style-type: none"> ✘ Preferences – Software preferences setup
	<ul style="list-style-type: none"> ✘ Colors – Element color selection


Utilities Menu

Table 2.6

	Utilities Drop Down Menu
	<ul style="list-style-type: none"> ✘ Device (ActiveSync) File Manager – Enables DR-500 series file management

Windows Menu

Table 2.7

	<table border="1"> <thead> <tr> <th colspan="2">Windows Drop Down Menu</th> </tr> </thead> <tbody> <tr> <td>✘</td> <td>Cascade – Cascade active traces</td> </tr> <tr> <td>✘</td> <td>Tile – Tile active traces</td> </tr> <tr> <td>✘</td> <td>Arrange Icons – Manually arranges all minimized windows</td> </tr> <tr> <td>✘</td> <td>Window List – Lists all open traces</td> </tr> <tr> <td>✘</td> <td>Displays Active List</td> </tr> </tbody> </table>	Windows Drop Down Menu		✘	Cascade – Cascade active traces	✘	Tile – Tile active traces	✘	Arrange Icons – Manually arranges all minimized windows	✘	Window List – Lists all open traces	✘	Displays Active List
Windows Drop Down Menu													
✘	Cascade – Cascade active traces												
✘	Tile – Tile active traces												
✘	Arrange Icons – Manually arranges all minimized windows												
✘	Window List – Lists all open traces												
✘	Displays Active List												

Help Menu

Table 2.8

	<table border="1"> <thead> <tr> <th colspan="2">Help Drop Down Menu</th> </tr> </thead> <tbody> <tr> <td>✘</td> <td>Help – Reference Manual</td> </tr> <tr> <td>✘</td> <td>About – Software Information</td> </tr> </tbody> </table>	Help Drop Down Menu		✘	Help – Reference Manual	✘	About – Software Information
Help Drop Down Menu							
✘	Help – Reference Manual						
✘	About – Software Information						


Markers Icon

Table 2.9

Markers Icon (Shortcut)		
<p>Markers Icon</p> 		<p>✘ Moves active Marker Left</p>
		<p>✘ Selects all Markers</p>
		<p>✘ Moves active Marker Right</p>
		<p>✘ Selects Left Marker as active Marker</p>
		<p>✘ Selects Right Marker as active Marker</p>

Trace

Table 3.0



A Trace is a visual representation of a fiber optic link. The beginning of the fiber optic link is located on the left side of the trace. The slope or attenuation of the fiber link can be seen as the trace moves to the right. There are two “active” markers, the information containing the location of the markers is located on the left side of the screen as shown above in Table 3.0

The screen also displays several numbers that correspond to measurement values (attenuation, attenuation loss at an event, distance to an event and Optical Return Loss (ORL), These values are the measurements from the Automatic Trace Analysis that the OTDR performs. Automatic Trace Analysis will be covered in a later section.

The testing parameters for the active trace are located below the trace window (in the gray area). All parameters are preset (by operator) prior to running a test. See the measurement parameters section for more information.

Parameters Panel

Table 3.1

X: [0.00000, 40.00001] km; 4.00000 km/div		Template:						
Y: [0.000, -45.000] dB; 4.500 dB/div		Buffer:						
SM-1310	n=1.47500	Lmax=40 km	TP=10 ns	Nav=32	L1=0.00000 km	L2=40.00002 km	dL=3 m	OMSN: 6000
<p>✘ X - Shows the location of section begin and section end and the scale of the distance on the horizontal axis</p>								
<p>✘ Y - Shows the top end and low end value of the dB loss for entire trace window and the scale of the loss per division on the vertical axis</p>								
<p>✘ 1st box - Identifies the fiber type (multimode or single mode) and the wavelength</p>								
<p>✘ N - The Refractive Index of the fiber</p>								
<p>✘ Lmax - Distance Range</p>								
<p>✘ TP - Duration of the Pulse Width</p>								
<p>✘ Nav - Number of Averages</p>								
<p>✘ L1 - Distance from the beginning of the fiber to the beginning of the measured section</p>								
<p>✘ L2 - Distance from the beginning of the fiber to the end of the measured section</p>								

The parameters properties window is accessed by selecting the **Config icon** or **Config** option under the measurement drop down menu. A dialog box will appear as shown in table 3.2 allowing the technician to modify or change the specific testing parameters in the appropriate box.

For more accurate measurements, it may be necessary for the Technician to adjust certain testing parameters for the specific fiber under test.

The operating parameters should be set according to the fibers being measured. For short fiber runs, shorter pulse widths and fewer averages are optimum. With longer fiber runs, longer pulse widths and more averages are best.

The values chosen by the user are dependent upon the testing requirements and there are tradeoffs that are sometimes necessary.

Measurement Parameter Properties Window

Table 3.2

	<ul style="list-style-type: none"> ✘ Manual – Enables manual Parameter setup
	<ul style="list-style-type: none"> ✘ Auto – The unit perform an Auto test to determine the appropriate parameters for cable under test
	<ul style="list-style-type: none"> ✘ Wavelength – Select at which wavelengths to test *1
	<ul style="list-style-type: none"> ✘ Apply to All - Apply active table parameter to all wavelengths
	<ul style="list-style-type: none"> ✘ Backscattering Coefficient – (BC) Values of the optical pulses in dB that are scattered back to the OTDR from the optical fiber being tested *2
	<ul style="list-style-type: none"> ✘ Refractive index (n) - The optical fiber's refractive index can be adjusted in increments of 0.00001 *3
	<ul style="list-style-type: none"> ✘ Distance range (Lmax) – Distance setting for test fiber *4
	<ul style="list-style-type: none"> ✘ Section Begin (L1) - Defines the location of the left marker *5
	<ul style="list-style-type: none"> ✘ Section End (L2) - Defines the location of the right marker *6
	<ul style="list-style-type: none"> ✘ Resolution (dL) - Selects the measurement sampling distance
	<ul style="list-style-type: none"> ✘ Pulsewidth (TP) - Selects width of output pulse *7
	<ul style="list-style-type: none"> ✘ Measuring with Averaging – Average using time parameter *8
	<ul style="list-style-type: none"> ✘ Measuring with Averaging – Average using 4096*Nav parameter *8
	<ul style="list-style-type: none"> ✘ Live Mode - Defines the screen refresh rate
<ul style="list-style-type: none"> ✘ Analysis Thresholds – *9 1 Event loss – LT 2 Reflectance - RT 3 End-of-Fiber – ET 4 Fiber loss – CT 	
<ul style="list-style-type: none"> ✘ High resolution – Increases measurement bandwidth ✘ Low Laser Power - Decreases pulse power 	

Individual parameters for each wavelength maybe selected within the appropriate wavelength tab.

- *1 If two (or more) Single Mode or both Multimode wavelengths are selected then Lmax, L1, L2 and dL become common parameters for the selected wavelengths.
- *2 **Default BC values**
 - 82 dB for SM at 1550 nm
 - 77 dB for SM at 1310 nm
 - 76 dB for MM at 1300 nm
 - 68 dB for MM at 850 nm
- *3 For an exact index of refraction value of the cable, contact the fiber optic cable manufacturer.
 - Default RI values**
 - 1.4682 for SM at 1550nm
 - 1.4675 for SM at 1310nm
 - 1.4860 for MM at 1300nm
 - 1.4900 for MM at 850nm
- *4 Available values in km:
2, 5, 10, 20, 40, 80, 120, 160 and 240
- *5 L1 marker can be placed anywhere from 0 to L2 in the trace window.
- *6 L2 marker can be placed anywhere from the L1 to the Lmax in the trace window.
- *7 Shorter pulses are generally used for shorter distances and higher resolution. Longer pulse widths are required for longer fiber runs. The allowable pulse width is determined by the distance range- **Lmax**.
- *8 **Number of Averages** (4096*Nav) This defines the number of allowable trace averages when the OTDR in the "RUN" mode. **Nav** may be set to any of the following values → 1, 2, 4, 8, 16, 32, 64, 128, 256
Averaging Time (min: sec) The user also has the option to set the time range that they would like for a particular measurement.

*9 Threshold values for Automatic Trace Analysis

The parameter menu contains the threshold values that the OTDR compares with the actual trace values when operating in the Automatic Trace Analysis mode. These values are inputted by the OTDR operator and are used to compare expected measurement values to actual measurement values. The measurement values are displayed on the events table and if the expected parameters are not met – the results will be indicated by an asterisks "*" in the events table.

Event Loss (LT) - Threshold of the event attenuation value in dB. Events with attenuation value that exceeds the threshold value will be shown in the **Events Table**.

Reflectance (RT) - Threshold of the event reflectance value in dB. The reflected event having a reflectance higher than the threshold value are shown in the **Events Table**.

End of Fiber (ET) - Threshold of the event attenuation value in dB for defining the fiber end. The first event with an attenuation exceeding the threshold value is defined during the automatic trace analysis as an optical fiber end. All subsequent events will be ignored.

Fiber Loss (CT) – Attenuation coefficient threshold value of the section in dB/km. Exceeding the attenuation coefficient threshold value will mark the section with an * in the **Events Table**.

If the threshold are exceeded, the coefficient value will be marked by an asterisk "*" in the marks table. This cannot be construed as certification – as true attenuation loss, according to the standards (EIA/TIA) are only determined by a power meter and a source.

Default values of Fiber Loss

0.25 dB/km for Single Mode at 1550nm


0.4 dB/km for Single Mode at 1310nm

1.0 dB/km for Multimode at 1300nm

2.0 dB/km for Multimode at 850nm

Taking a Measurement

Table 4.0

	Measurement Options
	<ul style="list-style-type: none"> ✘ Start (Averages) – Start a measurement with averaging *10
	<ul style="list-style-type: none"> ✘ Start (Live) – Real Time Mode *11
	<ul style="list-style-type: none"> ✘ Stop – Stops the measurement process *12

- *10 **Start (Averages)** - The measurement mode with averaging is designed for measuring and analyzing all of the parameters of the fiber optic cable. When using this feature, the measurement average counter is displayed on the bottom of the main screen. The OTDR displays a progress bar (**Nav=Number of Averages**) at the bottom of the screen. This indicates time elapsed verses total measurement time. The software will beep when the total measurement is completed.
- *11 **Start (Live)** – In the Real Time mode the OTDR will continue to run measurements according to the preset parameters.
- *12 **Stop** – Both an Average reading or a Live reading maybe stopped by this function at any time in the measurement process.

Measurement Modes

Table 5.0

Mode	Compare	Zoom	Setup	Measurement Modes
			P	✘ 2PT Attenuation *13
			D	✘ LSA Attenuation *14
			S	✘ Splice Loss *15
			R	✘ Reflectance *16
			O	✘ ORL – Optical Return Loss *17

***13 Measuring Attenuation between two marker points - (2 PT)**
 In this markers mode values are shown at the left side of the screen in the information panel. The measurement values are based upon where the left hand marker (**L**) and right hand marker (**R**) are positioned on the trace screen. The (**L,km**) field indicates the distance of the L marker while (**R,km**) field indicated the distance of the right hand marker on the trace. (**R-L,km**) indicates the distance between the left and right markers. The **dB** field in the information panel displays the attenuation between the left and right hand markers, while the **dB/km** field displays the attenuation co-eff.

2PT Attenuation

Table 5.1


<table border="1"> <tr><td>L, km</td><td>3.63636</td></tr> <tr><td>R, km</td><td>4.97608</td></tr> <tr><td>R - L, km</td><td>1.33972</td></tr> <tr><td>dB</td><td>0.453</td></tr> <tr><td>dB/km</td><td>0.338</td></tr> </table> <ul style="list-style-type: none"> ✘ L,km - Left marker location ✘ R,km - Right marker location ✘ R-L, km - Distance between R & L ✘ dB - Loss between R & L ✘ dB/km - attenuation co-efficient 	L, km	3.63636	R, km	4.97608	R - L, km	1.33972	dB	0.453	dB/km	0.338	
L, km	3.63636										
R, km	4.97608										
R - L, km	1.33972										
dB	0.453										
dB/km	0.338										

***14 Measuring the Attenuation by Approximation - (LSA)**

The attenuation measurement by approximation mode is used to measure “non-event” sections of the fiber optic link. This mode increases the accuracy of the attenuation measurement between the two markers by using a straight line to approximate the measurement. The approximation straight-line measurement values are shown on the left side of the screen in the information panel. The measurement values are based upon where the left hand marker (**L**) and right hand marker (**R**) are positioned on the trace screen. The (**L,km**) field indicates the distance of the L marker while (**R,km**) field indicated the distance of the right hand marker on the trace. (**R-L,km**) indicates the distance between the left and right markers. The **dB** field in the information panel displays the attenuation between the left and right hand markers, while the **dB/km** field displays the attenuation coefficient.

LSA Attenuation

Table 5.2




***15 Attenuation Measurement of an "Event" – (Splice Loss)**

Using the "Five Markers" method the OTDR measures the attenuation of a specific event. The "five marker" method works as follows:

The left marker (**L**) and right marker (**R**) are placed on either side of the event, as close as possible to the edges of the event, without touching the event itself. The two outermost markers (**Lx** and **Rx**) are used to calculate the straight line approximation of the fibers on both sides of the event and the fifth marker (**C**) is used to locate the beginning of the event. The measurement results are displayed in the information panel. The (**L,km**) field indicates the distance of the L marker while (**R,km**) field indicated the distance of the right hand marker on the trace. (**R-L,km**) indicates the distance between the left and right markers. The **Spl, dB** field in the information panel displays the attenuation of the event while the **Spl, km** field displays the distance to the event being tested (middle marker **C**).

Splice Loss

Table 5.3




***16 Reflective Coefficient Measurement - (Reflection)**

This marker method is used to measure the reflection coefficient of a specific connector event. Place the right marker (**R**) on the peak of the reflected event. Place the left marker (**L**) on the base line of the trace directly before the event. The measurement results are displayed in the information panel. The (**L,km**) field indicates the distance of the L marker while (**R,km**) field indicated the distance of the right hand marker on the trace. (**R-L,km**) indicates the distance between the left and right markers. The **Refl, dB** field displays the reflective coefficient between markers **L** and **R** while the **Refl, km** field displays the left (**L**) marker and location of the base of the connector.

Reflective Coefficient

Table 5.4




***17 Optical Return Loss - (ORL)**

This marker method measures the Optical Return Loss of a partial fiber section or the whole fiber link.

Place the left (**L**) and right (**R**) markers on the fiber link that is being tested. The measurement results are displayed in the information panel. The (**L,km**) field indicates the distance of the L marker while (**R,km**) field indicated the distance of the right hand marker on the trace. (**R-L,km**) indicates the distance between the left and right markers. The **dB** field in the information panel displays the attenuation between the left (**L**) and right (**R**) hand markers while the **ORL, dB** field displays the ratio (in dB) of the optical power entered into the fiber link verses the power which is returned to the beginning of the fiber for the marked section.

ORL

Table 5.5



Refractive Index


Table 6.0

	<table border="1"> <thead> <tr> <th colspan="2">Refractive Index</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">✘</td> <td>Distance to left marker</td> </tr> <tr> <td style="text-align: center;">✘</td> <td>Distance to right marker</td> </tr> <tr> <td style="text-align: center;">✘</td> <td>Refractive Index ^{*18}</td> </tr> </tbody> </table>	Refractive Index		✘	Distance to left marker	✘	Distance to right marker	✘	Refractive Index ^{*18}
Refractive Index									
✘	Distance to left marker								
✘	Distance to right marker								
✘	Refractive Index ^{*18}								

- *18 The **Refractive Index** box enables the user to adjust the refractive index setting according to the specific fiber under test. If the refractive index value is unknown but the fiber length is known, then the refractive index can be estimated by comparing the index of refraction with a known value from a previous trace.

Auto Trace Analysis

Table 7.0



When the OTDR takes a measurement it also performs an automatic trace analysis (if preset). Once the trace analysis is completed, the OTDR will determine the following, the **distance** of the fiber link and **distance to events**, the **attenuation** of the fiber link and of fiber sections, the **ORL**, the **splice losses** and the **connector losses**.

Once the OTDR completes the test, the OTDR displays the results on the trace screen, as shown in **table 7.0**. The results are also displayed in the **Events Table**.


The OTDR will establish "marks" with the "⊥" symbol. From these marks, the OTDR determines the appropriate values.

- x The event distance(s) is represented vertically on the trace.
- x Fiber attenuation values are displayed as dB/distance (unit measurements).
- x Optical return loss is displayed as a single value (no unit measurements).

In the auto mode, the OTDR compensates for the "Dead Zone" of the fiber link and calculates the attenuation from the end of the dead zone.

Events Table

Table 8.0



The **Events Table** lists the measurement values of the data points (marks, ⊥) on the particular fiber under test. The Events Table (**table 8.0**) has two fields, the "Events" field and the "Sections" field.

Events Tab

Table 8.1

	<p>Event Tab Columns</p>
<ul style="list-style-type: none"> ✘ Event Codes <ul style="list-style-type: none"> A = Added by the user M = Relocated by the user E = End of fiber F = Found by software O = Out of range without finding the E-O-F D = Modified end of fiber 	<ul style="list-style-type: none"> ✘ No. – Events in numeric order ✘ Event Type – R = reflective S = non-reflective ✘ Distance – From beginning of fiber to the event ✘ Reflectance - Reflective co-eff in an event (if any) in dB ✘ Splice loss– Attenuation of an event (if any) in dB ✘ OF loss - Attenuation coefficient of a non-event in dB/km ✘ Cumulative loss - Total attenuation from the beginning of the fiber under test to the next event in dB

The **“Delete”** Button will delete the highlighted marks from the trace window and the corresponding data from the Events table. (**Note*** it is impossible to remove the pre-established markers from the beginning and the end of the fiber trace.)

When in the events table, the **“Markers”** button, when pressed, will jump to the appropriate marks on the trace window related to the highlighted data.

The **“Move”** button allows the user to adjust the markers position incrementally back and forth around the highlighted event in the trace window, allowing the user to adjust any measurements made by the automatic trace analysis. Please see Table 8.3 below.

Section Tab

Table 8.2

Event Table - [AFSTestTrace.sor]					
Events		Sections			
No	Begin km	End km	Loss dB	OF loss dB/km	
1	3.59601	5.01664	0.457	0.322	LS
2	7.05882	11.58711	1.505	0.332	LS

Section Tab Columns	
✘	No. - Events in numeric order
✘	Begin - Distance to the left red box on the trace screen
✘	End - Distance to the right red box on the trace screen
✘	Loss - Complete attenuation between the marked sections
✘	OF Loss - Attenuation coefficient of the marked sections


Chosen sections will be highlighted on the events table. Pressing the “Markers” button will move the vertical markers in the trace window to the location indicated by the highlighted section in the events table.

To delete a section simply highlight that particular section and press the delete button.

The Reflect PC software allows the user to measure a specific section of the fiber under test by inserting marks ⊥ on the trace. To insert a set of markers, place the left vertical marker and the right vertical marker at each side of a section to be measured and press the “insert marks” button.

Event Move (Manually adjust an Event)

Table 8.3

	<ul style="list-style-type: none"> ✘ Additional left – adjust LSA left most marker ✘ Left – adjust left (main) marker ✘ Central – Adjust center marker ✘ Right - adjust right (main) marker ✘ Additional right – adjust LSA right most marker ✘ Change event type – enable the user to change event type between R(reflective) and S(non-reflective)
---	--

Compare and Trace Function

(Please refer to Table 2.3)

For a fast analysis of a multi-fiber optic cable with many events, the **Compare and Trace** function becomes a very useful tool. With the **Compare and Trace** option, the user can transfer marks and parameters on one fiber to another by simply pressing one key.

Selecting the **create template** allows the user to save data points of the marks on a trace to a buffer allowing the user to transfer those points on to a different trace for evaluation.

The **Compare** drop down menu will now activate the functions **Apply Template** and **Delete Template**.

The template is the analysis calculations related to a particular trace.

The data stored in the template buffer can be erased and written over by repeating the above procedure.

Each trace is displayed in its own separate window. However, if desired the user may insert several traces in one window for data comparison.

To insert a trace from one window into another window simply follow the below procedure

- ✘ Open the trace window to be copied
- ✘ Select Compare→Copy

By selecting **Compare→Copy**, the trace will be saved in the buffer displayed in the information panel. The **Compare** and **Paste** functions will now become active.

Note: They may have already been activated from a previously saved trace.

- ✘ Open host trace window
- ✘ Select **Compare→Paste**

The names of the inserted traces will appear in the information panel under **Traces** (The host trace name will appear at the top of the list.)

It is possible to insert up to seven traces at the same time.

Only one trace at a time is active in the host window. This is indicated by the symbol “^” beside the file name in the **traces** window of the information panel. Using the vertical markers it is possible to measure the length and attenuation of each active trace. To make a trace active simply double click on its name in the information panel. Pressing keys **CTRL+SPACE** when it is highlighted will also activate the trace. **CTRL+PAGE UP** and **CTRL+PAGE DOWN** will allow the user to scroll up and down through traces in the information panel.

To remove an inserted trace from the host window, select and highlight the trace then press the  icon or press the **CTRL+DEL** keys.

Shift Trace

Table 9.0


	<table border="1"> <tr> <th colspan="2" data-bbox="768 1085 1451 1157">Shift trace vertically</th> </tr> <tr> <td data-bbox="768 1163 922 1262">✘</td> <td data-bbox="927 1163 1451 1262">Shift up – move trace up vertically</td> </tr> <tr> <td data-bbox="768 1268 922 1367">✘</td> <td data-bbox="927 1268 1451 1367">Shift down – move trace down vertically</td> </tr> <tr> <td data-bbox="768 1373 922 1440">✘</td> <td data-bbox="927 1373 1451 1440">Restore Position – restore to original position</td> </tr> </table>	Shift trace vertically		✘	Shift up – move trace up vertically	✘	Shift down – move trace down vertically	✘	Restore Position – restore to original position
Shift trace vertically									
✘	Shift up – move trace up vertically								
✘	Shift down – move trace down vertically								
✘	Restore Position – restore to original position								

It is also possible to shift the inserted trace vertically in the host window. Highlight the desired trace to shift and select the **menu** item **Compare → Shift Trace**.

On the inserted trace it is possible to place vertical markers for specific measurements or enter explanatory information and apply it to the function "model."

Trace Information – General Tab


Table 10.0

	General Tab
	✘ Date/Time – displays time and date of recorded trace
	✘ Cable ID – enables the user to enter a cable ID
	✘ Fiber ID – enables the user to enter a fiber ID
	✘ Fiber Type – enables the user to select a fiber type
	✘ Originating Location – enables the user to enter a originating location
	✘ Terminating Location – enables the user to enter a terminating location
	✘ Condition – enables the user to select the fiber condition
	✘ Trace Type – enables the user to select the fiber trace type
	✘ Operator – enables the user to enter the operators information
	✘ Comment – enables the user to enter the additional comments

The Technician can input specific information about each fiber link that is being tested. This includes cable/fiber ID, fiber type, fiber location, termination location, fiber condition, the fiber optic test technician and any applicable comments.

Trace Information – Supplier Parameter Tab


Table 10.1

	Supplier Parameter Tab
	✘ Supplier Name – OTDR’s suppliers name
	✘ OTDR Mainframe ID – OTDR’s mainframe ID
	✘ OTDR Mainframe S/N – OTDR’s mainframe serial number
	✘ Optical Module ID – OTDR’s modules ID
	✘ Optical Module S/N – OTDR’s module serial number
	✘ Software Revision – Software revision number
	✘ Other – other module numbers

This information tab shows the OTDR’s mainframe characteristics.

Trace Information – Measurement Parameters


Table 10.2

	Measurement Parameters Tab
	<ul style="list-style-type: none"> ✘ Actual Wavelength – Precise value of wavelength used for this trace
	<ul style="list-style-type: none"> ✘ Refractive Index – Refractive index set for this trace
	<ul style="list-style-type: none"> ✘ Distance Range (Lmax) – Distance set for this trace
	<ul style="list-style-type: none"> ✘ Section begin (L1) – Defines the location of the left marker for this trace
	<ul style="list-style-type: none"> ✘ Section end (L2) – Defines the location of the right marker for this trace
	<ul style="list-style-type: none"> ✘ Resolution (dL) – Measurement sampling distance for this trace
	<ul style="list-style-type: none"> ✘ Pulse-width (Tp) – Pulse width for this trace
	<ul style="list-style-type: none"> ✘ # of Averages (4095*nav) – Number of average set for this trace
	<ul style="list-style-type: none"> ✘ High resolution – Indicates if high resolution was set for this trace
	<ul style="list-style-type: none"> ✘ Low laser power – Indicates if low laser power was used for this trace

This Information Window shows the initial measurement parameters tab that the user sets to take the OTDR measurements. These values are inputted during the initial measurement parameters setup.

Trace Information – Analysis Parameters


Table 10.3

	<h3>Analysis Parameter Tab</h3>
<ul style="list-style-type: none"> ✘ Backscattering Coefficient – BC value for this trace 	<ul style="list-style-type: none"> ✘ Event Loss (LT) - Threshold of the event attenuation value in dB for this trace
<ul style="list-style-type: none"> ✘ Reflectance (RT) - Threshold of the event reflectance value in dB for this trace 	<ul style="list-style-type: none"> ✘ End-Of Fiber (ET) - Threshold of the event attenuation value in dB for defining the fiber end for this trace
<ul style="list-style-type: none"> ✘ Fiber Loss (CT) - Attenuation coefficient threshold value of the section in dB/km for this trace 	

This information tab shows the threshold values selected by the Technician for the automatic trace analysis.


Preference – General Tab

Table 11.0

	<table border="1"> <thead> <tr> <th colspan="2">General Tab</th> </tr> </thead> <tbody> <tr> <td>✘ Distance unit</td> <td>- Change the measurement value. Km, m, Ft, Kf and Mi are the available options</td> </tr> <tr> <td>✘ Language</td> <td>- Change the language options. English, Spanish or Korean</td> </tr> <tr> <td>✘ Autonumbering of file names</td> <td>- Auto number the traces in the order the measurements are taken</td> </tr> <tr> <td>✘ Extended Save As</td> <td>- Provides the user the option of changing the file root</td> </tr> <tr> <td>✘ Color print</td> <td>- Printing with or without color</td> </tr> <tr> <td>✘ Use extended Print</td> <td>- Enables the user to use the extended Print option</td> </tr> <tr> <td>✘ Apply a Filter</td> <td>on all new traces</td> </tr> <tr> <td>✘ Apply the "Automatic" Analysis</td> <td>mode on all traces</td> </tr> <tr> <td>✘ Copy the trace information</td> <td>with template</td> </tr> <tr> <td>✘ Apply "Zoom" option</td> <td>on new traces</td> </tr> <tr> <td>✘ Maximize</td> <td>the trace window</td> </tr> <tr> <td>✘ Sound</td> <td>at end of measurement</td> </tr> <tr> <td>✘ Use Click</td> <td>for Marker Jump</td> </tr> <tr> <td>✘ Notify</td> <td>when opening multiple related traces</td> </tr> </tbody> </table>	General Tab		✘ Distance unit	- Change the measurement value. Km, m, Ft, Kf and Mi are the available options	✘ Language	- Change the language options. English, Spanish or Korean	✘ Autonumbering of file names	- Auto number the traces in the order the measurements are taken	✘ Extended Save As	- Provides the user the option of changing the file root	✘ Color print	- Printing with or without color	✘ Use extended Print	- Enables the user to use the extended Print option	✘ Apply a Filter	on all new traces	✘ Apply the "Automatic" Analysis	mode on all traces	✘ Copy the trace information	with template	✘ Apply "Zoom" option	on new traces	✘ Maximize	the trace window	✘ Sound	at end of measurement	✘ Use Click	for Marker Jump	✘ Notify	when opening multiple related traces
General Tab																															
✘ Distance unit	- Change the measurement value. Km, m, Ft, Kf and Mi are the available options																														
✘ Language	- Change the language options. English, Spanish or Korean																														
✘ Autonumbering of file names	- Auto number the traces in the order the measurements are taken																														
✘ Extended Save As	- Provides the user the option of changing the file root																														
✘ Color print	- Printing with or without color																														
✘ Use extended Print	- Enables the user to use the extended Print option																														
✘ Apply a Filter	on all new traces																														
✘ Apply the "Automatic" Analysis	mode on all traces																														
✘ Copy the trace information	with template																														
✘ Apply "Zoom" option	on new traces																														
✘ Maximize	the trace window																														
✘ Sound	at end of measurement																														
✘ Use Click	for Marker Jump																														
✘ Notify	when opening multiple related traces																														
<p>Note: The user can modify or change the appearance of the OTDR software depending upon operation, measurement, or operator preferences. Some of the items the user can modify are as follows: The trace screen, measurement parameters, (i.e. km to ft) or change the language.</p>																															

Preference – Trace Tab

Table 11.1

	Trace Tab
	<ul style="list-style-type: none"> ✘ Show grid - Turn on or Turn off the background grid
	<ul style="list-style-type: none"> ✘ Show event bar - Show the bottom marker bar, highlighted in Red
	<ul style="list-style-type: none"> ✘ Show events info on trace - Turn-on or turn-off the automatic analysis measurement
	<ul style="list-style-type: none"> ✘ Bind to trace when scrolling horizontally - Change the starting point of horizontal scrolling
	<ul style="list-style-type: none"> ✘ Show grid marks – show position marks on the grid
	<ul style="list-style-type: none"> ✘ Zoom relevant to <ul style="list-style-type: none"> ✘ Left corner ✘ Center ✘ Right corner ✘ Scrollbar
	<ul style="list-style-type: none"> ✘ Marker speed <ul style="list-style-type: none"> ✘ Usual ✘ Accelerated ✘ Acceleration delay <p>The marker speed can be changed to varying degrees</p>

The Trace tab in the preferences window allows the user to setup different parameters related to the trace grid, event bar, events information on trace, scrolling, zooming and markers speed.

Preference – Start & Exit Tab

Table 11.2

	<p style="text-align: center;">Start & Exit Tab</p> <ul style="list-style-type: none"> x Initialize the Device - Automatically check the device connection when software is launched x Confirm Exit - Confirm exit when closing program x Ask about saving file - Ask if the operator would like to save the trace upon closing x Save - Window size and position x Save working folder - Save in last working directory
--	---

The Start & Exit tab in the preferences window allows the user to setup different parameters related opening the program and exiting the program

Preference – Windows Integration Tab

Table 11.3


	<p style="text-align: center;">Windows Integration Tab</p> <ul style="list-style-type: none"> ✘ Register extensions now– enable the user to click on a *.sor file which will then open the OTDR software (if not already opened) and load the associated trace when the - Associate known file types is checked ✘ Create a shortcut to the PC or Laptops desktop ✘ Enables the user to drag a file onto the trace window where the software will then open
--	---

General Preferences Window Options

- ✘ The **"OK"** button accepts any changes.
- ✘ The **"Reset"** button resets default values.
- ✘ The **"Cancel"** button cancels all the changes.

Colors Setup – Elements

Table 12.0

	<p style="text-align: center;">Element Colors</p> <ul style="list-style-type: none"> ✘ Elements – Selectable Elements ✘ Left marker ✘ Right marker ✘ Subsidiary markers ✘ Central marker ✘ Grid ✘ Approximation line ✘ Selected event boarder ✘ Events info ✘ Sections info ✘ Trace Background ✘ Grid Marks <hr/> <ul style="list-style-type: none"> ✘ Change – Change highlighted element
---	--

This option enables the user to change the color scheme of the Reflect software elements by changing the color palette.

- ✘ Highlight the specific **“element”**
- ✘ Select **Change**. A standard windows™ “Color” window will appear
- ✘ Select the colors you wish and press **OK**

Do this as necessary. To store changes and return to software press **OK** or press **Cancel** to quit without changing any colors.

Connecting DR500 Series unit to Reflect.exe via *Windows Mobile Device Center*

Table 13.0

Windows Mobile Device Center	
 <p>The screenshot shows the Windows Mobile Device Center application window. The title bar reads 'Windows Mobile Device Center'. The main area has a green background with the Windows Mobile logo. A central box titled 'Set up your device' contains the text: 'Get Outlook contacts, calendar, e-mail and other information on your device.' Below this is a button labeled 'Connect without setting up your device'. At the bottom left, a green checkmark and the word 'Connected' are visible.</p>	<ul style="list-style-type: none"> ✘ Download Windows Mobile Device Center to PC ✘ Open Mobile Device Center Application ✘ Turn off OTDR – make sure all data is saved before power down. ✘ Connect the supplied USB cable between the OTDR and the PC Note: The Mini USB connector attaches to OTDR and the USB connector attaches to the PC ✘ Turn on OTDR – The PC will load the drivers for the OTDR and connect through the Mobile Device Center application

Connection to Reflect Software

Table 13.1

Connection and Parameters Panel									
 <p>The screenshot shows a 'Connect' dialog box with the text: 'DR-500 #02611 (SM/1310/1550) has been initialized successfully!'. A large green checkmark is centered in the dialog, and an 'OK' button is at the bottom.</p>	<ul style="list-style-type: none"> ✘ Once a connection has been established between the PC and OTDR the Reflect.exe application has the ability to setup parameters and activity OTDR measurements 								
<table border="1"> <tr> <td>Wave Length,nm: 1310</td> <td>Distance range,km: 80</td> <td>Pulse width,ns: 300</td> <td>Refr. index: 1.475</td> </tr> <tr> <td></td> <td>Resolution,m: 2.5</td> <td>Manual measurement</td> <td>Average Time: 00:38</td> </tr> </table>		Wave Length,nm: 1310	Distance range,km: 80	Pulse width,ns: 300	Refr. index: 1.475		Resolution,m: 2.5	Manual measurement	Average Time: 00:38
Wave Length,nm: 1310	Distance range,km: 80	Pulse width,ns: 300	Refr. index: 1.475						
	Resolution,m: 2.5	Manual measurement	Average Time: 00:38						

Troubleshooting

Software does not load correctly

System needs to be Win 98 or more recent, at least 16MB of RAM and a processor that is 75Mhz or better

PC or Laptop does not recognize OTDR

The PC and the OTDR communicate via **Window Mobile Device Center** please verify that this program is correctly installed on Laptop or PC

For further assistance contact AFS

Warranty Certificate

Advanced Fiber Solutions, Inc warrants that its products sold by it to purchaser will, upon delivery to purchaser, be free of defects in workmanship or materials and will conform and function in accordance with the specifications for the product as published by Advanced Fiber Solutions, Inc and in effect at the time of delivery. Should any failure to conform to this warranty become apparent during the one-year period after date of delivery of the product to purchaser, AFS will, upon prompt written notice from the purchaser, correct such non-conformity by repair or replacement at AFS's Boston, Massachusetts facilities, shipment to such facility to be at purchaser's cost and repaired or replaced components to be shipped to purchaser FOB AFS's facility in Easton, Massachusetts. Correction in the manner provided herein shall constitute a fulfillment of all liability of AFS with respect to the quality of any products sold by it to purchaser.

THE FORGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES OF QUALITY, WHETHER WRITTEN, ORAL OR IMPLIED (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR PURPOSE). THE REMEDIES PROVIDED HERIN SHALL BE THE PURCHASER'S SOLE REMEDY FOR ANY FAILURE OF AN AFS PRODUCT TO COMPLY WITH THE WARRANTY PROVISIONS HERIN, WHETHER CLAIMS BY THE PURCHASER ARE BASED IN CONTRACT OR IN TORT, INCLUDING NEGLIGENCE.

In no event will the AFS product warranty extend to non-conformity in the performance resulting from: improper or inadequate maintenance performed by any person other than AFS; failure of performance or function caused by or attributable to any associated or complimentary equipment not supplied by AFS; modification of any AFS product or connection therewith or supplementary equipment not supplied by AFS or not produced by it; operation of the product or its use other than as provided by AFS; accident, disaster, transportation or neglect or any other circumstance, agency or event beyond AFS's control.

IN NO EVENT SHALL AFS BE LIABLE FOR SPECIAL OR CONSEQUENTIAL DAMAGES SUCH AS, BUT NOT LIMITED TO, DAMAGE OR LOSS OF OTHER PROPERTY OR EQUIPMENT, LOSS OF PROFITS OR REVENUES, LOSS OF USE OF EQUIPMENT, COST OF CAPITAL, COST OF PURCHASED REPLACEMENT, OR CLAIMS FOR SERVICE INTERRUPTION.

The remedies of the purchaser set forth herein are exclusive and the liability of AFS with respect to any contract or anything done in connection therewith, such as the performance or breach thereof, or from sale, delivery, repair, or use of any AFS product, whether in contract, in tort, on strict liability or otherwise, shall not exceed the price of the equipment or part thereof on which such liability is based.

Advanced Fiber Solutions, Inc.

19 Norfolk Ave,
Easton, Ma, 02375, USA

508-238-7100
800-556-9313
Fax:617-507-0784

Issue 1.0 Copy right Advanced Fiber Solutions, Inc