


Accu-Time[®] Series 7000

Access Control Unit User's Manual

MANU7000-01h



Copyright © 2003, 2004 by Accu-Time Systems, Inc. All rights reserved. Printed in U.S.A.

Information in this document is subject to change without notice and should not be construed as a commitment by Accu-Time Systems, Inc. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without express written consent of Accu-Time Systems, Inc.

Accu-Time, Accu-Rate, and the Accu-Time logo are registered trademarks of Accu-Time Systems, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Accu-Time Systems, Inc.
420 Somers Road
Ellington, Connecticut 06029 USA
(860) 870-5000
(800) 355-4648
www.accu-time.com

Printed August 24, 2004 MANU7000-01h

FCC Statement

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the time clock and the receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.

FCC *Warning*: To assure continued FCC emission limit compliance, the user must use only the recommended shielded interfacing cable when connecting to a host computer. Also, any unauthorized changes or modifications to this equipment would void the user authority to operate this device.

Table of Contents

Preface

Purpose	x
Intended Audience	x
Structure	x
Document Conventions	xi
Character Representations	xii
Using The Manual Electronically	xii
Feedback	xiii

1 Introduction

Technical Summary	1-2
Switches/Jumpers	1-3
Firmware	1-4
Power Fail	1-4
Connectors, LEDES, Jumpers, and Switches	1-5
Operating Modes	1-7
Test Mode	1-7
Standalone Mode	1-8
Online Mode	1-8
On Line Mode, Dual Door	1-8
Reset	1-8
Validation Table	1-10
Validation Table Online Download	1-10
Standalone Validation Table	1-10
Single Card Add/Disable/Enable	1-10
Schedules	1-11

Door lock/release operation (DO_1)	1-11
“Good Swipe” and “Badge Valid”	1-11
”Good Swipe” and “Badge Not Valid”	1-11
”Bad Swipe”	1-11
Badge Swipe and Alarm Logging	1-12
Anti-Passback	1-12
Standalone Mode	1-13
Using the Master badge	1-13
Host Communications	1-14
AccuComm/ Test Program	1-14
Dynamic Link Library Files	1-14
Employee Identification	1-14

2 Installation

Installation Guidelines	2-2
Environmental Considerations	2-2
Mounting	2-2
Power	2-3
Cabling	2-3
Cabling Accessories	2-4
RS232	2-5
RS485	2-5
Connecting the Reader and DI/DO Wiring	2-6
Wiring the Readers	2-7
Wiring the Digital Inputs (DI_1 and DI_2)	2-8
Wiring the Digital Outputs (DO_1 and DO_2)	2-9
Wiring the Door Lock	2-9
Wiring an Alarm	2-10
Operation	2-10
Wiring the Tamper Switch	2-10
Setting the DIP Switches	2-11
DIP Switch 1	2-11
1. Test Switch Disable	2-11
2. Tamper Switch Disable	2-11
3. Default Reset	2-11
4. RS232/RS485 Mode	2-11
5. Reserved	2-11
6. Single/Dual Door Mode	2-11
7. ATS Serial Protocol	2-11
8. Online/Standalone	2-11
DIP Switch 2	2-12
1-2. Reader 0 Type	2-12
3. Reader 1 Type	2-12

4-8. Unit Address	2-12
Setting the Jumpers	2-13

3 Commands

Command Syntax	3-2
Command Index	3-3
General Commands	3-5
AQ10	3-5
C00	3-5
D10	3-6
D20	3-6
LAP01	3-7
LDA01	3-7
LPB01	3-7
LPB03	3-8
LPB04	3-8
LPB05	3-9
LSA01	3-9
O00	3-10
O10	3-10
R00	3-11
R01	3-11
S00	3-11
S01	3-12
S02	3-12
S03	3-13
S04	3-13
T00	3-14
T10	3-14
T20	3-14
Employee File Handling Commands	3-16
LEE01	3-16
LEC01	3-16
LED01	3-17
Badge Masking and Validation Commands	3-18
LEB01	3-18
Schedule File Handling	3-20
LSE01	3-20
LSB01	3-20
LSC01	3-21
LSD01	3-22
LHO101	3-22

Bell Schedule File Handling	3-24
LBE01	3-24
LBC01	3-24
Interactive Commands	3-26
BELL	3-26
SO	3-26
SI	3-26
Controlling Relays DO_1, DO_2	3-28
DC101	3-28
DC100	3-28
DC111	3-28
DC201	3-29
DC200	3-29
DC211	3-29
Messages Received From ACU	3-31
ALDI1	3-31
ALDI2	3-31
ALSTATE	3-32
ALTAMP	3-33
BA01	3-33
BA02	3-34
BG00	3-34
BG01	3-35
BS00	3-36
BS01	3-36
BS02	3-37
BS03	3-38
BS04	3-38
BT01	3-39
DI00	3-39
P....	3-40
General Command Syntax Notes	3-42

A Minute Offsets

B Pinouts, Interfaces, and Switches

Pinouts	B-1
12V Power Input	B-1
RS232 Network	B-1
RS485 Network	B-2
Battery Status Inputs	B-2
DIP Switches	B-3
DIP Switch 1	B-3

DIP Switch 2	B-3
Standard Reader Connections	B-4
Reader 7000/101 and 102 Wiring (Mag Stripe and HiTag Proximity)	B-4
Keypad 7000/103	B-5
HID “Clock and Data” Reader Wiring	B-6
Barcode Readers (ATS Weather Resistant 9001/XX)	B-7

C Terminal Addresses

D Sample Download File

Index

Figures

Figure 1-1: Series 7000 Network Connectors and Status LEDs	1-5
Figure 1-2: Series 7000 Switches and Connectors	1-6
Figure 1-3: Jumpers to Select Types of Readers	1-7
Figure 2-1: Typical Series 7000 Installation	2-1
Figure 2-2: Typical 12V Power Pack	2-3
Figure 2-3: Wiring a Terminal Block	2-6
Figure 2-4: Digital Output (Relay) Connections	2-9
Figure 2-5: Alternative Series 7000 Inputs and Outputs Wiring Example	2-14
Figure 2-6: Dual Door Mode Wiring Example	2-15
Figure 2-7: Series 7000 RS232 Serial Installation	2-16
Figure 2-8: Series 7000 RS485 Serial Installation	2-17
Figure 2-9: Series 7000 Mounting Template (Next Page)	2-17
Figure D-1: Sample Download File	D-1

Tables

Table 1: Non-Printing Character Representations	xii
Table 1-1: Series 7000 Diagnostic LEDs	1-3
Table 2-1: Wire Length Limitations	2-4
Table 2-2: ACU Reader/Keypad 0 and 1 Connections	2-7
Table 2-3: ACU DI Connections	2-8
Table 2-4: ACU DO Connections	2-9
Table 2-5: Decimal/Binary Unit Number Equivalents	2-13
Table 3-1: Character Equivalents to Enter Hexadecimal Values	3-2
Table 3-2: Command Index	3-3
Table A-1: Schedule Minutes Offset	A-2

Table B-1: RS232 Pinout	B-1
Table B-2: RS485 Pinout	B-2
Table B-3: Battery Status Pinout	B-2
Table B-4: DIP Switch 1 Settings	B-3
Table B-5: DIP Switch 2 Settings	B-3
Table B-6: Reader 7000/101 and 7000/102 Wiring	B-4
Table B-7: Keypad 7000/103 Wiring (Storm)	B-5
Table B-8: HID ProxPoint Plus “Clock and Data” Reader Wiring	B-6
Table B-9: Barcode Readers 9001/XX Wiring	B-7
Table C-1: Network Controller ID Addressing Table	C-1

Preface

Purpose

This manual describes the Accu-Time Series 7000 Access Control Unit (ACU) from Accu-Time Systems, Inc. It tells you how to install, configure, and use the Series 7000 ACU.

Intended Audience

You should read this manual if you plan to use the Accu-Time Series 7000 Access Control Unit.

Structure

This manual has been divided into sections covering installation guidelines, terminal architecture, configuration commands, host communications, and troubleshooting. A comprehensive index at the end of the manual provides a means of locating references to specific topics or commands.

Document Conventions

The table below explains the conventions used to present information in this manual.

Convention	Description
Subscripts	Subscripts indicate the base of a number. For example, 28_{10} is 28 base 10, and $3F_{16}$ is 3F base 16.
BOLD CAPITALS	Bold capitals represent keys on a terminal keypad, such as the ENTER key.
<i>nnnn</i>	<i>nnnn</i> represents a numeric string of digits.
<i>xxxx</i>	<i>xxxx</i> represents a string of alphanumeric characters.
<u>Blue underline</u>	Cross references in the manual are shown as blue underlined text. If you read this manual online, these cross-references act as hyperlinks, which work in the same way as links on a web page. If you click the cursor on a cross-reference, the display will shift to the corresponding location in the document. When viewed online, the document contents are listed in a frame at the left of the screen that contains hyperlinks to chapters, headings, figures, and tables. Each entry in the index is also a hyperlink that will take you to the page on which the reference is located.
Fixed width font	Filenames, directory entries, and script or log file text.
<i>italics</i>	A variable or argument for which you supply a value.

Character Representations

The syntax of commands includes some non-printing control characters (character codes 000 to 031₁₀, 000 to 1F₁₆) plus the space character. These non-printing characters and the space character are represented in this manual in various ways as shown in the table below. In many text editors, you can generate a control character by holding down the CTRL key and pressing the appropriate printing key. For example, you can generate a record separator (30₁₀, 1E₁₆) by holding down the CTRL key and pressing the caret ^ key (SHIFT 6). This key sequence is represented as CTRL ^ . Other text editors let you enter control characters by pressing the ALT key, then entering the three-digit decimal value.

Table 1: Non-Printing Character Representations

Value	Use	Symbol ^a	CTRL
01 ₁₀ , 01 ₁₆	Argument separator	soh or ☺	CTRL A
28 ₁₀ , 1C ₁₆	Field separator	└ or ┘	CTRL \
29 ₁₀ , 1D ₁₆	Group separator	↔	CTRL]
30 ₁₀ , 1E ₁₆	Record separator	rs, ▲, or ▲	CTRL ^
31 ₁₀ , 1F ₁₆	Unit separator	us, ▼, or ▼	CTRL _
32 ₁₀ , 20 ₁₆	Space character	┘ or └	

a.From the “Terminal” character set.

Using The Manual Electronically

The cross-references contained throughout this manual are hyperlinks, which work in the same way as links on a web page. When the cursor is clicked on a cross-reference, the display will shift to the corresponding location in the document. When viewed online, the document contents are listed in a frame at the left of the screen that contains hyperlinks to the following:

- Chapters
- Headings
- Commands
- Index - Each entry in the index is a hyperlink that will take you to the page on which the reference is located.

Feedback

We want to hear from you. Does this manual meet your needs? Is information missing or unclear? Did you find errors? Is there anything you particularly like? Please send any comments you may have about this manual to:

Technical Publications Group
Accu-Time Systems, Inc.
420 Somers Road
Ellington, CT, 06029

Or e-mail your comments to: sales@accu-time.com.

Be sure to include the title of the manual and the revision level, shown on the front cover, in your reply. Please include your name, address, and e-mail in case we need to get in touch with you.

Revisions

Revision	Description of Changes
-----------------	-------------------------------

- | | |
|---|--|
| f | <ul style="list-style-type: none">• Added this revision list.• Updated Appendix B. |
| g | <ul style="list-style-type: none">• Added dual door mode.• Revised to reflect PROM 200L firmware.• Corrected documentation of DIP switch 1 settings for positions 6 and 7. |
| h | <ul style="list-style-type: none">• Corrected pin 10 description for barcode reader connection. |

The Series 7000 Access Control Unit (ACU) provides a means of controlling the secure access of individuals through internal and external doors of a building. Typical installations dedicate one ACU to each door, which provides the maximum flexibility and security.

The Series 7000 ACU can often be mounted in the ceiling space above a particular door with the door lock, readers, and alarms wired to it.

The Series 7000 provides support for anti-passback control that prevents employees passing badges to colleagues to gain multiple access through a door. In addition, the digital input connections can be used to automatically trigger alarms if doors are left open or are forced open without a valid badge.

A choice of operating modes allows the Series 7000 to be used in a number of different types of installations:

- Stand-alone mode allows badges to be added and deleted from each controller using a master badge.
- Off-line mode provides local intelligence at the controller to determine access rights for individual badges. A PC is used to collect transaction data and download updated validation tables at set intervals.
- On-line mode maintains all of the intelligence at the PC with validation of badges being made in real time.

Technical Summary

This section summarizes the features of the Series 7000 ACU.

DI/DO:	<p>Two digital inputs (DI_1 and DI_2). Dual DI 2 x 5-terminal screw down connectors (+5V Vcc, DI+, DI-, ground, shield.) Detects closure of contacts between sense inputs.</p> <p>Two digital form C relay outputs (DO_1 and DO_2), selectable normally open (NO) or normally closed (NC). Dual DO 2 x 5-terminal screw down connectors. (+12V, common, normally closed, normally open, ground.) Relay outputs can switch 4-30 volts DC @ 7 amps.</p>
Readers:	<p>Connections for two readers, both of which must be the same type. Unique ID for each reader. Support for barcode, magnetic Track 2, “clock and data” proximity, and keypad. Circuitry for reader LEDs (3 individual and tri-state).</p> <p>Barcode: Infrared or visible red reader. Weatherproof or non-weatherproof versions.</p> <p>Magnetic Stripe: ABA Track II. Weatherproof or non-weatherproof versions.</p> <p>Proximity: Weatherproof or non-weatherproof versions using clock-and-data protocol.</p> <p>Keypad: Vandal-proof external keypad for PIN entry. Available with integrated magnetic stripe reader for added security.</p>
COMM:	RS232 and RS485 interfaces. Single RJ45 socket for direct RS232 connection to PC. Two RJ45 sockets for wiring a multi-drop RS485 network.
Microprocessor	Enhanced 8051 derivative, 512K PROM (firmware storage), 128K RAM (factory expandable to 256K).
Memory:	<p>128K EEPROM expandable to 256K, infinite time retention in absence of power. Contents of EEPROM written to RAM for fast access, then written back just before a power-down or reset.</p> <p>Events log rate: $(\text{Event log capacity} * 100,000) / (365 * \text{product life time})$ The events EEPROM has a capacity of 8,000 event logs, so it can log up to 219,000 events a day for a 10 year product lifetime.</p>

Input Power:	12VDC @ 1A. Standard inline power socket (2.5 / 5.5mm, center +V).
Output Power:	12VDC power source for powering door release strikes. Power available is 1A, less the amount drawn by the Series 7000 itself.
Modes:	Networked online, interactive, or stand-alone.
Battery Backup:	External UPS with charger circuit. (Not currently available.)
Real-Time Clock:	Internal battery backed real-time clock for date/time stamping. Estimated battery life is 10 or more years. (Return unit to factory if replacement is ever required.)
Data Backup:	EEPROM.
Construction:	Steel enclosure with wall mounting holes and openings for cable entry.
Diagnostics:	Eight on-board LEDs show status of readers, DI/DO, network, and power. Table 1-1 gives the meaning of each LED.

Table 1-1: Series 7000 Diagnostic LEDs

LED ID	Meaning
LED1 blinking Red	Alive (ACU functioning properly)
LED2 Green	ACU transmitting via RS232 or RS485 port
LED3 Yellow	ACU receiving via RS232 or RS485 port
LED4 Red	DI_1 active
LED5 Red	DI_2 active
LED6 Yellow	5V DC OK
LED7 Green	12V DC OK

Beeper: An on-board single tone beeper used for:
 Double short beep (a “good beep”).
 Single long beep (a “bad beep”).

**Switches/
Jumpers**

Test Switch:	On-board slide switch enables ACU test mode. (To enable test mode, slide to right away from RJ45 connectors.)
Tamper Switch:	An on-board tamper switch that operates when the case cover is removed. DIP switch 1, position 2, enables the tamper switch feature.

Jumpers	Select types of readers. One jumper per reader. Place jumper on top two of three pins for magnetic or proximity reader or for a keypad, on bottom two of three pins for barcode reader. See Figure 1-3 . See also Table B-5, “DIP Switch 2 Settings,” on page B-3 . (In current version of Series 7000 ACU, both readers must be of the same type.)
---------	---

Firmware

Memory Loop:	Auto-memory loop-around for offline use without need to download.
Anti-Passback:	Prevention of multi-employee badge use.
Intelligent Programming:	Configuration of ACU through “intelligent” badge swipes for badge enrollment, badge disable, relay activation time, badge check, etc.
Validation:	Employee badge validation and schedule validation.
DI/DO:	Full support for dual DI and DO operation.
Comm Management:	Auto revert to offline mode if network fails.
Maximum Employees:	Up to 2,500 depending on memory option.
Employee Schedules:	Up to 300 schedules, each with 8 definable time zones.
Date Settings:	Automatic daylight time savings update.

Power Fail


In the event of a power fail:

- No backup battery installed - The real time clock settings are preserved by the dedicated 3V button battery. The ACU will not function, but all transaction and configuration data will be maintained in the EEPROM.
- Backup battery installed - The ACU continues to function. If connected, the power fail input causes a status message sent to the host computer. (Not currently supported).

Connectors, LEDS, Jumpers, and Switches


Refer to [Figure 1-1](#) and [Figure 1-2](#) for the locations of connectors, switches, jumpers, and LEDs.

Figure 1-1:Series 7000 Network Connectors and Status LEDs




1. RS485 In – for multi-dropping ACUs
2. RS485 Out – for multi-dropping ACUs
3. RS232 – for direct PC serial line connection
4. Status LEDs (See [Table 1-1](#))
5. Earth ground standoff (on bottom of enclosure)

Figure 1-2:Series 7000 Switches and Connectors



1. RS485 In
2. RS485 Out
3. RS232
4. DIP switch 1
5. DIP switch 2
6. Tamper switch
7. Test switch
8. 12V power
9. Relay 1 (DO_1)
10. Relay 2 (DO_2)
11. DI_1
12. DI_2
13. Reader 0
14. Reader 1
15. Battery status monitor (for future use)
16. Jumpers for types of readers (See [Figure 1-3](#) and also [Table B-5](#))
17. Grounding stud on enclosure (6-32 thread)

Figure 1-3: Jumpers to Select Types of Readers



Operating Modes

The ACU can operate in three modes:

- Test Mode.
- Standalone Mode.
- Online Mode (RS485 Multidrop Network or RS232).

Test Mode

To enable test mode, set DIP switch 1 position 1 to ON and set the test mode slide switch ([Figure 1-2](#) item 7) to ON. (Slide to the right, away from the RJ45 connectors).

The ACU acts as follows when in this mode:

- If a card is swiped through a reader wired into reader 0 or reader 1 and the card data checks (parity and LRC) are valid, both readers' green LED pin out on the reader connectors (pin 5) will turn on for 1 second and a "good beep" will sound.
 - If DI_1 active, DO_1 active.
 - If DI2 active, DO_2 active.
 - If DI_1 inactive, DO_1 inactive.
 - If DI2 inactive, DO_2 inactive.
- If a card is swiped through a reader wired into Reader 0 or Reader 1 and the card data checks (parity and LRC) are **not** valid, both readers' red LED pin out on the reader connectors (pin 6) will turn on for 1 second and a 'bad beep' will sound.

Standalone Mode Standalone mode is selected by setting DIP switch 1 position 8 to OFF. This mode disables the RS232 and RS485 ports.

Online Mode Online mode is selected by setting DIP switch 1 position 8 to ON. In this mode, the RS485 or RS232 ports are enabled. The ACU can communicate with a host PC that is connected to either port and running software compliant with the ATS polled protocol.

On Line Mode, Dual Door Online mode is selected by setting DIP switch 1 position 8 to ON. In this mode, the RS485 or RS232 ports are enabled. The ACU can communicate with a host PC that is connected to either port and running software compliant with the ATS polled protocol.

Dual door mode is selected by DIP switch 1 position 6 to ON. In this mode, a door lock can be connected to each relay and two door sensors connected to each digital input. On swiping a valid badge on reader 0, relay 1 will activate according to the timeout set. Similarly, when swiping a valid badge on reader 1, relay 2 will activate.

Reset

The Reset DIP switch enables a reset to factory defaults.

If the Reset DIP switch (position 3 of DIP switch 1) is set to ON, the ACU resets parameters as follows:

- Reset the RS232 and RS485 network at 9600,8,1,N. (9600 baud, 8 data bits, 1 stop bit, no parity).
- Reset Queue pointers.
- Erase validation Table.
- Erase Schedule Table.
- Set DO_1 activation time to 1 second.
- Set DO_2 activation time to 10 seconds.
- Set DI_1 time out disabled (000).
- Set DI_2 time out disabled (000).
- No badge filtering.
- Set download ID to “Not Set.”
- Set Beeper Enable.

-
- Enable validation table testing.
 - Disable mask testing.
 - Set validation Positive.
 - Reset badge mask.
 - Disable anti-passback.
 - Reset daylight saving.
 - Reset the bell schedule.
 - Set the date to January 1, 2000.
 - Set master badge default number to 070261150168.

Validation Table

The ACU keeps in memory a validation table, where the badge numbers (up to 12 digits each) and the schedule IDs (up to 100) are stored. Up to 2500 badges can be stored in the validation table (2500 users). The ACU keeps only the first 2500 users loaded.

Validation Table Online Download

If online mode is selected, the ACU gets the validation table from a host PC using the serial port. You use commands from the host such as [LEE01](#), [LEC01](#), and [LED01](#) to load records into the ACU.

Standalone Validation Table

In standalone mode, the ACU's validation table is set up locally instead of being downloaded from a remote host.

Single Card Add/Disable/Enable

In standalone mode it is possible to add or remove a badge from the validation table. You must use a special master badge access card to put the ACU in this mode.

To add/disable/enable a badge:

- Swipe the access card, then swipe the employee badge.
- If the employee badge is not in the validation table, it will be added and enabled (access allowed).
- If the employee badge is already in the validation table and enabled, the badge will be disabled (access not allowed).
- If it is already in the validation table and disabled, the badge will be enabled.
- After swiping the a card to add or delete the badge, test the card to make sure it does (or does not) open the door.
- The master badge access card default is 070261150168.

Notes:

- The number of badges in the validation table is limited to 2500, and disabling a badge does not delete it from the validation table.
- All employees added in this way have an open schedule. Scheduling is not available.

Schedules

The ACU keeps in memory a schedule table, where the schedule IDs (up to 100) and the schedule zones (up to 800) are stored. Each schedule have 8 zones. The ACU keeps only the first 100 schedules loaded. You use commands such as [LSE01](#) and [LSC01](#) to download schedule information from the host to the ACU.

Door lock/ release operation (DO_1)

The DO_1 relay is typically connected to an electric door lock. In normal use, operation proceeds somewhat as follows:

Swipe a card to enter a badge number.

- The ACU recognizes a “good swipe” when the data received from the readers is valid according to the parity and LRC card check, and if the number of digits does not exceed 12. The badge number is accepted and will be processed.
- The ACU recognizes a “bad swipe” when the data received from the readers is not valid, when the parity or LRC card check fails. The badge number is rejected and will not be processed.
- If the number of digits exceeds 12, the ACU recognizes a “bad swipe.” The badge number is rejected and will not be processed.

To open the door, the badge has to be validated.

- If the badge number is in the validation table and inside its schedule zone, the badge is valid.
- If the badge number is in the validation table but outside its schedule zone, the badge is not valid.
- If the badge number is not in the validation table, the badge is not valid.

“Good Swipe” and “Badge Valid”

The green LED pin out on the reader connectors is set on for 1 second. A “good beep” sounds if enabled and the DO_1 is active for a pre-set time.

”Good Swipe” and “Badge Not Valid”

The yellow LED pin out on the reader connectors is set on for 1 second and a “bad beep” sounds if enabled.

”Bad Swipe”

The red LED pin out on the reader connectors is set on for 1 second and a “bad beep” sounds if enabled.

Badge Swipe and Alarm Logging

Every time a “good swipe” occurs, the ACU stores in memory:

- The badge number
- The date
- The time
- Access permit/denied decision

The ACU also logs the alarm occurrences (tamper, DI_1, and DI_2) and the battery status (low battery and on battery)

With 1Mbits of storing memory, the ACU can store the last 8000 events.

If the ACU is permanently polled, the host PC will receive the last swipe.

If the ACU is not polled for any reason:

- The ACU will remember the last polled data.
- When the ACU is polled again, the host will receive the data from this last polled data, one at a time at each poll, up to the last “good swipe.”

Anti-Passback

The validation table is stored in RAM for fast access and includes a PRESENCE flag to identify that a badge has been swiped in or swiped out.

If enabled, the anti-passback feature works as follows (reader 1 – outside):

- A “good swipe” in reader 0 sets the PRESENCE flag to OUT and the badge is valid.
- If the presence flag is OUT and a “good swipe” occurs in reader 1, the PRESENCE flag is set to IN and the badge is valid.
- If the presence flag is IN and a “good swipe” occurs in reader 1, the badge is not valid.

Note: When the ACU resets (power fail or startup), all the PRESENCE flags are set to OUT.

Standalone Mode

When the ACU is installed as a stand-alone ACU, a master card is used to add and delete users (badge IDs) to/from the ACU. The default master ID badge number is 070261150168.

If needed, the ACU can initially be connected to a PC communications port and employee validation files can be downloaded (according to the ATS protocol) using the relevant commands as outlined in the command set. Once this has been done, the ACU can be switched into stand-alone mode and employees can now swipe and use the ACU as normal.

Using the Master badge

You can use the master badge for setup only when the ACU is in standalone mode. The master badge can be barcode, magnetic stripe, or proximity format, depending on the type of reader that is connected. If the reader being used supports tri-state LEDs, the LEDs will provide visual indicators of the ACU state.

If the master badge is swiped on reader 1 or 2, the ACU will enter intelligent badge set-up mode and the readers will show an illuminated yellow LED. To add a new badge ID to the ACU's validation table, swipe a new card after the master card swipe. If successfully added, the ACU will sound a good beep and flash the reader's green LED. To delete a current badge, swipe the master badge followed by the existing badge you want to remove from the ACU.

The number for the master badge can be changed from the default number using the [LSA01](#) command.

Host Communications

There are a number of host software utilities available from ATS that are intended to be used by software developers to assist with the creation of access control application software. The scope of this manual does not cover in detail the use of these utilities. Contact Accu-Time Systems or your local ATS representative if you would like a copy of any of these utilities.

AccuComm/ Test Program

ATS can provide upon request AccuComm, a sample application program. The program uses both the ATS DLLs and third party controls to manage communications between a PC and a Series 7000 ACU. It provides the means to poll, download, set time/date, and send messages to the Series 7000 ACU.¹

Documentation describing the ATS proprietary protocol is available for software developers who need to manage the communications between a PC and a Series 7000 ACU.

Dynamic Link Library Files

Dynamic Link Libraries (DLLs) are available to run within an application to manage the protocol handling between a PC and a Series 7000 ACU. Currently, the following .DLLs are available:

atspol32.dll	Serial communications for Windows 95/98/2000
atstcp95.dll	TCP communications for Windows 95/98
atstcp32.dll	TCP communications for Windows NT

Employee Identification

Employees are identified, in a database, through the use of a unique set of alphanumeric characters. These characters can be presented on employee badges as bar code, magnetic stripe, or Proximity devices (Indala, Hughes, Sensor), or a combination of unique numbers and a biometric template. The ACU supports all of these technologies. The two most commonly used encoding techniques are bar code and magnetic stripe, described below.


- **Bar Code:** Bar coded employee badges probably represent the lowest cost, most easily produced, and most flexible of the badge types. Security from duplication can be provided through the use of an opaque covering over the bar coded area. Infra-red light from the barcode reader can penetrate this covering and read the bar code. The Series 7000 ACU currently supports only code 39 format. If other codes are needed, please consult factory.

¹ The Series 7000 serial ports default to 9600 baud, 8 character bits, 1 stop bit, no parity. Because of a quirk in Accu-Comm's operation, however, you should configure Accu-Comm for 2 stop bits when you use it to control a Series 7000 with default settings.

-
- **Magnetic Stripe:** Magnetically encoded badges look very similar to a standard bank issued credit card. Although there are physically three different magnetic “tracks” that can be encoded and read, ABA track 2 is most common and therefore recommended. Security (difficult to copy or modify) and higher data density (the number of characters and/or numbers per inch) are the main appeal of this technology. The magnetic strip or stripe is applied by the card manufacturer therefore no specifications are provided. Consult with the factory if you require Track 1 or Track 3 support.
 - **Proximity:** This technology uses RF (radio frequency) to activate a passive chip embedded in a card or a key fob, which contains an alphanumeric code representing the employees number. As the reader radiates a field, the badge or key fob does not have to actually make contact with the reader. Proximity badges/key fobs are almost impossible to copy, so they are quite often the preferred technology for high security access control applications
 - **Keypad:** A keypad is the simplest and probably the least secure of all input technologies. Each keypad has a calculator key layout with 0 – 9, enter and clear. A PIN number is entered into the keypad followed by the Enter key to complete the entry.

[Figure 2-1](#) shows a typical Series 7000 installation scenario.

Figure 2-1: Typical Series 7000 Installation



Installation Guidelines

The terminals and other data collection products manufactured by ATS are microcomputers and should be treated accordingly. Exposure to extreme heat or cold, airborne contaminants, electrically noisy environments, poor power, or any other hostile parameter can reduce the device's performance and introduce data errors. The following information is provided as a set of guidelines to help you understand the basic issues associated with the installation of an access control system.

Environmental Considerations

When choosing a site for installing the ACU, consideration should be given to the environment, the cable distance from the host computer, and where the power source will be located. The ACUs have been designed to be durable, industrial-grade units that can endure harsh environments, but they are not designed to be mounted outside exposed to the weather, nor can they be washed down. Select an interior location that is close to the door or other feature to be controlled, such as in the ceiling space above the door, ensuring that there is sufficient space around the unit to provide access for connecting the power supply and routing the cables.

Take into consideration the likely temperature conditions of the chosen location to ensure that the temperature will not exceed the operating limits of the ACU:

Temperature: 0 to 43 degrees C (32 to 110 degrees F)

Humidity: less than 95% (non-condensing)

Mounting

The ACU(s) should be located in areas that permit ease of employee access while remaining as close to the controlling computer as possible. This reduces the chances of noise coupling into the data lines and may let you run a single ACU using a simple RS-232 interface (under 50 feet, or 15meters). Should longer distances be required, an RS485 interface will support connections of up to 5000 feet (1500 meters), or up to 10,000 feet (3000 meters) with an ATS network booster. At longer distances, issues of cable selection, ATS port splitters, ATS junction boxes, and AC outlets will become more critical.

The readers (barcode, magnetic, or proximity) must be located within 20 wire-feet of the ACU.

The ACU is typically mounted on a wall or other vertical surface using the two keyhole mounting holes on the back plate of the unit. The mounting template shown in [Figure 2-9](#) gives dimensions and hole spacing.

To avoid electronic or electrical noise, take care when locating both the ACU and the routing of cables to the ACU. Some common noise producers include elevators, fluorescent lighting, large electric motors, commercial freezers, air conditioning systems, arc welders, and conveyor systems, which should all be avoided.

Power

The ACU is designed to operate from an unregulated 9-18 VDC power source. (nominal 12 VDC @ 300 mA with no options). Although concerns over the quality of the supplied AC power (high line, low line, brown outs, surges, spikes, etc.) are still important, the transformer in the AC to DC power pack and the tolerance of an unregulated 9-18 volt output gives some degree of isolation from these problems. Ideally, a clean, dedicated AC line should be provided to power the ACU(s) in the network. If a dedicated line is not available, the cleanest line possible, with no electromechanical devices on it, should be used.


Power can be supplied in two ways:

- Through two extra conductors in the 8-conductor RS232 or RS485 cabling supplied by Accu-Time Systems, Inc. You can supply power to these conductors through a power socket built into a DE-9-RJ45 comm adapter, available from ATS. Many factors, such as each terminal's load, the wire gauge, and the length of the wiring must be considered when using this approach, especially in a multi-drop environment. Consult ATS for guidance.
- Through the power socket on the ACU's PC board ([Figure 1-2](#), item 8).

A suitable plug-in power pack similar to [Figure 2-2](#) is available from Accu-Time Systems, Inc. Ensure that a conventional 120VAC wall outlet (220VAC in Europe and other areas, check local electrical code requirements) is available to accept the power pack assembly. The output cable from the power pack, typically 6 feet (1.8 meters) long, will plug into either the power socket on the PC board ([Figure 1-2](#) item 8) or into the power socket on a DE-9-RJ45 comm adapter.

The cover of the ACU is held in place by four #2 Phillips head screws. Remove the screws and lift off the cover to access the power socket on the PC board.

Figure 2-2: Typical 12V Power Pack



Cabling

Usually three things dictate what kind of cable will be used. The first is the environment in which it will be used. (Cable runs, length of pull, type of noise expected, fire/building codes etc.). Second is the communications interface being used (RS-232 or RS-485) and the need for local or remote power. Third is the cost per meter/foot.

You should use RS232 or RS485 cabling with correct twisted pairs. Category 5 cabling, although unshielded, will work in most non-industrial environments, but it is not recommended.

Be sure the distance from the terminal's location to the host computer does not exceed the wire length limitation of the connection type you plan to use. These limits are shown in [Table 2-1](#).

Table 2-1: Wire Length Limitations

Connection Type	Maximum Terminal-to-Host Distance
RS232	50 wire-feet
RS485	Combined terminal/host drop points should not exceed 5,000 wire-feet.
Ethernet 10BASE-T	328 wire-feet (100 meters) from terminal to Ethernet hub or switch

Cabling Accessories

The accessories listed in this section are available from ATS. They can assist you in setting up your overall system network.

Communications Adapter

This device lets you plug into the back of a computer with either a DB-25 connector or a DE-9 connector on one end of the adapter and a RJ-45 connector on the other. This adapter also has a power socket for connecting a 12V power pack. (See [Power on page 2-3](#).)

RS-232 to RS-485 Converter

This device converts RS-232 signals to 4 wire, differentially driven RS-485 signals. It is an active device and requires a separate 12VDC@ 500mA power supply. A single converter can support up to 32 Access Control Units over a network up to 1500m (5000 feet) in length.

Port Splitter

This passive 4 port device is designed to provide a network insertion point for up to 2 Access Control Units (ACUs). If the port splitter is inserted at the end of the network, 3 ACUs may be added. Connections into and out of the port splitter are made via RJ-45 connections.

Network Junction Box

This passive device provides three 8-position barrier strips to allow network wiring to be brought in, with a star configuration out to the rest of the network. Further, it has four RJ-45 ports for multi-dropping ACUs and a DC power input that can feed all four RJ-45 ports. It is supplied with tie wraps for network cable strain relief.

Network Junction Box Junior

Similar in function to the above, the Junior only has a single 8 position barrier strip (for bringing the network cable in and out); two RJ-45 ports for multi-dropping ACUs, and a DC input which can provide power to both RJ-45 ports. It also comes equipped with tie wraps for strain relief of the network cable.

Network Booster

This active device is used to “boost” or amplify signals in a second 1500m (5000’) segment of an RS-485 network. It provides two 8-position barrier strips, the first for bringing in the first 5000 feet, and the second for the next 5000 feet. It also provides four RJ-45 ports for multi-dropping to ACUs. A 12VDC @ 500mA power supply is required to drive the booster. Strain relief tie wraps are included

Network Terminal Block

This is a plastic, wall mounted device that provides 8 screw-down terminals for spade lug input connections with a single RJ-45 output. It is used to connect an ACU to the main network cable. Mounting hardware is included.

RS232

[Figure 2-7](#) shows a typical wiring setup for an RS232 installation. Each ACU connected to the host PC requires its own comm port.

RS485

[Figure 2-8](#) shows a typical wiring setup for an RS485 installation. ACUs connected using RS485 wiring can be “daisy chained” together and use a single host PC comm port.

Connecting the Reader and DI/DO Wiring

Be sure no power is connected to the ACU. The cover of the ACU is held in place by four #2 Phillips head screws. Remove the screws and lift off the cover to access the interior. Take appropriate electrostatic discharge (ESD) precautions whenever you open the enclosure and work around the PC board.


Although it is possible to connect the wiring for the digital inputs and outputs, the readers, and the power monitor in place, ATS does not recommend doing so. The screw-down wiring terminals are all of the form shown in [Figure 2-3](#). The terminal blocks are in two pieces that plug together. The part with the screw terminals will unplug from the part that is soldered to the PC board.

To unplug a block, place your fingernails behind the ridge in the block that is just behind the line of screw heads and pull straight forward, away from the PC board. The front portion of the block containing the screw terminals should unplug from the rear portion.

After you unplug a terminal block, be sure the terminal screws are unscrewed all the way. Strip approximately 5/16" (8mm) of insulation from the ends of the wires that go to the device to be connected to that set of terminals. Push the ends of the wires from the device into the rectangular openings in the front of the block below the screws, as far as the wires will go. Then tighten the screws. Be sure you screw down on the wire, not on the insulation. Also be sure you don't mix up left and right by inverting the block.

When the wires are in place, align the front portion of the terminal block with the mating socket on the PC board, and snap the block back together by squeezing the halves between your fingers.

Figure 2-3: Wiring a Terminal Block



Wiring the Readers

Refer to [Standard Reader Connections on page B-4](#) for tables of pinouts used for readers supported by the Series 7000 ACU. Find the types of readers you have, and connect their wiring to the reader terminal blocks in the ACU. [Table 2-2](#) identifies the ACU reader/keyboard pin numbers and summarizes the connections required. The current version of the Series 7000 ACU expects both readers to be of the same type.

Table 2-2: ACU Reader/Keypad 0 and 1 Connections

Pin Number	Function	Mag / Prox	Barcode	Keypad
1	Shield	Shield	Shield	Shield
2	Ground (0V)	Ground (0V)	Ground (0V) Link to pin 10	Ground (0V)
3	+9V	+9V	Not Connected	+9V
4	Not Connected	Not Connected	Not Connected	A – Row 1
5	Green LED	Green LED	Not Connected	B – Row 2
6	Red LED	Red LED	Not Connected	C – Row 3
7	Yellow LED	Yellow LED	Not Connected	D – Row 4
8	Not Connected	Not Connected	Not Connected	Not Connected
9	Data (Open/Collector)	Data	Data	2 – Col 2
10	Media Detect	Card Present	Link to pin 2	3 – Col 3
11	Clock (Open Collector)	Clock	Not Connected	1 – Col 1
12	+5V	+5V	+5V	+5V

- a. Pin 10 of reader 1 is the exit button input. This is an active low input
- b. If the anti-passback feature will be used then reader 0 should be connected to the IN side of the door and reader 1 to the outside.
- c. The LEDs should be pulled to Ground to light LED (20ma max.)
- d. Pin 10 (Media Detect) goes low (0V) during data transmission.


Wiring the Digital Inputs (DI_1 and DI_2)

The digital inputs each have five terminals: DI-, DI+, Vcc (+5V), shield, and ground. [Table 2-3](#) identifies the pin numbers for the digital inputs.

Table 2-3: ACU DI Connections

Pin Number	Description
1	Shield
2	Ground
3	DI -
4	DI +
5	Vcc (+5v)


In an inactive state, DI- should be pulled low (connected to ground) and DI+ pulled high (connected to Vcc). If either of those connections is broken, the digital input will signal alarm state. For the installation shown in [Figure 2-1](#), connect a normally open magnetic switch between DI- and ground of DI_1. Put a jumper between DI+ and Vcc. (Or, you could put the magnetic switch between DI+ and Vcc, and the jumper between DI- and ground. The effect is the same.) Connect the wire's shield, if any, to the shield terminal.



Magnetic Door Sensor

When contact is broken, DI_1 enters alarm state and can trigger DO_2 to sound alarm.

In the installation being described, DI_2 is not used. Place jumpers between DI- and ground, and between DI+ and Vcc, of DI_2 to disable it.



DI_2 not used. DI+ and DI- connected to power and ground to prevent ACU from entering alarm state.


Wiring the Digital Outputs (DO_1 and DO_2)

The digital outputs each have five terminals: ground, normally open, normally closed, common, and 12V. [Table 2-4](#) identifies the pin numbers for the digital outputs. [Figure 2-4](#) clarifies the relationship of the digital output connections.

Table 2-4: ACU DO Connections


Pin Number	Description
1	+12v
2	Common
3	Normally Closed
4	Normally Open
5	Ground

Figure 2-4: Digital Output (Relay) Connections



Wiring the Door Lock


In the installation shown in [Figure 2-1](#), DO_1 is connected to an electric door lock. The figure below shows one way to make the connection:



In that wiring example, the power for the door lock is being taken from the 12V terminal on DO_1. [Figure 2-5](#) shows an alternative method of powering the door lock from an external source for a voltage other than 12VDC or if the lock requires more power than can be supplied by the 12V relay connection.

Wiring an Alarm

In [Figure 2-1](#), the DO_2 relay is used for alarm output. Connect the DO_2 relay to a suitable alarm mechanism, as shown below:



12VDC alarm. Connection normally open.

When DO_2 is activated, the normally open contact will close, sounding the alarm. [Figure 2-5](#) shows an alternative method of powering an alarm from an external source for a voltage other than 12VDC or if the alarm requires more power than can be supplied by the 12V relay connection.

Operation

If the DI_1 switch is opened, indicating an open door, without a “validate good swipe” having been received from a reader, DO_2 is activated.

In any case, the DO_2 relay is activated if:

- DI_1 stays active during more than a pre-set time (door not closed).
- The tamper switch is opened (enclosure cover removed).

Wiring the Tamper Switch

The tamper switch itself requires no wiring. It is built onto the PC board. If the tamper switch functionality is enabled (DIP switch, position 2, set to OFF), the tamper switch activates the DO_2 relay when the ACU enclosure is opened. Any device you have wired to DO_2 will operate.

Setting the DIP Switches

The DIP switches (items 4 and 5, [Figure 1-2](#)) can be set using a blunt pointed stylus or similar tool to slide a switch up or down. If a proper tool is unavailable, the end of a straightened large-diameter paper clip will serve.

Review their functionality (See [Table B-4](#) and [Table B-5](#)) and set the switches as required.

DIP Switch 1

1. Test Switch Disable

Set OFF to disable operation of the Test switch ([Figure 1-2](#) item 7).

2. Tamper Switch Disable

Set OFF to disable operation of the Tamper switch ([Figure 1-2](#) item 6).

3. Default Reset

Set ON (with power connected to the ACU), then OFF, to reset the ACU to its factory default conditions. (See [Reset on page 1-8.](#))

4. RS232/RS485 Mode

Set ON to use the RS232 interface, OFF to use the RS485 interface.

5. Reserved

Reserved - always set OFF.

6. Single/Dual Door Mode

Set ON for dual door mode. Set OFF for single door mode. See [On Line Mode, Dual Door on page 1-8.](#)

7. ATS Serial Protocol

Always set OFF to use ATS serial protocol.

8. Online/Standalone

Set ON to use ACU in online mode, OFF to use in standalone mode.

DIP Switch 2

1-2. Reader 0 Type

Set switches 1 and 2 to select type of reader connected as reader 0. Options are:

Off/Off - Magnetic stripe or proximity reader (same as Off/On).

Off/On - Magnetic stripe or proximity reader (same as Off/Off).

On/Off - Barcode reader.

On/On - Keypad.

See also [Setting the Jumpers on page 2-13](#). The jumpers must be set correctly for each type of reader.

3. Reader 1 Type

Set switch 3 to select type of reader connected as reader 1. Options are:

Off - Same as reader 0.

On - Exit button (unlocks without swiping a card).

You cannot use two different types of reader. See also [Setting the Jumpers on page 2-13](#). The jumpers must be set correctly for each type of reader.

4-8. Unit Address

Set switches 4 through 8 to set the ACU's binary unit address. For example, if switches 4, 5, 6, and 7 are OFF and switch 8 is ON, that is unit 1, or 00001_2 . Use A setting of Off/Off/Off/Off/Off/Off (00000) for address 32.

[Table 2-5](#) shows binary equivalents for terminal addresses 1 through 32.

Table 2-5: Decimal/Binary Unit Number Equivalents

Decimal	Binary	Decimal	Binary	Decimal	Binary
1	00001	12	01100	23	10111
2	00010	13	01101	24	11000
3	00011	14	01110	25	11001
4	00100	15	01111	26	11010
5	00101	16	10000	27	11011
6	00110	17	10001	28	11100
7	00111	18	10010	29	11101
8	01000	19	10011	30	11110
9	01001	20	10100	31	11111
10	01010	21	10101	32	00000
11	01011	22	10110		

Setting the Jumpers

In addition to selecting the reader types using positions 1, 2, and 3 of DIP switch 1, you must also set two jumpers on the board ([Figure 1-2](#), item 16). Refer to [Figure 1-3](#), which shows the position in which to set the jumpers for each type of reader. Use the upper jumper positions for a magnetic or proximity reader or for a keypad. Use the lower jumper positions for a barcode reader.

Figure 2-5: Alternative Series 7000 Inputs and Outputs Wiring Example







Figure 2-6: Dual Door Mode Wiring Example



12VDC magnetic lock. Connection normally closed (powered to maintain locked state).




12VDC magnetic lock. Connection normally closed (powered to maintain locked state).



Magnetic Door Sensor

When contact is broken, unit will issue an alarm transaction back to the host.



Magnetic Door Sensor

When contact is broken, unit will issue an alarm transaction back to the host.

Figure 2-7: Series 7000 RS232 Serial Installation




Figure 2-8: Series 7000 RS485 Serial Installation





Figure 2-9: Series 7000 Mounting Template (Next Page)




This chapter explains the commands used to control an Accu-Time Series 7000 access control unit (ACU) when running the standard firmware. This firmware is appropriate for the majority of access control and security applications. Once an ACU is installed, a number of operations are possible depending on its setup. For example, you can:

- Swipe or key a badge at a reader / keypad and have the time logged and gain access.
- Validate an employee badge number against the ACU's internal validation tables. This can be a simple badge list or be linked with schedules in order to allow access at certain times to accommodate shift patterns, etc.
- Load bell schedules to sound alarms or bells at certain times using the Digital Output options to signal meal times, breaks, etc. The DO options can also be used to trigger door locks.
- Use interactive commands to control ACUs directly from a host application. Commands such as BELL and DCxxx (activating the relays) can be sent as and when required across a network. See Interactive commands section.

The functions listed above are available on all ACUs from Accu-Time Systems, Inc. You can tailor the functionality of an ACU to your particular requirements using the command set described in this chapter.

Command Syntax

Some commands, to be complete, need information added to them. These command descriptions have a table under them showing the valid choices. **Default** is the value applied if not modified. **Valid range** is the acceptable range of input the command will allow.



Some commands accept one or more arguments. Sometimes an argument is a hexadecimal (base 16) number and the valid range of a single digit may exceed 9. For those instances, use the equivalents in the following table to enter digit values 10 through 15:

Table 3-1: Character Equivalents to Enter Hexadecimal Values

Value	Equivalent
10	: (colon)
11	; (semicolon)
12	< (less than)
13	= (equals)
14	> (greater than)
15	? (question mark)

Command Index

This section lists all the commands in alphabetical order, with a brief description.

Table 3-2: Command Index

Command	Description
ALDI1	Digital IN 1 alarm message Page 3-31
ALDI2	Digital IN 2 alarm message Page 3-31
ALSTATE	Alarm query message Page 3-32
ALTAMP	Tamper alarm message Page 3-33
AQ10	Get current alarm status Page 3-5
BA01	Normal power recovery message Page 3-33
BA02	Low power message Page 3-34
BELL	Turn on “good” beep Page 3-26
BG00	Initial power-up message Page 3-34
BG01	Power-up recovery message Page 3-35
BS00	Program number request Page 3-36
BS01	Badge and schedule size request Page 3-36
BS02	Badge information request Page 3-37
BS03	Location information request Page 3-38
BS04	Schedule information request Page 3-38
BT01	Time request message Page 3-39
C00	Set up RS485 ports Page 3-5
D10	Set download ID Page 3-6
D20	Get download ID Page 3-6
DC100	Turn off DO_1 Page 3-28
DC101	Turn on DO_1 Page 3-28
DC111	Turn on DO_1 for preset time Page 3-28
DC200	Turn off DC_2 Page 3-29
DC201	Turn on DO_2 Page 3-29
DC211	Turn on DO_2 for preset time Page 3-29
DI00	Download ID message Page 3-39
LAP01	Set anti-passback enable Page 3-7
LBC01	Load bell schedules Page 3-21
LBE01	Erase all bell schedules Page 3-24
LDA01	Enable or disable digital inputs Page 3-7
LEB01	Set badge mask and validation Page 3-18
LEC01	Load employee records Page 3-16
LED01	Erase a simple employee Page 3-17
LEE01	Erase employee file Page 3-16

Table 3-2: Command Index (Continued)

Command	Description
<u>LHO101</u>	Load holiday schedules <u>Page 3-22</u>
<u>LPB01</u>	Set beeper enable <u>Page 3-7</u>
<u>LPB03</u>	Set relay activation time in milliseconds <u>Page 3-8</u>
<u>LPB04</u>	Set relay activation time in seconds <u>Page 3-8</u>
<u>LPB05</u>	Set digital IN timeout <u>Page 3-9</u>
<u>LSA01</u>	Set master badge number <u>Page 3-9</u>
<u>LSB01</u>	Set schedule start date <u>Page 3-20</u>
<u>LSC01</u>	Load schedules <u>Page 3-21</u>
<u>LSD01</u>	Delete individual schedule <u>Page 3-22</u>
<u>LSE01</u>	Erase all schedules <u>Page 3-20</u>
<u>O00</u>	Lock ACU <u>Page 3-10</u>
<u>O10</u>	Unlock ACU <u>Page 3-10</u>
<u>P...</u>	Employee transaction message <u>Page 3-40</u>
<u>R00</u>	Reset <u>Page 3-11</u>
<u>R01</u>	Reset <u>Page 3-11</u>
<u>S00</u>	Get program number <u>Page 3-11</u>
<u>S01</u>	Get number of badges and schedules <u>Page 3-12</u>
<u>S02</u>	Get badge information <u>Page 3-12</u>
<u>S03</u>	Get badge information by storage location number <u>Page 3-13</u>
<u>S04</u>	Get schedule information <u>Page 3-13</u>
<u>SI</u>	Turn on “bad” beep and yellow LED <u>Page 3-26</u>
<u>SO</u>	Turn on “good” beep and green LED <u>Page 3-26</u>
<u>T00</u>	Set time/date <u>Page 3-14</u>
<u>T10</u>	Get time/date <u>Page 3-14</u>
<u>T20</u>	Set daylight savings time <u>Page 3-14</u>

General Commands

This section lists general-purpose commands.

AQ10 Get Current Alarm Status

Syntax:

AQ10rs

Arguments:

None.

Discussion:

Returns status of the Tamper, DI_1, and DI_2 inputs, OK or still active as [ALSTATE](#) message.

Example:

AQ10^

C00 Set Up Serial Ports

Syntax:

C00n^mrs

Arguments:

n - Baud rate (value from 1 to 5)

1 = 1200

2 = 2400

3 = 4800

4 = 9600

5 = 19200

m - Data bits and parity (value from 0 to 2)

0 = 8 data bits / no parity

1 = 7 data bits / odd parity

2 = 7 data bits / even parity

Discussion:

The serial ports are set by default to 9600,8,1,N (9600 baud, 8 data bits, 1 stop bit, no parity). Use the C00 command to change the port settings. (The number of stop bits cannot be changed.)

The new settings will take effect only after a power off/on cycle or a RESET command occurs.

Example:

C0050▲

Sets the ports to 9600 baud, 8 data bits, no parity.

D10 Set Download ID

Syntax:

D10XXXXXXXXrs

Arguments:

XXXXXXXX - Eight-character alphanumeric ID for the download.

Discussion:

Sets a download ID so you can later request from the ACU the ID of the last download it received. For instance, if there several .d1d files each holding different groups of badges, the D10 command can get the ID of the download that was last sent to an ACU.

Example:

D10DL000023▲

Sets the download ID to DL000023.

D20 Get Download ID

Syntax:

D20rs

Arguments:

None.

Discussion:

Gets the download ID from an ACU, which was previously set by the last download using the [D10](#) command. The ACU responds with a [DI00](#) message.

Example:

D20▲

LAP01 Set Anti-passback Enable

Syntax:

LAP01**a**rs

Arguments:

a - 0 = disable anti-passback, 1 = enable anti-passback

Discussion:

This feature, if enabled, disallows a second access by a particular badge on reader A if the unit has not yet recorded a swipe by that badge on reader B.

Example:

LAP011 \blacktriangle

Enables anti-passback mode.

LDA01 Set Digital Inputs Active/Inactive

Syntax:

LDA01**a**rs

Arguments:

a - 0 = disable digital inputs, 1 = enable digital inputs.

Discussion:

This command enables or disables the digital inputs. Setting **a** to 1 enables the inputs and 0 disables them. Any other value is ignored.

Example:

LDA011 \blacktriangle

Enables digital inputs.

LPB01 Set Beeper Enable

Syntax:

LBP01**n**rs

Arguments:

n - 0 = Disable on-board beeper.
1 = Enable on-board beeper.

Discussion:

The on-board beeper is sounded during validation badge swipes, alarm states, and while in test mode. Setting the argument **n** to 0 disables the on-board beeper, setting to 1 enables the beeper.

Example:

LPB011▲

Enables on-board beeper.

LPB03 Set Relay Activation Time in Milliseconds

Syntax:

LPB03**aaaa****bbbb**rs

Arguments:

aaaa - Amount of time, in milliseconds, to activate relay D01. Enter 0000 to disable.

bbbb - Amount of time, in milliseconds, to activate relay D02. Enter 0000 to disable.

Discussion:

This command sets the amount of time the DO_1 and DO_2 relays will remain activated after reading a valid badge. The valid time range is from 0.001 to 9.999 seconds. Specify the time, in milliseconds, from 0001 to 9999. The value **aaaa** sets the time in milliseconds the DO_1 relay will be active. The value **bbbb** is used for the DO_2 relay. Entering 0000 disables a relay, thus NOT activating it after a valid badge swipe. You must specify 4 digits.

Note: See also the [LPB04](#) command below, which lets you set the relay activation time in seconds to allow longer periods of operation.

Example:

LPB0305000250▲

Activates relay D01 for 500 milliseconds and relay D02 for 250 milliseconds.

LPB04 Set Relay Activation Time in Seconds

Syntax:

LPB04**aa****bb**rs

Arguments:

aa - Amount of time, in seconds, to activate relay D01. Enter 00 to disable.

bb - Amount of time, in seconds, to activate relay D02. Enter 00 to disable.

Discussion:

This command sets the amount of time the DO_1 and DO_2 relays will remain activated after reading a valid badge. The valid time range is from 01 to 99 seconds. Specify the time, in seconds, from 01 to 99. The value **aa** sets the time in seconds the DO_1 relay will be active. The value **bb** is used for the DO_2 relay. Entering 00 disables a relay, thus NOT activating it after a valid badge swipe. You must specify 2 digits.

Note: See also the [LPB03](#) command above, which lets you set the relay activation time in milliseconds to allow shorter periods of operation.

Example:

```
LPB040520▲
```

Activates relay D01 for 5 seconds and relay D02 for 20 seconds.

LPB05 Set Digital IN Timeout

Syntax:

```
LPB05aabbbrs
```

Arguments:

aaa - Amount of time, in seconds, to wait for Digital IN 1. Enter 000 to disable.

bbb - Amount of time, in seconds, to wait for Digital IN 2. Enter 000 to disable.

Discussion:

This command sets the amount of time that DI_1 and DI_2 will wait for input until the ACU enters alarm mode and sends an alarm message to the host. **aaa** is used for DI_1. **bbb** is used for DI_2. Valid time range is 001 to 999 seconds. Setting an argument to 000 disables timeout for that DI.

Example:

```
LPB05010020▲
```

Sets DI_1 wait for input to 10 seconds and DI_2 wait to 20 seconds.

LSA01 Set Master Badge Number

Syntax:

LSA01[aaaaaaaaaaaa](#)rs

Arguments:

[aaaaaaaaaaaa](#) - Master badge number.

Discussion:

This command sets the master badge number that is used to program the Series 7000 when used in stand-alone mode. The badge number should be padded to 12 digits.

Example:

LSA01000000007965▲

Sets master badge number to 7965.

O00 Lock ACU

Syntax:

O00rs

Arguments:

None.

Discussion:

Locks ACU, disallows user input until unlock command [O10](#) received.

Example:

O00▲

O10 Unlock ACU

Syntax:

O10rs

Arguments:

None.

Discussion:

Unlocks ACU and allows user input.

Example:

O10▲

R00 Reset

Syntax:

R00

Arguments:

None.

Discussion:

Clears RAM queue, deletes all data, and performs a power-on reset. The ACU's baud rate setting is not reset.

Example:

R00▲

R01 Reset

Syntax:

R01

Arguments:

None.

Discussion:

Clears all stored transactions and performs a power-on reset. Any download file stored in the ACU is not deleted.

Example:

R01▲

S00 Get Program Number

Syntax:

S00rs

Arguments:

None.

Discussion:

Returns as a [BS00](#) message the current program number and revision.

Example:

S00▲

S01 Get Number Of Badges And Schedules

Syntax:

S01rs

Arguments:

None.

Discussion:

Returns as a [BS01](#) message the number of badges loaded, number of schedules loaded, largest used badge storage location number, and number of deleted areas (holes) in badge storage area.

Example:

S01▲

S02 Get Badge Information

Syntax:

S02**bbbbbbbbbbbb**rs

Arguments:

bbbbbbbbbbbb - Badge number for which to get information.

Discussion:

Returns as a [BS02](#) message the details on a loaded badge number or returns “NOT FOUND” if the badge is not loaded. Returns the badge number, schedule number, last reader swiped, holiday data in hex format, and location number in the badge storage area.

Example:

S02000000840001▲

Returns details for badge number 840001.

S03 Get Badge Information by storage location number

Syntax:

S03nnnrs

Arguments:

nnnn - badge storage location number, as returned by [S02](#) command in a [BS02](#) message.

Discussion:

Returns as a [BS03](#) message the details on a loaded badge number. If the badge was recently deleted with the LED01 command, the badge number will show ‘ff’ at the start. This indicates that the badge number has been deleted and the memory area has a hole, which will be next filled upon receiving a new employee badge. Note: this ‘ff’ badge will not be validated. If a location number larger than the largest valid badge storage location number (obtained by issuing S01) is queried, then a badge number may be returned from a previous load and look valid (not have ‘ff’ at the start). This will not be validated.

Example:

S0300074^

Obtains badge details in location 0074.

S04 Get Schedule Information

Syntax:

S04nnn^zrs

Arguments:

n - Three digit schedule number

z - One digit zone number

Discussion:

Returns as [BS04](#) message the specified schedule and zone information.

Example:

S040012^

Returns schedule information for schedule number 001 plus the schedule’s zone 2.

T00 Set Time/Date

Syntax:

T00YYMMDDHHMMSSrs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Sets date and time in ACU. Time is in 24-hour format.

Example:

T00030219101509▲

Sets date and time to February 19, 2003, 10:15:09.

T10 Get Time/Date

Syntax:

T10rs

Arguments:

None

Discussion:

Reads the current date and time from ACU. ACU responds with a [BT01](#) message containing current date and time.

Example:

T10▲

T20 Set Daylight Savings Time

Syntax:

T20YYMMDDrs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

Discussion:

Sets the date where daylight savings time will change. A date between June and December will set back the clock one hour. A date between January and May will advance the clock one hour.

Example:

T20030330^

Sets date of change to daylight savings time to March 30, 2003.

Employee File Handling Commands

The employee file is used to validate a badge stored in the ACU. When an employee swipes a badge, the ACU will look to see if the badge is present in the employee file. If the badge is found, the ACU will then check to be sure that the badge can be used at that time (check it against the employee's schedule). If the schedule confirms that access by that badge is valid at that time, the ACU will grant access.

One other item in the employee file is the supervisor level. The supervisor level is used to define whether or not that employee is a supervisor. This item is here for future use.

NEED FORMAT OF SERIES 7000 EMPLOYEE FILE

LEE01 Erase Employee File

Syntax:

LEE01rs

Arguments:

None.

Discussion:

Issuing this command erases the complete employee file stored in the ACU. Use the [LED01](#) command to erase a single employee record.

Example:

LEE01^

LEC01 Load Employee Records

Syntax:

LEC01[aaaaaaaaaaaa](#)[bbb](#)[c](#)

Arguments:

[aaaaaaaaaaaa](#) - Employee badge number (12 digits).

[bbb](#) - Schedule number (3 digits).

[c](#) - Supervisor level (1 digit). Not yet implemented; set to 1.

Discussion:

This command adds employees to the employee file stored in the ACU. Each load will append to the end of the file. Up to 2500 employee records can be loaded into standard ACU memory.

Note: If an employee is to be moved to a different schedule, you must first issue the LED01 (delete) command to remove the badge number then reload the badge with the different schedule number.

Example:

```
LEC010000001234560031▲
```

Defines an employee record with badge number 000000123456, schedule number 003, supervisor level 1.

LED01 Erase a Single Employee

Syntax:

```
LED01aaaaaaaaaaaars
```

Arguments:

[aaaaaaaaaaaa](#) - Badge number of employee record to erase.

Discussion:

Deletes the specified employee record from the employee file stored in the ACU. Use the [LEE01](#) command to erase the complete employee file.

Space freed by this command will be reused if you subsequently use the LEC01 command to add a new employee record.

Example:

```
LED01000000840012▲
```

Deletes the employee record for badge 840012.

Badge Masking and Validation Commands

This section lists commands used for badge masking and validation.

LEB01 Set Badge Mask and Validation

Syntax:

LEB01**a****b****c****d**xxxxxxxxxxxx**nnn**rs

Arguments:

- a** - 0 = No validation of the badge to the employee file.
1 = Do validate the badge.
- b** - 0 = No mask testing
1 = Check the badge against the mask
- c** - 0 = Positive validation (standard)
1 = Negative file validation
- d** 0 = Not used

xxxxxxxxxxx - This is the 12-character badge mask. A specific character in each position means the badge **MUST** have that character in that position.

? in any position means don't care, allow any character in that position.

DC2 (CTRL/R, 18₁₀, 12₁₆) means there must be an alphabetic character in that position.

DC3 (CTRL/S, 19₁₀, 13₁₆) means there must be a numeric character in that position.

nnn - Schedule number to test badge against if valid. 000 = Do not test.

Discussion:

This command sets three operating characteristics of the ACU:

- If the badge swiped will be validated against the employee file or not.
- If the badge is not to be tested against the employee file, will it be tested against the mask. (A mask is a string of characters the same length as the badge number, with each position of the mask allowing for screening of the badge on a byte-by-byte basis. In other words, each character position

of the badge will be tested to see if its valid, such as, is it a number, is it a character, is it either a number or a character, or test to see if it is a specific character.)

- If the badge is to be tested against the employee file, is it negative or positive validation. Positive validation will allow the badge if it is present in the employee file. Negative validation will allow the badge if is NOT present in the employee file.

Example:

LEB0111000000000???000▲

Requests validation against the employee file, requests mask checking, and positive validation. The mask requires zeros in the first eight badge number positions and any character in the last four positions. No schedule testing is to be performed.

Schedule File Handling

This section lists commands used to set up and maintain employee schedule files.

LSE01 Erase All Schedules

Syntax:

LSE01rs

Arguments:

None.

Discussion:

The LSE01 command erases all schedules loaded in the ACU.

Note: There may be a delay when using this command because of the time required to erase all memory locations reserved for all schedules. It may be faster to use the LSC01 command and erase individually.

Example:

LSE01▲

Erases all schedules.

LSB01 Set Schedule Start Date

Syntax:

LSB01YYMMDDrs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

Discussion:

This command sets the schedule start time at 00:00 the specified day. All start and stop zones are in minutes offset from that time.

Example:

LSB01030420▲

Sets the schedule start time to April 20, 2003, 00:00:00.

LSC01 Load Schedules

Syntax:

LSC0nnn_bbbbbeeeeeers

LSC01nnn_bbbbbeeeee_bbbbbeeeee...rs

(n.b. _ represents a space character, which must be present.)

Arguments:

nnn - Schedule identifier number, 001 through 999.

bbbb - Beginning zone time, minutes offset from schedule start date.

eeee - Ending zone time, minutes offset from schedule start date.


Discussion:

The LSC01 command defines a schedule and assigns beginning and ending times (time zones) between which an employee using that schedule will be allowed to use the ACU. If more than one zone is required for a schedule, then those times can be added to the argument string (see example below).

When loading multiple schedule zones with the LSC01 command, the maximum length of the message must not exceed 250 characters. Only one schedule at a time can be loaded with an LSC01 command. The number of zones can vary from schedule to schedule. The same schedule can be used for different employees.

The space (shown as _) between **nnn** and **bbbb** is reserved for future use. Also, when specifying multiple zones for a schedule there must be a space before the next start time.

Example:



The schedule shown in the example allows an employee to swipe between 473 minutes from the schedule start date (473 minutes = 7 hours 53 minutes or 7:53am) and 997 minutes (4:37pm) (zone 1), and between 12:23am and 4:37pm the next day (zone 2). A maximum of 300 schedules can be loaded each with 8 zones (1 zone = start time and stop time)

Appendix C provides a minutes-to-hours conversion table to assist in calculating schedule times.

Auto-schedule

If a schedule is set up and used for a week and not re-downloaded at the end of the week, then it will automatically be re-used and continue for the next week based on the original zones.

LSD01 Delete Individual Schedule

Syntax:

LSD01`nnn`rs

Arguments:

`nnn` - Number of the schedule to delete.

Discussion:

To delete an individual schedule, specify the schedule number with no zones after it. The schedule will be deleted.

Example:

LSD01031▲

Deletes schedule 31.

LHO101 Load Holiday Schedules

Syntax:

LHO101`abcdefg`rs

Arguments:

`abcdefg` - Each letter denotes a day of the week: a = Sunday, b = Monday, c = Tuesday, etc. Each letter can be set to zero or 1. Setting to 1 will place the badge on holiday that day, that is, will not allow access. Setting to zero will use the badge's normal schedule if one exists.

Discussion:

The holiday command lets you set a particular badge “on holiday” for particular days during the current week irrespective of its current schedules. The holiday command overrides any existing schedule for that badge.

Example:

LHO1011000011▲

Mark badge number as “on holiday” for Sunday, Friday, and Saturday.

Bell Schedule File Handling

This section describes commands used to set up and maintain bell schedule files.

LBE01 Erase All Bell Schedules

Syntax:

LBE01rs

Arguments:

None.

Discussion:

The LBE01 command erases all bell schedules loaded in the ACU.

Example:

LBE01^

Erases all bell schedules.

LBC01 Load Bell Schedules

Syntax:

LBC01dmmmm00rs

LBC01dmmmm00mmmm00...rs

Arguments:

d - Day of week to assign schedule to:
0=Sunday, 1=Monday, 2=Tuesday, 3=Wednesday, 4=Thursday,
5=Friday, 6=Saturday.

mmmm - Minutes past midnight to activate the DO.

00 - Two digit zero fill. Use the LPB03 command to specify the amount of time to activate the DO.

Discussion:

The bell schedule command gives you a way to activate the DO_2 output port at a specified time during the day. The load bell schedule command loads for a particular day, that days schedule.

You can define up to 32 bells per day. To load more than one bell schedule per day, specify the starting times (each with a two-digit zero fill) one after the other in the command line string.

If one or more of the arguments is invalid, the command is ignored.

Example:

```
LBC010087000090000....^
```

Assigns to Sunday (0) a bell schedule of 2:30pm (870 minutes after midnight) and 3:00pm (900 minutes after midnight).

Interactive Commands

The commands in this section can be sent from a host directly to any ACU on a network to trigger Digital Out relays or the beeper.

BELL Turn on “Good” Beep

Syntax:

BELLrs

Arguments:

None.

Discussion:

Turns on “good” beep (double short beep).

Example:

BELL^

SO Turn on “Good” Beep and Green LED

Syntax:

SO n rs

Arguments:

n - Reader number (1 or 2)

Discussion:

Turns on “good” beep (double short beep) and green LED on reader n ($n = 1$ or 2).

Example:

SO2^

Turns on “good” beep and green LED on reader 2.

SI Turn on “Bad” Beep and Yellow LED

Syntax:

SI n rs

Arguments:

n - Reader number (1 or 2)

Discussion:

Turns on “bad” beep (single long beep) and yellow LED on reader n (n = 1 or 2).

Example:

S12▲

Turns on “bad” beep and yellow LED on reader 2.

Controlling Relays DO_1, DO_2

Use the commands described in this section to control the ACU's relays DO_1 and DO_2.

DC101 Turn on DO_1

Syntax:

DC101rs

Arguments:

None.

Discussion:

Turns on DO_1 relay until turned off by [DC100](#) command.

Example:

DC101^

DC100 Turn off DO_1

Syntax:

DC100rs

Arguments:

None.

Discussion:

Turns off DO_1 relay.

Example:

DC100^

DC111 Turn on DO_1 for Preset Time

Syntax:

DC111rs

Arguments:

None.

Discussion:

Activates DO_1 relay for length of time previously set by [LPB03](#) or [LPB04](#) command.

DC201 Turn on DO_2

Syntax:

DC201rs

Arguments:

None.

Discussion:

Turns on DO_2 relay until turned off by [DC200](#) command.

Example:

DC201^

DC200 Turn off DO_2

Syntax:

DC200rs

Arguments:

None.

Discussion:

Turns off DO_2 relay.

Example:

DC200^

DC211 Turn on DO_2 for Preset Time

Syntax:

DC211rs

Arguments:

None.

Discussion:

Activates DO_2 relay for length of time previously set by [LPB03](#) or [LPB04](#) command.

Example:

DC211▲

Messages Received From ACU

This section describes the different types of messages that can be sent from an ACU to its host computer. Although they are included in the “commands” chapter, they are more properly thought of as message headers.

ALDI1 Digital IN #1 Alarm Message

Syntax:

ALDI1rsusYYMMDDHHMMSSrsFORCEDrs

or

ALDI1rsusYYMMDDHHMMSSrsOPENEDrs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

FORCED - This argument is sent to host if digital IN 1 (DI_1) is open when digital OUT 1 (DO_1) is not activated.

OPENED - This argument is sent to host if DI_1 remains open for longer than the wait time set by the [LPB05](#) command. The beeper will sound a bad beep and the DO_2 relay will also be activated.

Discussion:

Message returned by ACU in response to a Digital IN event. The message indicates the type of event, with a timestamp of when the event occurred.

Example:

ALDI1^v030416025111^FORCED^

DI_1 open, DO_1 not activated, timestamp April 16, 2003, 2:51:11am.

ALDI2 Digital IN #2 Tamper Alarm Message

Syntax:

ALDI2rsusYYMMDDHHMMSSrs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Timestamp message sent by ACU to host if Digital IN 2 is open when DO_1 is not activated or DI_2 remains open for longer than the wait time set by the [LPB05](#) command. The beeper will sound a “bad beep” and the DO_2 relay will be activated.

Example:

ALDI2^v030421092102^

Timestamp April 21, 2003, 9:21:02am.

ALSTATE Alarm Query Message

Syntax:

ALSTATErsusa**bc**rs

Arguments:

a - Tamper alarm state. 0 = inactive, 1 = active.

b - DI_1 state. 0 = inactive, 1 = active.

c - DI_2 state. 0 = inactive, 1 = active.

Discussion:

Message sent from ACU to host on receipt of the [AQ10](#) command.

Example:

ALSTATE^v010^

Tamper alarm inactive, DI_1 active, DI_2 inactive.

ALTAMP Tamper Alarm Message

Syntax:

ALTAMPrsus**YYMMDDHHMMSS**rs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Message sent to host if the tamper switch inside the ACU case is activated while online. The beeper will sound a “bad beep” and the DO_2 relay will also be activated. The date and time returned is the timestamp when tamper switch was activated.

Example:

ALTAMP[^]_v030416023741[^]

Tamper switch activated, timestamp of April 16, 2003, 2:37:41am.

BA01 Normal Power Recover Message

Syntax:

BA01rsus**YYMMDDHHMMSS**rs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Normal power recovery message sent from ACU to host when ACU returns to normal power operation. The timestamp is the time the message is sent.

Example:

BA01[^]_v030419114500[^]

Power recovery occurred April 19, 2003, at 11:45:00.

BA02 Low Power Message

Syntax:

BA02rsus^{YYMMDDHHMMSS}rs

Arguments:

^{YY} - Two-digit year

^{MM} - Two-digit month

^{DD} - Two-digit day

^{HH} - Two-digit hour (24-hour format)

^{MM} - Two-digit minutes

^{SS} - Two-digit seconds

Discussion:

Low power alarm message sent from ACU to host when ACU enters low power operation.

Example:

BA02[^]_v030419113019[^]

Low power occurred April 19, 2003, at 11:30:19.

BG00 Initial Power-Up Message

Syntax:

BG00rsus^{YYMMDDHHMMSS}rs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Power-up message sent by ACU to host on initial power-up, with a timestamp indicating the time the power-up occurred. If BG00 is returned, the ACU does not have a command download in memory and will be in a locked state until one is received. If [BG01](#) is returned, the ACU does have command download in memory.

Example:

BG00^v030412080307^

Initial power-up message sent by ACU to host indicating an initial power-up occurred April 12, 2003, at 8:03:07.

BG01 Power-Up Power Recovery Message

Syntax:

BG01rsusYYMMDDHHMMSSrs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Power-up message sent by ACU to host after a power recovery, with a timestamp indicating the time the power recovery occurred. If BG01 is returned, the ACU has a command download in memory. If [BG00](#) is returned, the ACU does not have command download in memory and will be in a locked state until one is received.

Example:

BG01^v0306211709042^

Power recovery message sent by ACU to host indicating a power recovery occurred June 21, 2003, at 17:09:42.

BS00 Program Number Request

Syntax:

BS00**PPP****R**rsus**YY****MM****DD****HH****MM****SS**rs

Arguments:

PPP - Program number

R - Program revision

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Message sent from ACU to host in response to program number request from host. The timestamp is the time the message is sent.

Example:

BS00200J^v030419120317^

The ACU reports a program number of 200, revision J, with a message timestamp of April 19, 2003, 12:03:17.

BS01 Badge And Schedule Size Request (response to S01 command)

Syntax:

BS01us**bbbb**us**sss**us**mmmm**us**hhhh**us**YYMMDDHHMMSS**rs

Arguments:

bbbb = Number of badges loaded

sss = Number of schedules loaded

mmmm = Largest valid badge storage location number

hhhh = Total number of “holes” in the used badge storage area

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Response to S02 command badge and schedule request.

Note: (**mmmm** – **hhhh**) should equal **bbbb**.

Example:

BS01√0250√005√0260√0010√030419085347^

(bbbb = 0250, sss = 005, mmmm = 0260, hhhh = 0010.)

BS02 Badge Information Request (response to S02 command)

Syntax:

BS02us**aaaaaaaaaaaa**us**bbb**soh**c**soh**dd**soh**eeeeers**

Arguments:

aaaaaaaaaaaa - Badge number loaded

bbb - Schedule number currently active

c - Last reader swiped

dd - Holiday data in hexadecimal format

eeee - Badge storage location number

Discussion:

Response to S02 command badge information request.

Example:

BS02√000000007965√003⊙0⊙00⊙00260▲

Badge number 7965, schedule 003, reader 0, holiday data 00, storage location number 00260.

BS03 Location Information Request (response to S03 command)

Syntax:

BS03usaaaaaaaaaasbbbsohcsohddsoheeeers

Arguments:

aaaaaaaaaaaa = badge number loaded

bbb = schedule number currently active

c = last reader swiped

dd = holiday data in hexadecimal format

eeee = storage location number

Discussion:

Response to S03 command location information request.

Example:

BS03√000000007965√003⊙0⊙00⊙00260▲

Badge number 7965, schedule 003, reader 0, holiday data 00, storage location number 00260.

BS04 Schedule Information Request (response to S04 command)

Syntax:

BS04usaaabusccccdddddrrs

Arguments:

aaa - Schedule number

b - Schedule zone number – starts at 0

cccc - Start minutes of zone

dddd - End minutes of zone

Discussion:

Response to S04 command schedule information request.

Example:

BS04√0031√0480005340▲

Schedule number 3, zone 1, start 04800 (Thursday, 8:00am), end 05340 (Thursday, 5:00pm).

BT01 Time Request Message

Syntax:

BT01YYMMDDHHMMSSrsusYYMMDDHHMMSSrs

Arguments:

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

Discussion:

Message sent from ACU to host in response to a [T10](#) get time request from host. The two timestamps are the same and are the date/time and stored in the ACU.

Example:

BT01030419114503▲√030419114503▲

The ACU reports its time as April 19, 2003, 11:45:03.

DI00 Download ID Message

Syntax:

DI00usaaaaaaars

Arguments:

aaaaaaa - Download ID

Discussion:

Message sent by ACU to host to return the download ID that was initially set with the [D10](#) command.

Example:

DI00_vDL000023_^

Download ID = DL000023.

P.... Employee Transaction Message

Syntax:

PeSnnrsbbbbbbbbbbbsus**YYMMDDHHMMSS**rsnrs

Arguments:

P - First character = P signifies employee transaction.

e - Type of entry. B = badge entry, K = keyboard entry.

S - Third character = S signifies standard punch.

nnn - Valid/invalid badge.

000 = badge swiped was valid.

999 = badge swiped was invalid or denied access.

bbbbbbbbbbbb - Employee number (badge number).

YY - Two-digit year

MM - Two-digit month

DD - Two-digit day

HH - Two-digit hour (24-hour format)

MM - Two-digit minutes

SS - Two-digit seconds

n - Reader number (0 or 1).

Discussion:

Each transaction message received by the host from an ACU contains a timestamp of the date and time the event occurred. The examples below show how transaction messages are formatted.

Example:

PBS000▲000000123456▲▼030412141753▲0▲

Employee swiped badge number 000000123456 on reader 0 at 14:17:53 pm April 12, 2003. The badge was valid.

PBS999▲000000123456▲▼030414061902▲1▲

Employee swiped badge number 000000123456 on reader 1 at 6:19:02 on April 14, 2003. The badge was invalid.

Note: The actual strings received from the ACU will contain two additional characters at the end, which are not used and can be ignored when processing the data.

General Command Syntax Notes

1.Date and time stamp is preceded by a **us** = unit separator (1F HEX)

2.All messages end with **rs** = record separator (1E HEX)

3.All messages to ACU must not exceed a maximum message length of 250 characters.

4.All messages transmitted and received start with a header which consists of:

\B!gs

**** back slash (5C HEX)

B application type (default is B) (41 HEX - 4A HEX)

! ACU address selected by onboard DIP switches (Sw2 Pos4-8)

gs group separator (1D hex)

Note: Appendix B shows a table with the single character addressing that is used to identify individual ACUs from the polled transaction data.

Appendix A

Minute Offsets

[Table A-1](#) shows the minute offset from Sunday midnight for each hour of the week for use in the schedule command ([LSC01](#)). The value used as the schedule offset should be a five-digit number padded with leading zeros. Add the minutes of a partial hour to the figure in the table below (e.g. 01:45 on Tuesday would be 1500 + 45, or 01545).

Table A-1: Schedule Minutes Offset

	MON	TUE	WED	THU	FRI	SAT	SUN
00:00	0	1440	2880	4320	5760	7200	8640
01:00	60	1500	2940	4380	5820	7260	8700
02:00	120	1560	3000	4440	5880	7320	8760
03:00	180	1620	3060	4500	5940	7380	8820
04:00	240	1680	3120	4560	6000	7440	8880
05:00	300	1740	3180	4620	6060	7500	8940
06:00	360	1800	3240	4680	6120	7560	9000
07:00	420	1860	3300	4740	6180	7620	9060
08:00	480	1920	3360	4800	6240	7680	9120
09:00	540	1980	3420	4860	6300	7740	9180
10:00	600	2040	3480	4920	6360	7800	9240
11:00	660	2100	3540	4980	6420	7860	9300
12:00	720	2160	3600	5040	6480	7920	9360
13:00	780	2220	3660	5100	6540	7980	9420
14:00	840	2280	3720	5160	6600	8040	9480
15:00	900	2340	3780	5220	6660	8100	9540
16:00	960	2400	3840	5280	6720	8160	9600
17:00	1020	2460	3900	5340	6780	8220	9660
18:00	1080	2520	3960	5400	6840	8280	9720
19:00	1140	2580	4020	5460	6900	8340	9780
20:00	1200	2640	4080	5520	6960	8400	9840
21:00	1260	2700	4140	5580	7020	8460	9900
22:00	1320	2760	4200	5640	7080	8520	9960
23:00	1380	2820	4260	5700	7140	8580	10020

Appendix B Pinouts, Interfaces, and Switches

This appendix describes the connector pinouts, interfaces, and switches of the Series 7000 access control unit (ACU).

Pinouts

12V Power Input

Connector type: 2.5mm socket

Pinout: Negative outside, positive inside

RS232 Network

Connector type: RJ45 socket – 8 contact

Table B-1: RS232 Pinout^a

Pin Number	Description
1	Earth ground
2	Receive data
3	Transmit data
4	N/C
5	N/C
6	Ground
7	Link to pin 7 on RS485 network plug
8	Ground

^a Pinouts are referenced to the terminal.

RS485 Network

Connector type: 2 RJ45 sockets – 8 contact

Table B-2: RS485 Pinout^a

Pin Number	Description
1	Earth ground
2	Network data in –
3	Network data out +
4	Network data out –
5	Network data in +
6	Ground
7	Link to pin 7 on RS232 network plug
8	Ground

^a Pinouts are referenced to the terminal.

Battery Status Inputs

Connector type: 3.5mm pitch screw terminal plug – 4 contact (**Note:** For future use.)

Table B-3: Battery Status Pinout

Pin Number	Description
1	Ground
2	Battery on (power failure) signal from UPS
3	Battery low signal from UPS
4	Chassis

DIP Switches

DIP Switch 1

Table B-4: DIP Switch 1 Settings

Number	On (1)	Off (0)
1	Test Switch Disable	Test Switch Enable
2	Tamper Switch Disable	Tamper Switch Enable
3	Factory Default Unit Reset	Normal Operation
4	RS232 Mode	RS485 Mode
5	Reserved – set OFF	
6	Dual Door Mode	Single Door Mode
7	Reserved	Normal Operation
8	On-Line	Stand-Alone

DIP Switch 2

Table B-5: DIP Switch 2 Settings

Number	Description	Value ^a	
1 – 2	Reader 0 type	00 ^b	Mag Stripe/Prox Reader
		01 ^b	Mag Stripe/Prox Reader
		10	Barcode Reader
		11	Keypad
3	Reader 1 type	0	Same as reader 1
		1	Exit Button
4 – 8	(Binary Unit Address)	00001	Address = 1
		00010	Address = 2
		00000	Address = 32

^a 0 = OFF, 1 = ON.

^b There is no difference in functionality between a setting of 00 and a setting of 01 for switches 1-2.

IMPORTANT: For a magnetic or proximity reader or for a keyboard, the board jumpers must be placed in the upper position. For barcode readers, the jumpers must be placed in the lower position. See [Figure 1-3 on page 1-7](#).

Standard Reader Connections

This section gives the wire color code and corresponding pinout for the readers supported by ATS for use with the Series 7000 ACU.

Reader 7000/101 and 102 Wiring (Mag Stripe and HiTag Proximity)

Table B-6: Reader 7000/101 and 7000/102 Wiring

Reader 0/1 Pin Number	Reader Wire Color
1	Shield
2	White and Black
3	N/C ^a
4	N/C
5	Green
6	Brown
7	Orange
8	N/C
9	Yellow
10	Purple
11	Blue
12	Red

^a N/C = not connected

Keypad 7000/103

Table B-7: Keypad 7000/103 Wiring (Storm)

Reader 0/1	
Pin Number	Keypad Wire Color
1	N/C ^a
2	N/C
3	N/C
4	Green
5	Pink
6	Grey
7	Brown
8	N/C
9	Orange
10	Purple
11	Blue
12	N/C

^a N/C = not connected

HID “Clock and Data” Reader Wiring

The following table shows the wiring details for connecting a clock-and-data interface HID Prox-Point Plus reader (P/N: 6008B) to an ATS Series 7000 ACU.

Table B-8: HID ProxPoint Plus “Clock and Data” Reader Wiring

Pin Number	Wire Color	Function
1	Shield (Black)	Shield ^a
2	Black	Ground
3	N/C ^b	
4	N/C	
5	Orange	Green LED
6	Brown	Red LED
7	N/C	
8	N/C	
9	Green	Data
10	Purple	Card Present
11	White	Clock
12	Red	+5V

^a The shield wire is usually covered with a black sheath and should not be confused with the 0V ground wire of the same color.

^b N/C = not connected.

**Barcode Readers
(ATS Weather
Resistant 9001/
XX)**

The supplied reader cables use one of two wire color codes, depending on the date of the cable's manufacture. [Table B-9](#) lists both color codes.

Table B-9: Barcode Readers 9001/XX Wiring

Pin Number	Wire Color Code A	Wire Color Code B	Function
1	N/C ^a		
2	Yellow	Blue	Ground
3	N/C ^a		
4	N/C ^a		
5	N/C ^a		
6	Black	White/Blue	Red LED (if supported)
7	N/C ^a		
8	N/C ^a		
9	Red	White/Orange	Data
10	Link to pin 2 ^b		
11	N/C ^a		
12	Green	Orange	+5 VDC

^a N/C = not connected

^b For barcode reader. Pin 10 of reader 1 connector can be used for exit button input if DIP switch 2 #3 is set to 1. See [DIP Switches on page B-3](#).

The cables that come with ATS 9001/xx readers may have attached modular plugs, but the reader interfaces of the 7000 have only screw-down connectors for separate wires. If the cables that come with your readers have attached plugs, cut the modular plugs off the cables, strip the wires as shown in the section [Connecting the Reader and DI/DO Wiring on page 2-6](#), and route the color-coded wires to the correct pins of the screw-down connectors.

You set a Series 7000 ACU serial network address using DIP switch 2, positions 4 through 8. That address is represented in the header of each transaction message sent from an ACU to the host as the character shown in the right-hand column of [Table C-1](#). For example, the character # will appear in transaction messages sent from an ACU with DIP switch 2 positions 4 through 8 set to 3. (011₂)

Table C-1: Network Controller ID Addressing Table

ACU/Network Controller ID (DIP Switch 2 Positions 4-8) 0 = OFF, 1 = ON	Transaction Header Address
1 (00001)	!
2 (00010)	"
3 (00011)	#
4 (00100)	\$
5 (00101)	%
6 (00110)	&
7 (00111)	'
8 (01000)	(
9 (01001))
10 (01010)	*
11 (01011)	+
12 (01100)	,
13 (01101)	-
14 (01110)	.
15 (01111)	/
16 (10000)	0

Table C-1: Network Controller ID Addressing Table

17 (10001)	1
18 (10010)	2
19 (10011)	3
20 (10100)	4
21 (10101)	5
22 (10110)	6
23 (10111)	7
24 (11000)	8
25 (11001)	9
26 (11010)	:
27 (11011)	;
28 (11100)	<
29 (11101)	=
30 (11110)	>
31 (11111)	?
32 (00000)	@

[Figure D-1](#) shows a sample download for a Series 7000 ACU running the standard firmware (200 version EPROM). Refer to [Table 1 on page xii](#) for definitions of the special character symbols used in the example.

Comment lines appear in the example as `/* . . . */`. These are ignored during processing.

Two lines in the example, identified by comments, wrap on the page because of their length. The lines in the actual download file do not, in fact, have line breaks in them.

Figure D-1: Sample Download File

```
/* Test 7000 ACU download*/  
  
/*Lock ACU*/  
O00▲  
  
/*Erase Employee and Schedule Files*/  
LEE01▲  
LSE01▲  
LBE01▲  
  
/*Set Date & Time on ACU*/  
T00030716132300▲  
  
/*Set Beeper Enable*/  
LBP011▲  
  
/*Enable Anti-PassBack*/  
LAP010▲  
  
/*Set Configuration Parameters*/  
LPB00001▲
```

```

/*Setup RS485 Ports*/
/*C0060▲*/

/*Set Relay Activation Time, DO1 & DO2*/
LPB0330003000▲

/*Set Digital In Timeout*/
/*LPB05060060▲*/

/*Set Schedule Start*/
LSB01010101▲

/*Set download ID*/
D1012345678▲

/*Set Daylight Savings*/
/*T20030328▲*/

/*Set Badge Filtering*/
/*LPB0455▲*/

/*Load Schedule File*/
LSC01001 0054001020 0192002460 0236003900 0480005340 0624006780▲
/* Next line wraps on page; treat as a single line */
LSC01003 0000000360 0144001800 0288003240 0432004680 0576006120 0720007560
0864009000▲
LSC01002 0108001300 0252002740 0396004180▲
LSC01004 0006000120▲

/*Set Validation*/
LEB011000          000▲

/*Load Employee File*/
LEC0100000000000010001▲
LEC010000001234560001▲
LEC010000000013780001▲
LEC0100000000000090001▲

/* Load Bell Schedules (LBC01dmmmmtt) */
/* Next line wraps on page; treat as a single line */
/*LBC01100613000623000633000643000653000663000673000683000693000703000713000723
0007330007430007530007630007730007830007930008030▲*/

/*Request Time & Date from ACU*/
T10▲

/*Request Download ID*/
D20▲

/*Request Program Number*/
S00▲

/*Request Number of Badges & Schedules*/
S01▲

/*Unlock ACU*/
O10▲

```

A

AccuComm 1-14
ACU, Access Control Unit
Alarm, wiring 2-10
ALDI1 command 3-31
ALDI2 command 3-31
ALSTATE command 3-32
ALTAMP command 3-33
Anti-passback 1-12
 enable 3-7
AQ10 command 3-5
Auto-schedule 3-22

B

BA01 command 3-33
BA02 command 3-34
Bad beep 1-3
Badge masking and validation 3-18
Bar code reader 1-14
Barcode readers B-7
Battery status inputs B-2
Beeper 1-3
 "bad beep" 1-3
 "good beep" 1-3
 turning on "bad beep" and yellow LED 3-26
 turning on "good beep" 3-26
 turning on "good beep" and green LED 3-26
BELL command 3-26

Bell schedules

 erasing 3-24
 handling 3-24
 loading 3-24
BG00 command 3-34
BG01 command 3-35
BS00 command 3-36
BS01 command 3-36
BS02 command 3-37
BS03 command 3-38
BS04 command 3-38
BT01 command 3-39

C

C00 command 3-5
Cabling 2-3
Cabling accessories 2-4
Character representations xii
Clear RAM queue 3-11
Commands
 ALDI1 3-31
 ALDI2 3-31
 ALSTATE 3-32
 ALTAMP 3-33
 AQ10 3-5
 BA01 3-33
 BA02 3-34
 BELL 3-26
 BG00 3-34

BG01 3-35
BS00 3-36
BS01 3-36
BS02 3-37
BS03 3-38
BS04 3-38
BT01 3-39
C00 3-5
D10 3-6
D20 3-6
DC100 3-28
DC101 3-28
DC111 3-28
DC200 3-29
DC201 3-29
DC211 3-29
DI00 3-39
LAP01 3-7
LBC01 3-24
LBE01 3-24
LDA01 3-7
LEB01 3-18
LEC01 3-16
LED01 3-17
LEE01 3-16
LHO101 3-22
LPB01 3-7
LPB03 3-8
LPB04 3-8
LPB05 3-9
LSA01 3-9
LSB01 3-20
LSC01 3-21
LSD01 3-22
LSE01 3-20
O00 3-10
O10 3-10
P.... 3-40
R00 3-11
R01 3-11
S00 3-11
S01 3-12
S02 3-12
S03 3-13
S04 3-13
SI 3-26
SO 3-26
T00 3-14
T10 3-14
T20 3-14

Communications adapter 2-4
Control characters xii
Conventions, used in document xi

D

D10 command 3-6
D20 command 3-6
DC100 command 3-28
DC101 command 3-28
DC111 command 3-28
DC200 command 3-29
DC201 command 3-29
DC211 command 3-29
Delete individual schedules 3-22
DI00 command 3-39
Digital IN timeout 3-9
Digital inputs, set active/inactive 3-7
DIP switches
 setting 2-11
 settings B-3
Door lock/release operation (DO1) 1-11
Dynamic link library files 1-14

E

Employee file
 erasing 3-16, 3-17
 handling 3-16
Employee records, loading 3-16
Employee transaction messages 3-40
Erase all schedules 3-20
Erase bell schedules 3-24
Erase employee file 3-16, 3-17

F

Field separator xii
Firmware 1-4

G

Good beep 1-3
Group separator xii

H

HID Proxpoint reader wiring B-6
Holiday schedules, loading 3-22
Host communications 1-14

I

Interactive commands 3-26

J

Jumpers 1-4
 setting 2-13

K

Keypad 1-15
Keypad 7000/103 wiring B-5

L

LAP01 command 3-7
LBC01 command 3-24
LBE01 command 3-24
LDA01 3-7
LDA01 command 3-7
LEB01 command 3-18
LEC01 command 3-16
LED01 command 3-17
LEE01 command 3-16
LHO101 command 3-22
Load bell schedules 3-24
Load employee records 3-16
Load holiday schedules 3-22
Load schedules 3-21
LPB01 command 3-7
LPB03 command 3-8
LPB04 command 3-8
LPB05 command 3-9
LSA01 command 3-9
LSB01 command 3-20
LSC01 command 3-21
LSD01 command 3-22
LSE01 command 3-20

M

Magnetic stripe reader 1-15
Master badge
 default 1-10, 1-13
 using 1-13
Master badge number, setting 3-9
Messages
 employee transaction 3-40
Modes
 online 1-8
 online, dual door 1-8
 standalone 1-8, 1-13
 test 1-7

N

Network booster 2-5
Network junction box 2-4
Network junction box junior 2-5
Network terminal block 2-5

O

O00 command 3-10
O10 command 3-10
Online mode 1-8
 dual door 1-8
Operating modes 1-7

P

P... command (employee transaction messages) 3-40
Passback 1-12
Passback (anti-passback enable) 3-7
Port splitter 2-4
Power 2-3
Power fail 1-4
Power input connector 12V B-1
Proximity reader 1-15

R

R00 command 3-11
R01 command 3-11

RAM queue, clearing 3-11
RAM queue, resetting 3-11
Reader 7000/101 & 102 wiring B-4
Reader/keypad connections B-4
Readers
 bar code 1-14
 magnetic stripe 1-15
 proximity 1-15
 wiring 2-7
Record separator xii
Relay activation time, setting 3-8
Relays
 controlling 3-28
Reset 1-8
RS232 network B-1
RS-232 to RS-485 converter 2-4
RS485 network B-2
RS485 port configuration 3-5

S

S00 command 3-11
S01 command 3-12
S02 command 3-12
S03 command 3-13
S04 command 3-13
Schedules 1-11
 deleting individual 3-22
 erasing 3-20
 erasing bell 3-24
 handling bells 3-24
 loading 3-21
 loading bell 3-24
 loading holiday 3-22
 setting start date 3-20
SI command 3-26
SO command 3-26
SOH, used as argument separator xii
Standalone mode 1-8, 1-13
Standalone validation table 1-10
Subscripts, meaning xi
Switches 1-3

T

T00 command 3-14
T10 command 3-14

T20 command 3-14
Tamper switch 1-3
 wiring 2-10
Test mode 1-7
Transaction message 3-40

U

Unit separator xii
Unlock ACU 3-10

V

Validation table 1-10
 online download 1-10
 standalone 1-10
Vcc, +5V 1-2

W

Wiring
 alarm 2-10
 readers 2-7
 tamper switch 2-10