



Flightdeck Avionics

User Manual

Version 1.00

16/05/2008



Table of Contents

Introduction.....	3
The Quick Start Guide.....	4
DEMO MODE and Activation.....	5
Update License.....	6
Server.....	6
Network connectivity.....	6
TCPIP Ports.....	6
TCP_Client.exe.....	6
Configuration.....	7
AVIONICS.EXE.....	8
CONFIG.INI.....	10
CDU.EXE.....	11
Navigation Data.....	14
SERVER.EXE.....	15
Main Control Panel.....	17
Server Options.....	17
FSUIPC Interface – also see menu FSUIPC I/O Interface.....	18
ACARS.....	18
System.....	19
EFIS.....	19
TCAS.....	20
Additional Systems.....	21
Internal Flight Controls.....	23
Aircraft Specific.....	24
Aircraft Details.....	25
Start Sequence:.....	27
System Logic.....	29
Terrain.....	30
FSUIPC I/O Interface.....	32
FSUIPC INPUT Offsets.....	33
FSUIPC OUTPUT Offsets.....	33
FSUIPC Fight Controls Values.....	34
FSUIPC MCP Values.....	34
Activation.....	35
Version Information.....	35
Additional Server Functions.....	36
Aircraft Gate PushBack.....	36
B777_MCP.EXE.....	37
B777_Panel.EXE.....	38
TERRAIN.EXE - (Terrain and Weather Radar).....	42
SOUND.EXE.....	44

Introduction

Sim-Avionics Flightdeck Avionics are designed to accurately simulate the avionics and systems of a modern glass cockpit aircraft.

The applications are designed to be run on multiple computers across a network using a TCPIP Protocol, although the software can run on a single computer if the hardware specification will allow.

The software is available under two separate licence schemes: Professional and Home-User. Please contact Sim-Avionics sales for any form of professional usage or application. If in any doubt it is better to check first rather than run into a licensing problem at a later date.

In order to use the software some knowledge of flying or appropriate training manuals will be required further to this software set-up manual. This manual will not in anyway discuss aircraft operations or training. It won't (for example) teach you how to operate a CDU or MCP. The software is highly detailed and requires that the user must either have prior knowledge of similar avionic operations or use the software in conjunction with appropriate training manuals.

As a general rule, none of the information herein and none of the software can be used for real world aviation or navigation. The software is by no means to be considered complete concerning any of the respective aircraft's real systems and operation. The software is designed to give familiarization of those aircraft modeled.

The applications are based on a Client/Server principle meaning that the Server application is the 'main brain' of the system. The other programs are all clients that connect to the Server. Clients receive all of their data from the Server.

The Server is the interface to Flight sim and therefore must be able to connect to flightsim. This is achieved via **FSUIPC** (if the Server is run on the FS PC) or via **WideClient** (if the Server is run on a separate PC to FS). FSUIPC and WideClient are additional programs written by Pete Dowson www.schiratti.com/dowson.html

The Server also contains all of the System Logic and Autopilot Functions.

It is possible to evaluate the basic functions of this software without FlightSim Running

If you find technical errors in this manual please e-mail: support@sim-avionics.com

The Quick Start Guide

[The programs can be started in any order.]

1. The installer will execute \TCP_Client\TCP_Client.exe and ask for the Server IP Address
2. At the Prompt enter the Server IP Address. (The IP Address of the PC that will run the Server Application)
3. Run [Avionics.exe] (icon) - At the prompt select the displays that you want to run
4. Run the Server.exe
5. Press the 'Quick Start' button on the Server Program.
6. Use F1-F7 to enable/disable PFD/ND/EICAS/MFD/Stbys
7. Press F9 to set all windows to the default size and position
8. Use 'A' to select a window to resize
9. Use the arrow keys and numpad - + to resize the selected window. Hold CTRL to increase movement.
10. press 'S' to save the current window sizes and positions to DISPLAY.INI
11. Launch other Clients as desired.

Any additional program files are automatically created when the main .exe is first run.

*** Please be aware that if you are running 'Windows Vista' then depending on which folder location you installed the programs you may have to change the folder permissions and enable 'full control' to the "Sim-Avionics" and sub folders. This is due to Vista's UAC (User Account Control) and will prevent the automatic creation of various config files ***

DEMO MODE and Activation

Without an Access Key the Flightdeck Avionics Suite will run in DEMO MODE.

Demo Mode is fully functional with the following exceptions :

- Programs will shutdown after 20 minutes of runtime. They can be restarted.
- Limited geographical test area:

Default Airport = EGCC Manchester, UK
Default Area = Aprx 80 miles around Manchester


	Latitude		
	54.0		
Longitude	-3.0		-1.5
	52.9		

Below 10,000 ft

- Only : Status, Electical, Ground Camera and Maintenance MFD Synoptics Available

Flight Sim is NOT required to test the DEMO, but functionality will be limited. In this scenario you can press 'T' in the AVIONICS.EXE to see some gauge movement.

When starting an unregistered version of the Server you will see this screen.



Select the "Cancel or Demo Mode" button to run the applications in DEMO MODE.

This screen is also used to 'activate' the server once a license has been purchased. Activation involves

1. Purchasing a license from www.sim-avionics.com
2. Running the Server and sending an email to register@sim-avionics.com **From** the email address used to purchase the license in Paypal containing
 - Your unique Computer ID as displayed in the activation window.
 - The 'Registration Name' that you wish to register the product to.
3. Once verified we will send you (via return email) a unique Activation Key.
4. You should enter the 'Registration Name' and 'Activation Key' into the appropriate boxes and press OK.
5. You should receive an "Application Successfully Registered" message
 Your registration name and activation key are then stored in a new file within the Sim-Avionics\Server\ folder called **SERVER.SET**

When Flightsim is running and the Server is connected - Press 'Quick Start'. This will position the aircraft on the runway at Manchester with the basic systems enabled.

If you want to start the aircraft systems yourself via the overhead panel then you will need to manually position the aircraft within the DEMO area (EGCC – Manchester, UK) .
Do not press 'Quick Start' after starting the Server.

Update License

Your Activation Key is unique to your Computer ID and Registration Name and will entitle you to run new versions of the Server up to **one year** from purchasing the license.
After this time you will not be able to run newer versions of Server.exe.

Your existing versions prior to your license expiration will continue to run.

Visit www.sim-avionics.com to extend your update license.

Server

This is the centre of the Flightdeck Avionics Suite.
All of the clients connect to the server from which they send and receive all of their data.

Network connectivity

By default data is transferred via a mixture of TCP and UDP protocols.
But you can set the system to only use TCP by adding
FD_PROTOCOL=tcp
into the CONFIG.INI in the \TCP_Client Folder

TCPIP Ports

If you are running firewalls on your PC's then you may need to unblock the ports used by the avionics programs. You will need to open ports **689-699**

TCP_Client.exe

When a 'client' program is executed it checks that TCP_Client.exe is running and will execute it as necessary.

TCP_Client.exe is used to receive data from the 'Server'.

When TCP_Client is run it checks for the existents of **CONFIG.INI** in the \TCP_Client folder.

If it doesn't exist then a popup will be displayed asking for the 'Server' IP address.

(This is the IP Address of the PC that will be running the 'Server' program. 127.0.0.1 is the default and can be use if the 'Server' and client will be run on the same PC)

TCP_Client is executed automatically at the end of the install to generate this initial CONFIG.INI.


Configuration

Our avionics suite is designed to run on multiple computers over a TCP/IP network.


You can run everything on as many PC's as you want, dual monitors are also supported. It is possible to run everything on a single PC, but for performance we recommend that you run Flightsim on a separate PC.

Here are a couple of configuration examples:

Example1 : Avionics running on one PC and Flight sim on another.



Example 2 : Here we've split the functions for use in a full cockpit. Note, we haven't shown the Sound Module, Weather, MCP or Panel Sim as these are optional and can be run anywhere.



AVIONICS.EXE

This is the client program that displays the PFD, ND, EICAS, MFD and Standby Instruments.



If you have purchased a 'Lite' or 'Captain Only' license then you will only be able to run one instance of the avionics program. This will also be limited to run in CAPTAIN mode. If you try and run a second instance of Avionics.exe then the applications will terminate.

If you have purchased a 'Full' or 'Pro' license then an unlimited number of avionics clients can be run in CAPTAIN or FO mode.

All of the avionics functions are controlled via the server and can be mapped to FSUIPC offsets. But the initial configuration will need to be made via a keyboard.

To help you configure the avionics, when executing the application for the first time a popup will ask you which instruments you wish to display and if this is to be a CAPTAIN or FO version. Make your selection and press OK after which a CONFIG.INI will be created in the Avionics directory. Once a CONFIG.INI has been created you will need to manually edit this file to switch between Captain and FO versions.

If you have an F/O license, to enable the PFD and ND in F/O Mode you can edit the CONFIG.INI and set the line :

```
[SETTINGS]
POSITION=FO
```

Valid options are **CPT** = CAPTAIN or **FO** = First Officer

At any time in the avionics application you can press **F11** to display the keyboard shortcuts help page:

Keyboard shortcuts :

- F1 : PFD (Enable / Disable)
- F2 : ND (Enable / Disable)
- F3 : EICAS (Enable / Disable)
- F4 : Standby Attitude (Enable / Disable)
- F5 : Standby Airspeed (Enable / Disable)
- F6 : Standby Altitude (Enable / Disable)
- F7 : MFD (Enable / Disable)

F9 : Default display window sizes
 F11 : Display Key Help

Display Resizing and Positioning

A = Cycle through the displays for adjustment
 Q = Reset Size and Position of the selected display
 Arrow Keys = Move Selected Display
 Num Pad - = Reduce Selected Display Size
 Num Pad + = Increase Selected Display Size
 Hold CTRL to increase movement

Additional Keys:

0-9 = MFD Synoptics
 Space Bar = Alternates between Single or Dual Monitor display
S = **Save Window Positions and Sizes to DISPLAY.INI**
 F = Display Frame Rates
 T = Simple Test Mode
 P = Reset Application position to top-left of the screen
Escape = **Close Application**

All avionics display positions and sizes are stored in a DISPLAY.INI after pressing 'S' but can be manually edited if necessary. If this file is deleted then a new one will be created when the avionics application is next run.

Editing \Sim-Avionics\Avionics\CONFIG.INI

CONFIG.INI

[SETTINGS]	
MAIN_TIMER=10	The main program loop time in ms
// Position=CPT or FO (for PFD/ND only)	
POSITION=CPT	Captain or FO position
// *** MFD PARAMERTERS ***	
// L =left 90 degs	
// R = right 90 degs	
// U = upsidedown rotate 180 degs	
// C = normal	
MFD_ORIENTATION=C	Mouse Orientation for Checklist
MFD_TIMER=100	Separate MFD loop Timer - Resource Saver
//NAV_DATA_PATH=..\CDU\Data	Map a custom path to the Navdata
USE_FONT=1	Use TTF Fonts
FONT_NAME=verdana	Install TTF Font
FONT_STRENGTH=550	Font Strength
FONT_SIZE_ADJUST=-0.3	Additional Font Sizing
ADD_FONT_OUTLINE=1	Add a black outline around the font
// 0..255	
BACKGROUND_R=0	Background Color Red
BACKGROUND_G=0	Background Color Green
BACKGROUND_B=0	Background Color Blue

```

// = PFD or ND or EICAS or STBY_ATT or STBY_AIR or STBY_ALT or ALL
TAKE_SCREENSHOT=NONE           Take a Screenshot of the displays
// In Seconds
SCREENSHOT_OUTPUT_TIME=10      Interval between Screenshots in Sec's
// Creates: PFD.jpg, ND.jpg, EICAS.jpg, STBY_ATT.jpg, STBY_AIR.jpg, STBY_ALT.jpg
SCREENSHOT_FILENAME=\\127.0.0.1\b777_webcam Output Filepath

[ENGINE]
EGT_START_MAX=700             EGT Hotstart Max line before engine start

DISPLAY.INI


WINDOW_WIDTH=979              Main Window Width
WINDOW_HEIGHT=772             Main Window Height
WINDOW_LEFT=0                  Main Window Left
WINDOW_TOP=0                   Main Window Top
MAXIMIZED=0                    Application is Maximized
BORDER=1                       Application Borders Displayed
DISPLAY_PFD=1                  PFD Enabeld
DISPLAY_ND=1                   ND Enabled
DISPLAY_EICAS=0                EICAS Enabled
DISPLAY_STBY_ATTITUDE=0        Standby Attitude Indicator Enabled
DISPLAY_STBY_AIRSPEED=0        Standby Airspeed Indicator Enabled
DISPLAY_STBY_ALTITUDE=0        Standby Altitude Indicator Enabled
DISPLAY_MFD=1                  MFD Enabled
PFD_X=0                        PFD Left Position
PFD_Y=0                        PFD Top Position
PFD_WIDTH=366                  PFD Width
ND_X=486                       ND Left Position
ND_Y=0                         ND Top Position
ND_WIDTH=366                   ND Width
EICAS_X=486                    EICAS Left Position
EICAS_Y=0                      EICAS Top Position
EICAS_WIDTH=486                EICAS Width
STBY_ATT_X=364                 Standby Attitude Indicator Left Position
STBY_ATT_Y=0                   Standby Attitude Indicator Top Position
STBY_ATT_WIDTH=162             Standby Attitude Indicator Width
STBY_AIR_X=364                 Standby Airspeed Indicator Left Position
STBY_AIR_Y=162                 Standby Airspeed Indicator Top Position
STBY_AIR_WIDTH=162            Standby Airspeed Indicator Width
STBY_ALT_X=364                 Standby Altitude Indicator Left Position
STBY_ALT_Y=324                 Standby Altitude Indicator Top Position
STBY_ALT_WIDTH=162            Standby Altitude Indicator Width
MFD_X=252                      MFD Left Position
MFD_Y=368                      MFD Top Position
MFD_WIDTH=366                  MFD Width

// Screen Rotation in Degrees
ROTATE_PFD=0                   Rotate PFD by x Degrees
ROTATE_ND=0                    Rotate ND by x Degrees
ROTATE_EICAS=0                 Rotate EICAS by x Degrees
ROTATE_STBY=0                  Rotate Standby's by x Degrees
ROTATE_MFD=0                   Rotate MFD by x Degrees

```

CDU.EXE

This is the client program that displays the CDU.



If you have purchased a 'Lite' or 'Captain Only' license then you will only be able to run one instance of the CDU program. This will also be limited to run in CAPTAIN mode. If you try and run a second instance of CDU.exe then the applications will terminate.

If you have purchased a 'Full' or 'Pro' license then an unlimited number of CDU clients can be run in 1xCAPTAIN, 1xFO and unlimited OBS modes (OBS in Pro License Only).

After executing the program for the first time a CONFIG.INI will be created in the CDU directory.

If you have an F/O license, to enable the CDU in F/O Mode you can edit the CONFIG.INI and set the line :

```
[SETTINGS]
POSITION=FO
```

Valid options are **CPT** = CAPTAIN or **FO** = First Officer

The alpha numeric keys (A-Z and 0-9) are mapped to the keyboard as normal.

The 'line select keys' are mapped to the Function keys (F1-F12)

The Left Line Select Keys = F1-F6

The Right Line Select Keys = F7-F12

The other CDU Menu keys can be custom mapped in the CONFIG.INI

CONFIG.INI

[NAVDATA]
//NAVDATA_PATH=..\Navigation_Data

Make a custom path to the Navdata

[SETTINGS]
// = CPT or FO or OBS
POSITION=CPT

CDU Position

EVENTS_TIMER=500

Internal Events Loop Timer in ms

[ACARS]
PROXY_NAME=
PROXY_PORT=
PROXY_USERNAME=
PROXY_PASSWORD=

**Proxy Server Name
Proxy Server Port
Proxy Server UserName
Proxy Server Password**

[AIRLINE_POLICY]
DERATE1_PERCENT=5
DERATE2_PERCENT=15
GA_DERATE_PERCENT=5
CON_DERATE_PERCENT=10
CRZ_DERATE_PERCENT=12

**% Derate 1 Thrust from T/O thrust
% Derate 2 Thrust from T/O thrust
% Derate Go-Around from T/O Thrust
% Derate Continuous Thrust from T/O
% Derate Cruise Max from T/O thrust**

CLB_TRANSITION_SPEED_RESTRICTION=250
CLB_TRANSITION_ALTITUDE_RESTRICTION=10000
ECON_CLIMB_SPEED=310
ECON_CRUISE_SPEED=0.84
DES_TRANSITION_SPEED_RESTRICTION=240
DES_TRANSITION_ALTITUDE_RESTRICTION=10000
TRANSITION_ALTITUDE=18000

**Default Transition Speed
Default Transition Altitude
Default ECON CLB Speed @CI 100
Default ECON Cruise Mach @ CI100
Default Descent Transition Speed
Default Descent Transition Altitude
Default Transition Altitude**

; 1,5,15 = Flap defaults
; > 15 = Height defaults
THRUST_REDUCTION_DEFAULT=1500
MAX_FUEL_LEFT_WEIGHT=30000
MAX_FUEL_CENTRE_WEIGHT=81100
MAX_FUEL_RIGHT_WEIGHT=30000

**Default Thrust Reduction Flaps or Alt
Left Tank Max Fuel (Tonnes)
Centre Tank Max Fuel (Tonnes)
Right Tank Max Fuel (Tonnes)**

[USER]

FULL_SCREEN=0

FullScreen or Frontend mode

WINDOW_WIDTH=650
WINDOW_HEIGHT=520
WINDOW_ROTATE=0
ROTATE_X=500
ROTATE_Y=380

**Fullscreen Window Width
Fullscreen Window Height
Fullscreen Rotation (degrees)**

FONT_LARGE=Sim-Avionics-CDU
FONT_SMALL=Sim-Avionics-CDU

**Installed TTF Font for Large text
Installed TTF Font for small text**

[FULLSCREEN]

Full Screen Settings

LINE1=120
LINE2=220
LINE3=320
LINE4=420
LINE5=520
LINE6=620
TITLE=10
PAGE=25
LINE_MARGIN_LEFT=84
LINE_MARGIN_RIGHT=940
LINE_T_MARGIN_LEFT=130
LINE_T_MARGIN_RIGHT=870
SCRATCHPAD=690

**Line 1 Vertical Position
Line 2 Vertical Position
Line 3 Vertical Position
Line 4 Vertical Position
Line 5 Vertical Position
Line 6 Vertical Position
Title Vertical Position
Page Number Vertical Position
Left Margin Horizontal Position
Right Margin Horizontal Position
Left Ref Margin Horizontal Position
Right Ref Margin Horizontal Position
Scratchpad Vertical Position**

FONT_SIZE_LARGE_FULL=36
 FONT_SIZE_SMALL_FULL=38
 FONT_SIZE_REF_FULL=32

Font Size Large Text
Font Size Small Text
Font Size Ref Text

; ctrl + shift + alt + xxx key number
 KEY_PROG_EXIT=001081
 KEY_CLR=000008
 KEY_NEXT_PAGE=000033
 KEY_PREV_PAGE=000034
 KEY_INIT_REF=100112
 KEY_ROUTE=100113
 KEY_DEP_ARR=100114
 KEY_ALTN=100115
 KEY_VNAV=100116
 KEY_FIX=100117
 KEY_LEGS=100118
 KEY_HOLD=100119
 KEY_FMC_COMM=100120
 KEY_PROGRESS=100121
 KEY_MENU=100122
 KEY_NAV_RAD=100123
 KEY_EXECUTE=000110

Key Assignments

[WINDOWED]

Non fullscreen defaults - Same as above

Defining Key Presses

// ctrl + shift + alt + xxx key number

The first 3 chars determine if **CTRL**, **SHIFT** or **ALT** should be held down during the key press.

The last 3 chars are the key number to assign.

0000**65** = a
 1000**65** = ctrl+a
 0100**65** = shift+a
 0010**65** = alt+a
 1100**65** = ctrl+shift+a

Navigation Data

Navigation Data for the CDU and ND is held centrally in the **sim-avionics\Navigation_Data** folder. Place new Navigation databases in here.

The base package comes with some limited Navigation Data, but the full version can be purchased at www.navigraph.at

The flightdeck package is compatible with the
'Wilco-Feel There 737/777, Airbus Series, ERJ, Legecy, CitationX' "nd.mdb"

Place the nd.mdb in the **\Navigation_Data** folder.

SERVER.EXE

This is the main Server window. It is split into several area's

The screenshot shows the Sim-Avionics Server interface. At the top, there's a menu bar with options like Server, System, Aircraft Specific, System Logic, Terrain, Version Information, FSUIPC I/O Interface, and Activation. Below the menu is a banner for 'sim-avionics' with the tagline 'The Ultimate Flightdeck Experience' and a 'Register' button. The main area is divided into several sections:

- Server Info:** Displays 'Server IP = 43.195.102.240', 'Data Send Loop = 50 ms', and 'Data Send Rate = 0 fps'. A yellow bar indicates 'Flight Sim NOT Connected'. Buttons for 'Reconnect FS', 'Last State', 'Quick Start', 'Shutdown', 'Time Sync', and 'Initial State' are present.
- System Status:** Shows 'DEMO MODE - DATA BLOCKED (A/C OUT OF DEMO AREA)' and 'TIME: 19:54'. It includes a 'Bank Limit' control set to -30 and a 'Sound Test' button.
- Connected Clients & Versions:** A table listing connected clients with columns for 'Current Version' and 'Latest Version'. Clients listed include Captains PFD/MD, Captains CDU, MFD, Sound Module, Terrain Gen, Panel Simulator, MCP, OBS CDU, Instructor Station, Joystick Interface, and EPIC Link.
- Log:** A scrollable text area showing system messages like 'Network Detected' and 'Flight Sim Not Detected'. It also displays version information for the server and clients.
- Main Ctrl Buttons:** A set of buttons for 'Stop ALL', 'Client Stop', 'Client Restart', 'Client Kill', and 'Client Restart'.
- Client PC control:** A grid of buttons for controlling various client components like PFD, CDU, MFD, SOUND, EPIC, JOYSTICK, TERRAIN, and INSTRUCTOR.
- PFD FMA:** A section with 'init' buttons for different client components.
- Pushback Ctrl:** Controls for 'Start Pushback', 'Dist' (50), 'Degs Left' (0), 'Degs Right', and 'Cancel Pushback'.
- Door ctrl:** A section with 'A', 'I', and 'O' buttons.
- A/C Info:** A list of aircraft parameters such as Thrust Mode, FMC Thrust Ref, FMC Heading, FMC Altitude, FMC V/S, FMC Bank Angle, FMC Cruise Alt, HDG / TRK Mode, Track, Mag Var, Latitude, Longitude, Altitude FT, Commanded Speed, TOC Dist, TOD Dist, VNAV VS, VNAV ALT, and Airport Elev.

- Shutdown** : Closes the Server.
- QuickStart** : Switches on the main Aircraft Systems.
(Will position the aircraft to EGCC – Manchester, UK in DEMO mode)
- Cold and Dark** : Switches OFF the Aircraft Systems.
- Last State** : Load the Server State from the Server Backup Files.
- Initial State** : Load the Server State from INITIAL_STATE.INI
- Reconnect FS** : Tries to Reconnect to FSUIPC or WIDECLIENT
(Used if FS or WideClient is started after the Server.)
- Time Sync** : Set's Flight Sim Time to the current Server PC Time.
- Server IP** : IP Address of the Server.
- Data Send Loop** : Time in milliseconds that critical flight data is sent.
- Data Send Rate** : Actual critical data send rate per second.


Flight Sim NOT Connected : The server was not able to establish a connection to Flight Sim. Check Flight Sim or WideClient is running press <Reconnect FS>

DEMO MODE – DATA BLOCKED (A/C OUT OF DEMO AREA) :

The Demo Mode is limited to a geographical area around EGCC Manchester, UK. If you fly out of this area then the flight data transfer will stop. It will restart when you fly back into the demo area.

Time : DEMO MODE has a 20 minute time limit. This shows amount of Demo Time Remaining.

Main Control Panel



Server Options

Enable State Backup : Every 20 seconds the current server state is saved to file
 SERVER_STATUS.DAT = System Data
 SERVER_CRITICAL_STATUS.DAT = Flight Data
 SERVER_CDU_HDR_STATUS.DAT = CDU Data
 SERVER_CDU_RTE_STATUS.DAT = CDU Route Data

Enable Auto Door Logic : Cabin Doors open automatically when:

- Aircraft is on the ground
- Doors are in 'Manual' status
- Both engines are SHUTDOWN
- Parking brake is Set

Enable Internal Flight Controls : Generally if you have joysticks connected directly to FlightSim then this should be OFF
 If you have I/O hardware writing 'pot' positions to FSUIPC offsets then this functionality can be used to manipulate the flight controls.
 These are configured under the >System > Flight Controls menu

Enable System Logic : This enables the internal system logic and would usually be switched ON.

Load "Initial State" on Startup : Sets the initial system switch positions during Server Start using settings from INITIAL_STATE.ini

FSUIPC Interface – also see menu FSUIPC I/O Interface

Use MCP Values

: If external I/O hardware is being used this will map FSUIPC offset values to the internal MCP values.
If you are using the MCP frontend client then this can be set OFF.

Use Flt CTRLS Values

: If external I/O hardware is being used this will map FSUIPC offset values to the internal flight controls.

Use INPUT Offsets

: If external I/O hardware is being used this will map FSUIPC offset values to the internal switch status.

Use OUTPUT Offsets

: If external I/O hardware is being used this will map internal values to FSUIPC offsets.

ACARS

Enable ACARS

: Used to enable ACARS functionality.
POS REP
ETA Times
ACARS Messaging
CPLDC Messaging to ATC ground station (coming soon)

ACARS Webserver

: Preferred ACARS service.
Sim-Avionics provides this web service but others can be used.
(Protocol based on ACARS system developed by
Jeroen Hoppenbrouwers (www.hoppie.nl))

ACARS Logon ID

: For Sim-Avionics server this is your unique computer ID.

ACARS PROXY Details


: Complete these details if you use a proxy server.

System



EFIS

Provides a quick way of accessing the Glareshield EFIS and EICAS controls.



TCAS


Provides a quick way of accessing the TCAS Controls.



Various modes are provided to select how TCAS traffic is displayed on the ND's and how Audible warnings are handled.

TCAS Mode	System Mode	Squawkbox Mode
Standby	TCAS OFF	TCAS OFF
XPNDR ON	TCAS ON	TCAS ON
TFC	TCAS ON – ND Traffic Display	TCAS ON
TA	TCAS ON – Audible Warnings	TCAS ON
TA/RA	TCAS ON – Traffic Avoidance	TCAS ON

Additional Systems



FMC Control

: Selects which CDU is issuing FMC commands.

Visibility

: A quick way of setting ground visibility in miles.

WXR Radar Auto Updates

: Tells the Weather Radar generator to use Flight Sim's weather to generate weather radar images. Exact cloud position data is not available from flight sim so the weather radar image is an approximation based on the current clouds coverage.

WXR Radar Intensity

: Flight Sim Cloud coverage is assigned an intensity and weather radar images are compiled based on that intensity. These buttons allow for manual override of the intensity value.

WXR Cloud Coverage

: Tells the Weather Radar generator LOW or HIGH volumes of clouds on the weather radar.

Reset WXR Radar

: Blanks the Weather Radar and generates a new image based on the current weather intensity.

Internal Flight Controls

Flt Ctrl's will only become active after the Hyd system has been pressurized.

Control Position
Pointer = Target Position
Bar = Actual Ctrl Position

Control Calibrations

Brake Indications

AutoBrake Selection

Flight Control Positions

Internal Flight Control Emulation

Aileron [Slider]

Spoilers [Slider]

Elevator [Slider] Up / Down

Rudder [Slider]

Throttle L [Slider]

Throttle R [Slider]

MCP OFF

FLT CTRLS INACTIVE

Elevator
Elevator Enabled Offset 0 Scale -1

Aileron
Aileron Enabled Offset 0 Scale -1

Rudder
Rudder Enabled Offset 0 Scale -1

Brake
Brakes Enabled Offset 0 Scale 1

Throttle
Throttle L Enabled Throttle R Enabled Offset 0 Scale 0.2

Throttle Control:
 Individual
 Left = Both
 Right = Both

Spoilers
Spoilers Enabled Offset 0 Scale 1

Landing Gear Enabled
Flaps Enabled
Parking Brake External

* Use 'negative' Scales to Reverse Control Input

Brakes:
Left 0
Right 0

AutoBrake: OFF RTO 1 2 3 4 MAX

Aircraft Specific

Configuration specific to a particular aircraft. This information is held in a separate config file.

The default is **MELJET-B777-200.CFG**

This is used to hold (amongst other) :

- Engine Idle values
- Startup Spool time values
- Autopilot Tuning Values

The aircraft config file is loaded when the Server is started and the filename is read from the SERVER.INI

[AIRCRAFT_DETAILS]

AIRCRAFT_CONFIG_FILE=MELJET-B777-200



Load Aircraft

: Loads a different Aircraft Config File

Save Aircraft

: Saves the current Aircraft config details to the Aircraft Config File that is currently loaded.

SaveAs Aircraft

: Saves the current Aircraft config details to a different Aircraft Config File.

Autopilot Tuning

: Use to calibrate the internal Autopilot to a flight model.

Additional Aircraft Details

: Displays the additional aircraft detail menu

Aircraft Details

Additional Aircraft Details			
Engine N1 Idle Speeds			
Ground Idle	<input type="text" value="27"/>	Default T/O N1 (No CDU)	<input type="text" value="94.2"/>
Flight Idle	<input type="text" value="33"/>	Default CLB N1 (No CDU)	<input type="text" value="89"/>
Approach Idle	<input type="text" value="35"/>		
Engine Start Sequence			
N1 Target	<input type="text" value="28.5"/>	N1 Spool Time	<input type="text" value="35"/>
N2 Target	<input type="text" value="45"/>	N2 Spool Time	<input type="text" value="35"/>
EGT Target	<input type="text" value="369"/>	EGT Spool Time	<input type="text" value="23"/>
FF Target	<input type="text" value="840"/>	FF Spool Time	<input type="text" value="25"/>
Oil Temp Target	<input type="text" value="56"/>	Oil Temp Spool Time	<input type="text" value="25"/>
Oil Press Target	<input type="text" value="77"/>	Oil Press Spool Time	<input type="text" value="18"/>
Misc			
Pilot Response Time (Minutes)	<input type="text" value="10"/>	Wing AOA	<input type="text" value="3"/>
Aircraft Height	<input type="text" value="18"/>	Flight Director Wing Mode	<input type="checkbox"/>
Take Off N1 % Config Trigger	<input type="text" value="70"/>	Autoland Flare Altitude (RA)	<input type="text" value="70"/>
AUTO Seatbelts Trigger Altitude	<input type="text" value="10000"/>	Autoland Idle Altitude (RA)	<input type="text" value="40"/>
Controls			
Control Response	<input type="text" value="400"/>	Aircraft Type	<input type="radio"/> 777 <input type="radio"/> 737 <input type="radio"/> 747

Ground Idle

: Engine N1 Idle speed on the Ground

Flight Idle

: Engine N1 Idle speed in flight

Approach Idle

: Engine N1 Idle speed when flaps > 20

Please note : Idle references will only be applicable if the Internal Flight Controls are being used. A joystick plugged directly into Flight Sim will use the normal windows calibration.

Default T/O N1 (No CDU)

: Initial Takeoff N1 Thrust Ref – For LITE users
 CDU values from Thrust Ref page will overwrite this.

Default CLB N1 (No CDU)

: Initial Climb N1 Thrust Ref – For LITE users
 CDU values from Thrust Ref page will overwrite this.

Start Sequence:**N1 Target**

: Target N1 value after engine start.
After Engine Combustion is detected the EICAS N1 will spool to this value.

N1 Spool Time

: The time in seconds from engine combustion to N1 Target value.

N2 Target

: Target N2 value after engine start.
After Engine Combustion is detected the EICAS N2 will spool to this value.

N2 Spool Time

: The time in seconds from engine combustion to N2 Target value.

EGT Target

: Target EGT value after engine start.
After Engine Combustion is detected the EICAS EGT will spool to this value.

EGT Spool Time

: The time in seconds from engine combustion to EGT Target value.

FF Target

: Target Fuel Flow value after engine start.
After Engine Combustion is detected the EICAS FF will spool to this value.

FF Spool Time

: The time in seconds from engine combustion to FF Target value.

Oil Temp Target

: Target Oil Temperature value after engine start.
After Engine Combustion is detected the EICAS Oil Temp will spool to this value.

Oil Temp Spool Time

: The time in seconds from engine combustion to Oil Temp Target value.

Oil Press Target

: Target Oil Pressure value after engine start.
After Engine Combustion is detected the EICAS Oil Pressure will spool to this value.

Oil Press Spool Time

: The time in seconds from engine combustion to Oil Pressure Target value.

Pilot Response Time

: The time in minute allowed with no button activity before a PILOT RESPONSE EICAS message is issued.
After x minutes a PILOT RESPONSE EICAS message is displayed
After x*2 minutes a MASTER CAUTION is issued
After x*3 minutes a MASTER WARNING is issued

Aircraft Height

: Height (in Feet) of the cockpit above the ground – when on the ground.
This is used for Radio Altimeter Calibration

Takeoff N1 % Config Trigger

: The N1 percentage required to check for a Takeoff config warning.
A Master Warning is issued if the N1 value is above x % AND
CONFIG SPOILER : Spoilers not down
CONFIG PARKINGBRAKE : Parking brake SET
CONFIG FLAPS : Flap not in Takeoff range - (Flaps UP or > 20)
CONFIG DOORS : A door is open

Auto Seatbelt Trigger Altitude

: Altitude in Feet that Seatbelt signs are triggered if the Seatbelts Signs are set to Auto.
Below Altitude x = Seatbelts ON
Above altitude x = Seatbelts OFF

Flight Director Wing Mode

: Changes the PFD Flight director style from the single magenta bars to the FD Wing style.

Autoland Flare Altitude (RA)

: Radio Altitude in Feet that initiates a Flare during autoland.

Autoland Idle Altitude (RA)

: Radio Altitude in Feet that initiates Idle Thrust during autoland.

Control Response

: Movement sensitivity when using Internal Flight Controls.
Low values will make the control surfaces respond slower.

Aircraft Type

: Select the Aircraft Type. (coming soon)
This will appropriately change the displays and the system logic.
A License upgrade may be required for additional aircraft types.

System Logic

The screenshot shows the 'System Logic Overview' window with a menu bar at the top containing: Server, System, Aircraft Specific, System Logic (selected), Terrain, FSUIPC I/O Interface, Activation, Version Information, and About. The main window is divided into several sections:


- Top Left:** Battery (4), APU Switch (0), APU Status (99), APU Gen (4), RPM (0.0), EGT (0), Oil T (0), Oil P (0).
- Top Middle:** Bus Tie L (4), Bus Tie R (4), Sec Pwr (00), Pri Pwr (00), Volt (0.0), Amp (0.0).
- Top Right:** RAT (4), Primary (4, 4, 4, 9), Demand (4, 4, 4, 4), D Press (1, 1, 1, 1), SYS Pressure (0, 0, 0).
- Bottom Left:** DC Power (0), AC Power (0), Volt (27.9), Amp (14.98), Jettison Arm (4), Jettison L/R (4, 4), Fuel Pumps (4, 4, 4, 4, 4, 4).
- Bottom Middle:** Gasper (4), Recirc (4, 4), Packs (4, 4), Trim Air (4, 4), ISLN (4, 4, 4), ENG (4, 4, 4), Duct (0), Outflow (138, 130), Cab Alt (0), Tar Alt (0), Delta P (0.000), Rate (0), APU (4).
- Bottom Right:** ENG section with N1 (0.0), EGT (0), N2 (0.0), FF (0), O/T (0.0), O/P (0.0), Fuel Tank Used (0.00), Fuel Eng Used (0.00).

This is for information only

And is mainly used for debugging to confirm I/O Interfacing. These are the Output states of the systems.

- 0 = Off
- 1 = On
- 4 = Blank/Off
- 9 = Failed

Terrain



Reload Terrain : Triggers the Terrain and Weather Radar Program to reload the current terrain file. (Normally it shouldn't be necessary to do this)

Download Terrain : Links to <http://www.ngdc.noaa.gov/mgg/topo/globe.html>
Terrain data can be downloaded from the National Geophysical Data Center.

From this page the current path to the download page is

- [Get GLOBE Data Online]
- [Select you own area]



Choose Your Type Of Area Selection: Text-Entry Map-Based (uses a Java applet)

North (+90.0) 90.000000

West (-180.0) -180.000000 180.000000 East (+180.0)

South (-90.0) -90.000000

Export type: FreeForm ND Compression option: Individual files

Data type: int16 Transfer option: FTP

File format: PC binary

File name: UK

Unique title: My Selection

Email address(es): (recommended for large selections or home u)

Show a detailed FreeForm ND Output Format Description.

Output data will be raw binary (with little-endian—Intel PC—byte order), is about a 180 by 360 degree area data value will occupy 2 bytes. The uncompressed data file size will be 1,866,240,000 bytes.

Refresh Get Data Reset

Select Area

Give it a Name

Get Data

Terrain Continued...

Processing Complete!

Please click on the links below to download the results of your request.

- [UK.bin](#) (57,600 bytes)
- [UK.hdr](#) (705 bytes)
- [UK.fmt](#) (435 bytes)

Download the .bin and the .hdr file and save them into
.. **Sim-Avionics\Terrain and Weather Radar\Terrain**

The Terrain and Weather Radar builds a Terrain.jpg based on this data and copies the .jpg to the location specified in the program.

The file destinations on the Terrain and Weather Radar program are the Captains \Avionics folder and the FO \Avionics folder (if applicable).

FSUIPC I/O Interface



All of the functions of the avionics suite can be interfaced via FSUIPC offsets.

FSUIPC is an Inter Process Communication interface that runs as part of the flight sim process but allows a block of memory to be accessed by external applications. We can read and write to specific locations in this block of memory via 'offsets'.

An FSUIPC offset is simply a memory location in Hex format.

Some of these memory offsets are populated by FSUIPC with internal Flight sim data such as Altitude, Latitude, Heading, Airspeed. Other locations are not populated and are free for other addon programs to use knowing they will not conflict with any other process.


You can freely use offsets **5300-53FF** for Sim-Avionics

So how do you interface with the Sim-Avionics Server ? Simple...

Tell your I/O software to write a value to an FSUIPC offset when a button is pressed and then assign that offset to a function in the Sim-Avionics Server.

You assign Offsets to function via the Server FSUIPC I/O Interface menu.

Select - **[Edit I/O File]**



This window is editing a file in the server folder called FSUIPC_IO.INI

FSUIPC INPUT Offsets

In the above example offset 5300 has been assigned to the **Battery Switch**
And the server is now monitoring the value of this offset.

For switch inputs the server is expecting :
Offset value = 0 means switch = OFF
Offset value = 1 means switch = ON

There are a few additional functions that you can use when assigning an offset but I would see the simple (normal) method as being the most useful.

Syntax : **Item = offset\$invert**(1 or 0) **b**(bit 00000000)

BATTERY_SWITCH=5300 **(normal)**
(if offset 5300 = 1 then
Battery Switch = 1
else
Battery Switch = 0)

BATTERY_SWITCH=5300\$1 **(inverting)**
(if offset 5300 = 1 then
Battery Switch = 0
else
Battery Switch = 1)

BATTERY_SWITCH=5300b00000100 **(bit offset)**
(if offset 5300 = 4 then
Battery Switch = 1
else
Battery Switch = 0)

BATTERY_SWITCH=5300\$1b00001000 **(Inverted bit offset)**
(if offset 5300 = 8 then
Battery Switch = 0
else
Battery Switch = 1)

FSUIPC OUTPUT Offsets

These are assigned in the same way as input offsets, with the exception of BIT offsets.

Syntax : **Item = offset\$invert**(1 or 0)

BATTERY=5301 **(normal)**
(if battery = ON then
offset 5301 = 1
else
offset 5301 = 0)

BATTERY=5301\$1 **(inverting)**
(if battery = ON then
offset 5301 = 0
else
offset 5301 = 1)

FSUIPC Fight Controls Values

Flight controls are assigned as 2 byte (Word)

They are expecting a range of movement of -16383 to 16383 and are passed through the internal Flight Controls calibration. If you do not wish all flight controls to be passed through the internal calibrations then you can set the value = 0.

In this example our Elevator and Aileron values are being read from offsets 5304 and 5300, however Throttle_L is controlled by a joystick connected directly to flight sim and therefore needs to be left unaffected.

```
[FSUIPC_FLIGHT_CONTROLS]
ELEVATOR_CPT=5304
AILERON_CPT=5300
THROTTLE_L=0
```

FSUIPC MCP Values

MCP Values are assigned as 2 byte (Word)


```
[FSUIPC_MCP_INPUTS]
MCP_SPEED=53A0
MCP_HDG=53A2
MCP_ALTITUDE=53A4
MCP_VS=53A8
```

```
[FSUIPC_EFIS_INPUTS]
CPT_BARO=530A
FO_BARO=530C
MINIMUMS=04FA
```

MCP_SPEED works slightly differently to the other offsets. To allow this offset to also control MACH the server is looking at the *delta* difference as the value changes. Therefore it is possible for the MCP speed to be out of sync with the value in this offset.

Important

You must enable FSUIPC offset monitoring under the [Main Control Panel] menu



Activation

Activation Option is used if you are upgrading you application license.
 A backup of your existing SERVER.SET is taken as
 SERVER – ddmmyyy hhmm.SET



Version Information




Check Version : will check www.sim-avionics.com for the latest version information. It uses the internet (proxy) setting from the Main Control Panel window. This check is also performed when the Server is started.

Your current program versions and the latest versions are displayed on the Server.

Connected Clients	Current Version	Latest Version
Server	1.000	1.000
Captains PFD/ND	1.000	1.000
FO's PFD/ND		
EICAS	1.000	1.000
Captains CDU		
FO's CDU		
MFD		
Sound Module		
Terrain Gen		
Panel Simulator		
MCP	1.000	1.000
OBS CDU		
Instructor Station		
Joystick Interface		
EPIC Link		

This information is also display in the Server log



Latest Version Information

Retrieves latest version information

Additional Server Functions

Aircraft Gate PushBack

- Set a Pushback distance (Distance travelled before the Turn – aprx 150)
- Set a Pushback Bearing (The delta between your current heading and your desired final heading
-90 (or L90 on the CDU) for a pushback facing 90° to the left)
- Start Pushback

After a few seconds a 'Go Ahead' wav is played...
(Pretend to ask for pushback)

After a few seconds a 'Set Parking Brake' wav is played....
This will loop *until* the parking brake is set

- Set Parking Brake
(Pretend to confirm 'Parking Brake Set')

After a few seconds a 'Towing pin inserted – Please Release Brakes' wav is played....
This will loop *until* the parking brake is released

- Release Parking Brake
(Pretend to confirm 'Parking Brake Set')

Pushback will start

Once the turn is initiated a 'Cleared to start engines' wav is played

When the desired heading is reached pushback stops.

'Set Parking Brake' wav is played...
This will loop *until* the parking brake is set

- Set Parking Brake

'OK Towing system is removed, please wait for my hand signal on the left hand side' wav is played.

Pushback complete.

Press Cancel Pushback at any time to cancel the pushback routine..

B777_MCP.EXE

B777_MCP.exe is a 'frontend' glareshield for the B777. It does **not** contain any Autopilot logic.

You only need to run this program if you require access to the Autopilot/EFIS functions and are not interfacing via FSUIPC offsets.

Starting and Stopping this program will have no effect on the Autopilot.

There are 2 display modes, both modes display :

- Captain EFIS Panel, MCP Panel, EICAS Control Panel

But you may also enable the FO EFIS Panel.




Captain Only Mode



Captain + FO Mode

Pressing **F11** whilst the MCP has focus will display an control popup.




This will allow you to


- set the **'Autobrakes'** and view the applied brake pressures.
- Display Assigned Keypress Information.
- Enable the FO EFIS

B777_Panel.EXE

B777_Panel.exe is a 'frontend' Overhead for the B777. It does **not** contain any Systems logic.



B777 Overhead – Full View



Electrical Panel

It shows the current switch and systems status for users that do not have overhead hardware.

The panel can be dragged around using the left-mousebutton.
 You can Zoom using the mouse scroll-wheel or by using keys **R** and **T**.
 If you cannot see the panel press **O** to centre the panel.

To operate 'switches'

click on a switch with the left mouse-button.

To operate Rotaries switches

click on a switch with the left mouse-button to rotate left
 click on a switch with the right mouse-button to rotate right

The overhead is about 90% functional.

Information:

For simulation purposes the Top Left panels contain some additional switches that are not found on the real overhead.

- Engine Fuel Control switches
- External Power Primary
- External Power Secondary
- External Ground Air
- EICAS Controls

TERRAIN.EXE - (Terrain and Weather Radar)

Terrain.exe

The Terrain and Weather Radar program creates Terrain and Weather images that are displayed on the ND.

Terrain images are built from real world elevation data that can be downloaded from <http://www.ngdc.noaa.gov/mgg/topo/globe.html>

Terrain data can be downloaded from the National Geophysical Data Center.

From this page the current path to the download page is

- [Get GLOBE Data Online]
- [Select you own area]

(see section **SERVER: Terrain** for more information.)

Weather images are **NOT** an exact representation of flight sim's weather because exact cloud position information is not available. However they are build based on the current cloud coverage at you current altitude.

So if you load 'realworld' weather into flight sim then the weather radar will show a similar cloud coverage to what is being displayed in flight sim.

The \Terrain and Weather Radar\Clouds folder contains 7 256x256 cloud images. The weather radar selects several of these images based on the current cloud coverage and randomly positions and rotates to generate a radar image.

The more artistic among you may wish to custom these images.

If you have created a good set of custom cloud images and wish to share them with other users, please send them to support@sim-avionics and we will upload the one's we like.


This program is very CPU intensive as it processes large amounts of terrain data.

The program displays 4 individual windows.

The top are the Captains and FO's Terrain Radar.

The bottom are the Captains and FO's Weather Radar.

These images are regenerated as per the set 'Update Interval' and are only generated if the EFIS TERR or WXR options are selected.



When the images have been generated they are copied to the folders specified in the **File Destinations** window. The images are copied as **terrain.jpg** and **wx.jpg** and should be copied to the captains and FO's **\avionics** folder.

If you are only running a single ND then you can disable the image generation by [right-clicking] on the **CAPT ND** or **FO ND** file destination entry box.


Two terrain styles are available : Relative to Ground and Relative to Aircraft.

Relative to ground will create an image that is black at ground level and gets lighter as the ground elevation increases.

Relative to Aircraft will create an image based on the distance between the aircraft and the ground elevation.

RED – means that the aircraft is below the ground elevation.

SOUND.EXE



The Sound Module is a client that can produce the additional ambient, voice and warning sounds heard in a modern cockpit environment.

The Sound module can be run on multiple machines allowing different sounds to be played through different speakers.

For example in our B777 simulator we run 3 instances of the sound module:

1. Main Cockpit warnings
2. Cabin Calls
3. Pushback calls through cockpit headsets

To prevent certain sounds playing simply delete or rename them. If the filename doesn't exist the the sound module will ignore it.

Various sound groups have their own volume controls so that you can balance the sounds better. These values are saved to \Sound\CONFIG.INI when the client is closed.