

Gebruiksaanwijzing

User manual

Gebrauchsanweisung

Mode d'emploi

Kabola B series

with calorifier control



Kabola Heating Systems
Populierenweg 41
NL 3421 TX Oudewater

Preface

This user-manual is written to enable the safe operation of the B-series central heating boilers with integrated calorifier control. The user must read this manual before installation of the boiler and must follow the instructions within this manual.

Therefore, this manual must be kept with the boiler.

In chapter 2, the safety instructions are detailed, which have to be complied with when installing and using the boiler. In other chapters you will find safety instructions, that can be identified in the following way.

Hint: This gives the user suggestions and advice to facilitate the execution of certain tasks.

Attention: Additional information is supplied to the user, and possible problems are indicated.

Warning: Watch out for possible (life-threatening) injuries.

For any remarks, wishes or omissions you can contact your supplier of Kabola Heating Systems. We also welcome any remarks to improve this manual. We wish you a lot of pleasure from your purchase.

Kabola Heating Systems
Populierenweg 41
NL 3421 TX Oudewater
The Netherlands
Tel: +31(0)348-561277
Fax: +31(0)348-562484
Site: www.kabola.nl
E-mail: post@kabola.nl

© 2005 Kabola Heating Systems
Copying of (parts of) this manual, is only allowed with written consent Kabola Heating Systems.

Table of contents

Preface	2
Table of contents	3
1 Introduction	4
1.1 General	4
1.2 Range of application	4
1.3 Product description	4
1.4 Technical specifications	4
2 Safety	5
2.1 General safety	5
2.2 Safety instructions	5
3 Transport and storage	6
3.1 Transport	6
3.2 Storage	6
4 Installing and preparing for first use	6
4.1 Installation	6
4.1.1 Fitting the boiler	6
4.1.2 Connection to the central heating system	7
4.1.3 Connection of domestic hot water supply	7
4.1.4 Flue gas outlet	7
4.1.5 Electrical connection	9
4.1.6 Filling the central heating system	10
4.1.7 Mounting the oil burner	11
4.1.8 Connecting the oil filter and oil burner	12
4.2 Starting your system	12
5 Operating the boiler	13
5.1 Explanation of the dashboard	13
5.2 Operation of the frost guard	14
5.3 Function of the domestic hot water supply	14
6 Cleaning and maintenance	14
6.1 Points for attention	14
6.2 Cleaning and maintenance	14
7 End of life of the boiler	15
Appendix	16
Appendix A Technical specifications	17
Appendix B Spare parts	18
Appendix C Electrical diagram 230 V	19
Appendix D Electrical diagram 24 V	20
Appendix E Troubleshooting	21
Appendix F CE declaration	22

1 Introduction

1.1 General

Congatulations with your purchase of this Kabola boiler. This user-manual covers the B-series with intgrated calorifier control. The B-series with integrated calorifier control cover a wide range of boilers with a broad range of applications. By purchasing this boiler, you have acquired a product, which is of high quality through the application of the latest European standards and directives.

1.2 Range of application

The B-series boilers with integrated calorifier control are designed to generate heat for the heating of water for a central heating system. By means of the integrated calorifier control the boilers can also be used for the generation of domestic hot water through an external calorifier. This calorifier is not included in the standard boiler set. The dimensions of the rooms to be heated, have to be taken into consideration.

These boilers are not designed for direct heating of the rooms in which they are installed.

1.3 Product description

The boilers of the B-calorifier series heat the boiler water by means of a pressure jet burner which is installed on front of the boiler. The boilers are available in both 230 VAC and 24 VDC versions. The 230 VAC model requires a small 24 VDC power supply for control purposes. All B-calorifier series boilers work in the same way, they only differ in the dimensions and the capacities of the boilers (see also technical specifications in Appendix A)

For fuel, diesel oil has to be used.

1.4 Technical specifications

The most important technical specifications are listed on the plate on the front of the boiler. More technical details are listed in Appendix A.

2 Safety

In this chapter we emphasise the safety-related points for operating the boiler.

2.1 General safety

Warning: Although Kabola Heating Systems designs and produces its products according to the current safety standards, it is possible that dangers may present themselves, which could lead to injuries or damage to the boiler, if the safety instructions in this manual are not complied with.

The user must:

- Have read and understood the chapter "safety";
- Avoid any actions which may lead to dangers to his health or others;
- Avoid any actions which may lead to damage to the boiler;
- Ensure that the boiler is only used when the boiler is in sound technical condition;
- Ensure that the safety regulations are observed whilst operating the boiler.

Attention: No alterations to the boilers may be done, without the explicit written consent of Kabola Heating Systems!

2.2 Safety instructions

In this chapter we emphasise the safety-related points for operating the boiler.

MEASURES FOR A SAFE INSTALLATION

- Don't store any flammable and/or gaseous products in the room where the boiler is installed to avoid explosions and fires.
- Install the boiler in a non-humid environment on a firm horizontal base.
- Ensure that there is sufficient ventilation in the room where the boiler is installed (See also § 4.1.1).
- Make sure, before you start connecting the boiler, that the system is disconnected from the power supply.
- Only use multi-stranded wire for electrical connections.
- Do not change the + pole with the – pole of the battery (for the 24 Volt DC power supply)

MEASURES FOR A SAFE OPERATION

- Never change the settings of the burner.
- Don't use any aggressive solvents which may affect the boiler (like petrol or turpentine).
- Insulate the chimney, when it can be touched by body parts.
- Don't damage the fire bricks.
- Make sure that the boiler and burner are checked annually by a skilled expert.
- Make sure that before you start any work on the boiler that the system is disconnected from the power supply.
- Make sure that any surplus oil is collected in case of oil spillage.
- We advise you to have any maintenance or repairs carried out by skilled experts.

3 Transport and storage

3.1 Transport

Take following precautions before transporting the boiler:

- Drain the water from the boiler;
- Uncouple the fuel system;
- Remove the burner (see § 4.1.5, replacing the burner).

While transporting the boiler take following precautions:

- Don't damage the boiler, use a blanket to cover the boiler;
- Transport the boiler standing up, if this is not possible transport the boiler lying down on its back;
- For the boiler models B-25 onwards use the hoisting eye to move the boiler. This hoisting eye is located below the top of the boiler cover.

3.2 Storage

Take the following precautions when the boiler is stored for a longer period of time:

- Store the boiler and accompanying parts in a dry place;
- Dismount the burner (see § 4.1.5)
- Store the boiler standing up;
- Store the boiler on a firm horizontal base.

4 Installing and preparing for first use

In this chapter you will find directions and hints for a correct placement and fitting of the boiler and accompanying parts.

Warning: Do not store any flammable or gaseous substances in the room where the boiler is installed. This is to ensure that no explosions or fires can occur.

4.1 Installation

4.1.1 Fitting the boiler

- Install the boiler in a dry place.
- Install the boiler on a firm horizontal base.
- Make sure there is sufficient supply of fresh air in the room where the boiler is installed (see hint below).

Hint: As a rule of thumb for the ventilation openings, take 2,5 times the diameter of the flue gas outlet.

- To avoid movement secure the base of the boiler by means of spotwelds or with nuts and bolts..
- Keep a minimum distance of 250 mm behind the boiler for the flue-gas outlet (see figure 1).
- Use an earthed plug socket for connecting the 230 Volt AC versions to the power supply.




Figure 1

4.1.2 Connection to the central heating system

PIPING

Take note of the following points, when installing the piping:

- Install the piping in such a way, that the boiler (cover and dashboard) remains accessible;
- Provide enough bleeding points in places where air may collect, especially near the boiler.

Attention: Install a bleeding point near the boiler, especially when the piping does not go up.

Connect the piping to the boiler as follows (see figure 2):

1. Install the feed to the CH at outlet B of the 3-way valve;
2. Install the return of the CH on the circulation pump

Hint: You may install a shunt with pressure equaliser, when thermostatic radiator valved are applied.

Attention: The couplings in the 3-way valve are not sealed at the factory. Make sure that the couplings are sealed, preferably with hemp and fitters kit, when the system is installed.




Figure 2

4.1.3 Connection of domestic hot water supply

Connect the domestic water supply as follows (figure 2):

1. Install the hot water feed to the calorifier to outlet A of the 3-way valve;
2. Install the return from the calorifier on the return of the CH-circuit using a T-connection.
3. Connect the calorifier thermostat according to 4.1.5.

DESCRIPTION OF THE DOMESTIC HOT WATER SUPPLY

When the calorifier drops below its set temperature, the boiler will switch on the heat up the calorifier. The calorifier has preference over the central heating. When the calorifier is heated, the boiler will be run at 90°C, whatever the setting of the boiler thermostat is. Once the calorifier has reached the required temperature, the boiler will continue to heat the calorifier for another 3 minutes. When the after purge time is finished, the rest of the heat will be dumped in the CH-circuit. The time for the heat dump is set by the pump timer on the dashboard.

Attention: The calorifier thermostat must be set to 70°C.

4.1.4 Flue gas outlet

GENERAL

The flue gas outlet is an essential part of your heating installation. An incorrect flue gas outlet reduces the lifespan of your boiler considerably and has a negative impact on the efficiency. Remember when installing the flue, that even the best boiler won't work properly unless the flue is properly installed.

Warning: Because the flue gas temperature lies between 180-240°C, it is advisable to insulate the flue with heat-resistant material on those parts where contact with human body parts is possible.

For a correct flue gas outlet the following points need to be observed:

- Use the proper diameter, use a diameter equal to the diameter of the flue gas outlet on the boiler (see also technical specification).
- Use double-walled chimney pipe outside to prevent a rapid cooling of the flue gasses, which may result in condensation in the chimney.

Hint: When using an existing chimney of a larger diameter than the diameter on the boiler, you can install flexible piping of the correct diameter inside the existing chimney.

The flue can be installed in several different ways. You must carefully consider under which circumstances the boiler will be used. For sea going boats and sail boats we advise the installation of a vertical flue where the heel angles of the boat may be larger. The following installation examples are most common.




Figure 3

– **HORIZONTAL FLUE GAS OUTLET**

It is possible to fit a horizontal flue gas outlet to the boiler. The following points need to be observed:

- The maximum allowed length is 5 metres.
- Make sure that the outlet is positioned at a sufficient height above the waterline. If this is not possible use a swan neck bend in the pipe as in figure 3.
- Use the correct hull fittings for installing the flue through a hullside
- Don't use more than 5 elbows of 90°.
- Every elbow of 90° is equivalent to 1 metre straight pipe
- **When a 80x60 silencer is installed, only the last meter of the chimney may be installed using 60 mm pipe**

– **VERTICAL FLUE GAS OUTLET**

This way of installation is preferable for seagoing boats and sailing boats, because these boats encounter large angles of heel through waves and under sail. For this kind of flue gas outlet, the following points are important:

- Install a proper storm cowl on top of the chimney (this must stop rain from entering) (figure 3).
- Install deck fittings for installing the flue through a deck.
- Install a water trap (figure 4), to trap possible water caused by condensation
- Keep the chimney as vertical as possible.
- Don't use more than 5 elbows 90°.
- The maximum allowed length is 10 metres.
- Every elbow of 90° counts as 1 metre.
- Use outside double walled chimney pipe




Figure 4

Hint: To reduce the noise from flames, it is wise to install a silencer in the flue

Your Kabola supplier can provide you with all components which may be required for installation such as:

- Cowls;
- Flexible piping;
- Single and double walled chimney pipes;
- Hull and deck fittings;
- Silencers;
- Water traps;
- Insulation.

4.1.5 Electrical connection

Warning: Disconnect the power supply from the boiler before you start the installation. **The quality of 230 VAC power supply to the boiler should be as good as the power supply from a land line.**

ELECTRICAL CONNECTION

The supplied room thermostat should be installed as listed below:

- **Connecting the room thermostat** (see figure 5 and electrical diagram in Appendix C)
 1. Remove the cover of the main connector situated below the dashboard;
 2. Remove, if present, the wire between point 1 and 2;
 3. Connect point 1 of the connector to point L of the room thermostat;
 4. Connect point 2 of the connector to point L1 of the room thermostat;




Figure 5

Attention: The core diameter of the connections mentioned above must be 0,75 mm² maximum. The wires should be suitable for the voltage used.

- **Connection of the frost guard**
 1. Connect the switch to points 3 and 4 of the main connector. (Operation of the frost guard is explained in chapter 5)
- **Connection of the calorifier thermostat**

Connect the calorifier thermostat to the dedicated connections (see Appendix C)

- Electrical installation 24 VDC power supply for 230 VAC version

Warning: Never change the + pole with the - pole on the battery (see figure 5).

1. Connect point 5 of the main connector to the + pole of the battery.
2. Connect point 6 of the main connector to the - pole of the battery.
3. Replace the cover on the main connector.

When no 24 VDC power supply is available, an adapter 230 x 24 Volt may be used (Ordernr 9-I051). When a 12 VDC power supply is available a DC-converter 12 V in 24 V out may be used (Ordernr 15-P001).

The wire diameter for the supply mentioned above has to be 1 mm² for the 230 VAC version.

Attention: The calorifier and room thermostat both switch 24 VDC.

- **Electrical installation 24 VDC power supply for 24 VDC version**

Warning: Never change the + pole with the – pole on the battery (see figure 5).

1. Connect point 5 of the main connector to the + pole of the battery.
2. Connect point 6 of the main connector to the - pole of the battery.
3. Replace the cover of the main connector.

The core diameter of the wires from points 5 and 6 of the main connector have to comply with the values from the table below.

Table 1

Distance to the battery	Core diameter
± 6 metres	6 mm ²
± 10 metres	10 mm ²
± 20 metres	16 mm ²

4.1.6 Filling the central heating system

The pressure in the system should:

- Never be lower than 0,5 bar cold;
- Never be higher than 2,5 bar hot.

Follow the procedure below for filling the CH-system (see figure 6):

1. Switch off the boiler;
2. Turn nut (1) loose;
3. Install the hose connection on the opening;
4. Connect the hose with a hose clamp to the connection and slowly open the valve (2);
5. Fill the system slowly with water, until the pressure indicator indicates a pressure of 2 bar;
6. Close the valve (2);
7. Bleed the CH-system;
8. If necessary, fill with water again up to 2 bar of pressure;
9. Switch on the boiler and let the pump run for about 5 minutes;
10. Switch off the boiler;
11. Check the water pressure, if it is too low, repeat steps 5 through 10;
12. Remove the hose.




Figure 6

Hint: The CH-system can be filled with cooling fluid, suited for CH-systems (pH-value 8.5) worden gevuld.

BLEEDING THE CIRCULATION PUMP

The circulation pump can only be bled when the electrical circuit is connected, because this has to be done with a running pump

Follow the points listed below to bleed the pump (see figure 7):

1. Check if the rotor can rotate without problems by turning the pump by hand (see manual pump);
2. Loosen the screw on front of the pump 1/2 to 1 turn with a screwdriver;
3. Fasten the screw when water comes out of the opening;
4. The pump is bled.




Figure 7

Attention: When locking pump couplings are supplied with the boiler, the adjusting grooves must point towards the pump.

4.1.7 Mounting the oil burner

Hint: Check if the inspection opening on the mounting plate can be reached. If this is not the case the mounting plate can be turned 180° to reach the opening easier. For a B12 you need to saw an extra piece off the flange.

The mounting of the burner is done in the following way:

1. Place the nut for the flange bolt in the dedicated position, screw the bolt into the nut and place the gasket;
2. Mount the flange with 4 supplied M*-bolts and hand tighten these on the mounting plate. **The arrow on the flange should point upward.**

Hint: Smear some sealant in the crack in the flange to seal.

3.
 - 3.1. Measure and set the distance from the back of the gasket mounted behind the mounting plate, to the front of the flange using the table below and figure 8;

Boiler type	Distance in mm
B12-B17	60
B25-B35-B45	155

- 3.2. Scribe the distance on the burner;
 - 3.3. Push the flame tube gently in place up to the scribed position (see figure 8).
4. Lift the burner a little according to **7A** (figure 9);
5. Fasten bolt **7** (Figure 9) on the flange to clamp the burner;
6. The bolts which have been hand tightened should now be fastened using a spanner.




Figure 8

Attention: Take care that the flame tube is not damaged during installation. Repairs to the flame tube are very expensive and don't fall under warranty.

4.1.8 Connecting the oil filter and oil burner

To connect the filter to the burner follow the procedure below (see also figure 9):




Figure 9

1. Remove the burner cover (1);
2. Connect the oil pump (2) to the oil filter (3), using the included fuel hoses. Make sure that the flow directions on the pump comply with those on the filter;
3. Connect the fuel line from the tank to the filter (5A). The fuel line must have an outer diameter of 8 mm and must be made from copper or steel. The fuel line has to be connected directly to the oil tank. Correct functioning of the burner can not be guaranteed when a fuel manifold or T connection is installed;
4. Connect the plug (4) from the boiler to the burner.

Hint: When the oil tank is situated below the boiler or when the oil supply line comes from below the boiler, it is advisable to use a self bleeding oil filter. This prevents unnecessary malfunctioning of the burner. In the manual of the burner you will find an overview with the allowed dimensions of the oil supply line.

4.2 Starting your system

When everything is connected follow the procedure below:

1. Connect the boiler to the power supply,
Both the 230 VAC and the 24 VDC will need to be connected for the 230 VAC version and only the 24 VDC for the 24 VDC version.
2. Switch the boiler on with the on/off switch on the dashboard. The lamp in the switch will indicate that the system is active. This lamp is not present in the 24 VDC version. The LED on the top left of the dashboard should be lighted for both versions.
3. Set the required boiler temperature between 55 and 90°C using the boiler thermostat.
4. Set the room thermostat so that it is switched on (see manual of the room thermostat)
5. Starting of the oilburner (see figure 9):
 - 5.1. Open the valve in fuel line (5);
 - 5.2. Install the bleed hose (3C) on the bleed opening of the oil filter;

- 5.3. Open the valve on the oil filter (5A);
- 5.4. Start the oil burner;
- 5.5. The burner switches on, this will take approximately 1,5 minutes because of the oil pre-heating element;
- 5.6. Open the bleed valve on the oil filter (3B);
- 5.7. Check if oil is coming out of the hose(3C);
- 5.8. Check all oil connections for leaks;
 - 5.8.1.If the burner does not start, the control light (8) will light;
 - 5.8.2.Close the bleed valve (3B) on the oil filter;
 - 5.8.3.Wait approximately 3 minutes;
 - 5.8.4.Reset the burner by pushing button (8) and return to 5.4 (repeat if necessary).
- 5.9. Close the bleed valve(3B) when only oil and no bubbles come out of the hose;

Attention: The oil burner is tested by the manufacturer, not adjusted. The adjustment of the burner has to be done by an experienced installer, because this requires expert knowledge. To be eligible for warranty, the boiler has to be adjusted by an approved installer. Contact your Kabola supplier to make an appointment.
Never adjust the burner using your own initiative.

5 Operating the boiler

When the boiler has been started and adjusted according to 4.2, operation for the boiler is very simple.

1. The required temperature is set using the lower knob **8** (figure 10).
2. The after purge cycle of the circulation pump is set with the upper knob **7** (figure 10). This cycle can be set from 3 to 10 minutes.

The required temperature is set with the room thermostat, which controls the boiler. The calorifier thermostat controls the 3-way valve on the boiler. The operation of the room thermostat is explained in the manual of the room thermostat.

If problems arise with the operation of the boiler, you will find a list of possible problems and solutions in Appendix D.

5.1 Explanation of the dashboard

The LED's on the dashboard display the active functions of the boiler

1. This LED indicates if the control panel is connected to the 24 VDC power supply.
2. This LED indicates if the room thermostat is switched on.
3. This LED indicates if the frost guard is active.
4. This LED if the burner is active.
5. This LED indicates if the circulation pump is active.
6. This LED indicates if the 3-way valve is active, this indicates that the calorifier is heated.



Figure 10

5.2 Operation of the frost guard

The switch which is mounted on the room thermostat is used when you leave the boat and wish to switch off the central heating system. The central heating system will then only switch on when the ambient temperature falls + 5°C.

To activate the frost guard follow the procedure below (figure 11)

1. Switch the frost guard switch (1) on the side of the room thermostat to the off-position (up);
2. LED 3 on the dashboard is lighting.

If you only want to use the domestic water supply, follow the procedure below:

1. Switch the frost guard switch on the side (1) of the thermostat to the on-position (down);
2. LED 3 on the dashboard is now off.



5.3 Function of the domestic hot water supply

When the calorifier drops below the set temperature, the boiler will switch on to heat the calorifier. The calorifier has priority over the central heating. When the calorifier is heated the boiler will be run at 90°C, independent of the set boiler temperature. Has the calorifier reached its set temperature, the pump will continue to run for 3 minutes to provide heat to the calorifier, after which the rest heat will be diverted to the central heating circuit. Using the pump timer you can determine, how long the pump will keep pumping water through the central heating.

Attention: The calorifier thermostat **must be set to 70°C**.

6 Cleaning and maintenance

6.1 Points for attention

Spare parts must be ordered through your Kabola supplier. For warranty purposes only original spare parts must be used. When ordering spare parts, state the type of boiler and its serial number. Your Kabola supplier will then be able to supply the correct parts. In Appendix B, the main spare parts are listed.

6.2 Cleaning and maintenance

Warning: Maintenance and repairs should only take place when the boiler is switched off, this is because the boiler may start unexpectedly. Take the plug from the wall socket for the 230 VAC versions. Disconnect the power supply for the 24 VDC version.

Warning: Maintenance and repairs may only be performed by personnel, who have read and understood the information in this manual, preferably an expert installer or mechanic

Every week

- Drain the water from the water trap if installed

Every year

1. Clean the boiler;
 - 1.1. Remove the burner (see § 4.1.7);
 - 1.2. Remove the burner mounting plate from the boiler;
 - 1.3. Remove the top cover, **be careful not to damage the earthing wire for the 230 VAC version**;
 - 1.4. Remove the top insulation;
 - 1.5. Remove the 4 bolts on the boiler top;
 - 1.6. Remove the boiler top;

Hint: With a B-8 boiler you can remove the upper fire brick to facilitate the cleaning of the heat exchanger. When replacing the fire brick you have to be careful to fit the fire brick to the back of boiler..

- 1.7. Clean the inside of the boiler, using a stiff brush;
- 1.8. Clean the space between the heat exchanger with a thin metal strip

Attention: Do not use any aggressive solvents like thinner or gasoline.

- 1.9. Clean the boiler with a vacuum cleaner;
 - 1.10. Replace the boiler top, if necessary use a new gasket;
 - 1.11. Replace the 4 bolts and fasten these;
 - 1.12. Replace the insulation;
 - 1.13. Replace the top cover of the boiler, **make sure the earthing wire is fitted correctly**;
 - 1.14. Replace the burner mounting plate and remount the burner (see § 4.1.5).
2. Clean the chimney;
 3. Clean the watertrap if installed;
 4. Change the oil filter element
 5. Clean the burner (see manual of the burner)

Hint: Kabola Heating Systems has a standard set of replacement parts for the yearly maintenance (see Appendix B).

Attention: The old oil filter element has to be processed as chemical waste.


7 End of life of the boiler

When the boiler is scrapped, take note of the points listed below:

- Process the oil filter and the oil hose as chemical waste;
- Separate the metal from the plastic parts and dispose off them separately.
- Process any excess oil in an environmentally freindly way.
- Transport the boiler according to the instructions in chapter 3
- Recycle this manual.

Appendix

Appendix A Technical specifications




Type	B-8	B-12	B-17	B-25	B-35	B-45
A	505	600	670	970	970	970
B	343	347	411	455	455	445
C	-	115	115	115	115	125
D	356	361	416	466	468	488
E	235	243	364	283	284	284
F	320	343	408	388	491	580
G	70	70	70	70	70	70
H	310	325	325	385	385	385
I	336	361	416	396	503	593
J	400	480	548	753	754	754
	80	80	80	100	130	150
Chimney ø	80	80	80	100	125	150
Flue gas temp °C	170-190	180-240	180-240	180-220	180-230	180-230
C.H.-connection	1"	1"	1"	5/4"	5/4"	1½"
IP-value	50-11					
Burner 230 V	2-B009	2-B010	2-B011	2-B012	2-B013	2-B014
24 V	3-C012	3-C013	3-C014	3-C015	3-C016	3-C017
Nozzle 60°	0.40	0.40	0.50	0.75	1.00	1.25
Nom. Capacity kW min	8.0	11.2	14	19.7	29	40.7
max	11.0	14	19.7	29	40.7	52.3
Max oil consumption kg/h	1.2	1.4	1.9	3.3	3.7	5.2
Test pressure in bar	5	5	5	5	5	5
Working pressure in bar	3	3	3	3	3	3
Weight	50	65	94	118	140	155
Water volume	20	30	36	47	64	98
Control range temperature	65-90	65-90	65-90	65-90	65-90	65-90
Insulation thickness in mm	30	30	30	50	50	50
Fuel	HBO 1, HBO 2, diesel of gasolie					
Efficiency in %	97	91	91	92	92	92
Waterside efficiency %	94	88	88	89	90	90
Relative standby loss	3 %					

Appendix B Spare parts

Listed below you will find the most important parts for the boilers. These parts can be ordered from your Kabola supplier, please state type and serial number. The numbers refer to the image.

- | | |
|---|--|
| 1 Boiler top cover | |
| 2 Insulation | Mineral wool thickness Appendix A |
| 3 Boiler cover | |
| 4 Boiler gasket | For B8 a plate |
| 5 Maximum thermostat | 24 VAC! |
| 6 3-way valve | |
| 7 Dashboard | |
| 8 NTC-probe | |
| 9 Control PCB | KBC specification |
| 10 On/Off switch | No light in 24 VDC version |
| 11 Pump coupling | |
| 12 Circulation pump | |
| 13 Seal 5/4" | Two |
| 14 Elbow | Dependent on type (1x1", 5/4x1" or 1½x1") |
| 15 Pressure valve/ pressure gauge fill/drain cock | Wavicom |
| 16 Main connector | |
| 17 Fire inspection opening | |
| 18 Oil burner | See specification |
| 19 Burner mounting plate | |
| 20 Gasket burner mounting plate | |
| 21 Boiler cover side/front | |
| 22 Boiler cover back | |
| 23 Oil filter (not shown in picture) | max. 25µm, P _{max} 6 bar
max. capacity 200 l/h,
total ± 6000 l.
max. vacuum -0,5 bar
L&G REV 11 |
| 24 Room thermostat (not shown in picture) | |



The following spare parts are available.

- 25 Nozzle



See technical specifications

For the yearly maintenance Kabola Heating Systems have compiled a set of spare parts often used during maintenance.

- 26 Service set consisting of 4+23+25



Appendix C Electrical diagram 230 V

Kabola B-calorifier 230 VAC 28-10-2004 White Elco casing



Appendix D Electrical diagram 24 V

Kabola B-calorifier 24 VDC 1-4-2005 White Elco casing



Appendix E Troubleshooting

Listed below you will find a list with possible problems, their reasons and solutions.

When you encounter problems not listed, you should contact your dealer. **Never try to solve problems on your own.**

Problem	Possible reason	Possible solution
Burner will not start	Oil supply interrupted	Bleed the oil filter Change contaminated filter element Fill the oil tank
	Power supply interrupted	Check the fuses Check the power supply
Burner stops		Reset burner (once)
	Flame protection dirty (photo cell)	Clean glass of flame protection
Burner starts pulsing	Flame protection defect (photo cell)	Replace flame protection
	Flue gas flow interrupted	Clear chimney opening
	Boiler dirty	Clean boiler
	Oil supply interrupted	See above
Burner shows error	Nozzle defective	Replace nozzle
		Reset burner (once)
	Low voltage	Check voltage level
Boiler does not react to thermostat	Oil supply interrupted	See above
	Wire in main connector has not been removed (room thermostat)	Remove wire from main connector between 1 and 2
	Boiler thermostat incorrectly adjusted	Adjust boiler thermostat
	Battery of room thermostat flat	Replace battery
Water is not circulating	Pump couplings are closed	Open pump couplings
	Pump not connected to electricity supply	Connect pump
	Rotor of pump is stuck	Turn pump with your hand (see pump manual)

The LED's on the dashboard can display the following error codes

LED		
Voltage (1)	3-way valve (6)	Reason
Fast flashing	Out	Voltage too high
Slowly flashing	Out	Voltage too low
Slowly flashing	Slowly flashing	Probe incorrectly installed or defect
Out	Flashing	Current too high 3-way valve motor defective

The boiler will reset automatically when the problem has disappeared. Action from the user is only required when the NTC-probe is incorrectly installed, the user needs to have the connection of the NTC-probe checked.

Appendix F CE declaration

Machinefabriek Gebr. Post B.V.
Populierenweg 41
3421 TX Oudewater
Netherlands



EC-declaration of conformity

We,

Machinefabriek Gebr. Post B.V.
Populierenweg 41
3421 TX Oudewater
Netherlands

declare under our own responsibility that the product:

**Boiler with calorifier control
Kabola B boiler 8/12/17/25/35/45**

to which this declaration relates complies with the following standards

EN 303-1, EN 303-2, EN 304, EN 50081-1, EN 50082-1, EN 61010

following the provisions of the following EC-directives

73/23/EEG,
89/336/EEG,
92/42/EEG,
amended by 93/68/EEG.

Nederland, Oudewater, 1-4-2005

A handwritten signature in black ink, appearing to read "P. Alles".

P. Alles
Directeur