ELECOM

Bluetooth® Laser Mouse M-BT6BL Series **User's Guide**

Thank you for purchasing the ELECOM M-BT6BL Series Bluetooth® Lase Mouse. The M-BT6BL is a wireless laser mouse that employs Bluetooth® wireless technology. It is equipped with Back and Forward buttons that are handy for browsing the Internet, as well as a resolution adjustment button for changing mouse speed.

This manual describes the operating instructions and safety precautions for using the M-BT6BL Series. Ensure that you have read this manual before using the product. After reading this manual, store it somewhere safe for

* Except in certain cases, the M-BT6BL Series is referred to as "this product" in

■Meaning of symbols

Failure to observe precautions may result in serious personal injury or death due to fire, electric shock, or other causes.
Failure to observe precautions may result in personal injury due to electric shock or other causes, and may damage other equipment.

Prohibited action

Mandatory action

(♥) Situation that needs attention

Notes and reference information

Difformation that is handy to know

Package Contents

This product's packaging contains the items listed below. Before using the product, check that all items are present. We make every effort to ensure that all products are packaged correctly. However, in the event that an item is missing or damaged, contact the retailer from whom you purchased the product. Mouse x1

- AAA alkaline battery x2
- User's Manual x1

Safety Precautions

Observe these precautions carefully to avoid personal injury, damage fire, and other problems.

a long period of time. Doing so may have an adverse effect on the

eve (Some laser beams cannot be seen with the naked eve.)

very dangerous. (3) The laser sensor may not work on glass or mirrored surfaces.

temperature returns to the operable range. (6) If this product is not operating normally, turn off the PC.

CLASS 1 ASER PRODUCT


(2) Never aim the rear surface of the mouse at a person's eyes, as this is

(4) Do not use this product for any application other than as a PC

(5) If this product is subjected to temperatures beyond its

specifications, turn off the PC, and do not use the product until the

- If a foreign object (water, metal chip, etc.) enters the product, immediately stop using the product, and remove the battery from the mouse. If you continue to use the product under these conditions, it may cause a fire or electric shock.
- If an abnormality is found with this product (emission of heat, smoke or abnormal smell from the product), immediately stop 0 using the product, shutdown the PC, and after thoroughly checking that heat from the product will not cause burns, emove the battery from the mouse. After doing this, contact the retailer from whom you purchased the product.




- Restoring from sleep state
 - Click the right mouse button
 - To reduce battery drain, the mouse enters sleep mode automatically if it is left without being operated for a certain period of time with the power or switch turned on.

3 Pairing the Mouse with the PC

To connect this product to the PC using Bluetooth, you need to pair the product with the PC.


Pairing involves registering Bluetooth devices (in this case, the mouse and the PC) with each other, and authorising a connection with a registered

Use your existing mouse or touch pad to operate the PC until the pairing process is completed successfully.



Refer to "4. Checking Mouse Operation" on the back of this sheet to confirm that the mouse works correctly.

Pairing the Mouse with the PC



Satiant

Check that the mouse scrolls up and down correctly in Windows ernet Explorer

- Trom the [Start] menu, select [All Programs], and then [Internet Explorer] Internet Explorer will launch.
- Display your favourite web site in Internet Explorer and change the size of the window so that the vertical scrollbar appears. *The sample website used here is the ELECOM homepage



not move when you scroll the wheel



In applications that do not support scrolling, the screen will



Scroll the wheel back and forth.

correctly in Safari.

appear

Click the Safari icon in the Dock.

Safari will launch.



2 Display your favourite web site in Safari and change the size

*The sample website used here is the ELECOM homepage.

200

of the window so that the vertical and horizontal scrollbars


• In applications that do not support scrolling, the screen will not move when you scroll the wheel

Check that the mouse is working correctly in the PlayStation® 3 Internet Check that the vertical and horizontal scrolling functions are working

- The second seco select [Internet Browser]. The Internet browser is displayed
- 2 Display your favourite website in the Internet browser, and change the size of the browser window so that the scroll bar is displayed.

*The sample website used here is the ELECOM hompage

Move the wheel of the mouse back and forward.



 In certain applications that do not support scrolling, the screer may not move up and down when the wheel is operated.

Troubleshooting

When the product appears to be malfunctioning

- When the mouse pointer on the screen does not move, or moves unstably, when the mouse is moved
- → Check that this product, and the PC's Bluetooth function or Bluetooth adapter are turned on.
- → Check pairing status to ensure that this product is paired correctly with the PC and that pairing has not been cancelled
 - The pairing indicator lamp turns on during the pairing procedure and turns off when the procedure is complete. For details on the PC's Bluetooth function and Bluetooth adapter, refer to the relevant instruction manuals. Alternatively, contact the manufacturer.

→ The PC and the mouse body are too far apart or there is a possibility that the PC is facing in a direction from which it cannot receive

Adjust the position of the PC. The operable range of this product is the area within a circle with a radius of 10 m from the PC. Depending on the usage environment, the mouse may not operate even when it is within approximately 10 m of the PC. In such cases



- move the mouse closer to the PC until operation stabilises ightarrow It is possible that the reflectivity of the surface on which this product
- is being used is not suitable for a laser mouse. Use this product on a mouse pad that is designed for use with laser mice.
- → When using this product on a metallic surface such as a steel desk, radio wave outreach may be shortened. In such cases, move the PC closer to the mouse until mouse operation stabilises.
- → Interference may occur if multiple units of this product are used together or if this product is used with other wireless devices. In this case, change the channel of other wireless devices.
- → Operation becomes unstable when battery power is low. See "Installing-Replacing the Battery" on the reverse of this sheet, and replace the batteries as soon as possible.
- The alkaline batteries supplied with this product are for checking product operation. These batteries may discharge and drain during storing and shipping.
- · When the remaining battery level is low, the remaining battery level indicator lamp is flashed in red for a certain period. * When not using the mouse, turn it off to save battery power
- ightarrow It is possible that the driver is conflicting with another driver such as that for a laptop touch pad. To use this product correctly, you must delete the touch pad driver. However, if you delete this driver, you may not be able to use the touch pad or touch pad functions Contact the PC manufacturer for more details.

Checking the PlayStation® 3 system software version

You must have system software version 3.41 to use this product with PlayStation® 3. Follow the procedure below to check the system software version.

The From the XMB™ home menu, select [Settings], select [System Settings], and then select [System Information].


System information is displayed

=

2 Check that the system software version is 3.41. If the system software version is not 3.41, perform a system update to update the PlayStation® 3 system software to the most recent version. For details regarding the system update procedure, refer to the PlayStation® 3 manual

ELECOM CO., LTD.

1-1 Fushimi-machi 4-Chome Chuoku, Os
宜麗客(上海)貿易有限公司 上海市徐匯区肇嘉浜路1065甲号飛 電話:86-21-33680011 FAX:86-21-64271706 URL:http://www.elecom-china.c
ELECOM (SHANGHAI) TRADING CO. , LTI Rm 704, Feidiao International Bldg , 100 , China 200030 TEL : 86-21-33680011 FAX : 86-21-64271706 URL : http://www.elecom-china.com/
Elecom Korea Co., Ltd. 5F Suam Bldg. 1358-17, Seocho2-dong, Korea TEL : 1588-9514 FAX : (02)3472-5533 URL : www.elecom.co.kr



Operating time

Basic specifications

Product name

Supported devices

Article No.

Bluetooth® Laser Mouse

M-BT6BL Series

Devices that support the Bluetooth HID profile (A Bluetooth® adapter that supports the HID profile is required to use this product with a PC that does not support Bluetooth®.)

PlavStation® 3 (system software version 3.41) Windows 7 (up to SP1), Windows Vista (up to SP2), Windows XP (SP2 to SP3)

Mac OS X (10.5 to 10.5.8, 10.6 to 10.6.7) Bluetooth® v3.0 / v2.1 + EDR / v2.1/v2.0 + EDR

hable)		
less		
Class 2		
erface Device)		
idth		
on		

Non-magnetic substance (e.g. wooden desk):

Magnetic substance (e.g. metal desk): Approx

* Values indicated are those obtained by ELECOM and are not guaranteed. 74.3 (W) x 52.3 (D) x 33.4 (H) mm

5 to 40°C, 90% RH max. (no condensation)

10 to 60°C, 90% RH max. (no condensation)

AAA alkaline battery, AAA manganese battery rechargeable AAA nickel hydride battery Measure of the operating time when an AAA

alkaline battery is used Continuous operating time: Approx. 75 hours Continuous standby time: Approx. 125 days Estimated serviceable time: Approx. 34 days (when the PC is operated for eight hours a day and 25% of the PC operation is assigned to nouse operation)

당해 무선설비는 운용 중 전파혼신 가능성이 있음 . B 급 기기 (가정용 정보통신기기) 이 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역에서는 물론 모든 지역에서 사용할 수 있습니다.



氏功率電波輻射性電機管理辦法 **室**十一條

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不 得擅自變更頻率、加大功率或變更原設計之特性及功能 第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信

經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。 前項合法通信,指依電信規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設 備之干擾。

Osaka Japan 541-8765

雕国際大厦704号

;om/

65 ZhaoJiaBang Rd , Shangh

, Seocho-gu, Seoul 137-862,

Bluetooth 5-button Laser Mouse M-BT6BL Series User's Manual 1st edition, September 10, 2010

- FLECOM Co., Ltd.
- This manual is copyright of ELECOM Co., Ltd. Unauthorised copying and/or reproducing of all or part of this manual is prohibited.
- The specifications and appearance of this product may be changed thout prior notice for product improvement purposes.
- ELECOM Co., Ltd. shall bear no responsibility for any and all affects resulting from the use of this product regardless of the above reasons.
- Export or service transaction permission under the Foreign Exchange and Foreign Trade Control Law is required in order to export this product or parts of this product that constitute strategic materials or services.
- Windows and the Windows logo are trademarks of the Microsoft group of companies.
- Mac, Mac OS, and Macintosh are registered trademarks or trademarks of Apple Inc., in the United States, "PlayStation" and "PS3" are trademarks or registered trademarks of Sony
- Computer Entertainment Inc.
- The Bluetooth word mark and Bluetooth logo are all trademarks that are owned by the Bluetooth SIG and licensed out for use to ELECOM Co., Ltd. that are incorporating Bluetooth wireless technology into their products. Company names, product names, and other names in this manual are generally trademarks or registered trademarks.