


Instruction Manual
CLB12T/CLE12T ELECTRIC STACKER

 **Operators should read and understand this manual and all warning Labels on power stacker before using the stacker.**

Keep the manual for future reference.

Date: 2012.6




Introduction	2
1 Guidelines for Safe Operation	3
2 Technical Manual	6
Specifications	6
2.1.1 Structure chart	6
2.1.2 Technical data	6
2.2 Technical Standards	7
2.3 Operation Conditions	7
3 Transport and Trial Run	8
3.1 Transport with a crane	8
3.2 Trial Run	8
3.3 Towing of stackers without driving ability	8
4 Operation	10
4.1 Schematic diagram of the lever	10
4.2 Starting-up the stacker	10
4.3 Operation of the stacker	10
5.1 Safety procedures for lead-acid accumulator operation	14
5.2 Specification of the accumulator	16
5.3 Storage, transportation and installation of the accumulator	16
5.4 Capacity indicator of the accumulator	16
5.5 Recharging	17
6 Maintenance and Service Manual	20
6.1 Safety procedures for maintenance and service	20
6.2 Routine Maintenance (Before every shift)	21
6.3 Professional Maintenance Manual	21
6.4 Service Manual	23
6.5 Storage of the stacker	25
7 Schematic Diagrams of Electric	27
7.1 Circuit diagram	27
7.2 Wiring diagram	28
7.3 Hydraulic system	30


Introduction


Welcome to use this series of power stackers. This manual gives clear information on how to master safe operation of the power stackers.

The differences between various power stackers are described in detail in this manual. During operation and maintenance, please refer to the contents corresponding to the power stacker types you are using.

The safety instructions and important precautions are indicated with the following icons:

1.  ---- This icon indicates the existence of a hazard that could result in personal injury if the safety instruction is not observed
2.  ---- This icon indicates that a failure to observe the described instruction could lead to equipment damage
3.  ---- Refers to general notes and instructions before use.

 Most parts of the product are made from recyclable steel. The recycling and disposal of cast-offs resulted during using, maintenance, cleaning and disassembling the product has to comply with local regulations without pollution to the environment. The recycling and disposal of the cast-offs should only be operated by specialised personnel in the designated area. The cast-offs such as hydraulic oil, batteries and electronic units, if improperly disposed, may be hazardous to the environment and human health.

 Due to continuous product improvement, Noblift reserves the right to make changes in product designs and specifications without prior notice. For the latest product parameters, please feel free to contact us. Note: All parameters provided herein are as of the publication date of the Instruction Manual.

1 Guidelines for Safe Operation

1.1 Requirements for the driver: The stacker should only be operated by personnel trained in operating the stacker, who can show to the user how to move and handle loads and instruct the user how to operate the stacker.

1.2 The right, duty and responsibility of driver: Clear with his own right and duty, the driver should be trained in operating the stacker and also knows the contents in this operation manual very well. If the stacker in use is controlled on foot, the driver should wear safety boots during operation.

1.3 Unauthorized persons are prohibited to use: The driver is responsible for managing the stacker in use, and must prevent any unauthorized person from driving or operating the stacker.

1.4 Malfunction and Defects: In case malfunction or defects occurs with the stacker, the driver should immediately inform the supervisor. If the stacker can not be operated safely, e.g. with worn wheels and brake malfunction, always stop using it until repaired completely.

1.5 Safety operation and environment protection


The checking and maintenance work described in this chapter should be executed according to the time intervals in the maintenance list.

 Never modify any parts, especially safety devices of the stacker without permission.

Never change the operation speeds of the stacker.

All original spare parts from the factory are verified by Quality Assurance Department. Only use spare parts from the manufacturer for the guarantee of the safety and reliability of stacker operation. The replaced material such as oil or fuel should be disposed of according to environment protection regulations.

1.7 High-risk environment: It should be with special equipment for protection if working under the high-risk environment.

 The stacker is not designed for use in high-risk environment.

1.8 Safety devices and warning signs : Sufficient attention should be paid to safety devices, warning signs and precautions described in above sections in this manual.

1.9 Driving in public places: The stacker is prohibited to drive in public places except for special areas.

1.10 Space between vehicles: Remember to keep a proper distance from the vehicle ahead, since it may stop suddenly at any moment.

1.11 Passengers: Never carry or lift persons with this stacker.

1.12 Headroom: Never use the stacker in areas where the headroom is lower than the height of loads or mast.

1.13 Operation in a lift or loading platform: If the load capacity of the lift or platform is sufficient and the space is enough for stacker operation, they can be used for transportation with the permission from the stacker user. The stacker must be confirmed by its driver himself before entering the lift or loading platform. When entering the lift, the loads must enter ahead. And locate the stacker in a suitable position to prevent from contacting walls around. If passengers take the lift together with the stacker, they have to enter after the stacker enters and stops firmly, and leave before the stacker.

1.14 Driving passageway and working area: The stacker must be driven in designated passageway. Non-related persons must leave the working area. Loads must be stacked in designated locations.

1.15 Operation Management: Driving speeds must be suitable to local conditions. Always drive in lower speed when passing curved passageways, narrow passageways, rotary doors or any obstructed places. The driver should be able to measure by sight and keep enough stopping space from vehicles ahead all the time. It is prohibited to make an abrupt stop (unless in emergency), rapid U-turn and chase with each other in obstructed places. Never operate the stacker with the body stretching out of it.

1.16 Visibility: The driver must keep his eyes on moving direction and have a clear view of the road ahead. In case the loads carried block sight of the driver, the stacker has to be driven reversely. If this is not practical, another person should walk in front of the stacker, giving corresponding guidance and warning to the driver.

1.17 Passing a ramp: Only known ramps are permitted to pass. And the ramps must be clean, anti-skid and meet specification requirements of the stacker. Loads on the fork must face the downward slope. Never turn around, drive obliquely or stop on a slope. Pass a ramp in lower speed and get ready for braking at any time.

1.18 Load capacity of the floor: Check if the weight of stacker and loads or wheel pressure on the floor exceeds the load capacity of the floor.

1.19 Transportation: The fork should be kept lower than 300mm from the floor during non-transportation driving. It is better to driver in reverse direction of the fork to get good vision and mobility. Driving with the fork forward may cause unpredictable mobility problems.

1.20 Speed: Select a suitable speed, depending on floor conditions, visibility and the principle of safety operation. During operation, it is prohibited to speed up, stop and turn suddenly, for that may cause roll-over of the loads and the stacker.

1.21 Driving on loading platform or approach bridge: Before driving the stacker onto loading platform or approach bridge of a truck, make sure to check load capacity of the

approach bridge and if it is equipped with anti-sliding devices. The driver must also check load capacity of the truck and if there are devices to prevent the truck from moving.

1.22 Safe Parking: Pay attention to safety when parking the stacker. Never park the stacker on a slope or on a ramp. The fork must be lowered down to the lowest position after parking. Turn off the electric lock and remove the key to prevent unauthorized operation.



Please disconnect the wires linked to batteries, if the stacker will not be used for a long time before recharging,

1.23 Signalling: Warning signals can be sent by the horn on the stacker.

1.24 Protection shoes: According to EU standard EN-345:1-S1, standard protective shoes must be worn when operating on the stacker.


1.25 Additional equipment: Unauthorized truck modification is not permitted. No modifications or alterations to a powered industrial truck, which may affect, for example, capacity, stability or safety requirements of the truck, shall be made without the prior written approval of the original truck manufacturer, its authorized representative, or a successor thereof. This includes changes affecting, for example braking, steering, visibility and the addition of removable attachments. When the manufacturer or its successor approve a modification or alteration, they shall also make and approve appropriate changes to capacity plate, decals, tags and operation and maintenance handbooks.

2 Technical Manual

CLB This series of stacker are designed for short and medium distance transportation on flat road surface. The maximum capacity can be 1250kg. It can be also used as an order picker or an Aerial work platform.

Specifications


2.1.1 Structure chart



2.1.2 Technical data


	CLB1216T	CLB1229T	CLB1232T	CLB1236T	CLB1229FT
A (mm)	1976	1946	2096	2296	1946
B (mm)	1889	1908	1908	1908	1908
C (mm)	570/685	570/685	570/685	570/685	570/685
D (mm)	890	890	890	890	890
E (mm)	335	354	354	354	354
F (mm)	1150	1150	1150	1150	1150

	CLE1216T	CLE1229T
A (mm)	1971	1946
B (mm)	1831	1831
C (mm)	570/685	570/685
D (mm)	890	890
E (mm)	355	355
F (mm)	1150	1150

 These tables provide only specifications of standard stackers. Specifications of non-standard stackers or stackers equipped accessories or other optional components may be different from above tables. We reserve the right to update the specifications of this stacker.


2.2 Technical Standards

Continuous noise level should be less than 70dB(A) according to ISO4871 standard.

 Continuous noise level is an average value of noise measured at the driver's ear during travelling, lifting and being standby.


Electromagnetic Compatibility (EMC)


The manufacturer confirms that the stacker complies with EN12895 and other relevant standards on limits of electromagnet radiation and interference, and has been tested on static discharge.

 Never modify any part of electrical system without written permission from the manufacturer.

2.3 Operation Conditions


Ambient temperature: 5°C ~ 40°C


 Special devices have to be used under a temperature below 5°C or in very humid environment.

 If there is quality problems with the truck or you need to order spare parts, please specify serial number of the truck and part number.


3 Transport and Trial Run

3.1 Transport with a crane

 Load capacity of the crane in use must be sufficient. The load weight equals the net weight of stacker plus weight of accumulator; see nameplate on the stacker. The hook holes are specially designed for transport the stacker.


 The hook holes are specially designed for transport the stacker.

- Park the stacker in a safe position.
- Hooks of the crane must be applied at hook holes.


 Hooks of the crane must be applied at hook holes, ensuring

the stacker will not be slipped down.

During operation, make sure the crane, whose hooks must be applied at hook holes of the stacker, do not contact with the stacker.



3.2 Trial Run

 The stacker can only use accumulator as power supply. Changing to use AC power will damage the electric circuit. Cables connecting accumulator should be less than six meters.

To ensure the stacker work normally after delivery and transportation, following operations have to be completed:

- Check if the completeness of all parts and components, and check if they are in compliance with requirements.
- If necessary, install batteries without damaging the connection cable.
- Recharge the accumulator immediately.
- If customers want to replace the accumulator with a new one, make sure that the new accumulator match with the accumulator coulombmeter (or is permitted by service technician of manufacturer).

3.3 Towing of stackers without driving ability


When towing the stacker without driving ability, release electromagnetic brake before moving.

- Press emergency control button and turn the power supply switch to OFF position.

—Open the cover of electric unit.


Release 3 screws counter clockwise on the electric motor until the brake does not impede the stacker from moving.

Now, you can tow the stacker.

 After arriving at the destination location, recover the stacker to original status.

4 Operation

4.1 Schematic diagram of the lever



1. Down Switch
2. Forward/Backward
3. Horn Button
4. Reverse Button
5. Up Switch

4.2 Starting-up the stacker

⊘ The driver should always make sure that no person stayed in dangerous area of the stacker before starting up and operating the unit or lifting loads.

Check before daily start-up

—Check the entire unit for defects and failure, especially the wheels and lifting mechanism.

—Check if the accumulator is firmly fixed and well-connected.

Starting-up the stacker

— Reverse and Turn on the emergency stop switch.

— Insert the key in electric lock and turn it clockwise to position “I”.

— The coulombmeter shows current battery level.

— Check the horn.

— Check braking function of the control lever.

Now the preparation before starting-up is completed.

4.3 Operation of the stacker

4.3.1 Starting-up, Driving and Parking

⊘ Be careful during starting up and driving, especially when part of your body stretches out of stacker’s outlines.

Do not carry any other person during driving.

Emergency Stop

Pressing the emergency stop switch will stop all electric control functions.

Forced Braking

When the control handle is released, the stacker will brake automatically (emergently stop). The control handle will enter the upper braking range (B1) automatically.

⊘ If the lever enters braking range slowly, make sure to find out its causes and troubleshooting the failure. If necessary, replace the air spring of the handle.


Starting up

⊘ Start up the stacker only when the battery cover is closed.

—Starting-up the stacker.

☞ Travelling speed is regulated with the controller.

—Rotate the control lever to driving range “F”, and adjust the control lever in required direction, the stacker will move towards selected direction.



Driving


Swing the control handle rightward or leftward to drive.

Driving on a slope

⚠ Always keep loads face the downward slope when transport loads on a slope.

Take following safety measures against the rolling down: With the control button in position “0”, quickly press the handle backward. The driver should release the handle as required to make the electromagnetic brake work automatically, controlling the speed and direction (if the driver find the stacker is rolling down).


Braking

 The braking performance of the stacker depends on floor condition. The driver must be clear about this point.


Three braking methods are available:

- Electromagnetic brake (control handle)
- Use reverse current brake (from the controller)
- Brake with the sensor (i.e. release the lever to brake)

Braking with the Electromagnetic Brake


 In case of an emergency, always stop the stacker only with electromagnetic brake (control lever).

—Turn up or down the control handle to braking range B1 or B2, the drive motor will be stopped mechanically.

 When the control handle is released, it will enter the upper braking range (B1) automatically.

After the stacker is stopped, the electromagnetic brake works as parking brake.


Braking with reverse current brake


 If the control system or driving power fails, braking with reverse current is possible.

- Turn controller in reversed direction of driving until the stacker stops.
- Release the controller.


Braking by the inertia

—When the “forward/backward button” is released, it returns to position “0”, and brakes by inertia of the motor.


 The slowing down rate depends on the position of the controller.

 If the controller position is set to ‘0’ and the inertia braking unit is removed by service technician, you have to use electromagnetic brake or reverse current brake to brake the stacker.

4.3.2 Operation of lifting and lowering loads

 Before lifting loads, the driver must check if the loads are placed on the pallet completely and the weight of loads does not exceed the loading capacity. Do not transport in full load status for a long time.

—Make sure the fork reach under the loads as far as possible.

 When operate with “Up” or “Down” button, the fork will move upward or downward at a fixed speed.


Lifting of the fork

—Press the “Up Switch” until the fork arrives at required height.

Lowering of the Fork

—Press “Down Switch” until the fork is lowered to required height.

Safe Parking

 Pay attention to safety when parking the stacker. Never park the stacker on a slope or on a ramp. The fork must to be lowered to its lowest position after parking.

—Lower the fork.

—Turn electric lock from position “1” to “0” and remove the key.

5 Maintenance, Recharging and Replacement of the Accumulator

5.1 Safety procedures for lead-acid accumulator operation

The stacker must be parked in a safe location before any operation on the accumulator.

5.1.1 Maintenance Technician

Only qualified technician can perform operations on the accumulator such as recharging, maintenance and replacing. Before operation carefully read instruction manuals including operation manual, replenishment preparation and recharging requirements.

5.1.2 Fire Prevention Measures

Never smoke or use open fire when perform operations on the accumulator. The accumulator should be away from flammable material at least two meters when storage or recharging. The location for accumulator storage should be well ventilated and equipped with fire fighting devices.

5.1.3 Maintenance of the Accumulator

- 1) Keep the nuts on every battery cell dry and clean. Tighten every terminal and cable end, and brush them with grease to prevent corrosion. Naked cable ends and terminal posts should be covered with a skid-proof insulating cover.
- 2) Every two cells should be well-connected. Check the nuts on each pole, if loose, tighten the nuts.
- 3) Keep the surfaces of accumulator clean and dry. After the completion of recharging, clean spilled acid with cotton yarns or brush. And clean with wet towel if necessary.
- 4) Over recharging and over discharging should be avoided, and fast charging and insufficient recharging are also not allowed. Otherwise life span of the accumulator may be affected.
- 5) Do not put conductive objects including metal tools on the accumulator, or short circuit or even explosion may be caused.
- 6) Never spill any hazardous liquid or solid material on surfaces of the accumulator. When using a densimeter or a thermometer, make sure the surface is clean and clear.

- 7) Recharge the discharged accumulator in time. Delayed recharging may damage the accumulator. Do not delay recharging more than 24 hours. Recharging of the accumulator may not work outdoors in cold weather. In this case, move it indoors to perform recharging.
- 8) If the accumulator will not be in use for a long time, it should be recharged and discharged once every month and it should be fully recharged every time.
- 9) During recharging or using, the liquid level of electrolyte lowers because of water evaporation, so pure water should be added. It is not allowed to add electrolyte with a specific weight of 1.280.
- 10) If individual cell fails, identify the cause and repair the cell immediately. Replace the cell when it cannot be repaired.
- 11) The site for recharging should be well ventilated. It is prohibited to smoke or use open fire, avoiding the risk of hydrogen explosion.
- 12) The electrolyte in accumulator is toxic and corrosive. For this reason, always wear working suit and protection glasses to protect your body from contacting the electrolyte in accumulator.
- 13) If your clothes, skin or eyes are spilled with acid liquid in accumulator, flush with large amount of clean water. For skin and eyes, flush with large amount of clean water and also seek doctor's treatment immediately. Acid spillage must be neutralized and treated immediately.
- 14) The weight and dimensions of the accumulator have remarkable effect on stability of the stacker. Therefore do not modify the type of accumulator without approval from the manufacturer.
- 15) Never discharge in large current, for example, performs travelling and lifting simultaneously.

5.1.4 Disposition of worn-out accumulators

Worn-out accumulators should be recycled according to local regulations, and stored in specified zone or cast-off treatment zone. These works should be done by qualified specialized companies.

5.2 Specification of the accumulator

Weight and dimensions can be found on the nameplate of the accumulator.



Uninsulated terminal poles on the accumulator should be protected with an insulated cover. When connecting the accumulator and socket, make sure to stop the stacker and put the switch at position "0".. When replace or install the accumulator, make sure the accumulator is fixed securely in battery box.

5.3 Storage, transportation and installation of the accumulator



The stacker must be parked on the level ground steadily. To prevent short circuit, naked cable ends and the terminal posts should be covered with insulated covers. When pulling out the accumulator, properly arrange removed accumulator's connectors and cables without blocking access of the accumulator.



When install or remove the accumulator with a crane, make sure the load capacity is sufficient (weight of the accumulator is marked on both the nameplates of the accumulator and the stacker.) The crane must pull vertically to prevent the battery box from being damaged. The hooks of the crane should be safe and secure. Never let the hooks fall on an individual battery .

- Press emergency stop switch and turn the power supply switch to OFF position.
- Remove the connectors of
accumulator cables.
- Connect the lifting device to lifting
holes.
- Lift out the accumulator from the top and move away with handling equipment.



Perform installation in reverse order of above steps. It is noticeable to put the accumulator in right position and connect the cables securely. After reinstalling the accumulator, always check all cable connections and connectors for obvious damage.

5.4 Capacity indicator of the accumulator

Capacity indicator of the accumulator The status of accumulator discharging is

indicated on the indicator with 10 bar graphs, each bar represents 10 percent of increment.

As the consumption of accumulator capacity, the lighting bars will fall down from the top. Preset “Warning” marks will appear when remaining capacity of accumulator meets following conditions: When the remaining capacity of the standard accumulator is 30 percent, “Warning” mark will appear and you can recharge the accumulator.

Preset “Warning” mark and a flashing “Stop” mark will appear when remaining capacity of accumulator meets following conditions: When the remaining capacity of standard accumulator is 20%, “Stop” mark will appear and keep lighting. When the “Stop” mark keeps lighting, lifting function of the stacker will be cut off automatically.

Capacity sufficient



Recharging needed



Low battery



If the indicator shows low battery when lifting loads for a not very long period, lifting function can only be performed after recharging the accumulator to at least 70% of capacity.

5.5 Recharging

The CLE series of stackers is supplied with a special charger for recharging.



Read the instruction manual carefully before recharging.



The batteries should be recharged in well-ventilated areas. Make sure no metal objects placed on the accumulator. Check all cables connection and connectors for obvious defects. Observe strictly all safety instructions, e.g. replenishment of the accumulator and preparation for recharging.

5.5.1 Initial recharging

1) Please check the electrolyte before recharging, if the electrolyte is diminished, we have to add the electrolyte into the battery. The Electrolyte is made of concentrated sulfuric acid and distilled water, the specific gravity is 1.280 ± 0.005 (Under the 25°C normal temperature), and then pour the electrolyte into the battery, 15–20mm overtopping the protective board is ok.



We can recharging the battery when the temperature of the electrolyte is lower than 35°C .

2) There are two stage during the initial recharging: A, when voltage $\leq 2.4\text{V}$, charge current $= 0.5 I_5\text{A}$ ($I_5\text{A} = 1\text{A} * 5\text{H}$); B, When the voltage upto 2.4V , please half the charging current, it is $0.25 I_5\text{A}$. Continue to recharge until the electrolyte start bubbling. Proof of 100% recharged: stable voltage, when the density of the electrolyte upto 1.280 ± 0.005 without obvious change within 3 hours, we think the battery was 100% recharged. At that time, the recharging voltage of the battery is 4-5 times than the reted capacity. The whole recharging process will be 70 hours.

5.5.2 Balanced Recharging

After using for a period, voltage and concentration may vary from battery to battery.

Balanced recharging will eliminate the differences so that the performance of each cell becomes uniformed.

In following cases, balanced recharging is necessary: Voltage of an individual cell is frequently below 1.7V ; large current occurs during discharging, for example, when using the driving motor and lifting motor simultaneously; for accumulators that are not recharged in time after discharging: Over discharged accumulators and those are not in use for a long time.

Perform balanced recharging as follows:


- A、 Recharge with a current of $0.1 I_5\text{A}$.
- B、 When the voltage up to 2.5V , and there occur bubbles in the electrolyte, continue recharging at a reduced current of $0.05 I_5\text{A}$.
- C、 Recharge the accumulator to full capacity and stop recharging for half an hour, and then continue recharging with further-reduced current of $0.025 I_5\text{A}$ for an hour.
- D、 Stop recharging again for half an hour and continue recharging with a current of $0.025 I_5\text{A}$ for an hour.

E、 Repeat step D until bubbles occurs intensely and instantly when switching on the charger.



Perform balanced recharging to accumulator once a month in normal use.

6 Maintenance and Service Manual


 Never modify any parts, especially safety devices of the stacker without permission. Never change the operation speeds of the stacker. All spare parts provided by original manufacturer are strictly tested. Only use spare parts from the manufacturer for the guarantee of the safety and reliability of stacker operation. The replaced material including oil should be collected and disposed of according to local environment protection and health regulations.

6.1 Safety procedures for maintenance and service

Maintenance technician: The maintenance and service should only be performed by special personnel trained by the manufacturer. After the technician sent by after-sales department of the manufacturer completed maintenance and servicing work, they should sign on the service log.

Lifting of the stacker: When the stacker needs to be raised up for repair, the lifting device must be safe and reliable, and must be strictly fixed to hook holes. When the stacker is raised up, proper measures such as using wedges and wooden blocks must be applied to prevent the stacker from sliding down or tilting over.

Cleaning Operation: Flammable liquid can not be used for cleaning the stacker. Before cleaning, take safety precautions to prevent electric sparks (e.g. sparks caused by short circuit). When operating the accumulator, connectors on it must be disconnected. Use soft air suction or compressed air, non-conductive and anti-static brushes to clean electric and electronic components.

 If you are going to use water spray or high pressure cleaner to clean the stacker, all electric and electronic components must be covered carefully in advance because moisture may cause them malfunction. Never use steam nozzles for cleaning.

Operation of Electric System: Operation on the electric system should only be performed by specially trained personnel. Before performing any operation on the electric system, precautions must be made to prevent electric shock. When operating the accumulator, connectors on it must be disconnected.

Welding Operation: To prevent electric components from being damaged, remove these electric components before welding.

Installation: When repairing or replacing hydraulic components, electric and electronic components, make sure to install them back to their original positions.

Wheels: Quality of the wheels has significant effect on stability and driving performance of the stacker. Modification on wheels can be performed only with the approval from the manufacturer. When replacing wheels, ensure that the stacker is levelled as delivery state (wheels must be replaced in pairs, i.e. replace right wheel together with left one).

Lifting chain and rollers: Chain and rollers will be worn quickly without good lubrication. Perform periodic lubrication according to following maintenance table. Shorten the lubrication period under adverse operation conditions (such as in dusty and hot environment).

Hydraulic Oil Pipes: Replace the hydraulic oil pipes every 6 years, when replace the hydraulic assembly, you should also change the oil pipes of the hydraulic assembly.

6.2 Routine Maintenance (Before every shift)

6.2.1 Check the liquid level of electrolyte in the accumulator.



The liquid level will be higher when being recharged.

6.2.2 Check every pole, every cable and their covers.

6.2.3 Check if the accumulator box is secured.

6.2.4 Check the stacker for oil leakage.

6.2.5 Check the chain, rollers, fork, oil pipes and horn.

6.2.6 Check the brake.

6.2.7 Check the wear and tear of drive wheels and loading wheels.

6.3 Professional Maintenance Manual

It is very important for safe operation of the stacker to perform overall professional maintenance. Failure in performing maintenance according to specified interval may cause malfunction of the stacker, and potential risk to human and equipment.



Maintenance periods listed in this manual apply to single shift a day under normal operation conditions. If using in dusty environment, the ambient temperature varies remarkably or in multi-shift situation, the maintenance period has to be shortened.

Maintain the stacker according to following maintenance list. Maintenance periods are as

follows:

W1 = Every 50 work hours, but at least once a week.

M3 = Every 500 work hours, but at least once every three months

M6 = Every 1000 work hours, but at least once every six months

M12 = Every 2000 work hours, but at least once every 12 months

Additional operations should be performed in trial run period:

(In initial 50 – 100 working hours or after two months)

— Check the nuts on the wheels, and tighten them if necessary.

— Check the hydraulic components for leakage, and tighten them if necessary.

—Replace the hydraulic filter.

Maintenance List

			Time interval of maintenance				
			Standard = ●	W	M	M	M
			Cooling storage = #	1	3	6	12
Chassis & Main frame	1.1	Check all bearing parts for damages		●			
	1.2	Check all bolt connections		●			
Driver	2.1	Check the drive system for noise and leakage		●			
	2.2	Check oil level in drive system		●			
	2.3	Replace lubricant oil				#	●
Wheels	3.1	Check for wear and tear		●			
	3.2	Check the bearings and make sure they fit well with the wheels a)		●			
Steering system	4.1	Check the steering control		●			
Braking system	5.1	Check the performance and adjust accordingly	#	●			
	5.2	Check reset function of the air spring, and check for leakage and damages		●			
	5.3	Check the brake disk for wear		●			
	5.4	Check the connection of brake and adjust if necessary		●			
Lifting Mechanism	6.1	Check performance and wear, and adjust accordingly		●			
	6.2	Visually inspect the loading wheels for blockage		●			
	6.3	Check fork tips and pallet support for wear and damages	#	●			
Hydraulic system	7.1	Check performance	#	●			
	7.2	Check all connections for leakage and damages b)	#	●			
	7.3	Check the cylinder for leakage and damages and if the accessories are safe and secure	#	●			
	7.4	Check the oil level.	#	●			

	7.5	Replace hydraulic oil and the filter element c)			#	●
	7.6	Check the pressure regulator valve			#	●
Hydraulic system	8.1	Check performance		●		
	8.2	Check all cable connections for safety, reliability and damages		●		
	8.3	Check if the amperage of fuses is proper				
	8.4	Check if the switches and release cam mechanism is secure and functions properly		●		
	8.5	Check the connectors and replace worn parts if necessary				
	8.6	Check the warning device	#	●		
Motor	9.1	Check the carbon brush for wear		●		
	9.2	Check safety of additional devices of motor		●		
	9.3	Use a vacuum to clean motor frame. Check the commutator for wear		#	●	
Accumulator	10.1	Check the density of acid liquid, capacity and voltage of the accumulator	#	●		
	10.2	Check the safety devices on terminals and the grease	#	●		
	10.3	Clean the connector of accumulator and check the connection.	#	●		
	10.4	Check the cable for damages, replace if necessary		●		
Lubricant oil	11.1	Grease the stacker according to time table for filling up lubricant	#	●		
General Test	12.1	Check the grounding connection of electric system				●
	12.2	Check the travelling speed and braking distance				●
	12.3	Check the lifting and lowering speed				●
	12.4	Check the safety device and switch off devices		●		
Trial	13.1	Perform trial run under rated load		●		
	13.2	The stacker is proved to be safe and reliable to personnel after completion of above maintenance	#	●		

- a) After about initial 100 working hours, check the nuts of wheels, tighten them if necessary.
- b) After about initial 100 working hours, check the hydraulic system connections for leakage and tighten it if necessary.
- c) After initial 500 working hours.

6.4 Service Manual

6.4.1 Troubleshooting

Fault	Cause	Repair measures
The stacker can not move	<ul style="list-style-type: none"> -Connectors on accumulator are not connected - Electric lock is in position "0" - Emergency stop switch is not turned on. - The accumulator capacity is in used up 	<ul style="list-style-type: none"> - Check the connectors on accumulator, connect them if necessary - Turn the Electric lock in position 1 - Turn on the emergency stop switch. - Check the capacity of accumulator, recharge if necessary - Turn the control lever to drive rage F - Check fuse FU and FU1

	<ul style="list-style-type: none"> - The control lever is not in drive range F - fuse blown 	
Loads can not be lifted up	<ul style="list-style-type: none"> - The stacker is not operating - Low hydraulic oil level - fuse blown - The accumulator has only 20/30% of capacity - The UP switch is in bad contact or damaged. 	<p>Do as methods in “The stacker can not move” table.</p> <ul style="list-style-type: none"> - Check hydraulic oil - Check fuse 2 FU - Recharge the accumulator. - Check UP switch and replace if necessary.
Loads can not be lowered down	<ul style="list-style-type: none"> - Dirty oil blocks control valve. - The solenoid valve for lowering is not opened or is damaged 	<ul style="list-style-type: none"> - Check hydraulic oil and clean control valve. Replace the oil if necessary. - Check or replace the valve for lowering
It can not stop when lifting up	<ul style="list-style-type: none"> - The UP switch is damaged. 	<ul style="list-style-type: none"> - Disconnect power supply and replace the UP switch
Moving in one direction	<ul style="list-style-type: none"> - The sensitive switch and the connecting cable are not well-contacted. 	<ul style="list-style-type: none"> - Check the sensitive switch in control lever and the connecting cable.
The stacker travels very slowly.	<ul style="list-style-type: none"> - The accumulator capacity is insufficient. Or the electromagnetic brake is tight. Or the related cables are not well-contacted. 	<ul style="list-style-type: none"> - Check the capacity indicator, the brake and related cables.
The stacker starts up suddenly	<ul style="list-style-type: none"> - The controller is damaged. - The button controlling backward or forward is not back to its normal position. 	<ul style="list-style-type: none"> — Replace the controller. - Repair or replace it.




If above steps still can not solve problems, please contact after-sales service department of the manufacturer and have the problems solved by specially trained technicians.

6.4.2 Preparation before repair


To prevent possible accidents during maintenance and repair work, following preparations must be done:

- Park the stacker safely.
- Press the emergency stop switch and disconnect the connectors on accumulator.

 When the fork needs to be lifted up or the stacker needs to be raised up for repairing, precautions for preventing the fork or the stacker from tilting over or falling down suddenly must be taken. For information on lifting of the stacker, see related parts in “Transportation and Trial Run” above.

6.4.3 Check hydraulic oil level

- Get the stacker ready for maintenance or repairing.
- Open the cover of electric unit.
- Check hydraulic oil level in oil tank.

 Check the hydraulic oil level only after the fork and main frame are lowered to their lowest position.

6.4.5 Use Preparation after maintenance or repairing


Use the stacker only after following operations have been completed.

- Clean the stacker.
- Check the brake.
- Check the emergency stop switch.
- Check the horn.

6.5 Storage of the stacker

If the stacker will be not in use for over two months, it must be stored in antifreeze and dry locations. Take protection measures before storing.

If the storage time is over six months, please consult the manufacturer on additional protection measures.

 During storing, the stacker should better be placed with the wheels off the ground for protecting the wheels and the bearings within wheels.

6.5.1 Operations before storing

- Clean the stacker thoroughly.
- Check the brake.
- Check the hydraulic oil level, refill if necessary.
- Apply lubricant oil or grease to protect all parts.
- Refill grease according to detailed lubrication cycle table.
- Recharge the accumulator again.
- Disconnect and clean the accumulator. Apply grease on terminal poles on

accumulator.



Besides these, the accumulator must be protected according to special requirements stated in accumulator instruction manual.

6.5.2 Cautions during storage

Every 2 months: Recharge the accumulator.



Operations related to accumulator

It is very important to recharge the accumulator periodically. Otherwise, the accumulator will self discharge, resulting complete loss of capacity and the accumulator may become worn-out thoroughly.

6.5.3 Trial Run Again

- Clean the stacker thoroughly.
- Refill grease according to lubrication cycle table.
- Clean the accumulator, apply pole lubricant on the terminal poles and reconnect the connectors.
- Recharge the accumulator again.
- Check if there is moisture in gearbox oil. If so, replace gearbox oil.
- Check if there is moisture in hydraulic oil. If so, replace hydraulic oil.
- Start up the stacker.




If the switches in electric system do not contact well, clean all exposed connectors with contact detergent spray, and repeat this operation to remove oxide layer on these connectors.




Perform several electromagnetic brake tests immediately after trial run again.

7 Schematic Diagrams of Electric

7.1 Circuit diagram




CLB1216、CLB1229A SCHEMATIC DIAGRAM




CLB1229、CLB1236、CLB1232 SCHEMATIC DIAGRAM

7.2 Wiring diagram



CLB1216、CLB1229A WIRING DIAGRAM




CLB1229、CLB1236、CLB1232 WIRING DIAGRAM

Following are names of electric components:

1	GB	Accumulator	14	P	Capacity indicator
2	B+	Positive pole of accumulator.	15	KM	Pump station contactor
3	B-	Negative pole of accumulator.	16	KM _T	Main contactor
4	MU	Fuse	17	YD	solenoid valve
5	FU,FU1,FU2	Fuse	18	H	Horn
6	B	accelerator	19	E	CURTIS 1243 controller
7	M	Drive motor	20	D1、D3、D4、D5	Diode
8	S1	Lowering button	21	SM	Emergency stop button
9	S2	Lifting button	22	SY	Key switch
10	S5	Horn button	23	K	24V electro-discharge module
11	S6	Emergency reverse switch	24	YB	electromagnetism band-type brake
12	SA	Switch	25	SH	Mode switch
13	A1、A2、A3、A4	Wiring board	26	SU	Lifting limit switch

7.3 Hydraulic system

CLB1216, CLB1229, CLB1232, CLB1236



CLB1229A

