



# **Multi Variable Air Conditioners Ducted Type Indoor Unit Owner's Manual**

Models :

OV-R224P/Na-M

OV-R280P/Na-M

# Please read this manual carefully before operating

Thank you for choosing ONIDA Air Conditioner Units, please read this manual carefully before using this unit and operates it correctly according to guideline in this manual, and keeps it for reference.

<b>CONTENTS</b>	User notices		1	
	Safety Precautions		3	
	The selection of installation place and notice of the air conditioner unit		4	
	Install the ducted type indoor unit		6	
	Name and Function of Each Part of Ducked Type Indoor Unit		20	
	Working Temperature Range		21	
	Wired remote control operation procedure	The components of the wired remote control		22
		On/Off operation		22
		Timer setting		23
		SLEEP mode setting		24
		Fan Speed Control		24
		Temp. adjusting		25
		Set of running mode		25
		Malfunction display		25
	Remote controller operation procedure	Names and functions of every button of the remote control		27
		Names and functions of every button of the remote control (Remove the cover)		28
		Operation procedure		29
		How to insert batteries		29
	Trouble shooting		30	
	Care and maintenance		31	
	Performance parameters list of the ducted type indoor unit		32	

# USER NOTICES

- ☆ **When the unit is operating, the total capacity of the indoor units should be no more than the capacity of outdoor unit. Otherwise, it can cause the shortage of cooling capacity (heating capacity) of each indoor unit.**
- ☆ **The power supply of the indoor unit must be the unified power supply. The indoor unit cannot have the individual power switch, and the entire indoor unit can only be controlled by one main power control. Disconnect the main power of all the indoor units before cleaning.**
- ☆ **In order to start the unit successfully, the general power supply switch of the air-conditioning units should be turned to the “ON” position for 8 hours before running.**
- ☆ **After each of indoor units received the stop running signal, the fan motor of the indoor unit will use the surplus cool or surplus heat of the heat exchanger go on running for 20-70 seconds, this is the preparation for the next time use and this is the normal phenomenon.**
- ☆ **When the selected mode of the indoor unit conflict with the mode of outdoor unit, after 5 seconds, the wired remote control will display the operation conflict, the indoor unit will stop running, then to unify the running modes of the indoor unit and outdoor unit, the unit will get right. There is no conflict in the COOL mode and DRY mode, the FAN mode will not conflict with any other modes.**
- ☆ **The appliance shall not be installed in the laundry**
- ☆ **An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring**
- ☆ **Missing information regarding electric supply tolerances( $\pm 10\%$ ,  $\pm 1\text{Hz}$ ) in documentation**
- ☆ **Missing information regarding humidity (30-95%) in documentation**

- ☆ **Missing information regarding installation altitude (max 1000m) in documentation**
  
- ☆ **Information regarding transport/storage temperature (-25-55°C) is missing**
  
- ☆ **Main switch provided by end user: main switch handle should be black or gray, it can be locked in “OFF” position with padlock**
  
- ☆ **The main disconnection device should be explained in user manual and the height should be recommended at 0.6-1.7m. over current protection is required(EN 60947-3, EN 60947-2)**
  
- ☆ **The cooling range of the unit is the outdoor environment temp.18-43°C DB, the heating range of the unit( only for the heat pump type unit) is the outdoor environment temp. -16-15°C WB.**

# Safety Precautions

---

1. Before using the appliance, read this manual thoroughly and operate under its direction.
2. “WARNING” and “ATTENTION” have the following meanings in these instructions:



**WARNING!** : This mark indicates procedures, which if improperly performed, might lead to the death or serious injury of the users.



**ATTENTION!** : This mark indicates procedures, which if improperly performed, might possibly result in personal injury to the user, or damage to property.



## **WARNING !**

- ⌘ When install the unit, please refer to the special arrangement maintenance center. If improperly performed, it can cause the water leakage, electric shock and fire etc. accidents.
- ⌘ Please install the unit to a steady and stable place. If the intension is inadequate, the unit will drop off and will lead to the personal injury and death.
- ⌘ In order to make sure the right water drainage, the installation of drainage pipe should be according to the installation methods of this manual, and also adopt the heat retaining measure to prevent the water condensing. If installed improperly, it will cause water leakage and might moisten the furniture.
- ⌘ Do not use or store the combustible and detonatable materials near the air conditioner.
- ⌘ When malfunction happened (there is the burning smell etc.), please power off the general power supply of the units.
- ⌘ Keep the well ventilation in order to avoid the oxygen lack.
- ⌘ Do not insert hands or other objects into the inlet or outlet grille.
- ⌘ Due to the long time use, please check the mounting frame if broken or not.
- ⌘ Do not refit the unit. When need to maintenance or remove the unit, please contact with the local dealer or the professional.



## **ATTENTION !:**

- ⌘ Ensure the power supply correspond to the nameplate and check the security of the power source before installation.
- ⌘ Make sure that the wires, pipes and drain hose are properly connected before operation to avoid a fire or electric shock.
- ⌘ The general power supply must be reliably earthed! To ensure the units are earthed available, to avoid the electric shock. The earth wire can't be connected to the gas pipe, water pipe, wires of the lightning rod and telephone.
- ⌘ Once the units start, need at least more than 5 minutes running then it could be turned off.
- ⌘ Don't let children operate the units.
- ⌘ Do not operate the units with wet hands.
- ⌘ When cleaning the air conditioner or changing filters, please turn off the general power supply of the units firstly.
- ⌘ Switch off power source when the units will not be operated for a long period.
- ⌘ Do not expose the units to the water place or the damp place or the corrosion environment.
- ⌘ After installation, when electrified the electric leakage should be tested.

## The selection of installation place and notice of the air conditioner unit

### ● The selection of the installation place of the air conditioner unit

The installation must accord with the national and local safe criterion.  
Since the quality of installation would affect the operation directly, user should contact the seller and have the conditioner installed and tested by the professional install personnel according to the install instruction instead of install by himself/herself.  
Only connect the power after all the installation works are finished.

### ● The selection of the installation place of the indoor unit

- ☆ Prevent direct sun burn.
- ☆ Make sure that the top steeve, ceiling, and the structure of the construction etc. is strong enough to bear the weight of the unit.
- ☆ The drainage pipe is easy to drain.
- ☆ The air flow is not blocked at the outlet and intake vents.
- ☆ The connecting pipe indoor and outdoor can be lead to outside conveniently.
- ☆ The unit cannot be installed in the place where stored the flammability, easy exploded thing or the place where would have leakage of flammability and exploded gas.
- ☆ The unit cannot be installed in the place where has the corrupt gas and serious dust, saline fog, lampblack and huge humidity.

#### **Note!**

The air conditioner unit installed in the following place may have malfunction, if the malfunction cannot prevent, please contact the Nominated Repair Center Of MIRC Electronics Ltd., Mumbai.

①the place with greasy all around; ②the seashore place with salinity and alkali; ③the place with vulcanized gas( such as vulcanized hot spring); ④the place with high frequency equipment ( such as wireless equipment, electric welding machine and medical treatment equipment);⑤the place with special environment.

### ● The electric cord disposal

- ☆ The cord disposal should be installed according to the National Principal.
- ☆ The power must use the rated voltage and the electric circuit specific for air conditioner unit.
- ☆ Please don't pull the power cord vigorously.
- ☆ All the electric equipment should be installed by the professional personnel according to the local law, regulation and this instruction.
- ☆ The power cord diameter should be big enough, the destroyed power cord and connecting cord should be replaced by the specific cord.

## The selection of installation place and notice of the air conditioner unit

---

- ☆ The earthing should reliably connected with the specific earthing equipment in the architecture, and this should be done by the professional personnel. There must be creepage protection switch and air switch with enough capacity in the rated circuit (reference the following form). The air switch should maintain the functions of magnetic de-buckle and heat de-buckle to assure the protection when circuit-short and overload happen.

### ● Earthing requirement

- ☆ The air conditioner is class I appliance, so please do take the reliable measurement to earthing.
- ☆ The yellow and green cord in the air conditioner unit is earthing cord which cannot be used for other purpose, and cut off, as well as fixed up with screw. Otherwise, it would lead electric shock.
- ☆ The reliable earthing terminal must be offered by the user power. And please don't connect the earthing cord to the following place:
  - ① Tap water pipe; ② Coal gas pipe; ③ Ejection pipe; ④ The place that is consider to be not reliable by the professional personnel.

### ● The attachment used for installation

Every attachment used for installation of the indoor and outdoor unit please refer to the packing list in every individual package carton.

# Install of the ducted type indoor unit

## ● Shape dimension diagram of indoor unit

1). The dimensions of installation hole and the intake/outlet port are shown in Fig. 1 and Table 1.  
The following figure is applicable to the indoor units of OV-R224P/ Na-M, OV-R280P/ Na-M




Fig. 1

Look into from air outlet vent, the wiring is in the right of the unit.

Table 1

Model	a	b	c	d	e	f
OV-R224P/ Na-M OV-R280P/ Na-M	1560	910	1194	1194	292	342



# Install of ducted type indoor unit

## ● Schematic diagram of installation spaces

2). Main body of the indoor unit The indoor unit should be installed horizontally and the demand of installation space is shown in Fig. 2. To install an indoor unit needs 4 hanging rods, and each hanging rod should at least withstand four times of the unit's weight.




Fig.2

## 3). Drain hose

For easy drainage of the condensation water, the should be installed with a downward gradient. To avoid the condensation, the connection pipe joint should be insulated with thermal insulation material. A water seal should be employed as shown in Fig. 3 and the height of the water seal could be determined by the pressure of the drain hose.

Drain hose is in negative pressure state:  $A = B \geq P/10 + 20$  (mm)

Drain hose is in positive pressure state:  $A \geq 30\text{mm}$ ,  $B \geq P/10 + 20$  (mm)

Note: P is the absolute pressure of the drain hose position, Pa




Fig.3


## 4). Refrigerant pipe insulation layer

To avoid condensation of dew and water leakage, gas pipe and liquid pipe of refrigerant should be insulated with thermal insulation material and adhesive tape.

# Install of ducted type indoor unit

## 5). Install the Electrical Box.

In order to ease the maintaining work, we recommend to get of the electrical box part of the indoor unit to refix it at the air outlet part. Please see following Fig 4.



**Fig. 4 Schematic for the Electrical Box part**

## 6). Adjust the tightness of the belt of the fan unit

The rotation of the fan is achieved by the transmission of the belt. The velocity and stability of the fan is associated with the tightness of the belt and the tightness should be adjusted after a period of time. For a new belt, the tightness should be adjusted for at least twice within 24 hours. After one week running, the tightness of the belt should be adjusted again, we should routinely check it every 1-2 months; also ensure the test results complying with Table 2. The adjustment of the tightness of the belt is shown in Fig. 5. Loosen screws fixing motor on the base, move motor along the direction of arrow as shown in the picture, then fix the screw again.


The tightness level of belt is tested by tensiometer as shown in Fig. 6, when  $\Delta$  reaches the deviation length (Deviation = The total length belt / 64), read the value on the meter, the value should be in the category specified in Table 2.

**Table.2 Tension range of the belt**


Section area of the belt	Diameter of the small belt (mm)	Tension (N)	
		Min	Max
SPA	Φ80	7.5	10.9
SPZ	Φ80	7.2	8.3
	Φ71	5.8	6.6
	Φ67	7.8	9.0

# Install of ducted type indoor unit

---



**Fig. 5 Adjust the tightness of the belt**



**Fig. 6 Utilization of the belt tensiometer**

# Install of ducted type indoor unit

---

## Attention:

- There should be thermal insulation layers around the air delivery and air return ducts as well as on the new air ducts to protect against heat losses and condensation. Adhere the plastic nails onto the ducts, and then attach a layer of insulation cloth with the tinfoil onto the ducts. Fix the plastic nail and then seal tightly the joints by way of tinfoil tapes. Some other materials with good thermal insulation properties can also be used.
  - The air delivery and air return ducts should be fixed to the prefabricated ceiling boards with iron stands. The joints of the air ducts should be sealed tightly to prevent from air leakage.
  - The designing and operation of the air ducts should comply with the related state standards and procedures for engineering.
  - It is recommended to leave at least a space of 150mm between the edge of the air return duct and the wall, and a filter screen should be placed at the air return opening.
  - Muffling and vibration reduction should be taken into consideration during the designing and operation of the air ducts. In addition, the noise source should be kept away from the crowds. It is absolutely not allowed to design the placement of the air return opening right above the head of the users (in the offices, lounges or other public sites).
- Installation of Condensed Water Pipes

The condensed water pipes should be kept at 5—10 degrees of gradient to facilitate discharge of the condensed water. Thermal insulation materials should be placed at the joints of the condensed water pipes so as to prevent from dew condensation. (As shown in Fig.7)





Fig.7: Thermal insulation of the condensed water pipe

 Attention: It must be made sure that there is no leakage at the joints of the condensed water pipes.

## Install of ducted type indoor unit

---

### ● Designing of the Drainage Pipelines

- ☆ The drainage pipes should be kept at a certain gradient (1/50—1/100) so as to avoid bulges of pipes where there might be water bends.
- ☆ When connecting the drainage pipes with the unit, care must be taken not to exert too much force on the pipelines of either side of the unit, and the pipes should be fixed as close to the unit as possible.
- ☆ The drainage pipes can be the locally purchased hard PVC pipes for common purposes. When making the connections, the end of the PVC pipe should be inserted into the drainage hole. Use drainage hose and wire bondage to fix it tightly. It is not allowed to use adhesive glue to join the drainage hole and the drainage tube.
- ☆ When the drainage pipeline is laid for a couple of units, the position of the shared pipeline should be approximately 100mm lower than the drainage outlet of each unit. In this case, some special-purpose pipes with thicker walls will be used.


### ● Testing on the Drainage System

- ☆ Upon completion of the installation of the electric appliances, the testing on the drainage system should be performed.
- ☆ During the testing, it should be made sure that the water flows through the pipeline in the correct direction. Careful observations should be made on the joints to ensure that there is no leakage of water at the joints.
- ☆ In the case that the unit is to be installed in a new building, it is recommended that the testing be made prior to the decoration of the ceiling.

## ● Install of ducted type indoor unit

### Function description of functional dial switch S7

- ☆ Before power on of the main board, 4-bit dial switch must be set to decide running status of indoor unit.
- ☆ Function description is as below:




The DIP switch setting showed in above illustration is the default setting after manufactured.

Dial switch Silk-screen	Function description	Dial ON	Dial OFF
1 (S/R)	Selection of memory mode: A. Selection between recovery mode after power on and standby mode after power on B. This function is effective without wired controller.	Standby after power on	Recovery after power on
2 (L/I)	Selection between receiver and manual controller: A. If manual controller is selected; remote-control function of receiver will be shielded. B. If receiver is selected, manual controller will be ineffective.	Select wired controller to operate	Select receiver to operate
3 (M/S)	Setting of master unit and slave indoor unit A. Used to solve modes conflict B. This function is effective without wired controller.	Master unit	Slave unit
4 (I/O)	Selection of ambient temp. sensor: A. selection between ambient temp. sensor (T amb.) of main board and ambient temp. sensor (T amb.1) of receiver This function is effective without wired controller.	Select ambient temp. sensor of main board	Select ambient temp. sensor of receiver
5 (L/H)	Select to choose high E.S.P or low E.S.P fan speed	Select low E.S.P fan speed	Select high E.S.P fan speed

# Install of ducted type indoor unit

## Notes:

1. When you choose to equip the receiving board (this component is optional) on the units it is required that set the 2nd position of S7 DIP switch to OFF position, meanwhile if need to plug the communication cable from receiving board into 9 core terminal CN20 which locates on the mainboard, and wired remote controller is disabled.
2. When you choosed to equip wired remote controller to the units, it needs to set the 2nd position of S7 DIP switch to the ON position, and connect 4 core communication cable to CN19 terminal on the mainboard; the address code on wired remote controller and indoor mainboard address code **MUST BE THE SAME**, after doing this, the receiving header is disabled.
3. The driving method of the blower on OV-R224P/Na-M and OV-R280P/Na-M is Belt driving, there is only 1 fan speed, if need to adjust the E.S.P, it is required that the adjustment of the pulley is within safe range (please consultant technical professionals)



5 bits functional DIP switch mainboard


# Install of ducted type indoor unit

## 1.Address code switch

All the indoor units of OV system must set the address code properly, else will cause communication abnormal between outdoor and indoor unit. There are total 4 bit of address code, with address code range from 1 to 16.

**⚠ Notice! When more than 1 indoor units is connected parallel, please modify the address code setting of the units before installation, their address code should be different from each other: (address code DIP switch locates on the main board of indoor units); if add wired remote controller to the unit, make sure the address code on controller is the same as on the indoor unit. (address code DIP switch of wired remote controller locates at the back of the controller)**

☆the default setting of DIP address setting is show as below:



Address

Default setting of address code DIP switch is 0000, and address is 1 (position showed as above)

☆Address DIP switch code list

The address code setting is based on binary, the “ON” side represents 0, while opposite side represents 1; on address code DIP switch, there are 4 position, 4 position is high side, 1 position is low side;

Address	1				2				3				4				5				6				7				8							
DIP position	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4
Set value	0	0	0	0	1	0	0	0	0	1	0	0	1	1	0	0	0	0	1	0	1	0	1	0	0	1	1	0	1	1	1	0				
Address	9				10				11				12				13				14				15				16							
DIP position	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4
Set value	0	0	0	1	1	0	0	1	0	1	0	1	1	1	0	1	0	0	1	1	1	0	1	1	0	1	1	1	1	1	1	1				

e.g.1: set DIP switch as “0111” represent address “8”, set DIP switch 1,2,3 position to OFF side, while set 4 position to ON side;

e.g.1: set DIP switch as “1010” represent address “11”, set DIP switch 2,4 position to OFF side, while set 1,3 position to ON side;

example showed as below:



Address 8: DIP value 0111



Address 11: DIP value 1010



# Install of ducted type indoor unit

## ● Usage of receiving board

When choose to use remote signal receiving board, do set 2<sup>nd</sup> position on the S7 functional DIP switch to the “OFF” side, then connect the receiving board to the main board.

For duct type indoor units, there are two options: work with remote signal receiving board or wired remote controller; if choose to use the receiving board, the wired controller can not put be put into work at the same time.




Fig.8 wiring between main board and receiving board




Fig.9 Power/communication Wiring illustration of wired remote controller

## Install of ducted type indoor unit

When connect wired controller to main board showed as Fig.9, use a 4 cores cable to set up a communication wiring from CN19 terminal on the main board to CN1 terminal on the wire controller. Make sure the power is shut off before the wiring; check if the wiring is firmly and prevent any circuit shortage after finishing this step one more time. There are 4 pieces of wires in the cable of controller. (all included in the 4 cores cable), count from upper right direction of wiring terminal are the name of the wires: Earthed wire (GND), communication wire A (A), communication B (B), power wire (+12V)

### ● Install the wired remote controller




Fig.10 Installation of wire remote controller

SN	1	2	3	4
Name	Casing base, installed into the wall	Controller Soleplate	Screw M4X25	Controller Panel

### ● Notice for installation under the guidance of Fig.10

1. Cut off power supply before install the electrical components, it is forbidden to carry out the installation with power on;
2. Get one end of the 4 core communication cable, put it through the rectangular hole on the base board on the wire remote controller;
3. hold the base board of controller on the wall, then fix it to the wall with M4x25 screw;
4. Plug the 4 core communication cable into the slot on the wired remote controller, then fix the controller panel with base board together;

# Install of ducted type indoor unit

● Connection between the Electric Wires and the Terminals on the Terminal Plate: (As shown in Fig.11)

## A. Connection of mono-branching wires

1. Use a wire stripper to strip off about 25mm of the insulation layer at the end of the mono-branching wire;
2. Remove the screws on the wiring board of the air conditioner unit;
3. Use the pliers to bend the end of the wire into a ring shape corresponding the size of the screw;
4. Pass the screw through the wire ring and fix it onto the wiring board.

## B. Connection of multi-ply stranded wires

1. Use the wire stripper to strip off about 10mm of the insulation layer of the stranded wires;
2. Remove the screws on the wiring board of the air conditioner unit;
3. Use the wire pressing pliers to press the ends of the multi-ply stranded wires onto the terminals corresponding to the size of the screws;
4. Pass the screws through the terminals of the multi-ply stranded wires and fixes them onto the wiring board.




Fig.11

## ⚠ Warning:

1. If the power cord or signal cord of the unit is damaged, special-purpose cords must be used for replacement;
2. Please identify the voltages for the components indicated on the nameplate before doing the wire connection, and then connect the wires in accordance with the schematic diagram of wiring.
3. The air conditioner unit should use the special-purpose power cord, and should be equipped with breaker or air switch so as to handle the occurrence of overloads;
4. The air conditioner unit must be properly grounded to prevent from the damages caused by the failure of insulation;
5. All the distribution wires must use the press-connecting terminals or single wires. The direct connection between the multi-ply stranded wires and the terminal board might lead to sparking;
6. All the wiring must follow the schematic diagram for the electric circuits. Any erroneous wiring and connection might result in the abnormal operations or damages of the air conditioner unit;

## Install of ducted type indoor unit

---

7. All the wiring must follow the schematic diagram for the electric circuits. Any erroneous wiring and connection might result in the abnormal operations or damages of the air conditioner unit; Do not allow the power cord to contact the pipelines or any moving parts like the compressor or fan;
8. The internal wiring of the air conditioner unit should not be altered without authorization. The manufacturer shall not be responsible for any losses or abnormal operations incurred from such unauthorized alterations.

### ● Connection of Distribution (Communication) Wires:

- 1、 Open the cover of the electric box of the indoor unit;
- 2、 Pass the distribution (communication) wire through the rubber gasket;
- 3、 Insert the distribution (communication) wire into the three pin stands of CN17 or CN18 on the electric circuit board of the indoor unit;
- 4、 Bind the distribution (communication) wires firmly together and fix them.

### ● Connection of Power Supply Lines:



**Attention: The power supply for various indoor units must be from the unified power supply.**

#### A、 Air conditioner units using single-phase power supply

1. Remove the cover of the electric box of the indoor unit;
2. Pass the power supply cord through the rubber gasket;
3. Connect the power cord to the L and N terminals as well as the grounding screw;
4. Bind the cord and wires firmly together and fix them properly;

#### B、 Air conditioner units using three-phase power supply。

1. Put power cable through rubber insulation ring。
2. Connect the power cord to the L1、 L2、 L3 and N terminals as well as the grounding screw。
3. Fix the power cable firmly by cable fixing clip。

## Install of ducted type indoor unit

---

- Connection of Remote controller Signal Wire:

1. Open the cover of the electric box of the indoor unit;
2. Pass the signal line of the remote controller through the rubber ring;
3. Insert the signal line of the remote controller into the four-positioned pin stands (CN19) on the electric circuit board of the indoor unit;
4. Bind the signal lines of the remote controller firmly together and fix them.




**Attention:**

Special precaution must be taken when doing the following connections so as to prevent from the failure of the air conditioner unit due to EMI (electromagnetic interference).

1. The signal lines and the distribution (communication) wires should be separated from the power supply cord and the connection lines between the indoor and the outdoor units;
2. In the case that the air conditioner unit has to be installed at the places subject to the EMI, it is advised to use shielded and double-strand wires for the signal lines and distribution (communication) wires.

# Name and Function of Each Part of Ducked Type Indoor Unit



DUCTED TYPE INDOOR UNIT

- ① Outlet vent
- ② Air return vent
- ③ Condensation Pipe

**NOTE: 1.Connection pipe and Air pipe are not included in this Air conditioner**

# Working Temperature Range

---

**Working Temperature Range**

	Indoor side state		Outdoor side state	
	Dry bulb temp. °C	Wet bulb temp. °C	Dry bulb temp. °C	Wet bulb temp. °C
Rated Cooling	27	19	35	24
Max. cooling	32	23	43	26
Min. cooling	21	15	18	—
Rated Heating	20	15	7	6
Max. heating	27	—	21	15
Min. heating	20	15	−15	−16

# Wired Remote Controller Operation Procedure




Fig. 12

Various Components of Wired Remote Controller			
1	Operating mode display (Cool, Dry, Fan, Heat)	9	On/Off button
2	Sleep mode display	10	Timer button
3	Environmental temp. display /Malfunction display	11	Sleep button
4	Fan control display (automatic, high, media, low)	12	Swing display
5	Set Temp. display	13	Fan control button
6	Defrosting display	14	Temp./ Timer decrease button
7	Timer display	15	Temp./ Timer increase button
8	Signal receptor	16	Mode button

## 1) On/Off (Fig.13)

- ☞ When press the ON/OFF key, the unit will start.
- ☞ When press ON/OFF key again, the unit will stop.

**NOTE:** Fig.13 shows the closedown status after power on. When the communication is normal, both at the running and stopping status will display the environment temp. Here, there is no “graticule line” on the LCD of Fig.14, it shows the unit is closedown..




Fig.13



# Wired Remote Controller Operation Procedure

2) Timer setting (Fig.14, hereinafter will be displayed according to the function of the wired remote controller.)

☞ At stopping, press TIMER ON button, set ON TIME, at operating, press TIMER OFF button, set OFF TIMER.

☞ When it is not timed (i.e. there is no show content in the timing display field), press TIMER ON, the liquid will display the pattern of “⌚ xx.x hour”, “⌚” and “HOUR” the samples will be flashed in every 0.5second on and on, at this time press “▲” or “▼” button to set time. After using “▲” or “▼” button, adjust to the desired temperature, then press the TIMER button, at this time “⌚” and “HOUR” will not flash, that shows the TIMER ON has been set.

☞ After power on, to press the TIMER button once, LCD will display “⌚ 0.0 HOUR”, The sign of “⌚” and “HOUR” will twinkle, when repress the TIMER button, the LCD will not display the sign, that shows the TIMER ON has been canceled.

☞ When the TIMER ON has been set, (i.e. the sign of “⌚” and “HOUR” will twinkle continuously), if press the TIMER button once more, LCD will show “⌚ xx.x HOUR” (Note: “xx.x” is the time of last setting, after power on it will be cleared automatically), the sign of “⌚” and “HOUR” will twinkle continuously, at this time could press “▲” or “▼” button for time setting, or press the TIMER button again to confirm the function of time.

☞ The range of TIMER ON and TIMER OFF is from 0.5hour to 24hour. Press “▲” or “▼” button for each time, the set time will be increased or decreased 0.5hour, hold the press “▲” or “▼” button, it will increase 0.5hour or decrease 0.5hour every other 0.5second. The setting range of “▲” and “▼” is from 0 to 24, and they are circulatory.






Fig.14



**NOTE:** The Fig. shows the relevant display area.

# Wired Remote Controller Operation Procedure

## 3 ) SLEEP mode setting ( Fig.15 )

☞ When PCB is running at COOL or DRY mode , after received the SLEEP mode setting and run for 1 hour, the preset temperature  $T_{set}$  will be increased  $1^{\circ}\text{C}$ , 2 hours later it will be increased  $1^{\circ}\text{C}$  again, it has been increased  $2^{\circ}\text{C}$  totally within 2 hours, then the unit will run accord to the setting temperature.

☞ When the PCB is running at HEAT mode , after received the SLEEP mode setting and run for 1 hour, the preset temperature  $T_{set}$  will be decreased  $1^{\circ}\text{C}$ , 2 hours later the  $T_{set}$  will be decreased  $1^{\circ}\text{C}$  again, it has been decreased  $2^{\circ}\text{C}$  totally within 2 hours, then the unit will run accord to the setting temperature.

☞ There is no SLEEP function in FAN mode.





Fig.15

## 4) Fan Speed Control ( Fig.16 )

☞ Press FAN SPEED button each time, fan speed will be changed as following:



☞ AT DRY mode : The fan speed will be set to the LOW speed automatically.




Fig.16

# Wired Remote Controller Operation Procedure

## 5) Temp. adjusting (Fig.17)

☞ When not setting the time, press “▲” and “▼” button, can set the temperature adjustment.

▲: For increasing setting temperature;


▼: For decreasing setting temperature.

(When press this button, the temperature will be increased or decreased in the unit of 1°C.)

☞ The temperature setting range is 16°C~30°C at every kind off modes

## 6) Set of running mode (Fig.18)

☞ When pressing MODE button each time, the mode will be changed as following:



☞ At “COOL” mode, the COOL display will be light on, the temperature of setting should be lower than the room temperature. If the setting temperature is higher than the room sensor, the unit will not run at cool mode operation.

☞ At “DRY” mode, the DRY display will be light on. Fan motor will run at low fan speed in the definite temperature range. The dehumidifying effect of this mode is better than that in COOL mode and more energy saving.

☞ At “HEAT” mode, the HEAT display will be light on. The temperature should be set higher than the room temperature; If the setting temperature is lower than the room temperature, the unit will not run at HEAT mode operation.

☞ At “FAN” mode, the FAN display will light on.

## 7) Malfunction display (Fig.19)

☞ When the malfunction happened during the operation, the environment temperature display area will show the error code. As shown in Fig.19 it shows the compressor high-pressure protection.

☞ When the malfunction happened, except for the FAN mode is in operation, at the mode of COOL, DRY, HEAT, the outdoor unit and fan motor are closedown, that will not affect the LCD display.




Fig.17




Fig.18




Fig.19

# Wired Remote Controller Operation Procedure

---

☞ When the controller displays malfunction, please turn off the unit to stop the malfunction display, ask for the professional to debug.

The meaning of error codes as shown in below:

Malfunction code	Malfunction
E1	High pressure protection of compressor
E2	Indoor anti-frozen protection
E3	Low pressure protection of compressor
E4	Discharge temp. protection of compressor
E5	Compressor overload protection
E6	Transmit malfunction
E7	Modes conflict
F0	Indoor environment temp. sensor mal-function
F1	Indoor pan tube inlet tube temp. sensor malfunction
F2	Indoor pan tube middle temp. sensor malfunction
F3	Indoor pane tube outlet tube temp. sensor malfunction
F4	Outdoor environment temp. sensor mal-function
F5	Outdoor pan tube inlet tube temp. sensor malfunction
F6	Outdoor pan tube middle temp. sensor malfunction
F7	Outdoor pan tube outlet tube temp. sensor malfunction
F8	Discharge temp. sensor 1 (rated frequency) malfunction
F9	Discharge temp. sensor 2 (digital) malfunction
FA	Greasy temp. temp. sensor 1 (rated frequency) malfunction
Fb	Greasy temp. temp. sensor 2 (digital) malfunction
FC	High pressure sensor malfunction
Fd	Low pressure sensor malfunction


# Remote controller operation procedure

## Names and functions of every button of the remote control



### NOTE!

- Make sure that there is no obstruction between the remote control and the signal receptor.
- The remote control signal can be received at the distance of up to about 10m.
- Don't drop or throw the remote control.
- Don't let any liquid flow into the remote control.
- Don't put the remote control directly under the sunlight or any place where is very hot.



### NOTE!


After every indoor unit received the turn off signal, the fan and electric inflate valve will continue to work for 20-70mins to make use of the rest cool or rest heat, while for preparation for the next work. And this is normal phenomenon.

# Remote controller operation procedure

## Names and functions of every button of the remote control (Remove the cover)

### NOTE!

This type of remote control is a kind of general use remote control that is suitable for several types (function) of air conditioner units. Please understand that the functions and buttons that are not suitable for this air conditioner will not be introduced.



# Remote controller operation procedure

## Operation procedure

### Normal procedure

1. Press ON/OFF button after connected with the power, then the unit is operating.
2. Press MODE button to choose the need operation mode.
3. Press FAN button to set the fan speed.
4. Press +/- button to set the need temp..

### Selectable procedure


5. Press SLEEP mode to set the sleep state.
6. Press TIMER OFF button to set the set time.

**Note: When the operating mode selected by the indoor unit is clash with the one selected by the outdoor unit, the remote controller will display the operating clash after 5 seconds and the power light will flicker, then the indoor unit turns off. At this time, the units will become normal after the operating mode of the indoor unit is changed to cooperate with the outdoor unit. Cool mode can cooperate with dry mode, and fan mode can cooperate with any mode.**

## How to insert batteries

Two batteries (Two AAA dry-cell batteries) are used by the remote control

1. Remove the cover from the back of the remote control downward, take out the worn batteries and insert two new ones (Make sure the two poles are correct)
2. Re-attach the cover.



1. All the prints and code no. will be showed on the displayer after the insert of batteries. The remote control can be operated after 10sec.
2. The lifetime of the batteries is about one year.
3. Don't confuse the new and worn or different types of batteries.
4. Remove batteries when the remote control is not in use for a longtime to avoid mal-function caused by liquid leakage.
5. The remote control should be placed about 1m or more from the TV set or any other electric appliances.
6. The remote control should be used in the receivable range (the reception range is 10m)
7. When the remote control can not be controlled in the situation of inserted batteries, please remove the back cover and press "ACL" button to make it normal.

# Trouble Shooting

---

If the malfunction occurs, please check item shown below before requesting on service center.

Phenomenon	Cause
The unit can't start	<ol style="list-style-type: none"> <li>1. The power supply is not connected well.</li> <li>2. The electrical leakage cause the jump</li> <li>3. The voltage is too low.</li> </ol>
Although the unit can run, after a while it will stop.	<ol style="list-style-type: none"> <li>1. The inlet vent and outlet vent are blocked</li> </ol>
The cooling effect is not good.	<ol style="list-style-type: none"> <li>1. The air filter is dirty or blocked</li> <li>2. There are heat sources in the air conditioner room or too many people in this room.</li> <li>3. The door or window is opened.</li> <li>4. There are obstructions in the air inlet or outlet grille.</li> <li>5. The set temp. is too high, that will affect the cooling effect.</li> </ol>
The heating effect is not good.	<ol style="list-style-type: none"> <li>1. The air filter is too dirty, or blocked.</li> <li>2. The door or window isn't closed well.</li> <li>3. The set temp. is too low, that will affect the heating effect.</li> </ol>
The remote controller can not work	<ol style="list-style-type: none"> <li>1. When replacing batteries or under other conditions, sometimes the "Machine Death" phenomenon is shown on the remote controller, please remove the rear cover, then press "ACL"(reset key), the unit will get back</li> <li>2. Is it in the receiving range? Or are there any obstructions?</li> <li>3. For the ducted type indoor unit, the remote controller should be aimed at the wired remote control for the control.</li> <li>4. To check the voltage of batteries is enough or not, if not enough please change it.</li> </ol>

**NOTE:**

After checking the above items, the unit still can't be operated, please turn off the unit immediately and contact with the local service center and ask for the professional to maintain.



# Care and Maintenance

---

## **ATTENTION: Please pay more attention to the following items before cleaning the units**

- ⌘ The general power supply of the indoor units must be powered off before contacting the wiring device;
- ⌘ Only when unit is turned off and the general power supply is cut off, the unit could be cleaned, otherwise it might cause the electric shock or injury;
- ⌘ Do not use water to clean air conditioners, or it may cause electric shock;
- ⌘ Especially when cleaning the units you should pay more attention, to stand on the firm place.

### **Daily Care**

#### **(1) Clean the air filter**

- ⌘ When not cleaning the air filter please do not disassembly the filter, or it will cause the malfunction.
- ⌘ When there is a lot of dust, the air filter should be cleaned many times (generally once for every two weeks)

#### **(2) The care of the season begin to use**

- ⌘ Check the inlet and outlet of the indoor units blocked or not;
- ⌘ Check the wires earthed well or not;
- ⌘ Check the lines connected well or not;
- ⌘ After switching on, the indicator lights of the wired remote control should light.

**NOTE: If there is any abnormal phenomenon, please operate the unit under the direction of after service.**

#### **(3) The care of the season end to use**

- ⌘ When the weather is fine, set the unit in the fan mode and running for half of the day.
- ⌘ When not to use the unit for a long time, please switch off the power supply, the indicator light of the wired remote control should extinguish.

# The Performance Parameters List of Ducted Type Indoor Units

Item		Model	OV-R224P/Na-M	OV-R280P/Na-M
Cooling capacity	W		22400	28000
Heating capacity	W		25000	31000
Air volume	m <sup>3</sup> /h		4000	4800
Noise(H/L)	dB(A)		54	57
Motor input power	W		2000	2000
External Static Pressure	Pa		120	120
Phase number-Voltage-Frequency			380V 3N ~ 50Hz	380V 3N ~ 50Hz
The type of anti-electric shock protection			I	
Outline dimensions	Width	mm	1500	1500
	Depth	mm	1000	1000
	Height	mm	500	500
The aperture of condensing drain pipe		inch	1 "	
Net weight		Kg	Please refer to the nameplate	
Dimensions of air outlet	Length	mm	1194	
	Width	mm	292	
Dimensions of air return	Length	mm	1194	
	Width	mm	342	
Diameter of gas pipe		inch	φ 3/4 "	7/8 φ
Diameter of liquid pipe		inch	φ 3/8 "	3/8 φ

Note:

1. The performance parameters are tested under the rated working condition;
3. Please refer to the actual parameters on the nameplate.
4. The cooling capacity was tested in the condition of outdoor temp.35°C(dry bulb)/24°C(wet bulb), indoor temp.27°C (dry bulb)/19°C(wet bulb)
5. The heating capacity was tested in the condition of outdoor temp.7°C(dry bulb)/6°C(wet bulb), indoor temp.20°C(dry bulb), it is not include the heating capacity of auxiliary electric heat.
6. The value of noise is the value which was tested in the anechoic chamber, the measuring point is 1.4m under the unit, the actual running the temp. will be higher due to the influence of environment.



MIRC ELECTRONICS LTD. Onida House, G-I, MIDC, Mahakali Caves Road, Andheri (East), Mumbai - 400093.  
[www.onida.com](http://www.onida.com) email: [response@onida.com](mailto:response@onida.com)