



Network converter

MECHATROLINK-III compatible

NETC01-M3

USER MANUAL



Thank you for purchasing an Oriental Motor product.

This manual describes product handling procedures and safety precautions.

- Please read it thoroughly to ensure safe operation.
- Always keep the manual where it is readily available.

Table of contents

1	Safety precautions	3	9.4	Read alarm or warning command (ALM_RD: 05h)	24
2	Introduction	4	9.5	Clear alarm or warning command (ALM_CLR: 06h)	24
3	Preparation	6	9.6	Establish connection command (CONNECT: 0Eh)	25
3.1	Checking the product	6	9.7	Release connection command (DISCONNECT: 0Fh)	26
3.2	Names and functions of parts	6	9.8	Data READ/WRITE_A command (DATA_RWA: 20h)	27
4	Installation	8	9.9	Timing chart of the data READ/WRITE_A command	38
4.1	Location for installation	8	10	Troubleshooting and remedial actions	45
4.2	Installation method	8	10.1	Alarms and MECHATROLINK-III communication error	45
4.3	Installing and wiring in compliance with EMC Directive	9	10.2	Warning	48
5	Connection	11	11	Inspection	49
5.1	Connection example	11	12	General specifications	50
5.2	Connecting the power supply and grounding the NETC01-M3	11	13	Operation using the OPX-2A	51
5.3	Connecting the RS-485 communication cable	12	13.1	Overview of the OPX-2A	51
5.4	Connecting the MECHATROLINK-III communication cable	13	13.2	Names and functions of parts	52
5.5	Connecting the data setter	13	13.3	Notation	52
6	Guidance	14	13.4	How to read the display	52
7	Setting	17	13.5	OPX-2A error display	53
7.1	Transmission rate of RS-485 communication	17	13.6	Screen transitions	54
7.2	Operation mode	17	13.7	Monitor mode	56
7.3	Station number	18	13.8	Parameter mode	57
8	MECHATROLINK-III communication format	19	13.9	Copy mode	58
8.1	Data format	19	14	Accessories (sold separately)	60
8.2	Phase	19			
9	Details of command	20			
9.1	No operation command (NOP: 00h)	20			
9.2	Read ID command (ID_RD: 03h)	21			
9.3	Setup device command (CONFIG: 04h)	23			

1 Safety precautions

The precautions described below are intended to prevent danger or injury to the user and other personnel through safe, correct use of the product. Use the product only after carefully reading and fully understanding these instructions.

 Warning	 Caution
<p>Handling the product without observing the instructions that accompany a "Warning" symbol may result in serious injury or death.</p> <p>General</p> <ul style="list-style-type: none"> • Do not use the product in explosive or corrosive environments, in the presence of flammable gases, locations subjected to splashing water, or near combustibles. Doing so may result in fire or injury. • Assign qualified personnel the task of installing, wiring, operating/controlling, inspecting and troubleshooting the product. Failure to do so may result in fire, injury or damage to equipment. <p>Connection</p> <ul style="list-style-type: none"> • Keep the power supply input voltage of the NETC01-M3 within the specified range. Failure to do so may result in fire. • For the power supply of the NETC01-M3, use a DC power supply with reinforced insulation on its primary and secondary sides. Failure to do so may cause electric shock. • Connect the cables securely according to the wiring diagram. Failure to do so may result in fire. • Do not forcibly bend, pull or pinch the cable. Doing so may cause fire. Applying stress to the connection area of the connectors may cause damage to the product. <p>Operation</p> <ul style="list-style-type: none"> • Turn off the NETC01-M3 power in the event of a power failure. Or the motor may suddenly start when the power is restored and may cause injury or damage to equipment. • When an alarm of the NETC01-M3 is generated, stop the motor. Failure to do so may result in fire, injury or damage to equipment. <p>Repair, disassembly and modification</p> <ul style="list-style-type: none"> • Do not disassemble or modify the NETC01-M3. Doing so may cause injury. Refer all such internal inspections and repairs to the branch or sales office from which you purchased the product. 	<p>Handling the product without observing the instructions that accompany a "Caution" symbol may result in injury or property damage.</p> <p>General</p> <ul style="list-style-type: none"> • Do not use the NETC01-M3 beyond its specifications. Doing so may result in injury or damage to equipment. • Keep your fingers and objects out of the openings in the NETC01-M3. Failure to do so may result in fire or injury. <p>Installation</p> <ul style="list-style-type: none"> • Install the NETC01-M3 in the enclosure in order to prevent injury. • Keep the area around the NETC01-M3 free of combustible materials in order to prevent fire or a skin burn(s). • Do not leave anything around the NETC01-M3 that would obstruct ventilation. Doing so may result in damage to equipment. <p>Connection</p> <ul style="list-style-type: none"> • The power supply connector (CN1), MECHATROLINK-III communication connector (CN2), data edit connector (CN3) and RS-485 communication connector (CN6) of the NETC01-M3 are not electrically insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the NETC01-M3 and these equipment to short, damaging both. <p>Operation</p> <ul style="list-style-type: none"> • Use the NETC01-M3 in combination with the designated applicable product. Failure to do so may result in fire. • When operating the product, do so after making preparations that an emergency stop can be performed at any time. Failure to do so may result in injury. • Set a suitable operation speed and acceleration/deceleration rate. Improper setting may cause loss of the motor synchronism and moving the load to an unexpected direction, which may result in injury or damage to equipment. • Immediately when trouble has occurred, stop running and turn off the NETC01-M3 power. Failure to do so may result in fire or injury. • Always use an insulated screwdriver to adjust the switches of the NETC01-M3. <p>Disposal</p> <ul style="list-style-type: none"> • To dispose of the NETC01-M3, disassemble it into parts and components as much as possible and dispose of individual parts/components as industrial waste. Contact your nearest Oriental Motor office if you have any questions.

2 Introduction

■ Before use

Only qualified personnel should work with the product.

Use the product correctly after thoroughly reading the section "1 Safety precautions" on p.3.

The product described in this manual has been designed and manufactured for use in general industrial equipment.

Do not use for any other purpose. For the power supply of the **NETC01-M3**, use a DC power supply with reinforced insulation on its primary and secondary sides. Oriental Motor Co., Ltd. is not responsible for any damage caused through failure to observe this warning.

■ Operating Manuals for the NETC01-M3

Operating manuals for the **NETC01-M3** are listed below.

After reading the following manuals, keep them in a convenient place so that you can reference them at any time.

- **Network converter MECHATROLINK-III compatible NETC01-M3 USER MANUAL**

This manual explains the function, installation and connection of the **NETC01-M3** as well as operating method.

For the command code or remote I/O of the RS-485 communication compatible product that can be connected to the **NETC01-M3**, refer to the USER MANUAL of the corresponding RS-485 communication compatible product.

- **Network converter MECHATROLINK-III compatible NETC01-M3 OPERATING MANUAL**

This manual explains safety precautions, connector pin assignments and others.

- **Data setting software MEXE02 OPERATING MANUAL**

This manual explains the parameter setting method or monitor function using the **MEXE02**.


■ Overview of the product

The **NETC01-M3** is a communication converter between MECHATROLINK-III and RS-485 communication. By converting the MECHATROLINK-III communication protocol of the upper level to the RS-485 communication protocol of the lower level, Oriental Motor RS-485 communication compatible products can be operated via MECHATROLINK-III communication.

The RS-485 communication protocol of the lower level is Oriental Motor's own RS-485 communication protocol.

**Parameters of the NETC01-M3 cannot be set with the master station.
When setting the parameters of the NETC01-M3, use an accessory OPX-2A
or MEXE02 (both are sold separately).**

■ System configuration



* The termination resistor for RS-485 communication is built into the product.

■ CE Marking

Because the input power supply voltage of this product is 24 VDC, it is not subject to the Low Voltage Directive but install and connect this product as follows.

- This product is designed and manufactured to be installed within another device. Install the product in an enclosure.
- For the power supply of the **NETC01-M3**, use a DC power supply with reinforced insulation on its primary and secondary sides.
- Overvoltage category: I
- Pollution degree: 2
- Degree of protection: IP20

● EMC Directive

This product has received EMC compliance under the conditions specified in "Example of NETC01-M3 installation and wiring" on p.10.

Since the conformity to the EMC Directive of the customer's equipment will be affected by various conditions such as other control-system devices used together with the **NETC01-M3**, as well as configuration of electrical components, wiring and installation condition, it therefore must be verified through EMC measurements of the equipment by the customer.

Applicable standards

- EMI: EN 61000-6-4, EN 55011 group 1 class A
- EMS: EN 61000-6-2

■ Hazardous substances

The products do not contain the substances exceeding the restriction values of RoHS Directive (2011/65/EU).

3 Preparation


This chapter explains the items you should check, as well as the name and function of each part.

3.1 Checking the product

Verify that the items listed below are included. Report any missing or damaged items to the branch or sales office from which you purchased the product.

- **NETC01-M3**.....1 unit
- CN1 connector (3 pins)1 pc.
- RS-485 communication cable2 pcs. [0.1 m (3.94 in.), 0.25 m (9.84 in.) each 1 pc.]
- OPERATING MANUAL.....1 copy
- USER MANUAL (CD-ROM)1 pc.

3.2 Names and functions of parts



Name	Description	Ref.
POWER LED (Green)	This LED is lit while the power is input.	-
ALARM LED (Red)	This LED will blink or illuminate steadily when an alarm or MECHATROLINK-III communication error has generated.	p.45
C-DAT LED (Green)	This LED is lit while transmitting and receiving data via RS-485 communication.	-
C-ERR LED (Red)	This LED is lit when an error has occurred via RS-485 communication.	-
CONT LED (Green)	This LED is lit while a connection is established.	-
ERR LED (Red)	This LED is lit when the MECHATROLINK-III communication error has generated.	p.45
RS-485 communication transmission rate setting switch (SW1)	Sets the transmission rate of RS-485 communication. Factory setting: 7 (625 kbps)	p.17
Data edit connector (CN3)	Connects a PC in which the MEXE02 has been installed, or an accessory OPX-2A (sold separately).	p.13
Power supply connector (CN1)	Connects a 24 VDC power supply.	p.11
MECHATROLINK-III station address setting switches (STATION No.×1, ×10)	Sets the station address in the 03h to EFh range. Factory setting: 61h (×10=6, ×1=1) ×10: Sets the upper of the station address ×1: Sets the lower of the station address	p.18
Operation mode setting switch (SW2-Nos.1 to 3)	Sets the operation mode. • SW2-No.1: Sets the remote I/O occupied size. Factory setting: OFF (16 bit mode) • SW2-No.2, No.3: Sets the number of transmission bytes. Factory setting: No.2=OFF, No.3=ON (32 bytes)	p.17
LINK1 LED (Green) LINK2 LED (Green)	These LEDs are lit while MECHATROLINK-III communication is properly connected.	-
MECHATROLINK-III communication connector (CN2-1, CN2-2)	Connects the MECHATROLINK-III communication cable.	p.13
RS-485 communication connector (CN6)	Connects the RS-485 communication cable.	p.12

4 Installation

This chapter explains the installation location and installation methods of the **NETC01-M3**. The installation and wiring methods in compliance with the EMC Directive are also explained.

4.1 Location for installation

The **NETC01-M3** has been designed and manufactured for use as a component to be installed inside equipment.


Install it in a well-ventilated location that provides easy access for inspection. The location must also satisfy the following conditions:

- Inside an enclosure that is installed indoors (provide vent holes)
- Operating ambient temperature 0 to +40 °C (+32 to +104 °F) (non-freezing)
- Operating ambient humidity 85% or less (non-condensing)
- Area that is free of explosive atmosphere or toxic gas (such as sulfuric gas) or liquid
- Area not exposed to direct sun
- Area free of excessive amount of dust, iron particles or the like
- Area not subject to splashing water (rain, water droplets), oil (oil droplets) or other liquids
- Area free of excessive salt
- Area not subject to continuous vibration or excessive shocks
- Area free of excessive electromagnetic noise (from welders, power machinery, etc.)
- Area free of radioactive materials, magnetic fields or vacuum

4.2 Installation method


Install the **NETC01-M3** to a 35 mm (1.38 in.) width DIN rail. There must be a clearance of at least 50 mm (1.97 in.) in the horizontal and vertical directions, between the **NETC01-M3** and enclosure or other equipment within the enclosure. When installing two or more **NETC01-M3** in parallel, it is possible to install them closely in the horizontal direction. Provide a minimum clearance of 50 mm (1.97 in.) in the vertical direction.

Note Be sure to install the **NETC01-M3** vertically (vertical position). If the **NETC01-M3** is installed in the direction other than vertical position, its heat radiation effect will deteriorate.




■ Mounting to DIN rail

Pull down the DIN lever of the **NETC01-M3** and lock it. Hang the hook at the rear to the DIN rail, and push in the **NETC01-M3**. After installation, secure the both sides of the **NETC01-M3** with the end plate.



Removing from DIN rail

Pull the DIN lever down until it locks using a flat tip screwdriver, and lift the bottom of the **NETC01-M3** to remove it from the rail. Use force of about 10 to 20 N (2.2 to 4.5 lb.) to pull the DIN lever to lock it. Excessive force may damage the DIN lever.



4.3 Installing and wiring in compliance with EMC Directive

Effective measures must be taken against the EMI that the **NETC01-M3** may give to adjacent control-system equipment, as well as the EMS of the **NETC01-M3** itself, in order to prevent a serious functional impediment in the machinery. The use of the following installation and wiring methods will enable the **NETC01-M3** to be compliant with the EMC directive. Refer to "CE Marking" on p.5 for the applicable standards.

Oriental Motor conducts EMC measurements on its **NETC01-M3** in accordance with "Example of NETC01-M3 installation and wiring" on p.10. The user is responsible for ensuring the machine's compliance with the EMC Directive, based on the installation and wiring explained below.

■ Power supply

This network converter is a product of DC power supply input. Use a DC power supply (switching power supply etc.) that conforms to the EMC Directive.

■ Noise filter


- Connect a noise filter in the DC power supply input to prevent the noise generated in the **NETC01-M3** from propagating externally through the power supply line.
- When using a power supply transformer, be sure to connect a noise filter to the AC input side of the power supply transformer.
- For a noise filter, use HF2010A-UPF (SOSHIN ELECTRIC CO.,LTD), FN2070-10-06 (Schaffner EMC) or equivalent product.
- Install the noise filter as close to the AC input terminal of DC power supply as possible. Use cable clamps and other means to secure the AC input cables (AWG18: 0.75 mm² or more) and output cables (AWG18: 0.75 mm² or more) firmly to the surface of the enclosure.
- Connect the ground terminal of the noise filter to the grounding point, using as thick and short a wire as possible.
- Do not place the AC input cable parallel with the noise filter output cable. Parallel placement will reduce noise filter effectiveness if the enclosure's internal noise is directly coupled to the power supply cable by means of stray capacitance.

■ How to ground

The cable used to ground the **NETC01-M3** and noise filter must be as thick and short as possible so that no potential difference is generated. Choose a large, thick and uniformly conductive surface for the grounding point.

■ Wiring the power supply cable and I/O signal cable


- Use a shielded cable of AWG22 (0.3 mm²) or more for the power supply cable of the **NETC01-M3**, and keep it as short as possible.
- For the MECHATROLINK-III communication cable, use a dedicated connector cable.
- To ground the power supply cable, use a metal cable clamp or similar device that will maintain contact with the entire circumference of the cable. Attach a cable clamp as close to the end of the cable as possible, and connect it as shown in the figure.



■ Notes about installation and wiring

- Connect the **NETC01-M3** and other peripheral control equipment directly to the grounding point so as to prevent a potential difference from developing between grounds.
- When relays or electromagnetic switches are used together with the system, use noise filters and CR circuits to suppress surges generated by them.
- Keep cables as short as possible without coiling and bundling extra lengths.
- Place the power cables such as the motor and power supply cables as far as 100 mm (3.94 in.) from the signal cables. If the power cables and signal cables have to cross, cross them at a right angle. Place the AC input cable and output cable of a noise filter separately from each other.

■ Example of NETC01-M3 installation and wiring



■ Precautions about static electricity


Static electricity may cause the **NETC01-M3** to malfunction or suffer damage. While the **NETC01-M3** is receiving power, handle the **NETC01-M3** with care and do not come near or touch the **NETC01-M3**. Always use an insulated screwdriver to change the switches of the **NETC01-M3**.

Note The **NETC01-M3** uses parts that are sensitive to electrostatic charge. Before touching the **NETC01-M3**, turn off the power to prevent electrostatic charge from generating. If an electrostatic charge is impressed on the **NETC01-M3**, the **NETC01-M3** may be damaged.

5 Connection

This chapter explains the connection method of the **NETC01-M3** and power supply/communication cable, as well as the grounding method.

5.1 Connection example



5.2 Connecting the power supply and grounding the NETC01-M3

■ Connecting the power supply

Connect the power supply cable (AWG22: 0.3 mm²) to the power supply connector (CN1) of the **NETC01-M3** using the supplied CN1 connector (3 pins).

■ Grounding the NETC01-M3

Ground the Frame Ground terminal (FG) of the **NETC01-M3** as necessary. Ground using a wire of AWG24 to 16 (0.2 to 1.25 mm²), and do not share the protective earth terminal with a welder or any other power equipment.

■ CN1 connector pin assignments

Pin No.	Signal name	Description
1	+24 VDC	+24 VDC 0.2 A or more
2	GND	Power supply GND
3	FG	Frame Ground

Note


- When connecting, pay attention to the polarity of the power supply. Reverse-polarity connection may cause damage to the **NETC01-M3**.
- Do not wire the power supply cable of the **NETC01-M3** in the same cable duct with other power lines. Doing so may cause malfunction due to noise.

■ Connecting method

1. Strip the insulation cover of the lead wire by 7 mm (0.28 in.)

2. Insert each lead wire into the CN1 connector and tighten the screw using a screwdriver.
Connector screw size: M2
Tightening torque: 0.22 to 0.25 N·m (31 to 35 oz-in)

3. Insert the CN1 connector into the CN1 and tighten the screws using a screwdriver.
Connector screw size: M2.5
Tightening torque: 0.4 N·m (56 oz-in)




5.3 Connecting the RS-485 communication cable

Connect the **NETC01-M3** and RS-485 communication compatible product using the supplied RS-485 communication cable.

Connect the RS-485 communication cable to RS-485 communication connector (CN6). Since RS-485 communication cables of two lengths are supplied, use either one of the two.


You can also use a commercial LAN cable to link drivers.



■ CN6 connector pin assignments

Pin No.	Signal name	Description
1	N.C.	Not used (Do not connect anything.)
2	GND	GND
3	TR+	RS-485 communication signal (+)
4	N.C.	Not used
5	N.C.	Not used
6	TR-	RS-485 communication signal (-)
7	N.C.	Not used
8	N.C.	Not used


• NETC01-M3 internal circuit and termination resistor



* The GND line is used in common with CN1 (not insulated)


5.4 Connecting the MECHATROLINK-III communication cable

Connect the MECHATROLINK-III communication cable to the MECHATROLINK-III communication connector (CN2-1 or CN2-2) of the **NETC01-M3**. For the MECHATROLINK-III communication cable, use a dedicated cable with connector. Other MECHATROLINK-III communication compatible products can be connected to the vacant connector.



5.5 Connecting the data setter

Connect the **OPX-2A** cable or communication cable for the data setting software to the data edit connector (CN3) on the **NETC01-M3**.



Caution

The power supply connector (CN1), MECHATROLINK-III communication connector (CN2-1, CN2-2), data edit connector (CN3) and RS-485 communication connector (CN6) of the **NETC01-M3** are not electrically insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the **NETC01-M3** and these equipment to short, damaging both.

6 Guidance

If you are new to the **NETC01-M3**, read this section to understand the operating methods along with the operation flow.

As an example, this chapter explains how to perform positioning operation for the "CRK Series FLEX Built-in controller type [described as the **CRD-KD** in this manual]," using the **NETC01-M3** via MECHATROLINK-III communication.

- Note**
- Before operating the motor, check the condition of the surrounding area to ensure safety.
 - Refer to "13.8 Parameter mode" on p.57 for how to set parameters.

STEP 1 Set the transmission rate, station address and address number

■ Using the parameter

1. Set the "connection (address number 0)" parameter of the **NETC01-M3** to "1: Enable."
2. Cycle the **NETC01-M3** power.

- Note**
- "Connection" parameters will be enabled after the power is cycled.
 - When setting the parameters of the **NETC01-M3**, use the **OPX-2A** or **MEXE02**.


■ Using the switches

• Setting condition of CRD-KD


- Address number of **CRD-KD**: 0
- Connection device of **CRD-KD**: Network converter

• Setting condition of NETC01-M3

- MECHATROLINK-III station address: 61h
- RS-485 transmission rate: 625 kbps
- Remote I/O occupied size: 16 bit mode
- Number of transmission bytes: 32 bytes




STEP 2 Check the connection and set the termination resistor



STEP 3 Turn on the power and check the setting

Check that the LED condition has become as shown in the figures.



- When C-ERR (red) of the **CRD-KD** or **NETC01-M3** is lit: Check the transmission rate or address number of RS-485 communication.
- When ERR (red) of the **NETC01-M3** is lit: Check the type of the MECHATROLINK-III communication error.

STEP 4 Set the parameters of CRD-KD

Set the parameters of the **CRD-KD** using any of the **OPX-2A**, **MEXE02**, RS-485 communication or MECHATROLINK-III communication.

1. Set the "START input mode (1C00h)" parameter of the **CRD-KD** to "0: RS-485 communication."
(Initial setting: I/O)
2. Set the position (travel amount: 1001h) and operating speed (1101h) to the operation data No.1 of the **CRK-KD**.
3. Set the "Data No. input mode (1C0Dh)" parameter of the **CRD-KD** to "0: RS-485 communication."
(Initial setting: I/O)
4. Set the "STOP contact configuration (1C03h)" parameter of the **CRD-KD** to "0: Normally open."
(Initial setting: Normally closed)

Note

- Operation data or parameters set via RS-485 communication or MECHATROLINK-III communication will be written to the RAM of the **CRD-KD**. The data stored in the RAM will be erased when turning off the power supply of the **CRD-KD**. When saving the data to the non-volatile memory, execute the "batch NV memory write" command of the maintenance command.
- The operation data or parameters set by the **OPX-2A** or **MEXE02** will be saved to the non-volatile memory of the **CRD-KD**.
- The non-volatile memory can be rewritten approx. 100,000 times.

STEP 5 Execute positioning operation

Control the I/O signal of the **CRD-KD** using the standard I/O command (DATA_RWA: 20h) of MECHATROLINK-III communication.

1. Select the data No.1 by turning the M0 of the address number 0.
2. Execute positioning operation by turning the START of the address number 0 to ON.

STEP 6 Were you able to operate the motor properly?


How did it go? Were you able to operate the motor properly? If the motor does not function, check the following points:

- Is any alarm present in the **NETC01-M3** or **CRD-KD**?
- Are the address number, transmission rate and termination resistor set correctly?
- Are the "connection" parameters of the **NETC01-M3** set correctly?
- Is the C-ERR LED lit? (RS-485 communication error)
- Is the ERR LED lit? (MECHATROLINK-III communication error)
- Is the operation data set correctly?
- Is the motor for the **CRD-KD** excited? Or is the excitation setting correct?
- Are the **CRD-KD** parameters set correctly?
- Is the STOP input of the **CRD-KD** I/O turned ON?

For more detailed settings and functions, refer to the following pages.

7 Setting

This chapter explains how to set the functions of the **NETC01-M3**.



Note Be sure to turn off the **NETC01-M3** power before setting the switches. If the switches are set while the power is still on, the new switch settings will not become effective until the **NETC01-M3** power is cycled.

7.1 Transmission rate of RS-485 communication

Set the transmission rate using the transmission rate setting switch (SW1).

Factory setting 7 (625 kbps)

- Note**
- For the SW1, always set to "7." If the switch is set to the dial of "8" or higher, the communication switch setting error alarm will be generated when turning on the power. And do not set the switch to the dial of "0" to "6" because they cannot be used. (An alarm will not be generated.)
 - For the transmission rate of the RS-485 communication compatible product, set to 625 kbps.

7.2 Operation mode

Set the remote I/O occupied size and number of transmission bytes for the RS-485 communication compatible product connecting to a **NETC01-M3**. Set the remote I/O occupied size using the operation mode setting switch SW2-No.1, and set the number of transmission bytes using the SW2-No.2 and No.3. If the operation mode is changed, cycle the power.

Factory setting No.1: OFF (Remote I/O occupied size: 16 bit mode)

No.2: OFF, No.3: ON (Number of transmission bytes: 32 bytes)

SW2	Description	Factory setting
No.1	Sets the remote I/O occupied size. OFF: 16 bit mode (Up to 8 units can be connected) ON: 8 bit mode (Up to 16 units can be connected)	OFF
No.2 No.3	Sets the number of transmission bytes. No.2=OFF, No.3=OFF: 16 bytes No.2=OFF, No.3=ON: 32 bytes No.2=ON, No.3=OFF: 48 bytes No.2=ON, No.3=ON: 64 bytes	No.2: OFF No.3: ON

Note The SW2-No.4 is not used.

7.3 Station number

Set the station number using the two MECHATROLINK-III station number setting switches (STATION No.×1 and ×10). When connecting two or more MECHATROLINK-III compatible products, do not set duplicate station numbers.

Set the tens place with the "STATION No.×10" switch and the ones place with the "STATION No.×1" switch.

Setting range 03h to EFh

Factory setting 61h (×10: 6, ×1: 1)

Note | 00h to 02h and F0h to FFh cannot be used.

8 MECHATROLINK- III communication format

This chapter explains the MECHATROLINK- III communication format that the **NETC01-M3** supports.

8.1 Data format

The outline of the data format for MECHATROLINK- III communication is shown below. The **NETC01-M3** is compatible with the cyclic communication mode.

The cyclic communication mode of MECHATROLINK- III communication specifies that the header fields are 0 byte to 3 bytes and the data fields are 4 bytes and later.

	Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
Header field	0	CMD	RCMD
	1	WDT	RWDT
	2	CMD_CTRL	CMD_STAT
	3		
Data field	4 to 31	Command data field	Response data field

8.2 Phase

The communication phases of MECHATROLINK- III communication are classified as follows.

Phase	Description
0	This is a state at power-on. When turning on the power for the master station and slave station, operation switches to the phase 1.
1	This is a state waiting for the connection establishment between the master station and slave station.
2	Asynchronous communication between the master station and slave station is enabled. Only asynchronous command can be used.
3	Synchronous communication between the master station and slave station is enabled. Both asynchronous command and synchronous command can be used.
4	This is a state that the communication between the master station and slave station is stopped and the connection is disconnected.
5	This is a state turning off the power for the master station and slave station.

9 Details of command

This chapter explains the common commands and standard I/O command that the **NETC01-M3** supports.

Profile	Command code (Hex)	Command	Description	Ref.
Common command	00	NOP	This command is used as "no operation command."	p.20
	03	ID_RD	This command is used to read the product information as ID data.	p.21
	04	CONFIG	This command is used to set up the NETC01-M3 .	p.23
	05	ALM_RD	This command is used to read the alarm code, warning code or MECHATROLINK-III communication error code that is currently occurred.	p.24
	06	ALM_CLR	This command is used to reset the alarm, warning or MECHATROLINK-III communication error that is currently occurred.	p.24
	0E	CONNECT	This command is used to establish a connection of MECHATROLINK-III communication.	p.25
	0F	DISCONNECT	This command is used to release a connection of MECHATROLINK-III communication.	p.26
Standard I/O command	20	DATA_RWA	Operation commands to the RS-485 communication compatible product, reading and writing parameters, and monitoring can be executed via remote I/O or remote register.	p.27

9.1 No operation command (NOP: 00h)

This command is used as "no operation command." A response returns the present status.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	NOP (00h)	NOP (00h)
1	WDT	RWDT
2	CMD_CTRL	CMD_STAT
3		
4 to 31	Reserved (0h)	Reserved (0h)

■ Explanation of command

Device group	Common command group
Communication type	Asynchronous command
Completion of command operation	<ul style="list-style-type: none"> • Confirms by the response RCMD=NOP (00h) and CMD_STAT.CMDRDY=1. • When the CMD_STAT.D_ALM or CMD_STAT.D_WAR is equal to 1, use the ALM_RD to read out the present alarm or warning codes and take appropriate action. • When the CMD_STAT.CMD_ALM or CMD_STAT.COMM_ALM is other than 0, take appropriate action according to the alarm code. Refer to p.32 "CMD_STAT" for details.

9.2 Read ID command (ID_RD: 03h)

This command is used to read the product information as ID data. Select ID data by specifying the ID_CODE.

Refer to the "ID_CODE list" for details.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	ID_RD (03h)	ID_RD (03h)
1	WDT	RWDT
2	CMD_CTRL	CMD_STAT
3		
4	ID_CODE	ID_CODE
5	OFFSET	OFFSET
6	SIZE	SIZE
7		
8 to 15	Reserved (0h)	ID

■ Explanation of command

Device group	Common command group
Communication type	Asynchronous command
Completion of command operation	<ul style="list-style-type: none"> • Confirms by the response RCMD=ID_RD (03h), CMD_STAT.CMDRDY=1, ID_CODE, OFFSET and SIZE. • When the CMD_STAT.D_ALM or CMD_STAT.D_WAR is equal to 1, use the ALM_RD to read out the present alarm or warning codes and take appropriate action. • When the CMD_STAT.CMD_ALM or CMD_STAT.COMM_ALM is other than 0, take appropriate action according to the alarm code. Refer to "Command status (CMD_STAT)" on p.37 for details.
Note	<ul style="list-style-type: none"> • This command can be used in the phase 2 and 3. • ID_CODE: ID data selection code • OFFSET: ID read offset • SIZE: Read data size (byte) • ID: ID data <p>If any of the ID_CODE, OFFSET, SIZE or ID is invalid, "9" is set for the CMD_ALM (CMD_ALM=9). When the CMD_ALM has occurred, the ID data is indefinite.</p>

■ ID_CODE list

ID_CODE	Description	Data size	Data type
01h	Vendor ID code	4 byte	Binary
	This is an ID code to specify the vendor. Vendor ID code of ORIENTAL MOTOR CO.,LTD. = 00 00 00 05h		
02h	Device code	4 byte	Binary
	This is a code specific to each product. It is specified as a unique number for each product series associated with the vendor ID code. Device code of the NETC01-M3 = 00 00 0C D1h (3281)		

ID_CODE	Description	Data size	Data type																								
20h	Supported communication mode	4 byte	Binary																								
	This is the supported status of the communication mode. The NETC01-M3 is compatible with the cyclic communication mode. (Not supported=0, Supported=1)																										
	<table border="1"> <thead> <tr> <th>bit7</th> <th>bit6</th> <th>bit5</th> <th>bit4</th> </tr> </thead> <tbody> <tr> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>			bit7	bit6	bit5	bit4	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	0	0	0	0												
	bit7	bit6	bit5	bit4																							
	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)																							
	0	0	0	0																							
	<table border="1"> <thead> <tr> <th>bit3</th> <th>bit2</th> <th>bit1</th> <th>bit0</th> </tr> </thead> <tbody> <tr> <td>Ether net communication</td> <td>Message communication</td> <td>Cyclic communication</td> <td>Event-driven communication</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>0</td> </tr> </tbody> </table>			bit3	bit2	bit1	bit0	Ether net communication	Message communication	Cyclic communication	Event-driven communication	0	0	1	0												
	bit3	bit2	bit1	bit0																							
	Ether net communication	Message communication	Cyclic communication	Event-driven communication																							
	0	0	1	0																							
* Bit 8 to bit 31 are all reserved (0)																											
30h	List of supported main commands	32 byte	Array																								
	This is the list of the main commands that the product supports. The main commands of the NETC01-M3 are allocated as shown in the table below (Command not supported = 0, Command supported = 1).																										
	<table border="1"> <thead> <tr> <th>bit7</th> <th>bit6</th> <th>bit5</th> <th>bit4</th> <th>bit3</th> <th>bit2</th> <th>bit1</th> <th>bit0</th> </tr> </thead> <tbody> <tr> <td>Reserved (0)</td> <td>ALM_CLR</td> <td>ALM_RD</td> <td>CONFIG</td> <td>ID_RD</td> <td>PRM_WR</td> <td>PRM_RD</td> <td>NOP</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>1</td> </tr> </tbody> </table>			bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	Reserved (0)	ALM_CLR	ALM_RD	CONFIG	ID_RD	PRM_WR	PRM_RD	NOP	0	1	1	1	1	0	0	1
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0																			
	Reserved (0)	ALM_CLR	ALM_RD	CONFIG	ID_RD	PRM_WR	PRM_RD	NOP																			
	0	1	1	1	1	0	0	1																			
	<table border="1"> <thead> <tr> <th>bit15</th> <th>bit14</th> <th>bit13</th> <th>bit12</th> <th>bit11</th> <th>bit10</th> <th>bit9</th> <th>bit8</th> </tr> </thead> <tbody> <tr> <td>DISCONNECT</td> <td>CONNCTC</td> <td>SYNC_SET</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>			bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	DISCONNECT	CONNCTC	SYNC_SET	Reserved (0)	1	1	0	0	0	0	0	0				
	bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8																			
	DISCONNECT	CONNCTC	SYNC_SET	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)																			
	1	1	0	0	0	0	0	0																			
* Bit 16 to bit 23 are all reserved (0)																											
<table border="1"> <thead> <tr> <th>bit31</th> <th>bit30</th> <th>bit29</th> <th>bit28</th> <th>bit27</th> <th>bit26</th> <th>bit25</th> <th>bit24</th> </tr> </thead> <tbody> <tr> <td>Reserved (0)</td> <td>MEM_WR</td> <td>MEM_RD</td> <td>PPRM_WR</td> <td>PPRM_RD</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>			bit31	bit30	bit29	bit28	bit27	bit26	bit25	bit24	Reserved (0)	MEM_WR	MEM_RD	PPRM_WR	PPRM_RD	Reserved (0)	Reserved (0)	Reserved (0)	0	0	0	0	0	0	0	0	
bit31	bit30	bit29	bit28	bit27	bit26	bit25	bit24																				
Reserved (0)	MEM_WR	MEM_RD	PPRM_WR	PPRM_RD	Reserved (0)	Reserved (0)	Reserved (0)																				
0	0	0	0	0	0	0	0																				
<table border="1"> <thead> <tr> <th>bit39</th> <th>bit38</th> <th>bit37</th> <th>bit36</th> <th>bit35</th> <th>bit34</th> <th>bit33</th> <th>bit32</th> </tr> </thead> <tbody> <tr> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>Reserved (0)</td> <td>DATA_RWS</td> <td>DATA_RWA</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> </tr> </tbody> </table>			bit39	bit38	bit37	bit36	bit35	bit34	bit33	bit32	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	DATA_RWS	DATA_RWA	0	0	0	0	0	0	0	1	
bit39	bit38	bit37	bit36	bit35	bit34	bit33	bit32																				
Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	DATA_RWS	DATA_RWA																				
0	0	0	0	0	0	0	1																				
* Bit 40 to bit 255 are all reserved (0)																											
80h	Main device name	32 byte	ASCII																								
	This is the main device name (ASCII code). The main device name of the NETC01-M3 is " NETC01-M3. "																										
	<table border="1"> <thead> <tr> <th>byte0</th> <th>byte1</th> <th>byte2</th> <th>byte3</th> <th>byte4</th> <th>byte5</th> <th>byte6</th> <th>byte7</th> </tr> </thead> <tbody> <tr> <td>N</td> <td>E</td> <td>T</td> <td>C</td> <td>0</td> <td>1</td> <td>-</td> <td>M</td> </tr> </tbody> </table>			byte0	byte1	byte2	byte3	byte4	byte5	byte6	byte7	N	E	T	C	0	1	-	M								
	byte0	byte1	byte2	byte3	byte4	byte5	byte6	byte7																			
	N	E	T	C	0	1	-	M																			
<table border="1"> <thead> <tr> <th>byte8</th> <th>byte9</th> <th>byte10</th> <th>byte11</th> <th>byte12</th> <th>byte13</th> <th>byte14</th> <th>byte15</th> </tr> </thead> <tbody> <tr> <td>3</td> <td>00</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>			byte8	byte9	byte10	byte11	byte12	byte13	byte14	byte15	3	00															
byte8	byte9	byte10	byte11	byte12	byte13	byte14	byte15																				
3	00																										
* The blank spaces and the byte 16 to byte 31 in the table are all represented by null.																											

9.3 Setup device command (CONFIG: 04h)

This command is used to set up the **NETC01-M3**.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	CONFIG (04h)	CONFIG (04h)
1	WDT	RWDT
2	CMD_CTRL	CMD_STAT
3		
4	CONFIG_MOD	CONFIG_MOD
5 to 31	Reserved (0h)	Reserved (0h)

■ Explanation of command

Device group	Common command group
Communication type	Asynchronous command
Completion of command operation	<ul style="list-style-type: none"> • Confirms by the response RCMD=CONFIG (04h), CMD_STAT.CMDRDY=1 and CONFIG_MOD. • When the CMD_STAT.D_ALM or CMD_STAT.D_WAR is equal to 1, use the ALM_RD to read out the present alarm or warning codes and take appropriate action. • When the CMD_STAT.CMD_ALM or CMD_STAT.COMM_ALM is other than 0, take appropriate action according to the code. Refer to "Command status (CMD_STAT)" on p.37 for details.
Note	<ul style="list-style-type: none"> • This command can be used in the phase 2 and 3. • CONFIG_MOD: Configuration mode If the CONFIG_MOD data is invalid, "9" is set for the CMD_ALM (CMD_ALM=9).
Command parameter	<ul style="list-style-type: none"> • CONFIG_MOD 0: Parameter re-calculation and setup

CONFIG command and operation status

The following table shows the state of each status before, during and after processing the CONFIG command.

See "Command status (CMD_STAT)" on p.37 for the ALM and CMDRDY.

Status	Before CONFIG processing	During CONFIG processing	After CONFIG processing
ALM	Current state	Current state	Current state
CMDRDY	1	0	1
Other status	Current state	Indefinite	Current state

9.4 Read alarm or warning command (ALM_RD: 05h)

This command is used to read the alarm code, warning code or MECHATROLINK-III communication error code that is currently occurred.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	ALM_RD (05h)	ALM_RD (05h)
1	WDT	RWDT
2	CMD_CTRL	CMD_STAT
3		
4	ALM_RD_MOD	ALM_RD_MOD
5		
6	ALM_INDEX	ALM_INDEX
7		
8 to 31	Reserved (0h)	ALM_DATA

■ Explanation of command

Device group	Common command group
Communication type	Asynchronous command
Completion of command operation	Confirms by the response RCMD=ALM_RD (05h), CMD_STAT.CMDRDY=1, ALM_RD_MOD and ALM_INDEX.
Note	<ul style="list-style-type: none"> This command can be used in the phase 2 and 3. ALM_RD_MOD: Reading mode ALM_INDEX: Alarm index ALM_DATA: Stores the alarm codes or warning codes. If any of the ALM_RD_MOD, ALM_INDEX or ALM_DATA is invalid, "9" is set for CMD_ALM (CMD_ALM=9).
Command parameter	<ul style="list-style-type: none"> ALM_RD_MOD 0: Reads the present alarm or warning status. ALM_INDEX 0: If "0" is specified, the latest alarm or warning can be read.

9.5 Clear alarm or warning command (ALM_CLR: 06h)

This command is used to reset the MECHATROLINK-III communication error that is currently occurred.

Note Only the MECHATROLINK-III communication error can be reset by the "clear alarm or warning command." To reset the alarm and warning of the **NETC01-M3**, cycle the power.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	ALM_CLR (06h)	ALM_CLR (06h)
1	WDT	RWDT
2	CMD_CTRL	CMD_STAT
3		
4	ALM_CLR_MOD	ALM_CLR_MOD
5		
6 to 31	Reserved (0h)	Reserved (0h)

■ Explanation of command

Device group	Common command group
Communication type	Asynchronous command
Completion of command operation	<ul style="list-style-type: none"> • Confirms by the response RCMD=ALM_CLR (06h), CMD_STAT.CMDRDY=1 and ALM_CLR_MOD. • When the CMD_STAT.D_ALM or CMD_STAT.D_WAR is equal to 1, use the ALM_RD to read out the present alarm or warning codes and take appropriate action. • When the CMD_STAT.CMD_ALM or CMD_STAT.COMM_ALM is other than 0, take appropriate action according to the code. Refer to p.32 "CMD_STAT" for details.
Note	<ul style="list-style-type: none"> • This command can be used in the phase 2 and 3. • ALM_CLR_MOD: Reading mode If the ALM_CLR_MOD is invalid, "9" is set for CMD_ALM (CMD_ALM=9).
Command parameter	<ul style="list-style-type: none"> • ALM_CLR_MOD 0: This command is used to reset the MECHATROLINK-III communication error that is currently occurred.

9.6 Establish connection command (CONNECT: 0Eh)

This command is used to establish the MECHATROLINK-III communication connection.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	CONNECT (0Eh)	CONNECT (0Eh)
1	WDT	RWDT
2	CMD_CTRL	CMD_STAT
3		
4	VER (30h)	VER (30h)
5	COM_MODE	COM_MODE
6	COM_TIME	COM_TIME
7	PROFILE_TYPE (30h)	PROFILE_TYPE (30h)
8 to 31	Reserved (0h)	Reserved (0h)

■ Explanation of command

Device group	Common command group
Communication type	Asynchronous command
Completion of command operation	<ul style="list-style-type: none"> • Confirms by the response RCMD=CONNECT (0Eh), CMD_STAT.CMDRDY=1, VER, COM_MODE, COM_TIME and PROFILE_TYPE. • When the CMD_STAT.D_ALM or CMD_STAT.D_WAR is equal to 1, use the ALM_RD to read out the present alarm or warning codes and take appropriate action. • When the CMD_STAT.CMD_ALM or CMD_STAT.COMM_ALM is other than 0, take appropriate action according to the code. Refer to "Command status (CMD_STAT)" on p.37 for details.
Note	<ul style="list-style-type: none"> • This command can be used in the phase 1. It is disregarded in the phase 2 and 3. • VER: MECHATROLINK application layer version COM_MODE: Communication mode COM_TIM: Communication cycle setting PROFILE_TYPE: Profile type setting If any of the VER, COM_MODE, COM_TIM or PROFILE_TYPE is invalid, "9" is set for CMD_ALM (CMD_ALM=9).

Command parameter	<ul style="list-style-type: none"> • COM_MODE The bit allocation is shown in the table below. 															
	<table border="1"> <thead> <tr> <th>bit7</th> <th>bit6</th> <th>bit5</th> <th>bit4</th> <th>bit3</th> <th>bit2</th> <th>bit1</th> <th>bit0</th> </tr> </thead> <tbody> <tr> <td>SUBCMD</td> <td>0</td> <td>0</td> <td>0</td> <td>DTMODE</td> <td>SYNCMODE</td> <td></td> <td>0</td> </tr> </tbody> </table> <ul style="list-style-type: none"> · SYNCMODE (Synchronous setting) <ul style="list-style-type: none"> 0: Asynchronous communication. Detecting the watchdog data error is disabled and synchronous command cannot be used.) 1: Synchronous command (Not used in the NETC01-M3) · DTMODE (Communication mode) <ul style="list-style-type: none"> 00b: Single transmission 01b: Consecutive transmission (Not used in the NETC01-M3) 10b, 11b: Reserved · SUBCMD (Subcommand setting) <ul style="list-style-type: none"> 0: Subcommand is disabled. • COM_TIM Sets a coefficient to calculate the communication cycle (natural number). COM_TIME = Communication cycle / Transmission cycle • PROFILE_TYPE Set "30h" since the NETC01-M3 is the standard I/O profile. 	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	SUBCMD	0	0	0	DTMODE	SYNCMODE	
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0									
SUBCMD	0	0	0	DTMODE	SYNCMODE		0									

9.7 Release connection command (DISCONNECT: 0Fh)

This command is used to release a connection of MECHATROLINK-III communication. When releasing a connection, the master station transmits the release connection command for two or more communication cycles. The **NETC01-M3** interrupts the current processing and performs the initialization required to reestablish the connection. Then, it waits for the connect establishment request from the master station. The release connection command can be sent regardless of the state of the CMD_STAT.CMDRDY. If the command is sent when the CMD_STAT.CMDRDY is equal to 0 (CMD_STAT.CMDRDY = 0), the processing is interrupted and the release connection command is processed.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	DISCONNECT (0Fh)	DISCONNECT (0Fh)
1 to 31	Reserved (0h)	Reserved (0h)

■ Explanation of command

Device group	Common command group
Communication type	Asynchronous command
Completion of command operation	Controls the command transmitting time of the mater station as at least two communication cycles.
Note	<ul style="list-style-type: none"> • This command can be used in all phases. • Upon receipt of this command, the following operation is performed. <ul style="list-style-type: none"> · Shifts the phase to the phase 1. · The DISCONNECT is sent to the RS-485 communication compatible product.

9.8 Data READ/WRITE_A command (DATA_RWA: 20h)

Operation commands to the RS-485 communication compatible product, reading and writing parameters, and monitoring can be executed via remote I/O or remote register.

• Remote I/O

Remote I/O is one of the data used in communication between the master station and RS-485 communication compatible product. The control like the ON-OFF switching of I/O signals can be executed using serial communication.

When remote I/O of the **NETC01-M3** is assigned to the register of the master station, it is possible to control using remote I/O via the **NETC01-M3**. The following functions can be executed using remote I/O.

- Controls the ON-OFF status of the input signal to the RS-485 communication compatible product.
- Checks the output signal from the RS-485 communication compatible product.

• Remote register

Remote register is one of the data used in communication between the master station and RS-485 communication compatible product. Reading and writing the numerical number can be executed using serial communication.

When remote register of the **NETC01-M3** is assigned to the register of the master station, it is possible to control using remote register via the **NETC01-M3**. The following functions can be executed using remote register.

- Reads the parameters from the RS-485 communication compatible product.
- Writes the parameters to the RS-485 communication compatible product.
- Monitors the status of the RS-485 communication compatible product.

■ Data format

Byte	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	DATA_RWA (20h)	DATA_RWA (20h)
1	WDT	RWDT
2	CMD_CTRL	CMD_STAT
3		
4	Reserved (0h)	Connection status
5		
6 to 31	OUTPUT	INPUT

■ Explanation of command

Device group	Standard I/O profile group
Communication type	Asynchronous command
Completion of command operation	Confirms by the response RCMD=DATA_RWA (20h) and CMD_STAT.CMDRDY=1.
Note	<ul style="list-style-type: none"> • This command can be used in the phase 2 and 3. • OUTPUT Output data. Refer to the "I/O data." • INPUT Input data. Refer to the "I/O data."

■ Connection status

The connection status with the RS-485 communication compatible product can be monitored by the response of the DATA_RWA command. For the connection status shown in the next section "I/O data," when the master station properly communicates with the RS-485 communication compatible product, the bit corresponding to the address number shown in the table below becomes "1." If the connection setting is disabled or if the communication error has occurred, the bit becomes "0."

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Address number 7	Address number 6	Address number 5	Address number 4	Address number 3	Address number 2	Address number 1	Address number 0
Address number 15	Address number 14	Address number 13	Address number 12	Address number 11	Address number 10	Address number 9	Address number 8

■ I/O data

The OUTPUT and INPUT respectively correspond to the command and response of the data field as shown below.

Controlling the I/O signal of the RS-485 communication compatible product, reading and writing operation data or parameters, and monitoring can be executed.

- Remote I/O occupied size: 16-bit mode
Number of transmission bytes: 16-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	-	DATA_RWA (20h)	DATA_RWA (20h)
1		WDT	RWDT
2		CMD_CTRL	CMD_STAT
3			
4		Reserved	Connection status
5			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output
7		Address number "1" remote I/O input	Address number "1" remote I/O output
8		Address number "2" remote I/O input	Address number "2" remote I/O output
9			
10		Address number "3" remote I/O input	Address number "3" remote I/O output
11			
12	-	Reserved	Reserved
13			
14			
15			

- Remote I/O occupied size: 16-bit mode
Number of transmission bytes: 32-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	-	DATA_RWA (20h)	DATA_RWA (20h)
1		WDT	RWDT
2		CMD_CTRL	CMD_STAT
3			
4		Reserved	Connection status
5			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output
7		Address number "1" remote I/O input	Address number "1" remote I/O output
8		Address number "2" remote I/O input	Address number "2" remote I/O output
9		Address number "3" remote I/O input	Address number "3" remote I/O output
10		Address number "4" remote I/O input	Address number "4" remote I/O output
11		Address number "5" remote I/O input	Address number "5" remote I/O output
12		Address number "6" remote I/O input	Address number "6" remote I/O output
13		Address number "7" remote I/O input	Address number "7" remote I/O output
14		Address number "8" remote I/O input	Address number "8" remote I/O output
15		Address number "9" remote I/O input	Address number "9" remote I/O output
16		Address number "10" remote I/O input	Address number "10" remote I/O output
17		Address number "11" remote I/O input	Address number "11" remote I/O output
18		Address number "12" remote I/O input	Address number "12" remote I/O output
19		Address number "13" remote I/O input	Address number "13" remote I/O output
20		Address number "14" remote I/O input	Address number "14" remote I/O output
21	Address number "15" remote I/O input	Address number "15" remote I/O output	
22	Remote register	Register address number	Register address number response
23		Command code + TRIG	Command code response + TRIG response + STATUS
24		DATA	DATA response
25			
26			
27			
28	-	Reserved	Reserved
29			
30			
31			

- Remote I/O occupied size: 16-bit mode
Number of transmission bytes: 48-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	-	DATA_RWA (20h)	DATA_RWA (20h)
1		WDT	RWDT
2		CMD_CTRL	CMD_STAT
3			
4		Reserved	Connection status
5			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output
7		Address number "1" remote I/O input	Address number "1" remote I/O output
8		Address number "2" remote I/O input	Address number "2" remote I/O output
9		Address number "3" remote I/O input	Address number "3" remote I/O output
10		Address number "4" remote I/O input	Address number "4" remote I/O output
11		Address number "5" remote I/O input	Address number "5" remote I/O output
12		Address number "6" remote I/O input	Address number "6" remote I/O output
13		Address number "7" remote I/O input	Address number "7" remote I/O output
14		Address number "8" remote I/O input	Address number "8" remote I/O output
15		Address number "9" remote I/O input	Address number "9" remote I/O output
16		Address number "10" remote I/O input	Address number "10" remote I/O output
17		Address number "11" remote I/O input	Address number "11" remote I/O output
18		Address number "12" remote I/O input	Address number "12" remote I/O output
19		Address number "13" remote I/O input	Address number "13" remote I/O output
20		Address number "14" remote I/O input	Address number "14" remote I/O output
21	Address number "15" remote I/O input	Address number "15" remote I/O output	
22	Remote register	Register address number	Register address number response
23		Command code + TRIG	Command code response + TRIG response + STATUS
24		DATA	DATA response
25			
26			
27		Register address number	Register address number response
28		Command code + TRIG	Command code response + TRIG response + STATUS
29		DATA	DATA response
30			
31			
32		Register address number	Register address number response
33		Command code + TRIG	Command code response + TRIG response + STATUS
34		DATA	DATA response
35			
36			
37	Register address number	Register address number response	
38	Command code + TRIG	Command code response + TRIG response + STATUS	
39	DATA	DATA response	
40			
41			
42	Register address number	Register address number response	
43	Command code + TRIG	Command code response + TRIG response + STATUS	
44	DATA	DATA response	
45			

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
46	-	Reserved	Reserved
47			

- Remote I/O occupied size: 16-bit mode
Number of transmission bytes: 64-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)	
0	-	DATA_RWA (20h)	DATA_RWA (20h)	
1		WDT	RWDT	
2		CMD_CTRL	Reserved	CMD_STAT
3				
4				
5	Connection status			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output	
7		Address number "1" remote I/O input	Address number "1" remote I/O output	
8		Address number "2" remote I/O input	Address number "2" remote I/O output	
9		Address number "3" remote I/O input	Address number "3" remote I/O output	
10		Address number "4" remote I/O input	Address number "4" remote I/O output	
11		Address number "5" remote I/O input	Address number "5" remote I/O output	
12		Address number "6" remote I/O input	Address number "6" remote I/O output	
13		Address number "7" remote I/O input	Address number "7" remote I/O output	
14		Register address number	Register address number response	
15		Command code + TRIG	Command code response + TRIG response + STATUS	
16		DATA	DATA response	
17		Register address number	Register address number response	
18		Command code + TRIG	Command code response + TRIG response + STATUS	
19		DATA	DATA response	
20	Register address number	Register address number response		
21	Command code + TRIG	Command code response + TRIG response + STATUS		
22	DATA	DATA response		
23	Register address number	Register address number response		
24	Command code + TRIG	Command code response + TRIG response + STATUS		
25	DATA	DATA response		
26	Register address number	Register address number response		
27	Command code + TRIG	Command code response + TRIG response + STATUS		
28	DATA	DATA response		
29	Register address number	Register address number response		
30	Command code + TRIG	Command code response + TRIG response + STATUS		
31	DATA	DATA response		
32	Register address number	Register address number response		
33	Command code + TRIG	Command code response + TRIG response + STATUS		
34	DATA	DATA response		
35	Register address number	Register address number response		
36	Command code + TRIG	Command code response + TRIG response + STATUS		
37	DATA	DATA response		
38	Register address number	Register address number response		
39	Command code + TRIG	Command code response + TRIG response + STATUS		
40	DATA	DATA response		
41	Register address number	Register address number response		

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
42	Remote register	DATA	DATA response
43			
44			
45			
46		Register address number	Register address number response
47		Command code + TRIG	Command code response + TRIG response + STATUS
48			
49			
50	Remote register	DATA	DATA response
51			
52			
53			
54		Register address number	Register address number response
55		Command code + TRIG	Command code response + TRIG response + STATUS
56			
57			
58		DATA	DATA response
59			
60			
61			
62	-	Reserved	Reserved
63			

- Remote I/O occupied size: 8-bit mode
Number of transmission bytes: 16-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	-	DATA_RWA (20h)	DATA_RWA (20h)
1		WDT	RWDT
2		CMD_CTRL	CMD_STAT
3			
4		Reserved	Connection status
5			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output
7		Address number "1" remote I/O input	Address number "1" remote I/O output
8		Address number "2" remote I/O input	Address number "2" remote I/O output
9		Address number "3" remote I/O input	Address number "3" remote I/O output
10		Address number "4" remote I/O input	Address number "4" remote I/O output
11		Address number "5" remote I/O input	Address number "5" remote I/O output
12		Address number "6" remote I/O input	Address number "6" remote I/O output
13		Address number "7" remote I/O input	Address number "7" remote I/O output
14	-	Reserved	Reserved
15			

- Remote I/O occupied size: 8-bit mode
Number of transmission bytes: 32-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	-	DATA_RWA (20h)	DATA_RWA (20h)
1		WDT	RWDT
2		CMD_CTRL	CMD_STAT
3			
4		Reserved	Connection status
5			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output
7		Address number "1" remote I/O input	Address number "1" remote I/O output
8		Address number "2" remote I/O input	Address number "2" remote I/O output
9		Address number "3" remote I/O input	Address number "3" remote I/O output
10		Address number "4" remote I/O input	Address number "4" remote I/O output
11		Address number "5" remote I/O input	Address number "5" remote I/O output
12		Address number "6" remote I/O input	Address number "6" remote I/O output
13		Address number "7" remote I/O input	Address number "7" remote I/O output
14		Address number "8" remote I/O input	Address number "8" remote I/O output
15		Address number "9" remote I/O input	Address number "9" remote I/O output
16		Address number "10" remote I/O input	Address number "10" remote I/O output
17		Address number "11" remote I/O input	Address number "11" remote I/O output
18		Address number "12" remote I/O input	Address number "12" remote I/O output
19		Address number "13" remote I/O input	Address number "13" remote I/O output
20		Address number "14" remote I/O input	Address number "14" remote I/O output
21		Address number "15" remote I/O input	Address number "15" remote I/O output
22	Remote register	Register address number	Register address number response
23			
24		Command code + TRIG	Command code response + TRIG response + STATUS
25			
26	-	DATA	DATA response
27			
28			
29			
30	-	Reserved	Reserved
31			

- Remote I/O occupied size: 8-bit mode
Number of transmission bytes: 48-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	-	DATA_RWA (20h)	DATA_RWA (20h)
1		WDT	RWDT
2		CMD_CTRL	CMD_STAT
3			
4		Reserved	Connection status
5			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output
7		Address number "1" remote I/O input	Address number "1" remote I/O output
8		Address number "2" remote I/O input	Address number "2" remote I/O output
9		Address number "3" remote I/O input	Address number "3" remote I/O output
10		Address number "4" remote I/O input	Address number "4" remote I/O output
11		Address number "5" remote I/O input	Address number "5" remote I/O output
12		Address number "6" remote I/O input	Address number "6" remote I/O output
13		Address number "7" remote I/O input	Address number "7" remote I/O output
14		Address number "8" remote I/O input	Address number "8" remote I/O output
15		Address number "9" remote I/O input	Address number "9" remote I/O output
16		Address number "10" remote I/O input	Address number "10" remote I/O output
17		Address number "11" remote I/O input	Address number "11" remote I/O output
18		Address number "12" remote I/O input	Address number "12" remote I/O output
19		Address number "13" remote I/O input	Address number "13" remote I/O output
20		Address number "14" remote I/O input	Address number "14" remote I/O output
21		Address number "15" remote I/O input	Address number "15" remote I/O output
22	Remote register	Register address number	Register address number response
23		Command code + TRIG	Command code response + TRIG response + STATUS
24			
25		DATA	DATA response
26			
27			
28		Register address number	Register address number response
29			
30		Command code + TRIG	Command code response + TRIG response + STATUS
31			
32		DATA	DATA response
33			
34			
35		Register address number	Register address number response
36			
37	Command code + TRIG	Command code response + TRIG response + STATUS	
38			
39	DATA	DATA response	
40			
41			
42	Register address number	Register address number response	
43			
44	Command code + TRIG	Command code response + TRIG response + STATUS	
45			
46	DATA	DATA response	
47			
48			

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
46	-	Reserved	Reserved
47			

- Remote I/O occupied size: 8-bit mode
Number of transmission bytes: 64-byte mode

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
0	-	DATA_RWA (20h)	DATA_RWA (20h)
1		WDT	RWDT
2		CMD_CTRL	CMD_STAT
3			
4		Reserved	Connection status
5			
6	Remote I/O	Address number "0" remote I/O input	Address number "0" remote I/O output
7		Address number "1" remote I/O input	Address number "1" remote I/O output
8		Address number "2" remote I/O input	Address number "2" remote I/O output
9		Address number "3" remote I/O input	Address number "3" remote I/O output
10		Address number "4" remote I/O input	Address number "4" remote I/O output
11		Address number "5" remote I/O input	Address number "5" remote I/O output
12		Address number "6" remote I/O input	Address number "6" remote I/O output
13		Address number "7" remote I/O input	Address number "7" remote I/O output
14		Address number "8" remote I/O input	Address number "8" remote I/O output
15		Address number "9" remote I/O input	Address number "9" remote I/O output
16		Address number "10" remote I/O input	Address number "10" remote I/O output
17		Address number "11" remote I/O input	Address number "11" remote I/O output
18		Address number "12" remote I/O input	Address number "12" remote I/O output
19		Address number "13" remote I/O input	Address number "13" remote I/O output
20		Address number "14" remote I/O input	Address number "14" remote I/O output
21	Address number "15" remote I/O input	Address number "15" remote I/O output	
22	Remote register	Register address number	Register address number response
23		Command code + TRIG	Command code response + TRIG response + STATUS
24			
25		DATA	DATA response
26			
27			
28		Register address number	Register address number response
29			
30		Command code + TRIG	Command code response + TRIG response + STATUS
31			
32		DATA	DATA response
33			
34			
35		Register address number	Register address number response
36			
37	Command code + TRIG	Command code response + TRIG response + STATUS	
38			
39	Register address number	Register address number response	
40			
41	Command code + TRIG	Command code response + TRIG response + STATUS	

Byte	Type	Command (Master to NETC01-M3)	Response (NETC01-M3 to master)
42	Remote register	DATA	DATA response
43			
44			
45			
46		Register address number	Register address number response
47		Command code + TRIG	Command code response + TRIG response + STATUS
48			
49	Remote register	DATA	DATA response
50			
51			
52			
53		Register address number	Register address number response
54		Command code + TRIG	Command code response + TRIG response + STATUS
55			
56		DATA	DATA response
57			
58			
59			
60			
61	-	Reserved	Reserved
62			
63			

■ **Watchdog Data (WDT/RWDT)**

During synchronous communication, synchronous data is exchanged for every communication cycle between the master station and RS-485 communication compatible product. This synchronous data is called the watchdog data, and used for establishing synchronous communication and detecting watchdog error in synchronous communication.

Since the **NETC01-M3** is a control device by asynchronous command, the WDT is disregarded.

■ **Command control (CMD_CTRL)**

In the cyclic communication mode, the second and third bytes of the command format are specified as the CMD_CTRL area. The bit fields of the CMD_CTRL are shown in the table below.

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
CMD_ID		Reserved	Reserved	ALM_CLR	Reserved	Reserved	Reserved
bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8
Reserved							

Explanation of bit field

Bit field	Description
CMD_ID	This is not used in the NETC01-M3 .
ALM_CLR	0: Disable alarm clear and warning clear 1: Enable alarm clear and warning clear

■ Command status (CMD_STAT)

The bit fields of the CMD_STAT are shown in the table below.

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
RCMD_ID		Reserved	Reserved	ALM_CLR_CMP	CMDRDY	D_WAR	D_ALM
COMM_ALM				CMD_ALM			

Explanation of bit field

Bit field	Definition	Description
D_ALM	0: No alarm 1: The NETC01-M3 is in the alarm state	This is a bit that indicates the alarm state of the NETC01-M3 . When the specific alarm of the NETC01-M3 occurs, the D_ALM status bit is set to 1 (D_ALM=1) [Except for the COMM_ALM, CMD_ALM and MECHATROLINK-III communication error]. The D_ALM is independent of the COMM_ALM and CMD_ALM. When the NETC01-M3 shifts from the alarm state to the normal state as a result of the execution of the ALM_CLR command, this bit is set to 0 (D_ALM=0).
D_WAR	0: No warning 1: The NETC01-M3 is in the warning state	This is a bit that indicates the warning state of the NETC01-M3 . When the specific warning of the NETC01-M3 occurs, the D_WAR status bit is set to 1 (D_WAR=1) [Except for the COMM_ALM, CMD_ALM and MECHATROLINK-III communication error]. The D_WAR is independent of the COMM_ALM and CMD_ALM. When the NETC01-M3 shifts from the warning state to the normal state as a result of the execution of the ALM_CLR command, this bit is set to 0 (D_WAR=0).
CMDRDY	0: Command cannot be accepted. 1: Command can be accepted.	CMDRDY=0 (the STATUS bit 2 is equal to "0") represents that the command processing of the NETC01-M3 is in progress. Although the current command processing is continued, only the DISCONNECT command is executed immediately regardless of the value of the CMDRDY bit.
ALM_CLR_CMP	0: Alarm clear unprocessed 1: Completion of alarm clear processing	ALM_CLR_CMP=1 represents that CMD_CTRL.ALM_CLR=1 has been received and the alarm clear processing has been completed. The ALM_CLR_CMP can be cleared by setting the CMD_CTRL.ALM_CLR to "0."
RCMD_ID	Echo-back of the CMD_ID in the command format	The RCMD_ID represents the response data of the RS-485 communication compatible product corresponding to the command change. Returns the echo of the CMD_ID of the command format.
CMD_ALM	0: No command error 1: Command error state	The CMD_ALM is independent of the COMM_ALM, D_ALM and D_WAR. If a normal command is received after the occurrence of a command error, the CMD_ALM is automatically cleared. The CMD_ALM alarm/warning classification is specified in the NETC01-M3 specifications. Refer to p.45 for details.
COMM_ALM	0: No communication error 1: MECHATROLINK-III communication error state	The COMM_ALM is independent of the CMD_ALM, D_ALM and D_WAR. The COMM_ALM is cleared at the leading edge of the CMD_CTRL.ALM_CLR or by the ALM_CLR command. Refer to p.45 for details.

9.9 Timing chart of the data READ/WRITE_A command

The command codes in the following timing charts are examples of the **AR** Series FLEX DC power input Built-in controller type.


TM: Communication cycle between the master station and **NETC01-M3**

TS: Communication cycle between the **NETC01-M3** and RS-485 communication compatible product.

■ When the power supply is turned on (remote I/O)

- 1) Turn on the power supply of the **NETC01-M3**.
- 2) Turn on the power supply of the RS-485 communication compatible product.
- 3) Check the connection status is turned from OFF to ON.


[Power supply input]



* When the connection status is OFF, turn the signals to start operation (START, HOME etc.) to OFF.

■ When the power supply is turned on (remote register)

- 1) Turn on the power supply of the **NETC01-M3**.
- 2) Turn on the power supply of the RS-485 communication compatible product.
- 3) Check the connection status is turned from OFF to ON. For the next step, refer to the next section "read parameter and operation data (remote register)."




*1 When the connection status is OFF, set the command code to "0000h" and turn the TRIG to OFF.

*2 When the power supply of the RS-485 communication compatible product is OFF, the most significant bit of the register address number response becomes "1."

■ Read parameters and operation data (remote register)

- 1) Specify the register address number.
- 2) Check the register address number response.
- 3) Turn the TRIG from OFF to ON. The selected parameter or operation data is started reading.
- 4) After checking the TRIG_R was turned from OFF to ON, check the command code response and DATA response.
- 5) Turn the TRIG from ON to OFF, and check that the TRIG_R was turned from ON to OFF.


When reading the "position (1000)" of the operation data No.0



■ Write parameters and operation data (remote register)

- 1) Specify the register address number.
- 2) Check the register address number response.
- 3) Turn the TRIG from OFF to ON. The selected parameter or operation data is started writing.
- 4) After checking the TRIG_R was turned from OFF to ON, check the command code response and DATA response.
- 5) Turn the TRIG from ON to OFF, and check that the TRIG_R was turned from ON to OFF.


When writing 1000 to the "position" of the operation data No.0



■ **Maintenance (remote register)**

- 1) Specify the register address number.
- 2) Check the register address number response.
- 3) Turn the TRIG from OFF to ON. The selected maintenance command is executed.
- 4) After checking the TRIG_R was turned from OFF to ON, check the command code response and DATA response.
- 5) Turn the TRIG from ON to OFF, and check that the TRIG_R was turned from ON to OFF.

When executing "batch NV memory write"



* It varies depending on the type of the RS-485 communication compatible products or commands.


■ Monitor (remote register)

- 1) Specify the register address number.
- 2) Check the register address number response.
- 3) Turn the TRIG from OFF to ON. The selected monitor command is executed.
- 4) After checking the TRIG_R was turned from OFF to ON, check the command code response and DATA response.

The DATA response value is updated while the TRIG is ON.

- 5) Turn the TRIG from ON to OFF, and check that the TRIG_R was turned from ON to OFF.

When monitoring the "command position"




■ When an error has occurred (remote register)

- 1) Specify the register address number.
- 2) Check the register address number response.
- 3) Turn the TRIG from OFF to ON. The selected parameter or operation data is started writing.
- 4) When the written value is an error, the STATUS is turned from OFF to ON. Check the command code and DATA.
- 5) Turn the TRIG from ON to OFF, and reset the error status.

Note | If an error has occurred in data transfer, the STATUS is turned ON.

When specifying data that is outside the setting range (write 1000 to the "STOP input action" parameter)




10 Troubleshooting and remedial actions

The **NETC01-M3** provides alarms that are designed to protect the **NETC01-M3** from poor connection, error in operation, etc. (protective functions), as well as warnings that are output before the corresponding alarms generate (warning functions).

10.1 Alarms and MECHATROLINK-III communication error

When an alarm or MECHATROLINK-III communication error has occurred, the ALARM LED on the **NETC01-M3** is blinked or lit. If the MECHATROLINK-III communication error has occurred, the ERR LED is also lit.




■ When an alarm in the NETC01-M3 unit was generated

If an alarm in the **NETC01-M3** unit has generated, RS-485 communication is stopped and the ALARM LED blinks.

The present alarm can be checked by counting the number of times the ALARM LED blinks. The present alarm can also be checked using the **OPX-2A** or **MEXE02**.

You can check the records of up to ten most recent alarms starting from the latest one, or clear the alarm records.

● ALARM LED status (Example: RS-485 communication error)



Note If an alarm is generated, the communication between the **NETC01-M3** and RS-485 communication compatible product is stopped. When RS-485 communication is stopped, the parameter command, maintenance command and monitor command of the RS-485 communication compatible product cannot be used.

● Alarm reset

Before resetting an alarm, always remove the cause of the alarm and ensure safety, and then cycle the power to reset the alarm.

Note The alarm in the **NETC01-M3** unit cannot be reset by the **OPX-2A**, **MEXE02** or via MECHATROLINK-III communication.

■ When the MECHATROLINK-III communication error has occurred

When the MECHATROLINK-III communication error has occurred, the ALARM LED is successively blinking or lit, and the ERR LED is lit. The motor operation is stopped but RS-485 communication is continued.

How to reset the MECHATROLINK-III communication error




Before resetting an error, always remove the cause of the error and ensure safety, and perform one of the reset operations specified below.

- Execute the alarm reset for the **NETC01-M3** or RS-485 communication compatible product using the **OPX-2A** or **MEXE02**.
- Cycle the power of the **NETC01-M3** or master device.
- Execute the clear alarm or warning command (ALM_CLR: 06h) of MECHATROLINK-III communication.

■ List of alarm and MECHATROLINK-III communication error

Product	Type	LED status		Alarm code
		NETC01-M3	RS-485 communication compatible product	
NETC01-M3 unit	Alarm	<p>ALARM blinking 9 times</p>	<p>POWER only lit</p>	A1h
		<p>ALARM blinking 7 times C-ERR lit red</p>		E3h
		<p>ALARM blinking 7 times C-ERR lit red</p>		E4h
		<p>ALARM blinking 7 times C-ERR lit red</p>		E6h
Between master and NETC01-M3	MECHATROLINK-III command error (CMD_ALM)	<p>ALARM successively blinking ERR lit red</p>	<p>ALARM blinking 7 times C-DAT lit green</p>	08h
		<p>ALARM successively blinking ERR lit red</p>		0Ah
		<p>ALARM successively blinking ERR lit red</p>		0Ch
	MECHATROLINK-III communication error (COMM_ALM)	<p>ALARM lit red ERR lit red</p>		08h
		<p>ALARM lit red ERR lit red</p>		09h
		<p>ALARM lit red ERR lit red</p>		0Ah
Between NETC01-M3 and RS-485 communication compatible product	MECHATROLINK-III communication error	<p>POWER only lit</p>	<p>ALARM blinking 7 times</p>	-
		<p>C-DAT lit green C-ERR lit red</p>	<p>ALARM blinking 7 times C-ERR lit red</p>	
		<p>POWER only lit</p>	<p>POWER only lit</p>	

Alarm type	System status	Cause	Remedial action
EEPROM error	Communication between the NETC01-M3 and RS-485 communication compatible product cannot be performed.	The stored data of the NETC01-M3 was damaged.	Initialize data using any of the maintenance command, OPX-2A or MEXE02 .
Communication switch setting error		The transmission rate setting switch (SW1) of RS-485 communication was set outside the range (8 and above).	Set the transmission rate setting switch (SW1) to "7".
RS-485 communication error		The RS-485 communication error has been detected three times consecutively.	<ul style="list-style-type: none"> • Check the transmission rate of RS-485 communication. • Check the connector or cable of RS-485 communication.
Network connection product error		The "communication (address number)" parameter is outside the setting range.	Set either "0: Disable" or "1: Enable."
Unsupported command	Communication between the NETC01-M3 and master station cannot be performed.	The command that was not implemented was executed.	Re-examine the command sending sequence of the master station.
Command execution condition error		The order (sequence) of the command that has been sent is not correct.	
Phase error		The command not being permitted in the current phase was executed.	
Invalid data		<ul style="list-style-type: none"> • The parameter number or data address is not correct. • The data in the command is not correct. 	Re-examine the command data content that the master station sends.
FCS error		The MECHATROLINK-III communication cable is affected by electrical noise.	<ul style="list-style-type: none"> • Check the wiring and surrounding area of the communication cables. • Take measures for protection against electrical noise.
Cyclic data not received			
Synchronous frame not received			
Synchronization interval error		The transmission cycle besides specification was set.	Re-examine the setting of the transmission cycle of the master station.
-	Communication between the NETC01-M3 and RS-485 communication compatible product cannot be performed.	The power supply of the NETC01-M3 was shut off while communicating via RS-485 communication.	Check the power supply of the NETC01-M3 .
		The setting of the SW1 of the NETC01-M3 is not the same as that of the transmission rate of RS-485 communication compatible product.	Check the setting of the switch.
		The "communication (address number)" parameter is set to "0: Disable."	Set the "communication (address number)" parameter to "1: Enable."

Product	Type	LED status		Alarm code
		NETC01-M3	RS-485 communication compatible product	
Between NETC01-M3 and RS-485 communication compatible product	MECHATROLINK-III communication error	 <p>C-DAT lit green C-ERR lit red</p>	 <p>C-DAT lit green</p>  <p>ALARM blinking 7 times</p>  <p>POWER only lit</p>	-

10.2 Warning

If a warning generates, the D_WAR of the command status (CMD_STAT) for the **NETC01-M3** is turned ON (1).

The motor will continue to operate.

Once the cause of the warning is removed, the warning will automatically cleared and the D_WAR will be turned OFF (0).

The present warning can be checked using the **OPX-2A** or **MEXE02**. You can also check the records of up to ten most recent warnings starting from the latest one, or clear the warning records.

Note | The warning records can be cleared by turning off the **NETC01-M3** power.

Warning code	Warning type	Cause	Remedial action
E4h	RS-485 communication error	The RS-485 communication error was detected.	<ul style="list-style-type: none"> • Check the transmission rate of RS-485 communication. • Check the connector or cable of RS-485 communication.
E5h	RS-485 communication timeout	Even though the receiving cycle of RS-485 communication has passed, the response frame was not completed receiving.	<ul style="list-style-type: none"> • Check the connector or cable of RS-485 communication. • Check the power supply of the RS-485 communication compatible product.

Alarm type	System status	Cause	Remedial action
-	Communication between the NETC01-M3 and RS-485 communication compatible product cannot be performed.	The RS-485 communication compatible product corresponding to the "communication (address number)" parameter does not exist.	Check the address number of the RS-485 communication compatible product.
		The communication of the RS-485 communication compatible product was shut off while communicating.	<ul style="list-style-type: none"> • Check the RS-485 communication cable. • Check the power supply of the RS-485 communication compatible product.
		When the RS-485 communication cable was connected incompletely or it was not connected, the power supply was turned on.	Check the RS-485 communication cable.

11 Inspection

It is recommended that periodic inspections for the items listed below are conducted after each operation of the motor. If an abnormal condition is noted, discontinue any use and contact your nearest Oriental Motor sales office.

- Is any of the **NETC01-M3** DIN rail mounting parts loose?
- Is any of the connection parts of the **NETC01-M3** loose?
- Is there attachment of dust, etc., on the **NETC01-M3**?
- Are there any strange smells or appearances within the **NETC01-M3**?

Note | The **NETC01-M3** uses semiconductor elements. Handle the **NETC01-M3** with care since static electricity may damage semiconductor elements. Static electricity may damage the **NETC01-M3**.

12 General specifications

■ Environment specification

	Operation environment	Storage environment Shipping environment
Ambient temperature	0 to +40 °C (+32 to +104 °F) (non-freezing)	-25 to +70 °C (-13 to +158 °F) (non-freezing)
Humidity	85% or less (non-condensing)	
Altitude	Up to 1000 m (3300 ft.) above sea level	Up to 3000 m (10000 ft.) above sea level
Surrounding atmosphere	No corrosive gas, dust, water or oil	

■ Insulation specification

Insulation resistance	Between FG terminal and power supply terminals	100 MΩ or more when 500 VDC megger is applied
Dielectric strength		Sufficient to withstand 500 VAC at 50/60 Hz applied for 1 minute, leak current 10 mA or less.

■ RS-485 communication specification

Electrical characteristics	In conformance with EIA-485, straight cable Use a twisted pair cable (TIA/EIA-568B CAT5e or higher is recommended) and keep the total wiring distance including extension to 50 m (164 ft.) or less.
Communication mode	Half duplex, Asynchronous mode (data: 8 bits, stop bit: 1 bit, parity: none)
Transmission rate	625 kbps
Protocol	Frame size: 10 bytes (fix), binary transmission
Maximum number of connected units	8 units or 16 units (it varies depending on the operation mode.)

■ MECHATROLINK-III communication specification


Type of Connection	Cascade connection/Star connection/Point to Point connection
Transmission cable	MECHATROLINK-III dedicated cable (CAT5e STP) To connect the NETC01-M3 , the dedicated cable with connector is recommended.
Connector	Industrial mini I/O connector (Tyco Electronics AMP)
Transmission distance	6300 m (20669.3 ft.) maximum
Distance between stations	100 m (328.1 ft.) maximum, 200 mm (7.87 in.) minimum
Baud rate	100 Mbps
Transmission method	4B/5B MULT-3
Access control method	Master - Slave
Electrical insulation between devices and transmission lines	Transformer
Number of stations connected	Up to 62 stations
Station address	03h to EFh (Factory setting: 61h)
Communication mode	Cyclic communication mode (Asynchronous command)
Transmission cycle	0.5/1.0/1.5/2.0/2.5/3.0/3.5/4.0/8.0 ms
Data size	16/32/48/64 (Factory setting: 32 bytes)
Implemented commands	Standard I/O profile command

13 Operation using the OPX-2A

This chapter explains the overview and operation using a data setter **OPX-2A**.

13.1 Overview of the OPX-2A

The **OPX-2A** is a data setter that lets you set parameters and monitor the communication time. In addition, the **OPX-2A** can be used to save the data of **NETC01-M3**. There are four destinations (data banks) to save data.



The **OPX-2A** can be used for the following purposes:


- The parameters for the **NETC01-M3** can be set.
- The communication time and status can be monitored.
- The alarm records can be checked and cleared.
- The parameters set in the **NETC01-M3** can be saved to the **OPX-2A**.
- The parameters saved in the **OPX-2A** can be copied to another **NETC01-M3** connected to the **OPX-2A**.

■ Edit lock function

Enable the edit lock function if you want to prevent parameters from being edited or cleared. Parameters cannot be changed or deleted while the edit lock function is enabled.


• Setting the edit lock function

In the top screen of each operation mode, press the **[MODE/ESC]** key for at least 5 seconds. The display will show "Lock" and the edit lock function will be enabled. The "LOCK" LED in the LED indicator area will also be lit.




• Canceling the edit lock function

Again in the top screen of each operation mode, press the **[MODE/ESC]** key for at least 5 seconds. The display will show "UnLock" and the edit lock function will be cancelled. The "LOCK" LED in the LED indicator area will turn off.



13.2 Names and functions of parts



Display
This area shows the parameters, alarms, etc.

LED indicators
These LED indicators are used to indicate the mode of the **OPX-2A** and **NETC01-M3** status.

Use this button to change the operation mode or move to the next upper level.

Use this button to select data or change the displayed item or move to the next lower level.

Use these buttons to change the selected item or set the parameters.

- Use these buttons to increase or decrease the value or change the selected item.
- Use these buttons to navigate through each data or parameter to a desired digit.

13.3 Notation

In this manual, keys are denoted by symbols, such as $\left[\begin{smallmatrix} \text{MODE} \\ \text{ESC} \end{smallmatrix} \right]$ $\left[\text{SET} \right]$ $\left[\uparrow \right]$ $\left[\downarrow \right]$ $\left[\leftarrow \right]$ $\left[\rightarrow \right]$.
In figures, a simplified illustration of the display and LED indicators is used, as shown below.



13.4 How to read the display

The display consists of 7-segment LEDs. (The number “5” and alphabet “S” are the same.)

• Numbers

1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	0	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

• Alphabets


A	A	B	b	C	c	D	d	E	E	F	F	G	G	H	H	I	,	J	J	K	K	L	L
M	n̄	N	n	O	o	P	P	Q	q	R	r	S	S	T	t	U	U	V	v	W	W	Y	Y

• Signs

+	+	-	-
---	---	---	---

■ How to read the LED indicators

When the operation mode is changed or an alarm or warning generates, a corresponding LED will be lit. While the edit lock function is enabled, the condition is also indicated by the illumination of a corresponding LED.




13.5 OPX-2A error display

Errors displayed on the **OPX-2A** are explained.


Error display	Meaning	Action
	A communication error occurred between the OPX-2A and NETC01-M3 .	<ul style="list-style-type: none"> • Check if the OPX-2A is connected securely. • Check if the OPX-2A cable is disconnected or damaged. • The OPX-2A or the communication part of the NETC01-M3 may have damaged. Contact your nearest Oriental Motor sales office.

13.6 Screen transitions



In the lower level except the top screen, press the **MODE ESC** key to return to the previous level.

- Note**
- For the parameter mode and copy mode, if the **[SET]** key is pressed while processing the memory of the **NETC01-M3** via MECHATROLINK-III communication, the screen cannot move to the lower level from the top screen and "mEm-busy" is displayed. Be sure to wait until the memory processing is completed, before pressing the **[SET]** key.
 - The following limitations are present while the edit lock function is enabled.
 - Parameter mode, copy mode: Although they are displayed on the screen, they are unable to operate.
 - Clearing the alarm and warning records: They are not displayed on the screen.



--- Broken line indicates that data writing cannot be executed when internal processing is in progress via MECHATROLINK-III communication.
 "mEm-bUSy" is displayed even when the SET key is pressed.

13.7 Monitor mode

■ Overview of the monitor mode

● Monitoring the communication status

The communication scan time and communication status can be monitored.

● Checking alarms/warnings, clearing alarm/warning records, and resetting alarms

- If an alarm or warning generates, a corresponding alarm code or warning code will be displayed. You can check the code to identify the details of the alarm/warning.
- Up to ten most recent alarms/warnings can be displayed, starting from the latest one.
- The present alarm can be reset.
- Alarm/warning records can be cleared.

■ Monitor items

● RS-485 communication scan time

The communication time between the **NETC01-M3** and connected product can be monitored in real time (unit: msec).

● RS-485 communication status

The communication status of the connected product can be checked.

<p>Address number 0 to 7</p>	<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Address number: 7 6 5 4 3 2 1 0</p>  </div> <div> <p>Connection request Lit: "Connection" parameter is enabled Unlit: "Connection" parameter is disabled</p> <p>Connection response Lit: Communicating properly Unlit: Communication error or "connection" parameter is disabled</p> </div> </div>
<p>Address number 8 to 15</p>	<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Address number: 15 14 13 12 11 10 9 8</p>  </div> <div> <p>Connection request Lit: "Connection" parameter is enabled Unlit: "Connection" parameter is disabled</p> <p>Connection response Lit: Communicating properly Unlit: Communication error or "connection" parameter is disabled</p> </div> </div>

• Present alarm

When an alarm generates, a corresponding alarm code will be displayed. Also, alarm records can be checked and cleared.

Alarm code list

No. of ALARM LED blinks	Alarm code	Alarm type
9	A1h	EEPROM error
7	E3h	Communication switch setting error
	E4h	RS-485 communication error
	E6h	Network connection product error

- Note**
- Do not turn off the **NETC01-M3** power while alarm records are being cleared (=while the display is blinking). Doing so may damage the data.
 - If an alarm generates, communication between the **NETC01-M3** and RS-485 communication compatible product is stopped. The remote I/O, parameter command, maintenance command and monitor command of the RS-485 communication compatible product cannot be used.
 - To reset the alarms, cycle the **NETC01-M3** power.

• Present warning

When a warning generates, a corresponding warning code will be displayed. Warning records can be checked and cleared.

Warning code list

Warning code	Warning type
E4h	RS-485 communication error
E5h	RS-485 communication timeout

- Note**
- Do not turn off the **NETC01-M3** power while a warning records are being cleared (=while the display is blinking). Doing so may damage the data.
 - Warning records can be cleared automatically by turning off the **NETC01-M3** power.

13.8 Parameter mode

When a parameter has been changed, the new parameter will become effective after the **NETC01-M3** power is cycled.

■ Application parameter

Parameter name	Description	Setting range	Initial value	OPX-2A screen display
Data setter edit	Sets whether it is possible to edit using the OPX-2A .	0: Disable 1: Enable	1: Enable	—*

* It can be changed by setting/canceling the edit lock function on the **OPX-2A**.

■ System parameter

Parameter name	Description	Setting range	Initial value	OPX-2A screen display
Connection (address number 0)	Sets whether to enable or disable the communication with the connected product.	0: Disable 1: Enable	0: Disable	SYS-4-00
Connection (address number 1)				SYS-4-01
Connection (address number 2)				SYS-4-02
Connection (address number 3)				SYS-4-03
Connection (address number 4)				SYS-4-04
Connection (address number 5)				SYS-4-05
Connection (address number 6)				SYS-4-06
Connection (address number 7)				SYS-4-07
Connection (address number 8)				SYS-4-08
Connection (address number 9)				SYS-4-09
Connection (address number 10)				SYS-4-10
Connection (address number 11)				SYS-4-11
Connection (address number 12)				SYS-4-12
Connection (address number 13)				SYS-4-13
Connection (address number 14)				SYS-4-14
Connection (address number 15)				SYS-4-15


- Note**
- If operations are limited by the edit lock function (p.51), parameters cannot be edited.
 - The non-volatile memory can be rewritten approx. 100,000 times.

13.9 Copy mode

■ Download

Parameters saved in the **OPX-2A** can be copied to the **NETC01-M3**.

If a download error occurs, a code indicating the description of the error will blink on the display. Download will not be performed and the display will return to the top screen of download. Refer to "Error of the copy mode" for the error display.



■ Upload

Parameters saved in the **NETC01-M3** can be copied to the **OPX-2A**.

■ Verification

Parameters in the **OPX-2A** can be verified against the corresponding parameters in the **NETC01-M3**.

If the verification finds that the two sets of parameter match, "Good" will be shown. If the two do not match, "Error" will be shown.

If a verification error occurs, a code indicating the description of the error will blink on the display.

Verification will not be performed and the display will return to the top screen of verification.

Refer to "Error of the copy mode" for the error display.

■ Initializing parameters

Parameters saved in the **NETC01-M3** can be restored to the initial values.

■ What happens when the [SET] key is pressed while the edit lock function is enabled

While the edit lock function is enabled, you cannot move to any lower level from the top screen of the copy mode. Pressing the [SET] key will generate an error, and "Lock-Err" will be shown. Be sure to cancel the edit lock function before pressing the [SET] key. Refer to p.51 for the procedure to cancel the edit lock function.

Lock-Err

Note

- If the [SET] key is pressed while processing the memory of the **NETC01-M3** via MECHATROLINK-III communication, the screen cannot move to the lower level from the top screen and "mEm-busy" is displayed. Be sure to wait until the memory processing is completed, before pressing the [SET] key.
- When a system parameter has been changed, the new parameter will become effective after the power is cycled. When system parameters were changed by downloading, cycle the **NETC01-M3** power.
- Do not turn off the **NETC01-M3** power while the download is still in progress (=while the display is blinking). Doing so may damage the data.

■ Error of the copy mode

If an error occurs in download or verification, the error code will blink on the display.

At this time, the processing will not be executed and the display will return to the top screen.

Blinking display	Description	Action
Prod-Err	There is a discrepancy between the selected product series and the data being processed.	<ul style="list-style-type: none"> • Check the product series. • Check the data bank number on the OPX-2A.
HEAd-Err bCC-Err	An error occurred while processing.	Execute the processing again. If the same error occurs, the parameters saved in the OPX-2A may have damaged. Upload and set the parameters of the OPX-2A again.
no-dAtA	The specified data bank number does not contain data.	Check the data bank number.
dAtA-Err	An error occurred while parameter was being downloaded.	Perform download again.

14 Accessories (sold separately)

■ Data setter

The data setter lets you set parameters for your **NETC01-M3** with ease and monitor the communication time.

Model: **OPX-2A**

■ Data setting software

The data setting software lets you set parameters for your **NETC01-M3** and monitor the communication time using a PC. The software comes with a PC interface cable [5 m (16.4 ft.)]. The cable is connected to the USB port on the PC.

Model: **MEXE02**

■ RS-485 communication cable

The RS-485 communication compatible product can be connected.

Model: **CC001-RS4** [0.1 m (0.3 ft.)]

CC002-RS4 [0.25 m (0.8 ft.)]

- Unauthorized reproduction or copying of all or part of this Operating Manual is prohibited.
If a new copy is required to replace an original manual that has been damaged or lost, please contact your nearest Oriental Motor branch or sales office.
- Oriental Motor shall not be liable whatsoever for any problems relating to industrial property rights arising from use of any information, circuit, equipment or device provided or referenced in this manual.
- Characteristics, specifications and dimensions are subject to change without notice.
- While we make every effort to offer accurate information in the manual, we welcome your input. Should you find unclear descriptions, errors or omissions, please contact the nearest office.
- **Orientalmotor** is a registered trademark or trademark of Oriental Motor Co., Ltd., in Japan and other countries. MECHATROLINK is a registered trademark of the MECHATROLINK Members Association.
Other product names and company names mentioned in this manual may be registered trademarks or trademarks of their respective companies and are hereby acknowledged. The third-party products mentioned in this manual are recommended products, and references to their names shall not be construed as any form of performance guarantee. Oriental Motor is not liable whatsoever for the performance of these third-party products.

© Copyright ORIENTAL MOTOR CO., LTD. 2013

- Please contact your nearest Oriental Motor office for further information.

ORIENTAL MOTOR U.S.A CORP.
Technical Support Tel:(800)468-3982
8:30 A.M. to 5:00 P.M., P.S.T. (M-F)
7:30 A.M. to 5:00 P.M., C.S.T. (M-F)
E-mail: techsupport@orientalmotor.com
www.orientalmotor.com

ORIENTAL MOTOR (EUROPA) GmbH
Headquarters and Düsseldorf Office
Tel:0211-52067-00 Fax:0211-52067-099
Munich Office
Tel:089-3181225-00 Fax:089-3181225-25
Hamburg Office
Tel:040-76910443 Fax:040-76910445

ORIENTAL MOTOR (UK) LTD.
Tel:01256-347090 Fax:01256-347099

ORIENTAL MOTOR (FRANCE) SARL
Tel:01 47 86 97 50 Fax:01 47 82 45 16

ORIENTAL MOTOR ITALIA s.r.l.
Tel:02-93906346 Fax:02-93906348

SHANGHAI ORIENTAL MOTOR CO., LTD.
Tel:400-820-6516 Fax:021-6278-0269

TAIWAN ORIENTAL MOTOR CO., LTD.
Tel:(02)8228-0707 Fax:(02)8228-0708

ORIENTAL MOTOR ASIA PACIFIC PTE. LTD.
Tel:+65-6745-7344 Fax:+65-6745-9405

ORIENTAL MOTOR (MALAYSIA) SDN. BHD.
Tel:(03)22875778 Fax:(03)22875528

ORIENTAL MOTOR (THAILAND) CO., LTD.
Tel:+66-2-251-1871 Fax:+66-2-251-1872

INA ORIENTAL MOTOR CO., LTD.
KOREA
Tel:080-777-2042 Fax:02-2026-5495

ORIENTAL MOTOR CO., LTD.
Headquarters Tokyo, Japan
Tel:03-6744-0361 Fax:03-5826-2576