





# SmartLight

# **Analogue Fire Alarm Control Panel**

# **Extinguishant System Control Panel**

# **Installation and Programming Manual**



# **GameOver**

# Copyright

The information contained in this document is the sole property of Inim Electronics s.r.l. No part may be copied without written authorization from Inim Electronics s.r.l.

All rights reserved.

This Control panel has been designed and developed to the highest standards of quality and performance implemented by Inim Electronics.

This control panel must be installed in accordance with the instructions described in this manual and in compliance with the laws in force.

All control panels from the **SmartLight** series are **EN54-2**; **EN54-4** compliant.

All control panels from the **SmartLight** series, and all accessory items and special functions have IMQ Sistemi di Sicurezza certification, unless otherwise stated.

# Table of contents

Chapter 1 1.1 1.2 1.3	Introduction
Chapter 2 2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 2.9 2.10 2.11 2.12 2.13 2.14 2.15 2.16 2.17	General information
Chapter 3 3.1 3.2 3.3	Device management
Chapter 4 4.1 4.2 4.3	Technical description
Chapter 5 5.1 5.2 5.3	User Interface17 SmartLight panel frontplate 17 Internal LEDs 21 Repeater (optional) 22
Chapter 6 6.1 6.2 6.3 6.4 6.5 6.6 6.7 6.8 6.9 6.10 6.11 6.12	Installing the SmartLight Panel
Chapter 7 7.1 7.2 7.3 7.4	Powering up and configuring the system

inim

Chapter 8	Programming from the panel		
Chapter 9 9.1 9.2 9.3 9.4 9.5 9.6	Preparing the programming data		
Chapter 10 10.1 10.2 10.3 10.4	Configuring the loop		
Chapter 11 11.1	Programming fire detection points		
Chapter 12 12.1 12.2 12.3 12.4	Programming the Extinguishant module		
Chapter 13	Configuring the Repeaters54		
Chapter 14 14.1	Closing the programming session55 Reset default programming 55		
Chapter 15 15.1 15.2 15.3 15.4 15.5 15.6 15.7 15.8 15.9	Other maintenance operations		
Chapter 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7	Diagnostics—Clearing Faults		
Appendix A	Maintenance63		
Appendix B	Argus devices accepted by the control panel		
Appendix C	Apollo devices accepted by the panel		
Appendix D	SmartLeague software72		
Appendix E	About the SmartLeague software76		
Appendix F	Order Codes78		
Installer's notes			

inim

# Chapter 1

# Introduction

Note:	The control panels described in this manual have been designed and developed to the highest standards of quality, reliability and performance. All product components are capable to application requirements and able to operate in compliance with the related technical specifications when the temperature external to their casing complies with Category 3k5 of IEC 721-3-3.
Danger:	The GAS control function is not EN54-2 compliant, as this feature is not mentioned in the aforesaid standard.
Danger:	In order to validate the IMQ-SISTEMI DI SICUREZZA certification, and in compliance with EN54-2, all the manual alarm buttons and fire detectors employed in the system must be associated with fire detection and alarm functions.

### 1.1 Application and use

The SmartLight analog-addressable fire alarm panel manages a single loop that accommodates different types of fire-security devices (detectors, input modules, outputs, callpoints, fire bells, sirens, etc.). The maximum loop wire length is 2000 m. The SmartLight provides supervised outputs which ensure full device functionality. The panel identifies and signals alarm, pre-alarm, fault, early warning, bypassed zone, test and monitoring conditions. The system status is indicated on the display and on the system status LEDs. The SmartLight panel supports up to 4 Repeater panels (accessory items) which replicate system data and allow building occupants with Level 2 authorization to silence and reset the system. The panel also accepts an extinguishant module (accessory item) that allows it to manage a gas extinguishant system.

The self-addressing feature and reduced-complexity point programming allow fast and easy installation.



Figure 1 - Example of a typical SmartLight installation

#### Caption

#### [A] Loop

All the peripheral devices of the system must be connected in parallel to the loop circuit (2 pole STP). The loop is a closed electrical circuit in which a wide variety of alarm devices can be accommodated. Opening or closing the circuit at any point will generate a fault signal. The loop circuit communication path starts on the Loop-Out terminals and ends on the Loop-In terminals. The panel controls and communicates with the loop devices via digital protocol. The loop utilizes the same two poles for the power supply to the system devices and the two-way communication channel. The loop accommodates:

- 1. **Detectors:** A smoke detector is an active fire protection device that detects smoke or flames and issues an alarm thereby alerting building occupants to the danger of fire. Detectors can be:
  - Optical smoke detectors which look for the presence of visible by-products of combustion in the detection chamber (Tyndall effect).
  - Optical/Heat detectors which operate as per optical smoke detectors but also sense for increase in the environment temperature. The combination of both sensing methods (smoke and heat) provides faster detection and reduces the false alarm rate.
  - Heat detectors: sense for an increase in the temperature in the protected environment. There are two types of heat detector: Fixed temperature that signal alarm when the temperature exceeds the predefined threshold; and Rate-of-rise that as well as monitoring the predefined fixed temperature also respond to rapid increase in temperature.
  - Ionization smoke detectors: feature a harmless radioactive source within a dual detection chamber. They operate by sensing for a change in electrical conductivity across the detection chamber.
  - CO detectors: sense the levels of carbon monoxide given off by all carbon-based materials in the smoldering stages of a fire (often combined with heat detection sensor).
- 2. **Input Module:** a device which monitors the status of another device (callpoint, detector, etc.) and sends the respective information to the panel. The Input module allows to accommodate any type of loop device.
- 3. **Output Module:** provides a supervised ancillary output. The cause of activation can be defined during the system configuration phase. The output module interfaces all types of loop devices (bells, signaling devices, fire door magnets [D], etc.).
- 4. **Callpoint:** a clearly labeled fire button with instructions for use in the event of fire. Usually placed near building entrances/exits. These push-button alarm-trigger devices allow building occupants to activate system alarms.
- 5. **Sounder/Flasher:** audible/visual alarm signaling devices. The cause of activation (alarm, pre-alarm, early warning, etc.) can be defined during the system configuration phase.
- **Note:** Sounders and flashers can also be connected directly to the control panel outputs [E].

For the list of the devices the loop accommodates, and for details regarding their operating principles, refer to *Appendix B* - *Argus devices accepted by the control panel Appendix C* - *Apollo devices accepted by the panel* 

The loop circuit configuration (as required by the local Fire code in force) is a fault-tolerant circuit which, in the event of short-circuit or loop interruption, allows the panel to continue to communicate and drive the elements on either side of the interruption.

#### Isolator

In order to provide a fault-tolerant loop circuit that is Fire code compliant, isolator modules must be installed in series with the loop circuit. The isolators modules will detect any short-circuit conditions and consequently interrupt the loop circuit. If a short-circuit occurs, the two isolators adjacent to the shorted section will open and split the loop in such way as to allow the panel to drive the elements on either side of the interruption. No more than 32 detectors/devices should be installed between two isolator modules.

Note:

Many detectors/devices have built-in isolators and therefore do not require isolator modules. Refer to "Appendix B - Argus devices accepted by the control panel" and "Appendix C - Apollo devices accepted by the panel" for further details.

#### [B] The Repeater (accessory item)

This optional system enhancement tool (equipped with keypad, LEDs, fast buttons and display) replicates all the system data. The panel supports 4 repeaters (maximum cable length 1000m from panel). Repeaters should be located at building entrances/exits in such way as to allow persons in charge to view the system status without going too far inside the building.

#### [C] Gas extinguishant system (optional system enhancement feature)

The panel can house and manage a gas extinguishant module. The Gas extinguishant module is compliant with *EN 12094-1*.

#### **1.2** Other parts of the system part–definitions

**Point:** synonym and definition of a loop device (detector, etc.). Refer to the previous point and Appendix *A* and *B* for further details.

**Zone:** a group of points (detectors, etc.). The points can be assigned to the zones during the configuration phase. Consult your local Fire code for the rules regulating automatic fire detection installations and for full details regarding zone limitations.

**Power Supply** (*Figure 22 - Connecting the Mains*): a module, connected to the mains 230 Vac, that provides a stabilized voltage @ 24 V (27.6 V) to the system and the charge source to the batteries. The EN54-4 compliant power-supply module is housed below the mother board. The mains voltage (230 Vac) is the primary power source of the system. Refer also to "Connecting the Mains" on page 32.

**Batteries:** the secondary power source of the system. The panel houses two lead batteries @ 12V 7Ah (connected in series). The system monitors the battery status (efficiency and charge). In the event of inefficient or low battery conditions, the system will signal battery fault. If primary (230 Vac) power failure occurs, the batteries will take over, however, they will shutdown automatically if the blackout persists. The automatic battery shutdown feature prevents irreparable damage to the batteries. Refer also to "Connecting the batteries" on page 32.

**Thermal probe:** an accessory tool, to be connected to the panel and attached to the battery pack. This device monitors the temperature of the external battery pack and regulates the battery charge accordingly. Refer also to "Thermal Probe" on page 33.

**RS485 Bus:** 4 wire BUS for the Repeater connections. Four pole twisted cable must be used for all connections. Refer also to "Connecting the RS485 BUS" on page 27.

**Timer:** a logical entity (the panel provides 8 timers) for automatic time-management of preset intervals (2 intervals per day) on preset days of the week and specific dates. The timers can be used in equations and/or to manage predefined operations.

**Equation:** a group of logical conditions defined by the installer. An equation comprises a series of operators (AND, OR, +, etc.) and a series of operands (Points, Zones, Timers, etc.). An equation can be associated with an output that will activate when the equation is satisfied.

Holidays: a list of days defined during the system configuration phase that can be associated with a timer.

**Early Warning:** a signal generated by detectors with the early-warning feature (to be defined during the system configuration phase). The detector senses for a level of smoke or heat that exceeds its early warning threshold (each detectors can be set separately). This signal indicates that the person/s responsible for the safety of the building and its occupants should verify the alarm or check the functionality of the detector concerned.

# **1.3** In order to validate the IMQ-SISTEMI DI SICUREZZA certification, and in compliance with EN54-2,

all the manual alarm buttons and fire detectors employed in the system must be associated with fire detection and alarm functions.

#### **1.4** The SmartLight fire alarm panel models

The available models are:

- SmartLight/G **SmartLight Gold** model manages 240 loop devices and 30 zones.
- SmartLight/S Smartlight Silver model manages 64 loop devices and 16 zones.



# Chapter 2

# **General information**

### 2.1 In-box documentation

- Installation manual (this manual)
- User Manual

The Installation manual is inside the device package. For further copies of the Installation Manual, please contact INIM ELECTRONICS offices quoting the order number shown in Appendix F - Order Codes.

### 2.2 Manual details

Title: SmartLight Installation and Programming Manual

- Edition, Issue: 1.10
- Month and Year of printing: June 2008
- Installation manual code: DCMIINE0SLIGHT

#### 2.3 Software information

- SmartLight Firmware Version: 1.0.x
- Extinguishant module Firmware Version: 1.0.x
- SmartLeague Software Version: 2.x.x

#### 2.4 Addressees

- Installer
- Technical assistance

#### 2.5 Operator authorization—access level

The SmartLight is EN-54 compliant. There are four access levels:

Level 1: All building occupants.

All building occupants can view the system status (active events) and events log; silence the panel beeper and, under pre-alarm conditions, override pre-alarm status and activate an instant alarm.

**Level 2:** Authorized operators — person/s responsible for the safety of the building and its occupants.

Authorized operators (keyswitch and PIN users) can silence the outputs; reset the panel; activate the 'Investigation' delay; disable zones, points and outputs; change the operating mode (Day/Night) and activate the 'Evacuation' alarm.

**Level 3:** Authorized technicians appointed by the Installer company.

Authorized technicians can, by means of a screw driver or similar tool, remove the screws and open panel box, in order to insert the programming jumper and access the programming phase (from panel or PC) or carry out maintenance work. The events cannot be accessed during the programming phase.

Level 4: Authorized technicians, appointed by the Manufacturer (INIM Electronics s.r.l.).

The manufacturer technicians can, by means of special tools, repair or replace the control panel components.



**Note:** This manual is for Authorized technicians (Level 3). However, it also provides some installation information regarding level 1 and level 2.

#### 2.6 Intellectual property rights

The information contained in this document is private property. All rights reserved.

No part of this document may be copied or reproduced unless expressly authorized in writing by INIM Electronics, in particular the parts regarding the device specified in *2.15 Device identifier* INIM Electronics s.r.l. shall not be responsible for damage arising from improper application or use.

#### 2.7 Disclaimer

INIM Electronics s.r.l. shall not be responsible for damage arising from improper application or use.

This control panel should be handled by qualified personnel only. Installation must be carried out strictly in accordance with the instructions described in this manual, and in compliance with the local fire code in force.

#### 2.8 Recommendations

INIM Electronics recommends that the entire system be tested on a regular basis (refer to paragraph *2.9 Testing the system*).

#### 2.9 Testing the system

This system has been designed to the highest standards of quality and performance. The system may fail to function as intended due to the failure of a component. Most problems that prevent a fire control system from operating as intended can be found by regular testing and maintenance (refer to *Appendice A* - Maintenance).

Testing should include all detectors, signaling devices and any other operational devices that are part of the system.

#### 2.10 Note to the installer

In order to provide adequate protection and instructions for proper use, you (the installer) must be familiar with the operating procedure of this device. As the only individual in contact with system users, it is your responsibility to instruct them on how to use this system properly and to bring to their attention that every fire is different in the amount of smoke and rate of burning. Therefore, smoke and heat detectors may not provide timely warning of fires caused by violent explosions, escaping gas or improper storage of inflammable materials.

Regardless of its capabilities, a fire alarm system is not a substitute for the necessary precautions building occupants must take to prevent or minimize the harmful effects of fire.

#### 2.11 Technical support

Our professional engineers are readily available to assist you. Call our phone number and you will be connected right away to a person who will answer all your questions and provide you with full technical support.

#### 2.12 Key

#### 2.12.1 Glossary and terminology

Panel; device; system: refer to the devices defined in 2.15 Device identifier.

Left, right, behind, above, below: refer to the directions as seen by the operator in front of the mounted device.

**Communicator** (telephone, SMS, digital): synonym of dialler.

**STP:** Shielded twisted pair cable.

**Qualified personnel**: those persons whose training, expertise and knowledge of the laws and bylaws regarding service conditions and the prevention of accidents, are able to identify and avoid all possible situations of danger.

Select: click on and select a specific item (from drop-down menu, options box, graphic object, etc.).

Press: click on a video button, or press a key on the panel keypad.

#### 2.12.2 Graphic key

Following are the graphic conventions used in the text. For a description of the graphic conventions relating to the interface, refer to paragraph *5.1 SmartLight panel frontplate*.

Conventions	Example	description
Text in Italics	Refer to" <i>paragraph</i> 4.1 Internal devices".	Text in italics: indicates the title of a chapter, section, paragraph, table or figure in this manual or other published reference.
<text></text>	# <customercode></customercode>	Variable data.
[lowercase letter] or [number]	[A] or [1]	Representation of a part of the system or video object.
BUTTON	CANC, ESC, RESET	Computer or control panel keys.

**Note:** The detached notes contain important information about the text.

Attention: The attention prompts indicate that total or partial disregard of the procedure could damage the connected devices.

Danger: The danger warnings indicate that total or partial disregard of the procedure could injure the operator or persons in the vicinity.

#### 2.13 Menu paths

Example

From panel: <key>, Configuration, Loop, <OK>, Loop Parameters

#### From PC: Panel, Loop

Access to specific functions can be achieved by using the panel keys or PC video objects and the respective path.

**Note:** This manual describes the recommended programming flow. This manual describes the loop configuration procedure from the panel, as indicated in the example.

Attention: For most part this manual describes programming from the control panel.

# **2.14** Manufacturer's name and address

INIM Electronics s.r.l. Via Fosso Antico, Centobuchi

63033 Monteprandone (AP) - Italy

Tel: +39 0735 70 50 07

Fax: +39 0735 70 49 12

info@inim.biz - www.inim.biz

# 2.15 Device identifier



Figure 2 - Overview

Product type: Fire control panel

Model: SmartLight

Year of Manufacture: from 2008

### 2.16 Warranty

INIM Electronics s.r.l. warrants the original purchaser that for a period of 24 months from the date of production, the product shall be free of defects in materials and workmanship. The warranty applies only to defects in parts and workmanship relating to normal use. It does not cover:

- Improper use or negligence
- Damage caused by fire, flood, wind or lightning
- Vandalism
- Fair wear and tear

Inim Electronics s.r.l. shall, at its option, repair or replace any defective products. Improper use, that is, use for purposes other than those mentioned in this manual will void the warranty. For the full details and conditions regarding the warranty, refer to the purchase order.

### 2.17 Safety laws

The aim of the instructions in this section is to ensure that the device is installed and handled properly. This chapter contains vital information. The installer should be familiar with this section and bring each item to the attention of the system users.

#### 2.17.1 Compliancy

The design and manufacture of the SmartLight panel comply with EN 54-2 requirements *Fire detection and signaling systems - Control and signaling panels.* 

The design and manufacture of the power supply complies with EN 54-2 *Fire detection and signaling systems - Power supply devices*.

SmartLight has been developed and designed in compliance with EN 12094-1 Fire-fighting Systems - Components of fire-extinguishant systems - Part 1: Requirements and testing methods for automatic electrical command and fire-extinction or delay management devices.

#### 2.17.2 Managing electronic devices

The normal motions of any person may generate electrostatic potential of thousands of volts. Discharge of this current through semiconductor devices during handling may cause serious damage which although may not be immediately evident may reduce the reliability of the circuits.

If located in their housings, the electronic circuits of INIM Electronics products are highly immune to electrostatic discharge.

Do not expose the circuits to damage by removing the modules unnecessarily from their housings.

- 1. When removing or handling the boards, hold the board edges only.
- 2. Do not touch the electronic components, the printed circuits or the metal parts of the connectors.
- 3. Do not hand the module to another person without first ensuring that you both have the same electrostatic potential. This can be achieved by simply shaking hands.
- 4. Place the module on an anti-static surface or a conductor surface with the same potential.

Further information regarding procedures relating to safety when working with electronic devices can be found in Directive *IEC 60147-0F*.

#### 2.17.3 Setting up the system

In order to provide adequate protection and instructions for proper use, security professionals (Installers and maintenance technicians) must be familiar with the operating procedure of this device.

Please read the instructions carefully before installing and/or servicing the system.

Before first power-up, be sure that the earth connection has been completed properly on the respective terminal.

The recommended minimum wire cross section for the earth connection is 2.5 mm<sup>2</sup>, that is, unless otherwise stated in accessory documentation.

#### 2.17.4 Replacement and disposal of used devices

#### Replacement

When replacing used devices, disconnect the devices concerned then complete the connections of the new devices in compliance with the instructions printed on the respective leaflets.

Contact your local municipal offices for information regarding the disposal of used electronic devices.

#### Disposal

Do not burn used electronic devices, or allow them to pollute the environment (countryside, rivers, etc.). Electronic devices must be disposed of in a safe environment-friendly way. In order to avoid short-circuits, take all the necessary precautions when removing used batteries. Contact your local municipal offices for information regarding the disposal of batteries.



# Chapter 3

# **Device management**

### 3.1 Product handling and storage

This device has been properly packed inside a cardboard box, however, care must be taken to avoid accidental damage during handling. Cartons/boxes should be placed in such a way as to avoid knocks and falls, and special care must be taken to protect the devices from extreme heat and/or cold.

### 3.2 Environmental conditions

Temperature limits

-10° / +55°C for transport and storage

-5° / +40°C operating temperature

### 3.3 Unpacking the device

Take due care when unpacking the product, and dispose of all waste packaging in accordance with the local method of disposal.

The cardboard box contains the Smartlight system box (in metal) and components.

Note: The two lead batteries @ 12 V - 7 Ah are not included. Be sure you have the batteries on hand before starting.

When you remove the four screws and metal-frontplate, you will find:

- The SmartLight motherboard mounted on a plastic support that bridges the two sides of the metal box.
- Power supply module located under the plastic support. The power supply module is connected to the SmartLight motherboard.
- A plastic bag containing:
  - Battery connection wires
  - Resistors and EOL diodes for supervised circuits



#### Figure 3 - Inside the box

The following accessory items must be ordered separately (see Appendix F - Order Codes):

- [A] Extinguishant module
- [B] Repeater
- [C] Thermal probe for battery charge optimization



inim

Figure 4 - Accessory devices



# **Chapter 4**

# **Technical description**

# 4.1 Internal devices



#### Figure 5 - SmartLight motherboard

#### Main components

[A]	Loop output terminals
[B]	Loop input terminals
[C]	Loop status LED (refer to Chapter 5 - User Interface)
[D]	RS232 serial port for PC connection
[E]	Dialler output—supervised
[F]	RS485 BUS terminals for Repeater connections, max.100mA
[G]	Fault output—dry contact
[H]	Fault output—supervised
[I]	Alarm output—supervised
[]]	24 V 0.8A output for external loads



[K]	Connector for the earth wire of the power supply module
[L]	Power-supply module connector
[M]	Battery connector
[N]	Thermal probe (accessory item) connector
[0]	Earth-fault bypass jumper—if the jumper is removed, earth faults will not be signaled.
[P]	Jumper for programming from panel (keypad and LCD) J8
[Q]	Jumper for programming from PC J9
[R]	Extinguishant module connector
S	Buzzer

Note:

INIM s.r.l. reserves the right to change, replace, in part or entirely, the components not strictly relating to the user and therefore, which do not involve the installation process described in "Chapter 6 - Installing the SmartLight Panel".

#### 4.2 Technical Specifications

AC power	230 Vac (-15% + 10%) 50/60 Hz
Maximum current draw 230V	0.5 A
Maximum current draw on terminal +AUX	0.8 A
CURRENT RIPPLE on AUX and AUX-R outputs	1% MAX
Maximum battery-charge current	400mA
Battery specifications	2 x 12 V/7 Ah YUASA NP-12 FR or similar with case flame class UL94-V2 or higher
Output current	19V - 27.6V
Fuse (F2) - Switching power supply	F 6.3 A 250V
Fuse (F1) - Switching power supply (not resettable)	T 3.15 A 250V
Maximum output current ripple	1%
Operating temperature	-5°C 40°C
Dimensions	325 x 325 x 80 mm
Weight	2.8Kg

### 4.3 PCB current draw

Module	Standby current draw	Maximum current draw
SmartLight motherboard	70 mA	120 mA
Extinguishant module	10 mA	70 mA
SmartLetUSee/LCD (Repeater panel)	40 mA	80 mA



# Chapter 5

# **User Interface**



#### Figure 6 - Frontplate

## 5.1 SmartLight panel frontplate

#### 5.1.1 Commands

Denomination	Access Level 1	Access Level 2	Note
[A] 4 scroll keys ▲/▼/ OK/ESC			To be used to navigate through the menus on the display. The effect these keys have during programming depends on the specific field. See <i>Chapter 8 -</i> <i>Programming from the panel</i> .
[ <b>B</b> ] SILENCE	Push this button to silence (turn OFF) the panel beeper.	Silences (turns OFF) active outputs with the silenceable attribute. The silenceable outputs will hold silenced status until a new event occurs that releases the outputs automatically. The SILENCE button operates as a toggle switch, therefore, silenced outputs can be unsilenced by pushing the button again.	If the system is operating in Night mode, SILENCE status will be held for the preset SILENCE time only. This is a safety precaution designed to protect building occupants and persons in charge of night-security who, after silencing the system, may be overcome by smoke or fumes during fire investigation and unable to restart the alarm signaling devices manually.
[C] RESET		Push this button to clear any active events, delete the memory and restore standby conditions.	Any alarm/fault conditions which persist after RESET operations will generate new alarm/fault signals.



Denomination	Access Level 1	Access Level 2	Note
[D] EVACUATION	If this button is pressed during active pre-alarm conditions, the system will override the programmed pre- alarm time and generate an instant alarm (i.e. activate all evacuation-warning devices).	If this button is pressed when pre-alarm conditions are not active, the system will generate a panel alarm.	
[E] INVESTIGATE		If this button is pressed during active pre-alarm conditions, the system will add the preset investigation time to the running pre-alarm time (this operation can be done once only).	The extended alarm delay will allow authorized building occupants and/or security staff to check and verify the fire hazard.
	Extinguishant	t module (accessory item) comma	ands
[F] BYPASS EXTINGUISH Button		If this button is pressed once, the system will disable Extinguish commands. If this button is pressed again, the system will re-enable Extinguish commands.	This button can be used during testing and maintenance of the fire extinguishant devices.
[G] AUTOMATIC BYPASS Button		If you push this button once, the system will disable automatic extinguish commands generated by the Extinguishant module. If you push this button again, the system will re-enable automatic extinguish commands generated by the Extinguishant module.	
[H] MANUAL BYPASS Button		If you push this button once, the system will disable manual extinguish commands. If you push this button again, the system will re-enable manual extinguish commands. Refer also to "Connecting the Extinguishant module (optional system enhancement tool)" on page 30.	

# 5.1.2 Signaling

Denomination	ON Solid:	ON Blinking:	Note
[I] LCD			See Chapter 8 - Programming from the panel.
[J] SILENCE LED (yellow)	Indicates that the system has been silenced.		



Denomination	ON Solid:	ON Blinking:	Note
[K] INHIBIT RESET LED (yellow)	In the event of pre-alarm/ alarm, indicates that reset commands are not allowed. Reset will be allowed when all outputs have been silenced and this LED goes Off.		This feature ensures that persons responsible for the safety of the building and its occupants do not reset the system without first silencing the outputs, and evaluating the alarm. The silence operation will stop the signaling devices and restore quiet thus allowing the operator to consider the best way to proceed. The operator will then be able to reset the system and restore standby status.
[L] ALARM LED (red)	Indicates an alarm condition, that is, an input point (detector, callpoint, input module, etc.) set to generate alarms has detected alarm conditions.		Examples: a smoke detector has sensed a quantity of smoke that exceeds its alarm threshold; a heat detector has sensed rise in temperature that exceeds its alarm threshold; a callpoint has been activated, etc. Authorized persons only (level 2) can clear these conditions (which may occur after an early warning, pre-alarm, etc.) by means of silence/reset operations. Signaling will continue even after the cause of the alarm has ceased.
[M] PRE-ALARM LED (red)	Indicates a pre-alarm condition, that is, an input point (detector, callpoint, input module, etc.) set with a pre-alarm time has activated.		Examples: a smoke detector has sensed a quantity of smoke that exceeds its alarm threshold; a heat detector has sensed rise in temperature that exceeds its alarm threshold; a callpoint has been activated, etc. Only authorized persons (level 2) can clear these conditions (which may occur after an early warning, pre-alarm, etc.) by means of silence/reset operations. Signaling will continue even after the cause of the alarm has ceased. If the operator does not intervene in the meantime, the point in pre-alarm status will generate an alarm when the programmed pre-alarm time expires. The pre-alarm time is a short alarm delay that notifies the person/s responsible for the safety of the building and its occupants of the possibility of fire. An alarm will be generated when the programmed pre-alarm time expires, thus causing the evacuation of all the building. After pre-alarm notification, the person/s responsible for the safety of the building and its occupants will have time to verify the real risk of fire and, in the event of a false alarm, will be able to avoid unnecessary evacuation signaling.
[N] FAULT LED (yellow)	Indicates an active fault condition. The display will provide the fault details.	Indicates a restored fault condition in memory. To view the restored fault condition details, consult the events log using the Main menu (level 1).	Reset the panel (level 2) to restore the fault memory (LED Off).



Denomination	ON Solid:	ON Blinking:	Note	
[O] CPU FAULT LED (yellow)	Indicates trouble with the panel CPU—the panel must be sent back immediately to the manufacturer for repair.	Indicates that the CPU re-initialized (due to control panel shutdown or fault condition).	Danger:	If this LED "blinks", the efficiency of entire system must be checked. Reset the panel (level 2) to turn this LED Off.
[P] BYPASS LED (yellow)	Indicates that one (or more) of the system components (loop point, zone or output) has been bypassed.		The display wil details. Bypass service compor- generate faults sort and canno circumstances. bypassed (put maintenance w	I provide the respective sed components (put out-of- nents) will be unable to s, alarms or signals of any it be activated under any Components must be out-of-service) during york.
[Q] TEST LED (yellow)	Indicates that one or more components (points or zones) is undergoing tests.		A bypassed po (separately or generate alarm However, the r for several seco Off automatica technicians to and inspections need of consta verify/reset the points.	int which is undergoing tests as part of a zone) will not as or signaling of any kind. espective LED will turn On onds and then reset and turn Ily. This feature allows carry out point/zone tests s alone, as it eliminates the ntly returning to the panel to e events generated by the
[R] ON LED (green)	Indicates that the system is operating (On).		This LED will g primary (230 \ (batteries) pov	o Off in the event of joint / ac) and secondary ver failure.
[S] DIALLER ON LED (red)	Indicates that the dialler activation output is active.		The dialler will set delay) in th	be activated (after the pre- ne event of an alarm.
[T] DISABLE/ FAULT DIALLER LED (yellow)	Indicates that the dialler activation output is disabled or faulty—the display will provide the respective details.	Indicates restoral of a fault event. This condition can be cleared by reset only (level 2).		
[U] DISABLE/ FAULT BELLS LED (yellow)	Indicates that the sounder/ flasher activation output is disabled or faulty—the display will provide the respective details.	Indicates restoral of a fault event. This condition can be cleared by reset only (level 2).		
[V] NIGHT MODE LED (yellow)	Indicates that the panel is operating in night mode.		For safety reas points is cance night mode (nis seconds). As a the system car SILENCE time applied when n or awake in the security is the watchman or s by the dialler.	ons, the pre-alarm time of all lled automatically during ght mode pre-alarm time = 0 further safety precaution, n be silenced for the pre-set only. Night Mode should be to or few persons are present e building, and the building responsibility of a night ecurity patrol guard notified
Extinguishant module signaling (optional system enhancement tool)				
<b>[X] LED</b> BYPASS EXTINGUISH	Indicates disablement of all types of extinguish commands, via key [F] (refer to the previous table <i>5.1.1 Commands</i> ).			



Denomination	ON Solid:	ON Blinking:	Note
<b>[Y] LED</b> AUTOMATIC BYPASS	Indicates disablement of automatic extinguish commands, via key [G] (refer to the previous table 5.1.1 Commands).		
[Z] LED MANUAL BYPASS	Indicates disablement of manual extinguish commands, via key [H] (refer to the previous table 5.1.1 Commands).		
<b>[A1] LED</b> EXTINGUISH	Indicates that fire extinction is running.		
[ <b>B1] LED</b> PRE- EXTINGUISH	Indicates activation of the pre-extinguish output, refer to "Connecting the Extinguishant module (optional system enhancement tool)" on page 30, terminal J4.	Indicates that only one zone is in alarm status, therefore, the extinguishant system will not be activated. If another zone latches in alarm, the extinguishant system will be activated.	
<b>[C1] LED</b> FAULT	Indicates trouble with the fire extinction circuits.	Indicates restoral of a fault event.	This condition can be cleared by reset only (level 2).
[D1] LED STOP EXTINGUISH	Indicates that the fire extinguishant system has been stopped from a remote Hold-off unit (refer to "Connecting the Extinguishant module (optional system enhancement tool)" on page 30, terminal J7).	Indicates restoral of a Stop extinguishant event.	
[E1] LED CPU FAULT	Indicates a CPU fault that requires immediate repair.	Indicates restoral of a fault event.	

#### 5.2 Internal LEDs



#### Figure 7 - Internal LEDs

These LEDs indicate communication between the panel and the detectors. These LEDs indicate that the panel is interrogating its devices, the protocol it is using and whether or not the interrogated devices have responded.

The green LED [A] (nearest to the Loop-I terminals) will blink each time a loop device responds during the interrogation phase of the devices from address 1 through to the maximum number of devices allowed (refer to *Appendix B* and *Appendix C* regarding the number of devices accommodated by the loop).

The red LED [B] will blink each time a command is sent to a loop device using ARGUS communication protocol (refer to *Appendix B* and *Appendix C*).

The red LED [C] on the far right will blink each time a command is sent to a loop device using APOLLO communication protocol (refer to *Appendix B* and *Appendix C*). Under normal operating conditions, the red protocol LED will blink rapidly and the green response LED will flicker. The flickering phase depends on the number of devices connected to the loop. The more devices the longer the LED will flicker.

## 5.3 Repeater (optional)

Up to four Repeater panels can be connected to the RS485 Bus. Connected Repeater panels replicate all the information provided by the control panel and allow access to all Level 1 and 2 functions (View active events, Reset, Silence, etc. Access to the Main menu is not possible).



#### Figure 8 - Front view of the Repeater panel

The SmartLetUSee/LCD Repeater is supported by most control panel models. However, not all the keys/button will work if it is connected to the SmartLight panel. The following keys/buttons will work:

[A] Keys ▲/▼	Scroll keys which will allow navigation through menus, etc.
[B] EVACUATION	As per paragraph 5.1 SmartLight panel frontplate
[C] SILENCE	As per paragraph 5.1 SmartLight panel frontplate
[D] RESET	As per paragraph 5.1 SmartLight panel frontplate
[E] INVESTIGATE	As per paragraph 5.1 SmartLight panel frontplate
[F] BUZZER	Turns the panel beeper Off
[G] TEST	Turns On al the LEDs to verify functionality.

Repeaters provide the following signals.

#### 5.3.1 Display

The display provides same event data as the panel. For further details refer to paragraph 2.5 Signaling on the display in the User Manual.



### 5.3.2 LEDs

Denomination	ON Solid:	ON Blinking:	
[H] SILENCE	As per paragraph 5.1 SmartLight panel frontplate		
[I] RESET DISABLED	As per paragraph 5.1 SmartLight panel frontplate		
[J] INVESTIGATE	Indicates that investigation time has been requested.		
[K] ALARM	As per paragraph 5.1 SmartLight panel frontplate		
[L] PRE-ALARM	As per paragraph 5.1 SmartLight panel frontplate		
[M] FAULT	As per paragraph 5.1 SmartLight panel frontplate		
[N] CPU FAULT	Indicates that the Repeater CPU is not operating properly. If this occurs, the Repeater must be sent back to the manufacturer immediately for repair.		
[O] BYPASS	As per paragraph 5.1 SmartLight panel frontplate		
[P] TEST	As per paragraph 5.1 SmartLight panel frontplate		
[Q] NIGHT	As per paragraph 5.1 SmartLight panel frontplate		
[R] BATTERY	Indicates that the panel batteries are low or inefficient.	Indicates restoral of the low/ inefficient battery event.	
[S] EARTH	Indicates voltage dispersion to earth.	Indicate restoral of the voltage dispersion to earth event.	
[T] FUSE	Indicates protection fuse intervention due to short-circuit on the "AUX" output.	Indicates restoral of the short- circuit on "AUX" output event.	
[U] MAINS	Indicates Mains failure.	Indicates restoral of the Mains failure event.	
[V] BELLS - ACTIVE	Indicates that the ALARM NAC output is active.		
[W] BELLS - FAULT	Indicates an "ALARM NAC" output fault.	Indicates restoral of the "ALARM NAC" output fault event.	
[X] BELLS - BYPASSED	Indicates that the "ALARM NAC" output has been disabled.		
[Y] DIALLER - ACTIVE	Indicates that the "Dialler" output is active.		
[Z] DIALLER - FAULT	Indicates a "Dialler" output fault.	Indicates restoral of the "Dialler" output fault event.	
[Z1] DIALLER - BYPASSED	Indicates that the "Dialler" output has been disabled.		



# Installing the SmartLight Panel

### 6.1 Installing the Extinguishant module (accessory item)

The Extinguishant module is packed in a separate cardboard box. Together with the Extinguishant module (IN015), you will find a plastic bag containing:

- Pin header for the Extinguishant module to SmartLight motherboard connection
- Screws
- EOL resistors and diodes



Figure 9 - Extinguishant module—in box



#### Figure 10 - Mounting the Extinguishant Module

- 1. Remove the four securing screws and the frontplate.
- 2. Remove the four securing screws and the plastic support.
- 3. Position the SmartLight motherboard as shown in picture 3.
- 4. Locate the Extinguishant module in its housing.
- 5. Using the four screws, secure the Extinguishant module in position.

- 6. Connect pins J17 of the SmartLight motherboard to the respective pins J2 on the Extinguishant module.
- 7. Move the SmartLight motherboard back to its original position.
- 8. Replace the plastic support.

#### 6.2 Wall mounting

#### 6.2.1 Panel



#### Figure 11 - Mounting the panel

- Pull the wires through the wire entry and ensure they do not get in way of operations.
- Using the wall plugs, attach the backplate to the wall.

# **Danger:** Care must be taken not to drill in the vicinity of electrical wiring, heating ducts and plumbing.

#### 6.2.2 Repeater (optional system enhancement panel)



#### Figure 12 - Mounting the Repeater

- Remove the four frontplate screws and lift off the frontplate.
- Pull the wires through the wire entry on the back of the Repeater and ensure they do not get in way of operations.
- Using the wall plugs, attach the backplate to the wall.

#### 6.3 Connecting the Loop

The loop accommodates all the peripheral devices of the fire control system (detectors; callpoints; modules; etc.), and if necessary, also a Gas Extinguishant Module. For a full description of the devices the loop accommodates, refer to *Appendix B* and *Appendix C*.

You can use either a 2 or 4 wire connection. To create a 4 wire connection, start on the LOOP-O terminals, connect all the system devices and re-enter on the LOOP-I terminals. 4 wire connections tolerate one wiring fault. If loop interruption occurs, the panel will manage the section entering on the LOOP-I terminals separately, thus splitting the loop in two separate sections.



Figure 13 - 2 wire connection



#### Figure 14 - 4 wire connection

#### 6.3.1 Wiring

1. Use 2 pole shield twisted cable. The cable section must be compatible with the loop load (refer to *Appendix B* and *Appendix C* for further details).

#### Attention: The maximum wire length is 2000 m.

- 2. Connect the cable shield to the earth terminal [3] (one end of the loop only).
- 3. Fire alarm wires must be separate from other power wiring circuits.

#### Guidelines

Danger: - 2 wire connection, no more than 32 detectors can be connected to the loop.
- 4 wire connection, T junctions are prohibited, that is unless the maximum number of devices that risk isolation during any type loop fault does not exceed 32.
- If the system loop devices do not have built-in isolators, you must install an isolator for each group of 32 detectors. Refer to "Appendix B" and "Appendix C" for further details.
- All circuits should be wired using the local country Fire Code compliant method.

### 6.4 Connecting the Dialler

The panel dialler must have an activation terminal that will generate calls when it connects to GND (activation -A).



#### Figure 15 - Connecting the Dialler

#### 6.4.1 Wiring

- 1. Connect the telephone dialler to the *Dialer* terminals.
- 2. Connect a 10 k $\Omega$  resistor to the dialler, as shown in the previous figure. This resistor will monitor the integrity of the connection between the panel and the dialler and will signal any short-circuits or interruptions.

In the event of an alarm, the panel will trigger the dialler which, after the programmed delay, will send the respective calls to pre-set telephone numbers.



Figure 16 - Dialer balancing when the dialler is not connected

#### 6.5 Connecting the RS485 BUS

The *RS485* BUS terminals accommodate up to 4 Repeaters. These devices replicate all the panel data and provide remote access to the system. Repeaters should be located near the entrances/exits of the protected premises.

Repeater panels should be connected in parallel. The panel communicates with the Repeater panels using a highly noise-immune digital protocol.



#### Figure 17 - Connecting the RS485 BUS

#### 6.5.1 Wiring

- 1. Use a 4 pole STP cable.
- 2. The cable length between the panel and Repeater should not exceed 1000 m.
- 3. Connect the shield to earth (terminal 6 can be used for this connection).

#### 6.5.2 Repeater settings

1. Using the *Dip Switch* [A], assign an address to the Repeater.



#### Figure 18 - DIP Switch

#### Attention: All other DIP switch configurations are NOT allowed.

2. Ensure that the EOL jumper is set in the EOL position on the last Repeater on the line ONLY.





### 6.6 Connecting the fault signaling outputs

The panel provides 2 fault signaling outputs:

- A normally-open dry contact.
- A supervised output protected by a resettable fuse @ 0.3 A.



#### Figure 20 - Connecting the fault signaling outputs

During standby status the voltage applied to the output will be less than 0.5 V, thus not enough to activate the connected load, but enough to allow the panel to verify the integrity of the connection cable.

**Open or shorted conditions on the wires will generate a fault signal:** Open **or** Shorted Fault Output.

In the event of a fault, the output will activate, and the panel will supply 24 V in accordance with the polarity indicated on the board.

**Note:** In order to validate the IMQ-SISTEMI DI SICUREZZA certification, these outputs must not be used as Type J outputs (EN 54-1), therefore, they must not be used to command devices that transmit fault signals.

#### 6.6.1 Wiring

- Use NON-shielded cable. The wire section should be compatible with the wire length and load connected to the output.
- 2. Connect the EOL resistor (10 K $\Omega$ ) in parallel to the last device on the line.

### 6.7 Connecting the Alarm signaling output



#### Figure 21 - Connecting the Alarm output

The alarm output is a silenceable supervised output protected by a resettable fuse @ 0.9 A.

During standby status the panel will allow a low supervisory current to circulate on the line, with reverse polarity to that indicated on the board. The diodes connected in series to each load on the line will ensure that the current closes on the EOL resistor. This current allows the panel to verify cable integrity. Open or shorted conditions on the wires will generate a fault signal: Open OR Shorted Alarm Output.

In the event of an alarm, the output will activate and the panel will supply 24 V in accordance with the polarity indicated on the board.

#### 6.7.1 Wiring

1. Use NON-shielded cable.

The wire section should be compatible with the wire length and load connected to the output.

- 2. Connect the EOL resistor (47 K $\Omega$ ) in parallel to the last device on the line.
- 3. Connect a 1N4007 diode (or equivalent) in series to each load.

#### 6.8 Connecting the Extinguishant module (optional system enhancement tool)



Figure 22 - Extinguishant module



## 6.8.1 Inputs

Denomination Terminal	Device to be connected	Input Type	Note	Wiring Diagram
MAN-EXT	Extinction system Start button	Supervised	Up to 20 devices can be connected to this input.	see fig.21/A 47K = Standby 15K = Active
STOP-EXT	STOP extinguishant- system button	Supervised	The STOP extinguishant-system button should always be located near to the protected area. This will allow any persons present during the release of extinguishant gas to stop the process and evacuate the area unharmed. Up to 20 devices can be connected to this input.	see fig.21/A 47K = Standby 15K = Active
PRESS	Gas extinguishant pressure switch	Supervised	The pressure switch has two functions: - Under normal operating conditions, it monitors the pressure of the Gas extinguishant. If the pressure drops spontaneously below the pre-set value, it will generate a fault signal. - After an 'Extinction' command, it confirms that the command has been executed.	see fig.21/A 47K = Standby 15K = Active

## 6.8.2 Outputs

Denomination Terminal	Device/s to connect	Output Type	Note	Wiring Diagram
VALVE	Electrovalve for gas release.	Supervised		see fig.21/B
PRE-EXT	Audible and Visual signaling devices	Supervised	The signaling devices activate as soon as the detectors sense fire conditions that require gas extinguishant intervention. This will allow building occupants to evacuate the building before the gas extinguishant is released. The delay between the activation of alarm signaling devices and the release of the gas extinguishant is customizable.	see fig.21/C 47K Balancing
RELEASED	"Extinguishant Gas release" signaling devices	Supervised	There are two activation modes: - activation on confirmation of Extinguishant Gas release; - simultaneous activation with the electrovalve output. This mode requires gas detectors in the protected environment.	see fig.21/C 47K Balancing



Denomination Terminal	Device/s to connect	Output Type	Note	Wiring Diagram
R	Remote LED that signals the deployment of the STOP extinguishant- system button.	Open Collector (Not- supervised)	Activates (closes to GND) in the event of activation of the STOP EXT input (max 100 mA).	see fig.21/D

#### 6.9 The AUX output

The AUX terminals provide the 24 V power supply to the peripheral devices. The output is protected by a resettable fuse @ 0.9 A.

In the event of short-circuit, the panel will signal a fault.

### 6.10 Connecting the Mains

The switching power supply module (housed inside the box under the motherboard) provides the power source to the entire system and recharges the batteries.

The panel must be connected to a separate line on the electrical switch board. The line must be protected by a fire code compliant sectioning device.

The protective earthing system must be compliant with the local safety regulations, fire code, laws and bylaws in force.

#### 6.10.1 Technical specifications

Primary power source: 230 V ac (-15% + 10%) 50/60 Hz.

Panel current draw: 0.5 A. (max.)

#### 6.10.2 Wiring



#### Figure 23 - Connecting the Mains

#### **Danger:** Switch Off the mains power.

- 1. Connect the wires to the terminal board [A] of the power supply.
- 2. Using a plastic cable tie, secure the cable to the hook [B] on the back of the control panel.

# Attention: Wiring circuits must not be commingled without proper separation. Adhere to the connection wiring in the diagram.

## 6.11 Connecting the batteries

The panel box provides housing for two 12 V-7 Ah lead batteries. The two batteries must be connected in series, in such way as to provide a 24 V current.

Using the battery terminal eyelet wire (included), insert the battery terminal bolt through the washer and battery terminal eyelet. The actual connection must be completed during the "Powering up the system" on page 38.

The batteries are the secondary power supply of the system. Once powered up, the panel will charge and monitor the batteries automatically. The battery monitoring process is as follows:

• Efficiency test

The panel checks the efficiency of the batteries by simulating load current demand at regular 60 second intervals. If the batteries fail to meet the demand, the event will be signaled on the respective trouble LED Battery disconnected.

Battery level test

In the event of mains failure, the panel continuously monitors the battery voltage. If it drops below 22.8 V, the panel will signal the event on the Low Battery LED. The event will end when the voltage restores to 24.6 V.

• Deep discharge shutdown If a mains failure event lasts for a long period, and battery voltage drops below 18 V, the panel will shutdown the batteries automatically in order to avoid irreparable damage.

# 6.12 Thermal Probe

Attention: In order to validate the IMQ-SISTEMI DI SICUREZZA certification and comply with EN 54-4 requirements, installation of a thermal probe is essential.

The battery has an on-board connector for a Thermal probe (accessory item). This device will regulate the charging process in accordance with the battery temperature. The thermal probe protects against battery overheating and consequent permanent damage.



#### 6.12.1 Connecting a thermal probe

#### Figure 24 - Connecting a thermal probe

- 1. Disconnect the batteries (if already connected).
- 2. Connect the thermal probe to the connector [C].
- 3. Using adhesive-insulating tape, attach the thermal probe to one of the batteries, in such way as to provide optimized heat-transfer measurements.
- 4. Hold a thermometer against the probe, and measure the probe temperature.

5. Using the following graph, find the value the measurement will be based on.



6. Using a tester, measure the voltage on the AUX [A] terminals and turn the trimmer [B] to the previously measured value.



Figure 26 - Adjusting the voltage charge



# Chapter 7

# Powering up and configuring the system

### 7.1 Testing wiring integrity

Double check the integrity of the wiring before first power up.

#### 7.1.1 Isolation from earth



Figure 27 - Isolation between cable shields and earthing system

- 1. Disconnect the wires from the terminals on the motherboard.
- 2. Using a tester, ensure there is no electric current flow between the wires and earthing system.
- 3. Reconnect the wires to their respective terminals on the motherboard.
- 4. Disconnect the cable shields from the respective terminals on the motherboard.
- 5. Using a tester, ensure there is no electric current flow between the cable shields and earthing system.
- 6. Reconnect the cable shields to their respective terminals on the motherboard.

#### **7.1.2** Testing the wiring integrity of the supervised outputs



#### Figure 28 - Supervised outputs

- 7. Disconnect the wires of the supervised outputs from the respective terminals on the motherboard.
- 8. Using a tester, measure the cable resistance. Test both polarities. At least one must have the same resistance value as the EOL resistor indicated in the previous figure.

# 7.1.3 Final tests



### Figure 29 - Final tests

- 9. Check that all cables are properly separated, bunched (by means of cable ties) and attached firmly to the cable hooks on the backbox.
- 10. Check the proper polarity of the primary power source connections (230 Vac).
- 11. Ensure that the cable is attached firmly (by means of a plastic cable tie) to the cable hook [A].

# 7.2 Testing Repeaters



#### Figure 30 - Testing Repeaters

- 12. Check that the Repeater panel DIP microswitches [B] have been properly set. See "Repeater settings" on page 28.
- 13. Check that the EOL resistance jumper [C] is in the EOL position on the last Repeater panel only.

#### 7.3 Connecting the RS232 PC serial link

Connect the RS232 cable to the device as indicated in the figure.


#### Figure 31 - RS232 serial port connection

Note:

The connection between the panel and the PC will be operative only when the PC programming jumper is inserted.

The cable should be connected to the device as shown:



Note:

The RS232 link can be ordered separately. The order code is indicated in "Appendix F". If your PC does not have a RS232 port but has a USB, use an RS232-USB adaptor.



#### 7.4 Powering up the system



#### Figure 32 - Connecting the batteries

- 1. Connect the connection wire [A] to the batteries. Refer also to "Connecting the batteries" on page 32.
- 2. Connect the connection wire [B] to the batteries.

#### Attention: Be sure that cable polarity is correct.

3. Connect the connector [C] of the battery wire to the control panel.

#### **Attention:** Ensure that connector polarity is correct.

The panel will take several seconds to stabilize, start up will be indicated by an intermittent audible signal and the Resetting message.

	Centrale	4	
	in funzione Esc 08/03/07 15:55	Ok	
STOP EXTINGUISHMENT	N ALARM FAULT DISABLE	D DISABLE FAULT DIALLER	
inim	PRE-ALARM CPU FAULT TEST	DISABLE FAULT BELLS	

#### Figure 33 - Reset signaling

Full panel reset will be indicated by:

- The On status of the green LED (indicating that the panel is operative).
- The CPU LED will blink to indicate that the board is initializing.
- If you do not carry out the successive step (connection to the mains power source) within 2 minutes, the Fault LED [N] will go On and the Mains Fault message will appear on the display.
- 4. Power up the panel from the mains.

A restored 'Mains faults' will be signaled by:

- Blinking on the Fault LED (indicating fault memory).
- 5. If the fault persists, check all wiring sections thoroughly. Refer to *Chapter 16 Diagnostics— Clearing Faults*.
- 6. Once all faults have been cleared, turn the key in the keyswitch (Access Level 2) and press the RESET button [C].



#### Figure 34 - RESET

After Reset operations, all the LEDs should go OFF, with the exception of the green LED [R] ON.

The display will show the "In Service" message.

7. Press any key to access the main menu. Using the ▼ key, select the second option on the Test LEDs menu. Press and hold <OK>, and check that all the LEDs go On.



# Programming from the panel

Access to programming is allowed only after the programming jumper has been inserted:

	1. Remove the frontplate.
Panel IN PROGRAMMING ver. 1.00	2. Insert the <b>jumper J8</b> (see Figure 5-C).
	3. The display will show the relevant message
01101101 01.00	4. The panel switches Off: no faults or alarms will be signaled.
Panel IN MAINTENANCE ver. 1.00 07/07/07 07:00	If this message appears, the programming phase has been bloc- ked via PC. If this occurs, only maintenance functions can be accessed.

**Note:** To unblock the programming phase, start the SmartLeague application on the PC and type in the code previously used to block it. This feature protects the system from being accessed by persons other than qualified technicians authorized by the Installer company.

Press <OK> to access the zone screen.

Press <ESC> to step back to the previous screen.

#### Menu options

→001 <zone< td=""><td>Descr.&gt;↑</td></zone<>	Descr.>↑
002 <zone< td=""><td>Descr. &gt;</td></zone<>	Descr. >
003 <zone< td=""><td>Descr. &gt;</td></zone<>	Descr. >
004 <zone< td=""><td>Descr.&gt;↓</td></zone<>	Descr.>↓

→Delay mains fail

-- hour -- mins Delay dialler

-- mins -- sec.

#### Editable alphanumeric field

Modify descr	Use keys $\blacktriangle$ and $\checkmark$ to move along the string.
$\uparrow\downarrow$ : move OK: mod.	Press and hold <ok> to scroll the alphanumeric characters.</ok>
<point 001=""></point>	Press <esc> to confirm the data entry, exit and step back to the previous screen.</esc>
Editable numeric field	

Press and hold <OK> to scroll the values the two-digit counters (e.g.: 0 to 99 and "--", which means non-specified).

'I' indicates that there is further information after the last line.

Use key  $\blacktriangle$  or  $\checkmark$  to move to the next programming field.

 $\ensuremath{\mathsf{Press}}\xspace < \ensuremath{\mathsf{ESC}}\xspace >$  to confirm the data entry, exit and step back to the previous screen.

#### Variable field

		Use key $\blacktriangle$ or $\checkmark$ to scroll the list.
Alarm: YES Pre-alarm: YES FAULT: YES Enabled: NO	Press $< OK >$ to toggle the value (e.g.: YES, NO)	
	YĒŠ NO	Press <esc> to confirm the data entry, exit and step back to the</esc>
		previous screen.

Note:

For the Programming from PC method, refer to "Chapter 16 - SmartLeague software.".



# Preparing the programming data

Before programming the panel, fire detectors, extinguishant module (if used) and loop points, set the following values.

## 9.1 Time and date

From the panel: <key>, Maintenance, Date and time

#### From PC: go to SmartLight Panel, System Programming, Date Time

Navigate through the programming field and set the new values. The system will select the day of the week automatically.

#### 9.2 Setting delays and times

From the panel: <key>, Programming, Option

From PC: (to follow)

Navigate through the programming field and set the new values.

#### 9.2.1 PARAMETERS

Delay mains failure	This is the delay (0 to 30 minutes) between a mains failure event and mains failure signaling on the control panel. This delay avoids unnecessary signaling of brief 'Mains failure' events.
	From PC: Go to SmartLight Panel/Power supply, Programming
Delay dialler	Delay (0 to 10 minutes): time between a zone alarm and DIALLER output activation.
	From PC: Go to SmartLight control panel, Programming
Verify Time	This delay allows the device to analyze the alarm conditions before triggering an alarm. If the point (detector) exceeds the pre-set threshold value, it will be reset by the panel. If the point (detector) exceeds the pre-set threshold value while the 'verify alarm' time is running, it will trigger an alarm. If it does not, it will restore to standby status. Applies to points with Verify=YES.
	From PC: go to SmartLight Panel/Loop, System Programming
Silence Time	Silence Time during Night Mode (starts when the $\langle$ SILENCE $\rangle$ button is pressed).
	From PC: go to SmartLight Panel, System Programming
Filter time	This represents the minimum duration of an line alarm or fault signal before the control panel will consider it as valid. This filter avoids unnecessary signaling of alarms and/or faults generated by a instantaneous activation (for example, when a fork-lift truck passes in front of the detection beam for an instant).
	From PC: go to SmartLight Panel/Loop, System Programming
Lock reset	This is the period (0 to 30 minutes), after activation of the Valve output, during which Reset operations are not allowed. If the extinguishant module receives a confirmation signal during this period, reset will be re-enabled.
	From PC: go to SmartLight Panel/Extinguish board, System Programming

#### 9.3 Other options

From the panel: **<key>**, **Programming**, **Option** 

#### From PC: go to SmartLight Panel, System Programming

Navigate through the programming field and set the new values.

#### 9.3.1 PARAMETERS

Monitor visible	Yes	Enables monitor event signaling on the display
	NO	Disables monitor event signaling on the display Events can be viewed in the events log only (refer to paragraph <i>15.2 Viewing Events</i> ).
Led blink	Yes	Enables visual signal (blinking) on the detector LEDs
	NO	Disables visual signaling (blinking) on detector LEDs
Max led on	Maximum number of loop LED that may switch on simultaneously	
Max remote	Maximum number of loop detector outputs that may activate simultaneously	

#### 9.4 Defining zones

#### From panel: <key>, Programming, Progr. zone, select zone number, <OK>

#### From PC: go to SmartLight Panel/Zones, System Programming

This option will allow you to create geographical point groups or "logical" point groups (e.g.: outputs). A zone will change status when one (or more) of its points triggers an alarm, pre-alarm, fault, early warning or monitor signal. Navigate through the programming field and set the new values.

# Attention: Consult the local laws in force for any restrictions regarding the "definition of zones" (dimensions and installation).

#### 9.4.1 PARAMETERS

ZONE	Zone number (maximum 30), preset.
<aaaaaaaaaaaaaa></aaaaaaaaaaaaaa>	Zone Description (e.g.downstairs kitchen).
Pre-alarm	Length of pre-alarm signal for the zone. The zone will trigger an alarm when the set time expires
Investigate	Length of investigation time, the countdown starts when the <investigate> button is pressed during pre-alarm status. Pressing this button will stop the pre-alarm timer and will start the <investigate> timer.</investigate></investigate>

#### 9.5 Setting holidays

#### From panel: <key>, Programming, Progr. holidays, select a holiday, <OK>

#### From PC: go to SmartLight Panel/Holidays, System Programming

This option will allow you to set specific periods which determine exceptions with regard timer programming, for example, holidays, bank holidays, etc. Navigate through the programming field and set the new values.

#### 9.5.1 PARAMETERS

HOLIDAY Number of holidays (maximum 15), preset.



day, month, year	Date of holiday or start date of holiday period. For an unspecified day, month or year, set "" (for example, to specify the 3rd of every month of every year set: day=3, month = "", year = ""). If you wish to create the setting using the day of the week (e.g. Sunday), set "" in the day, month, year fields.
Duration	Length of time (expressed in days) of the holiday period (0 at default). If you set 0, the system will not take the holiday into account.
Sunday, etc.	Day of the week for weekly arrangements. Valid only if <b>Duration</b> = 1

#### 9.6 Setting the Timers

#### From panel: <key>, Programming, Progr. timer, select timer, <OK>

#### From PC: go to SmartLight Panel/Timer, System Programming

This option will allow you define the timer intervals (e.g.: from 13.00 to 14.00), dates (e.g.: 25-12-2006) or special days (e.g.: Sundays and days of closure). The timer can be included in an equation and can contribute to the activation of an output. Timer activation may trigger associated actions (e.g. bypass a zone, toggle to Night Mode). Navigate through the programming field and set the new values.

#### 9.6.1 PARAMETERS

TIMER	Timer number (maximum 8), preset.
Interval 1, Start/End	Hour and minutes of the Start and End of the interval 1. If you do not wish to specify an interval, leave "".
Interval 2, Start/End	Hour and minutes of the Start and End of the interval 2. If you do not wish to specify an interval, leave "". If both intervals are set as "", the timer will operate on a 24 Hour basis.
day, month, year	Operational date of the timer. For an unspecified day, month or year, set "" (for example, to specify the 3rd of every month of every year set: day=3, month = "", year = "").
Sunday, etc.	Day of the week for weekly arrangements. Valid only when the <b>Day</b> , <b>month</b> , <b>year</b> are set as "". If you select <b>Holidays</b> , the timer will operate on the respective dates (refer to <i>paragraph 9.5 Setting holidays</i> ).
Force to Night Mode	Activation of the timer will switch the panel to Night mode. The panel cannot be switched back to Day mode until the set timer interval expires. Once the set timer interval expires, the panel can be switched back to day mode either by another timer or manually from the panel (refer to paragraph <i>15.3 Day/Night Mode</i> ).
Set Night Mode	Activation of the timer will switch the panel to Night mode. The panel can be switched back to Day mode either by another timer or manually from the panel.
Set Day Mode	Activation of the timer will switch the panel to Day mode. The panel can be switched back to Night mode either by another timer or manually from the panel.
Zone	Number of the zone to be bypassed/unbypassed.
Disable zone	Activation of the timer will bypass the specified zone.
Enable zone	Activation of the timer will unbypass the specified zone.



# **Configuring the loop**

When configuring the loop, you must define the typology (refer to *Appendix B* and *Appendix C*) and wiring (two or four wires), and also the connected devices. The connected devices may belong either to the fire control system (e.g.: detectors, modules, bells, etc.), or to the gas extinguishant system. The panel considers each device a "point" which must first be enrolled and then programmed.

**Note:** To install devices other than those specified in "Appendix B and Appendix C", you must use an input module to interface between the loop and the devices concerned.

Each point is assigned a device type (e.g.: optical smoke detector) and an address.

The following section describes the different ways of configuring loop points:

- 1. add/remove a point, using the respective address or type
- 2. assign an address to a device and allow it to acquire data from the panel
- 3. ask the panel to acquire data from the devices (all or only new devices) and assign their addresses (only for Argus).

Once the configuration has been completed, you can go on to program each separate point (refer to paragraph 11.1 Programming 'fire-detection' points).

# Attention:You must insert the respective programming jumper (J8 or J9) before starting the<br/>addressing procedure (J8 for programming from panel; J9 if for programming from PC).Note:In the first case, you can configure the loop without panel linkup, for example, at your office. The<br/>configuration can be downloaded to the panel later. In the other two cases, you can configure the<br/>loop from the panel or via a PC connected to the panel.<br/>Once the loop has been configured, any form of tamper to the device (e.g.: disconnection,<br/>dislodgement, etc.) will generate an anomaly signal.

## **10.1** Defining loop typology

From panel: <key>, Configuration, Loop, <OK>, Loop Parameters

#### From PC: go to SmartLight Panel/Loop, System Programming

Select the loop type (refer to *Appendix B* and *Appendix C*) and wiring type (2 or 4 wires).

#### 10.2 Adding/Removing any type of device manually

From the panel: **<key>**, **Configuration**, **Loop**, **<OK>**, **Add point** or **Delete point** 

#### From PC: go to SmartLight Panel/Loop, System Design

A new device can be added to the system configuration manually:

- 1. Select an unassigned address.
- 2. Associate the respective device type with the selected address.
- 3. Assign the respective address (as per the configuration) to the device (refer to *Appendix B* and *Appendix C*).
- 4. Connect the device to the loop.

- **Note:** This method is recommended for the addition or removal of a few devices only. The first configuration of a new installation should be done using the **Automatic Enrolling** option (only for devices that accept this method, refer to Appendix B B.6.3 Automatic setting of new devices) or the **Enroll devices** option (suitable for all devices) after an initial setting done manually on each separate device.
- 1. Select the address that corresponds to the physical position of the device (an assigned or unassigned address), press **<OK>**
- 2. Press  $\blacktriangle$  or  $\checkmark$  to select the address and device type.

**Note:** To remove a point, enter '0' in the "Type" programming field.

Once the points have been added, you must complete their programming (refer to paragraph 11.1 *Programming 'fire-detection' points*).

## **10.3** Configure the devices

Refer to Appendix B and Appendix C.

## 10.4 Checking enrolled/addressed devices

After initializing the enrolling procedure (for all devices) or the automatic-addressing procedure (only for devices that accept this method), you must wait for its completion, then compare the number of enrolled detectors/devices with the total number of detector/device placements.

If the totals differ:

- 1. Press **<OK>** to access **Programming points** (refer to paragraph *11.1 Programming 'fire- detection' points*).
- 2. Search the list for the devices that have not been found by the panel.
- 3. Clear the anomaly and re-initialize the addressing process.

If the totals match:

1. Press **<OK>** to access **Programming points** and program the points.



# **Programming fire detection points**

The panel sees all loop devices as points, therefore, the point must be duly programmed in order for the panel to determine their operating principles. Each point can be set up as an input and/or output. If a point is programmed as a 'fire-detection' point, the panel will deal with it as such and manage it accordingly.

Danger: In order to validate the IMQ-SISTEMI DI SICUREZZA certification, and in compliance with EN54-2 regulations, delays (pre-alarm time) must not be associated with the activation of the Dialler or "ALARM NAC" if activation is triggered by a manual callpoint.

## 11.1 Programming 'fire-detection' points

From panel: <key>, Programming, Progr. point, select point, <OK>

From PC: go to SmartLight Panel/Loop, System Programming

#### 11.1.1 General parameters

Address	Device address assigned during configuration		
Device type	Description of the device type assigned during configuration		
<point123></point123>	Example of a point description: "Downstairs kitchen"		
Extinguish	Determines whether the point is for fire detection or fire extinction		
	Yes	the point is for extinction purposes	
	NO	the point is for detection purposes	
Zone	The zone the point belongs to.		
<zone nn=""></zone>	Zone label (description) assigned during the zone programming phase.		

#### 11.1.2 Detector parameters

Level	Only fo etc).	or detectors. Real-time value. This value depends on the type of detector (Heat, Smoke,		
Sensitivity Day				
Sensitivity Night	Only fo this thr on the	or detectors. Alarm threshold (the detector will trigger alarm if the analysis value exceeds reshold). If enabled (refer to Input), it will generate a signal. The threshold value depends type of detector (Heat, Smoke, etc).		
Warning	Only fo the ana thresho the leve	for detectors. Early warning threshold (the detector will generate an early-warning signal, if nalysis value exceeds this threshold). If enabled (refer to Input), it will generate a signal. The hold value depends on the type of detector (Heat, Smoke, etc). If a signal is not required, set evel at "".		
Verify	Only fo	for detectors.		
	YES	If the device value exceeds the set threshold, the panel will not generate an instant alarm, but will wait to see if the device values exceed the threshold again within the pre-set time (refer to paragraph <i>9.2 Setting delays and times</i> ). If the device value exceeds the threshold again, the panel will generate an alarm, otherwise, it will restore to standby.		
	NO	If the device value exceeds the threshold, the panel will generate an instant alarm.		

## **11.1.3 Signals emitted by the point**

Alarm	YES	If the analysis value exceeds the alarm threshold (refer to paragraph <i>11.1.2 Detector parameters</i> ), it will generate an alarm signal to the panel, trigger an alarm on the zone it belongs to (primary zone) and activate the associated outputs. The point cannot be used for Monitoring purposes.		
	NO	If the analysis value exceeds the alarm threshold, it will send an alarm signal to the panel, but not trigger an alarm on the zone it belongs to (primary zone) or activate its associated outputs. If alarm events do not require signal transmission to the panel, select Monitor as the activation signal.		
Pre-alarm	YES	If the analysis value exceeds the alarm threshold, it will send a pre-alarm signal to the panel, and will trigger the pre-alarm time of the zone it belongs to. When the pre-alarm time expires, it will generate an alarm on the zone it belongs to (primary zone) and activate its associated outputs. The point cannot be used for Monitoring purposes.		
	NO	If the analysis value exceeds the alarm threshold, it will send an alarm signal to the panel, without activating the pre-alarm time.		
Fault	YES	If one of the possible faults occurs on the input (refer to <i>Chapter 16 - Diagnostics—Clearing Faults</i> ), it will send a fault signal to the panel and generate a fault on the zone it belongs to (primary zone).		
	NO	If one of the possible faults occurs on the input, it will be ignored.		
Warning	YES	If the analysis value exceeds the warning threshold, it will send a warning signal to the panel and the respective zone.		
	ΝΟ	If the analysis value exceeds the warning threshold, the event will be signaled on the panel but not on the zone.		
Monitor	YES	If the analysis value exceeds the alarm threshold, it will send a 'Monitor' signal to th panel and activate all the associated zone outputs.		
		Attention: Enablement of the Monitor signal inhibits the Alarm and Pre- alarm signals. If an input is programmed as 'Monitor', it will be unable to emit Alarm and Pre-alarm signals.		
	NO	The point will operate as an alarm point		
Actions	EXAMPLE	keyswitch that controls specific zones		
	Disable zone	Only for detectors with the "ON-OFF" option. Activation of the point bypasses the selected zone or zones.		
	Test zone	Only for detectors with the "ON-OFF" option. Activation of the point generates test conditions on the selected zone or zones.		
Pre-alarm Night mode	Enable or	disable the pre-alarm time during night mode.		
	EXAMPLE: buildings	: closed during the night do not require pre-alarm signaling.		
Mon. Restor.	YES	Only for the Monitor input. The outputs will restore to standby when alarm conditions clear. EXAMPLE: If the value exceeds the set threshold and, in response, the system activates a cooling system, the detector will stop signaling when the temperature restores to normal.		
	NO	Only for the Monitor input. If alarm conditions clear, the outputs will remain active.		

## 11.1.4 Signals that activate the output

Alarm	YES	The output will activate when one (or more) of its assigned zones goes into alarm status. A zone will generate an alarm when at least one of its input points goes into alarm status.
	NO	The output status will remain unchanged even if one of its assigned zones goes into alarm status.
Pre-alarm	YES	The output will activate when at least one of its assigned zones goes into pre-alarm status. A zone will generate a pre-alarm when at least one of its input points goes into pre-alarm status.
	NO	The output status will remain unchanged even if one of its assigned zones goes into pre- alarm status.
Fault	YES	The output will activate when at least one of its assigned zones signals fault status. A zone will generate a fault when one (or more) of its input points signals fault status.
	NO	The output status will remain unchanged even if one of its assigned zones signals fault status.
Warning	YES	The output will activate when one at least one of its assigned zones goes into early- warning status. A zone will generate an early warning when at least one of its input points goes into early-warning status.
	NO	The output status will remain unchanged even if one of its assigned zones goes into early- warning status.
Monitor	YES	The output will activate when at least one of its assigned zones goes into Monitor status. A zone will go into Monitor status if an input point goes into Monitor status.
	NO	The output status will remain unchanged even if one of the assigned zones goes into Monitor status.
Disable	YES	The output will activate when at least one of its assigned zones is bypassed.
	NO	The output status will remain unchanged even if one of the assigned zones is bypassed.
Test	YES	The output will activate when at least one of its assigned zones is in Test status.
	NO	The output status will remain unchanged even if one of the assigned zones is in Test status.
Primary Zone	хх	Number of a zone that activates the output. Successive zone group option = YES, the number of the first zone in the group.
	00	The output will activate when at least one of the system zones activates, that is, when the Alarm NAC output (Panel Alarm) is active.
Secondary Zone	ХХ	Number of another zone that activates the output Successive zone group option = YES, the number of the last zone in the group.
		The output can be activated by the primary zone only.
Zone group	YES	The output activates when one of the zones in the zone group activates (i.e. between the Primary zone and Secondary zone).
	NO	The output will activate when either one of the two zones indicated activates.
Echo point	YES	The output activates even if the input point is active.
	NO	The output will activate only when one of the signals selected under "Output" occurs.
	EXAM An ex locate	PLE: ternal LED, for instance, outside a hotel room, that replicates the status of the detector d inside.
Reset echo	YES	The output activates after a Reset.
Equation	Numb	er of the equation that activates the output.
Silenceable	YES	The output can be silenced (switched Off) by the <silence> button on the panel.</silence>
	NO	The output cannot be silenced. <silence> commands will be ignored.</silence>
Duration	Outpu	it activation time
Note:	Some interf	e of the parameters do not apply to certain devices. Accidental programming will not fere with the panel functions.



# Programming the Extinguishant module

The extinguishant module manages a gas extinguishant system activated by automatic or manual commands:

- automatic commands triggered by the fire-control panel when the programmed zones go into alarm status.
- manual commands from devices connected to the extinguishant module inputs or set up as firedetection loop input point.

The extinguishant module uses its own terminals and the loop points to provide its conditions of activation and command the outputs:



Figure 35 - Extinguishant module:

To ensure proper programming of the gas extinguishant system you must:

- 1. Configure the extinguishant module
- 2. Program the operating principles
- 3. Program the input and output extinction points

#### **12.1** Enable programming via PC

The extinguishant module can be programmed only via the SmartLeague software, whereas, the configuration and programming of the points can be done from the panel. If the programming jumper is not inserted, access to the programming via PC will be denied.



1. Remove the frontplate.

2. Insert the **jumper J9:** the respective message will appear. The panel keys will be disabled.

3. Connect your PC to the serial port (J7)

#### 12.2 Configuring the extinguishant module

From PC: go to System Design, Devices/Extinguishant module, drag and drop it to SmartLight Panel

From the panel: <key>, Programming, Configuration, Repeater-Ext., <OK>, <OK>

This option allows the panel to determine how many extinguishant modules are connected (this model accepts one module only).

#### 12.3 Programming the module

#### From PC: go to SmartLight Panel/Extinguishant module, Programming

From the panel: <key>, Programming, Extinct. board, <OK>

Program the parameters that define the operating principles of the system.

#### **12.3.1 PARAMETERS**

Zone group	Zones that will activate the fire extinguishant system if one (or more) of their input points goes into alarm status.		
Mode:			
	At least 1: If you select this mode, only one of the selected zones need be in alarm status in order to activate the fire extinguishant system.		
	At least 2: If you select this mode, at least 2 of the selected zones must be in alarm status in order to activate the fire extinguishant system.		
	ALL: If you select this mode, ALL the selected zones must be in alarm status in order to activate the fire extinguishant system.		
Confirm Extinguish	Extinguishant module feature that provides confirmation of extinguishant gas release.		
Do not confirm	If an "Extinguish" event occurs, the extinguishment module will activate the "valve" output (for the pre-set time) and the "released" output without awaiting confirmation of extinguishant gas release.		
Wait for "from pressure switch"	The RELEASED output will be activated when the <b>Extinction Time</b> expires, that is, if the "pressure switch" signal has been activated (from the pressure switch input or from an point set up as a "pressure switch" input). The "pressure switch" signal will be considered valid only when the signal persists after expiry of the Extinction Time.		
	EXAMPLE: You can connect a pressure-drop signaling device to the PRESS. input or an input point set up as a "pressure switch" (the device will signal when the cylinders empty thus confirming that the protected space has been successfully saturated).		

inim

Wait for "from flow detector"	The RELEASED output will be activated when the <b>Extinction Time</b> expires, that is, if the "from flow detector" signal has been activated during this phase (from the pressure switch input or from a point set up as a "flow detector" input).
	EXAMPLE: You can connect a gas-flow signaling device to the PRESS input or a point set up as a "flow detector" input (the device will signal when gas is being released).
Confirm extinction time	Delay between activation of the electrovalve output and the pressure switch activation analysis (if programmed as <b>Confirm extinction</b> ).
	EXAMPLE: In this way, the device connected to the pressure switch input can detect the pressure drop inside the cylinders and intervene.
Pause between discharges	Length of the pause between one gas discharge and another in the event of non- confirmation of gas discharge (extinguishant module allows three discharge events).
Extinguish Time	Length of time the electrovalve remains active, starting from the end of the pre-extinguish phase. If this value is not defined, the extinction phase will last until a "stop extinction" command is received (from a STOP-EXT input or point set up as a "STOP-EXT." input or from a button on the panel) or until the panel <reset> button is pressed.</reset>
Pre- extinguish Time	Duration of the automatic <b>Pre-extinguish Time</b> , activated by a zone in alarm status.
Manual Pre- extinguish Time	The duration of the manual pre-extinction phase, activated by a MAN-EXT input or extinction point set up as a manual extinction input or <b>manual extinguish</b> button.
RELEASED Time	Length of time the RELEASED output remains active, activated by the PRESS input (programmed as pressure switch) or VALVE output (start extinction).
	EXAMPLE: To keep gas saturation in the protected space at a constant level, connect a secondary electrovalve (smaller than the main electrovalve) to the RELEASED output.
Pressure switch input	Defines the significance of the signal coming from the PRESS input.
	Supervisory: Activation of the input signals a drop in gas extinguishant pressure.
	<b>From pressure switch</b> : activation of the input indicates that the gas cylinders are empty (therefore, the protected space is saturated), and activates the "confirm extinction from pressure switch" signal.

**From flow detector**: activation of the input indicates that gas has been released, and activates the "confirm extinction from flow detector" signal.

#### **12.4 Programming Extinction points**

#### From PC: SmartLight Panel/Loop, Programming, tick Extinction point

From the panel: <key>, Progr. points, select point, <OK>

The extinguishant module manages three inputs (e.g.: a button to stop the gas extinguishant) and three outputs (e.g.: a bell that alerts building occupants of the imminent release of gas). Under certain circumstances, it may be difficult to connect devices directly to the module, in such cases, you may find it easier to connect the extinction devices to the fire detection loop.

Programming a point as an Extinction point will allow the panel to identify it as an fire extinction device and manage it accordingly.

#### 12.4.1 General parameters

ADDRESS	Device address assigned during configuration		
<device></device>	Name of the device assigned during configuration		
POINT 123	Point Description		
Extinguish	Determines whether the point is for fire detection or extinction		
	Yes the point is for extinction purposes		
	NO the point is for detection purposes		
Ext. module	Number of extinguishant modules (currently 1 module only)		

# 12.4.2 Actions or operating mode of the input

	No signal, the point is disabled.			
Disable ext.	Disable	es extinguish commands, in the same way as the <b><extinguish></extinguish></b> button on the panel.		
	EXAMP	LE: During maintenance work on the fire extinguishant system.		
Disable man. ext.	Disable	es manual extinguish commands, in the same way as <b><manual< b="">&gt; button on the panel.</manual<></b>		
	EXAMP	LE: During maintenance work on a manual extinguish button.		
Disable auto. ext.	Disable panel.	Disables automatic extinguish commands, in the same way as <b><automatic></automatic></b> button on the panel.		
	EXAMP comma	LE: During maintenance work on the panel that may trigger unnecessary extinguish ands to the extinguishant module.		
Supervisory	Same a	Same as the <b>PRESS</b> input, but programmed as "Supervisory".		
	EXAMP safety	LE: A point connected to pressure switch that will signal if the pressure drops below the threshold.		
Pressure switch	Same a	as the <b>PRESS.</b> input, but programmed as "pressure switch".		
	EXAMP drop in saturat	LE: This input can manage a pressure detector that measures and signals pressure inside the gas extinguishant cylinders (thus confirming gas release and the successful tion of the protected space).		
Flow detector	Same a	as <b>PRESS</b> input, programmed as "flow detector"		
	EXAMPLE: This input can manage a flow detector that signals gas release (thus confirming the successful saturation of the protected space).			
Ext. manual	Same a	as <b>MAN-EXT</b> input.		
	EXAMP enviror	LE: A point connected to a Start-extinction button located inside the protected nment.		
Stop ext.	Same as STOP-EXT input			
	EXAMPLE: A point connected to a Stop-extinction button located inside the prot environment.			
Reset	YES	The signal can be reset (e.g.: by releasing the button).		
	NO	The signal will persist until the <reset> button on the panel is pressed.</reset>		



## 12.4.3 Signals that activate the point

	The point is not activated by any signal			
Pre- extinguish	Point activated at the same time as the <b>PRE-EXT</b> output			
Extinguish	Point activated at the same time as the <b>RELEASED</b> output programmed as "extinction"			
Confirm ext.	Point activated by a "pressure switch" input point or by the <b>PRESS</b> input programmed as "pressure switch" (refer to paragraph <i>12.3 Programming the module</i> ).			
Stop ext.	Point activated by the activation of "stop ext." input point or by the <b>STOP-EXT</b> input.			
Duration	Length of time the outputs will remain active.			
Silenceable	YES The output can be silenced.			
	NO	The output will remain active until the RESET button on the panel is pressed.		



# **Configuring the Repeaters**

#### From the panel: <key>, Programming, Configuration, Repeater-Ext., <OK>, <OK>

Repeaters are clone panels. They are equipped with displays and LEDs and replicate all the information provided by the panel. The panel supports up to 4 repeaters which, under normal circumstances, should be located at entrances/exits, in such way as to allow building occupants or fire officers to view alarm details without going too far inside the building.

After installing and addressing each Repeater, you must include them in the system configuration.

Current Devices Extinct. board n Repeater n OK to Configure This will allow the panel to recognize how many repeaters are connected to the BUS and show those found.

**Note:** The panel uses the screen above, to indicate the current configuration of repeaters and extinguishant modules. if you press OK (working from this screen), the panel will search the communication BUS and include any newly found devices in the configuration.

From PC: go to System Design, Devices/Repeater, drag and drop to SmartLight Panel/RS 425 BUS



# Closing the programming session

Once you have completed the programming, remove the panel/PC programming jumper. The panel will be ready to go into service, and the display will be as follows.

Double check the functionality of all the input/output devices.

Panel working

07/07/07 07:07

## 14.1 Reset default programming

In the Main programming menu, after Options, you will find Default data. If you select this option, you will access the 'Confirm' screen. If you press OK (working from this screen) all the programming data (panel and extinguishant module) will reset to default values (factory settings).



# Other maintenance operations

#### 15.1 Test Panel LEDs

Press <key>, Test led, <OK>: all the panel LEDs will go ON briefly.

#### **15.2 Viewing Events**

The system displays information regarding real-time events of major importance and disregards those of minor importance (e.g.: if the system is dealing with three fault events when a pre-alarm event occurs, the fault events will be disregarded and cleared from the display and the pre-alarm will take priority). All events are saved to the log and can be viewed.

#### 15.2.1 Signaling on the display

If several events of the same type occur, only the first will be shown on the display. If several alarms occur, the first alarm will remain on the first line of the display and the most recent alarm will be shown on the line below.

To view the events on the display, press button  $\blacktriangle$  or  $\blacktriangledown$ .

#### 15.2.2 Viewing the events log

**Press** <key>, View log, <OK>: all the recorded events (maximum 100) can be viewed in chronological order.

#### 15.3 Day/Night Mode

#### 15.3.1 Day

There are people in the building, therefore, those in charge of the safety of the building and its occupants should be duly informed before the evacuation command is given.

Silence	Silences (turns Off) the panel beeper and silenceable outputs. The Silence command will be
	undone automatically, if a new alarm event occurs (e.g.: another detector signals alarm conditions).

**Pre-alarm** Some points can be programmed to signal pre-alarm status. If no-one intervenes during the pre-alarm phase, the system will generate an alarm when the programmed pre-alarm time expires. Refer to paragraph *11.1 Programming 'fire-detection' points* to enable/disable the pre-alarm time of points.

Alarm Detectors can be programmed with a Day mode alarm threshold and a Night mode alarm threshold, refer to paragraph *11.1 Programming 'fire-detection' points*.

#### 15.3.2 Night

There are no people in the building, therefore, there is only one person in charge of building safety (e.g.: night watchman, guard).

- **Silence** The Silence command holds off signaling. The Silence phase will run for the pre-set time. If no-one intervenes during this phase, the system will undo the silence command and the alarm will continue. To change the night-mode silence time, refer to paragraph *9.2 Setting delays and times*.
- **Pre-alarm** The pre-alarm signal can be disabled on certain points. Alarm events will generate instant alarms. Refer to paragraph *11.1 Programming 'fire-detection' points* to enable/disable the pre-alarm time on points during Night mode.



**Alarm** Detectors can be programmed with a Day mode alarm threshold and a Night mode alarm threshold, refer to paragraph *11.1 Programming 'fire-detection' points* 

#### 15.3.3 Changing Day/Night mode manually

From the panel: <key>, Settings

#### 15.3.4 Changing Day/Night mode automatically

Setting up a timer (refer to paragraph 9.6 Setting the Timers) to toggle the panel status.

#### 15.4 Bypassing a zone or point

From the panel: <key>, Disablement, Point or Zone, <OK>, select point or zone, <OK>

Under certain circumstances (e.g. maintenance or fault), it may be necessary to bypass a zone or a point. Bypassed zones or points cannot generate fault or alarm signals and cannot be activated.

#### 15.5 Bypass Dialler output and supervised fault

From the panel: <key>, Disablement, Outputs, <OK>

Under certain circumstances (e.g. maintenance or fault), it may be necessary to bypass the dialler outputs (terminals 7-8) and Fault NAC (15-16). The bypassed object cannot be activated.

Bypass may be necessary in the event of fault signaling triggered by the Dialler or Supervised output (refer to *Chapter 16 - Diagnostics—Clearing Faults*).

#### **15.6** Testing points and zones

From the panel: <key>, Maintenance, Test point, select point, <OK>

#### From the panel:<key>, Maintenance, Test zone, select zone, <OK>

Maintenance work often entails point or zone tests. Points or zones in test status cannot generate faults or alarms signals, and cannot respond to activation signals. For example, if a zone is in test status, you can inspect all the zone detectors (points) without generating false alarms.

**Note:** When a detector (point) is put in test status, its LED will go On for several seconds.

 Point nnn↑
 1. Press <OK> to put the detector (point) or zone in test status.

 2. Press ▲ or ▼ to go to the adjacent point or zone.

#### 15.7 Force the LEDs and point outputs

From panel: <key>, Maintenance, Test led, select point, <OK>

From panel: <key>, Maintenance, Test output, select point, <OK>

After maintenance or on first startup, it may be necessary to force a point output or detector LED. For example, the On status of a detector LED allows fast identification of the detector location on the protected premises.

Point nnn↑ <Point descr.> Output: ON ↓

- 1. Press <OK> to activate/deactivate the LED or output
- 2. Press  $\blacktriangle$  or  $\blacksquare$  to go to the adjacent point or zone.

## **15.8** Set the date for the next maintenance session

#### From panel:<key>, Maintenance, Maintenance, <OK>

#### From PC: go to SmartLight Panel/Loop, Programming, tick Extinction point

If you have set the date of the next maintenance session, the system will signal a fault event on the specified date. Only a new date, selected via this menu, will clear this fault signal.

Maintenance

dd/mm/yy hh:mm Monday

#### 15.9 Loop Diagnostics

From panel: <key>, Maintenance, Diagnostic

From PC: this feature is not available

This menu will allow you to carry out diagnostics on all the smoke detectors connected to the loop. After the diagnostics phase, the panel will show the maximum level of dust detected, the detector concerned and the average dust level of all the detectors.

Dirty	
Average	XXX%
Maximum	XXX%
Point	nnn



# **Diagnostics—Clearing Faults**

#### Danger: Only authorized operators (Level 2 or 3) may search for, and correct faults.

#### 16.1 "Open I/O" fault

The panel is unable to find the EOL resistor on the supervised input/output terminals. The next line indicates the specific terminals (NAC, on a module connected to the loop etc.).

Check the EOL resistor connection on the last device. Using a tester, check that the resistor has not burnt out.

#### 16.2 "Shorted I/O" fault

A short-circuit has been detected on the input/output terminals. The next line indicates the specific terminals (NAC, on a module connected to the loop etc.). Check the device connections and cable sections.

# 16.3 Loop fault

Fault	Cause	Remedy
The display will show the Short on A message.	A short-circuit has been detected on the wiring section between the "Loop - O" terminals and the first isolator on the loop.	Check the connections and integrity of the wiring on the section concerned.
The display will show the Short on R message (only for 4 wire loops).	A short-circuit has been detected on the wiring section between the "Loop - I" terminals and their nearest isolator on the loop.	Check the connections and integrity of the wiring on the section concerned.
The panel shows the Loop Open message (only for 4 wire loops). No loop continuity between the "Loop-O" and	One or more open isolators on the line.	Check all the isolators on the loop: the LED of at least one of the isolators will signal "isolated" status. Once you have found the open isolator, check the connections and integrity of the wiring on the cable section between the open isolator and the successive one.
"Loop-I" terminals.	Interrupted cable	Disconnect the "Loop-I" terminals of the panel; search the loop until you find the last device on the line in working order. To check whether a device is working or not, access the Main menu from the panel and select MAINTENANCE -> TEST POINT LEDS. This menu will allow you to turn the various device LEDs On and Off (refer also to <i>Chapter 15 - Other maintenance</i> <i>operations</i> ). Once you have found the last device on the line in working order, check the connections and integrity of the wiring in the adjacent cable section.
	The number of devices found by the panel is less than expected.	From the MAINTENANCE -> TEST POINT LEDS identify the devices which are not recognized (refer also to <i>Chapter 15</i> - <i>Other maintenance operations</i> ). Check the wiring of the devices concerned and their respective addresses.
	Duplicated address: means the same address has been assigned to two devices.	Using the MAINTENANCE -> TEST POINT LED menu: turn On the LED of the device with the duplicated address; find the loop devices with the duplicated address and assign them new addresses. Refer also to <i>Chapter 15</i> - <i>Other maintenance</i> <i>operations</i> .



## **16.4** Testing the Loop



Figure 36 - Internal LEDs

**Note:** Refer also to "Internal LEDs" on page 21.

#### 16.4.1 Testing the Loop status LEDs

Check that the loop transmission LED [B] or [C] which is blinking matches the loop type setting. In the event of mismatch, check the loop parameter settings.

#### 16.4.2 Testing the Loop response LED

The green loop LED [A] should flicker each time an interrogated device responds.

If the green LED goes On solid, it means that there is a conductive path between the two poles of the loop that allows current to circulate and thus blind the device response.

Check that there is nothing other than the devices connected to the loop.

#### 16.5 Repeater faults

If the **number of Repeaters recognised** by the control panel is **less** than expected (refer also to *Chapter 13 - Configuring the Repeaters*):

1. Check that the address of each Repeater has been set properly (by means of the DIP switches [D]).



#### Figure 37 - Repeater Settings

- 2. Check that the cabling is intact.
- 3. Check the connection polarity.
- 4. Check that the EOL jumper is in the EOL position only on the last Repeater connected the BUS.
- 5. Using a tester, measure the voltage across the +24 V and GND terminals of the RS485 BUS. If the voltage is less than 20 V, it means that the resettable protection fuse is open and the current draw of the devices connected to the BUS is excessive.
  - Disconnect the BUS devices and reconnect them one by one until you find the problem.

# 16.6 Battery Fault

#### **16.6.1 Battery Disconnected**

The battery is not connected or has failed the batter efficiency test.

- 1. Allow the batteries to charge for several hours.
- 2. If the fault signal persists, disconnect the batteries from the panel and test them separately.
- 3. If only one of the batteries has a voltage below 12.5 13 V:
- Replace the faulty battery only.
- Allow the batteries to charge for several hours.
- Check that the fault has cleared.
- 4. If both batteries have a voltage of 12.5 13 V, it means they are both inefficient (even though the voltage without load is correct).
- Replace both batteries.
- Allow them to charge for several hours.
- Check that the fault has cleared.



#### Figure 38 - Battery charge

- With the batteries disconnected, check the voltage on the battery connector [A], ensure that it is: 13.8 V, if a thermal probe is not fitted, or
  - that it matches the measurement indicated on the graph in *Figure 24 Charge current in relation to Battery Temperature* on page 33, if a thermal probe is fitted.
- If the voltage is incorrect, use the trimmer [B] to adjust it.

#### 16.6.2 Low Battery

The batteries are running low.

This signal should only be present during primary power source failure (Main 230 Vac). Mains power must be restored in order to charge the batteries.



# 16.7 Other faults

The panel shows the message:	Meaning
Fault Dialler	Trouble on the dialler communication line (dialer output).
Fault AUX	Short-circuit on the AUX terminals protected by the resettable fuse.
Mains failure	Primary power failure (230 Vac).
Ground fault	Voltage dispersion detected
Lost	A loop device (included in the configuration) cannot be found.
Duplicated Add.	There are two loop devices with the same address.
Maintenance	The pre-set date for Maintenance has expired.



# **Appendix A**

# Maintenance

The following operations must be carried out regularly.

- 1. Using a damp lint-free cloth, remove any dust that may have gathered on the control panel (do not use any kind of cleaning product or solvent!).
- 2. From panel, **Press <key>, Test led, <OK>** to check the proper operating capability of the LEDs and beeper.
- 3. Check the battery efficiency and change them if necessary.
- 4. Check the integrity of all wires and connections.
- 5. Ensure that there are no insects inside the control panel.
- 6. Carry out maintenance on the detectors (clean the outside and the detection chamber).

**Note:** Points 1 and 2 can be carried out by authorized persons, whereas all other points must be carried out by qualified technicians.



# **Appendix B**

# Argus devices accepted by the control panel

Note:

The ARGUS devices accepted by this control panel do not have IMQ-SISTEMI DI SICUREZZA certification, refer to the instructions leaflet provided with each device.

All Argus Vega devices have built-in loop isolators. Therefore, isolators are not required. A shortcircuit on the loop will not provoke loss of any device.

Each detector is equipped with a 3-colour LED: green (periodic blinking) indicates the detector is working properly (if enabled). Yellow indicates fault status or open isolator; red indicates alarm status (if enabled).

Detectors are equipped with test LEDs: if you hold a magnet near the detector base (near to the two notches) the detector should generate an alarm signal.

#### **B.1** Devices

Model	Name	Description	Note
V100	Analogue Photo detector	Optical Smoke detector	
V200	Analogue Multicriteria detector	Optical Smoke/Heat detector	
V350	Analogue heat detector	Heat detector	( <sup>a</sup> )
VCP100	Manual callpoint	Intelligent resettable callpoint	
VMI100	Input Module	Module with 1 Supervised Input	
VMMI100	Input Mini Module	Mini module with 1 Supervised Input	( <sup>b</sup> )
VMC100	Output Module	Module with 1 Supervised Output	
VMMC100	Output Mini Module	Mini Module with 1 Supervised Output	( <sup>b</sup> )
VMC120	Output Module Form C	Module with 1 form C Output (1 NON-Supervised Output)	
VMMC120	Output Mini Module Form C	Mini Module with 1firm C Output (1 NON-Supervised Output)	( <sup>b</sup> )
VMIC100	Input Output Module	Module with 1 Supervised Input + 1 Supervised Output	
VMMIC100	Input Output Mini Module	Mini Module with 1 Supervised Input + 1 Supervised Output	( <sup>b</sup> )
VMIC120	Input output Module Form C	Module with 1 Supervised Input + 1 NON-Supervised Output (dry contact)	
VMMIC120	Input output mini Module Form C	Mini Module with 1 Supervised Input + 1 NON-Supervised Output (dry contact)	( <sup>b</sup> )
VLS100	Intelligent Wall Sounder	Loop Powered Sounder	

a. Configured as "Rate-of-rise detector" at default (alarm triggered by rapid rise in temperature or when the temperature exceeds the 54°C alarm threshold). To configure as "High temperature detector" (Rate-of-rise feature bypassed and fixed temperature set at 70°C) use the VPU100 programmer. The panel will recognize the configuration criteria automatically.

b. Smaller model for customized housing.

## **B.2** Device Bases

Model	Name	Description	Note
VB100	Vega Universal Base	Standard Base x Detectors	
VDBS100	Deep Standard Base	Deep Standard Base	Allows connection to wall-mount cable runs
BLR100	Vega Relay Base	Relay Base	Relay activated by the detector ${\bf R}$ output attached to the base
VBS100	Detector Sounder Base	Base with Sounder	Activated by the detector ${\bf R}$ output attached to the base

# **B.3** Wireless devices

Model	Name	Description	Note
SGW2W	Wire to Wireless Translator		Connected to Loop, 32-device interface (Sagittarius series - SG) wireless to panel The panel sees the 32 devices as if they were connected to the Loop (with different addresses).
SG100	Wireless Analogue Photo detector	Wireless Optical detector	Used only with SGW2W.
SG200	Wireless Analogue Multicriteria detector	Wireless Optical/Heat detector	
SG350	Wireless Analogue thermal detector	Wireless Analogue thermal detector	( <sup>a</sup> )
SGMI100	Wireless Input Module	Wireless Input Module	
SGMC100	Wireless Output module	Wireless Output module	
SGCP100	Wireless Call Point	Wireless button	
SGRS100	Radio Sounder	Radio Sounder	

a. Configured as "Rate-of-rise detector" at default (alarm triggered by rapid rise in temperature or when the temperature exceeds the 54°C alarm threshold). To configure as "High temperature detector" (Rate-of-rise feature bypassed and fixed temperature set at 70°C) use the VPU100 programmer. The panel will recognize the configuration criteria automatically.

# **B.4** Device Consumption

#### **B.4.1 Detectors**

In standby: 90 µA

In alarm: 6 mA

#### **B.4.2 Modules**

In standby: 120  $\mu$ A

In alarm: 6mA

#### **B.5** Loop limitation

Use suitable twisted shielded cable for the loop wiring. Connect the shield to earth using terminal 3 or 6, connect it to one end of the loop only.

In order to allow the loop to function properly, you must section the device connection cable in such way that voltage drop along does not exceed 8 V. The following table shows the minimum dimensions for the loop wiring with regard the distance between the Loop-O terminals and the most distant device:

up to 500 m	min. 1 mm <sup>2</sup>
up to 1000 m	min. 1.5 mm <sup>2</sup>
up to 1500 m	min. 2 mm <sup>2</sup>
up to 2000 m	min 2.5 mm <sup>2</sup>

#### **B.6 Configuring Argus devices**

You can either use an Argus VPU100 programmer to set the Argus device addresses and then let SmartLight enroll them or, launch the automatic addressing procedure provided by the SmartLight.

#### Address range: 1 to 240

For detailed installation and addressing instructions, contact www.argussecurity.it.

#### B.6.1 Manual device addressing via VPU100

#### Addressing devices via VPU100

Work carefully through the Argus VPU100 addressing procedure and address all the devices.

#### Enrolling addresses

Once the Argus VPU100 addressing procedure has been completed, initialize the enrolling process.

From the panel: <key>, Programming, Configuration, Loop, <OK>, Auto configure, Acquire

#### From a PC: this feature is not available

#### **B.6.2** Automatic addressing of all devices

The SmartLight can assign an address (1 to 240) automatically to each loop device, starting from the device on the LOOP-0 (J18) terminal.

**Note:** The automatic addressing process will automatically delete the previous address.

Once all the loop device connections have been properly completed and double checked, initialize the process.

From the panel: <key>, Programming, Configuration, Loop, <OK>, Auto configure, Readdress all

From a PC: this feature is not available

#### **B.6.3** Automatic setting of new devices

The SmartLight can assign addresses automatically to loop devices with address 255 (set at default). Starting from the LOOP-0 (J18) terminal, the SmartLight will scan for the first device that requires addressing and will assign an available address (1 to 240).

**Note:** This method of addressing new devices does not affect any previously assigned addresses. In order to ensure that new devices will be addressed automatically, check that they are set at default address 255. This test can be done using the VPU100.

After connecting new devices to the loop, initialize the process.

From the panel: <key>, Programming, Configuration, Loop, <OK>, Auto configure, Readdress new

#### From a PC: this feature is not available



# **Appendix C**

# Apollo devices accepted by the panel

**Note:** The APOLLO devices accepted by this control panel do not have IMQ-SISTEMI DI SICUREZZA certification, refer to the instructions leaflet provided with each device.

Apollo devices are not equipped with built-in loop isolators (that is, if not otherwise specified). Therefore, you must install loop isolators in such way as to avoid the loss of devices in the event of short-circuit.

#### C.1 Devices

#### C.1.1 Detectors: XP95 series

**Note:** *XP95 series detectors are especially designed to operate with a sensibility of 55 (sensibility at default). Sensibility adjustment should be limited to cases where it is absolutely essential, as any change may lead to delays in loop response time.* 

Model	Name	Description
55000-885	XP95 Multisensor Detector	Fire Smoke / Heat detector
55000-600	XP95 Optical Smoke detector	Optical Smoke detector
55000-500	XP95 Ionization Smoke Detector	Ionization Smoke Detector
55000-400	XP95 Heat detector - standard temperature	Heat detector - standard temperature
55000-401	XP95 Heat detector - High temperature	Heat detector - High temperature
55000-640	XP95 I.S. Smoke detector	Intrinsic security Smoke detector
55000-440	XP95 I.S.Heat detector	Intrinsic security Heat detector
55000-540	XP95 I.S.Ionization Smoke detector	Intrinsic security Ionization Smoke detector

#### C.1.2 Detectors: Discovery series

Model	Name	Description
58000-600	Discovery Optical Smoke detector	Optical Smoke detector
58000-400	Discovery Heat detector	Heat detector
58000-700	Discovery Multisensor detector	Optical Smoke detector + Heat detector
58000-300	Discovery Carbon Monoxide detector	Carbon Monoxide detector
58000-500	Discovery Ionization Smoke detector	Ionization Smoke Detector



#### C.1.3 Detectors: Xplorer series

Note:

Xplorer series detectors are especially designed to operate with a sensibility of 55 (sensibility at default). Sensibility adjustment should be limited to cases where it is absolutely essential, as any change may lead to delays in loop response time.

Model	Name	Description
59000-405	Standard heat detector with standard base	Standard heat detector with standard base
59000-406	Standard heat detector with LED driver base	Standard heat detector with LED driver base
59000-407	Standard heat detector with base sounder	Standard heat detector with base sounder
59000-415	High temperature heat detector with standard base	High temperature heat detector with standard base
59000-416	High temperature heat detector with LED driver base	High temperature heat detector with LED driver base
59000-417	High temperature heat detector with base sounder	High temperature heat detector with base sounder
59000-605	Optical Smoke detector with standard base	Optical Smoke detector with standard base
59000-606	Optical Smoke detector with LED driver base	Optical Smoke detector with LED driver base
59000-607	Optical Smoke detector with base sounder	Optical Smoke detector with base sounder

#### C.2 Device Bases

Model	Name	Description
45681-210	XP95/DISCOVERY Mounting BASE	XP95/DISCOVERY Mounting BASE
45681-215	XP95 I.S. Mounting Base	Intrinsic Security Mounting Base
45681-321	XP95/DISCOVERY Isolating Base	Isolating Base for XP95 detectors
45681-242	XP95/DISCOVERY Low power relay base	Mounting Base with relay
45681-250	XP95/DISCOVERY E-Z fit base	Large Mounting Base (150mm)
45681-276	Ancillary Base Sounder	Base with Sounder

## C.3 Accessories

Model	Name	Description
55000-720	XP95 Isolator	XP95 Isolator for Loops
59000-700	XPlorer Isolator	XPlorer Isolator for Loops
55000-855	XP95 protocol translator	Protocol translator for intrinsically secure lines

# C.4 Callpoints

Model	Name	Description
55000-905	XP95 Manual Call Point - Surface mounting	XP95 Manual Call Point for loops - Surface mounting
55000-906	XP95 Manual Call Point - Flush mounting	XP95 Manual Call Point for loops - Flush mounting



55000-940	XP95 I.S. Manual Call Point	Intrinsic Security Manual call point
58000-910	Discovery Manual Call Point - Surface mounting	Discovery Manual Call Point - Surface mounting
58000-920	Discovery Manual Call Point - Flush mounting	Discovery Manual Call Point - Flush mounting
59000-910	Xplorer manual call point	Xplorer manual call point

# C.5 Sounder + Flasher

Model	Name	Description
55000-278	Loop Powered Sounder	Loop Powered Sounder
55000-274	Weatherproof loop powered sounder	Weatherproof loop powered sounder
45681-265	Intelligent Base Sounder	Intelligent Base Sounder
55000-877	Loop Powered beacon	Loop Powered beacon
45681-331	Loop Powered Sounder + Flasher	Loop Powered Sounder + Flasher

# C.6 Modules

Model	Name	Description
55000-809	XP95 Switch Monitor Plus	Module with 1Input with delay and reset output for waterflow detectors (waterflow alarm)
55000-810	XP95 Switch Monitor	Single Input Module
55000-813	XP95 Zone Monitor	Conventional Detector Interface Module
55000-818	XP95 Input/Output Module	Module with 1 Relay Output + 1 Supervised Input + 1 Non-Supervised Input
55000-819	XP95 Output Module	Module with 1 Relay Output
55000-823	XP95 Sounder Control Unit	Module with 1 Output for externally-powered sounder control
55000-875	XP95 Mains Switch Input Output	Module with 1 Supervised Input + 1 Relay x 220V
55000-832	XP95 Mini Switch monitor (interrupt)	Mini input module (interrupt)
55000-833	XP95 mini switch monitor	Mini Input module
59000-810	XPlorer Output Unit	XPlorer Output Unit (Non-supervised)
59000-820	XPlorer Switch Monitor	Supervised input module

# C.7 DIN RAIL Modules

Model	Name	Description
55000-803	XP95 DIN RAIL Input Output Unit	DIN RAIL Module with 1Input + 1 Output
55000-804	XP95 DIN Rail Output Unit	DIN Rail Module with 1 Output

55000-821	XP95 DIN RAIL Switch Monitor Plus	DIN RAIL Module with 1 Delayed Input and Reset Output for waterflow detectors (waterflow alarm)
55000-822	XP95 DIN RAIL Switch Monitor	DIN RAIL Module with 1 Input
55000-812	XP95 DIN RAIL Zone Monitor (with Isolator)	DIN RAIL Interface Module for Conventional Zones (with isolator)
55000-826	XP95 DIN RAIL Sounder control Unit	DIN RAIL Module with 1 sounder control output externally -powered
55000-802	XP95 DIN RAIL Dual Isolator	DIN RAIL Dual Isolator

# C.8 Modules with Isolators

Model	Name	Description
55000-841	XP95 Switch Monitor Plus with Isolator	DIN RAIL Module with 1 Delayed Input and Reset Output for waterflow detectors (waterflow alarm)
55000-843	XP95 Switch Monitor with Isolator	Single Input Module with Isolator
55000-845	XP95 Zone Monitor with Isolator	Interface Module for Conventional Zones with Isolator
55000-847	XP95 Input/Output module (with Isolator)	Module with 1relay output + 1 Supervised Input + 1 Non- supervised Input (optoisolated)
55000-849	XP95 Output unit with isolator	Module with 2 relay outputs with isolator
55000-852	XP95 Sounder control unit with isolator	Module with 1output for self-powered siren (optoisolated)

## C.9 Loop limitations

Use shielded twisted cable for the loop wiring. The shield should be connected to earth using terminal 3 or 6. Connect the shield to one end of the loop only.

In order to allow the loop to function properly, you must section the device connection cable in such way that voltage drop along does not exceed 8 V. The following table shows the minimum wire sections for the Loop wiring with regard the distance between the Loop-O terminals and the most distant device:

up to 500 m	min. 1 mm <sup>2</sup>
up to 1000 m	min. 1.5 mm <sup>2</sup>
up to 1500 m	min. 2 mm <sup>2</sup>
up to 2000 m	min 2.5 mm <sup>2</sup>

## C.10 Configuring APOLLO devices

You must address all Apollo devices manually, and then allow the Smart Light panel to learn the assigned addresses.

#### Available addresses: 1 through 126

For information regarding Apollo device installation and address assignment, contact **www.apollofire.co.uk**.

#### C.10.1 Addressing detectors manually using the XPERT card

#### Setting detector addresses manually

- 1. Detach the detector from its base and remove the XPERT card.
- 1. Remove the breakoffs in such way as to achieve the address you wish to assign (sum up the value of each breakoff). Example: for address 43 remove breakoffs 1, 2, 8 and 32.
- 2. Insert the XPERT card an re-attach the detector to its base.

#### Addressing modules manually

Remove the cover and set the DIP microswitches. Refer to the Instructions leaflet for the various combinations available.

#### Allow the Smart Light panel to learn the manually assigned addresses.

Once all the Apollo devices have been properly addressed, initialize the enrolling process.

From the panel: <key>, Programming, Configuration, Loop, <OK>, Auto configure, Acquire

From a PC: this feature is not available

# **Appendix D**

# SmartLeague software

#### D.1 Introduction

The SmartLight system can be programmed from the panel or from a PC. All the programming functions can be accessed through the software. If you wish to program the SmartLight system using a PC, you will need:

- a portable computer for parameter downloading to the powered-up wall-mounted device.
- SmartLeague software.

SmartLeague can run on the installer company's computer. It will allow installers to pre-program most of the system parameters from a remote location (no computer to control panel link is required during this phase).

Computer to control panel link up is required for uploading and download operations only. The connection cable must be long enough to reach the mounted device without difficulty. Refer to paragraph *7.3 Connecting the RS232 PC serial link*.

The system programming parameters are considered the system *solution*. You can save the system solution to the SmartLeague database and use it for maintenance purposes or as a "model" for other systems.

#### D.1.1 The layout

The initial page of the SmartLeague application is common to all the products. This page is always active, even during the programming phase:



[1]	Menu bar and icons for the functions related to the application itself, programming accessories.	
[2]	List of recent solutions, which can be used to create new solutions or retrieve existing solutions.	
[3]	Documentation installed on the computer.	
[4]	Area dedicated to after-sales service: through internet, you can consult the FAQ page and request information and suggestions via e-mail.	
[5]	Access to the Password, yo newsletters.	e area reserved for registered users of the INIM website. By means of a Username and u can access any upgraded versions of the software, firmware and manuals, and also
-----	---	--
	Note:	To change the Web address of the page and reconnection interval, select <b>Settings, Application</b> data, Miscellaneous .

# **D.1.2 Working with solutions**

Each product, from the simplest of devices to the to the most complicated, is represented by a *solution* that comprises the respective programming parameters and the installation procedure.

Each solution is dedicated to a device type and has its own programming interface. You can work on several solutions contemporarily, even on several different device types. Each solution has its own account, next to the **Start page**, which is always available:

inn SmartLeague		_
File Programming Settings Control panel ?		
Start Page <b>Small oon</b>		
	Se Sustem Devian Kak Sustem Programming	
Smart Light Panel		
- BB Power Supply		
E→BB RS485 BUS		
Hepeateru	Panel Label	
-BB Timer	Silence endurance in night 10 s 👻	
Equations	Monitorina	
001 - V100 optical smoke detector	Date Time 14/03/2007 16:40	
- 002 - V200 optical/heat detector		
003 - VMI100 Input Module		
	dd/mm/yy	
	Date view Mode C mm/dd/yy	
	C yy/mm/dd	
	Maintenance request on 01/01/2000 00.00	
	Lock Panel	
	_ Dialler	

In this way, it is possible to compare different solutions, or keep two solutions open (one real and the other for test purposes), in order to verify step by step the effects of the programming process.

A solution can be created and changed without computer to device link up. For example, you can prepare a system layout and/or set parameters without leaving your office. The data can be downloaded to the system when you are ready.

## D.1.3 How to create a solution and program devices

- 1. Select **New Solution** from the **Recent Solutions** section.
- 2. Select the type of device and model:

			×
Model	Description	Release firmware	4
K G J	GSM network dialer and communicator	1.1x	
OP		1.0x	
HT I	SmartLight	01.x	-
		🤣 OK 🛛 🔀 Cancel	
	Model JK <sup>G</sup> OP H1	Model Description ∬K G ⊻ GSM network dialer and communicator OP SmartLight	Model Description Release firmware G GSM network dialer and communicator 1.1x OP 1.0x C SmartLight 01.x OK X Cancel

The respective programming interface will appear.

# **D.2 Programming interface for SmartLight**

When a SmartLeague solution opens, the following interface will appear:

in Smar	tLeague		- 0
File	Programming Settings Control panel	<b>\</b>	
🖓 S	itart Page 📲 SmallLoop 📲 SmallLoop		
*		🔀 System Design 🔯 System Programming	
	Smart Light Panel		
	BS485 BUS		
	Repeater0	eeu Devices	
	Bepeater1	First name	
	Ben Timer	▶ Repeater	
	Be Equations	T Junction	
	-B Zones	Extinction Card	
	E-BB Loop		
	- 002 - V200 optical/heat detect		
	- 003 - V350 H.T. thermal detec		
	- 004 - VCP100 Manual Call Poi		
		- + 1 APOLLO	
	2		
		Modules	
		VCP100 Maxual Call Point	
		Vidi Too Markar can tonk	
		VAMUTOO Insuit Mini Madula	
[1]	The open solution is she	own, with other open solutions and the Start page in the background.	

[1]	The open solution is shown, with other open solutions and the start page in the background.
[2]	Tree-structure layout represented by a network of control panels, and built-in and optional hardware modules. The system can be built by dragging the components from the System design page and dropping them onto the control panel configuration section.
[3]	The Layout page allows the installer to select the system components (type of control panel, peripheral devices, modules) and drag and drop them onto tree structure.
[4]	Programming sheet to be selected in order to program the selected component.

# D.3 How to configure the system

- 1. From the **Control panel configuration** section, select the part of the control panel you intend to configure.
- 2. Drag any optional modules (boards) from the **Devices** section and drop them to the **Control panel configuration** tree.
- 3. From the **Control panel configuration** section, select the loop to be configured.
- 4. Select the **System Programming** page, and ensure the loop type is correct:

irim SmartLeague		- 🗆 ×
File Programming Settings Control panel ?		
1000 <b>8</b> 288		
😡 Start Page 📲 SmallLoop 📲 SmallLoop		₹
*	🔀 System Design 😽 System Programming	
Smart Light Panel		
BS485 BUS	Coop Parameters	
Holidays	Loop AFGUS  Vires  Alarm verification Time	•
By Equations	Loop Sizer	
- B9 Zones	Maximum Min section mm2 Worst case (	points at the end)
	Address Detector	



5. Select the **System Design**, and in the section regarding the type of loop you have selected (e.g.: Apollo, Argus) expand the device typology, drag and drop one device at a time to the Control panel configuration loop section :

him SmartLeague	<u>_0×</u>
File Programming Settings Control panel ?	
Stat Page ( Snall on ) ( Snall on )	
	<b>*</b>
Smatl Lickt Panel	
Heigh Holidays	
- BUD Timer First name	
Big Zones Fepeater	
T Junction	
🖉 001 - V100 optical smoke dete 👘 Extinction Card	
002 - V200 optical/heat detect	
Logger	
**	
- <u>+</u>   APOLLO	
ARGUS	
Device tipo	
Detectors	
First name	
V100 optical smoke detector	
V200 optical/heat detector	
V30 H.T. thermal detector	
V 350 Rate of Rise thermal detector	

Note:

To delete a component from the Control panel configuration, simply select the device concerned and press **CANC.** 

# D.4 How to program the control panel

Proceed with the programming of each component in the system configuration:

- 1. Select the component from the system configuration
- 2. Select the **Programming** page and change the parameters as required. Changes can be saved by means of the Save command only (from the menu or by right-clicking from any other point).





# About the SmartLeague software

# E.1 Installing SmartLeague software from the CD

If included in your purchase order, you will have the SmartLeague Installation CD containing the software for the respective SmartLight firmware. Check the software version, refer to **Help**, **About SmartLeague**. New versions of the SmartLeague software can be downloaded from the INIM electronics Website at www.inim.biz.

After installing the SmartLeague software, contact the Web address to find out about new versions. Internet connection required.

## Installation instructions

- 1. Insert the Installation CD into your service computer.
- 2. Select 'Computer Resources' on your desktop.
- 3. Find the CD unit, double click on the icon: the CD contents appear.
- 4. Double click on Setup.exe: the Welcome to the installation program window appears.
- 5. Select 'Continue': the **Folder selection** window appears.

**Note:** You should select the suggested folder.

6. Select 'Continue': file installation initializes, the progress bar will indicate completion.

**Note:** Always complete installation, do not select **Cancel** during the installation phase.

7. Once installation has been completed, the SmartLeague icon will appear on your desktop (if requested by the user) and in the program list: inim

## E.1.1 Check for the availability of a new version of the SmartLeague software.

- 1. Connect with the INIM website at www.inim.biz to find out about the upgrades of the SmartLeague software.
- 2. View the differences between the new version and the installed version.
- 3. Work carefully through the upgrade instructions.

## **E.1.2** Check for the availability of a new version of the firmware.

- 1. Connect with the INIM website at www.inim.biz to find out about the new version of the SmartLight firmware.
- 2. Work carefully through the download and installation instructions. All upgrades come with the revised version of the manual.

# E.2 Setting up the computer serial output

Using the **Settings, Application data, Serial Ports** menus, check that the selected settings match the serial cable you intend using for the computer to SmartLight panel connection.

# **E.3** Configuring a new system

- 1. Create a new solution (select **File, New**), or open a solution previously used for a similar system (select **File, Open**), and save it in the name of the new customer with the new account code.
- 2. Customize the parameter settings.



- 3. Save (select File, Save) and, if necessary, print the details (menu File, Print).
- 4. Connecting the device to the computer.
- 5. Download the 'solution' (configuration) to the device, select **Program, Download**): all six LEDs will blink during downloading phase.

#### E.4 Programming an installed device

- 1. Connecting the device to the computer.
- 2. Create a new solution (select **File, New**), or open the current solution (configuration) of the system (select **File, Open**).
- 3. To view the current parameters, select **Program, Upload**): all six LEDs will blink during the viewing phase.
- 4. Customize the parameter settings.
- 5. Save (select File, Save) and, if necessary, print the details (menu File, Print).
- Write the new 'solution' (configuration) on the device, select **Program, Download**): all six LEDs will blink during downloading phase.
- **Note:** If an error occurs during this phase, you will have to repeat the operation. The new data will overwrite the previous data of the SmartLight panel.

## E.5 Print

- 1. Define the Print-out header (e.g. logo, company name, etc.).
- 2. To type in the respective data, select **Printer settings**, from **Settings**, **Application settings**.
- 3. Select the ڬ icon and click on the file you wish to print.

# E.6 Verify version, inputs

- 1. Connect the computer to the RS232 serial port of the device.
- 2. Select **Status enquiry**, **Monitoring** from the menu: a window will open showing the IMEI code, the installed versions and the status of the batteries and inputs.

#### E.7 Viewing the Events log

- 1. Connect the computer to the RS232 serial port of the device.
- Create a new solution (select File, New), or open the current solution (configuration) of the system (select File, Open).
- 3. To view the contents of the events log, select Log.
- Select the <a>icon on the bottom left.</a>
- 5. The recorded events appear.

Note:

The contents of the event log can be printed or saved to the database.

**Note:** If an error occurs during this phase, you will have to repeat the operation. The new data will overwrite the previous data of the SmartLight panel.



# Appendix F

# **Order Codes**

Quote the following order codes when ordering INIM Electronics s.r.l. products:

Code	Description
SmartLight	Fire Control Panel
SmartLight-MAN-INST	Installation manual
SmartLetLoose/ONE	Extinguishant Module
ProbeTH	Thermal probe for battery charge optimization
SmartLetUSee/LCD	Repeater
SmartLeague	Programming software, runs under Windows
Link232F9F9	RS232 link

# Installer's notes:



#### **INIM Electronics s.r.l.**

Via Fosso Antico, Centobuchi 63033, Monteprandone AP - Italy

> Tel. +39 0735 70 50 07 Fax. +39 0735 730 49 12

email: info@inim.biz www.inim.biz

DCMIINE0SLIGHT-R110-20080604