


*Aristo*<sup>®</sup>

# *MechTig C2002i*



**Instruction manual**

<b>1 DIRECTIVE</b> .....	<b>3</b>
<b>2 SAFETY</b> .....	<b>3</b>
<b>3 INTRODUCTION</b> .....	<b>5</b>
3.1 Equipment .....	5
3.2 Control panel WO 100 .....	5
<b>4 TECHNICAL DATA</b> .....	<b>6</b>
<b>5 INSTALLATION</b> .....	<b>7</b>
5.1 Lifting instructions .....	7
5.2 Location .....	7
5.3 Mains power supply .....	7
5.4 Connecting the terminating resistor .....	8
<b>6 OPERATION</b> .....	<b>8</b>
6.1 Connections and control devices .....	8
6.2 Gas flow meter .....	9
6.3 USB connection .....	9
6.4 Water connection .....	9
6.5 Overheating protection .....	9
6.6 Flow guard, water .....	9
6.7 Flow guard, gas .....	9
6.8 Symbol explanations .....	10
<b>7 MAINTENANCE</b> .....	<b>10</b>
7.1 Inspection and cleaning .....	10
7.2 Topping up the coolant .....	11
7.3 Printer .....	11
<b>8 FAULT-TRACING</b> .....	<b>12</b>
<b>9 ORDERING SPARE PARTS</b> .....	<b>12</b>
<b>DIAGRAM</b> .....	<b>14</b>
<b>PUMP DATA</b> .....	<b>18</b>
<b>COOLING CHARACTERISTIC</b> .....	<b>19</b>
<b>ORDERING NUMBER</b> .....	<b>20</b>
<b>ACCESSORIES</b> .....	<b>21</b>

---

# 1 DIRECTIVE

---

## DECLARATION OF CONFORMITY

ESAB AB, Welding Equipment, SE-695 81 Laxå, Sweden, gives its unreserved guarantee that welding power source MechTig C2002i from serial number 810 are constructed and tested in compliance with the standard EN 60974-1 /-3 and EN 60974-10 (Class A) in accordance with the requirements of directive (2006/95/EC) and (2004/108/EEC).

-----

Laxå 2008-05-20



Kent Eimbrodt  
Global Director  
Equipment and Automation

---

# 2 SAFETY

---

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
  - its operation
  - location of emergency stops
  - its function
  - relevant safety precautions
  - welding and cutting
2. The operator must ensure that:
  - no unauthorized person is stationed within the working area of the equipment when it is started up.
  - no-one is unprotected when the arc is struck
3. The workplace must:
  - be suitable for the purpose
  - be free from drafts
4. Personal safety equipment
  - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves. **Note!** *Do not use safety gloves when replacing wire.*
  - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns.
5. General precautions
  - Make sure the return cable is connected securely.
  - Work on high voltage equipment **may only be carried out by a qualified electrician.**
  - Appropriate fire extinguishing equipment must be clearly marked and close at hand.
  - Lubrication and maintenance must **not** be carried out on the equipment during operation.



# WARNING



**Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.**

**ELECTRIC SHOCK - Can kill**

- Install and earth the unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

**FUMES AND GASES - Can be dangerous to health**

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

**ARC RAYS - Can injure eyes and burn skin.**

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

**FIRE HAZARD**

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.

**NOISE - Excessive noise can damage hearing**

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk.

**MALFUNCTION - Call for expert assistance in the event of malfunction.**

**Read and understand the instruction manual before installing or operating.**

**PROTECT YOURSELF AND OTHERS!**




## WARNING

**Do not use the power source for thawing frozen pipes.**




## CAUTION

*Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.*



## CAUTION

*This product is solely intended for arc welding.*



**Dispose of electronic equipment at the recycling facility!**

In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.


As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.



**CAUTION**

*Read and understand the instruction manual before installing or operating.*



**ESAB can provide you with all necessary welding protection and accessories.**

---

## 3 INTRODUCTION

---

**MechTig C2002i** is a welding power source intended for mechanized TIG welding.

**ESAB's accessories for the product can be found on page 21.**

### 3.1 Equipment

The power source is supplied with:

- instruction manual for the welding power source
- instruction manual for the control panel
- 5 m return cable
- terminating resistor.

### 3.2 Control panel WO 100



See the separate instruction manual for a detailed description of the control panel.

## 4 TECHNICAL DATA

<b>MechTig C2002i</b>	
<b>Mains voltage</b>	230 V ± 10%, 1~ 50/60 Hz
<b>Mains supply</b>	Z <sub>max</sub> 0.35 Ω
<b>Primary current</b> I <sub>max</sub>	22 A
<b>Setting range</b>	5 A - 200 A
<b>Permitted load</b>	
30% duty cycle	200 A / 18 V
35% duty cycle	180 A / 17 V
60 % duty cycle	150 A / 16 V
100% duty cycle	110 A / 14 V
<b>Power factor</b> at maximum current	0.98
<b>Efficiency</b> at maximum current	73 %
<b>Open-circuit voltage</b>	92 V
<b>Operating temperature</b>	-10 to +40° C
<b>Transportation temperature</b>	-20 to + 55° C
<b>Constant A-weighted sound pressure</b>	< 70 dB
<b>Dimensions</b> l x w x h	470 x 479 x 472 mm
<b>Weight</b>	30 kg
<b>Enclosure class</b>	IP 23
<b>Application class</b>	S

<b>Cooling unit</b>	
<b>Cooling power</b> at 50 Hz at 60 Hz	670 W at 40° C temp. difference and flow 1.0 l/min 650 W at 40° C temp. difference and flow 1.0 l/min
<b>Type of cooling</b>	50 % water / 50% monoethylene glycol
<b>Coolant quantity</b>	2.0 l
<b>Maximum water flow</b> at 50 Hz at 60 Hz	1.22 l/min 1.44 l/min
<b>Maximum water pressure</b> at 50 Hz at 60 Hz	0.32 MPa (3.2 bar) 0.42 MPa (4.2 bar)

### **Mains supply, Z<sub>max</sub>**

Maximum permissible line impedance of the network in accordance with IEC 61000-3-11.

### **Duty cycle**

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40° C.

The duty cycle is valid for 40° C.

### **Enclosure class**


The IP code indicates the enclosure class, i. e. the degree of protection against penetration by solid objects or water. Equipment marked **IP23** is designed for indoor and outdoor use.

### **Application class**

The symbol S indicates that the power source is designed for use in areas with increased electrical hazard.

## 5 INSTALLATION

*The installation must be executed by a professional.*




### Note

#### Mains supply requirements

High power equipment may, due to the primary current drawn from the mains supply, influence the power quality of the grid. Therefore connection restrictions or requirements regarding the maximum permissible mains impedance or the required minimum supply capacity at the interface point to the public grid may apply for some types of equipment (see technical data). In this case it is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment may be connected.

### 5.1 Lifting instructions



### 5.2 Location

Position the welding power source such that its cooling air inlets and outlets are not obstructed.

### 5.3 Mains power supply

Make sure that the welding power source is connected to the correct supply voltage and that it is protected by the correct fuse rating. A protective earth connection must be made in accordance with regulations.


#### Recommended fuse sizes and minimum cable area

MechTig C2002i	
<b>Mains voltage</b>	230 V 1 ~ 50/60 Hz
<b>Mains cable area</b>	3 G 2.5 mm <sup>2</sup>
<b>Phase current I RMS</b>	12 A
<b>Fuse</b>	
anti-surge	16 A
type C MCB	16 A
<b>Welding cable area</b>	50 mm <sup>2</sup>

**NOTE!** The mains cable areas and fuse sizes as shown above are in accordance with Swedish regulations. Use the welding power source in accordance with the relevant national regulations.

## 5.4 Connecting the terminating resistor

To avoid communication interference, the remote socket must be fitted with a terminating resistor, when a remote control unit is not connected.




## 6 OPERATION

**General safety regulations for the handling of the equipment can be found on page 3. Read through before you start using the equipment!**

### 6.1 Connections and control devices

- 1 Connection for start gas in
- 2 Connection for weld gas in
- 3 Connection for root gas in
- 4 Switch for mains power
- 5 Rating plate for connection data
- 6 Control panel, see separate instruction manual
- 7 Gas flow meter
- 8 Printer
- 9 USB connection, see point 6.3.
- 10 Connection for documentation system WMS 4000
- 11 Connection (CAN) for remote control unit, terminating resistor or welding station A25
- 12 Connection for wire feed
- 13 Root gas connection out
- 14 Weld and start gas connection out
- 15 Connection for rotation
- 16 Connection for coolant from tube welding tool RED
- 17 Connection with ELP\* for coolant to the tube welding tool BLUE
- 18 Topping up with coolant
- 19 Connection for welding current (-)
- 20 Connection for manual TIG torch
- 21 Return cable connection (+)



\*ELP = ESAB Logic Pump, see point 6.4.



## **6.2 Gas flow meter**

NOTE! To achieve the correct flow, the flow must be measured at the tool.

The flow meter is calibrated for Argon gas at 4 bar pressure. The gas flow obtained from the tool can vary depending on the connected tool. If other pressures or gases are used, the gas flow must be measured at the workpiece.

ESAB recommends that a pressure regulator set for 4 bar is used.

## **6.3 USB connection**

The external USB memory can be used to transfer programs to and from systems.

### **Note!**

During normal use there is no risk of "viruses" "infecting" equipment. To eliminate the risk entirely, we recommend that the memory, which is used together with this equipment, not be used for any other purpose other than its intended.

Certain USB memories may not work with this equipment. We recommend using USB memories from a reputable supplier.

ESAB assumes no responsibility for any damage caused as a consequence of incorrect use of the USB memory.

## **6.4 Water connection**

The power source is equipped with a detection system **ELP (ESAB Logic Pump)** which checks that the water hoses are connected. When connecting a water-cooled tube welding tool, the water pump starts.

## **6.5 Overheating protection**

The welding power source has overheating protection that operates if the temperature becomes too high. When this occurs, the welding current is interrupted and a red flashing field with the text "OVERHEAT" appears in the lower right-hand corner of the control panel.

When the temperature drops, the overheat protection is automatically reset and the field stops flashing red.

For further information see the control panel user manual.

## **6.6 Flow guard, water**

The water flow guard blocks the power source if the coolant stops (minimum water flow 0.7 l/min). When this occurs the welding current is interrupted and an error message is shown on the control panel.










For further information see the control panel user manual.

## **6.7 Flow guard, gas**

The flow guard stops the welding process if the gas flow falls below 4 l/min. When this occurs an error message appears on the control panel.

For further information see the control panel user manual.

## 6.8 Symbol explanations

	TIG-torch		Start and weld gas out
	Tube welding tool		Root gas out
	Rotation		Root gas in
	Wire feed		Weld gas in
			Start gas in

For detailed description of the function see instruction manual for the control panel.

## 7 MAINTENANCE

*Regular maintenance is important for safe, reliable operation.*

*Only those persons who have appropriate electrical knowledge (authorized personnel) may remove the safety plates.*



### CAUTION

*All guarantee undertakings from the supplier cease to apply if the customer himself attempts any work in the product during the guarantee period in order to rectify any faults.*

### 7.1 Inspection and cleaning

#### Power source

Check regularly that the welding power source is not clogged with dirt.

How often and which cleaning methods apply depend on:

- welding process
- arc time
- placement
- surrounding environment.

It is normally sufficient to blow down the power source with dry compressed air (reduced pressure) once a year.

Clogged or blocked air inlets and outlets can cause overheating.


### Tube welding tool

The tube welding tool's wear parts should be cleaned and replaced at regular intervals in order to achieve trouble-free welding.

## 7.2 Topping up the coolant

Top up with coolant to the level of the filling hole.

ESAB's refrigerant is recommended for use. See accessories on page 21.



### CAUTION


*The coolant must be handled as chemical waste.*

## 7.3 Printer


### Changing the paper roll

To change the paper roll, proceed as described below:

1. Open the printer cover as shown in the figure.
2. Position the paper roll making sure it unrolls in the proper direction as shown in the figure.




*Opening the printer cover*




*Positioning the paper roll*

3. Pull out the paper and close the cover, as shown in the figure.
4. The printer is ready to print.



*Closing the printer cover*



*Ready to print*

## **8 FAULT-TRACING**

*Try these recommended checks and inspections before sending for an authorised service technician.*

<b>Type of fault</b>	<b>Corrective action</b>
No arc.	<ul style="list-style-type: none"> <li>• Check that the mains power supply switch is turned on.</li> <li>• Check that the welding current supply and return cables are correctly connected.</li> <li>• Check that the correct current value is set.</li> <li>• Check the coolant flow.</li> <li>• Check the coolant level.</li> </ul>
The welding current is interrupted during welding.	<ul style="list-style-type: none"> <li>• Check whether the overheating protection has operated (fault code 6 2 is displayed on the control panel).</li> <li>• Check the coolant flow.</li> <li>• Check the mains power supply fuses.</li> </ul>
The overheating protection trips frequently.	<ul style="list-style-type: none"> <li>• Make sure that you are not exceeding the rated data for the welding power source (i.e. that the unit is not being overloaded).</li> </ul>
Poor welding performance.	<ul style="list-style-type: none"> <li>• Check that the welding current supply and return cables are correctly connected.</li> <li>• Check that the correct current value is set.</li> <li>• Check that the correct electrodes are being used.</li> <li>• Check the mains power supply fuses.</li> <li>• Check that the correct welding gas is being used.</li> </ul>


## **9 ORDERING SPARE PARTS**


**MechTig C2002i is designed and tested in accordance with the international and European standards 60974-1, 60974-2, 60974-3 and 60974-10 . It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.**

Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.




# Diagram







WMS/SPS


USB








# Pump data



**P** = Pump pressure  
**Q** = Flow rate


# Cooling characteristic



**P** = Power  
**tö** = Flow rate

## MechTig C2002i




### Ordering number



Ordering no.	Denomination	Type
0444 700 880	Welding power source	Aristo™ MechTig C2002i, WO100
0459 839 009	Spare parts list	Aristo™ MechTig C2002i, WO100
0444 536	Instruction manual	Control panel WO100

Instruction manuals and the spare parts list are available on the Internet at [www.esab.com](http://www.esab.com)


**Accessories**

	<b>Thermal paper</b> ..... 0444 529 002
	<b>Coolant</b> (ready mixed) 50 % water and 50% monoethylene glycol (10 l) ... 0007 810 012
	<b>Carriage</b> ..... 0301 100 880


## MechTig C2002i

Product	Ordering number
<b>Tube welding tool PRB</b>	
17-49 watercooled .....	0443 750 882
33-90 watercooled .....	0443 760 882
60-170 watercooled .....	0443 770 882
17-49 aircooled .....	0443 750 883
33-90 aircooled .....	0443 760 883
60-170 aircooled .....	0443 770 883
<b>Tube welding tool PRD</b>	
160 (for meltwelding with floating head) .....	0444 151 880
160 with wire feeder .....	0444 151 881
<b>Tube welding tool PRH</b>	
3-12 enclosed .....	0444 300 880
3-38 enclosed .....	0444 301 880
6-76 enclosed .....	0444 302 880
<b>Tube welding tool POC 12-60 with wire feed unit</b> .....	0443 930 880
<b>TIG hand torch TXH 400W (4 m OKC)</b> .....	0460 014 840
<b>Wire feed unit MEI 10</b>	
for PRB 17-49 .....	0444 211 880
for PRB 33-90 .....	0444 212 880
for PRB 60-170 .....	0444 213 880
<b>Wire feed unit MEI 21</b> .....	0443 830 880
<b>Remote control unit MechT1 CAN</b> .....	0460 181 880
⑤ <b>Remote cable CAN 4 pole - 12 pole,</b>	
5 m .....	0459 554 880
10 m .....	0459 554 881
15 m .....	0459 554 882
25 m .....	0459 554 883
0.25 m .....	0459 554 884
<b>Documentation system</b>	
Welldoc™ WMS 40000 .....	0457 410 880
SPS 4000 .....	0457 410 881
Opto cable, 15 m .....	0457 072 881
Opto cable, 2 m .....	0457 072 882
<b>Return cable 4,5 m, 25 mm<sup>2</sup></b> .....	0156 743 909
<b>Extension cable</b>	
① for wire feed unit and CAN 42 V, 10 m .....	0456 904 880
② for rotation, 10 m .....	0456 906 880
<b>Extension set</b>	
③ for current, water and gas, 8 m .....	0456 905 880
④ for current, water, gas and torch contact, 8 m .....	0466 705 881


# MechTig C2002i




PRB, PRD, PRH  
F H G E D




MEI  
G




TXH  
H G E D J




POC  
H G E D C F




F




H G E D





G




H G E D




H G E D C F




K



SPS, WMS  
M



AH 0827A  
L



M

# ESAB subsidiaries and representative offices

## Europe

### AUSTRIA

ESAB Ges.m.b.H  
Vienna-Liesing  
Tel: +43 1 888 25 11  
Fax: +43 1 888 25 11 85

### BELGIUM

S.A. ESAB N.V.  
Brussels  
Tel: +32 2 745 11 00  
Fax: +32 2 745 11 28

### BULGARIA

ESAB Kft Representative Office  
Sofia  
Tel/Fax: +359 2 974 42 88

### THE CZECH REPUBLIC

ESAB VAMBERK s.r.o.  
Vamberk  
Tel: +420 2 819 40 885  
Fax: +420 2 819 40 120

### DENMARK

Aktieselskabet ESAB  
Herlev  
Tel: +45 36 30 01 11  
Fax: +45 36 30 40 03

### FINLAND

ESAB Oy  
Helsinki  
Tel: +358 9 547 761  
Fax: +358 9 547 77 71

### FRANCE

ESAB France S.A.  
Cergy Pontoise  
Tel: +33 1 30 75 55 00  
Fax: +33 1 30 75 55 24

### GERMANY

ESAB GmbH  
Solingen  
Tel: +49 212 298 0  
Fax: +49 212 298 218

### GREAT BRITAIN

ESAB Group (UK) Ltd  
Waltham Cross  
Tel: +44 1992 76 85 15  
Fax: +44 1992 71 58 03

### ESAB Automation Ltd

Andover  
Tel: +44 1264 33 22 33  
Fax: +44 1264 33 20 74

### HUNGARY

ESAB Kft  
Budapest  
Tel: +36 1 20 44 182  
Fax: +36 1 20 44 186

### ITALY

ESAB Saldatura S.p.A.  
Mesero (Mi)  
Tel: +39 02 97 96 81  
Fax: +39 02 97 28 91 81

### THE NETHERLANDS

ESAB Nederland B.V.  
Amersfoort  
Tel: +31 33 422 35 55  
Fax: +31 33 422 35 44

## NORWAY

AS ESAB  
Larvik  
Tel: +47 33 12 10 00  
Fax: +47 33 11 52 03

## POLAND

ESAB Sp.zo.o.  
Katowice  
Tel: +48 32 351 11 00  
Fax: +48 32 351 11 20

## PORTUGAL

ESAB Lda  
Lisbon  
Tel: +351 8 310 960  
Fax: +351 1 859 1277

## ROMANIA

ESAB Romania Trading SRL  
Bucharest  
Tel: +40 316 900 600  
Fax: +40 316 900 601

## RUSSIA

LLC ESAB  
Moscow  
Tel: +7 (495) 663 20 08  
Fax: +7 (495) 663 20 09

## SLOVAKIA

ESAB Slovakia s.r.o.  
Bratislava  
Tel: +421 7 44 88 24 26  
Fax: +421 7 44 88 87 41

## SPAIN

ESAB Ibérica S.A.  
Alcalá de Henares (MADRID)  
Tel: +34 91 878 3600  
Fax: +34 91 802 3461

## SWEDEN

ESAB Sverige AB  
Gothenburg  
Tel: +46 31 50 95 00  
Fax: +46 31 50 92 22

## ESAB international AB

Gothenburg  
Tel: +46 31 50 90 00  
Fax: +46 31 50 93 60

## SWITZERLAND

ESAB AG  
Dietikon  
Tel: +41 1 741 25 25  
Fax: +41 1 740 30 55

## UKRAINE

ESAB Ukraine LLC  
Kiev  
Tel: +38 (044) 501 23 24  
Fax: +38 (044) 575 21 88

## North and South America

### ARGENTINA

CONARCO  
Buenos Aires  
Tel: +54 11 4 753 4039  
Fax: +54 11 4 753 6313

### BRAZIL

ESAB S.A.  
Contagem-MG  
Tel: +55 31 2191 4333  
Fax: +55 31 2191 4440

### CANADA

ESAB Group Canada Inc.  
Mississauga, Ontario  
Tel: +1 905 670 02 20  
Fax: +1 905 670 48 79

### MEXICO

ESAB Mexico S.A.  
Monterrey  
Tel: +52 8 350 5959  
Fax: +52 8 350 7554

### USA

ESAB Welding & Cutting Products  
Florence, SC  
Tel: +1 843 669 44 11  
Fax: +1 843 664 57 48

## Asia/Pacific

### CHINA

Shanghai ESAB A/P  
Shanghai  
Tel: +86 21 2326 3000  
Fax: +86 21 6566 6622

### INDIA

ESAB India Ltd  
Calcutta  
Tel: +91 33 478 45 17  
Fax: +91 33 468 18 80

### INDONESIA

P.T. ESABindo Pratama  
Jakarta  
Tel: +62 21 460 0188  
Fax: +62 21 461 2929

### JAPAN

ESAB Japan  
Tokyo  
Tel: +81 45 670 7073  
Fax: +81 45 670 7001

### MALAYSIA

ESAB (Malaysia) Snd Bhd  
USJ  
Tel: +603 8023 7835  
Fax: +603 8023 0225

### SINGAPORE

ESAB Asia/Pacific Pte Ltd  
Singapore  
Tel: +65 6861 43 22  
Fax: +65 6861 31 95

## SOUTH KOREA

ESAB SeAH Corporation  
Kyungnam  
Tel: +82 55 269 8170  
Fax: +82 55 289 8864

## UNITED ARAB EMIRATES

ESAB Middle East FZE  
Dubai  
Tel: +971 4 887 21 11  
Fax: +971 4 887 22 63

## Africa

### EGYPT

ESAB Egypt  
Dokki-Cairo  
Tel: +20 2 390 96 69  
Fax: +20 2 393 32 13

### SOUTH AFRICA

ESAB Africa Welding & Cutting Ltd  
Durbanville 7570 - Cape Town  
Tel: +27 (0)21 975 8924

## Distributors

*For addresses and phone numbers to our distributors in other countries, please visit our home page*

[www.esab.com](http://www.esab.com)



ESAB AB  
SE-695 81 LAXA  
SWEDEN  
Phone +46 584 81 000



[www.esab.com](http://www.esab.com)