


# ***NETWORK CAMERA***

## ***User's Manual***

---



ZS10-0000002G 875 A.5

# Table of Content

1. Notice of Use .....	2
2. Product Overview .....	3
2.1 Camera Parts and Definition .....	4
2.2 Specification .....	5
3. Camera Installation.....	6
3.1 Installation .....	6
3.1.1 Drill the Mounting Location.....	8
3.1.2 Positioning the Camera.....	8
3.1.3 Attaching the Camera to a Surface.....	9
3.1.4 Adjusting Camera Focus.....	9
3.1.5 Using "SmartFocus" to Adjust Focus Smartly .....	9
3.2 Network Camera Diagram.....	9
3.3 Hardware/Software Requirement.....	10
3.4 Connecting the Camera to a Personal Computer .....	12
3.4.1 Setting IP.....	10
3.4.2 Connect the camera to personal computer.....	10
3.5 Using "IPFinder" to Search Camera's IP Address.....	14
4. Live View .....	15
4.1 Video Format.....	15
4.2 Snapshot .....	15
4.3 Recording LED .....	15
5. Camera Settings.....	16
5.1 Image Settings .....	17
5.1.1 Image .....	17
5.1.2 Image Advanced Settings.....	19
5.2 Network .....	20
5.2.1 Network Basic .....	22
5.2.2 FTP .....	23
5.2.3 SMTP .....	22
5.2.4 NTP .....	24
5.3 System.....	23
5.3.1 DateTime.....	23
5.3.2 Time Stamp.....	24
5.3.3 User.....	25
5.3.4 Audio .....	25
5.3.5 Update.....	26
5.3.6 Information .....	26
5.4 Application .....	27
5.4.1 Setting .....	30
5.4.1.1 Video File .....	28
5.4.1.2 FTP .....	29
5.4.1.3 SMTP .....	31
5.4.2 Schedule .....	30
5.4.2.1 Record Type.....	30
5.4.2.2 Period Setting.....	32
5.4.3 Alarm.....	31
5.4.3.1 Event .....	31
5.4.3.2 Action .....	32
6. Reset Camera.....	35
6.1 Software Reset.....	35
6.2 Hardware Reset .....	35

# 1. Notice of Use

---

- ◆ This manual is designed for administrators and users of the network camera. Read it carefully before using the camera. Follow all requirements to ensure proper camera use.
- ◆ We are not responsible for any technical or typographical errors and reserve the right to change the product and manuals without notice.
- ◆ Keep this document for future reference.
- ◆ Please make sure the power source is 12V DC/24V AC. Only connect the camera to this required power system.
- ◆ The camera must be installed on a solid mounting surface.
- ◆ Keep the camera and accessories dry.
- ◆ We are not responsible for any damage caused by inappropriate use.

## 2. Product Overview

---

### Key Features

- **Exceptional Images**

This camera employs a 5MP Lumii sensor that quadruples sensitivity without blurring. The camera utilizes Lumii technology to monitor the surveillance area in great detail in even the most difficult lighting conditions. It delivers crisp and detailed images that are perfect for object- and person-recognition. The camera's high resolution also enables it to provide larger overviews, increasing the size of the surveillance area without affecting image resolution.

- **Smartfocus**

A built-in nine-point focus indicator enables the camera to focus precisely and automatically on objects, relieving users of the need to adjust the focus manually.

- **Powerful IR Illuminator**

The powerful IR illuminator lights objects evenly, reducing image noise and storage requirements. The IR illuminator activates automatically when the lighting dims to under 10 lux. In night mode, the illuminator enables the camera to capture images at even 0 lux. To help minimize energy usage, the camera also comes equipped with a high-power LED.

- **ICR Day/Night Switching**

This camera incorporates a mechanical ICR filter to capture perfect pictures at any light level. The camera switches between its day and night modes automatically depending on the lighting conditions, enabling it to capture color video in even 0.3-lux conditions and black/white video in as little as 0 lux, ensuring crisp, clear images at all times. The camera's megapixel resolution and mechanical ICR filter deliver sharp, detailed captures and images of distant objects in even total darkness.


- **Housing Certified to IP66 and IP67**

Certified to IP66 and IP67, the die-cast aluminum alloy housing protects the camera against extremely bad weather, making it perfect for outdoor surveillance.

- **Easy Installation**


The cable-management bracket enables easy installation in any location, including walls, surfaces, and ceilings. The camera's built-in user-friendly I/O connectors also help reduce installation time and maintenance costs.

### Camera Overview



## 2.1 Camera Parts and Definition

---



- 1. Rain guard/extendable sunshield:** minimize the effects of rain and sunlight on image quality.
- 2. Pipe Segment:** easy to mount at different angles.
- 3. Mounting Bracket:** attach to a surface
- 4. Power In (Red+/Black-):** power connector, DC12V/AC24V.
- 5. RJ-45 Ethernet Connector:** network connection. Support PoE (Power over Ethernet).
- 6. BNC:** video output
- 7. Audio Out (Green):** audio output
- 8. Audio In (Red):** audio input
- 9. Alarm Out (Orange):** alarm signal output port.  
**RS485+(Green):** function reserved  
**RS485- (Yellow):** function reserved
- 10. GND:** ground (electricity) in electrical circuits.  
**Alarm In (Red):** alarm signal input port.  
**Alarm Reset (Brown):** for resetting an external alarm device.

## 2.2 Specification

Image System	
Image sensor	1/2.5" 5 MP Lumii image sensor optimized for low-light performance
Effective pixels	2592 (H) X 1944 (V)
Image Compression Method	Triple Streaming : MPEG4 x2/ Motion JPEG x1
Resolution/ Frame rate	MPEG4: HD 720P 1280 X 720 @30fps, 640 X480@30fps, 352 X192@30fps MJPEG: 640 X 480@30fps, 640 X 352@30fps
Electric	
Sync system	Internal
Built-in lens	f=3.3 ~ 12 mm, F1.6, Varifocal Megapixel lens IR-corrected, Angle of view: 22° ~ 76° (Horizontal)
Shutter time	AES 1/10000 to 1/3.75 sec
Audio	Two-way Mono Audio, Full-duplex, G.711 PCM 8kHz 64kbit/s
Alarm	Yes; 1x Alarm-in, 1x Alarm-out
Motion detection	Yes; 4 x 3 MD window & 5 level sensitivity
Day & Night Mode	Mechanical ICR Filter
Minimum illumination	IR LED OFF: 0.3lux (F1.2, 50 IRE) IR LED ON: 0lux
IR LED	IR LED 24pcs(850nm)
IR distance	25 meters (82 ft.)
IR turn on status	Under 10 lux by auto control
LED life	More than 10,000 hours (50°C)
TV output	NTSC, 720 X 480 @30fps   PAL, 720 X 576 @25fps
Feature	
BLC	ON/Off
White Balance	Auto/Daylight/Fluorescent/Incandescent
Sharpness	Low/ Middle/High
Saturation	Low/ Middle/High
Brightness	Low/ Middle/High
Contrast	Low/ Middle/High
Other	Mirror, Flip, system log, snapshot
Power supply	
Power requirement	DC12V/ AC24V/ PoE(IEEE 802.3af)
Power consumption	< 8W
Power connector	Screwless Terminal block
Environment	
Operating temperature	-10°C ~ 50°C (14°F ~ 122 °F)
Operating humidity	10~ 90% RH
Storage temperature	-20°C ~ 60°C (-4°F ~ 140 °F)
Network	
Ethernet	10Base-T/100Base-TX
Internet protocol	TCP/IP, UDP, HTTP, SMTP, DNS, DHCP, NTP, FTP, RTP,RTSP, ICMP, uPNP
Connectors	RJ-45 Ethernet 10Base-T/100Base-TX
Browser	IE browser 6.0 or above
I/O connector	
Video port	BNC X1, 1.0Vp-p, 75Ω
Alarm port	Terminal block
Audio port	3.5mm Phone Jack
Mechanism	
Dimensions(LxWxH)	300 x 88 x 86 mm (11.79" x 3.47" x 3.39")
Weight	0.995 kg (2.2 lb.)
Protection Class	IP66 and IP67

## 3. Camera Installation

---

Use the appropriate brackets and equipment to mount this camera. After installing the camera, your network camera should be accessed from your local network. Configure network routers first.

### Package Contents:

Camera *1	Rubber Pad *1
Insulation caps *3	Guide Pattern Sticker *1
Self-tapping screws *3	Plastic anchor *3
Cable adaptor * 1	Power connector * 1
Printed Quick Start Guide *1	Document CD *1

## 3.1 Installation

---

This section details how to set up the camera.

### 3.1.1 Drill the Mounting Location

---


1. Place the “guide pattern sticker” on the desired mounting location.
2. Drill the marked holes

### 3.1.2 Positioning the Camera

---

Listed below are different ways to adjust the camera position to capture the desired field of vision.

1. Loosen the screw (a.) to rotate either the camera or “pipe segment”. Select the desired position then tighten the screw to set the position.
2. Loosen the screws on both sides (b.) to change the mounting bracket angle. Move the camera into the desired position. Tighten the screws to set the position.




### 3.1.3 Attaching the Camera to a Surface

---

1. Place the “rubber pad” inside the mounting bracket.
2. Place the 3 “insulation caps” onto the “self tapping screws”.
3. Position the mounting bracket to the desired mounting location.
4. Screw the camera into the holes.
  - For cement surfaces, insert the “plastic anchors” into the holes. Align the holes in the mounting bracket. Then use the “self tapping screws” to screw the camera into the holes.
  - For any other surfaces, align the holes in the mounting bracket. Then use the “self tapping screws” to screw the camera into the holes.

The mounting bracket can be loosened for easier cable installation. Loosen the screw (c.) on both sides to rotate the mounting bracket and adjust the cable.




### 3.1.4 Adjusting Camera Focus

---


Note: This camera can be focused using a service monitor. Attach the service monitor to the BNC Cable. If no monitor is available then focus must be performed by using an internet browser to view the camera images.

1. Loosen the two screws on top of the sunshield and remove the sunshield.






2. Rotate camera cover counter clockwise to expose the lens.



3. Loosen the zoom adjust lever screw and focus adjust lever screw. Set the desired field of view then tighten the zoom adjust lever screw and focus adjust lever screw.



Note: Two desiccant packs are already placed near the lens. The desiccant pack prevents fogging on the inside of the lens due to any moisture. Make adjustments within 30 minutes or the desiccant pack may absorb too much moisture and become ineffective.

Desiccant packs that have absorbed too much moisture need to be replaced or reactivated.


When lens adjustments are complete, reattach the camera cover and sunshield.

### 3.1.5 Using “SmartFocus” to Adjust Focus Smartly

---

This network box camera provides “SmartFocus” to obtain correct focus on a subject, instead of requiring users to adjust focus manually. 9 view zones are provided. When you obtain correct focus on each view zone, the green light will be turned on.


1. Directly connect the video output cable to your monitor.
2. Press the reset button until the power is on.
3. The nine zones will appear in your monitor. Adjust the lens focus and symbols will be displayed on the top left corner of each zone.
  - ◆ The green light: it means each view zone’s best focus position.
  - ◆ The red arrow: it means it is near the best focus position. You just need to fine-tune it.




### 3.2 Network Camera Diagram

---

- ◆ Connection type:1



- ◆ Connection type 2:



### 3.3 Hardware/Software Requirement

---

- ◆ **Computer**

- Windows Vista or XP as OS
- Internet Explorer Version 6.0 or later
- CPU: Intel Pentium 4.2 GHz or higher
- Memory: 512 MB or more
- VGA card--support Direct X 9.0 or above

- ◆ **Power Supply**

The camera requires a DC12V/AC24V/PoE power supply. Make sure you use the correct power supply before connecting to this network camera.

Use a RJ45 network connector to connect the camera to your computer or hub switch.

- ◆ **Hub Switch**

A Hub Switch is required to monitor two or more cameras from the same computer.

### 3.4 Connecting the Camera to a Personal Computer

---

This section details how to access the camera from a computer.

#### 3.4.1 Setting IP

---

This is a network-based camera and must be assigned an IP address first.


- ◆ Enter a default IP address manually. The camera's default IP address is 192.168.1.30 and submask address is 255.255.255.0.
- ◆ Obtain an IP address automatically from the DHCP server. You don't need to change the camera's IP address if your network uses a DHCP server.

#### 3.4.2 Connect the Camera to a Personal Computer

---

1. Connect the network cable to the camera and then turn on the camera's power.
2. Set the personal computer's IP address. The camera's default IP address: 192.168.1.30 and submask is 255.255.255.0.
3. Check that the camera and computer are connected by pinging the IP address you have set. To do this, start a command prompt and type the IP address you set. If the message "Reply from..." appears, it means the connection is done.
4. Start Internet Explorer and enter the set IP address (default is http://192.168.1.30). A login window will appear. Enter the default user name: admin and password: 1234 to login .
5. Install ActiveX viewer. It is required to monitor both MPEG4 and Motion-JPEG video modes.

6. Images of the camera can be viewed through Internet Explorer. Before viewing, follow these steps to enable the display.
  - a. Enable Cookies as shown below:
    - In Internet Explorer, click **Internet Options** on the **Tools** menu.
    - On the **Privacy** tab, move the settings slider to **Low** or **Accept All Cookies**.
    - Click **OK**.
  - b. Set "Browser setting when proxy sever is used" when a proxy server is used.
  - c. Change "security" in Internet options as shown below:
    - On tool menu, click "Internet Option".
    - Press the Security tab.
    - If the camera operates inside the intranet, click the "Intranet" icon. If the camera operates on the Internet, click the "Internet" icon.
    - Click "Custom level". This will open the "Security Settings – Internet Zone" screen.
    - Scroll down to the "ActiveX controls and plug-ins" radio buttons and enable all of them as shown in the illustrations:




- Press OK to save the settings. Close all Internet Explorer Windows and start a new window. This will allow the new settings to take effect.
7. Type your set IP address into the browser.
  8. Then you should be able to see the camera image screen as follows:




### 3.5 Using “IPFinder” to Search Camera’s IP Address

“IPFinder” is a program which helps users find network cameras. Please note that “IPFinder” is only compatible with Windows Vista and Windows XP.


1. Insert the CD in the CD-ROM drive.
2. Double click “IPFinder.msi” to run the program. Follow the instructions to install.
3. After successfully installing “IPFinder”, double click the “IPFinder” icon which is displayed in your desktop. A “IPFinder” window will pop out. The window will display a list of net cameras which you are using currently.




4. Click “Tool” on the tool bar to set related functions. Press “Search Network” to search cameras. Press “Set Master ID and Password” to set a master ID and password for all cameras. Or click “Management Tool” to either restart the camera, update firmware, reset all of the camera settings to default (except network settings) or reset all of the camera parameters to default.



5. After searching cameras, choose one to view detailed information. The top right frame of the “IPFinder” window will display the camera’s monitor section and the bottom right frame of “IPFinder” will display the camera’s IP address and related information.



6. Right click a camera to set its related functions. Press "Go to Presentation URL" to access the camera which you want to login. Press "Set Device ID and Password" to set the camera's login ID and password. Click "Network Information" to configure the camera's network settings. Or Press "Management Tool" to either restart the camera, update firmware, reset all of the camera settings to default (except network settings) or reset all of the camera parameter to default.



## 4. Live View

---



Live view is designed for general users to control the camera. " Video Format", "Snapshot", "Recording LED", "Live" and "Setup" functions are listed on the live view. Please note, only administrators can access "Setup" to configure camera settings.

### 4.1 Video Format

---

Select a resolution type for live view. .

### 4.2 Snapshot

---

The "Snapshot" function is for snapshot capture. Press the "Snapshot" button to take a picture which will be automatically saved into an automatically created IPCAM folder on your computer.

### 4.3 Recording LED

---

The recording LED becomes red when the alarm/event function is triggered.



## 5. Camera settings

**Mega IP Cam** Live|Setup

- **Image**
  - Image
  - Advanced
- **Network**
- **System**
- **Application**

**Image:**

Live

**Basic Setting**

Camera Name: Mega IP Cam

Video Codec: MPEG4\_1+MJPEG

Resolution: 1280x720,640x352

TV System:  NTSC  PAL

Mirror: OFF

Flip: OFF

**MJPEG Setting**

Quality: Best

**MPEG-4\_1 Setting**

Bit Rate: 4000 (kbit/s) (min=500, max=10000)

Frame Rate: 30

**MPEG-4\_2 Setting**

Bit Rate: 2000 (kbit/s) (min=500, max=10000)

Frame Rate: N/A

Save

Click on "Setup" to configure camera settings. On the left is a navigation bar with 5 setting categories. "Image Settings", "Network Settings", "System Settings", and "Application Settings" are provided for administrators to set up the camera's functionalities.

## 5.1 Image Settings



“Image” is used to change any picture setting on the camera. Remember to click “Save” to keep your settings.

### 5.1.1 Image

Basic Setting	
Camera Name:	Mega IP Cam
Video Codec:	MPEG4_1+MPEG4_2+MJPEG
Resolution:	1280x720,352x192,640x352
TV System:	<input checked="" type="radio"/> NTSC <input type="radio"/> PAL
Mirror	OFF
Flip	OFF

#### -Basic Setting

Every parameter of “Basic Setting” affects the displayed image. Specify appropriate parameters in the following section.

- Camera Name: enter a desired network camera name. The name will be displayed at the top of the Live page.
- Video Codec: Choose a compression mode to be displayed in “Live View”. Compression choices include "MPEG4\_1+MPEG4\_2+MJPEG", "MPEG4\_1+MJPEG", "MPEG4\_1+MPEG4\_2", and "Single MPEG4\_1".
  - MPEG4\_1 is for high-resolution live view/compression mode.

- MPEG4\_2 is for low-resolution live view/compression mode.
- MJPEG is for middle-resolution live view/compression mode.
- Resolution: "Resolution" and "Video Codec" are dependent fields.
  - If "MPEG4\_1+MPEG4\_2+MJPEG" is selected, "1280x720, 352x192, 640x352" can be set.
  - If "MPEG4\_1+MJPEG" is selected, "640x480, 640x480" or "1280x720, 640x352" can be set.
  - If "MPEG4\_1+MJPEG\_2" is selected, "1280x720, 352x192" can be set.
  - If "Single MPEG4\_1" is selected, "1280x720" can be set.

\*Note: the corresponding fields are listed below.

Video Codec Field	Resolution	Live View/Compression Selections
MPEG4_1+MPEG4_2+MJPEG	1280x720, 352x192, 640x352	MJPEG (640x352) MPEG4_1 (1280x720) MPEG4_2 (352x192)
MPEG4_1+MJPEG	640x480, 640x480	MJPEG (640x480) MPEG4_1 (640x480)
	1280x720, 640x352	MJPEG (640x352) MPEG4_1 (1280x720)
MPEG4_1+MJPEG_2	1280x720, 352x192	MPEG4_1 (1280x720) MPEG4_2 (352x192)
Single MPEG4_1	1280x720	MPEG4_1 (1280x720)

- TV System: "NTSC" and "PAL" are provided for different TV system settings.
- Mirror: set images as left or right. Select ON or OFF to enable or disable this function.
- Flip: set images upside down. Select ON or OFF to enable or disable this function.

**MJPEG Setting**

Quality:

#### -MJPEG Setting

- Quality: set the image's quality as "Basic", "Normal" or "Best".

**MPEG-4\_1 Setting**

Bit Rate:  (kbit/s) (min=500, max=10000)

Frame Rate:

#### -MPEG-4\_1 Setting

- Bit Rate: according to your bandwidth, specify a value for data transmission rate (kbit/s).
- Frame Rate: frame rate is the image transfer speed. 5 is 5 images transmission per second, 10 is 10 images transmission per second, etc. If "Auto" is selected, the camera will decide the image transfer speed automatically.

**MPEG-4\_2 Setting**

Bit Rate:  (kbit/s) (min=500, max=10000)

Frame Rate:

#### -MPEG-4\_2 Setting

The values contained in the frame rate field are displayed depending on the value you set in the video code field (please note that you have to press the save button to save the value you select)

in the video code field first and then the corresponding values contained in the frame rate field will be displayed for selection.) Here lists the corresponding values.

Video Codec Field	Frame Rate Field
MPEG4_1 + MPEG4_2+MJPEG	15, 7.5, 2.5
MPEG4_1+MJPEG	N/A
MPEG4_1+MPEG4_2	30, 15, 5
Single MPEG4_1	N/A

- Bit Rate: according to your bandwidth, specify a value for data transmission rate (kbit/s).
- Frame Rate: the frame rate is the image transfer speed. 15 is 15 images transmission per second, 7.5 is 7.5 images transmission per second...etc.

## 5.1.2 Image Advanced Settings



“White Balance”, “Day and Night”, “AES”, “Lumii”, “Working Environment”, “Lens Format”, “BLC”, “Brightness”, “Contrast”, “Saturation” and “Sharpness” are provided for you to set the quality of images. Please click the “Save” button to save your image settings.

### -Advanced settings

- White Balance: select a white balance mode according to external lighting condition for the best color temperature.
  - Auto: adjust the white balance automatically according to the environment conditions.

- Daylight: adjust the white balance if the external light source is daylight.
- Fluorescent: adjust the white balance if the external light source is fluorescent.
- Incandescent: adjust the white balance if the external light source is incandescent.
- Day and Night: This function detects changes in the level of light at any time of day, and then switches to the optimum surveillance mode according to the light level.
  - Auto : This mode is always on. The camera will change either to Color Mode or Black and White Mode depending on the light level.
- AES: automatic exposure values which determine how much light passes through the camera aperture to the focus. The higher the value, the brighter the images.
- Lumii: Lumii function increases the sensitivity, reduces video noise in low light conditions, as well as makes night images bright and clear. This function is always active.
  - ON: the Lumii function is always enabled.
- Working Environment:
  - Normal: the camera's color is automatically adjusted for outdoor environment.
  - Anti-Flicker: reduce color rolling for indoor environment.
- Lens Format: choose an appropriate lens matching with the lens size which you have installed.
- BLC (Backlight Compensation): this function adjusts the image to compensate for areas that are too dark due to insufficient light.
  - ON: enable the BLC function.
  - OFF: disable the BLC function.
- Brightness: adjust the image brightness level, to "Low", "Middle" or "High". The default is "Middle".
- Contrast: adjust the image contrast level, to "Low", "Middle" or "High". The default is "Middle".
- Saturation: adjust the image saturation level, to "Low", "Middle" or "High". The default is "Middle".
- Sharpness: adjust the image sharpness level, to "Low", "Middle" or "High". The default is "Middle".
- Default All Image parameters: All image parameters will be set back to default.

## 5.2 Network

The screenshot shows the 'Mega IP Cam' web interface. The title bar includes a camera icon, the text 'Mega IP Cam', and 'Live | Setup'. On the left, a sidebar lists menu items: Image, Network (highlighted), FTP, SMTP, NTP, System, and Application. The main area is titled 'Network' and contains a 'Basic' section with the following settings:

<input type="checkbox"/> DHCP	
IP Address:	192.168.254.127
Subnet Mask:	255.255.255.0
Default Gateway:	0.0.0.0
DNS:	0.0.0.0
HTTP Port:	80 (default:80, port range:1025~65534)

A 'Save' button is located at the bottom of the configuration area.

Click "Network" to view the current network settings, including "Network", "FTP", "SMTP" and "NTP". Configure all Network, FTP, SMTP and NTP settings in the Network section.

## 5.2.1 Network Basic

Network  
Basic

DHCP

IP Address: 192.168.254.127

Subnet Mask: 255.255.255.0

Default Gateway: 0.0.0.0

DNS: 0.0.0.0

HTTP Port: 80 (default:80, port range:1025~65534)

Save

### -Basic Setting

- DHCP: the IP address is automatically obtained when this is checked; otherwise, uncheck it to set up the network settings manually. If you enable the DHCP function, just specify DNS and HTTP Ports in the below fields.
- IP Address: specify your IP address here if you don't select DHCP.
- Subnet Mask: use default number: 255.255.255.0.
- Default Gateway: leave blank as default setting. It is not required if it is not used. Please contact your Network Administrator for Default Gateway information.
- DNS: leave blank as default setting. It is not required if it is not used. Please contact your Network Administrator for DNS information.
- HTTP Port: We recommend using the default path. Contact your Network Administrator if it needs to be changed.
- Press "Save" to save your settings.

### Network Error

Network  
Basic

DHCP

IP Address: 192.168.254.127

Subnet Mask: 255.255.255.0

Default Gateway: 0.0.0.0

DNS: 0.0.0.0

HTTP Port: 80 (default:80, port range:1025~65534)

Save

Microsoft Internet Explorer

# Error: <Over Range>, must be (1025..65534)

確定

Entering the wrong values can result in a network error.

## 5.2.2 FTP

---

FTP Server Setting		
FTP Server IP:	<input type="text" value="192.168.1.1"/>	Port: <input type="text" value="21"/>
User Name:	<input type="text"/>	
Password:	<input type="password"/>	
File Upload Path:	<input type="text" value="default_folder"/>	
<input type="button" value="Save"/>		
<b>Note:</b> FTP Server IP is the IP of the computer on which you installed and built the FTP server.		

### -FTP Server Setting

Enable the FTP function and configure FTP settings here.

- FTP Server/ Port: enter your FTP server address. The port default value is 21.
- User Name: input a user login name.
- Password: enter a user password.
- File Upload Path: enter a folder path where you'd like to upload files to.

## 5.2.3 SMTP

---

Mega IP Cam		Live Setup
<ul style="list-style-type: none"><li>• <b>Image</b></li><li>• <b>Network</b><ul style="list-style-type: none"><li>○ Network</li><li>○ FTP</li><li>○ <b>SMTP</b></li><li>○ NTP</li></ul></li><li>• <b>System</b></li><li>• <b>Application</b></li></ul>	<b>SMTP</b>	
	<b>SMTP Server setting</b>	
	<input type="checkbox"/> My Server Requires authorization.	
	SMTP Server IP:	<input type="text" value="192.168.1.1"/>
	User Name:	<input type="text"/>
	Password:	<input type="password"/>
	Sender:	<input type="text"/>
	Receiver:	<input type="text"/>
	<input type="button" value="Save"/>	

### -SMTP Server Setting

- My Server Requires authorization: Check it to enable the server authorization requirement setting.
- SMTP Server: enter the SMTP server address.
- User Name: enter a user name.
- Password: enter a user password.
- Sender: enter an outgoing mail server in the "E-mail Server (SMTP)" field.



- Receiver: enter an incoming mail server in the “E-mail Server (POP)” field.

## 5.2.4 NTP




The screenshot shows a web interface titled "NTP Server setting". It contains two input fields: "NTP Server:" with the value "tw.pool.ntp.org" and "Time Zone:" with a dropdown menu showing "GMT+08 Taipei, Beijing, Hong Kong". Below these fields is a "Save" button.

### -NTP Server Setting

- NTP Server: assign an IP address or domain name for a time server.
- Time Zone: select a correct time zone.


## 5.3 System



The screenshot shows the "Mega IP Cam" system setup interface. The "Date & Time" section is active. It displays "Current Time" as Date: 2010-3-5 and Time: 16:02:52. Under "New Time", there are three options: "Set Manually" (with Date: 2010-3-5 and Time: 16:2:34), "Synchronize with Computer Timer" (with Date: 2010-3-5 and Timer: 16:02:37), and "Synchronize with NTP Server" (with NTP Server: tw.pool.ntp.org and Time Zone: GMT+08 Taipei, Beijing, Hong Kong). The "Date Format" is set to "YYYY/MM/DD". A "Save" button is at the bottom.

In this section, you can configure the system settings, including “Date Time”, “Time Stamp”, “Users”, “Audio”, “Update” and “Information”. Please click the “Save” button to save your settings.

### 5.3.1 DateTime



The screenshot shows a "Current Time" section with two input fields: "Date:" with the value "2000-1-26" and "Time:" with the value "07:50:42".

### -Current Time



Display the current time on the camera. Date and time will be changed after you configure it in the “New Time” section.

**New Time**

Set Manually

Date: 2009 - 6 - 14

Time: 19 : 33 : 46

Synchronize with Computer Timer

Date: 2009-6-14 Timer: 19:33:48

Synchronize with NTP Server

NTP Server: tw.pool.ntp.org

Time Zone: GMT+08 Taipei, Beijing, Hong Kong

Date Format: YYYY/MM/DD

Save

### -New Time

You can set the camera time by “Set Manually”, “Synchronize with Computer Timer” and “Synchronize with NTP Server”. Then, select a date format type. “YYYY/MM/DD”, “MM/DD/YYYY” and “DD/MM/YYYY” are choices provided.

- ◆ Set Manually: set date and time manually.
- ◆ Synchronize with Computer Timer: synchronize your camera’s date and time with the computer’s timer.
- ◆ Synchronize with NTP Server: synchronize your camera’s date and time with the NTP server’s timer.

## 5.3.2 Time Stamp

---

**Time Stamp**

Enable Date and Time Stamp

Date Format: YYYY/MM/DD

Save

### - Time Stamp

Enable the “Enable Date and Time Stamp” function to display the current time on the “Live” page.

- Enable Date and Time Stamp: check “Enable Date and Time Stamp” to activate this function.
- Date Format: select a date format. “YYYY/MM/DD”, “MM/DD/YYYY” and “DD/MM/YYYY” are choices provided.

### 5.3.3 User

---




User List:

admin: [Admin]  
guest: [Viewer]

Delete User

#### - User List

Displays the list of users. Only two roles can be specified, administrator (admin) and guest (viewer). If you want to delete a user, select a user and then press the “Delete User” button.



Add/Modify User

User Name:

Password:

Confirm:

Authority:  Admin  Viewer

Add


#### - Add/Modify User

You can add a new user or modify a user’s information or authority.

- To add/modify a new user, enter a user name and password. Then, specify his/her role as Admin or Viewer.
- Press “Add” to add a user or to modify a user’s password or authority

### 5.3.4 Audio

---



Audio

Audio Recording  OFF  ON

Audio Playing  OFF  ON

Alarm level  (1~4)

- Audio Recording: if the camera is connected to an external microphone, select “ON” to record the external voice or “OFF” to disable the audio recording function.
- Audio Playing: if the camera is connected to an external speaker, select “ON” to output audio signals from the computer to outside.
- Alarm level: specify a value for voice volume in the “Alarm Level” field. The volume increase in the order of “1”, “2”, “3” and “4”. This function only works when the Audio Playing function is enabled.

### 5.3.5 Update

**Mega IP Cam** Live | Setup

**Update**

**Current Version Description**

Kernel Version:	Linux version 2.6.10_mvl401_IPNC-1.0.8.18MS
BIOS Version:x	U-Boot 1.2.0 (Apr 22 2009 - 13:35:36) IPNC-U-1.0.2.02M
App Version:	C076_00-02-07_MS
ActivX Version:	1,0,0,36

Upload the device with the latest firmwareSpecify the firmware to update:

瀏覽... Update

**Note: Do not disconnect the power of the device, during the update.**

!!Restart Camera will cause disconnect.

!!Reset all of the camera parameters to default except Network.

!!Reset all of the camera parameters to default.

Restart Camera

Factory Default

Hard factory default

**網頁訊息**

Please wait at least 60 sec for "Restart". DO NOT press any buttons or it may cause unexpected errors due to incomplete processes. Restart camera....Are you sure?

確定 取消

This function is designed to update firmware. Stop all camera operations when you update firmware. Do not turn off power or disconnect the internet connection during the firmware update process. Click "Restart Camera" after you have updated firmware successfully.

### 5.3.6 Information

**Mega IP Cam** Live | Setup

**Information**

#000	2010-03-05	16:04:05	admin login on	192.168.1.253
#001	2010-03-05	16:04:05	admin login on	192.168.1.253
#002	2010-03-05	16:03:36	admin login on	192.168.1.253
#003	2010-03-05	16:03:36	admin login on	192.168.1.253
#004	2010-03-05	16:03:16	admin login on	192.168.1.253
#005	2010-03-05	16:03:16	admin login on	192.168.1.253
#006	2010-03-05	16:02:49	admin login on	192.168.1.253
#007	2010-03-05	16:02:49	admin login on	192.168.1.253
#008	2010-03-05	16:02:37	admin login on	192.168.1.253
#009	2010-03-05	16:02:37	admin login on	192.168.1.253
#010	2010-03-05	15:51:56	admin login on	192.168.1.253
#011	2010-03-05	15:51:56	admin login on	192.168.1.253
#012	2010-03-05	15:51:36	admin login on	192.168.1.253
#013	2010-03-05	15:51:36	admin login on	192.168.1.253
#014	2010-03-05	15:50:50	admin login on	192.168.1.253
#015	2010-03-05	15:50:50	admin login on	192.168.1.253

It displays all login and alarm records.


## 5.4 Application



In this section, you can configure system settings, including “Setting” (Video File, FTP, and SMTP), “Schedule” (Record Type and Period Setting) and “Alarm” (Event and Action).




## 5.4.1 Setting



The screenshot shows the Mega IP Cam web interface. At the top, there is a camera icon, the title "Mega IP Cam", and a "Live | Setup" link. On the left side, there is a navigation menu with the following items: **Image**, **Network**, **System**, and **Application**. Under **Application**, there are sub-items: **Setting** (with a sub-item **Video File**), **Schedule** (with sub-items **Record Type** and **Period Setting**), and **Alarm** (with sub-items **Event** and **Action**). The main content area is titled "Video File" and has a "Basic" tab selected. It contains two settings: "AVI duration" set to "10" with the unit "Second(s)", and "AVI Format" set to "MPEG4(720)". A "Save" button is located below these settings.

Set video record time by selecting a value in the “AVI duration” field and a video record format when the alarm is triggered. Press the “Save” button to save your settings.

### 5.4.1.1 Video File



This screenshot is identical to the one above, showing the Mega IP Cam web interface with the "Video File" settings page. The "AVI duration" is set to "10" and the "AVI Format" is "MPEG4(720)". The "Save" button is visible at the bottom of the settings area.

Set video record time by selecting a value in the “AVI duration” field and set a video format when the alarm is triggered. The values contained in the AVI format fields are displayed depending on the values you set in the video code and resolution fields in the image setting page. The corresponding values are listed below.

Video Codec Field	Resolution Field	AVI Format Field
MPEG4_1 + MPEG4_2+MJPEG	1280x720,352x192, 640x352	MPEG4(720) MPEG4(CIF)
MPEG4_1 + MJPEG	640x480,640x480	MPEG4(VGA)
	1280x720,640x352	MPEG4(720)
MPEG4_1+MPEG4_2	1280x720,352x192	MPEG4(720)/ MPEG4(CIF)
Single MPEG4_1	1280x720	MPEG4(720)

- AVI duration: select video record time by selecting a value in the “AVI duration” field once the alarm is triggered.
- AVI Format: select a video record format.

The screenshot shows a configuration window titled "Basic". It contains two dropdown menus: "AVI duration" is set to "--" with the unit "Second(s)" displayed to its right, and "AVI Format" is set to "MPEG4(720)". A "Save" button is located at the bottom left of the window.

### 5.4.1.2 FTP

The screenshot shows a configuration window titled "FTP". It is divided into two sections: "FTP Networking" and "Storage Setting". In the "FTP Networking" section, "FTP Server" is set to "192.168.1.1", "User Name" is empty, and "File Upload" is set to "default\_folder". In the "Storage Setting" section, "File Format" is set to "MPEG4". A "Save" button is located at the bottom left of the window.


Set a format of video which is set to be saved to FTP. The values contained in the file format field are displayed depending on the values you set in the video code field of the image setting section. The corresponding values are listed below.

Video Codec Field	File Format
MPEG4_1 + MPEG4_2+MJPEG	MPEG4
MPEG4_1+MJPEG	JPEG
MPEG4_1+MPEG4_2	MPEG4
Single MPEG4_1	MPEG4

- FTP Networking section: it displays FTP information.
- File Format: select a format of file which set to be saved to FTP.
- Click “Save” to save your settings.

### 5.4.1.3 SMTP

---



**SMTP**

**SMTP Networking**

SMTP Server: 192.168.1.1

E-Mail Address:

**Storage Setting**

Attach File Numbers: 5 (1~20)

Attach File Format: JPEG

Save

**Note:**

The file number could be limited since the client's SMTP server may regulate & restrain the data volume from senders.

You can set the number and type of images which you want to receive via e-mail. The values contained in the “Attach File Format” field are displayed depending on the values you set in the video code field in the image setting page. The corresponding values are listed below.

- SMTP Server: it displays the SMTP address which can be set in Network>SMTP.
- Email Address: the receiver’s mail address which can be set in Network>SMTP.
- Attach File Number: specify the number of files which can be attached to a mail.
- Attach File Format: select a format of files which can be attached to a mail.

### 5.4.2 Schedule

---

This function can be activated at preset times, in a repeating pattern on selected weekdays..

#### 5.4.2.1 Record Type

---



**Record Type**

**Basic Setting**

Enable Record - Upload Via FTP.

Save

**Note:**

Please uncheck the box if you want to change the current file format. Then select the file format of the transmission method you need before checking the box again.

Two recording types can be set at the same time, which is FTP recording .

- Enable Record-Upload Via FTP: save files on the FTP server.
- Press “Save” to save your settings.

## 5.4.2.2 Period Setting

---

### Period Setting

#### Basic Setting

<input type="checkbox"/>	Monday	▼	From	0	▼	:	0	▼	To	0	▼	:	0	▼
<input type="checkbox"/>	Monday	▼	From	0	▼	:	0	▼	To	0	▼	:	0	▼
<input type="checkbox"/>	Monday	▼	From	0	▼	:	0	▼	To	0	▼	:	0	▼
<input type="checkbox"/>	Monday	▼	From	0	▼	:	0	▼	To	0	▼	:	0	▼
<input type="checkbox"/>	Monday	▼	From	0	▼	:	0	▼	To	0	▼	:	0	▼
<input type="checkbox"/>	Monday	▼	From	0	▼	:	0	▼	To	0	▼	:	0	▼
<input type="checkbox"/>	Monday	▼	From	0	▼	:	0	▼	To	0	▼	:	0	▼

**Note:**  
The "AVI duration"(in Application->Setting->Video File)and "Alarm duration"(in Application->Alarm->Action) will not work once any schedule period is set.

Store image files based on the schedule you set. Configure settings and then press "Save" to save settings.

**Note:** if you set up recording schedules, the "AVI duration" function (refer to 5.4.1.1 for related settings) or the "alarm duration" function (refer to 5.4.3 for related settings) can not work.

## 5.4.3 Alarm

---

You can set to trigger alarms on the conditions that an event or action signal has been sent to the camera.

### 5.4.3.1 Event

---

### Event

#### Ethernet

Trigger an Alarm When Ethernet is Lost.

#### Digital Input

Digital Input:  OFF  ON  
Active Type: Low ▼

#### Motion

Motion Detection:  Disable  Enable  
Sensitivity:  Lowest ▼  
 50 (Customized Threshold)





- Trigger an Alarm When Ethernet is Lost: set an alarm condition when Ethernet disconnected.
- Digital Input: send a signal to the camera to trigger an alarm. Check it to enable this function. Then, set digital input as “High” or “Low”
- Motion Detection: this function is designed to record video once the camera detects a motion condition. Select “Disable” to disable this function or “Enable” to enable this function.
- Sensibility: set sensibility level as “Lowest”, “Low”, “Medium”, “High” or “Highest”. Or input a value from 0 to 99 in the customized threshold field. Higher number gets higher sensitivity.
- Press “Save” to save your settings.

**Select a motion detection area by clicking squares displayed on the screen to disable a detection area. 12 motion detection areas are choices provided. Then press “Save Motion Window” to save your motion detection area setting.**

### 5.4.3.2 Action

---

**Action**

**Basic Setting**

Upload Via FTP.

Send Via SMTP.

Digital Output:  OFF  ON

Active Type: Low

Alarm Duration: 10 seconds

---

**Note:**

1. You can save recorded files through the above modes when an event is triggered.

2. When both "Schedule" and "Event" are activated, "Schedule" recording will be terminated once an event is triggered.

Configure image transfer settings after triggering an alarm.

- Select an image transfer method. You could upload the file via FTP server or send via SMTP. Note that you can only choose one transfer method.
- Digital Output: select “OFF” to disable this function or “ON” to enable this function. If select “ON”, choose an output file’s resolution as “Low” or “High”.
- ◆ Digital Output
  - If you want to set digital output function start, you need to set ON. After that, you need to set “Active Type” (Low or High) about digital output by the hardware.
- ◆ Alarm duration
  - The alarm time period of digital output.


## 6. Reset Camera

---

There are two ways to reinstate the Factory Default settings for the camera.

### 6.1 Software Reset

---



Login as the administrator to "Live View". Go into **Setup**. Then click **System** → **Update**. Choose the desired option:


- Restart Camera – The camera is restarted without changing any settings. Typically used after updating firmware. After clicking, a pop up will appear asking you to confirm. Click Yes.
- Factory Default – Resets the camera to factory settings but keeps the Network settings. After clicking, a pop up will appear asking you to confirm. Click Yes.
- Hard factory default – Resets the camera to factory settings and will cause all parameters (including the IP address) to be reset. After clicking, a pop up will appear asking you to confirm. Click Yes.

### 6.2 Hardware Reset


---

If the Internet Explorer browser cannot be access for whatever reason or Software Reset does not work then use Hardware Reset.

1. Loosen the two screws on top of the sunshield and remove the sunshield.



2. Rotate camera cover counter clockwise to expose the lens.



3. Use a screwdriver to press the hardware reset button. Then assemble the front cap & the sun shield back

Reset Button

