# TH2821B Portable LCR Meter

### OPERATION MANUAL

English
February 2006

1st Edition Rev 1.0.0
© Copyright 2006 Changzhou Tonghui Electronic Co., Ltd.
All rights reserved.

# Contents

<i>Contents</i>	2
How to Contact Us	3
Incoming Inspection	4
Notes on Use	
Warranty:	6
Chapter 1 Overview	
1.1 Introduction	
1.2 Main Functions	7
1.3 Specifications	8
1.4 Environment Requirements	10
Chapter 2 Panel Illustration	
2.1 LCD Display Illustration	11
2.2 Keyboard Illustration	
Chapter 3 Operation	
3.1 Power on	14
3.2 How to operate	15
3.2.1 Key Functions	15
3.3 Battery Replacement	21
3.4 Clearing Instruction	22
Appendix	

#### How to Contact Us

# Changzhou Tonghui Electronic Co., Ltd.

Address: No. 3, Tianshan Road, New District,

Changzhou, Jiangsu, China

Tel: 0086-519-5132222, 5113342, 5109592

Fax: 0086-519-5109972 http://www.tonghui.com.cn http://www.tonghui.cn

Email: sales@tonghui.com.cn

### Incoming Inspection

Inspect the shipping container for damage. The contents of the shipment should be listed as follows. If the contents are incomplete, if there is damage or defect, please contact our company or your nearest Sales and Service Office.

### Accessories

TH26028 DC Power Adapter	1
TH26027 4 terminal Kelvin test clip leads	1
1604A 9V battery	1
User Manual	1

# Options

TH26029 SMD component test fixture

### Notes on Use

- This meter is only for indoor use.
- Turn off the TH2821B while switching the power supply between battery and DC adapter or replacing the battery.
- Although internal circuit protection is provided, DC voltage or current may damage TH2821B. Before you measure a capacitor, be sure the capacitor is fully discharged.
- Take out the battery when the meter is not in use for more than 3 months.
- A single standard 9V battery can be used for the power supply. TH2821B will not work normally when battery voltage is less than 6V.
- The 12V AC to DC adaptor is recommended to be used for TH2821B power supply.
- Perform Open and Short corrections for accurate measurement especially when test fixture is changed.
- The functions locked with password are not accessible by users.

# Warranty:

This instrument product is warranted against defects in material and workmanship for a period of two years from the date of shipment. During the warranty period, Our company will, at its option, either repair or replace products which prove to be defective. For warranty service or repair, this product must be returned to a service facility designated by our company.

### Warranty limitation

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, or improper site preparation or maintenance.

# Chapter 1 Overview

Thank you for purchasing our product. To get the maximum performance from the instrument, please read this manual first, and keep this manual at hand.

### 1 1 Introduction

TH2821B is a microprocessor-controlled portable meter with low power consumption. It can measure six basic parameters, they are inductance L, capacitance C, resistance R, impedance |Z|, dissipation factor D and quality factor Q. TH2821B can fulfill the measurement needs of various component manufacturers and maintenance technicians.

### 1.2 Main Functions

- 1. Test Parameter
- L-Q, C-D, R-Q and Z-Q. 2. Correction

OPEN: multi-frequency correction of open circuit; SHORT: multi-frequency correction of short circuit.

- 3. Display Mode — direct measurement value: Direct
- Range Hold 4. When measuring a large number of components with the same nominal value, this function can effectively improve the measuring rate.
- 5. **Equivalent Circuit Mode** Both parallel and series equivalent circuit modes can

be obtained.

### 6. Data Hold

This function can be used to freeze the current display value.

# 1.3 Specifications

Parameter	L-Q, C-D, R-Q and Z-Q			
Frequency	100 Hz, 120 Hz and 1 kHz			
Accuracy	Basic Accuracy: 0.3%			
Display	5 digits display for both primary and secondary parameters			
	1	100 Hz,120 Hz	1 μH - 9999 H	
	١	1 kHz	0.1 μH - 999.9 H	
	С	100 Hz, 120Hz	1 pF - 9999 μF	
Measurem ent Range	C	1kHz	0.1 pF - 999.9 μF	
	R,  Z	0.0001 Ω - 999.9 ΜΩ		
	D, Q	0.0001 - 9999		
	Δ%	0.0001% - 9999%		
Test Level (Range	1kHz	0.3 Vrms (1±10%)		
Auto and Open Circuit)	100Hz 120Hz	0.3 Vrms (1±15%)		
Ranging Mode	Auto and Hold			
Equivalent Circuit	Parallel and Series			
Display	Direct			

	(Continued)
Correction	Open and Short Zeroing
Rate	Approx. 3 meas/sec
Terminals	5 terminals

Power Supply	1604 9V battery or DC12V(100 mA) adapter	
Low Battery Indication	Approx. 6V	
Power Consumption	Normal: Approx. 30 mA Auto power-off: Approx. 500 nA	
Auto Power Off time	Approx. 30 minutes	
Weight	Approx. 400 g	
Dimensions	200mm(L) × 95mm(W) × 40mm(D)	

Table 1-1 Specifications

# Note:

Primary parameter accuracy(A<sub>e</sub>)

C: 
$$A_e = 0.3\%(1+C_x/C_{max}+C_{min}/C_x)$$

L: 
$$A_e = 0.3\% (1 + L_x/L_{max} + L_{min}/L_x)$$

Z: 
$$A_e = 0.3\% (1 + Z_x/Z_{max} + Z_{min}/Z_x)$$

R: 
$$A_e = 0.3\%(1 + R_x/R_{max} + R_{min}/R_x)$$

Max and Min values are as follows:

Parameter	Range Auto	
C <sub>max</sub>	80μF/f	
$C_{\min}$	150pF/f	
$L_{max}$	159H/f	
$L_{min}$	0.32mH/f	
$Z_{max}$	$1 M\Omega$	
$Z_{\min}$	$1.59\Omega$	

Here:  $Z_{max} = R_{max}$ ;  $Z_{min} = R_{min}$ , Frequency unit: kHz.

Secondary parameter accuracy

$$D_e = A_e/3$$
 when  $D_x \le 0.1$   
 $D_e = A_e(1+D_x)/3$  when  $D_x \ge 0.1$ 

$$Q_e = \pm \frac{Q_x \times D_e}{1 \mp Q_x \times D_e}$$
 when  $Q_x \cdot D_e < 1$ 

# 1.4 Environment Requirements

- Please do not operate TH2821B under the following environment conditions, as any of them will directly affect measuring precision or damage the meter:
  - Please do not operate the instrument in places where is dusty, vibrant, under direct sunlight, or where there is corrosive air.
  - Although TH2821B has been specially designed for reducing the noise caused by AC power, the environment with low noise is still recommended. If this can not be arranged, please make sure to use power filter for the AC-DC adaptor.
- 2. The TH2821B must be operated under the following environment conditions:

Temperature: 0°C ~ 40°C, Humidity: ≤ 90% RH at 40°C.

3. Storage Temperature: -25°C ~ 50°C.

# Chapter 2 Panel Illustration

# 2.1 LCD Display Illustration




Figure 2-1 LCD Display

No.	Description	No.	Description	
1	Battery Power Indicator	8	Unit Indicator	
2	Remote Indicator	9	Ranging Mode Indicator	
3	Beeper Indicator	10	Primary Parameter Display	
4	Series/Parallel Indicator	11	Frequency Indicator	
5	Comparator Indicator	12	Primary Parameter Indicator	
6	Secondary Parameter Indicator	13	2 <sup>nd</sup> Function Indicator	
7	Secondary Parameter Display	14	DC Adaptor Power Supply Indicator	

Table 2-1 LCD Description

### Others:

DH: Data hold indictor

CAL: Correction function indictor MENU: Menu operation indictor

# 2.2 Keyboard Illustration



Figure 2-2 Keyboard

No.	Key	Function
1	POWER	Power On/Off
2	PARA	Parameter Selection
3	FREQ	Frequency Selection
4	CLEAR	CLEAR Selection
(5)	RANGE	Range Selection
6	AUTO	Range Auto Selection
7	DH	Data Hold
8	EQU	Series/Parallel Indicator

Table 2-2 Key Description

# Chapter 3 Operation

### 3.1 Power on

- 1. Press POWER key to turn on TH2821B.
- 2. The operation system version will be displayed.
- 3. At last the instrument enters the measurement state.




Figure 4-1 Measurement Display

# Measurement display description:

- Battery Supply
   Beeper ON
- 4. Series Circuit5. Sorting Result: P16. Parameter D7. Secondary parameter
- 8. Unit 9. Range 0 (Auto)
- 10. Primary parameter 11. Frequency: 1 kHz
- 12. Parameter C

# 3.2 How to operate

# 3.2.1 Key Functions

### 1. Parameter Setup:

Press PARA key to select the following measurement parameter combinations: L-Q, C-D, R-Q and Z-Q.

Units Description:

L	μΗ	mH	Н
С	pF	nF	μF
R/ Z	Ω	kΩ	MΩ

Table 4-1 Units

|Z| is the absolute value of impedance. Measurement value of L, C or R may be positive or negative. Negative capacitance value means that the device under test is actually an inductor; also negative inductance value means that the device under test is actually a capacitor. In theory R should be positive constantly, under some condition, R may be negative due to over zero correction. Please carry out correct zero correction.

The maximum number of display digits is 5, but 5-digit is not always available and 4-digit is displayed sometimes.

The conversion is described in the following description: From 4-digit to 5-digit:

When the first 2 digit of current value is less than 18. From 5-digit to 4-digit:

When the first 2 digit of current value is more than 20.

# 2. Frequency Setup:

Use FREO key to select the following test frequencies in turn: 100 Hz, 120 Hz and 1 kHz.

# 3. Range Setup:

RANGE and AUTO keys are used to set the measurement range. AUTO key toggles ranging mode between "Auto" and "Hold". RANGE keys are used to increase or decrease the measurement range, if the current ranging mode is "Auto", then the ranging mode is changed to "Hold" at the same time.

# 

When ranging mode is set to HOLD, the measurement range is fixed at current range. Overload symbol "-----" will be displayed if the impedance under test exceeds the current effective measurement range or display range.

Range No.	Range Resistor	Range Up	Range Down
0	100kΩ	<b>↑</b> 20kΩ	<b>↓</b> 18kΩ
1	10kΩ	<b>↑</b> 2kΩ	<b>↓</b> 1.8kΩ
2	1kΩ	<b>^</b>	Ψ
3	100Ω	200Ω <b>↑</b>	180Ω <b>↓</b>
4	20Ω	20Ω <b>↑</b>	18Ω <b>↓</b>

Table 4-2 Ranges

# Note:

How to calculate the measurement range

Example: Assume capacitance C=210pF, dissipation D=0.0010 and test frequency f=1 kHz.

Solution:

$$Z_x = R_x + \frac{1}{j2\pi f C_x}$$

$$|Z_x| \approx \frac{1}{2\pi f C_x} = \frac{1}{2 \times 3.1416 \times 1000 \times 210 \times 10^{-9}} \approx 757.9\Omega$$

From the Table 4-2, we can get the correct measurement range is No. 2.

#### 4. Data Hold

Press DH key to freeze the display, press DH key again to release.

### 5. Correction Function

- Press CLEAR key to select the second function, "SHIFT" will be lighted on the screen.
- Press CLEAR key to enter the correction function, the following information will be displayed on the screen.



Figure 4-2 Correction Display

 ELERr (Clear) is displayed in the primary parameter display area, OPEN (OPEN), Short (Short) or gove (Quit)

will be displayed in the secondary parameter display area.

# Note:

<code>OPEN</code> (OPEN), <code>Short</code> (Short) and <code>quit</code> (Quit) are selected and displayed automatically by the meter according to the impedance value of the device under test.

- Press any key to cancel the correction operation and return to the measurement state. Press CLEAR key to start the correction measurement.
- When correction measurement is finished, PASS or FAIL will be displayed on the screen, see Figure 4-3



Figure 4-3 Open correction Passed

# Note:

- The correction function must be used for accurate measurement.
   The correction function can eliminate the stray admittance (capacitance, and inductance) and the residual impedance (resistance and reactance) induced by test fixture, test leads and instrument itself. Perform the correction operation again if the measurement conditions are changed such as test fixture and environment temperature.
- 2. It is recommended to perform the open and short correction at the same time.
- During short correction period, FR IL (FAIL) will be displayed in the secondary parameter display area when short correction is failed. Make sure that the measurement contacts are shorted reliably

and perform the short correction again.

- 4. Th2821B measures the correction data at all frequency points and all measurement ranges. The correction data is stored in the non-volatile memory. So you don't have to perform the correction again, if the test conditions are not changed.
- 5. Open and short corrections are automatically selected by the instrument according to the impedance value under test. If there is a component in the fixture or if there is error with the instrument,  $q_{u,t}$  (Quit) will be displayed in the secondary parameter display area.


### 6. Equivalent Circuit

Press EQU key to select the Series or Parallel circuit mode.



- The actual C, R and L are not the ideal pure C, R and L. Normally an actual component can be regarded as the combination of an ideal resistor and an ideal reactor in series or parallel circuit mode.
- 2. TH2821B can convert between the two different equivalent circuit modes using the following equations. The measurement values of the two different circuit modes maybe different under different quality factor Q (or dissipation factor D).

Capacitance Cp: from parallel to series



Series: 
$$C_s = (1 + D^2)C_p$$
  
 $R_s = R_p D^2 / (1 + D^2)$ 

Capacitance Cs: from series to parallel



Dissipation: 
$$D = 2\pi f R_s C_s = \frac{1}{O}$$

Parallel: 
$$C_P = 1/(1+D^2) C_S$$
  
 $R_P = R_S (1+D^2)/D^2$ 

Inductance Lp: from parallel to series



Circuit Mode:

Dissipation: 
$$D = \frac{2\pi f L_P}{R_P} = \frac{1}{Q}$$

Series:  $L_S = 1/(1 + D^2)L_P$ 

$$R_S = R_P D^2 / (1 + D^2)$$

Inductance Ls: from series to parallel

Circuit Mode: Lp Rp

Dissipation:  $D = \frac{R_s}{2\pi L_s} = \frac{1}{Q}$ 

Parallel:  $L_p = (1 + D^2)L_S$ 

 $R_P = R_S (1 + D^2) / D^2$ 

Here parameter with subscript s means the series mode, parameter with subscript p means the parallel mode.

3. From the above equations, we can conclude that the conversion between series and parallel is determined by  $D^2$  or  $Q^2$  (Q=1/D) . The value of  $D^2$  or  $Q^2$  directly determined the parameter values in different circuit mode. Example:

Three capacitors have the same series capacitance: Cs=0.1 $\mu$ F, but their dissipations are different with each other: D1=0.0100, D2=0.1000, D3=1.0000. According to the above equation, we can get their capacitance in parallel mode:

 $Cp1 = 0.09999 \mu F$ 

 $Cp2 = 0.09901 \mu F$ 

 $Cp3 = 0.05000 \mu F$ 

We can find that Cs is almost the same with Cp when D is very small (D < 0.01), but when D is more than 0.01, Cp and Cs are different obviously. For example: When D = 0.1, the difference is 1%, but when D = 1, the difference is almost 50%.

# 3.3 Battery Replacement



The instrument will not be started, when the battery is weakening. Replace the battery immediately.

• Loosen the three screws with suitable driver and

- remove the bottom cover.
- Replace the degraded battery with a new DC 9V battery.
- Model 1604, 006P or other equivalent battery must be used. Alkaline battery is recommended.
- If the instrument is not in use for more than three months, if the external DC adapter is always be used, please take out the battery.
- Close the bottom cover. The degraded battery must be disposed of properly.

# 3.4 Clearing Instruction

To clean the instrument, use a soft cloth slightly dipped in water. Do not spray cleanser directly onto the instrument, since it may leak into the cabinet and cause damage. Do not use chemicals containing benzine, alcohol or aromatic hydrocarbons.

# Appendix

### Message Code Table:

Clear: Correction CLEBe NPEN Open: Open correction Short: Short correction Short P 1-P1<sup>-</sup>: High limit of P1 Bin P1\_: Low limit of P1 Bin Ρ! NG: No-Good nr. Q\_: 9\_ Low limit of quality factor D : High limit of dissipation factor d-Std: Standard value (Nominal value) 568 APO: Auto Power Off RPO CAL: **Accuracy Calibration** CRL PSD: Password PSd Alert RIFCH ON ПΩ OFF NEE Pass PRSS -Fail FR 11 Ouit 9016

First Edition2006-2