



KW4M

Eco-Power Meter

User's Manual



This manual was created using Adobe Acrobat.
Adobe, the Adobe logo, and Acrobat are trademarks
of Adobe Systems Incorporated.

KW4M Eco-Power Meter User's Manual
ARCT1F413E-2 '08.03

Cautions for Your Safety

Read the manual carefully before installing, running and maintenance for proper operation. Before using, master the knowledge of the equipment, safety information and all of other notes.

This manual uses two safety flags to indicate different levels of danger.



WARNING

A handling error could cause serious physical injury to an operator and in the worst case could even be fatal.

- If the use is predicted to lead to human injuries and/or grave expanding damage, take the special safety measures such as double interlock.
- Do not use the product in the environment that has inflammable gas. It might lead to an explosion.



CAUTION

A handling error could cause serious physical injury to an operator or damage to the equipment.

- Tighten the wires firmly with terminal screws.
The bad connection might cause abnormal heat and smoke.
- Do not use the unit outside the range of the specifications regarding such as rating, environment conditions etc.
It might cause abnormal heat or smoke.
- Do not discompose or modify the unit.
It might give you an electric shock or cause smoke.
- Do not touch the terminal while current is running.
It might give you an electric shock.

Introduction

Thank you for indeed for purchasing “KW4M Eco-POWER METER” for this time.

In this manual, we explain the usage of “KW4M Eco-POWER METER” in detail.

Please use it correctly after understanding the content enough.



Table of Contents

Cautions before using	i
Chapter 1 Unit's Features and Structure.....	1
1-1 Features.....	1
1-2 Unit's Name and Part Numbers.....	1
1-2-1 Main unit.....	1
1-2-2 Dedicated Current Transformer (CT).....	1
1-2-3 Options.....	1
1-3 Measurement items	2
Chapter 2 Parts Name and Working	3
2-1 Parts Names	3
2-2 Select Keys' Functions	3
Chapter 3 Display of each Value.....	4
3-1 Instantaneous electric power / Integrated Electrical energy.....	4
3-2 Current.....	5
3-3 Voltage.....	5
3-4 Electricity Charge.....	6
3-5 Hour Meter.....	6
3-6 Count Value / Preset Value	7
Chapter 4 Various Functions.....	8
4-1 LOCK mode.....	8
4-2 CT Direction Notification (POWER Measurement).....	8
4-3 Counter function (PULSE measurement).....	8
4-3-1 Operation mode	8
4-3-2 Change the Preset Value.....	8
Chapter 5 Settings	9
5-1 Operation procedure.....	9
5-2 Setting Mode Explanation.....	10
5-2-1 MODE (Select input method)	10
5-2-2 MODE1	10
5-2-3 MODE2	13
5-2-4 MODE3	14
5-2-5 MODE4	15
Chapter 6 Installation and Wiring	16
6-1 Panel Cut-out dimensions	16
6-2 Panel mounting diagram.....	16
6-3 Wiring.....	17
6-3-1 Terminal arrangement.....	17
6-3-2 Power measurement.....	17
6-3-3 Pulse measurement	20
6-3-4 For Output connection	21
6-3-5 For Wiring terminal.....	21
6-3-6 RS-485 communication.....	21
6-3-7 Low Voltage Directive	22
Chapter 7 Communications	23
7-1 Communication Procedures	23
7-2 Communication timing	23
7-3 MEWTOCOL communication	24
7-3-1 Overview of MEWTOCOL-COM (RS-485)	24
7-3-2 Data Register List	25
7-3-3 Error Codes.....	26
7-3-4 Command.....	26
7-5 MODBUS (RTU) Communication	28
7-5-1 Overview of MODBUS (RTU)	28
7-5-2 Data Register List	31

Chapter 8 Specifications	33
8-1 Main unit	33
8-2 Input Specifications	34
8-2-1 Power Input	34
8-2-2 Pulse input specifications.....	35
8-3 Pulse output (Transistor output) Specifications.....	35
8-4 Communication Specifications	36
8-5 Dedicated Current Transformer Specifications	36
8-6 Self-diagnostic function	37
Chapter 9 Dimensions	37
9-1 Main unit	37
9-2 Dedicated CT.....	37
9-2 Dedicated CT.....	38



Cautions before using

■ Installation environment

◇ Do not use the Unit in the following environments.

- Where the unit will be exposed to direct sunlight and where the ambient temperature is outside the range of -10 to 50 °C.
- Where the ambient humidity is outside the range of 30 to 85 % RH (at 20°C non-condensing) and where condensation might occur by sudden temperature changes
- Where inflammable or corrosive gas might be produced
- Where the unit will be exposed to excessive airborne dust or metal particles
- Where the unit will be exposed to water, oil or chemicals
- Where organic solvents such as benzene, paint thinner, alcohol, or strong alkaline solutions such as ammonia or caustic soda might adhere to the product
- Where direct vibration or shock might be transmitted to the product, and where water might wet the product

◇ Please use the Unit according to the specifications described in this manual. Otherwise, it may malfunction or cause fire and an electric shock.

- Connect to the power supply in compliance with the rating.
- Refer to the wiring diagram to ensure proper wiring for the power supply, input and output.
- Do not perform wiring or installation with a live line. It may also lead to circuit burnout or fire by way of the secondary CT side opening.
- Do not add voltage and current to an output terminal from outside.

■ Installation

- Installation and wiring must be performed by expert personnel for electrical work or electric piping.
- The power supply terminal and voltage input terminal of the main unit is common. Therefore if additional noise affects the power supply line, incorrect measurements may result.
- Eco-POWER METER is designed to be used in a control panel.
- As to measurement
If there is some distortion by harmonic or waveform, it may not measure correctly.
Please check with the actual system before adopting it.

■ Static electricity

- Discharge static electricity touching the grounded metal etc. when you touch the unit.
- Excessive static electricity might be generated especially in a dry place.

■ Cleaning

- Wipe dirt of the main unit with soft cloth etc. When thinner is used, the unit might deform or be discolored.

■ Power supply

- Connect a breaker to the voltage input part for safety reasons and to protect the device.
The breaker that connects to the voltage input part must arrange at the position easily reached, and display shows it is the breaker of the equipment.
- Do not turn on the power supply or input until all wiring is completed.

■ Before power on

Please note the following points when turning on power at the first time.

- Confirm there are neither wiring rubbish nor especially an electrical conduction when installed.
- Confirm neither the power supply wiring, the I/O wiring nor the power-supply voltage are wrong.
- Tighten the installation screw and the terminal screw surely.
- Use an electric wire applicable to the rated current.

Chapter 1 Unit's Features and Structure

1-1 Features

■ KW4M Eco-POWER METER is a wattmeter in DIN48 size. Electrical energy (voltage, current, etc.) is measured using AC voltage and AC current input via one of the following systems: single-phase two-wire system, single-phase three-wire system, or three-phase three-wire system.

This also works as an hour meter, that is measured power-on or power-off time, and as a counter that is for pulse output equipment like flowmeter.

■ **Eco-POWER METER is designed chiefly to manage saving energy. It is neither intended nor can it be legally used for billing.**

1-2 Unit's Name and Part Numbers

1-2-1 Main unit

Phase and Wire system	Power Supply	Measured voltage input	Measured current input	Current transformer	Terminal type	Protocol	Model No
· Single-phase two-wire · Single-phase three-wire · Three-phase three-wire	100-240V AC	· 100-120 /200-240V AC · 100-120V AC · 200-240V AC	5A 50A 100A 250A 400A	Dedicated CT type (5A/50A/100A/250A/400A)	Screw terminal	MEWTOCOL	AKW5111
						MODBUS (RTU)	AKW5112
					11-pin	MEWTOCOL	AKW5211
						MODBUS (RTU)	AKW5212

1-2-2 Dedicated Current Transformer (CT)

Rated primary current	Model No
5A	AKW4801
50A	
100A	AKW4802
250A	AKW4803
400A	AKW4804

1-2-3 Options

Product name	Contents	Model No
Mounting frame	Used for mounting in a panel (supplied with a unit)	AT8-DA4
Rubber gasket	Used for mounting in a panel (supplied with a unit)	ATC18002
Protective cover	Used for protecting a front display (common to Timer/Counter)	AQM4803
DIN rail socket	For 11-pin type(surface mounting)	ATC180041
Rear terminal socket	For 11-pin type (embedded mounting)	AT78051
11P cap	For 11-pin type (connectable directly with soldering)	AT8-DP11
Mounting rail	DIN rail terminal socket fixing rail	AT8-DLA1

1-3 Measurement items

Item		Unit	Data range
Instantaneous electric power		kW	0.00 to 9999.99
Integrated electrical energy		kWh	0.00 to 9999.99kWh to 10.00MWh to
		MWh	9999.99MWh 9-digit display: 0.00 to 99999999.99 kWh
Current	L1(CT1)-phase current	A	0.0~999.9 (MEWTOCOL type)
			0.0~6000.0 (MODBUS (RTU) type)
	L2(CT2)-phase current	A	0.0~999.9 (MEWTOCOL type)
			0.0~6000.0 (MODBUS (RTU) type)
Voltage	Voltage between 1-2	V	0.0 to 9999.9
	Voltage between 2-3	V	0.0 to 9999.9
Electricity charge ※	Yen	JPY	0 to 999999
	Dollars	\$	0 to 9999.99
	Euros	EUR	0 to 9999.99
	Yuan	CNY	0 to 9999.99
Hour meter	ON-time	h(Hour)	0.0 to 99999.9
	OFF-time	h(Hour)	0.0 to 99999.9
Pulse input		Count	0 to 999999


※Eco-POWER METER is designed chiefly to manage saving energy.

It is neither intended nor can it be legally used for billing.

Chapter 2 Parts Name and Working

2-1 Parts Names

- ① Mode name display (16-segment)
- ② Lock indicator Light is on when locked.
- ③ Mode indicator Light is on when the mode is being set.
- ④ Output indicator Light is on when pulse is output.
- ⑤ CT direction notification Light is on when CT is connected correctly and current flows.
- ⑥ Display for value selected (7-segment)
Instantaneous electric power,
Integrated electrical energy,
Current, Voltage, Electricity charge, Hour meter and Counter
- ⑦ MODE key Use to select mode
- ⑧ SET key Use to set each value entered
- ⑨ Select keys a) Change which value is displayed.
b) Make settings in a particular mode.



2-2 Select Keys' Functions


	POWER measurement	PULSE measurement
< kW/kWh >	<ul style="list-style-type: none"> Instantaneous electric power → Integrated electrical energy (Continuous press) Display by 9-digit (Integrated electric power) 	---
< A >	L1 (CT1) -phase current → L2 (CT2) -phase current	
< V >	Voltage between 1 and 2 → Between 2 and 3	
< CHARGE >	Electricity charge: JPY → \$ → EUR → CNY	
< TIME >	ON-time → OFF-time	
< COUNT >	---	<ul style="list-style-type: none"> Count value → Preset value (Continuous press at preset value display) Shift to preset value setting mode
< MODE > + < SET >	Reset (Integrated electrical energy, ON-time, OFF-time)	Reset (Count value)
< MODE >	Shift to each setting mode	
< SET >	<ul style="list-style-type: none"> Set each value entered (Continuous press) All keys locked. While in LOCK mode, releases LOCK mode 	

Chapter 3 Display of each Value


3-1 Instantaneous electric power / Integrated Electrical energy

- Press <kW/kWh>key to display the instantaneous electric power and integrated electrical energy.
 - Press <kW/kWh>key to change the instantaneous electric power to integrated electrical energy.
- *Displayed data is updated at every 1 second.

Instantaneous electric power(kW) → Integrated electrical energy(kWh)



- Integrated electrical energy is measured and displayed from 0.00kWh to 9999.99MWh.
- The decimal point and the unit are changed automatically.




(After reaching the full scale (99999.9kWh), the value reverts to 0.00kWh but continues to measure.)

How to display with 9-digit


Integrated electrical energy can be displayed with 9-digit.

- Continuous press <kW/kWh> for about 2sec. or more at the instantaneous electric power or integrated electrical energy display, "kWh" shows for about 0.5sec. and integrated electrical energy with 9-digit is displayed.




How to reset the integrated electrical energy

- Press <MODE>key while pressing <SET>key makes integrated electrical energy clear.



3-2 Current

- Press <A>key to display the current value of the load.
- Press <A>key to change L1(CT1)-phase current to L2(CT2)-phase current
- *Displayed data is updated at every 1 second.



- When input current exceeds 150%F.S. at each range, 「— — — — —」 will be displayed in the lower line.


- Current measurement parts

Eco-POWER METER measures the current as below.

System \ Display	L1(CT1)A	L2(CT2)A
Single-phase two-wire	1(L1)-phase current	-
Single-phase three-wire	1(R)-phase current	3(T)-phase current
Three-phase three-wire	1(R)-phase current	3(T)-phase current

3-3 Voltage

- Press <V>key to display the voltage value of the load.
- Press <V>key to change voltage between 1 and 2(V) to 2 and 3(V).
- *Displayed data is updated at every 1 second.



- When input voltage exceeds 150%F.S. at each range, 「— — — — —」 will be displayed in the lower line.

- Voltage measurement parts


Eco-POWER METER measures the voltage as below.

System \ Display	L1V	L2V
Single-phase two-wire	Voltage between 1 and 2 (R-phase)	—
Single-phase three-wire	Voltage between 1 and 2 (R-phase)	Voltage between 2 and 3 (T-phase)
Three-phase three-wire	Voltage between 1 and 2 (Between R and S line)	Voltage between 2 and 3 (Between S and T line)

3-4 Electricity Charge


It displays the standard electricity charge for the integrated electrical energy.

- Press <CHARGE>key to display the electricity charge.
- At electricity charge display, press <CHARGE>key to change between JPY, \$,EUR and CNY.




3-5 Hour Meter

- Press <TIME> key to display the load ON-time or load OFF-time measured by CT1.
- Press <TIME> key to change the load ON-time to load OFF-time.




* When load current is under the setting current for time measurement (HM-A), it measures as OFF-time. When load current is exceeded to the setting current for time measurement (HM-A), it measures as ON-time. Current for time measurement (HM-A) is set to under cutoff current (CUTA), all current is measured as OFF-time.

* Current flow of CT1




* After reaching the full scale (99999.9h), the value reverts to 0.0h but continues to measure.



How to Reset ON/OFF-time


- Press <MODE>key while pressing <SET>key makes ON / OFF-time clear.



3-6 Count Value / Preset Value

It displays present count value (pulse input value) and preset value.

- Press <COUNT> key to display count value (pulse input value).
- Press <COUNT> key to change count value to preset value.



How to Enter the Preset Value

- Press <COUNT> continuously for about 3sec. at preset value display, "PSET" is blinking.
- Enter a preset value using <kW/kWh>,< A > , < V > , <CHARGE> , <TIME> and <COUNT>.
- Press <SET> to set the entered value. "PSET" stops blinking.


Position of Decimal Point

- The position of decimal point for count value and preset value is decided according to the setting at 'Pre-scale setting mode'.

Ex) When preset value set to 0.01, the decimal point is fixed the last 2 digit for count value and preset value.

How to Reset Count value

- Press <MODE>key while pressing <SET>key makes count value clear.



Chapter 4 Various Functions

4-1 LOCK mode

It is the mode makes <MODE>key and Select keys unable.

Use when you want to fix one of the measurement displays (For all displays).

When you press <SET>key continuously for about 3sec., the "LOCK" indicator lights and <MODE>key and Select keys become locked (pressing them will have no effect).

Press <SET>key continuously for about 3sec. again to release Lock mode.


The "LOCK" indicator goes off and the lock mode is released (unlocked)



4-2 CT Direction Notification (POWER Measurement)

This shows the connection condition of CT and notices wrong voltage or wrong connection of CT wiring.

- "CT1(CT2)" lights if the input voltage is corresponding to the direction of the current.
- "CT1" lights if the voltage between 1 and 2 is corresponding to the direction of L1-phase current.
- "CT2" lights if the voltage between 2 and 3 is corresponding to the direction of L2-phase current.



*** It does not light if the load current is under the cutoff current (CUTA) or if there is some distortion by harmonic or waveform.**

4-3 Counter function (PULSE measurement)

4-3-1 Operation mode

Maintain output hold count **HOLD**

[Output] _____ OFF _____ ON

[Counting] <----- possible ----->
[Addition] 0 1 2 3 ... n-2 n-1 n n+1 n+2 n+3

n: Preset value

- (1) Output control is maintained after count-up completion and until reset. However counting is possible despite of count-up completion.
- (2) It reverts "0" after counting up full scale, but output control is maintained. However output is OFF if count value or preset value is changed.

4-3-2 Change the Preset Value

It is possible to change the preset value even during counting. However note the following points.

◇When the pre-scale value is "1.000". (PSCL=1.000)

- (1) If the preset value is changed to the value less than the count value, counting will continue until it reaches full scale, returns to "0" and then reaches the new preset value.
- (2) If the preset value is changed to "0", it will not count up at start with "0". It counts up when the counting value comes to "0" again (after reach to full scale). However output is OFF if count value or preset value is changed.
- (3) When the count value is fixed, output is changed according to the changing of preset value as below.
 - ① If the preset value is changed to the value less than the count value or same as count value, output is ON.
(Count value \geq Preset value)
 - ② If the preset value is changed to the value more than the count value, output is OFF.
(Count value $<$ Preset value)

◇When the pre-scale is not "1.000". (PSCL \neq 1.000)

Even if the preset value is changed after counting to full scale, output is not changed.

Chapter 5 Settings

5-1 Operation procedure

Each setting is classified as follows. There are the detailed explanations from next pages.

•MODE:<MODE>


...Mode for selection of Power measurement (Power meter) or Pulse measurement (Pulse counter).

•MODE1: <MODE>+<kW/kWh> ... Mode for setting each parameter for power measurement.

•MODE2: <MODE>+<A> ... Mode for setting of each parameter for pulse measurement

•MODE3: <MODE>+<V> ... Mode for setting of each parameter for serial communication (RS-485)

•MODE4: <MODE>+<CHARGE> ... Mode for setting of each parameter for optional function



* 1 MODE1 is only for POWER measurement.

* 2 MODE2 is only for PULSE measurement.

* 3 Primary side current of CT setting mode is only for when '5A' is selected on CT type setting mode.

* 4 Alarm value setting mode is only for when 'ALARM' is selected on Unit for pulse output setting mode.

* 5 Response time setting mode is only for MODBUS type.

NOTE) Power measurement (Power meter) and Pulse measurement (Pulse counter) can not be used at the same time.

5-2 Setting Mode Explanation

■ The value with under line is initial setting among each setting value. ☆ Set before measurement.


5-2-1 MODE (Select input method)

<MODE>

Input method setting mode IN

Mode defines input method, power measurement or pulse measurement.

- Select from POWER / COUNT
- “POWER” is selected when using power measurement (Power meter).
- “COUNT” is selected when using pulse measurement (Pulse counter).



5-2-2 MODE1

(Mode for setting each parameter for power measurement.

This mode doesn't show when pulse measurement is selected.)

<MODE>+<kW/kWh>

CT type setting mode CT-T

Mode defines input current type of the dedicated CT.

- Select from the type of 5A/50A/100A/250A/400A.
- When the secondary current of CT is 5A, select “5A”.

Primary side current of CT setting mode CT-I

Mode defines primary current when measuring by combination with existing CT, its secondary current of 5A.

It is possible to use as the second step for combination with existing CT by selecting “5A” in the CT type setting mode. In this case, it is necessary to set the primary side current.

- It can be set the range of 1 to 999.
- When connecting 5ACT directly and measure with 5A range, set to “5”.
- ex) If measured CT is 400A/5A, set to “400”.

※This mode is only when “5A” is selected on CT type setting mode.

VT ratio setting mode VT

Mode defines voltage-input method to the main unit, input voltage directly or uses a voltage transformer (VT) (over 240VAC).

- It can be set the range of 1.00 to 99.99.
- “1.00” should be set when voltage input directly without connecting VT.
- “1.01~99.99” should be set when VT is used to input voltage.
- ex) If the VT is 440V/110V, set to “4.00”.

Current for time measurement setting mode HM-R

Mode defines for time measured current. Unit measures ON-time and OFF-time by setting value.

- It can be set the range of 1.0% to 100.0%F.S.
- ex) When 10.0 is set, the current exceeds 10.0%F.S is measured as ON-time, the current under 10.0%F.S is measured as OFF-time.
- ※Measured current is the current of L1(CT1)-phase.

Cutoff current setting mode CUTR

Mode defines load current that does not measured (Cutoff current).

Use to avoid miss-measurement by wiring or induction noise at no-load.

0.00kW is displayed for instantaneous electric power, 0.0A is displayed for current. Integrated electrical energy is not measured.

• It can be set the range of 1.0% to 50.0%.

ex) When set to 10.0, current under 10.0%F.S is not measured.

Unit for pulse output setting mode (Power) PL-P

Mode defines unit used for pulse output.

• Select from 0.001/0.01/0.1/1/10/100kWh /Alarm.

When "ALARM" is set, alarm is output at the time when instantaneous electric power is over the setting value.

When one of the "0.001/0.01/0.1/1/10/100"[kWh] is set, one pulse is output at the setting value.

Alarm value setting mode AL-P

Mode defines instantaneous electric power used for alarm output.

• It is set the range of 0.00 to 9999.99kW.

※This mode is only when "ALARM" is selected on unit for pulse output setting mode.

Electricity charge setting mode JPY/\$/EUR/CNY

Mode defines electricity charge ratio used as a standard per 1kWh.

The electricity charge ration of 4 kinds of currency (JPY, \$,EUR,CNY) can be set.

• It can be set the range of 0.0 to 99.9 yen/1kWh. (Initial 10.0)

• It can be set the range of 0.000 to 9.999 dollars/1kWh. (Initial 0.093)

• It can be set the range of 0.000 to 9.999 euros/1kWh. (Initial 0.085)


• It can be set the range of 0.00 to 99.99 yuan/1kWh. (Initial 10.00)

Normal display


↓ **<MODE>**

MODE display


↓ **<kW/kWh>**

CT type setting mode	Factory setting / Display
<ul style="list-style-type: none"> • Press <kW/kWh> to change CT type. • CT type is selected from 50→100→250→400→5 	






↓ **<SET>**

Primary side current of CT setting mode	Factory setting / Display
<ul style="list-style-type: none"> • Enter primary side current of CT using <kW/kWh>, < A >, < V >. • If measured CT is 100A/5A, set to 100. • If 5A is measured, set to 5. <p>It is only when "5A" is selected on CT type setting mode.</p>	

↓ **<SET>**

VT ratio setting mode	Factory setting / Display
<ul style="list-style-type: none"> • Enter VT ratio using <kW/kWh>, < A >, < V >, <CHARGE>. • If the VT is 440/110, set to "4.00". (1.00~99.99) 	

↓ **<SET>**

Current for time measurement setting mode <ul style="list-style-type: none"> Enter current for time measurement using <kW/kWh>,< A >,< V >. If you measure the current over 50.0%F.S, set to “50.0”. (1.0~100.0) 	Factory setting / Display 
↓ <SET>	
Cutoff current setting mode <ul style="list-style-type: none"> Enter cutoff current using <kW/kWh> ,< A >,< V >. If you don't measure the current under 10.0%F.S, set to “10.0”. (1.0~50.0) 	Factory setting / Display 
↓ <SET>	
Unit for pulse output setting mode <ul style="list-style-type: none"> Press <kW/kWh> to change unit for pulse output. Unit is selected from 0.001→0.01→0.1→1→10→100 →ALARM. 	Factory setting / Display 
↓ <SET>	
Alarm value setting mode <ul style="list-style-type: none"> Enter power for alarm using <kW/kWh>,< A >,< V >,<CHARGE>,<TIME>,<COUNT>. *It is only when “ALARM” is selected on unit for pulse output setting mode. (0~9999.99kWh) 	Factory setting / Display 
↓ <SET>	
Electricity charge setting mode <ul style="list-style-type: none"> Press <COUNT> to change JPY→\$→EUR→CNY. Enter the rate per 1kWh using <kW/kWh>,< A >,< V >,<CHARGE>. 	Factory setting / Display 
↓ <SET>	
<div>Normal display</div>	

5-2-3 MODE2

(Mode for setting each parameter for pulse measurement.

This mode doesn't show when power measurement is selected.)

<MODE>+< A >

Max. counting speed setting mode Hz

Mode defines max. counting speed.

- Select from 2kHz/30Hz

Pre-scale setting mode PSCL

Mode defines pre-scale value used for change count value.

- It can be set the range of 0.001 to 100.000. (Initial 1.000)
- The position of decimal point set with this mode is applied to count value and preset value.
ex) When 0.01 (Last 2-digit) is set, the decimal point of count value and preset value has 2 digit under decimal point.


Unit setting mode UNIT

Mode defines unit used for count value display.

- Select from CNT/l/kl/m³.

Set	CNT	l	kl	m ³
Display	CNT	l	kl	m ³

※Count value does not change even if the unit setting is changed during counting.



5-2-4 MODE3

(Mode for setting of each parameter for serial communication (RS-485))

<MODE>+< V >

Station number setting mode NO.

Mode defines an individual station no. for each unit when two or more units communicate via serial communication (RS-485).

- It can be set the range of 01 to 99.

Transmission speed (Baud rate) setting mode SPD

Mode defines serial communication (RS-485) transmission speed. Define the transmission speed according to the master's (PLC etc.).

- Select from 19200/9600/4800/2400【bit/s】.

Transmission format setting mode FMT

Mode defines serial communication (RS-485) transmission format (Data length, Parity). Define the transmission format according to the master's (PLC etc.).

- Select from 8bit-o/7bit-n/7bit-E/7bit-o/8bit-n/8bit-E for MEWTOCOL type.
8bit-o/8bit-n/8bit-E for MODBUS type.

“n(none)” means parity is not available.

“E(Even)” means parity is even number.

“o(odd)” means parity is odd number.


Response time setting mode RESP


<Only MODBUS type>

MODE defines serial communication (RS485) response time of main unit.

When command is received, it sends response after setting response time passes.

- It can be set the range of 5 to 99ms.





5-2-5 MODE4


(Mode for setting of each parameter for optional function)

<MODE>+<CHARGE>

Auto-off setting mode OFF

Backlight LED turns off automatically when there is no key operation for a long time.


- Off time can be set the range of 0 to 99min.
- “0” should be set if you want to turn always light on.
- “1~99” should be set if you want to turn light off at setting time.
- After turns off the backlight, any key operation makes it turns on.



Chapter 6 Installation and Wiring


6-1 Panel Cut-out dimensions

(Unit: mm)



Dimension A when 'u' products are mounted in a row: $A = (48 * n - 2.5)_{0}^{+0.6}$
If the products are mounted in a row, they lose their waterproofing properties.

6-2 Panel mounting diagram



How to mount

From the panel front, pass the main unit through the square holes. Insert the mounting frame from the rear and push it in so that the gap between the mounting frame and the panel surface is minimized. Tighten the screws (2 places) equally tight and check that there is no rattling. If the screws are overly tightened, the frame may come off. In that case, loosen the screws and tighten them again pushing the frame in.

6-3 Wiring

6-3-1 Terminal arrangement

Functions	Terminal No.	
	Pin type	Screw terminal type
1, R, R	①	⑧
2, N, S	②	⑨
3, T, T	③	⑩
RS-485	(+)	⑪
	(-)	①
Pulse output	(+)	⑥
	(-)	⑦
CT1(k) / IN	⑧	②
CT1(l), CT2(l)	⑨	③
CT2(k)	⑩	④
0V	⑪	⑤

- (1) Be sure to wire correctly according to the terminal arrangement and wiring diagrams.
 (2) A DIN rail socket (ATC180041) should be used for Pin type Eco-POWER METER.



The input (applied) voltage to each pin (terminal) is as follows.

Phase and wire	Type	Pin (Terminal)	Input (Applied) voltage
Single-phase two-wire	Pin type	①-②	100-120/200-240VAC (100-120/200-240V~)
	Screw terminal type	⑧-⑨	
Single-phase three-wire	Pin type	①-②-③	100-120VAC (100-120V~ :3W)
	Screw terminal type	⑧-⑨-⑩	
Three-phase three-wire	Pin type	①-②-③	200-240VAC (200-240V 3~)
	Screw terminal type	⑧-⑨-⑩	

6-3-2 Power measurement

◇Main unit wiring diagrams


***Please connect a breaker to the voltage input part for safety reasons and to protect the device.**

*Grounding CT's secondary side (l line) is recommended for the unit protection when CT breaks down.

1) When measuring load with 100-200V system


① Single-phase 2 wire system

*One CT is required to measure single-phase 2 wire system.



②Single-phase 3 wire system / Three-phase 3 wire system

*Two CTs are required to measure Single-phase 3-wire / Three-phase 3 wire system.




2) When measuring load with 200V or more system


VT (Voltage transformer) is needed when you measure a load with voltage over 200V system. Use commercial VT, those secondary rating is 110V.

*Grounding CT's secondary side (I line) and VT's neutral line is recommended for the unit protection when CT or VT breaks down.

① Single-phase 2 wire system



②Single-phase 3 wire system / Three-phase 3 wire system




◇To connect CT with secondary current 5A

How to connect the unit to measure by combination with existing commercial CT

- (1) Select 5A at CT type setting mode (CT-T).
- (2) Set the primary current of measured commercial CT (secondary current 5A) at primary side current of CT setting mode (CT-1).
< ex > If the measured CT is 400A/5A, set to "400".
- (3) Clamp the dedicated CT for 5A (AKW4801), which is connected to the main unit first, to secondary side of the commercial CT. CT direction (K→L) should be set for the commercial CT direction.

(Connection example)




◇How to attach the Current Transformer (CT)

- One current transformer (CT) is required to measure a single-phase, two-wire system. Two CTs are required to measure a single-phase, three-wire system or three-phase, three-wire system. Using 2 CTs should be the same.
- When connecting CT, connect the secondary side to the terminal of the main unit first, and after that wire the primary side to a load electric wire.
- The CT has polarity. Wire correctly according to the K and L marks.
- For the dedicated CT (AKW4801, 4802, 4803, 4804), 'k' is the white wire and 'l' is the black wire.
- Check beforehand that the thickness of the electric wire is smaller than the through-hole of the CT. If you use a CT that separates at the bottom, make sure it is closed securely once the wire is in place; if not an error in measurement will occur.
- When CT's cable is extended, it is possible to extend up to about 10m with the cable of 0.75mm² or more cross section under the environment without noise at all. Please use the thick cable as much as possible.

6-3-3 Pulse measurement

◇Main unit wiring diagrams



◇Input connection

•Contact input

Use highly reliable metal plated contacts. Since the contact's bounce time leads directly to error in the count value, use contacts with as short a bounce time as possible. In general, select 30Hz for max. counting speed.

•Non-contact input (Transistor input)

Connect with an open collector. Use the transistor with the following specifications.

$V_{CE0}=20V$ min. $I_C=20mA$ min. $I_{CBO}=6\mu A$ max

Use transistors with a residual voltage of less than 1.5V when the transistor is ON.

※Short-circuit impedance should be less than $1k\Omega$.

(When the impedance is 0Ω , drain current is approx. 5mA.)



The open-circuit impedance should be more than $100k\Omega$.

•Input wiring

Please wire as short as possible by using a shielded wire or a metallic electric wire tube individually.


(Caution)

The AC power supply input part is not insulated to pulse input parts. So the input equipment must have the power supply transformer in which the secondary side is not grounded with the primary and secondary sides insulated, in order to prevent interference of the power supply circuit when connecting the external input circuit. Be sure not to use an auto-transformer.




6-3-4 For Output connection

Since the transistor output is insulated from the internal circuit by a photo-coupler, it can be used both as a NPN output and PNP (equal value) output.






6-3-5 For Wiring terminal

- When using a crimp terminal, it should be with insulation sleeve applicable to M3.5 screw as shown below.
- Tightening torque: under 0.8N·m



6-3-6 RS-485 communication



- When using shielded cable for the RS-485 transmission line, ground one end. Use a class D (class 3) dedicated earth for grounding. Do not share a ground with other earth lines. (Fig.1)
- Change the slide switch on the side of main unit as a terminal station. (Fig.2)
- Be sure to connect with daisy chain the RS-485 transmission line between each unit. Do not use a splitter. (Fig.3)



Recommended Cable

Use the transmission cables shown below for Eco-POWER METER RS485 communication system.

Cable	Conductor		Insulator		Cable diameter	Applicable cable
	Size	Resistance (at 20°C)	Material	Thickness		
Twisted-pair with shield	1.25 mm ² (AWG16) or more	Max.16.8 Ω/km	Polyethelene	Max. 0.5 mm	Approx. 8.5 mm	HITACHI KPEV-S 1.25 mm ² × 1P Belden Inc. 9860
	0.5 mm ² (AWG20) or more	Max.33.4 Ω/km	Polyethelene	Max. 0.5 mm	Approx. 7.8 mm	HITACHI KPEV-S 0.5 mm ² × 1P Belden Inc. 9207
VCTF	0.75 mm ² (AWG18) or more	Max.25.1 Ω/km	PVC	Max. 0.6 mm	Approx. 6.6 mm	VCTF 0.75 mm ² × 2C (JIS)

Cable	Section
Twisted-pair with shield	
VCTF	

Notes

- 1) Use shielded type twist cables.
- 2) Use only one type of the transmission cables. Do not mix different types of the cables.
- 3) Use twist pair cables under a bad noise environment.

6-3-7 Low Voltage Directive

When using in the application confirming to EN61010-1/IEC61010-1, make sure to satisfy the following conditions.

- (1) Pulse output part secure only basic insulation. In order to secure reinforced (double) insulation demanded by EN 61010-1/ IEC61010-1, secure basic insulation or more with load side and reinforced (double) insulation with communication system side.
- (2) Provide the voltage input part with an EN60947-1 or EN60947-3 compliant circuit breaker. The breaker that connects to the voltage input part must arrange at the position easily reached, and display shows it is the breaker of the equipment.
- (3) Use a wire with basic insulation or more for a wire cramped (or connected) CT.

【Environmental conditions】

- Overvoltage category II, Pollution degree 2
- Indoor use
- An ambient temperature of -10 to 50°C
- An ambient non-condensing humidity of 35 to 85%RH (at 20°C)
- Altitude of 2000m or less


【Mount the product in a place with】

- A minimum of dust, and an absence of corrosive gases
- No flammable, explosive gasses
- Few mechanical vibrations or shocks
- No exposure to direct sunlight
- No large capacity electromagnetic switches or cables through which large current is flowing

Chapter 7 Communications

7-1 Communication Procedures

Communication starts with command transmission from the host computer (hereafter Master) and ends with the response of Eco-POWER METER (hereafter Slave).



7-2 Communication timing

◆ The minimum access time from the master is 1 sec. (Minimum time for update the data)
Eco-POWER METER may not response due to noise and so on, be sure to check that it receives the response from Eco-POWER METER.

◆ In order to improve the communication quality, we recommend to send the transmission again.

Communication timing of RS-485

◇Eco-POWER METER (Slave) side

When Eco-POWER METER (Slave) starts transmission to RS-485 communication line, it is arranged so as to provide an idle status transmission period of the below before sending the response to ensure the synchronization on the receiving side.

- | | |
|----------------|--|
| •MEWTOCOL type | about 3ms (transmission speed: 19200bps, 9600 bps) |
| | about 10ms (transmission speed: 4800bps, 2400bps) |
| •MODBUS type | about 5 to 99ms (setting available) |

And after sending the response, transmitter is cut within transmission period of about 20ms.

◇Master side (Cautions of setting a program)

At communication, keep the following conditions.


- 1) Set the program so that the master can disconnect the transmitter from the communication line within the transmission period of about 3ms after sending the command in preparation for reception of the response from Eco-POWER METER (Slave).
- 2) To avoid collision of transmissions between the master and Eco-POWER METER (Slave), send a next command after checking that the master received the response.

7-3 MEWTOCOL communication


7-3-1 Overview of MEWTOCOL-COM (RS-485)

◆ Command and response functions

The computer sends commands (instructions) to Eco-POWER METER, and receives responses in return. This enables the computer and Eco-POWER METER to converse with each other, so that various kinds of information can be obtained and provided.



◆ Command and response formats



◇ Control codes

Name	Character	ASCII code	Explanation
Header	%	25H	Indicates the beginning of a message.
Command	#	23H	Indicates that the data comprises a command message.
Normal response	\$	24H	Indicates that the data comprises a normal response message.
Error response	!	21H	Indicates that the data comprises a response message when an error occurs.
Terminator	CR	0DH	Indicates the end of a message.

◇ Destination and source AD (H), (L)

Two-digit decimal 01 to 99 (ASCII codes)

Command messages contain a station number for Eco-POWER METER that receives the message. When FF (ASCII code table) is used, however, the transmission is a global transmission (sent to all stations at once).

Note) When a global transmission is sent, no response to the command message is returned.

◇ Block check code Bcc (H), (L)

Two-digit hexadecimal 00 to FF (ASCII codes)

These are codes (horizontal parity) that are used to detect errors in the transmitted data.

If "***" is entered instead of "Bcc", however, messages can be transmitted without the Bcc. In this case, the Bcc is included with the response

◇ Error code Err (H), (L)


Two-digit hexadecimal 00 to FF (ASCII codes)

These indicate the contents if an error occurs.

◆ Bcc (Block Check Code)

-The Bcc is a code that carries out an error check using horizontal parity, to improve the reliability of the data being sent.

-The Bcc uses an exclusive OR from the header (%) to the final character of the text, and converts the 8-bit data into a 2-character ASCII code.



7-3-2 Data Register List

Data register	Name	Unit	Kind of data	Range	R/W
DT00050	Rate ¥ (JPY)	0.1¥	Sign-less 16bit	0 to 99.9	R/W
DT00051	Rate \$	0.001\$	Sign-less 16bit	0.000 to 9.999	R/W
DT00052	Rate € (EUR)	0.001€	Sign-less 16bit	0.000 to 9.999	R/W
DT00053	Rate yuan (CNY)	0.01 yuan	Sign-less 16bit	0.00 to 99.99	R/W
DT00100	Integrated electric power	0.01kWh	Sign-less 32bit	0 to 9999999.99	R/W
DT00101					
DT00107	L1(CT1)-phase current	0.1A	Sign-less 16bit	0.0 to 999.9	R
DT00109	L2(CT2)-phase current	0.1A	Sign-less 16bit	0.0 to 999.9	R
DT00060	CT type	Rated A (rms)	Sign-less 16bit	5 types: 5,50,100,250,400	R/W
DT00061	Unit for Pulse output	—	Sign-less 32bit	1(0.001),10(0.01),100(0.1),1000(1),10000(10),100000(100)999(Instantaneous electrical energy: Values of DT00064 and 00065 are applied)	R/W
DT00062					
DT00063	Primary side current value when CT 5A	A	Sign-less 16bit	1 to 999	R/W
DT00064	Alarm value (Instantaneous electric power)	0.01kW	Sign-less 32bit	0 to 9999.99	R/W
DT00065					
DT00066	VT ratio	0.01	Sign-less 16bit	1.00 to 99.99	R/W
DT00067	Threshold value current for time measurement	0.1%	Sign-less 16bit	1.0 to 100.0	R/W
DT00068	Cutoff current	0.1%	Sign-less 16bit	1.0 to 50.0	R/W
DT00150	Load ON-time	0.1h	Sign-less 32bit	0 to 99999.9	R/W
DT00151					
DT00152	Load OFF-time	0.1h	Sign-less 32bit	0 to 99999.9	R/W
DT00153					
DT00154	Pulse count value	—	Sign-less 32bit	0 to 999999	R/W
DT00155					
DT00158	Preset value	—	Sign-less 32bit	0 to 999999	R/W
DT00159					
DT00160	Pre-scale value	0.001	Sign-less 32bit	1 to 100000 (0.001 to 100.000) * Decimal point fixed	R/W
DT00161					
DT00162	Max.counting speed	Hz	Sign-less 16bit	30 or 2000	R/W
DT00163	Auto-off time	min	Sign-less 16bit	0 to 99 (0 means always light on)	R/W
DT00164	Display unit	—	Sign-less 16bit	0: CNT, 1: l, 2: kl, 3: m3	R/W
DT00170	Voltage between 1 and 2	0.1V	Sign-less 32bit	0 to 9999.9	R
DT00171					
DT00172	Voltage between 2 and 3	0.1V	Sign-less 32bit	0 to 9999.9	R
DT00173					
DT00176	Instantaneous electric power	0.01kW	Sign-less 32bit	0 to 9999.99	R
DT00177					

Note1) R: Read W: Write

2) Data register except specified is 0.

3) DT00061,00062 (Unit for pulse output) and DT00160,00161 (Pre-scale value) is numerical value (in the range of data register).

4) If each setting value is wrote by communication, it memories to internal EEP-ROM at the same time. Therefore, change setting frequently makes EEP-ROM's life short. Avoid to usage like this.

5) Write a data within the range when you write it.

7-3-3 Error Codes

◇Basic procedure errors

Error code	Error name	Explanation
40H	Bcc error	• A Bcc error occurred in the command data.
41H	Format error	• A command message was sent that does not fit the transmission format.
42H	No support error	• A command was sent that is not supported.
43H	Procedure error	• Delimiter with multiple frames was sent. • The response shall be multiple frames.

◇Application error

Error code	Error name	Explanation
60H	Parameter error	• The data code is not "D".
61H	Data error	• Word No. was specified without decimal. (0000F etc.) • The starting word No. is bigger than the ending word No. • Writing data has a code that is not hexadecimal.
62H	Registration error	• Too many registrations have been entered (more than 17). • "MD" command was sent when some registration has been exist. • "MG" command was sent when registration has not been entered.

◇Self-diagnostic error

Error code	Error name	Explanation
45H	Operation error	• At "WD" command, writing data is exceeded the range of data register.

7-3-4 Command

Eco-POWER METER has 5 kinds of commands.

Command name	Code	Explanation
Read data area	RD	Reads the contents of data area.
Write data to data area	WD	Writes data to a data area.
Resister or Reset data monitored	MD	Resisters the data to be monitored.
Monitoring start	MG	Monitors a registered data.
Read status	RT	Reads the specifications of Eco-POWER METER and error code if an error occurs.

◆[RD]: Read data area (Reads the contents of data area.)

◇Command

%	Destination	#	R	D	D	Starting word No. 5 characters	Ending word No. 5 characters	Bcc	CR
	$\times 10^1$ $\times 10^0$					$\times 10^4$ $\times 10^3$ $\times 10^2$ $\times 10^1$ $\times 10^0$	$\times 10^4$ $\times 10^3$ $\times 10^2$ $\times 10^1$ $\times 10^0$	$\times 16^1$ $\times 16^0$	

◇Normal response (Read successful)

%	Source	\$	R	D	First register contents 4 characters	Last register contents 4 characters	Bcc	CR
	$\times 10^1$ $\times 10^0$				$\times 16^1$ $\times 16^0$ $\times 16^3$ $\times 16^2$	$\times 16^1$ $\times 16^0$ $\times 16^3$ $\times 16^2$	$\times 16^1$ $\times 16^0$	
					(lower word) (higher word)	(lower word) (higher word)		

◇Error response

%	Source	!	Error code	Bcc	CR
	$\times 10^1$ $\times 10^0$		$\times 16^1$ $\times 16^0$	$\times 16^1$ $\times 16^0$	
					(Common to each command)

◆[WD]: Write data area (Writes data to a data area.)

◇Command




%	Destination	#	W	D	D	Starting word No. 5 characters	Ending word No. 5 characters	First writing data 4 characters	⇒
	$\times 10^1$ $\times 10^0$					$\times 10^4$ $\times 10^3$ $\times 10^2$ $\times 10^1$ $\times 10^0$	$\times 10^4$ $\times 10^3$ $\times 10^2$ $\times 10^1$ $\times 10^0$	$\times 16^1$ $\times 16^0$ $\times 16^3$ $\times 16^2$	
								(lower word) (higher word)	

◇Normal response (Write successful)


%	Source	\$	W	D	Bcc	CR
	$\times 10^1$ $\times 10^0$				$\times 16^1$ $\times 16^0$	

⇒	Last writing data 4 characters	Bcc	CR
	$\times 16^1$ $\times 16^0$ $\times 16^3$ $\times 16^2$	$\times 16^1$ $\times 16^0$	
	(lower word) (higher word)		


◆[MD]: Register or Reset data monitored (Registers the data to be monitored.) *Up to 16 points can be registered for one unit.



◆[MG]: Monitoring start (Monitors a registered data.)



◆[RT]: Read the status of Eco-POWER METER (Reads the specifications of Eco-POWER METER and error codes if an error occurs.)



7-5 MODBUS (RTU) Communication

7-5-1 Overview of MODBUS (RTU)

◆8-bit binary data in command is transmitted as it is.

Data format	Start bit	: 1 bit
	Data bit	: 8 bits ※7bits is not available.
	Parity	: No parity, Even parity, Odd parity Selectable
	Stop bit	: 1 bit (Fixed)
	Error detection	: CRC-16 (Cyclic Redundancy Check)
	Data interval	: 3.5 character transmission time or less

◆Message configuration

RTU mode is configured to start after idle time processing of more than 3.5 character transmissions and end after idle time processing of more than 3.5 character transmissions.

3.5 idle characters	Slave address	Function code	Data	Error check CRC-16	3.5 idle characters
	8-bit	8-bit	* * bits	16-bit	

Master judges the transmission complete after no command for 4-characters idle time and process the command.

*Transmission speed and judgment time to complete transmission

Transmission speed (bps)	Judgment time to complete (ms)
19200	about 2.00
9600	about 4.00
4800	about 8.00
2400	about 16.00

◇Slave address:

Slave address is an individual instrument number on the slave side and is set within the range 1 to 99 (01H to 63H). Master identifies slaves by the slave address of the requested message.

Slave informs master which slave is responding to master by placing its own address in the response message. Slave address 0 (00H, broadcast address) can identify all slaves connected. However slaves do not respond.

◇Function code: Function code is command code for the slave to undertake the following action types.

Function code	Contents
03(03H)	DT Read
06(06H)	DT1 word write
16(10H)	DT several data write

Function code is used to discern whether the response is normal (acknowledgement) or if any error (negative acknowledgement) has occurred when slave returns response message to master.

When acknowledgement is returned, slave simply returns original function code. When negative acknowledgement is returned, MSB of original function code is set as 1 for response.

For example, when the master sends request message setting 00H to function code by mistake, slave returns 80H by setting MSB to 1, because the former is an illegal function.

For negative acknowledgement, the exception codes below are set to data of response message and returned to master in order to inform it of what kind of error has occurred.

Exception code	Contents
1(01H)	Illegal Function (Non-existent function)
3(03H)	Illegal data value (Value out of the device numbers)

note1) Even if it commands to write (06H.10H) to non-existent data address, slave response with acknowledgement. However, it doesn't write.

note2) Even if it commands to write the value out of the setting range, slave response with acknowledgement. However, it doesn't write.

note3) The maximum number of reading slaves is 26 (57-bite), the maximum number of writing slaves is 23 (55-bite).

◇Data: Data depends on the function code.

A request message from the master side is composed of data item, number of data and setting data.

A response message from the slave side is composed of number of bytes, data and exception code in negative acknowledgement.

◇Error check: 16-bit data to detect communication errors. Refer to the next.

◇Acknowledgement response

When command is to write 1 point, same message of command is responded.

When command is to write several points, part of command message (6-bite) is responded.

◆Error check

After calculating CRC-16 (Cyclic Redundancy Check) from slave address to the end of data, the calculated 16-bit data is appended to the end of message in sequence from low order to high order.

<How to calculate CRC>

In CRC system, the information is divided by the polynomial series. The remainder is added to the end of the information and transmitted. The generation of polynomial series is as follows.

(Generation of polynomial series: $X^{16} + X^{15} + X^2 + 1$)

- ① Initialize the CRC-16 data (assumed as X) (FFFFH).
- ② Calculate exclusive OR (XOR) with the 1st data and X. This is assumed as X.
- ③ Shift X one bit to the right. This is assumed as X.
- ④ When a carry is generated as a result of the shift, XOR is calculated by X of ③ and the fixed value (A001H). This is assumed as X. If a carry is not generated, go to step ⑤.
- ⑤ Repeat steps ③ and ④ until shifting 8 times.
- ⑥ XOR is calculated with the next data and X. This is assumed as X.
- ⑦ Repeat steps ③ to ⑤.
- ⑧ Repeat steps ③ to ⑤ up to the last data.
- ⑨ Set X as CRC-16 to the end of message in sequence from low order to high order.

◆Message example

① Reading electricity rate (0032H) of address 1

•Command

3.5 idle characters	Slave address (01H)	Function code (03H)	Data item (0032H)	Number of data (0001H)	Error check CRC-16 (25C5H)	3.5 idle characters
	1	1	2	2	2	←character number

•Response message from slave in normal status (When Rate=1000(10.00) [03E8H])

3.5 idle characters	Slave address (01H)	Function code (03H)	Number of response byte (02H)	Number of data (03E8H)	Error check CRC-16 (B8FAH)	3.5 idle characters
	1	1	1	2	2	←character number

② Setting electricity rate (0032H) of address 1 (When rate is set to 20.00(2000) [07D0H])

•Command


3.5 idle characters	Slave address (01H)	Function code (06H)	Data item (0032H)	Number of data (07D0H)	Error check CRC-16 (2BA9H)	3.5 idle characters
	1	1	2	2	2	←character number

•Response message from slave in normal status


3.5 idle characters	Slave address (01H)	Function code (06H)	Data item (0032H)	Number of data (07D0H)	Error check CRC-16 (2BA9H)	3.5 idle characters
	1	1	2	2	2	←character number

- ③ Reset integrated electric power (0064H, 0065H:2-word) of address 1
(When setting to 0 [0000, 0000H])

• Command



• Response message from slave in normal status




• A response message from the slave in exception (error) status


(When number of data has been mistaken.)

Function code MSB is set to 1 for the response message in exception (error) status (90H).
The exception code 03H (Value out of the device numbers) is returned as contents of error.

<Mistaken message example (Command)>



<Response message from slave to mistaken command
(Response message in exception (error) status)>



7-4-2 Data Register List

MODBUS Function code	Data item (MEWTOCOL)	Name	Unit	Kind of date	Range: Hexadecimal (Range: Decimal)
03H/06H/10H	0032H (DT00050)	Rate ¥ (JPY)	0.01	Sign-less 16bit	0H~270FH (0~9999)
03H/06H/10H	0033H (DT00051)	Rate \$	0.001\$	Sign-less 16bit	0H~270FH (0~9999)
03H/06H/10H	0034H (DT00052)	Rate €(EUR)	0.001€	Sign-less 16bit	0H~270FH (0~9999)
03H/06H/10H	0035H (DT00053)	Rate yuan (CNY)	0.01CNY	Sign-less 16bit	0H~270FH (0~9999)
03H/06H/10H	0064H (DT00100) 0065H (DT00101)	Integrated active power	0.01kWh	Sign-less 32bit	0H~3B9AC9FFH (0~999999999)
03H	006BH (DT00107)	Current L1A (CT1)	0.1A	Sign-less 16bit	0H~270FH (0~9999)
03H	006CH (DT00108)	Current L2A (CT2)	0.1A	Sign-less 16bit	0H~270FH (0~9999)
03H/06H/10H	003CH (DT00060)	CT type	Rated A (rms)	Sign-less 16bit	5 types: 5H(5), 32H(50), 64H(100), FAH(250), 190H(400)
03H/06H/10H	003DH (DT00061) 003EH (DT00062)	Unit for Pulse output	—	Sign-less 32bit	1H(1)<0.001>, AH(10)<0.01>, 64H(100)<0.1>, 3E8H(1000)<1>, 2710H(10000)<10>, 186A0H(100000)<100>, 3E7H(999) <Instantaneous electric power: Values of 0040H, 0041H>
03H/06H/10H	003FH (DT00063)	Primary side current value when CT 5A	1A	Sign-less 16bit	1H~3E7H (1~999)
03H/06H/10H	0040H (DT00064) 0041H (DT00065)	Alarm value (Instantaneous active power)	0.01kW	Sign-less 32bit	0H~F423FH (1~9999999)
03H/06H/10H	0042H (DT00066)	VT ratio	0.01	Sign-less 16bit	64H~270FH (100~9999)
03H/06H/10H	0043H (CT00067)	Current threshold for time measurement	0.1%	Sign-less 16bit	AH~3E8H (10~1000)
03H/06H/10H	0044H (DT00068)	Cutoff current	0.1%	Sign-less 16bit	AH~1F4H (10~500)
03H/06H/10H	0096H (DT00150) 0097H (DT00151)	Load ON-time	0.1h	Sign-less 32bit	0H~F423FH (0~9999999)
03H/06H/10H	0098H (DT00152) 0099H (DT00153)	Load OFF-time	0.1h	Sign-less 32bit	0H~F423FH (0~9999999)
03H/06H/10H	009AH (DT00154) 009BH (DT00155)	Pulse count value	—	Sign-less 32bit	0H~F423FH (0~9999999)

03H/06H/10H	009EH (DT00158)	Preset value	—	Sign-less 32bit	0H~F423FH (0~999999)
	009FH (DT00159)				
03H/06H/10H	00A0H (DT00160)	Pre-scale value	0.001	Sign-less 32bit	1H~186A0H (1~100000) * Decimal point is fixed.
	00A1H (DT00161)				
03H/06H/10H	00A2H (DT00162)	Max. counting speed	Hz	Sign-less 16bit	1EH (30), 7D0H (2000)
03H/06H/10H	00A3H (DT00163)	Auto-off time	min	Sign-less 16bit	0H~63H (0~99)
03H/06H/10H	00A4H (DT00164)	Display unit	—	Sign-less 16bit	0H(0):CNT, 1H(1): l , 2H(2): kl , 3H(3): m3
03H	00AAH (DT00170)	Voltage L1V (Between 1 and 2)	0.1V	Sign-less 32bit	0H~1869FH (0~99999)
	00ABH (DT00171)				
03H	00ACH (DT00172)	Voltage L2V (Between 2 and 3)	0.1V	Sign-less 32bit	0H~1869FH (0~99999)
	00ADH (DT00173)				
03H	00B0H (DT00176)	Instantaneous power	0.01kW	Sign-less 32bit	0H~F423FH (0~999999)
	00B1H (DT00177)				

note 1) 03H: Read 06H/10H: Write

note 2) Data register except specified is "0".

note 3) If each setting value is wrote by communication, it memories to internal EEP-ROM at the same time. Therefore, change setting frequently makes EEP-ROM's life short. Avoid to usage like this.

note 4) Write a data within the range when you write it.

Chapter 8 Specifications

8-1 Main unit

Rated operating voltage	100-120/200-240V AC	
Rated frequency	50/60Hz common	
Rated power consumption	8VA	
Allowable operating voltage range	85-132/170-264V AC (85%~110% of rated operating voltage)	
Allowable momentary power-off time	10ms	
Ambient temperature	-10~+50°C (-25°C to +70°C at storage)	
Ambient humidity	30~85%RH (at 20°C non-condensing)	
Breakdown voltage (initial)	Between the isolated circuits: 2000V for 1min note) Cut-off current: 10mA However protective varistor excluded.	【Use as a Power meter】 • Insulated circuit (Between ①—②, ②—③, ①—③) ①Power terminal 1(R),2(N,S),3(T)), CT input terminal (CT1(+),CT2(+),CT1,2(-)) ②RS-485 terminal(+,-) ③Pulse output terminal(+,-) • Outer edge (case)—all terminals 【Use ad a Pulse counter】 • Insulated circuit (Between ①—②, ②—③, ①—③) ①Power terminal (1(R),2(N)), Pulse input terminal (CT1 (+), 0V) ②RS-485 terminal (+,-) ③Pulse output terminal (+,-) • Outer edge (case)—all terminals
Insulation resistance (initial)	Between the isolated circuits: 100MΩ or more (measured with 500V DC)	
Vibration resistance	10 to 55Hz (1cycle/min) single amplitude: 0.75mm(1h on 3 axes)	
Shock resistance	Min. 294m/s ² (5 times on 3 axes)	
Display method	6-digit, 7-segment LCD with backlight (Setting value) 4-digit, 16-segment (Mode) LCD Upper section: Green, Lower section: Amber	
Power failure memory method	EEP-ROM (more than 100,000 overwrite)	
Protection	IEC Standard IP66 (only front panel with rubber gasket) Note) Mounted in a row, waterproofing property will be lost.	
Weight	approx.130g (11-pin type), approx.140g (Screw terminal type)	

8-2 Input Specifications

8-2-1 Power Input

Measuring item	Power	Instantaneous electric power (kW)
		Integrated electrical energy (kWh, MWh)
	Voltage	Each phase Voltage (Between 1 and 2, 2 and 3) (V)
	Current	Each phase Current (L1(CT1)-phase current, L2(CT2)-phase current) (A)
	Electricity charge	Integrated electricity charge (JPY, \$,EUR,CNY)
	Power-on time	Hour Meter (Load ON-time, Load OFF-time) (hour)
Phase and wire system		Single-phase two-wire system Single-phase three-wire system Three-phase three-wire system
Input voltage	Rating	Single-phase two-wire : 100-120/200-240V AC (common) Single-phase three-wire : 100-120V AC Three-phase three-wire : 200-240V AC
	Allowance	85% to 110% of rated input voltage
	Allowable measurement voltage	Single-phase two-wire : 85-132/170-264V AC (common) Single-phase three-wire : 85-132V AC Three-phase three-wire : 170-264V AC
	VT ratio	1.00~99.99 (Set with setting mode) ※Voltage transformer (VT) is required when you measure a load with voltage over 200V system. ※Secondary current rating of commercial VT is 110V.
	Max. measured voltage	9999.9V
Input current	Primary side rating	<In case using dedicated CT> •5A/50A/100A/250A/400A (Select with setting mode) <In case using 5A CT with secondary rating 5A> •1~999.9A (Set with setting mode) (MEWTOCOL type) •1~4000A (Set with setting mode) (MODBUS type) ※Use a commercial CT with secondary side current of 5A when measuring 400A or more. ※Accuracy coverage: 10~100% of rated current of CT
		•1~999 (Set with setting mode) (MEWTOCOL type) •1~4000 (Set with setting mode) (MODBUS type) ※In case measuring CT of secondary rated current 5A.
	CT ratio	
	Max. measured current	• 999.9A (MEWTOCOL type) •6000.0A (MODBUS type)
Special functions	Cut-off current	1.0~50.0%F.S
	Hour meter threshold current	1.0~100.0%F.S
Allowable measured instantaneous electric power		0.00~9999.99kW
Allowable measured integrated electrical energy		•Display with 6-digit: 0.00kWh~9999.99MWh •Display with 9-digit: 0.00kWh~9999999.99kWh
Allowable measured time (Power ON/OFF time)		0.0~99999.9h
Allowable measured electricity charge		Yen (JPY) : 0~999999 Dollars (\$) : 0~9999.99 Euros (EUR) : 0~9999.99 Yuan (CNY) : 0~9999.99

Accuracy (without error in CT and VT)	Basic accuracy	Instantaneous electric power, Integrated electrical energy Voltage, Current, Electricity charge
		±2.5% F.S. ±1digit (at 20°C, rated input, rated frequency, power-factor 1) ※Accuracy coverage: 10~100% of rated current of CT
		Hour Meter
		±0.01% ±1digit (at 20°C) (In case power on start or current energizing, ±0.01%+1s±1 digit)
	Temperature characteristics	±1.5% F.S. /10°C ±1digit (Range of -10 to 50°C based on 20°C for rated input power-factor 1)
	Frequency characteristics	±1.5% F.S. ±1 digit (Frequency change ±5% based on rated frequency, for rated input power-factor 1)

8-2-2 Pulse input specifications

Input mode		Addition (Fixed)
Max. counting speed		2kHz /30Hz (Select with setting mode)
Pulse input		Min. input signal width: 0.25ms (When selected 2kHz) /16.7ms (When selected 30Hz) ON:OFF ratio = 1 : 1
Input signal		Contact / No contact (open collector) • Impedance when shorted: 1kΩ • Residual voltage when shorted: Max. 2V • Impedance when open: 100kΩ
Output mode		HOLD (Over count)
Number of Digit		6-digit (0 to 999999) (Selectable with setting mode)
Pre-scale setting	Decimal point	Set to 3rd decimal places (Auto-setting)
	Range	0.001~100.000 (Selectable with setting mode)
	Unit	「CNT」/「I」/「kI」/「m3」 (Selectable with setting mode) (Count value does not change even if the unit setting is changed during counting.)

8-3 Pulse output (Transistor output) Specifications

Number of output point		1 point
Insulation method		Optical coupler
Output type		Open collector
Output capacity		100mA 30V DC
Pulse width		approx. 10ms *
ON state voltage drop		1.5V or less
OFF state leakage current		100 μA or less
Pulse output unit	Power measurement	0.001/0.01/0.1/1/10/100kWh/Alarm (Selectable with setting mode)
	Pulse measurement	HOLD (Over count)

* We recommend the setting of minimum unit for pulse output for measurement shown as below.
Output pulse: 4 pulse or less per 1sec.

How to calculate

(Unit for pulse output: PL-P) > (Max. measurement power [kW]) / (3600[s] × 4 [pulse/s])

Caution (1) Improper unit setting may cause miss counting.
(2) If the OFF time is too short, there is a possibility of counting errors.

8-4 Communication Specifications

Interface		Conforming to RS-485	
Protocol		MEWTOCOL/MODBUS (RTU) (different model)	
Isolation status		Isolated with the internal circuit	
Number of connected units		99 (max.) ※ ¹ ※ ²	
Transmission distance		1200m	
Transmission speed		19200/9600/4800/2400bps (selectable with setting mode)	
Transmission Format	Data length	8bit/7bit (selectable with setting mode) 7bit (fixed)	(MEWTOCOL type) (MODBUS type)
	Parity	Not available/Odd number/Even number (selectable with setting mode)	
	Stop bit	1bit (fixed)	
Communication method		Half-duplex	
Synchronous system		Synchronous communication method	
Ending resistance		approx. 120 Ω (built-in) ※ ³	

◆Factory settings

Transmission speed (Baud rate)	Data length	Parity	Stop bit	Station no.
19200 bps	8 bit	Odd number	1 bit (fixed)	1

※1 For RS-485 converter on the computer side, we recommend SI-35 (from LINE EYE Co.,Ltd.).

※2 When using SI-35, SI-35USB or PLC from Matsushita Electric Works, Ltd. (which can be connected up to 99 units), up to 99 Eco-POWER METER can be connected.

In case using this system with the other devices, up to 31 Eco-POWER METER can be connected.

※3 Change the sliding switch of main unit as a terminal station. (Factory setting; General side)

8-5 Dedicated Current Transformer Specifications

Model No.		AKW4801	AKW4802	AKW4803	AKW4804
Primary side rated current		5A / 50A	100A	250A	400A
Rated secondary side current		1.67mA / 16.7mA	33.3mA	125mA	200mA
Winding (Turn)		3000	3000	2000	2000
Ratio error		± 1.0% F.S.			
Hole Dia (mm)		ϕ 10	ϕ 16	ϕ 24	ϕ 36
Breakdown voltage (initial)		AC1000V/1min (Between through hole and output lead wire)	AC2000V/1min (Between through hole and output lead wire)		
Insulation resistance (initial)		Min. 100MΩ (at DC500V) (Between through hole and output lead wire)			
Vibration resistance	Functional	10~55Hz (1 cycle/ minute) single amplitude of 0.375mm (1 hrs. on X, Y and Z axes)			
	Destructive	10~55Hz (1 cycle/ minute) single amplitude of 0.15mm (10 min. on X, Y and Z axes)			
Shock resistance	Functional	Min. 98m/s ² (4 times on X, Y and Z axes)			
	Destructive	Min. 294m/ s ² (5 times on X, Y and Z axes)			
Output protection level		± 7.5V with clamp element		± 3.0V with clamp element	
Permissible clamping frequency		Approx. 100 times			
Ambient temperature		-10 to +50°C (without frost and non-condensing)			
Storage temperature		-20 to +60°C (without frost and non-condensing)			
Ambient humidity		35~80%RH (at 20°C non-condensing)			
Weight		Approx. 50g (Trunk cable included)	Approx. 80g (Trunk cable included)	Approx. 200g (without trunk cable)	Approx. 300g (without trunk cable)

Note) Dedicated current transformers (CT), AKW4801, 4802, 4803, 4804, are dedicated for low voltage under 440V. They can not be used for high voltage circuit. In case measuring high voltage circuit, make a 2-step construction by combination of a commercial CT of secondary side current 5A for high voltage and the dedicated CT for 5A (AKW4801).

8-6 Self-diagnostic function

If an error occurs, the following indication will be given.

Indicator	Meaning	Output status	To recover
Err-00	CPU error	OFF	Turn the power off and then on again.
Err-01	Memory error*		EEP-ROM life ended. Replace the unit.


*Includes the possibility that the EEPROM's life has expired.

Chapter 9 Dimensions


9-1 Main unit

(Unit: mm)
(Clearance: ± 1.0)

◆ Screw terminal type (AKW5111)




◆ Pin type (AKW5211)




9-2 Dedicated CT

(Unit: mm)
(Clearance: ± 1.0)


◆ For 5A/50A(AKW4801)




◆ For 100A(AKW4802)




◆ Attached trunk cable: L=(1000)



◆ For 250A (AKW4803)



◆ For 400A (AKW4804)



Revision History

Issue Date	Manual no.	Content of revision
June, 2005	ARCT1F413E	First edition
October, 2007	ARCT1F413E-1	Second edition 6-3 Wiring: Add the explanation in detail.
March, 2008	ARCT1F413E-2	Third edition MODBUS type series addition • Model No. • MODBUS communication • MODBUS specifications

Please contact

Matsushita Electric Works, Ltd.

Automation Controls Business Unit

Head Office: 1048, Kadoma, Kadoma-shi, Osaka 571-8686, Japan

Telephone: +81-6-6908-1050

Facsimile: +81-6-6908-5781

<http://www.mew.co.jp/ac/e/>

All Rights Reserved © 2008 COPYRIGHT Matsushita Electric Works, Ltd.

Specifications are subject to change without notice.

Printed in Japan.