


C35- QUICK SETUP BREAKOUT BOARD

Rev. 1.1

User manual Rev. 1



1. Overview

This card provides an easy way of interfacing your inputs and outputs from the parallel port. It provides terminals and RJ45 for connections. It conditions the signals for use in CNC applications.

2. Features

- IEEE 1284 Standard compatible.** Includes the circuitry recommended by the IEEE 1284 Level 1 standards for bidirectional parallel communications between personal computers and peripherals.
- RJ45 connectors for all I/Os.** You only have to use standard networks cable to make all your connections.

- **Easy connections with CNC4PC relay boards and speed control boards.**
 - **Microcontroller based SCHKP.**

This board comes with a microcontroller that allows the implementation of a complex algorithm for sampling and analyzing the SCHKP signal.
 - **Easy way to connect up to 4 stepper motor drivers by using Networks cables. (Pins 2-9)**
 - **Buffered inputs and outputs.**

Outputs are buffered through the use of high speed and high current buffers allowing the card to output the signals without using the power from the parallel port. It can take the +3.3 or +5vdc signal from the parallel port and deliver solid +5vdc at 24 milliamps.
 - **Output pins 1, 2, 3, 4, 5, 6, 7, 8, 9, 14, 16, 17.**
 - **Input pins 10, 11, 12, 13, 15.**
 - **Input and output pins with close by ground or +5vdc connections**
 - **External Enable Pin (EN).** The board has a pin that allows you to enable/disable all the outputs at once. The board requires +5vdc in the EN pin. If it is not present, it will send all the outputs to ground. You can use this to enable or
- disable the system manually, or you can install an external Safety Charge Pump or other external safety monitoring device.
- **Works directly with popular CNC hardware and software.** Such as Geckodrive, Rutex, and parallel port control software, such as mach2, Linux EMC, TurboCNC, CNCPlayer, CNCZeus and others. (Not all tested).
 - **All TTL 5VDC signals.** Interface directly with parallel port interface products and other CNC4PC cards. 5VDC (TTL) cards are very common among automation devices.
 - **Screw-On connections for input signal terminals.**


3. Specifications.

DIGITAL INPUT SPECIFICATIONS	
On-state voltage range	2 to 5V DC
Maximum off-state voltage	0.8V
Maximum operation frequency	4 MHz
Typical signal delay	10nS

DIGITAL OUTPUT SPECIFICATIONS	
Maximum output voltage	(5V power supply voltage) + 0.5V
Typical output current	24mA
Maximum off-state voltage	0.44 V
Maximum operation frequency	4 MHz
Typical signal delay	10 nS
Time of transition to high impedance state	120 mS*

*Time passed since a low in the ENABLE input is detected and the outputs are disabled.

4. Board description



5. Especial Functions

5.1 Safety Charge Pump “SCHP”. (Pin 17)

This board takes advantage of Mach ability to send a specific frequency through one of the pins of the parallel port when the program is in control of the system. CNC machinery can be very dangerous, and you could have a risk of the machine doing something different that what you intend the machine to do if the program loses control of your system. Mach be can be programmed in a way, so when it is “in control”, it delivers a 12.5 KHz signal through one of the pins. This card lets you use this signal to work as an On/Off switch for your system, enabling a powerful

safety system for your equipment. If you ever had windows crash on you, then this card is for you. The port can also do weird things while the system is coming up, or down.

For Configuring the *Charge Pump* in *Mach X*: Use the dialog *Config / Ports and pins / Output Signals*. Enable the *Charge Pump* output and configures it as is shown in the Fig. 8 Next, press the *apply* button.





Fig. 1. Charge Pump configuration

Selecting the SCHP operation mode.

The Safety Charge Pump can be activated or deactivated depending on the jumper position.




Note: When the Safety Charge Pump is activated, the EN terminal is active and a valid SCHP signal is present, pin 17 will go high. This high signal can be used to enable other external devices, such as enabling other Breakout Boards, or relays that would enable servos, VFDs, contactors, etc....

5.2 Enable pin.

The card must be provided with a 5VDC signal to enable operation. This feature has been added to externally control the status of the outputs. When the enable signal is not present, output signals sent high impedance state. If this function is not required, an jumper can be placed between +5vdc and the EN terminal. It has an internal 4.7kOhm pull-down resistor.

Wiring:

The Parallel Port Interface Card has a very basic design that provides the flexibility you look for on CNC projects.



WARNING: This card must have the power supplied while it is connected to the PC. If power is removed to the card while it is connected to the PC, noise can be introduced to the output lines. This can create a dangerous situation as relays or other devices that might be connected to this card could get activated.

6. Requirements

It requires a 5VDC @ 500 milliamps power supply to operate. This power can be taken from the computer's power supply or USB port. Consider using the A3 – USB Power Cable found under Accessories in the website.



WARNING

Check the polarity and voltage of the external power source and connect the 5V and GND. Overvoltage or reverse-polarity power applied to these terminals can cause damage to the board, and/or the power source. Follow the steps bellow.

7. Functional Block Diagrams

7.1 Pins 2-9 simplified block diagram




Fig. 2 Simplified functional block diagram for pins 2-9.

7.2 Pins 1, 14, 16 and 17 simplified block diagram




Fig. 3 Simplified functional block diagram for outputs 1, 14, 17 and 16, .

Note: “Internal Enable” = “External Enable Pin” AND (“SCHP” OR “Bypassed SCHP”)

The “Internal Enable” is the result of an AND Operation between the “External Enable Pin” and the SCHP operation mode selected by the user.

Note: The outputs will be deactivated if the board is not connected to the PC parallel port.

7.3 Inputs simplified block diagram




Fig. 4 Simplified functional block diagram for inputs.

8. Pinout




Fig. 5 C35 Sample Product integration

The above image shows how can be easily integrated the C35 board with other CNC4P products. On each RJ45 connector you can connect only one external board.

PINS USED ON EACH RJ45 CONNECTOR.

	RJ45_1 Function	RJ45_2 Function	RJ45_3 Function	RJ45_4 Function	RJ45_5 Function	RJ45_6 Function	RJ45_7 Function	RJ45_8 Function
RJ45 PIN 1	5V	5V	5V	5V	NC	NC	NC	NC
RJ45 PIN 2	NC	NC	NC	NC	5V	5V	5V	5V
RJ45 PIN 3	P.P. Pin 3	P.P. Pin 5	P.P. Pin 7	P.P. Pin 9	NC	NC	NC	NC
RJ45 PIN 4	EN (5V)	EN (5V)	EN (5V)	EN (5V)	P.P. Pin 14	P.P. Pin 17	NC	P.P. Pin 15
RJ45 PIN 5	GND	GND	GND	GND	P.P. Pin 1	P.P. Pin 16	P.P. Pin 11	NC
RJ45 PIN 6	NC	NC	NC	NC	P.P. Pin 16	NC	P.P. Pin 12	NC
RJ45 PIN 7	P.P. Pin 2	P.P. Pin 4	P.P. Pin 6	P.P. Pin 8	P.P. Pin 17	NC	P.P. Pin 13	NC
RJ45 PIN 8	NC	NC	NC	NC	GND	GND	GND	GND

9. Wiring diagrams

While this board supports only TTL +5VDC signals, different kind of sensors, switches using different voltages can be connected using the diagrams that follow:

Note: The below wiring diagrams are an example, any input can be used for the connections.

9.1 Connecting Switches or push button.




Fig. 6 Wiring diagram to connect switches.

9.2 Connecting NPN sensors.




Fig. 7 Wiring diagram to connect NPN open collector proximity sensors.




Fig. 8 Wiring diagram to connect in parallel NPN open collector proximity sensors.

Connecting NPN open collector proximity sensor with the C35	
R1 Value (12V)	R1 Value (24V)
Aprox. 10K Ω	Aprox. 25K Ω





Fig. 9 Wiring diagram to connect NPN proximity sensors with internal pull up resistor.

Some NPN proximity sensor has a pull-up resistor (R1) internally. It is necessary to know its value in order to connect safely the sensor with the BOB. Follow this recommendation:

Connecting NPN open collector proximity sensor with the C35	
(R1+R2) Value (12V)	(R1+R2) Value (24V)
Aprox. 10KΩ	Aprox. 25KΩ

Calculating the R1 value.

Note: Rx is the unknown resistor value.



$$R_x = V_{EX} \cdot (R/V) - R \quad (1)$$

Where:

V_{EX} is the external power supply voltage

V is the voltage across the R resistor

An external resistor and a voltmeter are required to calculate the internal resistor (R_x) value.

Note. The user should know the R value to do this operation. A 4.7KOhm @ 1/2W is recommended.

SAMPLE: if you are using a 12V power supply (V_{EX}), and using a 4.7KOhm as external resistor (R), then the voltage across R should be 6V, using the equation 1, the R_x value is 4.7KOhm.

9.3 Connecting PNP sensors.




Fig. 10 Wiring diagram to connect PNP proximity sensors

Connecting PNP proximity sensor with the C35	
R Value (12V)	R Value (24V)
Aprox. 10K Ω	Aprox. 25K Ω

9.4 Other connection.

Other connections can be implemented by setting the inputs to pull-up resistor.




Fig. 11 Wiring diagram to do an “Auto Tool Zero”

10. Troubleshooting.

SYMPTOM 1: THE BOARD DOES NOT RELAY THE SIGNALS.

POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> - Pin conflict or mach3 configuration. It is possible that the port address used for the pin is not right, or that there is a pin conflict with the. That is that you are using that same pin twice. (it could be assigned to a different function). 	<ul style="list-style-type: none"> - Go to the device manager in windows, and check the memory address used for the parallel port you are using. Usually it will be 378 for LPT1. Check also that the port does not have a conflict. Then in mach3, go to Ports & Pins / Port Setup and Axis Selection. Check the memory address is correct. - Check that the pin you are using is not been used anywhere else in your setup. Got to motor output and output signals, and check all the entries.
<ul style="list-style-type: none"> - The board does not like the waveform it is getting. Some breakout boards could invert the signals or modify the pulse width. Changing the active low status of the pin used also inverts the waveform. 	<ul style="list-style-type: none"> - Play with the active low status of the pin used for the frequency.
<ul style="list-style-type: none"> - The signal or frequencies are not getting to the board. It could be the cable or that you are passing the signal through the same breakout board that you are enabling/disabling, so the outputs could be disabled, so they will not get to the breakout board. 	<ul style="list-style-type: none"> - Try a different cable. - Test the pins in the cable (before they reach the breakout board) with a multimeter.
<ul style="list-style-type: none"> - Problems with Mach3 Pulse Generation. Mach3 could have installation problems (you did not restart immediately after installation), or there could be something creating a conflict. Some dongle devices might cause this, other software, like QuickTime or drivers for touch screen. 	<ul style="list-style-type: none"> - Test this in a different PC. - Follow Art's suggestions for optimizing up WinXP: http://www.machsupport.com/downloads/XP_Optimization.txt.

SYMPTOM 2: THE OUTPUTS DO NOT GET ENABLED / NO SIGNALS ARE COMING OUT.

POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> - The EN terminal (Enable Outputs) is not enabled. The board requires to be externally enabled. - The parallel cable is not well connected to the PC parallel port. 	<ul style="list-style-type: none"> - Make sure you are providing +5vdc to the EN terminal. This +5vdc can be taken from the terminal next to it. - Check if the parallel port is well connected to the PC.

SYMPTOM 3: THERE IS NOISE IN THE SYSTEM, OR THE MOTORS DO NOT MOVE SMOOTHLY.


POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> - The board could be underpowered. 	<ul style="list-style-type: none"> - Make sure you are using a +5vdc 500mA power supply.
<ul style="list-style-type: none"> - There could be a short that could be draining the power to the board. 	<ul style="list-style-type: none"> - Check that there are no hot spots in the board or it's connections. - Measure the board's power consumption, it should be less than 400mA (depending on the features used). - Blown chips could create an internal short and end up drawing power that can affect how other chips work.
<ul style="list-style-type: none"> - There could be an external noise source that could be introducing noise into the system. 	<ul style="list-style-type: none"> - Try using shielded cables. - Try to isolate VFDs or AC servos, etc. - Try using 103. 0.1mF caps between the I/O terminal and a ground of the board.

SYMPTOM 5: A I/O PIN MIGHT NOT BE WORKING.

POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> - A chip may have gone bad. These buffers could act as fuses for the signals, and they can go bad because of noise spikes or even strong static. 	<ul style="list-style-type: none"> - These chips are inexpensive and readily available. You can order them here: http://www.cnc4pc.com/Store/osc/index.php?cPath=38_43. - Carefully moving chips around and

	checking if the problem moves around could be a way of figuring out if this is the case.
- There could be a problem with the parallel cable or parallel port.	- Test this with a different PC or parallel port.

11. Dimensions.



All dimensions are in Millimeters.

Disclaimer:

Use caution. CNC machines could be dangerous machines. DUNCAN USA, LLC or Arturo Duncan are not liable for any accidents resulting from the improper use of these devices. The C35 is not fail-safe device, and it should not be used in life support systems or in other devices where its failure or possible erratic operation could cause property damage, bodily injury or loss of life.