

KIT-VR5400-TP

User's Manual

RealTimeEvaluator

Revision History

Rev.0.8 Jul. 19,1999
Rev.0.81 Jul. 26, 1999
Rev.0.82 Aug. 11, 1999
Rev.1.00 Sep. 24, 1999

Preliminary 1st edition
Modified
Modification to description of pin mask
Official 1st edition
* Addition of parameter to env command
* Addition of cacheinit and cacheflush

CONTENTS

1. OVERVIEW.....	3
2. HARDWARE SPECIFICATIONS	4
Emulation.....	4
Host system and interface	4
3. RTE FOR WIN32.....	5
Starting ChkRTE32.exe	5
4. INITIALIZATION COMMANDS.....	6
env command.....	6
rom command.....	7
5. INTERFACE SPECIFICATIONS.....	8
Pin arrangement table	8
Connectors	8
Wire length.....	8
Layout of the connectors on the board	9
6. PRECAUTIONS	10
Precautions related to operation	10
Precautions related to functions.....	10

1. OVERVIEW

KIT-VR5400-TP is a product to use RTE-200-TP. It is an In-circuit emulator for NEC's RISC processor, VR5464 and VR5432 by using KIT-VR5400-TP and RTE-200-TP together.

Please read a User's Manual of RTE-200-TP together.

This product comes with the following components. First check that none of the components are missing.

- RTE for Win32 Setup Disk
- User's manual (This manual)
- License sheet

2. HARDWARE SPECIFICATIONS

Emulation

Target device	VR5464, VR5432
RTE-TP	RTE-200-TP
Emulation functions	
Operating frequency	Max: 66 MHz (Bus clock)
Interface	JTAG/N-Wire
Break functions	
Break using an execution address event (*2)	1
Break that can be set using an access event (*3)	1
S/W break points	100
Step breaks	Supported
Manual breaks	Supported
Trace functions (*4)	
Trace data bus	4 bits
Trace memory	4 bits x 128K words
Trigger that can be set using an execution address event (*2)	1
Trigger that can be set using an access event (*3)	1
Trace delay	0 - 1FFFFh
Trace clock	66 MHz (max.)
Disassembled trace data display function	Provided
ROM emulation functions	
Memory capacity	4 M-Byte
Access time	50 ns
Number of ROMs that can be emulated	
DIP-32pin-ROM (8-bit ROM)	4 (max.)
DIP-40/42pin-ROM (16-bit ROM)	2 (max.)
STD-16BIT-ROM connector	2 (max.)
Types of ROMs that can be emulated	
DIP-32-ROM probe(bits)	1M, 2M, 4M, 8M (27C010/020/040/080)
DIP-40-ROM probe(bits)	1M, 2M, 4M (27C1024/2048/4096)
DIP-42-ROM probe(bits)	8M, 16M (27C8000/16000)
Bus width specification (bits)	8/16/32
Target ROM capacity (bits)	512K, 1M, 2M, 4M, 8M, 16M(*1)
Pin mask functions	NMI, INT

*1 An 8-bit ROM probe supports ROMs of up to 8M bits.

*2 Break and execution address event for trigger are shared.

*3 Break and access event for trigger are shared.

*4 The execution speed drops during trace.

Host system and interface

Item	Description
Target host machine	PC 9800 Series and DOS/V PCs
Debugger	GHS-Multi, PARTNER/Win (Windows95/98/NT)
Interface	PC card Type II (version 2.1 of the PCMCIA specifications/version 4.2 of the JEIDA specification or later) PC 9800 (C bus), PC/AT (ISA bus and PCI bus), or LAN-BOX
Power supply	AC adapter (in: 100 V out: +5 V, 2A)

3. RTE FOR WIN32


This chapter describes the setting of RTE for WIN32, with the focus on the aspects specific to KIT-VR5400-TP.

Starting ChkRTE32.exe

Start ChkRTE32.exe after RTE-100-TP has been connected to the user system and the power to all the devices is on. When RTE-200-TP is installed for the first time, ChkRTE32.exe must be started once to select RTE.

<Selecting RTE>

Set the Setup dialog box of ChkRTE32.exe, as follows.



<Function test>

If RTE-200-TP is properly connected to the user system and capable of debugging, the following dialog box appears upon the normal completion of the function test. In this state, control from the debugger is possible.



If an error occurs during the test, the N-Wire cable is not properly connected. Check its connection.



Perform the ChkRTE32.exe function test after the RTE-200-TP has been connected to the user system and the power to all the devices has been turned on.

4. INITIALIZATION COMMANDS

Before debugging can be started, initialization is required. The following explains initialization using the appropriate internal commands. If the debugger offers a means of initialization, they may be used instead. (See Appendix A for an explanation of starting the internal commands and an explanation of the other internal commands.)

env command

[Format]

```
env [[!]auto] [[!]nmi] [[!]int] [jtag{25|12}] [[!]verify] [[!]hispeed]
    [work ADDR]
```

[Parameters]

- [[!]auto: If a break point is encountered during execution, the break point causes a temporary break. Choose [Auto] to automatically perform the subsequent execution. Choose [!auto] to suppress it.
- [[!]nmi: Specifies whether the NMI pin is to be masked. Enter ! if it is not to be masked.
- [[!]int: Specifies that pins INTxx are to be masked. Enter ! if they are not to be masked.
- jtag[12|25]: Specifies the JTAG clock (12.5 MHz|25 MHz) for N-Wire. Initial value of rte4win32 is 12.5 MHz (Ver. 4.37 or later) or 25 MHz (before Ver. 4.37).
- [[!]verify: Specifies the verification after writing memory is set. Enter ! if it is not to be set.

Remark The CPU also accesses an area that emulates ROM (jread or equivalent). Therefore, this command is useful for testing the area during downloading. Note, however, that the processing speed slows down.

[[!]hispeed]: Specifies high-speed mode to write data to memory. ! specifies the normal mode.

Remark The high-speed mode can be specified on condition that the ROM probe be connected. If this mode is specified, a control program temporarily located in the ROM emulated is executed in the foreground only when data of 128 bytes or more are contiguously written. Use this mode after the hardware has been completely debugged because the CPU must be able to access the ROM correctly. In normal mode, data can be written to ROM via JTAG.

[work ADDR]: Specifies an area for clearing the cache or executing initialization processing. Be sure to specify the RAM on uncache immediately after starting the system. The VR5400 requires RAM on the user system for cache processing. The monitor uses an area of 128 bytes from the specified address destructively.

Remark As this area is not used unless the cache area is accessed, confirm that the RAM can be accessed in the uncache area before accessing the cache area.

[Function]

The env command sets the emulation environment. Enter only those parameters that need to be changed. Parameters may be entered in any order. If the same parameter is entered twice, only the last entry is valid.

rom command

[Format]

rom [ADDR [LENGTH]] [512k|1m|2m|4m|8m|16m] [rom8|rom16] [bus8|bus16|bus32] [little|big]

[Parameters]

ADDR [LENGTH]:	Specifies an area to be emulated.
ADDR:	Specifies a start address. An error occurs if the specified start address does not match the lowest address of the ROM to be emulated (boundary of the ROM).
LENGTH:	Number of bytes of the ROM to be emulated. (Must be specified in boundary units of 4 bytes.)
512k 1m 2m 4m 8m 16m:	Specifies the bit size of the ROM to be emulated. Sizes from 512K bits to 16M bits can be specified. For the 27C1024, for example, specify 1M bits.
rom8 rom16:	Specifies the number of data bits of the ROM to be emulated. Either 8 bits or 16 bits can be specified. If a DIP-32-ROM probe is used, choose rom8; if a DIP-40/42-ROM probe is used, choose rom16.
bus8 bus16 bus32:	Specifies the ROM bus size in the system to be emulated. 8 bits, 16 bits, or 32 bits can be specified.
Little big:	Specifies the endian of the rom data. If little endian is specified during downloading, the binary image of a file is written as is. If big endian is specified, the data of the high-order bytes and low-order bytes are exchanged depending on the bus size of the ROM.

[Function]

The rom command sets the ROM emulation environment. Enter only the parameters that need to be changed. Parameters may be entered in any order. If the same parameter is entered twice, only the last entry is valid. The initial value of LENGTH is 0 (not used).

5. INTERFACE SPECIFICATIONS

This chapter describes the specifications of the connectors used for control that are required for the user system.

Pin arrangement table

Pin number	Signal name	Input/output (user side)	Treatment (user side)
A1	CLKOUT	Output	22 - 33 Ω series resistor (recommended)
A2	TRCDATA0	Output	22 - 33 Ω series resistor (recommended)
A3	TRCDATA1	Output	22 - 33 Ω series resistor (recommended)
A4	TRCDATA2	Output	22 - 33 Ω series resistor (recommended)
A5	TRCDATA3	Output	22 - 33 Ω series resistor (recommended)
A6	TRCEND	Output	22 - 33 Ω series resistor (recommended)
A7	DDI	Input	4.7 K - 10 k Ω pullup
A8	DCK	Input	4.7 K - 10 k Ω pullup
A9	DMS	Input	4.7 K - 10 k Ω pullup
A10	DDO	Output	22 - 33 Ω series resistor (recommended)
A11	DRST-	Input	Open or connected to ColdReset* via external circuit (outputs the reset signal of negative logic from TP).
A12	Rmode*/ BkTGIO*	Input/Output	4.7 k - 10 k Ω pullup
A13	NC.	-----	Open

Pin number	Signal name	Input/output (user side)	Treatment (user side)
B1-B10	GND	-----	Connection to the power GND
B11	NC.	-----	Open
B12	NC.	-----	Open
B13	+3.3V	-----	Connection to the power

Connectors

Manufacturer: KEL


Models: 8830E-026-170S (straight)
8830E-026-170L (right angle)
8831E-026-170L (right angle, fixing hardware attached)

Wire length

Keep the wire from the CPU to the connector as short as possible.
>>100 mm or shorter is recommended.

Layout of the connectors on the board

The figure below shows the physical layout of the connectors on the board.



Note When actually arranging the pins, design them according to the connector dimensional information.

6. PRECAUTIONS

This chapter provides precautionary information on the use of KIT-VR5400-TP.

Precautions related to operation

- 1) Do not turn on the power to the user system while the power to KIT-VR5400-TP is off. Doing so can cause a malfunction.
- 2) KIT-VR5400-TP externally controls the debugging control circuit built into the CPU. Consequently, KIT-VR5400-TP does not operate correctly unless the following conditions are satisfied:
 - * KIT-VR5400-TP is properly connected to the user system using the N-Wire cable.
 - * The power to the user system is on so that the CPU can run correctly.

Precautions related to functions

- 1) The disassembly and display of real-time trace data is performed by reading the contents of memory at the point the trace display command is issued, according to the branching information received from the CPU. Consequently, the disassembly and display of the program located in RAM of the user system is not correct if changes (including erroneous writing due to a CPU hang up) are made after program execution. Note that the following functional constraints must be observed.
 - a. Analysis and display cannot be made correctly if the branch information contains an error.