


# Telemetry Module

## MT-021

CE

User Manual



telemetria.pl

inVentia



# **Telemetry Module**

## **MT-021**

### **User Manual**

GSM/GPRS Telemetry Module  
for monitoring and control

Class 1 Telecommunications Terminal  
Equipment for GSM 850/900/1800/1900

**MT-021**

# **MT-021**

**© 2013 Inventia Ltd.**

Wszelkie prawa zastrzeżone. Żaden fragment niniejszego dokumentu nie może być powielany lub kopowany w żadnej formie bez względu na stosowaną technologię – graficzną, elektroniczną lub mechaniczną, włączając fotokopiowanie i/lub zapis cyfrowy, również w systemach przechowywania i wyszukiwania dokumentów – bez pisemnej zgody Wydawcy.

Nazwy produktów wymienionych w niniejszym dokumencie mogą być Znakami Towarowymi i/lub zastrzeżonymi Znakami Towarowymi należącymi do odpowiednich Właścicieli. Wydawca i Autor oświadczają, że nie roszczą do tych znaków towarowych żadnych praw.

Pomimo, że niniejsze opracowanie tworzone było z zachowaniem wszelkiej należytej staranności, zarówno Wydawca jak i Autor nie ponoszą żadnej odpowiedzialności za błędy lub pominięcia w jego treści jak również za straty wynikłe z wykorzystania zawartej w niniejszym opracowaniu informacji lub ewentualnie towarzyszącego jej oprogramowania. W żadnym wypadku Wydawca lub Autor nie będą odpowiedzialni za utratę zysku lub inne straty, w tym handlowe, spowodowane lub rzekomo związane, bezpośrednio lub pośrednio, z niniejszym opracowaniem.

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

**Publisher:**

INVENTIA Sp. z o.o.  
ul. Kulczyńskiego 14  
02-777 Warszawa  
Tel: +48 22 545-32-00  
[inventia@inventia.pl](mailto:inventia@inventia.pl)  
[www.inventia.pl](http://www.inventia.pl)

**Version:**

1.51  
Warsaw, Junuary 2013

**MTC Compatibility:**

1.51

## INDEX

<b>1. MODULE'S DESTINATION .....</b>	<b>7</b>
<b>2. GSM REQUIREMENTS .....</b>	<b>7</b>
<b>3. MODULE'S DESIGN .....</b>	<b>7</b>
3.1. MODULE'S TOPOGRAPHY.....	7
3.2. POWER SUPPLY.....	8
3.3. SIM CARD .....	9
3.4. LED DIODES.....	9
3.5. ANTENNA.....	10
3.6. HOUSING .....	10
3.7. RESOURCES.....	11
3.7.1. <i>Binary inputs</i> .....	11
3.7.2. <i>Relay outputs</i> .....	12
3.7.3. <i>Analog inputs</i> .....	12
3.7.4. <i>Real time clock (RTC)</i> .....	13
3.7.5. <i>USB port</i> .....	13
3.7.6. <i>Event logger</i> .....	14
3.7.7. <i>Timers</i> .....	14
3.7.8. <i>1-Wire inputs</i> .....	14
<b>4. STARTING THE MODULE .....</b>	<b>16</b>
4.1. CONFIGURING MT-021 USING MTMANAGER .....	17
4.2. REMOTE CONFIGURATION VIA SMS.....	21
4.3. HOW DO I DISABLE A SIM PIN NUMBER.....	22
<b>5. CONNECTIONS SCHEME.....</b>	<b>23</b>
5.1. POWER SUPPLY.....	23
5.2. BINARY INPUTS I1 ... I4.....	24
5.3. RELAY OUTPUTS Q1...Q4.....	25
5.4. ANALOG INPUTS AN1, AN2 .....	25
5.5. 1-WIRE INPUTS .....	27
<b>6. CONFIGURATION .....</b>	<b>28</b>
6.1. GENERAL INFORMATION.....	28
6.2. PARAMETER GROUPS .....	28
6.2.1. <i>Header</i> .....	29
6.2.1.1. Module name.....	29
6.2.1.2. Module type.....	29
6.2.1.3. Module serial number.....	29
6.2.1.4. IMEI number .....	29
6.2.1.5. SIM card number .....	29
6.2.1.6. Modem's firmware version.....	30
6.2.1.7. Firmware version .....	30
6.2.1.8. Configuration file version.....	30
6.2.1.9. Configuration identifier.....	30
6.2.1.10. Last configuration date .....	30
6.2.1.11. Last reading time .....	31
6.2.2. <i>General</i> .....	31
6.2.2.1. SIM card PIN number.....	31

6.2.2.2. Configuration password.....	31
6.2.2.3. Use of GPRS .....	32
6.2.3. <i>SMS</i> .....	32
6.2.3.1. Daily SMS limit .....	32
6.2.3.2. Roaming for SMS .....	32
6.2.3.3. Number of SMS sending retries .....	33
6.2.3.4. Answer for blank SMS.....	33
6.2.3.5. SMS limit exceed information text.....	33
6.2.3.5.1. Phone number of info recipient .....	33
6.2.3.5.2. SMS limit exceed information .....	34
6.2.3.6. Formats.....	34
6.2.3.6.1. Date format.....	34
6.2.3.6.2. Time format .....	34
6.2.3.6.3. General format 1.....	35
6.2.3.6.4. General format 2.....	35
6.2.3.7. Symbolic names .....	35
6.2.3.7.1. Number of symbolic names .....	35
6.2.3.7.2. Symbolic name.....	36
6.2.3.7.3. Space.....	36
6.2.3.7.4. Register/bit number.....	36
6.2.3.8. Macros .....	36
6.2.3.8.1. Number of macros .....	36
6.2.3.8.2. Macro name.....	37
6.2.3.8.3. Macro's content.....	37
6.2.4. <i>GPRS</i> .....	37
6.2.4.1. APN name .....	37
6.2.4.2. APN user name .....	37
6.2.4.3. APN password .....	37
6.2.4.4. Module IP.....	38
6.2.4.5. GPRS login retry interval [s] .....	38
6.2.4.6. GPRS testing address (ping) .....	38
6.2.4.7. Idle time [s] .....	38
6.2.5. <i>Authorized numbers</i> .....	39
6.2.5.1. Number of phone numbers .....	39
6.2.5.2. Update phone numbers from SIM card .....	39
6.2.5.3. Phone number from SIM card always authorized.....	39
6.2.5.4. Phone.....	40
6.2.6. <i>Resources</i> .....	40
6.2.6.1. Terminals .....	41
6.2.6.1.1. Inputs I1 ... I4.....	41
6.2.6.1.1.1. Name .....	41
6.2.6.1.1.2. Input type .....	41
6.2.6.1.1.2.1. Counter input .....	41
6.2.6.1.1.2.1.1. Counting direction .....	41
6.2.6.1.1.2.1.2. Counting range (32bits) .....	42
6.2.6.1.1.2.1.3. Triggering slope .....	42
6.2.6.1.1.3. Filtering constant [s].....	42
6.2.6.1.2. Outputs Q1 ... Q4 .....	42
6.2.6.1.2.1. Name .....	43
6.2.6.1.2.2. Output mode.....	43
6.2.6.1.2.3. Pulse duration [s] .....	43
6.2.6.1.2.4. On event.....	43
6.2.6.1.2.5. Off event .....	43
6.2.6.1.3. Analog inputs AN1...AN2.....	44
6.2.6.1.3.1. Name.....	44

6.2.6.1.3.2. Input type.....	44
6.2.6.1.3.3. Filtering constant [s].....	44
6.2.6.1.3.4. Signal range.....	44
6.2.6.1.3.5. Low reference - internal units .....	45
6.2.6.1.3.6. High reference - internal units .....	45
6.2.6.1.3.7. Low reference - engineering units .....	45
6.2.6.1.3.8. High reference - engineering units .....	45
6.2.6.1.3.9. Alarm HiHi - engineering units .....	46
6.2.6.1.3.10. Alarm Hi - engineering units.....	46
6.2.6.1.3.11. Alarm Lo - engineering units .....	46
6.2.6.1.3.12. Alarm LoLo - engineering units.....	46
6.2.6.1.3.13. Alarm hysteresis - engineering units .....	46
6.2.6.1.3.14. Deadband - engineering units .....	47
6.2.6.1.4. Inputs 1-WIRE1, 1-WIRE2.....	47
6.2.6.1.4.1. Name.....	47
6.2.6.1.4.2. Input type.....	47
6.2.6.1.4.2.1. Temperature measurement.....	47
6.2.6.1.4.2.1.1. Alarm HiHi.....	48
6.2.6.1.4.2.1.2. Alarm Hi.....	48
6.2.6.1.4.2.1.3. Alarm Lo.....	48
6.2.6.1.4.2.1.4. Alarm LoLo.....	48
6.2.6.1.4.2.1.5. Alarm hysteresis .....	48
6.2.6.1.4.2.1.6. Deadband .....	49
6.2.6.2. Synchronous timers TMR1...TMR4 .....	49
6.2.6.2.1. Active .....	49
6.2.6.2.1.1. Start [HH:MM].....	49
6.2.6.2.1.2. Period .....	49
6.2.6.2.1.3. Days of week .....	50
6.2.6.2.1.4. Days of month .....	50
7.2.6.3. State logging .....	50
6.2.6.3.1. Start [HH:MM] .....	50
6.2.6.3.2. Period .....	50
6.2.6.3.3. Logged information.....	51
6.2.7. Events .....	51
6.2.7.1. Number of events .....	51
6.2.7.2. Name .....	51
6.2.7.3. Trigger source (binary inputs) .....	51
6.2.7.3.1. Trigger input.....	52
6.2.7.3.2. Trigger condition .....	52
6.2.7.4. Trigger source (analog inputs) .....	52
6.2.7.4.1. Trigger input.....	53
6.2.7.4.2. Trigger condition .....	53
6.2.7.5. Trigger source (inputs 1-WIRE) .....	53
6.2.7.5.1. Trigger input.....	53
6.2.7.5.2. Trigger condition .....	54
6.2.7.6. Trigger source (Clocks).....	54
6.2.7.6.1. Triggering clock .....	54
6.2.7.7. Trigger source (Flags).....	55
6.2.7.7.1. Triggering flag .....	55
6.2.7.8. Trigger source (Counters) .....	55
6.2.7.8.1. Triggering counter.....	56
6.2.7.9. Trigger source (Connections) .....	56
6.2.7.9.1. Connection from any authorized .....	56
6.2.7.9.1.1. Dial-in from number.....	57
6.2.8. Rules .....	57

6.2.8.1. Message sending.....	57
6.2.8.1.1. Number of message sending rules.....	57
6.2.8.1.2. Sender e-mail address.....	57
6.2.8.1.3. SMTP server name .....	58
6.2.8.1.4. SMTP server port .....	58
6.2.8.1.5. SMTP authentication.....	58
6.2.8.1.6. SMTP user name .....	58
6.2.8.1.7. SMTP password.....	58
6.2.8.1.8. Message sending rules 1...32 .....	59
6.2.8.1.8.1. Triggering event .....	59
6.2.8.1.8.2. Transmission type .....	59
6.2.8.1.8.3. Recipient number.....	59
6.2.8.1.8.4. Receiver e-mail address .....	60
6.2.8.1.8.5. E-mail title .....	60
6.2.8.1.8.6. Message text .....	60
6.2.8.2. CLIP calls .....	60
6.2.8.2.1. Number of CLIP calls rules.....	61
6.2.8.2.2. CLIP call rules 1...16.....	61
6.2.8.2.2.1. Triggering event .....	61
6.2.8.2.2.2. Recipient number.....	61
6.2.8.3. E-mail sending.....	61
6.2.8.3.1. Number of e-mail sending rules.....	61
6.2.8.3.2. Sender e-mail address.....	62
6.2.8.3.3. SMTP server name .....	62
6.2.8.3.4. SMTP server port .....	62
6.2.8.3.5. SMTP authentication.....	62
6.2.8.3.6. SMTP user name .....	63
6.2.8.3.7. SMTP password.....	63
6.2.8.3.8. E-mail sending rules 1...16 .....	63
6.2.8.3.8.1. Triggering event .....	63
6.2.8.3.8.2. Receiver e-mail address .....	63
6.2.8.3.8.3. E-mail title .....	64
6.2.8.3.8.4. E-mail text .....	64
6.3. CONFIGURATION WRITING .....	64
6.4. VERIFICATION OF CONFIGURATION .....	64
<b>7. TECHNICAL DATA .....</b>	<b>65</b>
7.1. GENERAL.....	65
7.2. GSM MODEM .....	65
7.3. POWER SUPPLY.....	65
7.4. BINARY INPUTS I1....I4 .....	66
7.5. RELAY OUTPUTS Q1...Q4.....	66
7.6. ANALOGUE INPUTS AN1, AN2.....	66
7.7. DRAWINGS AND DIMENSIONS (ALL DIMENSIONS IN MILLIMETERS) .....	67
<b>8. PROBLEM SOLVING .....</b>	<b>68</b>
8.1. LED SIGNALING .....	68
8.2. UNBLOCKING OF SIM CARD .....	69
<b>9. SAFETY INFORMATION .....</b>	<b>69</b>
9.1. WORKING ENVIRONMENT.....	69
9.2. ELECTRONIC EQUIPMENT .....	69
9.2.1. <i>Heart pacemakers</i> .....	69

9.2.2. Hearing aids.....	69
9.2.3. Other medical equipment.....	69
9.2.4. RF Marked equipment.....	70
9.3. EXPLOSIVE ENVIRONMENT .....	70
<b>10. APPENDICES .....</b>	<b>70</b>
10.1. REGISTER OF CHANGES .....	70
10.2. MODULE CONFIGURATION VIA SMS .....	71
10.3. SYNTAX FOR READING AND WRITING DATA IN SMS MODE.....	79
10.4. MEMORY MAP .....	85
10.4.1. Analog inputs address space .....	86
10.4.2. Internal registers address space.....	90
10.5. FLAGS.....	91



## **1. Module's destination**

Telemetry Module **MT-021** with built-in GSM modem is a device dedicated for remote monitoring, diagnostics and control of objects via short text messages (SMS), CLIP calls or e-mail. Configurable messages send from device with static (text) or dynamic (text and measured values) content are a convenient way of passing important information to the monitoring center, or directly to the defined phone numbers. SMS messages sending can be triggered by change of binary input state, reaching alarm thresholds, marker state change, counters and clocks. Industrial design, practical set of I/O resources, easy to use software tools as well as the ability to configure the module from remote via SMS commands are significant advantages of MT-021 in the wireless telemetry systems. Direct connection of temperature sensors lowers the cost of building system. 1-Wire inputs can be used for reading typical Dallas pellets for the purpose of identification and authentication. The module can work with humidity sensors, water level sensor, pressure transducers, flow sensors, smoke, gas, motion, shock and noise detectors, etc.

Typical applications:

- Alarm systems
- Access control
- Preventive diagnostic
- Remote meter reading (AMR)
- Remote control of various devices by CLIP call or SMS (gates, pumps, heating, lighting, etc.)


## **2. GSM requirements**

For proper operation of the module a SIM card provided by a GSM operator with SMS/CLIP option enabled is essential. Enabled GPRS communication allows device to send e-mails.

A paramount condition for operation is securing the adequate GSM signal level in the place where module's antenna is placed. Using the module in places where there is no adequate signal level may cause breaks in transmission and thereby data loss along with generating excessive transmission costs.


## **3. Module's design**

### **3.1. Module's topography**



### 3.2. Power supply


MT-021 may be powered by 9...30 V (DC).



**NOTICE!**  
**Exceeding the range of accepted power supply voltage may cause  
faulty operation or damage to the module!**

### 3.3. SIM card

**MT-021** telemetry module is equipped with standard miniature SIM card holder for connecting card to GSM modem.



Proper placement of the SIM card is imperative for module's operation. The module accepts only SIM cards operating in low potential technology 3,3V.


### 3.4. LED diodes

LED indicators placed on **MT-021** front panel are convenient during module start up phase.

The LED's have assigned following significance:


- **PWR** LED indicates module's activity,
- **I1 ... I4** LED indicates state of binary inputs,
- **Q1 ... Q4** LED indicates state of binary outputs,
- **ERR** LED indicates an error,
- **GSM** LED reflects current login to GSM network state,
- **SGN** LED reflects GSM signal strength,
- **ACT (Tx i Rx)** LEDs indicate GSM communication (TX - data transmission, RX - data reception),
- **USB** LED indicates USB port state.

Detailed description can be found in [LED signaling subchapter of Problem solving chapter](#).



### 3.5. Antenna

Attachment of antenna is essential for proper operation of MT-101 telemetry module. SMA socket is placed on module's front panel. The attached antenna has to secure appropriate radio signal level enabling login to GSM network.



The type and placement of antenna has significant influence on module's sender/receiver circuits. GSM signal level is reflected by **SGN** led on module's front panel. Please use a directional antenna system when GSM signal level is not sufficient. Refer chapter [Problem solving/LED signaling](#).

### 3.6. Housing

MT-021 module is encapsulated in standard housing made of plastic compliant with safety requirements and protecting the module in standard operating environment. The applied solution complies with standard industrial requirements for DIN rail mounting.


### 3.7. Resources

**MT-021** module's resources:

I1...I4 - binary inputs	4	Optoisolated binary inputs
Q1...Q4 - Relay outputs	4	Relay outputs can operate in one of two functional modes: <ul style="list-style-type: none"><li>• monostable</li><li>• bistable</li></ul>
CNT - Counters	0 (max. 4)	Each input can work as a counter input
AN1, AN2 - Analog inputs	2	<ul style="list-style-type: none"><li>• PT100</li><li>• NTC</li><li>• 0..10V/0..5V</li><li>• 4-20mA</li></ul>
1-Wire - Inputs	2	Standard Dallas I-Button, Temperature measurement
USB Port	1	Standard RS232 - configuration

#### 3.7.1. Binary inputs

**MT-021** module is equipped with 4 optoisolated binary inputs marked as I1...I4. They may work only in positive logic. All binary inputs have same reference - module's electrical ground - negative pole of the power supply connected to GND pin.



The change of the input signal sets the alarm flag, connected with the corresponding binary input respectively as Bi 0->1, Bi 1->0 or Bi 0->1|Bi 1->0.

Any of binary inputs I1...I4 may operate as counter input. This requires a change in the operating mode of input, which is made during its [configuration](#). The counter can count „up” or „down”, and the range can be freely defined in range of 1 to 2 147 483 647. Counting “up” means that the counter value is increased by 1 for each detected pulse and after reaching the value set as “counter length-1” is reset to “0”. Counting “down” diminishes the counter value by 1 for each detected pulse and after reaching the value set as “counter length-1” is reset to “0” to resume the value of defined maximum. Crossing the value of counter length sets counter flag for respective input.

These flags may be used in [events table](#) to trigger rules.


### 3.7.2. Relay outputs

**MT-021** telemetry module has 4 relay outputs **Q1 ... Q4**. Outputs can operate in one of two functional modes:

- monostable
- bistable

The outputs operate independently and are isolated from each other.

Outputs are control by writing value to the internal register (No. 8 - OUT\_CTRL flag). This can be made remotely via SMS or CLIP.



### 3.7.3. Analog inputs


**MT-021** provides two analog inputs marked as **AN1, AN2** which can operate in following modes:

#### **AN1:**

- PT100 sensor temperature readout
- voltage input - 0...5V/0...10V
- current input - 4...20mA

### **AN1:**

- NTC sensor temperature readout
- voltage input - 0...5V/0...10V
- current input - 4...20mA



### 3.7.4. Real time clock (RTC)

**MT-021** Module is equipped with **astronomical time clock (RTC)**.

The clock is a base for defining working cycles of module, timers and time stamps for measurement results recorded in registers. Imprecise clock setting results in faulty time stamping and subsequent loss of vital information. For that reason, it is recommended to set the clock to UTC time instead of the local time zone of the module's placement.

#### **CAUTION!**


**The clock setting has to be repeated if the module was turned off for long time.**

Setting the time is described in configuring mode documentation for the MTManager program. There is also a method for setting the RTC remotely using SMS configuration commands described in chapter [Starting the module/Remote configuration via SMS](#).

### 3.7.5. USB port

**MT-021** module is equipped with one USB port.

This port is intended for the local configuration of the module's parameters and readout event logger. The port should be connected to an external PC computer with the configuration program running (MTManager) or software for reading event logger (MT Log Reader).



### 3.7.6. Event logger

**MT-021** automatically registers events like analog inputs measurement, time interval being counted by timer, GSM logon, making an outgoing call, one of analog values exceeding an alarm thresholds value, module power on and other. Logger can store up to 48000 records. This allows to reconstruct the history of module operations.

Logger records can be read via USB using MT Log Reader application.


### 3.7.7. Timers

MT-021 provides four synchronous timers TMR1...TMR4 that enable cyclical time measuring from 1 min to 1 month with synchronization with module z RTC clock. Timers can be used for triggering various actions like establishing clip calls, setting binary outputs and other.

### 3.7.8. 1-Wire inputs

Telemetry Module **MT-021** is equipped with two 1-Wire inputs for connection sensors using this interface for transmission of measured temperature value and Dallas I-button used for identification.

There is possibility of creating individual 1-Wire solutions to suit special application needs. For more information please contact your local distributor.



## 4. Starting the module

Starting **MT-021** module requires few basic activities.

There are two methods of configuring module:

- [locally - using MTManager](#)
- [remotely - via SMS](#)

Using one method does not exclude using of the second as the can be used interchangeably.


### **Starting MT-021**

1. Connect GSM antenna,
2. Install SIM card. If plan to make first configuration of module via SMS turn off PIN code request,

#### **Notice!**

**The details of the procedure unlock the SIM card is described in the chapter [How do I disable a SIM PIN number.](#)**

3. Connect power to module ('POWER' terminal block; 9...30 VDC).



Correct power connection is signaled by PWR LED (green light). After connecting power the module starts process of registration in the GSM network. If you use a SIM card with PIN code request option turned off, module should log on to the GSM network.

Successful GSM network logon is indicated by three blinks of GSM LED and signal strength presented on SGN LEDs.

In next steps you will see how to create basic configuration, which can be described by following points:

- Entering PIN code,
- Adding telephone number to authorized phone list,
- Defining event for binary input I1 when it is changing its state from 0 to 1 (rising edge),
- Defining SMS sending rule which will send SMS that reads "ALARM" to a predefined phone number when previously configured event is triggered,
- Setting RTC clock of the device.

#### 4.1. Configuring MT-021 using MTManager

Install MTManager on your PC from CD provided with module.




When installed with default setting MTManager creates shortcuts on Desktop and in Start menu.

Please proceed to next step.


Start MTManager by double-click on shortcut icon:



In newly created MTManager project add new module using main menu option **General->New->Module**.




Choose **MT-021** as type, type module name (e.g. ST\_1) in name field and select firmware version (firmware version is marked on the box).




In the next step set parameters essential for establishing GSM connection:


- [SIM card PIN number](#) (required if PIN code request is on)
- [Configuration password](#) to protect module from unauthorized access.




Open [Authorized numbers -> Phone](#) and add to the list new telephone number which will be receiving SMS messages from device (e.g. +48111222333).




Create [Event](#) EVT1 (in this example event will be triggered by binary input I1 when changing it will change logical state 0->1).




As last step of configuration please set [SMS sending](#) rule 1. Choose EVT1 as [Triggering event](#), type *ALARM* in [SMS text](#). NUM1 corresponds to telephone number added in previous step.




To write into module configuration prepared in previous steps connect MT-021 with PC using USB cable provided with module. Proper USB connection is signaled by USB LED. Operating system should automatically install driver for MT-021 - it will be seen in Device Manager as additional COM port called **Silicon Labs CP210x USB to UART Bridge (COMX)**, where X is COM port number.




Please open **Environment** in MTManager (General->Environment), set correct COM port in **USB cable** option and press **Write** to save setting.



Next press **Connect** button (Transmission->Connect) then **Write** button (Transmission->Write).



At the end synchronize device RT using **Set time** button (Configuration->Set time).



Now setting binary input in high logical state, e.g. by connecting V+ cable with terminal I1 and power GND with binary inputs GND, will result in sending SMS that reads 'ALARM' to +48111222333.

## 4.2. Remote configuration via SMS

Configuration described in chapter Configuring MT-021 using MTManager can be also written to module using SMS commands. Those commands, their default values and allowed value ranges are described in chapter [Appendices/Module configuration via SMS](#). Below you can find sample configuration SMS:

```
&#SPIN="2323"#CONF_PSW="PASS">#SMSN_1="+48111222333"#EVNO=1  
#EV_TRIG_1=2#EV_FLAG_1=0#EV_EDGE_1=1#TRNO=1#TR_TRIG_1=1  
#TR_TCH_1=1#TR_T_1="ALARM"#TR_N_1=1
```

That SMS sets:

- SIM card PIN number (2323)
- Configuration password (PASS)
- First telephone on Authorized->Phone list (+48111222333)
- Event EVT1 triggered when binary input I1 changes its logical state 0->1
- SMS sending rule 1 which will send SMS saying *ALARM* to previously defined telephone number each time event EVT1 is triggered.

As an answer to this SMS module will send back the same text preceding it with '>' sign. After first configuration it is good to adjust module RTC. SMS below sets time to last second of 2010:

```
&PASS#CRTC="2010-12-31 23:59:59"
```

SMS begins new password set by previous configuration SMS preceded by '&' sign.

First configuration can be done from any phone number. Any following SMS configuration commands will be accepted only from numbers placed on Authorized list. Therefore it is vital to enter at least one phone number to that list during first configuration. Maximum length of SMS configuration command should not exceed 160 signs.

Now setting binary input in high logical state, e.g. by connecting V+ cable with terminal I1 and power GND with binary inputs GND, will result in sending SMS that reads 'ALARM' to +48111222333.

#### 4.3. How do I disable a SIM PIN number

The procedure for setting the SIM mode to allow its use without requiring a PIN (e.g. Nokia, model 6210):


- Place the SIM card into the appropriate slot on the phone.
- Turn on the phone, and enter the correct PIN number for your SIM card.
- From the available commands, select **Menu\Settings\Security Settings**.
- Choose menu **PIN code request** then press Select, you will be prompted for a PIN number.
- Then select **OFF** response to a question **PIN code request**
- At the end appears a message **PIN code request is not active**.

## 5. Connections scheme

The chapter shows standard configurations securing proper operation of MT-021 module's integral inputs/outputs in all available operating modes.

### 5.1. Power supply

MT-021 module can be powered from **any DC power source** providing voltage within the range 9-30 VDC.




**Notice!**  
Exceeding the range of power supply may cause faulty operation or damage the module!

**Notice!**  
Supply cables length < 10m. Signal cables length < 30m.  
For longer cables it is recommended to use external overvoltage protection.

## 5.2. Binary inputs I1 ... I4

Internal optoisolated binary inputs marked as I1...I4 may work only in positive logic. All binary inputs have same reference - module's electrical ground - negative pole of the power supply connected to GND pin.

**Connection scheme:**



**Notice!**

Supply cables length < 10m.


Signal cables length < 30m.

For longer cables it is recommended to use external  
overvoltage protection.

### 5.3. Relay outputs Q1...Q4

Telemetry module has 4 normally open (NO) relay outputs marked as **Q1 ... Q4**. The outputs operate independently and are isolated from each other.

**Connection scheme:**




**Notice!**

**Maximum voltage between contacts is 230V AC**  
**Maximum switching current is 6A.**


### 5.4. Analog inputs AN1, AN2

Analog inputs **AN1** and **AN2** can be used for measuring temperature using Pt-100 and NTC sensors or collecting measurements via current (4-20mA) or voltage signal (0-5V/0-10V). Mode of operation is user-configurable. Below are shown proper connection schematics:


**Pt-100 - 2 wire (AN1 only)**




**Pt-100 - 3 wire (AN1 only)**




**NTC (AN2 only)**



**Voltage output sensor**




## Current output sensor



## 5.5. 1-Wire inputs

For the **1-Wire** communication is used one line for data and GND line. The **MT-021** has two 1-Wire bus inputs marked as 1 and 2 with a common reference point (GND).

**Connection scheme:**



## **6. Configuration**

### **6.1. General information**

The configuration of **MT-021** module, as is the case for other modules in the MT series, is carried out using the MTM (MT Manager) program portal, delivered free of charge to users of our telemetry solutions.

The portal is a specialized environment providing full control of the entire telemetry system regardless of the system's size. The possibility of dividing hardware resources into Projects and Folders facilitates efficient management of very complex telemetry systems.

After adding a new module to the environment and selecting it, all module parameters are available for editing. Detailed description of functions and their applications are to be found in MTM user manual.

Each of the configuration parameters is also possible to set by SMS. SMS schemes have been presented in [Chapter Appendices/Module configuration via SMS](#)

**NOTICE!**

**Availability of different functions and parameters depends on module's firmware version and the settings of parameters they may be dependent on.**

### **6.2. Parameter groups**

For clarity and ease of use, the operating parameters of **MT-021** module are divided into logically or functionally connected groups in the following order:

[Header](#) group - contains unmodifiable parameters describing the module, its firmware and configuration.

[General](#) group - contains basic parameters defining module's operating mode

[SMS](#) group - contains parameters for SMS services handling

[GPRS](#) group - contains parameters for GPRS logging

[Authorized numbers](#) group - contains lists of phone numbers of other terminals authorized for communication with configured module.

[Resources](#) group - defines parameters for hardware and software resources related to reading and processing measurement data.

[Events](#) group - contains list of defined events (e.g. binary input state change), used to trigger module's actions (e.g.: sending SMS or trigger CLIP)

[Rules](#) group - contains lists of transmission tasks to be carried out upon occurrence of activating criteria

## 6.2.1. Header

**Header** of parameter structure describes **MT-021** telemetry module. It holds basic information unique to the module, the configuration contained by module and configuration file version. Information displayed is not user editable and solely used for verification and information purpose.

### 6.2.1.1. Module name

<b>Function</b>	- displays name assigned to module during configuration
<b>Data type</b>	- text
<b>Range</b>	- n/a, read-only parameter
<b>Default value</b>	- <a href="#">New module</a>
<b>Comments</b>	- n/a

### 6.2.1.2. Module type

<b>Function</b>	- displays the type of configured telemetry module
<b>Data type</b>	- text
<b>Range</b>	- n/a, read-only parameter
<b>Default value</b>	- <a href="#">MT-021</a>
<b>Comments</b>	- n/a

### 6.2.1.3. Module serial number

<b>Function</b>	- displays serial number configured telemetry module
<b>Data type</b>	- text
<b>Range</b>	- n/a, Read-only parameter
<b>Default value</b>	- n/a
<b>Comments</b>	- this field displays module serial number assigned during manufacturing. This number is static and unique identifier of the unit.

### 6.2.1.4. IMEI number

<b>Function</b>	- displays GSM modem's IMEI number
<b>Data type</b>	- text
<b>Range</b>	- n/a, read-only parameter
<b>Comments</b>	- n/a

### 6.2.1.5. SIM card number

<b>Function</b>	- displays SIM card's serial number
<b>Data type</b>	- Number
<b>Range</b>	- n/a, read-only parameter
<b>Comments</b>	- n/a

#### 6.2.1.6. Modem's firmware version

<b>Function</b>	- displays GSM modem's firmware version
<b>Data type</b>	- text
<b>Range</b>	- n/a, read-only parameter
<b>Default value</b>	- n/a
<b>Comments</b>	- the field updates automatically after downloading the firmware.

#### 6.2.1.7. Firmware version

<b>Function</b>	- displays the identifier of current firmware version
<b>Data type</b>	- text
<b>Range</b>	- n/a, read-only parameter
<b>Default value</b>	- e.g. 1.00
<b>Comments</b>	- the field updates automatically after downloading the firmware.

#### 6.2.1.8. Configuration file version

<b>Function</b>	- displays version identification of configuration file used for actual configuration
<b>Data type</b>	- text
<b>Range</b>	- n/a, Read-only parameter
<b>Default value</b>	- e.g. 1.00 C
<b>Comments</b>	- value depends on module's firmware version chosen during creation of module definition. Auxiliary extension character defines the sub-version

#### 6.2.1.9. Configuration identifier

<b>Function</b>	- displays identification of current configuration
<b>Data type</b>	- hexadecimal
<b>Range</b>	- n/a, read-only parameter
<b>Comments</b>	- the value of this parameter increases automatically by 1 after each successfully stored configuration.

#### 6.2.1.10. Last configuration date

<b>Function</b>	- displays time and date of last successful configuration change
<b>Data type</b>	- text
<b>Range</b>	- n/a, read-only parameter
<b>Comments</b>	- the value changes automatically with successful configuration change. Useful in tracing unauthorized configuration changes.

#### 6.2.1.11. Last reading time

<b>Function</b>	- displays internal module time recorded during last configuration reading or during last time setting
<b>Data type</b>	- text
<b>Range</b>	- compliant with Date and Time format
<b>Comments</b>	- this field is useful in verifying last access time and checking internal module clock settings (RTC)

#### 6.2.2. General

**General** group encompasses parameters vital for whole module. Contains data necessary for successful login to GSM network and password-protection module configuration.  
Note: values set here have impact on module's behavior and in worst case, when chosen improperly may even lock the module.

##### 6.2.2.1. SIM card PIN number

<b>Function</b>	- defines PIN access code for SIM module delivered by GSM operator. For SIM modules not protected by PIN code, the value is insignificant.
<b>Data type</b>	- Number
<b>Range</b>	- numerals, from 4 to 8 characters
<b>Default value</b>	- empty
<b>Comments</b>	- wrong pin can cause locking of SIM module

#### **CAUTION!**

**Caution is vital when setting the PIN code value. Entering faulty PIN code may cause module start-up to be impossible and lock SIM card. In latest versions of the module, attempting to enter wrong PIN code twice renders a third attempt impossible.**

[Procedure in case of blocked module as the result of the wrong PIN value](#)

##### 6.2.2.2. Configuration password

<b>Function</b>	- defines the password protecting access to configuration of the module. The password will be required for both local and remote access, thus protecting against unauthorized configuration alterations. The password does not protect against reading current configuration or the module status.
<b>Data type</b>	- text string
<b>Range</b>	- letters and numerals, max. 32 characters
<b>Default value</b>	- n/a
<b>Comments</b>	- since the only way of unlocking the module is resetting it to factory settings, it is vital that the password is stored in a safe way and available when needed.

### 6.2.2.3. Use of GPRS

<b>Function</b>	- enables GPRS usage required for e-mail sending.
<b>Data type</b>	- Selection list
<b>Range</b>	- <i>No</i> GPRS is disabled. <i>Yes</i> GPRS is enabled.
<b>Default value</b>	- <i>No</i>
<b>Comments</b>	- When GPRS is enabled new group of parameters called GPRS is visible.

### 6.2.3. SMS

Group **SMS** contains parameters related to sending and receiving of text messages by **MT-021** module.

#### 6.2.3.1. Daily SMS limit

<b>Function</b>	- Defines max number of SMS, the module may send during one day. The parameter protects against uncontrolled sending of SMS messages and consequent high running expenses.
<b>Data type</b>	- Number
<b>Range</b>	- <i>1...65 535</i>
<b>Default value</b>	- <i>0 = unlimited</i>
<b>Comments</b>	- N/A

#### ATTENTION!

**Reaching set by the parameter limit results with unconditional stop of SMS sending. One has to bear in mind that until 00:00 o'clock no messages will be sent even in alarm situations!**

**Unsent due to limitation SMS messages are queued (the queue holds 16 messages) and will be sent when it is possible (after 00:00). If the number of queued messages is higher than the limit set by the user, there is a risk of immediate consuming of the next day limit.**

#### 6.2.3.2. Roaming for SMS

<b>Function</b>	- Decides whether the module may send SMS when roaming in foreign network.
<b>Data type</b>	- Selection list
<b>Range</b>	- <i>No</i> When roaming in foreign GSM network no SMS are sent.
<b>Answer</b>	The module can only respond to queries from authorized numbers

	<i>Yes</i>	All SMS messages are sent regardless of the GSM roaming
<b>Default value</b>	-	<i>Answer</i>
<b>Comments</b>	-	In order to be able to sent SMS in roaming the SIM card in the module has to have roaming option active.

#### 6.2.3.3. Number of SMS sending retries

<b>Function</b>	- Defines max number of retries of failed SMS transmission
<b>Data type</b>	- Number
<b>Range</b>	- <i>0...255</i>
<b>Default value</b>	- <i>10</i>
<b>Comments</b>	- After reaching the defined value the SMS is deleted from sending queue.

#### 6.2.3.4. Answer for blank SMS

<b>Function</b>	- defines the text of reply for empty SMS to the sender.
<b>Data type</b>	- Text
<b>Range</b>	- max. 160 characters
<b>Default value</b>	- <i>*MO</i>
<b>Comments</b>	- In replay message text symbolic names may be used following syntax rules defined in Appendices in the <a href="#">Syntax of read and write commands in SMS</a> chapter.

#### 6.2.3.5. SMS limit exceed information text

<b>Function</b>	- Decides whether the module may send alert that SMS limit was exceeded.
<b>Data type</b>	- Selection list
<b>Range</b>	- <i>On</i> module send SMS limit alert to defined <a href="#">phone number of info recipient</a> <i>Off</i> disabled sending SMS limit alert
<b>Default value</b>	- <i>Off</i>
<b>Comments</b>	- This information is sent beyond standard messages queue and only <b>once a day</b> . This message does not increment sent messages counter.

##### 6.2.3.5.1. Phone number of info recipient

<b>Function</b>	- Selects the SMS limit alert recipient
<b>Data type</b>	- Selection list
<b>Range</b>	- Authorized numbers list
<b>Default value</b>	- <i>NUM 1</i>

<b>Comments</b>	- The recipient must be previously defined in <a href="#">Authorized numbers -&gt; Phone</a> .
-----------------	--

#### 6.2.3.5.2. SMS limit exceed information

<b>Function</b>	- Contains the text of the SMS message sent upon reaching Daily SMS limit.
<b>Data type</b>	- Text
<b>Range</b>	- max 160 characters
<b>Default value</b>	- empty
<b>Comments</b>	- This information is sent beyond standard messages queue and only <b>once a day</b> . This message does not increment sent messages counter.

#### 6.2.3.6. Formats

Group **Formats** contains parameters allowing user to define formats of date and time presented in SMS messages.

##### 6.2.3.6.1. Date format

<b>Function</b>	- Defines date format used by <a href="#"><code>#date</code></a> predefined symbolic name and by <a href="#"><code>Id</code></a> and <a href="#"><code>ud</code></a> macro prefixes
<b>Data type</b>	- Text
<b>Range</b>	- 0...31 signs
<b>Default value</b>	- <a href="#"><code>YYYY-DD-MM</code></a>
<b>Comments</b>	- In the text user can put any sign combination but predefined with special meaning listed below: YYYY - if placed in this format text automatically changed for year in four digit notation (e.g. 2011), YY - if placed in this format text automatically changed for year in two digit notation (e.g. 11), MM - if placed in this format text automatically changed for month (e.g. 01 for January), DD - if placed in this format text automatically changed for day of month (e.g. 31).

Example:

Parameter is set to:

[\*Date of measurement: YYYY-MM-DD\*](#)

Macro result is (providing today is 31st of January 2011):

[\*Date of measurement: 2011-01-31\*](#)

##### 6.2.3.6.2. Time format

<b>Function</b>	- Defines date format used by <a href="#"><code>#time</code></a> predefined symbolic name and by <a href="#"><code>It</code></a> and <a href="#"><code>ut</code></a> macro prefixes
<b>Data type</b>	- Text
<b>Range</b>	- 0...31 signs
<b>Default value</b>	- <a href="#"><code>HH:MN:SS</code></a>
<b>Comments</b>	- In the text user can put any sign combination but predefined with special meaning listed below:

HH - if placed in this format text automatically changed  
for current hour in 24h format (e.g. 01),  
MN - if placed in this format text automatically changed  
for current minutes (e.g. 01),  
SS - if placed in this format text automatically changed  
for current seconds (e.g. 59).

Example:

Parameter is set to:

*Time of measurement: HH:MN:SS*

Macro result is (providing the time is 01:01:59):

*Time of measurement: 01:01:59*

#### 6.2.3.6.3. General format 1

<b>Function</b>	- Defines date format used by <a href="#">#RTC</a> predefined symbolic name and by <a href="#">T1</a> macro prefix
<b>Data type</b>	- Text
<b>Range</b>	- 0...31 signs
<b>Default value</b>	- <a href="#">YYYY/MM/DD, HH:MN:SS</a>
<b>Comments</b>	- In the text user can use symbols available for parameters <a href="#">Date format</a> i <a href="#">Time format</a> .

#### 6.2.3.6.4. General format 2

<b>Function</b>	- Defines date format used by <a href="#">T2</a> macro prefix
<b>Data type</b>	- Text
<b>Range</b>	- 0...31 signs
<b>Default value</b>	- <a href="#">YYYY/MM/DD, HH:MN:SS</a>
<b>Comments</b>	- In the text user can use symbols available for parameters <a href="#">Date format</a> i <a href="#">Time format</a> .

#### 6.2.3.7. Symbolic names

**Symbolic names** group contains names assigned by the user referring to the internal and input registers. There can be defined up to 16 symbolic names.

In order to use a symbolic name in SMS put it name preceded by '#' sign in SMS text send from mobile phone or defined in [Rules/SMS sending](#) or as a component of user-defined [macros](#). Using symbolic names makes composing SMS text much more convenient and user friendly.

##### 6.2.3.7.1. Number of symbolic names

<b>Function</b>	- declares number of user defined symbolic names.
<b>Data type</b>	- number
<b>Range</b>	- 1..16
<b>Default value</b>	- 1
<b>Comments</b>	- N/A

#### 6.2.3.7.2. Symbolic name

<b>Function</b>	- Defines user friendly name
<b>Data type</b>	- Text
<b>Range</b>	- 0..50 characters
<b>Default value</b>	- <i>IREG0...IREG15</i>
<b>Comments</b>	- N/A

#### 6.2.3.7.3. Space

<b>Function</b>	- Selection of register address space assigned to symbolic name.
<b>Data type</b>	- selection list
<b>Range</b>	- <i>HReg</i> Internal registers address space (registers readout) <i>IReg</i> Analog input address space (registers readout) <i>HB</i> Internal register address space (bits readout) <i>IB</i> Analog register address space (bits readout)
<b>Default value</b>	- <i>IReg</i>
<b>Comments</b>	- N/A

#### 6.2.3.7.4. Register/bit number

<b>Function</b>	- This parameter, together with the parameter <a href="#">Space</a> defines the register address or bit assigned to symbolic name.
<b>Data type</b>	- number
<b>Range</b>	- 0...65535
<b>Default value</b>	- 0...15
<b>Comments</b>	- N/A

#### 6.2.3.8. Macros

**Macros** group contains up to 16 use-defined macros. Macro may contain ASCII signs, [symbolic names](#), [SMS commands](#) and other macros that will be put in SMS text.

In order to use a symbolic name in SMS put it name preceded by '\*' sign in SMS text send from mobile phone or defined in [Rules/SMS sending](#) or other macro.

Using macros makes composing complex SMS texts and queries much more convenient and user friendly.

#### 6.2.3.8.1. Number of macros

<b>Function</b>	- declares number of user defined macros.
<b>Data type</b>	- number
<b>Range</b>	- 1..16

<b>Default value</b>	-	1
<b>Comments</b>	-	N/A

#### 6.2.3.8.2. Macro name

<b>Function</b>	-	Defines macro's user friendly name
<b>Data type</b>	-	Text
<b>Range</b>	-	0..20 characters
<b>Default value</b>	-	MO
<b>Comments</b>	-	N/A

#### 6.2.3.8.3. Macro's content

<b>Function</b>	-	The content that is inserted into the SMS message, instead of macro name.
<b>Data type</b>	-	text
<b>Range</b>	-	0..160 characters
<b>Default value</b>	-	#It.ir0 #Id.ir0
<b>Comments</b>	-	N/A

### 6.2.4. GPRS

GPRS group contains parameters related to GPRS transmission and logging.

#### 6.2.4.1. APN name

<b>Function</b>	- defines APN name selected for GPRS transmission
<b>Data type</b>	- text
<b>Range</b>	- letters, numerals, special characters - max. 63 characters
<b>Default value</b>	- empty
<b>Comments</b>	- absence of APN name disables login to GPRS network

#### 6.2.4.2. APN user name

<b>Function</b>	- defines APN user name
<b>Data type</b>	- text
<b>Range</b>	- letters, numerals, special characters - max. 31 characters
<b>Default value</b>	- empty
<b>Comments</b>	- Optional parameter used only if required by GSM network operator

#### 6.2.4.3. APN password

<b>Function</b>	- defines password for APN user account
<b>Data type</b>	- text
<b>Range</b>	- letters, numerals, special characters - max. 31 characters

<b>Default value</b>	- empty
<b>Comments</b>	- Optional parameter used only if required by GSM network operator

#### 6.2.4.4. Module IP

<b>Function</b>	- allows user to define IP number for newly created module definition and displays IP number read from the module configuration that was assigned to the module during last login to GPRS network
<b>Data type</b>	- IP number field
<b>Range</b>	- 0.0.0.0 - 255.255.255.255
<b>Default value</b>	- 0.0.0.0
<b>Comments</b>	- If after reading the configuration or setting device time this parameter value is different from 0.0.0.0, it means that module is logged into GPRS network with this particular IP address assigned to it.

#### 6.2.4.5. GPRS login retry interval [s]

<b>Function</b>	- Defines interval (in seconds) between retries of GPRS logon attempts after GPRS login failure.
<b>Data type</b>	- number
<b>Range</b>	- 10...3600 [s]
<b>Default value</b>	- 10 [s]
<b>Comments</b>	-

#### 6.2.4.6. GPRS testing address (ping)

<b>Function</b>	- sets IP address which is used to test GPRS network connection in case it is lost
<b>Data type</b>	- IP address field
<b>Range</b>	- 0.0.0.0 - 255.255.255.255
<b>Default value</b>	- 0.0.0.0
<b>Comments</b>	- This parameter sets recipient address for ping data frames testing GPRS transmission channel. Leaving recipient address at <a href="#">0.0.0.0</a> turns off GPRS testing functionality which is not advised.

#### 6.2.4.7. Idle time [s]

<b>Function</b>	- Defines interval (in seconds) for sending data frame (ping) testing GPRS network in case it is lost
<b>Data type</b>	- number
<b>Range</b>	- 0...21600 [s] (6h)
<b>Default value</b>	- 0 [s]
<b>Comments</b>	- in case of inactivity longer than the value defined in this parameter the module sends a control frame in order to check

whether transmission is still possible. The frame is sent to the address specified by parameter [GPRS testing IP address](#), if different than 0.0.0.0.

Lack of reply to sent ping frame after exercising defined timeout and number of retries is considered as GPRS connection loss and resets modem.

## 6.2.5. Authorized numbers

Group **Authorized numbers** comprises lists of phone numbers the module is going to communicate with.

### 6.2.5.1. Number of phone numbers

<b>Function</b>	- Defines the length of phone numbers list authorized to exchange SMS messages.
<b>Data type</b>	- Number
<b>Range</b>	- <a href="#">1...32</a>
<b>Default value</b>	- <a href="#">1</a>
<b>Comments</b>	- The value of this parameter may vary as the result of adding/deleting when using the context menu operating directly on <a href="#">Phone</a> number. The module will communicate only with units with the phone number present on the list. Read more in <a href="#">Syntax for reading and writing data in SMS mode</a> chapter of Appendices.

### 6.2.5.2. Update phone numbers from SIM card

<b>Function</b>	- Enables synchronization of <a href="#">Authorized numbers\Phone</a> list with phone book saved on Defines the length of phone numbers list authorized to exchange SMS messages.
<b>Data type</b>	- selection list
<b>Range</b>	- <a href="#">Yes</a> synchronization is on <a href="#">No</a> synchronization is off
<b>Default value</b>	- <a href="#">No</a>
<b>Comments</b>	- Synchronization is done after every reboot of the module, after inserting the SIM card or when configuration is written to the module. The module browses SIM card phone book and if it finds entries of the same name as defined in the <a href="#">Authorized numbers\Phone</a> it overrides the numbers from configuration with the numbers from the SIM card. Those numbers are remembered till module restart.

### 6.2.5.3. Phone number from SIM card always authorized

<b>Function</b>	- Enables receiving voice calls authorization for all phone numbers stored in SIM card phone book.
-----------------	--

<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <b>Yes</b> authorization is on</li> <li>- <b>No</b> authorization is off</li> </ul>
<b>Default value</b>	- <b>No</b>
<b>Comments</b>	<ul style="list-style-type: none"> <li>- If set to <b>Yes</b>, all mobile phones stored on SIM card are treated as if they were placed on <a href="#">Authorized numbers\Phone</a> list with tick next to <i>Receiving voice calls</i> option.</li> <li>The name assigned to him on the SIM card cannot be empty.</li> <li>Phone book entries with empty name won't be analysed.</li> </ul>

#### 6.2.5.4. Phone

<b>Ip.</b>	- Index number
<b>Name</b>	- Friendly name facilitating identification of the module while defining Rules. Max. length 16 characters
<b>Number</b>	- Phone number assigned to list index. Max. 14 characters
<b>Configuration</b>	<ul style="list-style-type: none"> <li>- Depending on configuration settings incoming configuration SMS will be processed or ignored.</li> </ul> <p><b>Default value:</b> ✓ (Allowed)</p>
<b>Query</b>	<ul style="list-style-type: none"> <li>- The module receives and analyzes SMS query messages depending on selected setting. When Query is not allowed, all SMS query messages from that phone number will be ignored</li> </ul> <p><b>Default value:</b> ✗ (not allowed)</p>
<b>Receiving voice calls</b>	<ul style="list-style-type: none"> <li>- The module receives calls and can use these signals for trigger event depending on selected setting. When Receiving is not allowed, all calls from that phone number will be ignored</li> </ul> <p><b>Default value:</b> ✗ (not allowed)</p>

Entries on phone list may be easily added and deleted by using context menu activated by right mouse button click on any position of the list in parameters window.

Idx.	Name	Number	Configuration	Query	Receiving voice calls
1	NUM 1	+48666000666	✓	✗	✗
2	NUM 2	+48777888999	✓	✗	✗
3	NUM 3	+48111222222	✗	✗	✗

- Del
- Ins
- Append

#### 6.2.6. Resources

Resources group contains user defined hardware configuration. Particular sub-groups contain fields allowing fast and intuitive preparation of the module to perform measurements and evaluations of external parameters (binary states, counters, temperature and air humidity) as well as internal (timers, flags).

### 6.2.6.1. Terminals

Sub-group **Terminals** gathers all inputs and outputs. Depending on type of accepted input, they are binary and analogue. Final functionality of each input depends on settings and configuration parameters connected.

#### 6.2.6.1.1. Inputs I1 ... I4

Module **MT-021** has four identical binary inputs. Inputs can operate in one of two functional modes:

- standard binary input
- counter input

Each mode has a set of specific configuration parameters.

##### 6.2.6.1.1.1. Name

<b>Function</b>	- Defines input's user friendly name
<b>Data type</b>	- Text
<b>Range</b>	- Letters and numerals, max. 16 characters
<b>Default value</b>	- Respective <i>I1, I2, I3, I4</i>
<b>Comments</b>	- Assigning friendly names facilitates discrimination of inputs destination and required settings.

##### 6.2.6.1.1.2. Input type

<b>Function</b>	- Defines binary input's operating mode.
<b>Data type</b>	- Selection list
<b>Range</b>	- <i>Binary input</i> Operates as binary input <i>Counter input</i> Operates as counter input
<b>Default value</b>	- <i>Binary input</i>
<b>Comments</b>	- According to selected mode MTManager displays additional configuration parameters for each input

##### 6.2.6.1.1.2.1. Counter input

###### 6.2.6.1.1.2.1.1. Counting direction

<b>Function</b>	- defines counting direction
<b>Data type</b>	- selection list
<b>Range</b>	- <i>Up</i> A pulse on input increases value of counter register <i>Down</i> A pulse on input decreases value of counter register
<b>Default value</b>	- <i>Up</i>
<b>Comments</b>	- N/A

#### 6.2.6.1.1.2.1.2. Counting range (32bits)

<b>Function</b>	- defines max. value assumed by the counter
<b>Data type</b>	- number
<b>Range</b>	- 0....2 147 483 647
<b>Default value</b>	- 0
<b>Comments</b>	- N/A

#### 6.2.6.1.1.2.1.3. Triggering slope

<b>Function</b>	- selects counting direction
<b>Data type</b>	- selection list
<b>Range</b>	- <i>Bi 0-&gt;1</i> The change of counter state occurs upon signal change from 0 > 1 <i>Bi 1-&gt;0</i> The change of counter state occurs upon signal change from 1 > 0 <i>Bi 0-&gt;1 / 1-&gt;0</i> The change of counter state occurs upon any change of signal
<b>Default value</b>	- <i>Bi 0-&gt;1</i>
<b>Comments</b>	- N/A

#### 6.2.6.1.1.3. Filtering constant [s]

<b>Function</b>	- Defines (in seconds) value of minimum duration of altered state on input in order to consider state to be stable.
<b>Data type</b>	- number
<b>Range</b>	- 0....163,83 [s]
<b>Default value</b>	- 0,10 [s]
<b>Comments</b>	- Setting value appropriate to contact characteristics eliminates disturbance caused by contact bounce thus preventing multiple registration of what is in reality one pulse.

#### 6.2.6.1.2. Outputs Q1 ... Q4

The **MT-021** module is equipped in four relay outputs Q1...Q4. Outputs can operate in one of two functional modes:

- monostable
- bistable

Each mode has a set of specific configuration parameters.

#### 6.2.6.1.2.1. Name

<b>Function</b>	- Defines output's user friendly name
<b>Data type</b>	- Text
<b>Range</b>	- Letters and numerals, max 16 characters
<b>Default value</b>	- Respectively ( <i>Q1...Q4</i> )
<b>Comments</b>	- Assigning friendly names facilitates discrimination of outputs destination and required settings.

#### 6.2.6.1.2.2. Output mode

<b>Function</b>	- selection of binary output mode
<b>Data type</b>	- selection list
<b>Range</b>	- <i>Monostable</i> binary output is set for time given by <a href="#">Pulse duration</a> parameter <i>Bistable</i> state of output is defined by user
<b>Default value</b>	- <i>Monostable</i>
<b>Comments</b>	- N/A

#### 6.2.6.1.2.3. Pulse duration [s]

<b>Function</b>	- defines length (in seconds) of impulse on binary output in monostable output mode
<b>Data type</b>	- number
<b>Range</b>	- <i>0.1 ... 214748364.7</i>
<b>Default value</b>	- <i>0.1</i>
<b>Comments</b>	- N/A

#### 6.2.6.1.2.4. On event

<b>Function</b>	- Allows selection of predefined event from the event list, which is to be used to turn on output.
<b>Data type</b>	- selection list
<b>Range</b>	- <i>None</i> or names of event from the <a href="#">Events table</a>
<b>Default value</b>	- <i>None</i>
<b>Comments</b>	- N/A

#### 6.2.6.1.2.5. Off event

<b>Function</b>	- Allows selection of predefined event from the event list, which is to be used to turn off output.
<b>Data type</b>	- selection list
<b>Range</b>	- <i>None</i> or names of event from the <a href="#">Events table</a>
<b>Default value</b>	- <i>None</i>
<b>Comments</b>	- Parameter is only available when <a href="#">Output mode</a> is set to <i>Bistable</i> .

#### 6.2.6.1.3. Analog inputs AN1...AN2

**MT-021** module is equipped with two analog inputs operating in 4...20mA or 0...5V/0...10V standard and direct measurement of the temperature sensor PT100 (AN1) or NTC (AN2).

Each mode has a set of specific configuration parameters.

##### 6.2.6.1.3.1. Name

<b>Function</b>	- Defines input's user friendly name
<b>Data type</b>	- Text
<b>Range</b>	- Letters and numerals, max. 16 characters
<b>Default value</b>	- Respectively ( <i>AN1</i> , <i>AN2</i> )
<b>Comments</b>	- Assigning friendly names facilitates discrimination of inputs destination and required settings.

##### 6.2.6.1.3.2. Input type

<b>Function</b>	- selection of analog input mode
<b>Data type</b>	- selection list
<b>Range</b>	- <i>Voltage input</i> signal measurement 0..10V or 0..5V depending on selected setting
	<i>Current input</i> signal measurement 4..20mA
	<i>Pt100</i> temperature measurement by PT100 sensor (available for AN1)
	<i>NTC</i> temperature measurement by NTC sensor (available for AN2)
<b>Default value</b>	- <i>Voltage input</i>
<b>Comments</b>	- N/A

##### 6.2.6.1.3.3. Filtering constant [s]

<b>Function</b>	- defines (in seconds) the value of the measurement averaging time of analog input
<b>Data type</b>	- selection list
<b>Range</b>	- 0, 0.05, 0.1, 0.25, 0.5, 1, 2, 4, 8
<b>Default value</b>	- 0
<b>Comments</b>	- N/A

##### 6.2.6.1.3.4. Signal range

<b>Function</b>	- selection of voltage analog input range
<b>Data type</b>	- selection list

<b>Range</b>	- 0...10V or 0...5V
<b>Default value</b>	- 0...10V
<b>Comments</b>	- N/A

#### 6.2.6.1.3.5. Low reference - internal units

<b>Function</b>	- used along with other reference parameters for rescaling input signal range to engineering units range
<b>Data type</b>	- number
<b>Range</b>	- 0...500 for voltage input ( <i>range 0...5V</i> ) 0...1 000 for voltage input ( <i>range 0...10V</i> ) 0...2 000 for current input
<b>Default value</b>	- 0 for voltage input 400 for current input
<b>Comments</b>	- low reference point for internal units

#### 6.2.6.1.3.6. High reference - internal units

<b>Function</b>	- used along with other reference parameters for rescaling input signal range to engineering units range
<b>Data type</b>	- number
<b>Range</b>	- 0...500 for voltage input ( <i>range 0...5V</i> ) 0...1 000 for voltage input ( <i>range 0...10V</i> ) 0...2 000 for current input
<b>Default value</b>	- 500 - for voltage input ( <i>range 0...5V</i> ) 1 000 - for voltage input ( <i>range 0...10V</i> ) 2 000 - for current input
<b>Comments</b>	- high reference point for internal units

#### 6.2.6.1.3.7. Low reference - engineering units

<b>Function</b>	- used along with other reference parameters for rescaling input signal range to engineering units range
<b>Data type</b>	- number
<b>Range</b>	- -32767...32767
<b>Default value</b>	- 0
<b>Comments</b>	- Low reference for engineering units

#### 6.2.6.1.3.8. High reference - engineering units

<b>Function</b>	- used along with other reference parameters for rescaling input signal range to engineering units range
<b>Data type</b>	- number
<b>Range</b>	- -32767...32767
<b>Default value</b>	- 1 000
<b>Comments</b>	- High reference for engineering units

#### 6.2.6.1.3.9. Alarm HiHi - engineering units

<b>Function</b>	- Defines <b>HiHi</b> alarm level for analog signal value in engineering units.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-32767...32767</a>
<b>Default value</b>	- <a href="#">32 767</a>
<b>Comments</b>	- Upon exceeding the preset value by analog signal the HiHi alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.3.10. Alarm Hi - engineering units

<b>Function</b>	- Defines <b>Hi</b> alarm level for analog signal value in engineering units.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-32767...32767</a>
<b>Default value</b>	- <a href="#">32 767</a>
<b>Comments</b>	- Upon exceeding the preset value by analog signal the Hi alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.3.11. Alarm Lo - engineering units

<b>Function</b>	- Defines <b>Lo</b> alarm level for analog signal value in engineering units.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-32767...32767</a>
<b>Default value</b>	- <a href="#">-32767</a>
<b>Comments</b>	- Upon exceeding the preset value by analog signal the Lo alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.3.12. Alarm LoLo - engineering units

<b>Function</b>	- Defines <b>LoLo</b> alarm level for analog signal value in engineering units.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-32767...32767</a>
<b>Default value</b>	- <a href="#">-32767</a>
<b>Comments</b>	- Upon exceeding the preset value by analog signal the LoLo alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.3.13. Alarm hysteresis - engineering units

<b>Function</b>	- Defines hysteresis value for analog signal thresholds. The value is set in engineering units.
-----------------	---

<b>Data type</b>	- number
<b>Range</b>	- <i>0...32767</i>
<b>Default value</b>	- <i>100</i>
<b>Comments</b>	- Setting hysteresis relevant for signal fluctuations prevents excessive activations of alarm flags.

#### 6.2.6.1.3.14. Deadband - engineering units

<b>Function</b>	- This parameter defines a minimal change of registered analog signal to react on.
<b>Data type</b>	- number
<b>Range</b>	- <i>0...32767</i>
<b>Default value</b>	- <i>100</i>
<b>Comments</b>	- When set to value <i>0</i> , the flag will rise upon every detected signal change by minimum 1 engineering unit. Deadband flags are dedicated to continuous monitoring of analog signal changes.

#### 6.2.6.1.4. Inputs 1-WIRE1, 1-WIRE2

**MT-021** module is equipped with two 1-WIRE inputs which allow connection of external transducers (e.g. temperature sensors).

##### 6.2.6.1.4.1. Name

<b>Function</b>	- Defines input's user friendly name
<b>Data type</b>	- Text
<b>Range</b>	- Letters and numerals, max. 16 characters
<b>Default value</b>	- Respectively ( <i>1-WIRE1</i> , <i>1-WIRE2</i> )
<b>Comments</b>	- Assigning friendly names facilitates discrimination of inputs destination and required settings.

##### 6.2.6.1.4.2. Input type

<b>Function</b>	- selection of 1-WIRE input mode
<b>Data type</b>	- selection list
<b>Range</b>	- <i>Temperature measurement</i> Temperature measurement by <b>DS18B20</b> sensor <i>Inactive</i> Input switched off
<b>Default value</b>	- <i>Inactive</i>
<b>Comments</b>	- N/A

###### 6.2.6.1.4.2.1. Temperature measurement

In this mode, the input module performs temperature reading from the DS18B20 sensor connected to a 1-Wire bus. Configuration parameters associated with that operation mode allows to set alarm thresholds, hysteresis and deadband.

#### 6.2.6.1.4.2.1.1. Alarm HiHi

<b>Function</b>	- Defines <b>HiHi</b> alarm level for 1-wire value.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-25...125</a>
<b>Default value</b>	- <a href="#">125</a>
<b>Comments</b>	- Upon exceeding the preset value by 1-wire signal the HiHi alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.4.2.1.2. Alarm Hi

<b>Function</b>	- Defines <b>Hi</b> alarm level for 1-wire signal value.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-25...125</a>
<b>Default value</b>	- <a href="#">125</a>
<b>Comments</b>	- Upon exceeding the preset value by 1-wire signal the Hi alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.4.2.1.3. Alarm Lo

<b>Function</b>	- Defines <b>Lo</b> alarm level for 1-wire signal value.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-25...125</a>
<b>Default value</b>	- <a href="#">-25</a>
<b>Comments</b>	- Upon exceeding the preset value by 1-wire signal the Lo alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.4.2.1.4. Alarm LoLo

<b>Function</b>	- Defines <b>LoLo</b> alarm level for 1-wire signal value.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">-25...125</a>
<b>Default value</b>	- <a href="#">-25</a>
<b>Comments</b>	- Upon exceeding the preset value by 1-wire signal the LoLo alarm flag is risen. The resetting level of the flag depends on <a href="#">Alarm hysteresis</a> setting.

#### 6.2.6.1.4.2.1.5. Alarm hysteresis

<b>Function</b>	- Defines hysteresis value for 1-wire signal thresholds.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">0...50</a>
<b>Default value</b>	- <a href="#">2</a>
<b>Comments</b>	- Setting hysteresis relevant for signal fluctuations prevents excessive activations of alarm flags.

#### 6.2.6.1.4.2.1.6. Deadband

<b>Function</b>	- This parameter defines a minimal change of registered 1-wire signal to react on.
<b>Data type</b>	- number
<b>Range</b>	- <i>0...50</i>
<b>Default value</b>	- <i>2</i>
<b>Comments</b>	- When set to value <i>0</i> , the flag will rise upon every detected signal change by minimum 1 unit. Deadband flags are dedicated to continuous monitoring of 1-wire signal changes.

#### 6.2.6.2. Synchronous timers TMR1...TMR4

Synchronous timers group contains parameters set for four timers capable of cooperating with module real time (RTC) clock thus enabling triggering of events synchronized with defined time.

##### 6.2.6.2.1. Active

<b>Function</b>	- selection timer activity
<b>Data type</b>	- selection list
<b>Range</b>	- <i>Yes</i> Inactive timer <i>No</i> Active timer
<b>Default value</b>	- <i>No</i>
<b>Comments</b>	- N/A

##### 6.2.6.2.1.1. Start [HH:MM]

<b>Function</b>	- Defines the synchronization point with RTC
<b>Data type</b>	- Time
<b>Range</b>	- <i>00:00 - 23:59</i>
<b>Default value</b>	- <i>00:00</i>
<b>Comments</b>	- At time defined by this parameter the module will always generate a pulse. One can make it generate pulse every hour, 15 minutes after the hour elapses (in that case the parameter <b>Start</b> should have value <i>00:15</i> )

##### 6.2.6.2.1.2. Period

<b>Function</b>	- Defines the interval module's clock should measure.
<b>Data type</b>	- selection list
<b>Range</b>	- <i>1 min., 2 min., 3min., 5 min., 10 min., 15 min., 30 min., 1 hour, 2 hours, 3 hours, 4 hours, 6 hours, 8 hours, 12 hours, 24 hours</i>
<b>Default value</b>	- <i>12 hours</i>
<b>Comments</b>	- N/A

#### 6.2.6.2.1.3. Days of week

<b>Function</b>	- defines days of week when the timer is active
<b>Data type</b>	- Multiple choice field
<b>Range</b>	- <i>Mo., Tu., We., Th., Fr., St., Sn.</i>
<b>Default value</b>	- <i>Mo., Tu., We., Th., Fr., St., Sn.</i> (all week days selected)
<b>Comments</b>	- The timer's activity is depending on logical sum of <a href="#">days of week</a> and <a href="#">days of month</a> . Selecting all week days will make the timer active all of the time. If no days of week are selected the activity of the timer will depend only on <a href="#">days of month</a> selection.

#### 6.2.6.2.1.4. Days of month

<b>Function</b>	- Selects days of month when the timer is active.
<b>Data type</b>	- Multiple choice field
<b>Range</b>	- <i>1, 2, ... 30, 31, Last</i>
<b>Default value</b>	- <i>No day selected</i> (none of month days is selected)
<b>Comments</b>	- The timer's activity is depending on logical sum of <a href="#">days of week</a> and <a href="#">days of month</a> . Selecting all month days will make the timer active all of the time. If no days of month are selected the activity of the timer will depend only on <a href="#">days of week</a> selection.

#### 6.2.6.3. State logging

Save status Subgroup contains parameters for defining messages (which may include the current states of inputs and outputs) periodically saved in the event logger of MT-021 module. This allows to periodically record measured values.

##### 6.2.6.3.1. Start [HH:MM]

<b>Function</b>	- Defines the synchronization point of period of logging device state to event logger with RTC clock
<b>Data type</b>	- time
<b>Range</b>	- 00:00 - 23:59
<b>Default value</b>	- 00:00
<b>Comments</b>	-

##### 6.2.6.3.2. Period

<b>Function</b>	- Defines interval of saving user-defined message in the event logger of MT-021 module
<b>Data type</b>	- selection list
<b>Range</b>	- <i>10 min., 20 min., 30 min., 45 min., 1 hour, 2 hours, 3 hours, 4 hours, 6 hours, 8 hours, 12 hours, 24 hours</i>
<b>Default value</b>	- <i>6 hours</i>
<b>Comments</b>	-

#### 6.2.6.3.3. Logged information

<b>Function</b>	- Defines text of message periodically put in event logger
<b>Data type</b>	- text
<b>Range</b>	- 0..160 characters
<b>Default value</b>	-
<b>Comments</b>	- text may contain any string of characters, except diacritical. It may contain mnemonics dynamically replaced at run-time by values drawn from the module e.g.: time, register or logical states of bits. The syntax of commands is described in detail in <a href="#">Syntax of commands for reading and writing data by SMS</a> paragraph.

#### 6.2.7. Events

Group **Events** defines status change of binary inputs (flags, inputs, outputs, bits) as events. Events are used to trigger recording events logger and sending SMS messages/CLIP calls or to control relay outputs.

##### 6.2.7.1. Number of events

<b>Function</b>	- Defines the number of events in events table.
<b>Data type</b>	- number
<b>Range</b>	- <i>0...32</i>
<b>Default value</b>	- <i>0</i>
<b>Comments</b>	- If the value is 0, events table is not displayed

##### 6.2.7.2. Name

<b>Function</b>	- Defines events user friendly name
<b>Data type</b>	- Text
<b>Range</b>	- Letters and numerals, max. 15 characters
<b>Default value</b>	- <b>EVT1...EVT32</b>
<b>Comments</b>	- Entering user-friendly names makes it much easier to distinguish events source and therefore choosing the correct event to trigger specific rule or action of module.

##### 6.2.7.3. Trigger source (binary inputs)

<b>Function</b>	- defines resource to trigger event
<b>Data type</b>	- selection list
<b>Range</b>	- <i>None</i> Inactive event <b>Binary inputs</b> Events associated with binary inputs I1 ... I4 <b>Analog inputs</b> Events associated with analog inputs AN1, AN2 <b>Inputs 1-WIRE</b> Events associated with 1-WIRE inputs

	<p><i>Clocks</i> Events associated with TMR1...TMR4 timer flags</p> <p><i>Flags</i> Events generated by the system/internal processor</p> <p><i>Counters</i> Events associated with counter's flags</p> <p><i>Connections</i> Events associated with incoming telephone calls</p>
<b>Default value</b>	- <b>None</b>
<b>Comments</b>	- N/A

#### 6.2.7.3.1. Trigger input

<b>Function</b>	- select flag of binary input which can trigger an event
<b>Data type</b>	- selection list
<b>Range</b>	- I1...I4
<b>Default value</b>	- I1
<b>Comments</b>	- N/A

#### 6.2.7.3.2. Trigger condition

<b>Function</b>	- Defines the flag associated with the selected binary input and used to trigger an event
<b>Data type</b>	- selection list
<b>Range</b>	- Bi 0->1, Bi 1->0, Bi 0->1 1->0
<b>Default value</b>	- Bi 0->1
<b>Comments</b>	- N/A

#### 6.2.7.4. Trigger source (analog inputs)

<b>Function</b>	- defines resource to trigger event
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <b>None</b> Inactive event</li> </ul>
	<b>Binary inputs</b> Events associated with binary inputs I1 ... I4
	<b>Analog inputs</b> Events associated with analog inputs AN1, AN2
	<b>Inputs 1-WIRE</b> Events associated with 1-WIRE inputs
	<i>Clocks</i> Events associated with TMR1...TMR4 timer flags
	<i>Flags</i> Events generated by the system/internal processor
	<i>Counters</i> Events associated with counter's flags
	<i>Connections</i> Events associated with incoming telephone calls

<b>Default value</b>	- None
<b>Comments</b>	- N/A

#### 6.2.7.4.1. Trigger input

<b>Function</b>	- select flag of analog input which can trigger event
<b>Data type</b>	- selection list
<b>Range</b>	- <a href="#">AN1, AN2</a>
<b>Default value</b>	- <a href="#">AN1</a>
<b>Comments</b>	- N/A

#### 6.2.7.4.2. Trigger condition

<b>Function</b>	- Defines the alarm flag associated with the selected analog input and used to trigger an event
<b>Data type</b>	- selection list
<b>Range</b>	- <a href="#">Alarm HiHi, Alarm Hi, Alarm Lo, Alarm LoLo</a>
<b>Default value</b>	- <a href="#">Alarm HiHi</a>
<b>Comments</b>	- N/A

#### 6.2.7.5. Trigger source (inputs 1-WIRE)

<b>Function</b>	- defines resource to trigger event
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <a href="#">None</a> <ul style="list-style-type: none"> <li>Inactive event</li> </ul> </li> <li><a href="#">Binary inputs</a> <ul style="list-style-type: none"> <li>Events associated with binary inputs I1 ... I4</li> </ul> </li> <li><a href="#">Analog inputs</a> <ul style="list-style-type: none"> <li>Events associated with analog inputs AN1, AN2</li> </ul> </li> <li><a href="#">Inputs 1-WIRE</a> <ul style="list-style-type: none"> <li>Events associated with 1-WIRE inputs</li> </ul> </li> <li><a href="#">Clocks</a> <ul style="list-style-type: none"> <li>Events associated with TMR1...TMR4 timer flags</li> </ul> </li> <li><a href="#">Flags</a> <ul style="list-style-type: none"> <li>Events generated by the system/internal processor</li> </ul> </li> <li><a href="#">Counters</a> <ul style="list-style-type: none"> <li>Events associated with counter's flags</li> </ul> </li> <li><a href="#">Connections</a> <ul style="list-style-type: none"> <li>Events associated with incoming telephone calls</li> </ul> </li> </ul>
<b>Default value</b>	- <a href="#">None</a>
<b>Comments</b>	- N/A

#### 6.2.7.5.1. Trigger input

<b>Function</b>	- select flag of 1-WIRE input which can trigger event
<b>Data type</b>	- selection list

<b>Range</b>	- 1-WIRE1...1-WIRE2
<b>Default value</b>	- 1-WIRE1
<b>Comments</b>	- N/A

#### 6.2.7.5.2. Trigger condition

<b>Function</b>	- Defines the alarm flag associated with the selected 1-WIRE input and used to trigger an event
<b>Data type</b>	- selection list
<b>Range</b>	- Alarm HiHi, Alarm Hi, Alarm Lo, Alarm LoLo
<b>Default value</b>	- Alarm HiHi
<b>Comments</b>	- N/A

#### 6.2.7.6. Trigger source (Clocks)

<b>Function</b>	- defines resource to trigger event
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <i>None</i> Inactive event</li> <li><i>Binary inputs</i> Events associated with binary inputs I1 ... I4</li> <li><i>Analog inputs</i> Events associated with analog inputs AN1, AN2</li> <li><i>Inputs 1-WIRE</i> Events associated with 1-WIRE inputs</li> <li><i>Clocks</i> Events associated with TMR1...TMR4 timer flags</li> <li><i>Flags</i> Events generated by the system/internal processor</li> <li><i>Counters</i> Events associated with counter's flags</li> <li><i>Connections</i> Events associated with incoming telephone calls</li> </ul>
<b>Default value</b>	- <i>None</i>
<b>Comments</b>	- N/A

#### 6.2.7.6.1. Triggering clock

<b>Function</b>	- Defines the flag associated with the selected Clock and used to trigger an event
<b>Data type</b>	- selection list
<b>Range</b>	- TMR1...TMR4
<b>Default value</b>	- TMR1
<b>Comments</b>	- N/A

#### 6.2.7.7. Trigger source (Flags)

<b>Function</b>	- defines resource to trigger event
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <i>None</i> Inactive event</li> <li><i>Binary inputs</i> Events associated with binary inputs I1 ... I4</li> <li><i>Analog inputs</i> Events associated with analog inputs AN1, AN2</li> <li><i>Inputs 1-WIRE</i> Events associated with 1-WIRE inputs</li> <li><i>Clocks</i> Events associated with TMR1...TMR4 timer flags</li> <li><i>Flags</i> Events generated by the system/internal processor</li> <li><i>Counters</i> Events associated with counter's flags</li> <li><i>Connections</i> Events associated with incoming telephone calls</li> </ul>
<b>Default value</b>	- <i>None</i>
<b>Comments</b>	- N/A

##### 6.2.7.7.1. Triggering flag

<b>Function</b>	- Defines the system flag and used to trigger an event
<b>Data type</b>	- selection list
<b>Range</b>	- <i>Module power on reset</i> - module restart
<b>Default value</b>	- <i>Module power on reset</i>
<b>Comments</b>	- N/A

#### 6.2.7.8. Trigger source (Counters)

<b>Function</b>	- defines resource to trigger event
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <i>None</i> Inactive event</li> <li><i>Binary inputs</i> Events associated with binary inputs I1 ... I4</li> <li><i>Analog inputs</i> Events associated with analog inputs AN1, AN2</li> <li><i>Inputs 1-WIRE</i> Events associated with 1-WIRE inputs</li> <li><i>Clocks</i> Events associated with TMR1...TMR4 timer flags</li> <li><i>Flags</i> Events generated by the system/internal processor</li> <li><i>Counters</i> Events associated with counter's flags</li> </ul>

	<i>Connections</i> Events associated with incoming telephone calls
<b>Default value</b>	- <b>None</b>
<b>Comments</b>	- N/A

#### 6.2.7.8.1. Triggering counter

<b>Function</b>	- Defines the flag associated with the <a href="#">configured counter input</a> and used to trigger an event
<b>Data type</b>	- selection list
<b>Range</b>	- <a href="#">I1...I4</a>
<b>Default value</b>	- <a href="#">I1</a>
<b>Comments</b>	- N/A

#### 6.2.7.9. Trigger source (Connections)

<b>Function</b>	- defines resource to trigger event
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <a href="#">None</a> Inactive event</li> <li><a href="#">Binary inputs</a> Events associated with binary inputs I1 ... I4</li> <li><a href="#">Analog inputs</a> Events associated with analog inputs AN1, AN2</li> <li><a href="#">Inputs 1-WIRE</a> Events associated with 1-WIRE inputs</li> <li><a href="#">Clocks</a> Events associated with TMR1...TMR4 timer flags</li> <li><a href="#">Flags</a> Events generated by the system/internal processor</li> <li><a href="#">Counters</a> Events associated with counter's flags</li> <li><a href="#">Connections</a> Events associated with incoming telephone calls</li> </ul>
<b>Default value</b>	- <a href="#">None</a>
<b>Comments</b>	- N/A

#### 6.2.7.9.1. Connection from any authorized

<b>Function</b>	- Determines whether the event it to be triggered by an incoming call from particular number or with a group of numbers from authorized number list.
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <a href="#">Yes</a> Event will trigger by any connection from <a href="#">authorized numbers</a> and selected permission for <a href="#">Receiving voice calls</a> parameter.</li> <li><a href="#">No</a> Event will trigger by connection from selected phone number defined <a href="#">Dial-in from number</a> parameter.</li> </ul>

<b>Default value</b>	- Yes
<b>Comments</b>	- N/A

#### 6.2.7.9.1.1. Dial-in from number

<b>Function</b>	- select phone number name from authorized list which can trigger event
<b>Data type</b>	- selection list
<b>Range</b>	- friendly names of recipients associated with phone numbers in <a href="#">Authorized number</a> list
<b>Default value</b>	- <b>NUM 1</b> - first number on the list
<b>Comments</b>	- N/A

### 6.2.8. Rules

Rules group contains lists of transmission tasks performed by internal program when criteria defined in rules are met. Tasks are divided into two groups:

- rules concerning transmission of SMS messages
- rules concerning transmission of CLIP calls
- rules concerning transmission of e-mail messages

In both cases, the criteria are defined by using same resources and conditions of application of the rule.

#### 6.2.8.1. Message sending

List of SMS sending rules can hold max. 32 entries defining short text message transmission conditions. Adding a new position is done in the context menu by right-clicking mouse while one of positions on the list is highlighted.

Adding more rules is done by setting the parameter [Number of SMS sending rules](#).

##### 6.2.8.1.1. Number of message sending rules

<b>Function</b>	- declares number of SMS or e-mail sending rules.
<b>Data type</b>	- number
<b>Range</b>	- <b>1..32</b>
<b>Default value</b>	- <b>1</b>
<b>Comments</b>	- diminishing the number of rules does not delete settings until the configuration is written to the module.

##### 6.2.8.1.2. Sender e-mail address

<b>Function</b>	- Allows to enter sender e-mail address, e.g. john.smith@company.com
<b>Data type</b>	- text
<b>Range</b>	- <b>0..31</b> characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.1.3. SMTP server name

<b>Function</b>	- Allows to enter name of SMTP server which will be used for e-mail sending, e.g. smtp.company.com
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.1.4. SMTP server port

<b>Function</b>	- declares port number which is used for communication with SMTP server
<b>Data type</b>	- number
<b>Range</b>	- 1..65535
<b>Default value</b>	- 25
<b>Comments</b>	-

#### 6.2.8.1.5. SMTP authentication

<b>Function</b>	- enables SMTP authentication if required by SMTP server.
<b>Data type</b>	- Selection list
<b>Range</b>	- <i>No</i> SMTP authentication is disabled. <i>Yes</i> SMTP authentication is enabled. In configuration two new parameters appear: <a href="#">SMTP user name</a> and <a href="#">SMTP password</a> which are used to authenticate module on SMTP server.
<b>Default value</b>	- <i>No</i>
<b>Comments</b>	-

#### 6.2.8.1.6. SMTP user name

<b>Function</b>	- Allows to enter user name which will be used during authentication process on SMTP server, e.g. john.smith
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.1.7. SMTP password

<b>Function</b>	- Allows to enter password which will be used during authentication process on SMTP server, e.g. j0h2ny\$mlth
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters

<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.1.8. Message sending rules 1...32

Each of rules residing on the list is defined by following parameters:

[Triggering event](#)  
[Transmission type](#)  
[Recipient number](#)  
[Receiver e-mail address](#)  
[E-mail title](#)  
[Message text](#)

##### 6.2.8.1.8.1. Triggering event

<b>Function</b>	- Assigns which one of previously defined event will trigger sending of a particular text message.
<b>Data type</b>	- selection list
<b>Range</b>	- <i>None</i> or names of events from the <a href="#">Events table</a>
<b>Default value</b>	- <i>None</i>
<b>Comments</b>	- N/A

##### 6.2.8.1.8.2. Transmission type

<b>Function</b>	- selection of method of textual message delivery
<b>Data type</b>	- selection list
<b>Range</b>	<ul style="list-style-type: none"> <li>- <b>SMS</b> message is delivered as SMS</li> <li>- <b>E-mail</b> message is delivered as e-mail</li> <li>- <b>E-mail or SMS</b> message is delivered as e-mail and if it is not possible (e.g. no GPRS available) - as SMS</li> </ul>
<b>Default value</b>	- <b>SMS</b>
<b>Comments</b>	- Value of which this parameter is set affects availability of other parameters within the same group.

##### 6.2.8.1.8.3. Recipient number

<b>Function</b>	- Assigns a recipient of SMS from list defined in <a href="#">Authorized numbers-&gt;Phone</a>
<b>Data type</b>	- selection list
<b>Range</b>	- friendly names of recipients associated with phone numbers in <a href="#">Authorized number</a> list
<b>Default value</b>	- <b>NUM 1</b> - first number on the list
<b>Comments</b>	- since recipient's phone number is selected from the list of friendly names, it is important to enter unique, unambiguous names facilitating identification.

#### 6.2.8.1.8.4. Receiver e-mail address

<b>Function</b>	- Allows to enter receiver e-mail address, e.g. jane.brown@other_company.com
<b>Data type</b>	- text
<b>Range</b>	- <a href="#">0..31</a> characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.1.8.5. E-mail title

<b>Function</b>	- Defines an e-mail title
<b>Data type</b>	- text
<b>Range</b>	- <a href="#">0..31</a> characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.1.8.6. Message text

<b>Function</b>	- Defines text which will be send as an e-mail or SMS message
<b>Data type</b>	- text
<b>Range</b>	- <a href="#">0..160</a> characters
<b>Default value</b>	-
<b>Comments</b>	- Messages text may contain any string of characters, except diacritical signs. It may contain mnemonics dynamically replaced at run-time by values drawn from the module e.g.: time, register values or logical state of bits. Syntax of commands is described in <a href="#">Syntax of commands for reading and writing data by SMS</a> paragraph.

#### 6.2.8.2. CLIP calls

The term „CLIP call” describes attempts to establish a phone connection to a defined number. This connection is not supposed to be picked up by the recipient. Identification of sending module's phone number is enough to convey the alert. The meaning of alert should be agreed upon. Notice that recipient does not have to be a GSM network subscriber but must have a phone able to identify and display caller ID. The function corresponds to sending 1 bit of information triggered by event occurrence free of charge. The list of rules holds max. 16 rules allowing to establish a connection with selected phone number. Adding a new position is done in the context menu by right-clicking mouse while one of positions on the list is highlighted.

Adding more rules is done by setting the parameter [Number of CLIP calls rules](#) to desired value.

#### 6.2.8.2.1. Number of CLIP calls rules

<b>Function</b>	- declares number of CLIP calls rules.
<b>Data type</b>	- number
<b>Range</b>	- <a href="#">1..16</a>
<b>Default value</b>	- <a href="#">1</a>
<b>Comments</b>	- diminishing the number of rules does not delete settings until the configuration is written to the module.

#### 6.2.8.2.2. CLIP call rules 1...16

Each of rules residing on the list is defined by following parameters:

[Triggering event](#)

[Recipient number](#)

##### 6.2.8.2.2.1. Triggering event

<b>Function</b>	- Assigns which one of previously defined event will trigger CLIP call rule.
<b>Data type</b>	- selection list
<b>Range</b>	- <a href="#">None</a> or names of events from the <a href="#">Events table</a>
<b>Default value</b>	- <a href="#">None</a>
<b>Comments</b>	- N/A

##### 6.2.8.2.2.2. Recipient number

<b>Function</b>	- Selects CLIP call recipient number
<b>Data type</b>	- selection list
<b>Range</b>	- friendly names of recipients associated with phone numbers in <a href="#">Authorized number</a> list
<b>Default value</b>	- <a href="#">NUM 1</a> - first number on the list
<b>Comments</b>	- since recipient's phone number is selected from the list of friendly names, it is important to enter unique, unambiguous names facilitating identification.

#### 6.2.8.3. E-mail sending

List of e-mail sending rules can hold max. 16 entries defining e-mail message transmission conditions. Adding a new position is done in the context menu by right-clicking mouse while one of positions on the list is highlighted.

Adding more rules is done by setting the parameter [Number of e-mail sending rules](#).

##### 6.2.8.3.1. Number of e-mail sending rules

<b>Function</b>	- declares number of e-mail sending rules.
<b>Data type</b>	- number
<b>Range</b>	- 1..16

<b>Default value</b>	- 1
<b>Comments</b>	- diminishing the number of rules does not delete settings until the configuration is written to the module.

#### **6.2.8.3.2. Sender e-mail address**

<b>Function</b>	- Allows to enter sender e-mail address, e.g. john.smith@company.com
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.3.3. SMTP server name

<b>Function</b>	- Allows to enter name of SMTP server which will be used for e-mail sending, e.g. smtp.company.com
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.3.4. SMTP server port

<b>Function</b>	- declares port number which is used for communication with SMTP server
<b>Data type</b>	- number
<b>Range</b>	- 1..65535
<b>Default value</b>	- 25
<b>Comments</b>	-

#### 6.2.8.3.5. SMTP authentication

<b>Function</b>	- enables SMTP authentication if required by SMTP server.				
<b>Data type</b>	- Selection list				
<b>Range</b>	<table><tr><td>- <i>No</i></td><td>SMTP authentication is disabled.</td></tr><tr><td>Yes</td><td>SMTP authentication is enabled. In configuration two new parameters appear: <u>SMTP user name</u> and <u>SMTP password</u> which are used to authenticate module on SMTP server.</td></tr></table>	- <i>No</i>	SMTP authentication is disabled.	Yes	SMTP authentication is enabled. In configuration two new parameters appear: <u>SMTP user name</u> and <u>SMTP password</u> which are used to authenticate module on SMTP server.
- <i>No</i>	SMTP authentication is disabled.				
Yes	SMTP authentication is enabled. In configuration two new parameters appear: <u>SMTP user name</u> and <u>SMTP password</u> which are used to authenticate module on SMTP server.				
<b>Default value</b>	- <i>No</i>				
<b>Comments</b>	-				

#### 6.2.8.3.6. SMTP user name

<b>Function</b>	- Allows to enter user name which will be used during authentication process on SMTP server, e.g. john.smith
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.3.7. SMTP password

<b>Function</b>	- Allows to enter password which will be used during authentication process on SMTP server, e.g. jOh2ny\$m1th
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.3.8. E-mail sending rules 1...16

Each of rules residing on the list is defined by following parameters:

Triggering event  
Receiver e-mail address  
E-mail title  
E-mail text

##### 6.2.8.3.8.1. Triggering event

<b>Function</b>	- Assigns which one of previously defined event will trigger sending of a particular text message.
<b>Data type</b>	- selection list
<b>Range</b>	- <i>None</i> or names of events from the <u>Events table</u>
<b>Default value</b>	- <i>None</i>
<b>Comments</b>	- N/A

##### 6.2.8.3.8.2. Receiver e-mail address

<b>Function</b>	- Allows to enter receiver e-mail address, e.g. jane.brown@other_company.com
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.3.8.3. E-mail title

<b>Function</b>	- Defines an e-mail title
<b>Data type</b>	- text
<b>Range</b>	- 0..31 characters
<b>Default value</b>	-
<b>Comments</b>	-

#### 6.2.8.3.8.4. E-mail text

<b>Function</b>	- Defines text of an message
<b>Data type</b>	- text
<b>Range</b>	- 0..160 characters
<b>Default value</b>	-
<b>Comments</b>	- Text may contain any string of characters, except diacritical signs. It may contain mnemonics dynamically replaced at run-time by values drawn from the module e.g.: time, register or logical state of the bit. The syntax of commands is described in detail in <u>Syntax of commands for reading and writing data by SMS</u> paragraph.

### 6.3. Configuration writing

After required modifications and parameter settings, the configuration is stored on the configuring PC's hard disk only. In order to write it to the module memory, it has to be transmitted to the module. For local configuration, it is enough to secure a connection via RS232 cable. Detailed description of local configuration is to be found in the MTM user manual.

Remote configuration can be realized via SMS commands. It is necessary to enter the phone number on an authorized list, except for the first configuration of the module. Detailed description of remote configuration is to be found in the chapter [Module configuration via SMS](#).

### 6.4. Verification of configuration

Despite high reliability of both local and remote module configuration, verify of it is important. It is relevant if the module's behavior does not comply in accordance with the performed configuration. For verification, please read the configuration from the module and check parameters settings.

Reading of module configuration is described in details in MTM user manual and chapter [Module configuration via SMS](#).

## 7. Technical Data

### 7.1. General

Dimensions (height x width x length)	105x86x58 mm
Weight	300 g
Mounting method	DIN Rail 35mm
Operating temperature	0 ... +55°C
Protection class	IP40

### 7.2. GSM Modem

Modem type	Cinterion TC63i
GSM	Quad Band (850/900/1800/1900)
Frequency range (GSM 850)	Transmitter: from 824 MHz to 849 MHz Receiver: from 869 MHz to 894 MHz
Frequency range (EGSM 900)	Transmitter: from 880 MHz to 915 MHz Receiver: from 925 MHz to 960 MHz
Frequency range (DCS 1800)	Transmitter: from 1710 MHz to 1785 MHz Receiver: from 1805 MHz to 1880 MHz
Frequency range (PCS 1900)	Transmitter: from 1850 MHz to 1910 MHz Receiver: from 1930 MHz to 1990 MHz
Transmitter peak power (GSM850 / EGSM900 MHz)	33 dBm (2W) – class 4 station
Transmitter peak power (DCS1800 / PCS1900 MHz)	30 dBm (1W) – class 1 station
Modulation	0,3 GMSK
Channel spacing	200 kHz
Antenna	50Ω

### 7.3. Power supply

Power voltage range	9 ... 30VDC
Current for 12 VDC	Idle 0,05 Max 1,00
Current for 24 VDC	Idle 0,03 Max 0,70

#### CAUTION!

**Due to high momentary current consumption the power supply must be capable of delivering  $\geq 1A$  of current.**  
**Inappropriate power supply may result in faulty operation or cause damage to MT-021 module!**

## 7.4. Binary inputs I1....I4

Signal voltage range	0 ... 30VDC
Input resistance	5,4 kΩ
Input ON (1) voltage	> 9V
Input OFF (0) voltage	0 ... 3V

## 7.5. Relay outputs Q1...Q4

Output type	Relay, optoisolated, NO
Maximum voltage between contacts	250VAC/300VDC
Load current	6A/230VAC, 6A/24VDC
Maximum switching current	15A/20ms
Resistance	< 100mΩ

## 7.6. Analogue inputs AN1, AN2

### Analog/Pt100 input AN1 - temperature measurement

Sensor type	PT100, 2- or 3-wired
Wires resistance compensation	yes (applies only to 3-wire sensor)
Measurement range	-40...+200°C
Accuracy	+/-1°C

### Analog/NTC input AN2 - temperature measurement

Sensor type	NTC 10k
Measurement range	-25...+55°C
Accuracy	+/-1°C (depending on used sensor)


### Analog inputs AN1, AN2 - voltage measurement

Measurement range	0...5V/0...10V
Maximum input voltage	18V
Input dynamic impedance	150kΩ typ.
Accuracy	+/-1,5% max.
Nonlinearity	+/-1% max.

### Analog inputs AN1, AN2 - current measurement

Measurement range	4...20mA
Maximum input current	50 mA max.
Input dynamic impedance	100Ω typ.
Voltage drop at 20mA	2V max.
Accuracy	+/-1,5% max.
Nonlinearity	+/-1% max.


## 7.7. Drawings and dimensions (All dimensions in millimeters)



## **8. Problem solving**

### **8.1. LED signaling**

LED indicators placed on **MT-021** panel are a great diagnostic tool.



In table below are described all states signaled by LED diodes.

<b>LED</b>	<b>Signaling</b>	<b>Description</b>
PWR	on	Module powered V+ and GND terminals
USB	on	USB connected - module powered from USB
I1...I4	on	Input activated
	off	Input deactivated
Q1...Q4	on	Output activated
	off	Output deactivated
GSM	blinking quickly	Module initialization
	1 blink	Modem initialization
	2 blinks	GSM network searching
	3 blinks	Module logged in GSM network
	1 long i 3 short blinks	Module logged in GPRS network
SGN	1-4 blinks	GSM signal strength
ACT Tx	on	Sending SMS
	blinking	Outgoing call
ACT Rx	on	Receiving SMS
	blinking	Incoming call
ERR	blinking quickly	Updating module firmware
	1 blink	Unsuccessful SMS sending attempt
	2 blinks	No SIM card or SIM card improperly inserted
	3 blinks	Wrong PIN
	4 blinks	Wrong PIN. No more PIN entering attempts or PUK needed.
	5 blinks	Unsuccessful GSM log in attempt

## **8.2. Unblocking of SIM card**

Three failed attempts of entering PIN code locks the SIM card and requires entering the PUK code. The fact that the SIM card locked is indicated by the ERR LED. An attempt to unlock the module may be performed only when the right PIN code is known.

Necessary procedure:

- turn the power supply off,
- remove SIM card from the module,
- insert SIM to ordinary mobile phone accepting cards from the operator that issued actual SIM,
- start the phone and enter proper PUK code and correct PIN code,
- if not accomplished before...
  - start the module,
  - insert appropriate PIN into configuration,
  - power the module off,
- remove the SIM from the phone and place it in the module,
- start the module

Entering correct PUK-code unblocks the card and resets PIN fault counter making the card operational.

## **9. Safety information**

### **9.1. Working environment**

When deploying telemetry modules one has to observe and comply to local legislation and regulations. Using the telemetry module in places where it can cause radio noise or other disturbances is strictly prohibited.

### **9.2. Electronic equipment**

Though most of modern electrical equipment is well RF (Radio Frequency) shielded there is no certainty that radio waves emitted by the telemetry module's antenna may have negative influence on its function.

#### **9.2.1. Heart pacemakers**

It is recommended that the distance between the antenna of telemetry module and the Heart Pacemaker is greater than 20 cm.

This distance is recommended by manufacturers of Pacemakers and in full harmony with results of studies conducted independently by Wireless Technology Research.

#### **9.2.2. Hearing aids**

In rare cases the signal emitted by the telemetry module's antenna may disturb hearing aids functions. Should that occur, one has to study detailed operating instructions and recommendations for that particular product.

#### **9.2.3. Other medical equipment**

Any radio device including the telemetry module may disturb the work of electronic medical equipment.

When there is a need of installing telemetry module in vicinity of medical equipment one has to contact the manufacturer of this equipment in order to make sure that the equipment is adequately protected against interference of radio frequency waves (RF).

#### 9.2.4. RF Marked equipment

The restriction against installing telemetry modules in areas marked as radio frequency (RF) prohibition zones must be unconditionally observed.

### 9.3. Explosive environment

Installation of telemetry modules in the environment where explosion hazard is present is not permitted. Usually, but not always, these places are marked with warning signs. Where there is no marking do not install telemetry modules at liquid or gas fuels stores, inflammable materials stores, nor places contaminated with metal or wheat dust.

## 10. Appendices

### 10.1. Register of changes

Current version - **v1.51.02**

---

**v1.51.02** - 2012-08-01

- added new prefix #Fx (x-number of digits after dot) to the SMS commands allowing to present values from 16-bit registers as numbers with decimal fraction
- SMS and E-mail sending rules are merged into one block of Messages sending rules. This allow to choose channel of communication from: "SMS", "e-mail", "e-mail or SMS" where last option sends SMS where unable to send e-mail for some reason (e.g. no GPRS available)
- added three new predefined symbolic names for use in SMS and e-mail commands: #NAME (gives name of device defined during configuration)), #SERIAL (gives serial number of device) i #IPADDR (gives current IP address of module).
- added GPRS testing address and Idle time parameters used for GPRS connection check
- added possibility to write to multiple registers at once using Monitoring - software module of MTM

**v1.50.01** - 2012-04-16

- added email sending functionality (via SMTP server and GPRS service)

**v1.00.12** - 2011-03-31

- improvement in access to read/write resources from memory map via USB port

**v1.00.11** - 2011-03-03

- improvement in answer for blank SMS
- improvement in procedure of sending SMS with '\$' sign (without answer)
- improvement in roaming procedure
- added access to read/write resources from memory map via USB port

---

**v1.00** - First official version

## 10.2. Module configuration via SMS

MT-021 can be configured locally using **MTManager** (software tool for telemetry modules management) and remotely via SMS commands. However, you should note that the first SMS message with configuration commands is processed without sender authorization verification - number of sender does not have to figure on [Authorized numbers->Phone](#) list (this allows to make first configuration via SMS). Therefore it is strongly recommended to add at least one phone number to this list in first SMS command with allowed configuration changing. Otherwise remote configuration will be disabled.

For system demanding high security configuration can be additionally protected by password (parameter [General->Configuration password](#)). It will be needed for both local and remote configuration of the module.

Format of SMS configuration commands:

**&password#parameter=value#parameter=value#parameter...**

where:

**password** - password protecting module given by [General->Configuration password](#) parameter (if module is not password protected this parameter should be omitted - SMS should begin only with '&')

**parameter** - predefined configuration parameter mnemonic

**value** - parameter value. It may be number or text depending on parameter type. Text values should be put in quotes, e.g. "+48123456789" or "Anna". If equals sign and **value** are omitted module will treat command as an inquiry.

If in sent SMS command parameters were given values than module will make attempt to write them into configuration. Result of this action will be send in response SMS.

If SMS was send with correct syntax and values within allowed range or SMS was an inquiry (no values) than response is built from list of parameters with corresponding values.

**>#parameter=value#parameter=value#parameter...**

If there was at least one wrong parameter name module will not change any configuration parameter and will send following response:

**>#parameter?#parameter?...**

If there was at least one of parameter values will not be within accepted range or will be of wrong type change any configuration parameter and will send following response:

**>#parameter=Err#parameter=Err...**

The following tables list all available configuration parameter mnemonics, their allowed parameter value range and default value. Please note that some of the parameters and parameter values are depending on other parameter values, e.g. number entered on sixth position on [Authorized numbers->Phone](#) list is active only if [Authorized numbers->Number of phone numbers](#) parameter is set to six or more.

Parameters in bold accept only text values.

### General group:

Parameter	MTManager description	Default value	Range	Definition
<b>SPIN</b>	SIM card PIN number	empty	from 4 to 8 characters or empty	
<b>CONF_PSW</b>	Configuration password	empty	max. 32 characters	
<b>CRTC</b>	RTC time	2000-01-01 00:00:01	YYYY-MM-DD HH:MN:SS	
<b>GPRS_EN</b>	Use of GPRS	1	1 2	No Yes

### SMS group:

\* - index from 1 to 16

Parameter	MTManager description	Default value	Range	Definition
<b>MAXS</b>	Daily SMS limit	0	0...65535	
<b>RSMS</b>	Roaming for SMS	2	1 2 3	No Answer All
<b>SREP</b>	Number of SMS sending retries	10	0...255	
<b>SPAT</b>	Answer for blank SMS	*M0	max. 160 characters	
<b>SLII</b>	SMS limit exceed information text	1	1 2	Off On
<b>SLIN</b>	Phone number of info recipient	1	1...32	SMST_* (* - index from 1 to 32)
<b>SLIT</b>	SMS limit exceed information	empty	max. 160 characters	
<b>SFOD</b>	Date format	YYYY-DD-MM	max. 31 characters	
<b>SFOT</b>	Time format	HH:MN:SS	max. 31 characters	
<b>SFO01</b>	General format 1	YYYY/MM/DD , HH:MN:SS	max. 31 characters	
<b>SFO02</b>	General format 2	YY/DD/MM, HH:MN:SS	max. 31 characters	
<b>SREB</b>	Number of symbolic names	1	0...16	
<b>SREA_*</b>	Symbolic name	IREGO	max. 50 characters	
<b>SRES_*</b>	Space	2	1 2 3 4	Hreg Ireg HB IB
<b>SREN_*</b>	Register/bit number	0	0...65535	
<b>SMAS</b>	Number of macros	1	0...16	
<b>SMAN_*</b>	Macro name	M0	max. 20 characters	
<b>SMAC_*</b>	Macro's content	#It.ir0 #Id.ir0	max. 160 characters	

### GPRS group:

Parameter	MTManager description	Default value	Range	Definition
<b>APN_NAME</b>	APN name	empty	max. 63 characters	
<b>APN_USR</b>	APN user name	empty	max. 31 characters	
<b>APN_PSW</b>	APN password	empty	max. 31 characters	
<b>GLBR</b>	GPRS login retry interval [s]	10	10...3600	

### Authorized numbers group:

\* - index from 1 to 32

Parameter	MTManager description	Default value	Range	Definition
LPHN	Number of phone numbers	1	1...32	
SPBS	Update phone numbers from SIM card	1	1 2	No Yes
SALS	Phone number from SIM card always authorized	1	1 2	No Yes
<b>SMST_*</b>	Name	NUM *	max. 16 characters	
<b>SMSN_*</b>	Number	+48	max. 14 characters	
SCFG	Configuration	FFFFFF	from 00000000 to FFFFFFFF	Bits defining configuration access authorization. Bit=1 - authorization granted. Representation - see reference 1.
SINQ	Query	00000000	from 00000000 to FFFFFFFF	Bits defining data polling authorization. Bit=1 - authorization granted. Representation - see reference 1.
SMS_AUT	Receiving voice calls	00000000	from 00000000 to FFFFFFFF	Bits defining receiving calls authorization. Bit=1 - authorization granted. Representation - see reference 1.

### Resources group:

Parameter	MTManager description	Default value	Range	Definition
<b>Binary inputs I1...I4 (counter inputs) * -index from 1 to 4</b>				
<b>IN_NAME_*</b>	Name	I*	max. 16 characters	
<b>IN_MODE_*</b>	Input type	1	1 3	Binary input Counter input
<b>IN_DIR_*</b>	Counting direction	1	1 2	Up Down
<b>IN_RANGE_*</b>	Counting range (32bits)	0	0...2147483647	
<b>IN_EDGE_*</b>	Triggering slope	1	1 2 3	Bi 0->1 Bi 1->0 Bi 0->1 1->0
<b>IN_FLR_*</b>	Filtering constant [s]	10	10...16383	unit is value/100 [s]
<b>Relay outputs Q1...Q4 * - index from 1 to 4</b>				
<b>OUT_NAME_*</b>	Name	Q*	max. 16 characters	
<b>OUT_IMP_*</b>	Output mode	1	1 2	Monostable Bistable
<b>OUT_IMPLEN_*</b>	Pulse duration [s]	1	1...3600	unit is value/10 [s]
<b>OUT_ONEVT_*</b>	On event	0	0 1 ... 16	None EVT1 ... EVT16 (* - index from 1 to 16)

Parameter	MTManager description		Default value	Range	Definition
OUT_OFFEVT_*	Off event		0 1 ... 16	0 1 ... 16	None EVT1 ... EVT16 (* - index from 1 to 16)
<b>Analog inputs AN1, AN2 * - index from 1 to 2</b>					
AN_NAME_*	Name	AN*	max. 16 characters		
AN_MODE_*	Input type	1	1 2 3	Voltage input Current input PT100 (AN1) or NTC (AN2)	
AN_FLR_*	Filtering constant [s]	0	0 1 2 3 4 5 6 7 8	0 0,05 0,1 0,25 0,5 1 2 4 8	
AN_RANGE_*	Signal range	1	0 1	0...5V 0...10V	
AN_LREF_*	Low reference - internal units {0...5V}	0	0...500		
AN_LREF_*	Low reference - internal units {0...10V}	0	0...1000		
AN_LREF_*	Low reference - internal units	0	0...2000		
AN_HREF_*	High reference - internal units {0...5V}	1000	0...500		
AN_HREF_*	High reference - internal units {0...10V}	1000	0...1000		
AN_HREF_*	High reference - internal units	1000	0...2000		
AN LENG_*	Low reference - engineering units	0	-32757...32767		
AN HENG_*	High reference - engineering units	1000	-32757...32767		
AN_ALM_HH_*	Alarm HiHi - engineering units	32767	-32757...32767		
AN_NAME_*	Name	AN*	max. 16 characters		
AN_ALM_HI_*	Alarm Hi - engineering units	32767	-32757...32767		
AN_ALM_LO_*	Alarm Lo - engineering units	-32767	-32757...32767		
AN_ALM_LL_*	Alarm LoLo - engineering units	-32767	-32757...32767		
AN_ALM_HIST_*	Alarm hysteresis - engineering units	100	0...65535		
AN_DBDB_*	Deadband - engineering units	100	0...65535		
<b>1-Wire inputs (1, 2) * - index from 1 to 2</b>					
OW_NAME_*	Name	1-WIRE*	max. 16 characters		
OW_ACT_*	Input mode	1	1 2	Inactive Temperature measurement	
OW_ALM_HH_*	Alarm HiHi	125	-25...125		
OW_ALM_HI_*	Alarm Hi	125	-25...125		
OW_ALM_LO_*	Alarm Lo	-25	-25...125		
OW_ALM_LL_*	Alarm LoLo	-25	-25...125		
OW_ALM_HIST_*	Alarm hysteresis	2	0...50		
OW_DBDB_*	Deadband	2	0...50		

### Synchronous timers TMR1...TMR4 group:

\* - index from 1 to 4

Parameter	MTManager description	Default value	Range	Definition
TMR_ON_*	Active	2	1 2	Yes No
TMR_START_*	Start [HH:MM]	00:00	00:00...23:59	
TMR_PERIOD_*	Period	14	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	1 min. 2 min. 3 min. 5 min. 10 min. 15 min. 30 min. 1 hour. 2 hours. 3 hours. 4 hours. 6 hours. 8 hours. 12 hours. 24 hours.
TMR_DOFW_*	Days of week	7F	from 00 to 7F	Days of week when timer is active. 1 - Monday 2 - Tuesday 4 - Wednesday 8 - Thursday 10 - Friday 20 - Saturday 40 - Sunday e.g. Wednesday, Thursday and Friday is 1C.
TMR_DOFM_*	Days of month	00000000	from 00000000 to FFFFFFFF	Days of month when timer is active. Bit=1 - day is selected. Representation - see reference 2.

### State logging group:

Parameter	MTManager description	Default value	Range	Definition
STWS	Start [HH:MM]	00:00	00:00...23:59	
STWP	Period	9	1 2 3 4 5 6 7 8 9 10 11 12	10 min. 20 min. 30 min. 45 min. 1 h 2 h 3 h 4 h 6 h 8 h 12 h 24 h
STWI	Logged information	empty	max. 160 characters	

### Events group:

t - index from 1 to 16

Parameter	MTManager description	Default value	Range	Definition
EVNO	Number of events	0	0...32	
EV_TRIG_t	Trigger source	1	1 2 3 4 5 6 7 8	None Binary inputs Analog inputs Inputs 1-wire Clocks Flags Counters Connections
<b>Binary inputs I1...I4 (counter inputs)</b>				
EV_FLAG_t	Trigger input	0	0 1 2 3	I1 I2 I3 I4
EV_EDGE_t	Trigger condition	1	1 2 3	Bi 0->1 Bi 1->0 Bi 0->1 1->0
<b>Analog input AN1, AN2</b>				
EV_FLAG_t	Trigger input	63	63 71	AN1 AN2
EV_EDGE_t	Trigger condition	1	1 2 3 4	Alarm HiHi Alarm Hi Alarm Lo Alarm LoLo
<b>1-Wire inputs (1, 2)</b>				
EV_FLAG_t	Trigger input	79	79 87	1-Wire1 1-Wire2
EV_EDGE_t	Trigger condition	1	1 2 3 4	Alarm HiHi Alarm Hi Alarm Lo Alarm LoLo
<b>Clocks</b>				
EV_FLAG_t	Triggering clock	32	32 33 34 35	TMR1 TMR2 TMR3 TMR4
<b>Flags</b>				
EV_FLAG_t	Triggering flag	48	48	Module power on reset
<b>Counters</b>				
EV_FLAG_t	Triggering counter	16	16 17 18 19	I1 I2 I3 I4
<b>Connections</b>				
EV_FLAG_t	Connection from any authorized	1	1 2	Yes No
EV_NUM_t	Dial-in from number	1	1...32	1...32 - number index from Authorized phone numbers list

**Rules group:**

\* - index from 1 to 16

† - index from 1 to 32

Parameter	MTManager description	Default value	Range	Definition
<b>Message sending</b>				
TRNO	Number of message sending rules	1	1...32	
TR_SMF	Sender e-mail address	empty	max. 63 characters	
TR_SMA	SMTP server name	empty	max. 63 characters	
TR_SMP	SMTP server port	25	1...65535	
TR_SML				
TR_AU	SMTP user name	empty	max. 31 characters	
TR_AP	SMTP password	empty	max. 31 characters	
TR_TRIG_†	Triggering event	0	0...32	0-None 1...32 - event index from event list
TR_TCH_†				
TR_N_†	SMS recipient number	1	1...32	1...32 - number index from Authorized phone numbers list
TR_A_†	E-mail receiver address	empty	max. 48 characters	
TR_S_†	E-mail title	empty	max. 31 characters	
TR_T_†	Message text	empty	max. 160 characters	
<b>CLIP calls</b>				
CRNO	Number of CLIP calls rules	1	1...16	
CR_TRIG_*	Triggering event	0	0...32	0-None 1...32 - event index from event list
CR_N_*	Recipient number	1	1...32	1...32 - number index from Authorized phone numbers list
Parameter	MTManager description	Default value	Range	Definition
<b>Message sending</b>				
TRNO	Number of message sending rules	1	1...32	

References:

- 1.) Information about configuration authorization, query authorization and receiving calls authorization is stored in one 32-bit digit, in which each single bit corresponds to position on Phone list according to table below:

<b>Bit position</b>	31 (M SB)	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
<b>Position on Phone list</b>	8	7	6	5	4	3	2	1	16	15	14	13	12	11	10	9
<b>Bit position</b>	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0 (LS B)
<b>Position on Phone list</b>	24	23	22	21	20	19	18	17	32	31	30	29	28	27	26	25

For example to enable authorization for eighth and ninth phone on the list you need to set parameter to 80010000 (10000000 00000001 00000000 00000000 in binary notation).

2.) Information about days of month is stored in one 32-bit digit, in which each single bit corresponds to one day of month according to table below:

<b>Bit position</b>	31 (M SB)	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
<b>Day of month</b>	8	7	6	5	4	3	2	1	16	15	14	13	12	11	10	9
<b>Bit position</b>	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0 (LS B)
<b>Day of month</b>	24	23	22	21	20	19	18	17	All	31	30	29	28	27	26	25

For example to enable timer for first and last day of month (30th and 31st) you need to set parameter to 1000060 (00000001 00000000 00000000 01100000 in binary notation).

### Examples:

- Setting new value of [SIM card PIN number](#) (0101) and new [Configuration password](#) (ADMIN):

**&#SPIN="0101"#SMSP="ADMIN"**

Module response:

**>#SPIN="0101"#SMSP="ADMIN"**

Attention!!! All changes to [SIM card PIN number](#) and [Configuration password](#) parameters are taking effect after module restart.

- Reading telephone number stored on second position on [Authorized numbers->Phone](#) list:

**&ADMIN#SMSN\_2**

Module response:

**>#SMSN\_2="+48111222333"**

Number on this position is +48 111 222 333.

- Setting new phone number (+48 123 456 789) on second position on [Authorized numbers->Phone](#) list:

**&ADMIN#SMSN\_2="+48123456789"**

Module response:

**>#SMSN\_2="+48123456789"**

- Setting new phone number on sixth position on [Authorized numbers->Phone](#) list. Name parameter is *Mark* and Number parameter is +48 987 654 321:

**&ADMIN#LPHN=6#SMST\_6="Mark"#SMSN\_6="+48987654321"**

Module response:

**>#LPHN=6#SMST\_6="Mark"#SMSN\_6="+48987654321"**

- Setting [HiHi alarm](#) threshold of 1-Wire 2 input to 115:

**&ADMIN#OW\_ACT\_2=2#OW\_ALM\_HH\_2=115**

Module response:

**>#OW\_ACT\_2=2#OW\_ALM\_HH\_2=115**

- Setting new event on seventh position on event list. Event is triggered by crossing [LoLo alarm](#) threshold on analog input AN2:

**&ADMIN#EVNO=7#EV\_TRIG\_7=3#EV\_FLAG\_7=71#EV\_EDGE\_7=4**

Module response:

**>#EVNO=7#EV\_TRIG\_7=3#EV\_FLAG\_7=71#EV\_EDGE\_7=4**

- Setting module RTC clock to 2010-12-31 23:59:59:

**&ADMIN#CRTC="2010-12-31 23:59:59"**

Module response:

**>#CRTC="2010-06-17 08:27:40"**

### 10.3. Syntax for reading and writing data in SMS mode

#### Description of SMS command

Internal application of a module is able to receive, process and send short text messages (SMS). There is a set of command which can be put in SMS message, allowing the user to read from and write to internal registers placed in module's memory.

Characters with special meaning:

Character	Description
#	starts a command ATTENTION! putting two hash signs one after another will prevent module from processing command following it. However after sending one of hash signs will be deleted - this allows to control resources of one module from another, e.g. set binary output Q1 to '1' (#HB128=1)
*	starts a macro
>	used as first character in SMS text inhibits parsing of SMS
\$	used as first character in SMS text inhibits answering to this SMS

After reception of SMS message, internal application tries to parse SMS text and execute command enclosed in it. Parsing process generates new message text, which is send back to user (if module is allowed to, either by configuration or by presence/absence of '\$' sign).

Commands are formatted as follows:

**#[prefix.]symbol[=value]**

where:

**prefix** defines data representation and register count

**symbol** defines register address and register space being accessed

**value** defines data to be written to register (s)

Prefix is optional; when not present, data is interpreted according to preset defaults.

Basic read command:

**#HRO**

When module receives and parses the SMS message containing this command, command string will be replaced with value of register 0 read from holding registers space, noted in decimal format, and this value will be put in SMS sent back to user. Answer to this command sent back will be:

**>10**

where 10 is value read from holding register 0.

If received SMS contains any other characters than correctly formatted commands, these characters will be copied unaltered to message being sent back. This allows user to freely compose text of return message and include register values together with some informational text. For example, if user sends containing:

**Voice call was #IR12 seconds long**

then module will answer with:

**>Voice call was 15 seconds long**

where 15 is a value read from input register 12.

It should be noted that answer from module begins with '>' sign - it means that this SMS was generated by module. If module receives SMS beginning with '>', such message will be ignored (not parsed). This prevents endless "looping" of messages in case they are being exchanged between modules

Writing to register is archived by expanding basic command with '=' sign and value that should be written:

**#HR20=2**

User should be aware that writing is allowed only to holding register space.

When module receives SMS with write command, it executes the command and sends back value written. For example, sending to module SMS with text:

**#HR1=1234**

causes module to write value 1234 to holding register 10 and send back SMS with text:

**>1234**

Both read and write commands can be expanded by adding a prefix, which defines data format (notation). Prefix should be placed between '#' mark (command start) and register symbol, and should contain one (or more) characters ended with a dot. For example, to read an input register 4 in hexadecimal format, one should use a command:

**#H.IR4**

and module's answer will be:

**>1FC8**

Prefixes can also be used with write commands.

Command can operate on more than one register. Register count can be included in prefix, after character denoting data format (which is then mandatory). For example, command:

**#D2.HR2=123456**

causes write 123456 to two registers, HR2 and HR3 (32-bit variable).

Full list of available prefixes is enclosed below.

User can define in MTManager own symbolic names in module's config and assign them to registers. Then, such names can be used instead of register symbols. It allows user to define "friendly" names for registers and to erase access to bit values. For example, if user has defined symbolic name "output" and assigned it to bit 321 of internal registers space (which is equal to bit of HR20 register), then sending a command:

**#output=1**

causes module to write 1 to bit 1 of HR20 register. There are several predefined (internal) symbolic names.

Apart from symbolic names, user can define macros. A macro is defined as a name and a text assigned to this name. Parsing of received message begins with macro expansion. Parser looks for words beginning with '\*' sign and replaces such names with assigned strings. Once macro expansions ends, new message text is being interpreted and commands executed. It allows user to place both commands and symbolic names in macro text. Furthermore, macros can contain another macro names ("nested" macros), but only those defined higher in macro list. For example, if configuration contains following macros (in order shown):

No.	Macro name	Macro text
1	counter	*mtime: input 0 counter: #D2.HR0
2	mtime	#date #time
3	state	*mtime: inputs - #B8.IB64, #IR19 SMS sent

then macro \*mtime used in macro number 3 (\*state) will be correctly expanded and SMS text:

**\*state**

after macro expansion (before executing commands) will be changed to:

**#date #time: inputs - #B8.IB64, #IR19 SMS sent**

but expansion of macro 1 will not contain text assigned to macro name \*mtime, therefore text being executed after macro 1 was used will look like:

**\*mtime: input 0 counter: #D2.HR0**

which in turn causes module to send back SMS containing:

**>\*mtime: input 0 counter: 123**

### Register spaces

Module's firmware distinguishes two register spaces: [input registers](#) and [holding registers](#). Access to register space can be made by calls to 16-bit registers or by calls to individual bits.

Symbol	Description
HR{0..n}	Holding registers space. Read/write access. 16-bit registers.
IR{0..n}	Input registers space. Read only. 16 bit registers.
HB{0..16*n}	Bit access to holding registers space. One can access individual bits (or groups of bits). Read/Write. Bit mapping is as follows: bits 0..15 correspond to holding register 0, bits 16...31 - to holding register 1 and so on.
IB{0..16*n}	Bit access to input registers space. One can access individual bits (or groups of bits). Read only. Bit mapping is as follows: bits 0..15 correspond to input register 0, bits 16..31 - to input register 1 and so on.

Register symbols can be preceded by prefixes, which can define amount of data being processed and data format.

### Available prefixes:

#### Register space HR, IR (16-bit registers)

Prefix	Description
B[1..4]	Binary format, 16 characters (bits) default, bits from most to least significant. Prefix can contain register count (1..4) being processed (register symbol defines lowest register) - in resulting string, rightmost character corresponds to bit with lowest number.
D[1..4]	Decimal format, 1..5 characters, unsigned. Prefix can contain register count (1..4) being processed (register symbol defines lowest register) - number returned is decimal notation of n*16 bit value where most significant bit is placed in register with lowest address (big endian).
H[1..4]	Hexadecimal format, 4 characters. Prefix can contain register count (1..4) being processed - returned string contains n*4-character groups, leftmost group corresponds to register with lowest address (big endian).
LT	Local time fetched from three consecutive registers Rn: Rn+1: Rn+2, where n corresponds to register symbol used. Time format according to "Time format" string in configuration.

UT	UTC time fetched from three consecutive registers $Rn:Rn+1:Rn+2$ , where $n$ corresponds to register symbol used. Time format according to „Time format” string in configuration.
LD	Local date fetched from three consecutive registers $Rn:Rn+1:Rn+2$ , where $n$ corresponds to register symbol used. Date format according to „Date format” string in configuration.
UD	UTC date fetched from three consecutive registers $Rn:Rn+1:Rn+2$ , where $n$ corresponds to register symbol used. Date format according to „Date format” string in configuration.
T{1..2}	UTC timestamp fetched from three consecutive registers $Rn:Rn+1:Rn+2$ , where $n$ corresponds to register symbol used. Timestamp format according to „General format 1” or „General format 2” strings in configuration.
S	Decimal format, 1..5 characters (with ‘-’ sign when needed), signed. Access to single register treated as 16-bit signed value.
F[1..3]	Converts decimal value to floating point number. Number next to prefix defines number of digits after dot.

### Bit access to register spaces - HB, IB

Prefix	Description
B[1..64]	Binary format. Amount of bits being displayed provided in prefix. Bits are presented in order from least to most significant (opposite to binary representation of whole register).
D[1..64]	Decimal format. Value presented is calculated from amount of bits provided in prefix, with bit with lowest address being least significant ( <i>little endian</i> )
H[1..64]	Hexadecimal format. Value presented is calculated from amount of bits provided in prefix, with bit with lowest address being least significant ( <i>little endian</i> )

It is worth noting that use of D prefix to display more than 16 bits of data will return different results when combined with different access modes (registers, bits). Such behavior is result of storage model used for multi-register (32- or 64-bit) data. Most significant word is stored in register with lowest address (big endian) and, consequently, on bits with lowest addresses. Register access obeys this storage model, but bit access does not, treating bits as linear space from bit with lowest address to bit with highest address.

So, if one tries to read two registers using “register access”:

#### #D2.IRO

then such a command can return:

**134749453**

but “bit access” to 32 bits from two registers:

#### #D32.IBO

will return:

**487393288**

The same applies to **H** prefix and to write access.

## Predefined symbolic names

Name	Description
TIME	Returns local time read from RTC registers – the same as <b>#LT.IRO</b> command
DATE	Returns local date read from RTC registers – the same as <b>#LD.IRO</b> command
RTC	Returns UTC time and date read from RTC registers – the same as <b>#T1.IRO</b> command
NAME	Returns module name
SERIAL	Returns module serial number
IPADDR	Returns module current IP address

## Date and time formats

User is allowed to specify date and time formats which will be used in SMS messages when timestamp processing commands are used. Module's configuration contains four format strings:

**Date format** is used by date processing commands (prefixes LD, UD)

**Time format** is used by time processing commands (prefixes LT, UT)

**General format 1** and **2** are used by timestamp processing commands (prefixes T1 and T2, respectively)

Format strings can contain specific character combinations, related to date/time information, which will then be replaced with corresponding values during parsing. Apart from this, format strings can contain additional characters – they will be copied to resulting timestamp string unchanged.

Available specifiers are:

Specifier	Replaced with
YYYY	year, four digits (e.g. 2010)
YY	year, two digits (e.g. 10)
MM	month, two digits (01..12)
DD	day in month, two digits (01..31)
HH	hour, two digits (00..23)
MN	minute, two digits (00..59)
SS	second, two digits (00..59)

For example, if user defines "General format 1" as:

**DD/MM/YYYY, HH:MN:SS**

and when it will be applied to RTC registers by a SMS command:

**#T1.IRO**

returned string will look like:  
**>25/02/2010, 08:51:33**

User should define at least **Date format** and **Time format** strings – this will ensure that use of LT, UT, LD and UD prefixes return expected data.

#### **Other examples:**

Read input registers 20:

**#IR20**

Write value 1 to holding register 0:

**#HRO=1**

Binary representation of input register 4 (readout):

**#B.IR4**

Read flag (bit) 4:

**#B.IB4**

Write hexadecimal value **01AC** to holding register 0:

**#H.HRO=01AC**

## **10.4. Memory map**

All accessible from remote resources of MT-021 module were collected in two address spaces: analog inputs and internal registers.

### 10.4.1. Analog inputs address space

Address Dec	Bit address	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Description								
0	0	Month								Year								RTC								
1	16	Hour								Day of month																
2	32	Seconds								Minutes																
3	48	Event source								Number of event in a second																
4	64	I1	I2	I3	I4					Q1	Q2	Q3	Q4	--	--	--	digital I/Os									
5	80	Modem OK	GSM SEARCH	GSM OK	GSM ERROR					SMS ERR	NO SIM	PIN ERROR	PIN CNT					GSM status								
6	96	GSM signal																GSM signal [0...31]								
7	112																	Number of SMS messages sent since power on								
8	128																	Number of SMS messages sent today								
9	144																	Number of SMS messages which could not been sent								
10	160	Lower 16-bits																Module on timer [s]								
11	176	Higher 16-bits																								
12	192	Time zone												Sign	Time zone [quarters]			Time zone [quarters]								
13	208																									
14	224																	Analog input AN1 - internal units								
15	240																									
16	256																	Analog input AN2 - engineering units (signed)								
17	272	Wire 1 OK	Wire 1 SHORT	Wire 1 No dev.	Wire 1 CRC					Wire 2 OK	Wire 2 SHORT	Wire 2 No dev.	Wire 2 CRC					1-Wire status								
18	288																	Temperature - 1-Wire 1 (signed)								
19	304																	Temperature - 1-Wire 2 (signed)								
20	320	LAC																GSM LAC (Location Area Code) code								
21	336	CID																GSM CID (Cell ID)								
22	352																	Module restart code								

Address Dec	Bit address	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Description
23	368	I1 CNT	I2 CNT	I3 CNT	I4 CNT												Pulse counters flags	
24	384	TMR 1	TMR2	TMR3	TMR4												Timer flags	
25	400	RES ET	CALL AUTH ORIZE D														General flags: * RESET - set to '1' after reset * CALL AUTHORIZED - set to '1' on incoming authorized call	
26	416	AN1 HiHi	AN1 Hi	AN1 Lo	AN1 LoLo					AN2 HiHi	AN2 Hi	AN2 Lo	AN2 LoLo				Analog inputs alarm flags	
27	432	1-WI RE1 HiHi	1-WIR E1 Hi	1-WI RE1 Lo	1-WIR E1 LoLo					1-WIR E2 HiHi	1-WI RE2 Hi	1-WI RE2 Lo	1-WI RE2 LoLo				1-WIRE inputs alarm flags	
28	448	CALL 1	CALL2	CALL 3	CALL4	CA LL 5	CA LL 6	CA LL 7	CA LL 8	CALL9	CALL 10	CALL 11	CALL 12	CA LL 13	CALL 14	CA LL 15	CALL1 6	Incoming calls flags
29	464	CALL 17	CALL 18	CALL 19	CALL 20	CA LL 21	CA LL 22	CA LL 23	CA LL 24	CALL2 5	CALL 26	CALL 27	CALL 28	CA LL 29	CALL 30	CA LL 31	CALL3 2	
30	480	EVT1	EVT2	EVT3	EVT4	EV T5	EV T6	EV T7	EV T8	EVT9	EVT1 0	EVT1 1	EVT1 2	EV T1 3	EVT1 4	EV T1 5	EVT16	Event flags
31	496	EVT 17	EVT18	EVT 19	EVT20	EV T2 1	EV T2 2	EV T2 3	EV T2 4	EVT25	EVT2 6	EVT2 7	EVT2 8	EV T2 9	EVT3 0	EV T3 1	EVT32	
32	512																Power voltage [mV]	
33	528	Lower 16-bits															IP address	
34	544	Higher 16-bits															Reserved	
35	560	Reserved															Reserved	
36	576	Reserved															Reserved	
37	592	Reserved															Reserved	
38	608	Reserved															Reserved	
39	624																Number of failed GPRS logins (zeroed on reset)	
40	640																Number of successful GPRS logins (zeroed on reset)	
41	656	Reserved															Reserved	
42	672																Number of sent e-mails (zeroed on reset)	

Address Dec	Bit address	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Description
43	688																	Number of e-mail sending errors (zeroed on reset)
44	576																	Number of e-mail sending retries (zeroed on reset)

**"GSM Status"** register flags description

Flag	Description
Modem OK	Successful modem initialization
GSM SEARCH	GSM network searching
GSM OK	Module registered in GSM network
GSM ERROR	Unsuccessful GSM registration attempt
SMS ERR	Unsuccessful SMS sending attempt
NO SIM	No SIM card, or SIM card inserted improperly
PIN ERROR	Wrong PIN
PIN CNT	Wrong PIN. Two attempts made. No more attempts will be made.

**"1-Wire line status"** register flags description

Flag	Description
Wire 1 OK	Successful communication with device on 1-Wire 1 line
Wire 1 SHORT	1-Wire 1 line short
Wire 1 No dev.	No device connected to 1-Wire 1 line
Wire 1 CRC	CRC error on 1-Wire 1 line
Wire 2 OK	Successful communication with device on 1-Wire 2 line
Wire 2 SHORT	1-Wire 2 line short
Wire 2 No dev.	No device connected to 1-Wire 2 line
Wire 2 CRC	CRC error on 1-Wire 2 line

#### 10.4.2. Internal registers address space

**Internal registers address space (read 03H/write 06H or 10)** - Not zeroed at reset

## 10.5. Flags

During operation **MT-021** module governs a number of binary flags (assuming value True or False) that trigger rules processing and remote diagnostics.

The User has access to following flags:

Bit name	Description
I1...I4	State of binary inputs I1...I4
Alarm HiHi	Flag assuming value True if value of analogue or 1-wire input is higher than value set as Alarm HiHi (preserving relation to hysteresis)
Alarm Hi	Flag assuming value True if value of analogue or 1-wire input is higher than value set as Alarm Hi (preserving relation to hysteresis)
Alarm LoLo	Flag assuming value True if value of analogue or 1-wire input is lower than value set as Alarm LoLo (preserving relation to hysteresis)
Alarm Lo	Flag assuming value True if value of analogue or 1-wire input is lower than value set as Alarm Lo (preserving relation to hysteresis)
TMR1...TMR4	Synchronous timer flags
Module power on (reset)	Flag informs about power on (reset) unit