


COBY

MPC651

USER'S MANUAL

DIGITAL AUDIO PLAYER W/ VOICE RECORDER



Coby Electronics Corp.
56-65 Rust Street
Maspeth, NY 11378

www.cobyusa.com
www.ecoby.com

Please read manual before operation

Customer Service Hours

Monday-Friday 8:00 AM - 11:00 PM EST, 1-800-681-2629 or 718-416-3197

Monday-Friday 6:30 PM - 11:00 PM EST, 1-800-727-3592

Saturday-Sunday 9:00 AM - 11:00 PM EST, 1-800-727-3592

Or Send E-Mail to: Customerservice@cobyusa.com / techsupport@cobyusa.com

Getting Started

Features	4
Accessory.....	5
Safety Instructions	6
Installing a battery	7
Location of Control	8
LCD Display	9
MENU Table	10

Connection to Computer

USB Driver Installation	11
Connecting the player to PC	12
Downloading/ Uploading files	13
Disconnection the USB	13

Basic Operations

Power On/ Off	14
Entering the Menu	15
Playing Music	16
Adjusting the Volume	16
Recording Voice	17
Searching for Music/ Voice Files	18

Advance Setup

System setup	19
Play/ Repeat Mode	21
Loop A-B Repeat	21
Delete/Format.....	22
Format/Resume	23


Customer Support

F/W Upgrade	24
Troubleshooting	25
Specifications	26
Warranty	27


- 512 MB Built-in Flash Memory
- MP3, WMA Playback
- Removable Storage Device (Music, Data and Pictures)
- Plug and Play (No installation software require for Window 2000 / Window ME / Window XP)
- Voice Recording
- Displays Song Title, Album and Artist
- Upgradable Firmware (You can upgrade the programs when available. Please check the home page www.cobyusa.com for upgrades.




MP3 Player



User's Manual



Earphone w/ Neck strap



USB Cable



Installation CD



1xAAA Battery

1. Do not expose the unit to high temperature or humidity.
2. Do not subject the unit to severe impact, or place heavy objects on it.
3. Do not use strong detergent or solvent to clean the unit.
4. Remove battery when the device is left unused for a long period of time.
5. Do not try to disassemble and repair the device yourself.
6. Do not expose to direct sunlight or heat sources.
7. Do not store in dusty areas.

Protect your ears:


Hearing experts advise against the constant use of personal stereo played at high volume. Constant high volume use can lead to hearing loss. If you experience ringing in the ears or hearing loss, discontinue use and seek medical advice.

Battery (included):




This unit operates on one alkaline battery (AAA size).

Installing Battery and SD/MMC Card

1. Open the battery cover.
2. Insert the AAA battery.
Make sure to match the + and - ends of the battery with the diagram inside the battery compartment.
3. Insert the SD/MMC Card.



Note: To release the SD/MMC Card, just press the card which will spring back out.



MENU	NAV	Music Voice Play list SD/MMC Card
	MSC	(Music)
	REC	(Recording)
	SYS	EQ- Normal, Classic, Live, Pop, Rock Repeat Mode- Normal, One, All, Intro, Random Display- ID3 Tag, Lyric, Contrast, B-light Time, Auto Off- 30 Sec, 1 Min, 2 Min, 3 Min Recording- 1. REC Mode- Low, Middle, High 2. VAD-On/Off Resume- 1. Track On (Off) 2. Time Line On (Off) Delete File - Music Voice Format- 1. Internal M. 2. SD/MMC Card Reset Information- 1. F/W Version 2. Internal M. 3. SD/MMC Card

■ USB Driver software Installation:


If you are using Windows Me/2K/XP or Mac X (version 10.2.6 or above), there is no installation required, just connect the player to the computer. OS will setup for one moment and then removable disk icon will show in "My Computer" (For Mac OS user, it'll show on the "Desktop").

If you are using Windows 98, you must install the driver which will setup the update utility and driver to computer.

1. Insert the Installation CD into the CD-ROM drive.
2. Click to open the disc D: (Where D:\ is your CD-ROM drive) and find out "Win98Driver.exe", click to run the program.
3. Setup dialogue Window will be displayed on the screen.
4. Operate following the instructions on the screen until get the suggestion that restart your computer now or restart it later.
5. Select one option and then click FINISH .

Connecting the player to PC:

1. Make sure the player is turned off.
2. Connect the player with your computer by supplied USB cable.
3. PC will automatically detect the player as removable disk under MY COMPUTER.
4. Go to MY COMPUTER and confirm the connection.



Downloading/ Uploading files:

1. Connect the player to PC.
2. Open Window Explorer on PC.
3. Select the file to save and drag-and-drop it into the removable disc icon. You can also transfer file from the player to your PC.

Note: Do not remove the player while it's transferring files. It might corrupt or damage the firmware and or files on the player. If the player is accidentally removed while transferring and does not work properly, remove battery for 3 seconds and replace it.

Disconnecting the Player:

After completing the file transfer, you must disconnect the player as following direction:

1. Double-click on the green arrow in the taskbar on the bottom right of the window.



2. When the [Stop a Hardware device] message appears, press the [OK] button and disconnect the USB port.
3. Now you can remove the player safely.

Hold Function:

Hold Off: Set the HOLD switch to opposite direction of arrow symbol to operate the player.

Hold On: Slide HOLD switch to the arrow direction to disable all the functions. The screen displays hold symbol:




Turning Power On and Off:

Power On: Press/hold the Joystick to turn on the power. The display shows "COBY".



Power Off: Press/hold the Joystick to turn off the power.

To enter the main menu, press MENU button.



In the main menu, it will display NAV, MSC, REC and SYS. Refer to the MENU Table for detail(pg 9)

NAV (Navigation)

1. MUSIC : Navigation for the Music files (ex. MP3, WMA)
 2. VOICE : Navigation for the Record files (ex. MIC0001.mp3)
 3. PLAY LIST : Navigation for the PlayList files (ex. M3U)
 4. SD/MMC CARD : Navigation for files in SD/MMC Card
- MSC (Music Playback)
REC (Voice Recording)
SYS (System Setup)

To exit the menu, press the MENU button

Note: While working with MENU:

1. Slide joystick to make selection.
2. Press joystick to confirm.
3. Press MENU button to exit menu.

Playing Music using MSC Menu

1. Enter the MSC menu.
2. Press the joystick up ►|| for music playback.

Adjust Tracks

Press joystick to right ►► to play next track and left ◀◀ to move to and play previous track.

Press and hold joystick right ►► to move fast forward .

Press and hold joystick left ◀◀ to move fast backward.

Adjust Volume

Press volume button +/ - to adjust the volume.

Pause Playback

1. Press the joystick up ►|| to pause playback.

Note: If no buttons are pressed within custom settings, the player automatically powers off.

2. Press the joystick up again to resume playback.

Start Recording:

1. Select REC menu from the main menu.
2. Press joystick to enter.
3. The player will start recording immediately. Blinking REC symbol will appear on lower left corner of the screen:



Stop Record:

Slide the joystick down ■ .

Play Record Voice:

Press the joystick up ►|| to start playback.

Please refer to other playback mode for detail. (page 6)

Recording under the REC mode:

1. Get to the stop mode.
2. Press REC button to start recording.

Note: Recorded voice is saved automatically in the VOICE folder under the NAV menu.

To search desired file using NAV menu

1. Enter NAV menu.
2. Select desired submenu from MUSIC/ VOICE/ PLAYLIST SD/MMC Card
 MUSIC : MP3 and WMA music files
 VOICE : Recorded voice files
 PLAYLIST : Playlist file
 SD/MMC Card: Files on SD/MMCcard.
4. In the MUSIC menu, all files and folders are listed under the "ROOT".
5. In the VOICE menu, all files and folders are listed under the "RECORD".
6. Press joystick up/down ►/▼ to move to desired folder or file.
 Press joystick right ► to open the folder.
 Press the joystick left ◀ to exit the folder.
 Press joystick to confirm your choice.

Note: You will not be able to open the PLAYLIST / RECORD folder under the ROOT of MUSIC menu.

System setup menu contains the following sub-menus.
 Please note each function of sub-menus.






1. EQ: Change equalizer settings (Normal, Classic, Live, Pop, Rock)
2. REPEAT Mode: Change repeating options. (refer to pg. 20)
3. Display: Adjust screen display settings.
 ID3TAG : Displays track information such as album name, artist and name of the song if any when turned on.
 LYRIC: Displays lyric when playing.
 CONTRAST : Adjust contrast of LCD
 B-LIGHT TIME : Adjust backlight illumination time
4. Auto off: Select to shut off the player automatically when it is left unattended.
5. REDORDING- REC Mode: Adjust recording quality
 VAD: Voice Activate Detection. This function adjusts volume automatically when recording voice according to input level.
6. RESUME: This is mark function, it remembers elapsed time from last music or voice file playback.
7. DELETE FILE: Delete unwanted files.
8. FORMAT: Format internal memory.
9. Reset: Reset all menu to factory setting.
10. Information-
 1. F/W Version: Select to view current F/W version.
 2. INTERNAL M. : Select to view memory status.
 3. SD/MMC Card: Select to view info in SD/MMD.

■ To setup Repeat mode using Main menu

1. Get to the "Repeat Mode" submenu by below steps.
Main menu → SYS menu → Repeat Mode
2. Press joystick to enter "Repeat Mode"
3. Press the joystick left/right ◀▶ to select the desired play mode and press it to confirm.
4. To exit the menu, press MENU button.

Note: MENU button will backing up menu each time you press the MENU button.

■ While in Playback mode

- NORMAL:  The player will play tracks in normal order
- ONE:  The player will repeat current track only.
- ALL:  The player will repeat all tracks.
- INTRO:  The player will play each track for a few seconds.
- RANDOM:  The player will play tracks in random order.


■ Starting Point "A"

While playing music or voice files, press the A-B button briefly at the beginning of the loop you want to set.

 appears in right upper corner of the display.

■ Ending Point "B"

Press the A-B button briefly again to set the end of the loop.


 appears in the display.

Now, the loop is playing repeatedly.

Press the A-B button again to cancel the loop.

Deleting

1. Follow below steps to enter the "Delete File " submenu.
Main menu → SYS menu → Delete File
2. In "Delete File" menu, it displays Music, Voice.
Press joystick to confirm an option. "Delete File" window appears




3. Press joystick left ◀◀ to select "Yes" and press joystick to delete file.
4. Press joystick right ▶▶ to select "NO" and press joystick to confirm. It will skip to the next file.

Formatting

Note: When formatting MMC Card, use this MP3 player to format, not with PC.

Formatting


1. Follow below steps to get to the "Format " submenu.
Main menu → SYS menu → Format
2. In "Format" menu, it displays INTERNAL M., SD/MMC Card.
Press joystick to confirm an option. The " Format" window appears.



3. Press the joystick left ◀◀ to select "Yes" and press the joystick to format.

Setting Resum Function On

1. Get to the RESUME menu.



2. Press joystick right ▶▶ to select "ON" and press joystick to confirm.
3. If you want it also remember the time line, perform step 2 to set the time line on.
4. The player will start with the last playback once it's turned on.
5. To set RESUME off, get to the resume menu. Slide joystick left ◀◀ to select "OFF" and press joystick to confirm.
The player will start with the first file once it's turned on.

■ Downloading F/W Upgrade

When you upgrade firmware, make sure to use new battery because it take large amount of power when upgrading. If battery run out of power during upgrading, flash memory will get damaged.

1. Make sure the player is turned off.
2. Connect USB port to the PC computer.
3. PC will automatically detect the player as "Removable disk" under MY COMPUTER.
4. Download available F/W Upgrade from our web site.
5. Select new F/W upgrade and drag-and drop it into the removable disc icon.

Note: After completing the file transfer, disconnect the player using [Stop a Hardware device]. Refer to page 13 for detail note "Disconnecting the player".

6. After remove the player, turn on the power.

Note: Player will automatically update it when the player is turn on.

■ The player does not work

1. Check the battery capacity.
 2. Check to see if the battery is inserted properly.
-

■ Download failure

1. Check to see if the driver is installed correctly in the PC.
 2. Check the connection.
 3. Check if the memory is full.
 4. Check the battery.
-

■ The buttons do not work

1. Check setting of Hold switch.
 2. Remove the battery once and then insert it again.
-

■ Poor sound quality

1. Check if the quality of music file is poor, and reformat or download it again.
-

■ Something's wrong with LCD display

1. Remove the battery and then insert it again.
-

■ The LCD displays nothing

1. Copy the font file(FTUP_COBY641_V00_04.FNT) from the supplied CD to the player's root folder.
2. Or you can download the font file from our home page: www.cobyusa.com
3. Or you can call technical support for Hot-key reboot.
Tel) 1-718-416-3197, 1-800-681-2629

Specification

Power	1xAAA Battery
Memory	512MB
Size(WXHXD)	2.2"x2.87"x0.82"
Interface	USB Rev. 1.1
Display	128x64 dots Dot-Matrix LCD
Processor	65MIPS DSP
Audio Playback	MP3 decode
Voice Recording	IMA-ADPCM encoding 32 hours recording
Signal to Noise Ratio	90dB
Frequency Response	20Hz~20KHz
Output	>5mW(each output)
Distortion Output	0.01%~0.1%
Ports	USB
WMA Format	32-192Kbps
MP3 Format	Bit Rate: 96-320Kbps, Optional
SD/MMC Card	