

# MegaVision

## TereScope Management

### User Guide



**Disclaimer**

MRV<sup>®</sup> reserves the right to modify the management application for this device at any time and in any way it sees fit in order to improve it.

MRV provides this document without any warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of merchantability or fitness for a particular purpose.

The user is advised to exercise due discretion in the use of the contents of this document since the user bears sole responsibility.

**Trademarks**

All trademarks are the property of their respective holders.

**Copyright © 2004 by MRV**

All rights reserved. No part of this document may be reproduced without the prior permission of MRV.

This document and the information contained herein are proprietary to MRV and are furnished to the recipient solely for use in operating, maintaining and repairing MRV equipment. The information within may not be utilized for any purpose except as stated herein, and may not be disclosed to third parties without written permission from MRV. MRV reserves the right to make changes to any technical specifications in order to improve reliability, function, or design.

**Document Number:** ML48200

**Document Revision:** Rev. 01

**Release Date:** November 2004

Contact Information
For customer support, you can: Contact your local MRV representative E-mail us at <a href="mailto:InternationalSupport@mrv.com">InternationalSupport@mrv.com</a> Visit our MRV Web site at <a href="http://www.mrv.com">http://www.mrv.com</a>

# Contents

<b>About this Guide .....</b>	<b>5</b>
Scope .....	5
Audience .....	5
Related Documents .....	5
Organization .....	5
Typographical Conventions .....	5
Acronyms .....	6
<b>TereScope Overview .....</b>	<b>7</b>
General .....	7
Requirements .....	7
SNMP Agent .....	7
General .....	7
Models .....	7
Layout .....	8
Setup .....	8
Cabling .....	8
<b>Management Access .....</b>	<b>9</b>
<b>Management Setup .....</b>	<b>11</b>
<b>Device Management .....</b>	<b>19</b>
Accessing the Management Window .....	19
General Device Parameters .....	20
<b>Appendix A: IP Address Unknown .....</b>	<b>25</b>
<b>Appendix B: LLB and RLB Tests .....</b>	<b>26</b>
General .....	26
LLB Test .....	26
Purpose .....	26
Data Path .....	26
Procedure .....	26

<b>RLB Test</b> .....	<b>27</b>
Purpose .....	27
Data Path.....	27
Procedure .....	27
 <b>Appendix C: Fusion Control</b> .....	<b>29</b>
<b>General</b> .....	<b>29</b>
<b>Purpose</b> .....	<b>29</b>
<b>Procedure</b> .....	<b>29</b>

## Figures

Figure 1: Straight and Cross Cable Wiring .....	7
Figure 2: Login Window .....	9
Figure 3: Map Level Window .....	10
Figure 4: Device Types Window .....	11
Figure 5: Describe Device Communication Parameters Window .....	12
Figure 6: Define Interface Window .....	13
Figure 7: DOS Command Window .....	14
Figure 8: TereScope Icon (Green) Added in Map Level Window.....	15
Figure 9: Device Parameters Configuration Window (showing TereScope default IP address)..	16
Figure 10: Device Parameters Configuration Window (showing TereScope new IP address)....	17
Figure 11: Confirm Window .....	18
Figure 13: Device Parameters Configuration Window .....	19
Figure 14: Data Path in LLB Test .....	26
Figure 15: Fusion Mode Configuration and Mode Select Status Con ... Windows.....	27
Figure 16: Data Path in RLB Test.....	27

## Tables

Table 1: Models of SNMP Agent .....	7
Table 2: DIP Switch Setting of TereScope .....	8
Table 3: General Device Parameters Fields and Tools.....	20
Table 4: Communication Parameters Fields and Tools .....	21
Table 5: Thresholds Fields and Tools .....	23

# About this Guide

## Scope

This guide shows how to manage any of the series of TereScopes (e.g., TereScope 2, TereScope 155, TereScope 2000, TereScope 4000, TereScope 5000) using MRV's MegaVision® network management application.

## Audience

This guide is intended for the use of network administrators who have working knowledge of SNMP management.

## Related Documents



- **MegaVision NMS Application User Manual**  
This manual describes how to install and use the MRV's MegaVision NMS Application.
- **MegaVision TereScope Release Notes**  
This document contains information not found in the User Guide and/or overriding information, and is produced if warranted.
- **TereScope Manual**  
This document contains information on the relevant TereScope to be managed.

## Organization

For customer convenience, the management description is organized according to the service architecture of the MegaVision Application GUI which is hierarchical.

## Typographical Conventions

The typographical conventions used in this document are as follows:

Convention	Explanation
<b>CourierBold</b>	This typeface represents information provided by/to the system.
<i>Italics</i>	This typeface is used for emphasis.
<b>Enter</b>	This format represents the key name on the keyboard or keypad.
	This icon represents important information.
	This icon represents risk of personal injury, data loss, or system damage.

## Acronyms

<b>ARP</b>	Address Resolution Protocol
<b>BER</b>	Bit-Error Rate
<b>CLI</b>	Command Line Interpreter
<b>CTS</b>	Clear To Send
<b>dB</b>	decibel
<b>DCD</b>	Data Carrier Detect
<b>DCE</b>	Data Communication Equipment
<b>DNS</b>	Domain Name System/Service
<b>DSR</b>	Data Set Ready
<b>DTE</b>	Data Terminal Equipment
<b>DTR</b>	Data Terminal Ready
<b>Gnd</b>	Ground
<b>GUI</b>	Graphical User Interface
<b>IP</b>	Internet Protocol
<b>ITU</b>	International Telecommunications Union
<b>LLB</b>	Local LoopBack
<b>LAN</b>	Local Area Network
<b>MDI</b>	Media Dependent Interface
<b>MDI-X</b>	Media Dependent Interface with cross-wiring
<b>NIC</b>	Network Interface Card
<b>NMS</b>	Network Management Station
<b>OID</b>	Object Identifier
<b>RARP</b>	Reverse ARP
<b>RI</b>	Ring Ignore
<b>RLB</b>	Remote LoopBack
<b>RMON</b>	Remote MONitoring
<b>RTS</b>	Request To Send
<b>RxD</b>	Receive Data
<b>SNMP</b>	Simple Network-Management Protocol
<b>TDM</b>	Time-Division Multiplexer/Multiplexing
<b>TELNET</b>	(dial-up) TELEphone NETwork (connection protocol)
<b>TFTP</b>	Trivial-File Transfer Protocol
<b>TxD</b>	Transmit Data
<b>UPS</b>	Uninterruptible Power Supply
<b>URL</b>	Universal Resource Location
<b>WAN</b>	Wide Area Network

# TereScope Overview

## General

The TereScope is a communication link that can carry voice, data, and video transparently over a photonic beam. The link consists, basically, of two heads, each containing a transceiver, and facing each other so that the beam interconnects them. A wide range of models is available to support various frequencies, operating ranges, and eye-safety compliance. There are models that support data rates of up to 1 Gbps and operating ranges of up to 5 km.

## Requirements

- SNMP NMS<sup>1</sup> with a 10Base-T NIC/port and MS-DOS program.
- Category 5 *cross* cable (shown in *Figure 1*, page 7) not longer than 100 m or 328 ft if the TereScope is to be connected to the SNMP NMS directly. (The SNMP NMS, e.g., PC is a DTE.)
- or
- Category 5 *straight* cable (shown in *Figure 1*, page 7) not longer than 100 m or 328 ft if the TereScope is to be connected to the SNMP NMS via a DCE (e.g., switch).




Figure 1: Straight and Cross Cable Wiring

## SNMP Agent

### General

A TereScope is SNMP manageable if it has an SNMP agent installed in each of its two heads. In models 2000, 4000, and 5000 the SNMP agent is pre-installed. TereScopes in the field can have the SNMP agent installed in them by an MRV-approved service person.

### Models

Table 1 describes the available models of the SNMP agent for TereScope management.

Table 1: Models of SNMP Agent

Model	Description
RSM-SNMP	Installable in all TereScopes, except TereScopes 4000 and 5000.
SNMP-MGT	Installable in TereScopes 4000 and 5000. This SNMP agent model provides, in addition, operation configurability, such as, Fusion and Loopback testing.

<sup>1</sup> e.g., PC running MRV's *MegaVision*® Web-based network management application.

## Layout

### Port

Protocol: Ethernet 10Base-T.

Connector: RJ45

Pinout: MDI (1 → Tx+; 2 → Tx-; 3 → Rx+; 6 → Rx-)

### LEDs

## Setup

Set the DIP switch toggles as shown in *Table 2*, page 8.

**Table 2: DIP Switch Setting of TereScope**

Toggle	Position	Function
IP configurability. (To determine the right toggle, refer to the description of the toggle on the TereScope.)	ON	Enable TereScope configuration (e.g., changing default IP address of the SNMP agent) from the SNMP NMS.  (The default IP address of the SNMP agent is marked on a sticker on the rear panel of the TereScope.)
	OFF	Disable TereScope configuration from the SNMP NMS, enable configuration at the TereScope head, and set the IP address of the SNMP agent as <b>10.0.0.101</b> .

## Cabling

Connect the TereScope management port (RJ45 connector) to an SNMP NMS either:

- Directly with a Category 5 *cross* cable, or
- Via a DCE (e.g., switch) with a Category 5 *straight* cable.




# Management Access

The procedure for accessing the MegaVision application is as follows:




1. Double-click the icon.
2. Follow the prompts until the login window (*Figure 2*) opens.



**Figure 2: Login Window**

3. Select the access level by typing the associated name (possibly **user** or **supervisor**) in the **User Name:** field.
4. In the **Password:** field, either type the password or, if the default password was not changed, leave it empty. Click **OK** or press **Enter** key to open the Map Level window (*Figure 3*).



**Figure 3: Map Level Window**

The hot spots and active areas that apply generically to devices are described in detail in the ***MegaVision NMS Application User Manual***.

The hot spot and active area that applies specifically to the TereScope is described below.



– Opens the TereScope Device Level management window.


**Green** – Communication with SNMP host OK.


**Red** – Communication with SNMP host lost.

## Management Setup

In order to manage a TereScope, certain setup actions must be performed with the TereScope and MegaVision application. In particular, these actions include setting IP addresses so that the TereScope can be managed from the same or a different subnet.


The setup procedure is as follows:

1. Set the IP configurability DIP switch toggle to the **ON** position.
2. In the Map Level window (*Figure 3*, page 10), either click the button  (top left corner) or click with the right mouse button and select **Add Device**. The **Device Types** window (*Figure 4*, page 11) opens.



**Figure 4: Device Types Window**

3. In the **Device Types** window, select **TSJ** from the list.
4. The **Describe Device Communication Parameters** window (*Figure 5*, page 12) opens.



**Figure 5: Describe Device Communication Parameters Window**

5. In the **Describe Device Communication Parameters** window:
  - a. Enter a name for the TereScope in the field **Name** and make sure that the entry in the two fields **Name for SET** and **Name for SET** is **public**.
  - b. Click on the button **Modify**. The **Define Interface** window (*Figure 6, page 13*) opens.











Figure 6: Define Interface Window

6. In the **Define Interface** window, do the following:
  - a. Enter the default **IP Address**. (The default IP address – e.g., 10.0.0.150 – is marked on a sticker on the rear panel of the TereScope).
  - b. Select **Interface Type** as **Ethernet**.
  - c. Set **Polling Interval**
  - d. Set **Time-Out**
  - e. Set **Retries**
  - f. Click  to close the window.
7. In the **Describe Device Communication Parameters** window, click  to close the window. The TereScope icon  appears in the **Map Level** window (Figure 3, page 10).
8. If the SNMP NMS and TereScope are on **different** subnets, set a new static route in the routing table of the router as follows:
  - a. Open **MS-DOS Prompt** window. (To open the window at the SNMP NMS which runs a Microsoft Operating System, click  and select . When the **Run** window opens, type **command** and click .)
  - b. At the DOS command prompt , type  
`route add [TS_IP_ADDR] mask [MASK] [MGR_IP_ADDR]`  
 Where,  
`route`, `add`, `mask` are keywords to be typed as is.

[TS\_IP\_ADDR] is TereScope default IP address (marked on a sticker on the rear panel of the TereScope).

[MASK] is Subnet Mask.

[MGR\_IP\_ADDR] is SNMP NMS IP address (e.g., PC's IP address).







Figure 7: DOS Command Window

9. Close the DOS Command window. The Map Level window (Figure 8) will show a green icon of the TereScope  to indicate that its communication with the SNMP NMS is OK.



**Figure 8: TereScope Icon (Green) Added in Map Level Window**

10. Double-click on the icon . The **Device Parameters Configuration** window (Figure 9, page 16) opens. The field **IP Address :** shows the TereScope default IP address.



**Figure 9: Device Parameters Configuration Window (showing TereScope default IP address)**

11. In the **Device Parameters Configuration** window:

- a. In the field **IP Address**, enter the new TereScope IP address. (The IP address is usually one from the IP address space of your network.)
- b. In the field **Communication Mode**, select one of the following:
  - **LAN\_Mode** if the TereScope and SNMP NMS are connected to the same IP network.
  - **Router\_Mode** if the TereScope and SNMP NMS are interconnected via a router.
- c. If **Router\_Mode** was selected, in the field **GateWay**, enter the Gateway address.
- d. Press **OK**. (The window closes.)

12. Click on the button **Parameters Config** to reopen the **Device Parameters Configuration** window (Figure 10, page 17), and verify that the IP settings are OK.







Figure 10: Device Parameters Configuration Window (showing TereScope new IP address)

13. Click the button **Reset Device** to reset the TereScope. When the **Confirm** window (Figure 11, page 18) opens, press the button .







Figure 11: Confirm Window

The communication icon  turns into  to indicate that communication is currently broken since the TereScope is undergoing reset. At the end of the reset process, the communication icon reverts to  indicating that communication has been reestablished and that the TereScope is operating with its new IP address.

# Device Management

## Accessing the Management Window

This section shows how to monitor, configure, and control the TereScope remotely.

Open the **Device Parameters Configuration** window (Figure 12, page 19).

(This window can be opened in one of the following ways:

### Way 1

In the Map Level window (Figure 8, page 15), double-click on the icon .

### Way 2

In the MegaVision Main Menu window, click on the menu button **Monitor** or **Network** and select the item **Devices List/Network Inventory...** and click. A window with the list of all devices is opened. Double-click on the row **TSJ**.)











Figure 12: Device Parameters Configuration Window

## General Device Parameters

Table 3: General Device Parameters Fields and Tools

No.	Field/Tool	Function
1	Product Type	Type of TereScope.
2	MAC Address	MAC address of the TereScope SNMP agent.
3	IP Address	IP address of the TereScope SNMP agent.
4	Comm. Mode	Communication mode. The options are: LAN_Mode TereScope is set to assume that it is on the same network as that of the SNMP NMS. Router_Mode TereScope is set to assume that it is connected to the SNMP NMS via a router.
5	GateWay	Gateway IP address.
6	SW Version	The version of the <i>firmware</i> of the SNMP Agent of the TereScope.
7	HW Version	The version of the <i>hardware</i> of the SNMP Agent of the TereScope.
8	Mgmt Port	Type of SNMP NMS port (e.g., 10Base-T Ethernet).
9	WireLink Port	Type of data port connected to the device at the end of the TereScope link, e.g., MultiMode fiber, 1310 nm operating wavelength, and 155 Mbps operating speed.
10	<div>Parameters Config</div> <div>LAN_Mode</div> <div>Router_Mode</div>	Set the IP Address, Communication Mode, and Gateway. The choices for Communication Mode are: TereScope and SNMP NMS are connected to the same IP network. TereScope and SNMP NMS are interconnected via a router.
11	Refresh	Update display from the database of the TereScope.
12	Reset Device	Ignore the changes in the window and close it. (Opens the confirm window shown in <i>Figure 11</i> , page 18.)

Table 4: Communication Parameters Fields and Tools

No.	Field/Tool	Function
1		SNMP Communication OK.
2		No SNMP Communication.
3	F/O Flag (or Electrical Flag)  (Green-ON LED)  (Red-ON LED)	SNMP Agent link to switch side. Link OK Link Faulty
4	Air RX Flag  (Green-ON LED)  (Red-ON LED)	SNMP Agent link to air link (photonic beam). Link OK Link Faulty
5	Mode Select Status and Fusion Mode can be changed via NMS!	The TereScope can be configured from the SNMP NMS, i.e., DIP switch toggle for IP configuration is set to <b>ON</b> position.
6	Change Mode Select Status and Fusion Mode only via hardware switch on the TereScope!	The TereScope can be configured only by locally and physically changing its settings, i.e., DIP switch toggle for IP configuration is set to <b>OFF</b> position.
7	Mode Select Status:	Normal TereScope set to operate normally. Local Loopback TereScope set to operate Local LoopBack mode. Remote Loopback TereScope set to operate Remote LoopBack mode.
8	Config (This tool is activated when Fusion Mode is disabled.)	Open the Mode Select Status Con... window:  The window fields/tools are: <input checked="" type="radio"/> Normal TereScope to operate normally. <input checked="" type="radio"/> Local Loopback TereScope to operate in Local LoopBack mode. <input type="radio"/> Remote Loopback TereScope to operate in






































		<p><i>Remote LoopBack mode.</i></p> <p> Accept the changes in the window and close it.</p> <p> Ignore the changes in the window and close it.</p>
9	<p><b>Fusion Status</b></p> <p> (Grey LED)</p> <p> (Green LED)</p> <p> (Black LED)</p>	<p>Fusion (redundant link) disabled.</p> <p>Fusion active; low RSSI at one end of link.</p> <p>Fusion in standby; RSSI OK.</p>
10	<b>Fusion Mode</b>	<p> Fusion mode enabled.</p> <p> Fusion mode disabled.</p>
11		<p>Open <b>Fusion Mode Configuration</b> window:</p>  <p>The window fields/tools are:</p> <p> <b>Disable</b> Deselect Fusion Mode</p> <p> <b>Enable</b> Select Fusion Mode</p> <p> Accept the changes in the window and close it.</p> <p> Ignore the changes in the window and close it</p>

Table 5: Thresholds Fields and Tools

No.	Field/Tool	Function
1		Close the window.
2		<p>Open the <b>Threshold Configuration</b> window.</p>  <p>The window fields/tools are:</p> <p>Set the lower and upper thresholds which if crossed can generate an alarm or trap.</p> <p> Lower threshold</p> <p> Upper threshold</p> <p> Strength of the signal at the receiver (RSSI) (in millivolts).</p> <p> Bias on the receiver (in volts). (For factory use.)</p> <p> Threshold temperature (in °C or °K). for TereScope</p> <p>Temperature threshold values can be set only if °K is selected as the unit of measurement.</p>
3		The actual strength of the RSSI signal at the receiver (in millivolts).
4		The actual bias on the receiver (in volts). (For factory use.)
5		The actual TereScope temperature (in °C or °K).
6		<p>Clicking the check box  under  to get  will display a speedometer chart for the row (Rx Signal Strength (RSSI), Bias, or Temperature). This chart displays the <i>instantaneous</i> value at the end of the polling interval.</p> <p>Clicking the check box  under  to get  will display a line graph for the row (Rx Signal Strength, Bias, or Temperature).</p>

		display a line chart for the row (Rx Signal Strength (RSSI), Bias, or Temperature). This chart displays the values at times that are integral multiples of the polling interval.
7		Threshold values using  .  Lower threshold  Upper threshold
8	<input checked="" type="checkbox"/> Log the RSSI, BIAS, Temperature	Start logging the RSSI, bias on the signal, temperature, etc. in the log file.
9	<input type="text" value="0"/> sec. (0 means: do not log)	TereScope Status Information Collection Interval. The value 0 means that data will not be logged. Any value in the range 1 to 300 (seconds) may be set. If a value larger than the polling interval is to be selected, it should be an integral multiple of the polling interval for the purpose of synchronization. If a value smaller than the MegaVision's polling interval is selected, data will be logged at times that are multiples of the polling interval.
10	<a href="D:\Disk_Win2000\mgv227h1\data\tsj.log">D:\Disk_Win2000\mgv227h1\data\tsj.log</a>	TereScope Status Information Collection File <b>tsj.log</b> . Clicking a check mark in the check box  will visually emphasize this field. The file can store up to 15,000 entries. When the file becomes full, its contents replace the contents of the <b>tsj.bak</b> file, which can also store up to 15,000 entries. This means that up to 30,000 newest entries can be stored in the two files. In order not to lose entries, the <b>tsj.bak</b> file must be copied to another file before the <b>tsj.log</b> file becomes full.
11		Accept value in TereScope Status Information Collection Interval field <input type="text" value="0"/> sec. (0 means: do not log).



## Appendix A: IP Address Unknown

This appendix describes the procedure for setting the IP address for a TereScope in the event that the IP address is no longer known (for whatever reason).

1. Set the IP configurability DIP switch toggle to the **OFF** position. (In this position, the IP address of the TereScope is **10.0.0.101**.)
2. In the procedure described in the section *Management Setup* (page 11), perform steps 2 to 5.
3. In step 6 set the IP address to 10.0.0.101.
4. Perform steps 7 and 9.
5. Set the IP configurability DIP switch toggle to the **ON** position.
6. Perform steps 10 to 13.
7. Verify that the new IP has been accepted.

## Appendix B: LLB and RLB Tests

### General

This appendix applies only for SNMP Agent model SNMP-MGT, described in *Table 1*, page 7.

### LLB Test

#### Purpose

The LLB test is used to determine whether the local TereScope head's electro-optical circuitry is OK.

#### Data Path

The data path (round-trip) in an LLB test is shown schematically in below. (The remote TereScope head is not used in the LLB test.)




Figure 13: Data Path in LLB Test

#### Procedure

LLB can be performed by hardware or software control. The procedure for performing LLB by hardware control is described in the relevant TereScope manual.

The procedure for performing LLB by software control is as follows.

1. Ensure that the Control Mode DIP switch toggle is set to the ON (SW MODE) position.
2. If **Config** is dimmed, i.e., it is disabled, click on **Config** in the same row as **Fusion Mode**. The window **Fusion Mode Configuration** (*Figure 14*, page 27) opens. Set ☒ **Disable** and click **OK**.
3. Click on **Config** in the same row as **Mode Select Status**. The window **Mode Select Status Con...** (*Figure 14*, page 27) opens.
4. Set ☒ **Local Loopback** and click **OK**.




Figure 14: Fusion Mode Configuration and Mode Select Status Con ... Windows

## RLB Test

### Purpose

The RLB test is used to determine whether the local TereScope head, WDM cabling connected to it, and remote TereScope head's air link interface are OK.

### Data Path

The data path (roundtrip) in an RLB test is shown schematically in below.




Figure 15: Data Path in RLB Test

### Procedure

RLB can be performed by hardware or software control. The procedure for performing RLB by hardware control is described in the relevant TereScope manual.

The procedure for performing RLB by software control is as follows.

1. Ensure that the Control Mode DIP switch toggle is set to the ON (SW MODE) position.
2. If **Config** is dimmed, i.e., it is disabled, click on **Config** in the same row as **Fusion Status**. The window **Fusion Mode Configuration** (Figure 14, page 27) opens. Set **Disable** and click **OK**.
3. Click on **Config** in the same row as **Mode Select Status**. The window **Mode Select Status Con...** (Figure 14, page 27) opens.
4. Set **Remote Loopback** and click **OK**.

**Note**

When RLB mode is set, the SNMP NMS is included in the RLB loop. An NMS outside the RLB loop cannot be used to exit the RLB mode.

# Appendix C: Fusion Control

## General

This appendix applies only for SNMP Agent model SNMP-MGT, described in *Table 1*, page 7.






## Purpose

MRV's Fusion system, in full redundancy mode, activates a radiowave link when the IR laser link of the TereScope fails so that the TereScope continues to operate as if the failure did not occur. The Fusion system is constructed to maximize availability to 99.999% between network nodes and operates in most weather conditions including rain, snow, and fog.

## Procedure

Fusion can be performed by hardware or software control. The procedure for performing Fusion by hardware control is described in the relevant TereScope manual.

The procedure for performing Fusion by software control is as follows.

1. Ensure that the Control Mode DIP switch toggle is set to the ON (SW MODE) position.
  2. If  is dimmed, i.e., it is disabled, click on  in the same row as . The window **Fusion Mode Configuration** (*Figure 14*, page 27) opens. Set  **Enable** and click .
-