



---

A Sierra Monitor Company

**Driver Manual**  
**(Supplement to the FieldServer Instruction Manual)**

**FS-8700-93 EST QuickStart**

**APPLICABILITY & EFFECTIVITY**

**Effective for all systems manufactured after December 2012**

Driver Version:	1.05
Document Revision:	2

**TABLE OF CONTENTS**

<b>1</b>	<b>EST QuickStart Description.....</b>	<b>3</b>
<b>2</b>	<b>Driver Scope of Supply .....</b>	<b>3</b>
2.1	Supplied by FieldServer Technologies for this driver.....	3
<b>3</b>	<b>Hardware Connections.....</b>	<b>4</b>
3.1	Pinouts .....	4
3.2	Hardware Connection Tips / Hints.....	4
<b>4</b>	<b>Data Array Parameters.....</b>	<b>5</b>
<b>5</b>	<b>Configuring the FieldServer as an EST QuickStart Client .....</b>	<b>6</b>
5.1	Client Side Connection Parameters .....	6
5.2	Client Side Node Parameters .....	6
5.3	Client Side Map DescriptorParameters .....	7
5.3.1	<i>FieldServer Related Map Descriptor Parameters.....</i>	7
5.3.2	<i>Driver Specific Map Descriptor Parameters .....</i>	7
5.4	Map Descriptor Example. ....	8
<b>Appendix A.</b>	<b>Useful Features.....</b>	<b>9</b>
Appendix A.1.	FieldServer Synchronization.....	9
Appendix A.2.	Clear All Data Arrays - Map Descriptor Example.....	10
<b>Appendix B.</b>	<b>Reference .....</b>	<b>11</b>
Appendix B.1.	Device States .....	11
Appendix B.2.	Data Array Memory Allocation by Card.....	11
Appendix B.3.	Device Addressing .....	13
Appendix B.4.	Message Types Supported .....	13
Appendix B.5.	Error Messages .....	15
Appendix B.6.	Driver Statistics.....	15

## 1 EST QUICKSTART DESCRIPTION

The EST QuickStart Serial driver allows the FieldServer to record data from Edwards Systems Technology QS1-2/4-8 and QSC Fire Panels over the RS-232 printer port. The FieldServer acts as a Passive Client receiving messages and recording the status of Fire Alarm System points connected to the EST QuickStart fire alarm control panel in bit oriented Data Arrays. The EST QuickStart panels do not support duplexed communications; therefore this driver has not been designed to respond or to generate polls.

The Driver is limited by the information that the EST QuickStart control panels broadcasts in the form of text messages through its RS-232 printer port.

The types of EST messages supported by this driver are listed in Appendix B.1. Device status to Data Array mapping is also provided. Since there are a variety of optional cards that can be selected for each EST QuickStart installation, each FieldServer application must be specifically configured before use. FieldServer data storage arrays for panel status will be allocated according to the number and type of cards implemented. Message information will also be stored according to card and panel addressing.

This driver is connection oriented; therefore, only one EST Panel may be connected to any single RS-232 FieldServer port.

The driver currently accommodates European and American Conventional/Intelligent panels using the American English protocol with provisions for using the British English protocol at a later date.


## 2 DRIVER SCOPE OF SUPPLY

### 2.1 Supplied by FieldServer Technologies for this driver

FieldServer Technologies PART #	Description
FS-8917-16	Cable, EIA232:485 Pigtail RJ45 Port

### 3 HARDWARE CONNECTIONS

The FieldServer is connected to the EST QuickStart power supply card as shown below. Configure the EST QuickStart panel according to manufacturer's instructions.



#### 3.1 Pinouts

RJ45 Pin	From RJ45	Color	QuickStart Panel
RJ45-01	Rx	Brown	Tx
RJ45-08	Tx	White/Orange	Rx
RJ45-04	GND	Blue/white	COM

#### 3.2 Hardware Connection Tips / Hints

The QuickStart panels must be pre-configured using their own proprietary configuration tool to send messages to the RS-232 printer port. Ensure that this is done before attempting to connect to the FieldServer and verify that messages are being sent using an appropriate utility e.g. Hyperterminal.

## 4 DATA ARRAY PARAMETERS

Data Arrays are “protocol neutral” data buffers for storage of data to be passed between protocols. It is necessary to declare the data format of each of the Data Arrays to facilitate correct storage of the relevant data.

Section Title		
Data_Arrays		
Column Title	Function	Legal Values
Data_Array_Name	Provide name for Data Array	Up to 15 alphanumeric characters
Data_Array_Format	Provide data format. Each Data Array can only take on one format.	Bit, UInt16, Packed_Bit
Data_Array_Length	Number of Data Objects. Must be larger than the data storage area required by the Map Descriptors for the data being placed in this array.	1-10, 000

### Example

```
// Data Arrays
Data_Arrays
Data_Array_Name , Data_Array_Format , Data_Array_Length
DA_AI_01      , UInt16           , 200
DA_AO_01      , UInt16           , 200
DA_DI_01      , Bit              , 200
DA_DO_01      , Bit              , 200
```

## 5 CONFIGURING THE FIELD SERVER AS AN EST QUICKSTART CLIENT

For a detailed discussion on FieldServer configuration, please refer to the FieldServer Configuration Manual. The information that follows describes how to expand upon the factory defaults provided in the configuration files included with the FieldServer (See ".csv" sample files provided with the FieldServer).

This section documents and describes the parameters necessary for configuring the FieldServer to communicate with a EST QuickStart Server.

It is possible to connect the Edward QuickStart panel to any RS-232 or RS-485 (with adapter) port on a FieldServer. These ports need to be configured for Protocol="qstart" in the configuration files.

### 5.1 Client Side Connection Parameters

Section Title		Legal Values
Column Title	Function	
Connections		
Port	Specify which port the device is connected to the FieldServer	P1-P8, R1-R2 <sup>1</sup>
Protocol	Specify protocol used	qstart
Baud*	Specify baud rate	<b>9600</b> (vendor limitation)
Parity*	Specify parity	<b>None</b> (vendor limitation)
Data_Bits*	Specify data bits	<b>8</b> (vendor limitation)
Stop_Bits*	Specify stop bits	<b>1</b> (vendor limitation)
Handshaking*	Specify hardware handshaking	<b>None</b> (vendor limitation)
Ic_timeout	Specify intercharacter timeout	<b>2.0s</b>

#### Example

```
//      Client Side Connections
Connections
Port    , Protocol   , Baud    , Parity      , Ic_Timeout
P3      , qstart     , 9600    , None       , 2.0s
```

### 5.2 Client Side Node Parameters

Section Title		Legal Values
Column Title	Function	
Nodes		
Node_Name	Provide name for node	Up to 32 alphanumeric characters
Node_ID	Address of physical Server node	1-255
Protocol	Specify protocol used	qstart
Connection	Specify which port the device is connected to the FieldServer	P1-P8, R1-R21

<sup>1</sup> Not all ports shown are necessarily supported by the hardware. Consult the appropriate Instruction manual for details of the ports available on specific hardware.

**Example**

```
// Client Side Nodes

Nodes
Node_Name , Node_ID , Protocol , Connection
Node_A     , 1        , qstart    , P1
```

**5.3 Client Side Map DescriptorParameters****5.3.1 FieldServer Related Map Descriptor Parameters**

Section Title	Map Descriptors	Column Title	Function	Legal Values
Map_Descriptor_Name	Name of this Map Descriptor		Up to 32 alphanumeric characters	
Data_Array_Name	Name of Data Array where data is to be stored in the FieldServer			One of the Data Array names from Section 4
Data_Array_Offset	Starting location in Data Array			0 to maximum specified in Section 4
Function	Function of Client Map Descriptor			Passive

**5.3.2 Driver Specific Map Descriptor Parameters**

Section Title	Map Descriptors	Column Title	Function	Legal Values
Node_Name	Name of Node to fetch data from			One of the Node names specified in Section 5.2.
Msg_Type	Identifies the message type of the Map Descriptor.			Trouble, Other, State
Panel*	Id of QuickStart panel			0-22, <b>0</b>
Card*	Id of Card			0-9, <b>0</b>
Length*	Length of Map Descriptor			Permissible range of addresses based on Data Array size
Address*	Starting address of read block			<b>0</b> for passive Clients

## 5.4 Map Descriptor Example.

All messages will be recorded into the Data Arrays designated to this port as described in Section 4. The Message Type, Panel, Card, and Address fields are used to match the appropriate Map Descriptor for updating data.

```
// Client Side Map Descriptors
```

### Map Descriptors

Map_Descriptor_Name	Data_Array_Name	Data_Array_Offset	Function	Node_name	Msg_type	Panel	Card	Address	Length
SLV_PSEUDO	DA_PSEUDO	0	Passive	Node_A	Other	0	0	0	50
SLV_PSEUDO_TR	DA_PSEUDO_TR	0	Passive	Node_A	Trouble	0	0	0	50
SLV_ZONE	DA_ZONE	0	Passive	Node_A	Other	0	17	0	500
SLV_ZONE_TR	DA_ZONE_TR	0	Passive	Node_A	Trouble	0	17	0	500
SLV_AND_GRP	DA_AND_GRP	0	Passive	Node_A	Other	0	18	0	100
SLV_AND_GRP_TR	DA_AND_GRP_TR	0	Passive	Node_A	Trouble	0	18	0	100
SLV_MTRX_GRP	DA_MTRX_GRP	0	Passive	Node_A	Other	0	19	0	100
SLV_MTRX_GRP_TR	DA_MTRX_GRP_TR	0	Passive	Node_A	Trouble	0	19	0	100
SLV_SVC_GRP	DA_SVC_GRP	0	Passive	Node_A	Other	0	20	0	200
SLV_SVC_GRP_TR	DA_SVC_GRP_TR	0	Passive	Node_A	Trouble	0	20	0	200
SLV_TIME_CTRL	DA_TIME_CTRL	0	Passive	Node_A	Other	0	21	0	50
SLV_TIME_CTRL_TR	DA_TIME_CTRL_TR	0	Passive	Node_A	Trouble	0	21	0	50
SLV_OP_GRP	DA_OP_GRP	0	Passive	Node_A	Other	0	22	0	500
SLV_OP_GRP_TR	DA_OP_GRP_TR	0	Passive	Node_A	Trouble	0	22	0	500
SLV_CPU_RSRV	DA_CPU_RSRV	0	Passive	Node_A	Other	1	0	0	50
SLV_CPU_RSRV_TR	DA_CPU_RSRV_TR	0	Passive	Node_A	Trouble	1	0	0	50
SLV_PSEUDO	DA_PSEUDO	0	Passive	Node_A	state	0	0	0	50

The driver internally calculates the correct offset for each message type. Refer to Appendix B.2.

QuickStart is a passive Client and neither reads or writes to another device

There can only be one node per port. This field indirectly links the FieldServer port to a data storage array. Refer to Section 5.2

Messages are defined as either trouble, other or state types.

The values for state that will be stored are as follows:

NORMAL	0
ALARM	1
SUPERVISOR	3
TROUBLE	4
MONITOR	6
DISABLE	7

For this driver, address should always be zero. It defines the lowest possible expected address value.

Acceptable ranges for address are determined by the card type. Each card has an expected maximum address which this field defines.

## Appendix A. Useful Features

### Appendix A.1. FieldServer Synchronization

To synchronize the FieldServer's Data Arrays with the QuickStart control panel's status, the panel must have no active or disabled points on FieldServer startup. Alternatively, a panel can be hard/soft restarted to clear all point status, and then re-annunciate any active devices after the FieldServer has been started. This should only be undertaken by qualified technicians.

Should the panel be soft restarted unexpectedly, the FieldServer will recognize the "restart" command and clear all internal Data Arrays. There will be no need for FieldServer restart. For a hard restart, the FieldServer Data Arrays should be manually cleared by changing a bit in the CLEAR\_FLAG Data Array through RUINET, then soft restarting the panel again to ensure that status of all points is re-annunciated and recorded by the FieldServer.

A method for manually clearing all Data Arrays for the QuickStart driver is available. This is useful if the QuickStart Panel is hard re-started, and the user wishes to synchronize the FieldServer Data Arrays. To enable this feature, a CLEAR\_FLAG Data Array needs to be declared in the configuration file that is 16 bits long. To invoke a manual clear, any bit within the array needs to be set to high or "1". (See FieldServers RUINET user manual for detailed instructions on user operations) After the clearing function has been completed, all bits within the CLEAR\_FLAG array should be automatically set to zero again.

## Appendix A.2. Clear All Data Arrays - Map Descriptor Example.

```
// Data Arrays  
Data_Arrays  
Data_Array_Name , Data_Format , Data_Array_Length  
CLEAR_FLAG , Bit , 16
```

Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Panel , Card , Address , Length
CLEAR_CHK , CLEAR_FLAG , 0 , , Wrbx , Node_A , 0 , 0 , 0 , 16

This array needs to be declared in order to manually reset all Data Arrays

QuickStart is a passive Client and neither reads or writes to another device. WRBX monitors the identified Data Array for changes, and invokes the clear function when this occurs.

Use these default panel id, card id, and device address as dummy values

Set to the defined length of the CLEAR\_FLAG array

## Appendix B. Reference

### Appendix B.1. Device States

Each addressable device connected to the QuickStart panel (real or pseudo) can have multiple states: alarm supervisory, monitor, other (security), and troubles. Since these states are not exclusive; a single addressable point may occupy multiple states at the same time.

There can only be a single alarm, supervisory, monitor and other (security) state per address, thus any restoring messages for these four states indicate that the device is clear of any active problems for these types of conditions.

There may be several trouble states for a single addressable port. These trouble states are recorded in a separate trouble array of 2 byte elements. Each array element corresponds to a device address and each bit within the element corresponds to a trouble type. The mapping of message trouble types to element bit configuration is presented in the following table. For modeling simplicity and flexibility, it is assumed that all addressable points (real or pseudo) can exist in all states.

Message Type		State	Bit /UINT16/Packed_Bit
TROUBLE OPEN	TBL OPEN RST	T	0
TROUBLE SHRT	TBL SHRT RST	T	1
LCL TROUBLE	LCL TRBL RST	T	2
DIRTY HEAD	DTY HEAD RST	T	3
COMMN FAULT	COMM FLT RST	T	4
GROUND FAULT	GND FLT RST	T	5
INTERNAL TBL	INTR TRBL RS	T	6
BAD TYPE	BAD TYPE RST	T	7
BAD PRSONATY	BAD PRSTY RS	T	8
UNEPECT DEV	UNEC DEV RST	T	9
TROUBLE	TROUBLE RST	T	10
TEST	TEST RST	T	11
DEV COMPATBL	DEV COMP RST	T	12
SERVICE GRP	SERVICE G RS	T	13
DISABLED	DISABLED RST	T	14
DISAB SOUND	DISSOUND RST	T	15

### Appendix B.2. Data Array Memory Allocation by Card

Each QuickStart card (real and pseudo) is configured with BIT and UNIT16 Data Arrays. The following states are recorded in the BIT array in the order listed.

- Alarms
- Supervisory
- Monitor
- Other (security)

Troubles are recorded in a separate array of UINT16 or Packed\_Bit elements. Each element represents a uniquely addressable point, and each bit within the element represents a different type of trouble condition which is described by the specific trouble message.

The following table lists the BIT and UINT16/Packed\_Bit Data Array sizes that should be configured for every panel by default, and arrays for each optionally installed card. The Data Arrays configured for all QuickStart panels are for cards (real and pseudo) which always have fixed card addresses. Not all of these default Data Arrays will be utilized for every installation. Optionally installed cards can have variable card id #'s depending on the sequence the cards are installed.

Data Arrays are referenced relatively according to their declared size. Therefore, care must be taken to ensure that the array sizes are configured as below.

Card/Array Descriptions	Array Size	Data Type
Pseudo points	200	BIT
Pseudo point troubles	50	UINT16/Packed_Bit
Zones	2000	BIT
Zone troubles	500	UINT16/Packed_Bit
AND group	400	BIT
AND group troubles	100	UINT16/Packed_Bit
Matrix group	400	BIT
Matrix group troubles	100	UINT16/Packed_Bit
Service group	800	BIT
Service group troubles	200	UINT16/Packed_Bit
Time control	200	BIT
Time control troubles	50	UINT16/Packed_Bit
Output group	2000	BIT
Output group troubles	500	UINT16/Packed_Bit
CPU reserved	200	BIT
CPU reserved troubles	50	UINT16/Packed_Bit
Power card	200	BIT
Power card troubles	50	UINT16/Packed_Bit
<b>Optional Cards</b>		
ADC (dual loop)	2000	BIT
ADC (dual loop) troubles	500	UINT16/Packed_Bit
SLIC	2000	BIT
SLIC troubles	500	UINT16/Packed_Bit
Class A card	200	BIT
Class A card troubles	50	UINT16/Packed_Bit
Class B card	200	BIT
Class B card troubles	50	UINT16/Packed_Bit
Relay card	200	BIT
Relay card troubles	50	UINT16/Packed_Bit
Annunciator (per card)	200	BIT
Annunciator troubles (per card)	50	UINT16/Packed_Bit
Dialer	200	BIT
Dialer troubles	50	UINT16/Packed_Bit

### Appendix B.3. Device Addressing

The following table defines the address space expected by the driver for each type of card. The table includes both physical and pseudo points used by the QuickStart systems.

	Panel	Card	Address	Card Type
Point Addressing	0	0	0-18 (49)	pseudo points
	0	17	0-480 (499)	zone
	0	18	0-64 (99)	AND group
	0	19	0-64 (99)	matrix group
	0	20	0-128 (199)	service group
	0	21	0-32 (49)	time control
	0	22	0-250 (499)	output group
	1	0	0-32 (49)	CPU (reserved)
	2	0	0-33 (49)	annunciator
	3	0	0-33 (49)	annunciator
	4	0	0-33 (49)	annunciator
	5	0	0-33 (49)	annunciator
	6	0	0-33 (49)	annunciator
	7	0	0-33 (49)	annunciator
	8	0	0-33 (49)	annunciator
	9	0	0-33 (49)	annunciator
	1	01-07	0-341 (499)	ADC
	1	01-07	0-275 (499)	SLIC
	1	01-13	0-19 (49)	Class B (ZA16-8)
	1	01-13	0-11 (49)	Class A (ZA8-2)
	1	01-13	0-11 (49)	Relay (ZR-8)
	1	14	0-16 (49)	Dialer (DLD)
	1	15	0-24 (49)	Power (PS6)

### Appendix B.4. Message Types Supported

The driver reports messages that directly affect device status only. The following set of events and messages will be recognized and recorded in the Data Arrays.

Event Description Text Strings		State	Comments
ACTIVATE RESTART			-OPERATOR COMMAND- clears all the Data Arrays
QUIESCENT			Not Implemented
ALARM ACTIVE		A	
PULL STATION		A	
HEAT ALARM		A	
WATERFLOW		A	
STAGE ONE		A	

Event Description Text Strings	State	Comments
SUPERVISORY	SUP RST	S
TAMPER	TAMPER RST	S
SECURITY	SECURITY RST	O
FIREPHONE	PHONE RST	M
MONITOR	MONITOR RST	M
LATCH SUPV	LAT SUPV RST	S
LATCH TAMPER	LAT TAMP RST	S
UNKNOWN	UNKNOWN RST	O
ALARM VERIFY	ALM VFY RST	M
PREALARM	PREALARM RST	M
TROUBLE OPEN	TBL OPEN RST	T
TROUBLE SHRT	TBL SHRT RST	T
LCL TROUBLE	LCL TRBL RST	T
MAINT ALERT	MAT ALERT RS	M
DIRTY HEAD	DTY HEAD RST	T
COMMN FAULT	COMM FLT RST	T
GROUND FAULT	GND FLT RST	T
INTERNAL TBL	INTR TRBL RS	T
BAD TYPE	BAD TYPE RST	T
BAD PRSONATY	BAD PRSTY RS	T
UNEPECT DEV	UNEC DEV RST	T
TROUBLE	TROUBLE RST	T
RELAY CONFIR	RLY CFRM RST	M
LCL MONITOR	LCL MNTR RST	M
SWITCH	SWITCH RST	M
TEST	TEST RST	T
DEV COMPATBL	DEV COMP RST	T
AND GROUP	AND GRP RST	A
MATRIX GROUP	MATRIX G RST	A
SERVICE GRP	SERVICE G RS	T
TIME CONTROL	TIME CNTL RS	M
ACK	ACK RST	M
DISABLED	DISABLED RST	T
DISAB SOUND	DISSOUND RST	T
OBJECT RUN	OBJETRUN RST	M
ZONE ALARM	ZONE ALM RST	A
ZONE SUPER	ZONE SUP RST	S
ZONE MONITOR	ZONE MON RST	M
OUTPUT GROUP	OUTPUT G RST	M
AUDIBLE	AUDIBLE RST	M
VISUAL	VISUAL RST	M
SUPER OUTPUT	SUPER OUT RT	M
NONSUPER OUT	NONSUP OUT R	M
COMM ALM OUT	COMMALOUTRST	M
LED OUTPUT	LEDOUTPU RST	M

## Appendix B.5. Error Messages

Error Message	Corrective Action
Qstart:#1 Err. Illegal Map Descriptor length - defaulting to 1	Check configuration file settings, the length field is not appropriately set. <sup>2</sup>
Qstart:#2 Err. Card value error	Check configuration file settings, printed circuit board card id numbers must be 0-22 per QuickStart's addressing scheme above. <sup>2</sup>
Qstart:#3 Err. Panel value error	Check configuration file settings, panel id numbers must be 0-9 per QuickStart's addressing scheme above. <sup>2</sup>
Qstart:#4 Err. Message Type error	Check configuration file settings, message type must be either "trouble", or "other". <sup>2</sup>
Qstart:#5 Err. Test file <%s> not found.	For developmental diagnostics only, call Technical Support
Qstart:#6 Err. Diagnostic line ignored.	For developmental diagnostics only, call Technical Support
Qstart:#7 Err. parsing Event message\n%s	Call Technical Support
Qstart:#8 Err. storing Event message\n%s	Call Technical Support
Qstart:#9 Err. Message address <%d> exceed Data Array size <%d>	Call Technical Support
Qstart:#10 Err. Incoming data is being abandoned on port %d. MapDesc's are required to define storage for message:\n%s	Check that a valid Map Descriptor exists in the configuration files for message. Call Technical Support
Qstart:#17 Err. No polling allowed. Presumed write thru abandoned! Map Descriptor <%s>	Writes are not possible; avoid writes from SCADA system or from Ruinet.

## Appendix B.6. Driver Statistics

The following table identifies statistics generated by the EST QuickStart serial driver and their meanings.

Driver Statistics Recorded	Explanation
Message received	Total number of messages of all types
Bytes received	Total number of bytes received by all message types.
Message ignored	Ignored messages include those discarded by the complete function's sliding window criteria, and unrecognized messages in the parsing function. The sliding window discards the first line of three line messages if the correct line pattern is not recognized. Therefore, this stat counts both discarded lines, and messages if they could not be parsed.
Protocol	Protocol error, the message is recognized but does not take a valid form.

<sup>2</sup> Modify the configuration CSV file, transfer the modified file to the FieldServer and reset the FieldServer for the modifications to take effect