# How to get started

with

# Kongsberg XP Auto systems

Serial number: \_\_\_\_\_

# Please Read This First

Note

We remind you that only the Esko staff, or persons having received appropriate training, are allowed to handle, manipulate or do repairs on the system.

A Publication of: Esko-Graphics Kongsberg AS

Copyright © 1984-2014 Esko.

This copyright does not indicate that this work has been published.

All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the publisher.

**Esko** reserves the right to change specifications without notice.



**Esko-Graphics Kongsberg AS** 

www.esko.com

P.O.Box 1016, N-3601 Kongsberg, Norway

Tel: +47 32 28 99 00 Fax: +47 32 28 85 15 / 32 28 67 63

Document number: D3123

Status: 110126

#### Table of content

1.	Introduction	5
2.	Where to find information	5
	Safety issues	
	What is received?	
	Unpack the equipment	
6.	Installation	7
	Start-up and Shut-down procedures	
	Table operation	
9.	What can the system be used for?	9
10.	Who are allowed to use the system?	9
	Software updates	
	Maintenance	

#### © Copyright Esko

All rights reserved. This material, information and instructions for use contained herein are the property of Esko. There are no warranties granted or extended by this document. Furthermore Esko does not warrant, guarantee or make any representations regarding the use, or the results of the use of the system or the information contained herein. Esko shall not be liable for any direct, indirect, consequential or incidental damages arising out of the use or inability to use the system or the information contained herein.

The information contained herein is subject to change without notice. Revisions may be issued from time to time to advise of such changes and/or additions.

No part of this system may be reproduced, stored in a data base or retrieval system, or published, in any form or in any way, electronically, mechanically, by print, photoprint, microfilm or any other means without prior written permission from Esko.

This document supersedes all previous dated versions.

Correspondence regarding this publication should be forwarded to:

Global Support Esko-Graphics Kongsberg AS Kirkegårdsveien 45 N-3616 KONGSBERG

### **EC DECLARATION OF CONFORMITY FOR MACHINERY**

in the sense of the EC-directive 2006/42/EC Annex 11, 1A

#### Manufacturer:

• Esko-Graphics Kongsberg AS, Kirkegårdsveien 45, N-3600 Kongsberg, Norway For manufacturing plant, see type plate.

The manufacturer declares that

Product: KONGSBERG Digital Converting Machine

Type: XPnnA

Serial number:

is in conformity with the provisions of the Machinery Directive 2006/42/EC, as amended, and with national implementing legislation;

is in conformity with the provisions of the following other EEC directives:

- 2004/108/EC (EMC)
- 2006/95/EC (LVD)

has completed EMC test according to

- EN 61000-6-3 (2007)
- FCC CFR 47 Part 15 (2007) Class A
- EN 61000-6-2 (2005)

and furthermore declares that the following harmonized standards have been applied:

EN 1010-1:2004, EN 1010-3:2002, EN ISO 12100-1:2003+A1:2009,

EN ISO 12100-2:2003+A1.2009, EN ISO 13849-1:2008 and EN 60204-1:2006

Conformity evaluation body:

Nemko GmbH & Co, Reetzstrasse 58, 76318 - Pfinztal, Germany

Type-examination certificate no: xx

The above-mentioned product corresponds to the prototype for which the Statement of Conformity certificate was issued.

The responsible person for documentation is: Emil Skarra.

Kongsberg, June 15, 2010

Emil Skarra

Managing Director





### **EC Declaration of Conformity**

as defined by EU-directive 2002/95/EG RoHS Kongsberg, 26th of April 2006

Reference is made to the European Union Restriction of Hazardous Substances Directive 2002/95/EG RoHS, related to forbidden substances in electrical and electronic equipment. We hereby confirm that our standard products are free from the defined forbidden materials as of the date of this statement, and consequently fully in compliance with said directive coming into force on July the 1st 2006.

Emil Skarra

Managing Director

Esko-Graphics Kongsberg AS

Emil Sleana

# 1. Introduction

Dear customer

Welcome to co-operation with Esko. This document is a brief introduction to the system you are about to receive.

# 2. Where to find information

The following documentation is available for the equipment

Title	Target personnel	Media, shipment	Language	Purpose
How to get started	Customer	Paper prior to installation. Online in shipment (pdf).	Local <sup>(1)</sup> and US	Shortform introduction.
Site Preparation Instruction Manual	Customer	Paper prior to installation. Online in shipment (pdf).	Local <sup>(1)</sup> and US	How to prepare for installation.
User Manual for XPA	Customer	Online in shipment (pdf).	Local (1) and US	User manual.
Online Help	Customer	Online (chm) in shipment.	Local (1) and US	Context sensitive help (2)
Service Guide ARS	Service	Online in shipment (pdf).	US	Technical information aimed for service needs.
Technical Reference	Tech. support personnel	Online in shipment (pdf).	US	Technical information for special purpose.
Test manual	Service	Online in shipment (pdf).	US	How to run HWTXP test programs.
Technical Manual	Service	Online in shipment (pdf).	US	Technical information aimed for service needs.
Installation Manual	Service	Online in shipment (pdf).	US	Technical information aimed for service needs.
Maintenance Manual	Customer/ Service	Online in shipment (pdf).	US	Technical information aimed for service needs.
Training plan	Customer/ Service	Online in shipment (pdf).	Local (1) and US	A plan for customer training.
Questionnaire Customer feedback sheet.	Customer	Online in shipment (pdf).	Local <sup>(1)</sup> and US	Customer feedback about installation and training.

1) Local languages supported will be listed here.

2) You can run the Context Sensitive Help system as a stand alone program. Execute the file xpguide\_xx.chm located in c:\xpguide\system. xx defines the language of the file; the US version has the name: xpguide\_us.chm.

### 2.1 Site preparation

The information you need for planning and preparing the installation of the Kongsberg XP Auto system is described in the Site Preparation Instruction handbook.

All preparations given in that handbook should be completed before the Esko Service Engineers arrive on-site to assemble the system.

All technical data and requirements about the equipment are found in this manual.

#### 2.2 User Manual for XP Auto

The User Manual is available from the XP-Guide CD and from the XP-Guide user interface. The User Manual contains all information needed about:

- Operator safety.
- ♦ How to operate the system.
- ♦ How to adjust the system properly.
- System description.
- Daily maintenance.

### 3. Safety issues

Your Kongsberg XP Auto system is built for high speed and productivity. Hence, the system represents potential hazard if operating procedures and safety precautions are not followed. Danger zones are designed away as far as practically possible and the system is equipped with additional provisions for warning against potential hazards. These additional provisions are:

- 'Warning signs' on moving parts.
- 'Do not touch' signs at critical areas.
- 'Warning' sign on the electrical control unit.
- Warnings in the Online Help system.

The safety issues including a label plan are described in the User Manual topic 'Safety regulations'.

Special attention should be paid upon the following:

- Be careful when handling knives. Knives are extremely sharp.
- Be careful when handling heavy materials. Take care of your own health. Be careful not to hit parts of the tools and the tool head.
- The system is equipped with a class II laser pointer. Avoid laser beam hit your eyes.
- The main power on/off switch on the Operator stand is for daily power on/off. To permanently remove mains from the equipment, remove the power cable to the equipment from the wall outlet. (If wall outlet is not available, turn off the mains power switch.)

Work flows and awareness of potential hazards should be periodically reviewed by the customer's safety responsible

### 4. What is received?

A specification of the delivery is found in the 'Customer Specification sheet' following the shipment.

## 5. Unpack the equipment

Only Esko Service Engineers are allowed to unpack the equipment.

### 6. Installation

Only Esko Service Engineers are allowed to install the equipment.

# 7. Start-up and Shut-down procedures

## 7.1 Start up

- Turn on the PC.
- From the desktop, start XP-Guide.
- Follow the start-up procedure described in the User Manual.

### 7.2 Shut down

• Follow the shut-down procedure described in the User Manual.

## 8. Table operation

For detailed information on how to operate the system, be familiar with the User Manual and complete the following sequences:

- Get started.
- Basic operation.
- ♦ Table setup.
- ◆ Tool heads and tools.

### 9. What can the system be used for?

The system is designed for use within applications, materials, tools and workflow as described in the Work flow and How to chapters in the User Manual. Any other use is considered non-intended use.

#### Examples of non-intended use:

- Operation by operators not meeting the requirements as described above.
- Unauthorized modifications (bridging safety devices, removing covers etc.)
- Utilizing accessories other than those specified by Esko.

#### Non-intended use may cause:

- ♦ Health hazards and injuries.
- Damage to the system.
- Incorrect functionality.
- Damage to work materials.

#### Esko is not liable for use of the system when these guidelines are not followed.

### 10. Who are allowed to use the system?

Only personnel trained by Esko authorized personnel are allowed to operate the system. Training will be given to customer appointed operator(s) by the Esko Service Engineer as part of the installation. The training covers:

- Safety regulations
- Start-up and shut-down procedures
- Online help
- ♦ Set-up procedures
- Adjustment procedures
- Workflow
- ♦ Maintenance

For additional training courses contact Esko Service Organization.

#### <u>Un-trained personnel shall under no circumstances be allowed to operate the system!</u>

# 11. Software updates

Follow the installation procedure on the CD cover. The procedure is also described in the User Manual.

## 12. Maintenance

The maintenance done by the customer is limited to preventive maintenance. This is described in the User Manual.

Any other maintenance, repair, replacement of parts etc. must be done by Esko authorized personnel only.