



NTC/2094
DVB-RCS Indoor Unit
Installer Manual

TO WHOM IT MAY CONCERN

EC DECLARATION OF CONFORMITY

We,

NEWTEC n.v.

declare that our product

- "NTC/2094/AB DVB-RCS" Indoor Unit

to which this declaration relates is in conformity with :

the requirements of the R&TTE Directive 1999/5/EC

in accordance with the harmonised standards listed below :

For the essential EMC requirements contained in Directive 89/336/EEC

EN 55022:1998 Radio disturbance characteristics of information technology equipment

EN 61000-3-2:2000 Limits for harmonic current emissions

EN 61000-3-3:1995 Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems

EN 55024:1998 Immunity characteristics of information technology equipment

EN 61000-4-2:1995+A2:2000

Electro Static Discharge

EN 61000-4-3:

1995 Radiated Susceptibility

EN 61000-4-4:

1995 Electrical Fast Transient/Burst immunity

EN 61000-4-5:

1995 Surge immunity

EN 61000-4-6:

1996 Immunity to conduct disturbances

For the safety requirements contained in Directive 73/23/EEC

EN 60950:92 incl. A1-A4 and A11:97 Safety of information technology equipment

Done at Sint-Niklaas, on November 21st, 2003

Dirk Breynaert,
Managing Director

Relevant EMC information

(to FCC rules)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SAFETY

Please read this chapter before installation and use of the instrument

The power cord, used to connect the equipment to a socket outlet, must have an incorporated earthing ground. The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. The building installation shall be regarded as providing protection in accordance with the rating of the wall socket outlet.

In USA and Canada, the equipment may only be used with a 15 A branch circuit protection.

Any interruption of the protective conductor, inside or outside the instrument, is likely to make the instrument dangerous. Intentional interruption is prohibited.

Power cords must have the following specifications to ensure a proper and safe power connection:

- 1) 250 Vac, 10 A, 1 mm² (EU) or 16 AWG (US, CA).
- 2) The appropriate national specification are listed below:
 - a) For the USA and Canada: Use cord set SVT or SJT (North America) with plug (5-15P or 6-15P) and moulded on appliance connector, IEC60320 type. Similar type cords, conform to UL817 may be employed."
 - b) Europe- Use cord set "H03 VV-F or H03 VVH2-F" with moulded on appliance connector, IEC60320 type and plug according the national wiring rules.
 - i) Denmark-Supply cord of single-phase equipment having a rated current not exceeding 10 A shall be provided with a plug according to the Heavy Current Regulations, Section 107-2-D1. Class I equipment provided with socket-outlets with earth contact or which are intended to be used in locations where protection against indirect contact is required according to the wiring rules shall be provided with a plug in accordance with standard sheet DK 2-1a or DK 2-5a.
 - ii) Ireland-Apparatus which is fitted with a flexible cable or cord and is designed to be connected to a mains socket conforming to I.S. 411 by means of that flexible cable or cord and plug, shall be fitted with a 13 A plug in accordance with Statutory Instrument 525:1997 - National Standards Authority of Ireland (Section 28) (13 A Plugs and Conversion Adaptors for Domestic Use) Regulations, 1997.
 - iii) Spain-Supply cords of single-phase equipment having a rated current not exceeding: - 2.5 A shall be provided with a plug according to UNE EN 50075:1993 - 10 A shall be provided with a plug according to UNE 20315:1994 CLASS I EQUIPMENT provided with socket-outlets with earth contacts, or which are intended to be used in locations where protection against indirect contact is required according to the wiring rules, shall be provided with a plug in accordance with UNE 20315:1994
 - iv) Switzerland-Supply cords of equipment having a rated current not exceeding 10 A shall be provided with a plug complying with SEV 1011 or IEC 884-1 and one of the following dimension sheets:

SEV 6532-2.1991 Plug Type 15	3P+N+PE 250/400 V, 10 A
SEV 6533-2.1991 Plug Type 11	L+N 250 V, 10 A
SEV 6534-2.1991 Plug Type 12	L+N+PE 250 V, 10 A

EN 60309 applies for plugs for currents exceeding 10 A.

- v) UK- Apparatus which is fitted with a flexible cable or cord and is designed to be connected to a mains socket conforming to BS 1363 by means of that flexible cable or cord and plug, shall be fitted with a "standard plug" in accordance with Statutory instrument 1786: 1994 - The Plugs and Sockets etc. (Safety) Regulations 1994, unless exempted by those regulations. NOTE: "Standard plug" is defined in SI 1786: 1994 and essentially means an approved plug conforming to BS 1363 or an approved conversion plug.

To allow a proper air-cooling of the equipment, do not cover the ventilation holes.

No user serviceable parts inside. Refer servicing to qualified personnel. To prevent electrical shock, do not remove covers.

In case the cover of the equipment has been removed, it is imperative that the equipment is closed before power is supplied. The closure of the equipment, with the top lid, is ensured by tightening the two screws on the rear panel.

Whenever it is likely that safety protection is impaired, the instrument must be made inoperative and secured against unintended operation. The appropriate servicing authority must be informed. For example, safety is likely to be impaired if the instrument shows visible damage.

WARNINGS

Do not use the equipment in damp surroundings.

Avoid direct contact with water. Never place the equipment in direct sunlight.

The outside of the equipment may be cleaned using a lightly dampened cloth. Do not use any cleaning liquids containing alcohol, methylated spirit or ammonia etc.

Contents

- 1 RELEASE HISTORY 6**
- 2 WHO SHOULD READ THIS MANUAL?..... 6**
- 3 CONTACT INFORMATION..... 6**
- 4 LIST OF ACRONYMS 6**
- 5 GENERAL SPECIFICATIONS..... 7**
 - 5.1 DESCRIPTION 7
 - 5.2 FEATURES..... 7
- 6 DVB-RCS SYSTEM ARCHITECTURE..... 8**
- 7 FRONT PANEL CONTROL..... 8**
- 8 FRONT CONTROL BUTTONS 9**
- 9 REAR PANEL CONNECTIONS..... 9**
- 10 CONFIGURATION 10**
 - 10.1 DESCRIPTION 10
 - 10.2 LOGIN 10
 - 10.3 USER INTERFACE START UP 11
 - 10.4 GENERAL IDU SET UP..... 12
 - 10.5 ENTERING CORRECT GPS COORDINATES WITH GUI 13
 - 10.6 IP - CONFIGURATION 14
 - 10.7 PORT FORWARDING 16
 - 10.7.1 Port forwarding configuration 17
 - 10.7.2 Configured servers 18
 - 10.8 VPN CONFIGURATION 19
 - 10.9 VALUE ADDED SERVICES 20
 - 10.10 IDU FIRMWARE..... 21
 - 10.11 POINTING PROCEDURE..... 22
 - 10.12 SIT COMMISSIONING..... 24
 - 10.13 TERMINAL STATUS 25
 - 10.14 TCP ACCELERATION 25
 - 10.15 VPN CONNECTIONS 25
 - 10.16 DHCP LEASES..... 26
 - 10.17 EVENT LOG 27
 - 10.18 PEP SERVICE..... 28
 - 10.19 VPN SERVICE..... 28
 - 10.20 USER MANAGER..... 29
- 11 DATA SUMMARY..... 30**
- 12 PERFORMANCE..... 30**

1 Release History

Version/Edit	Date	Details
Edit 0	February 25, 2004	First internal pre-release
Edit 1	May 19, 2004	Update according UL regulations
Edit 2	May 27, 2004	Update according UL regulations
Edit 3	July 22, 2004	Update for release 2.0.0
Edit 4	August 4, 2004	Update of screenshots
Edit 5	November 5, 2004	Update for release 2.1.0

2 Who should read this manual?

This manual will provide the “installer” with the necessary information to install and configure the NTC 2094 IDU via the user interface of the NTC 2097 POP router.

3 Contact information

Should you have questions about your installation or NTC 2094, contact your service provider.

4 List of Acronyms

ACM : Adaptive Coding & Modulation
 ALC : Automatic Level Control
 BDM : Burst Demodulator
 BUC : Block Up Converter
 CCC : Customer Care Centre
 CCMT : Customer Configuration Management Tool
 CPE : Customer Premises Equipment
 CRA : Constant Rate Assignment
 DHCP : Dynamic Host Configuration Protocol
 DNS : Domain Name Server
 DVB : Digital Video Broadcast
 FLE : FW Combiner & IP Encapsulator
 FW : Forward (Link)
 GPS : General Positioning System
 HPS : HTTP Pre-fetching Server
 HTTP : Hyper Text Transfer protocol
 IP : Internet Protocol
 ISP : Internet Service Provider
 LNA : Low Noise Amplifier
 LNB : Low Noise Block Converter

MF- TDMA : Multi Frequency-Time Division Multiple Access
 NAT : Network Address Translation
 NCR : Network Clock Reference
 OMT : Ortho Mode Transducer
 PMS : POP Management Server
 PMT : Performance Monitor Tool
 QoS : Quality of Service
 RCS : Return Channel by Satellite
 RLP : Return Link Processor
 RT : Return (Link)
 SAP : Satellite Access Provider
 SDR : Sit Drive
 SIT : Satellite Interactive Terminal
 SLR : Satellite Link Router
 SME : Small-Medium-Sized Enterprise
 SOHO : Small Office Home Office
 TCP : Transmission Control Protocol
 VBDC : Volume Based Dynamic Capacity
 VPN : Virtual Private Network
 VSAT : Very Small Aperture Terminal
 WCS : Web Caching Server

5 General specifications

5.1 Description

The DVB-RCS Indoor Unit (IDU) is a flexible unit designed for use in IP Broadband Satellite Access Networks. The highly integrated design supports IP over DVB on the Forward Link and IP over ATM on the Return Link and is fully compliant with the DVB-RCS standard.

IP broadband applications such as web browsing, E-mail, file transfer, video and audio streaming are supported by the terminal as well as the unique Multi-Cast capability of Satellite Networks.

The IF-transmit range from 2500 to 3000 MHz and IF-receive range from 950 to 2150 MHz allows connection to a wide choice of Outdoor equipment, all within the specifications of DVB-RCS.

To provide flexible Network Operations, the indoor unit supports TDMA and MF-TDMA access methods on the Return Link.


The Return channel supports rates up to 1 Mb/s while the unit is easily connected to a LAN via the integrated 10Base-T interface.

5.2 Features

- Broadband Wireless Access
- DVB-RCS compliant
- MF-TDMA Return Channel
- Supports IP broadband applications
- Supports Uni- & Multicast IP traffic
- SNMP manageable
- Compact reliable design
- Standard SFF housing
- Easy installation & deployment
- Supports ODUs operating at Ka/Ka-Band, Ka/Ku-Band and Ku/Ku-Band
- SB2100CB Rev. D and tuner/demodulator type SU1278/SVA

6 DVB-RCS system architecture

The IDU is part of the Newtec 2Way-Sat platform. It is installed at the end users premises along with the outdoor unit (ODU) and POP Router:



7 Front panel control



The front panel control LEDs indicate, when lit:

1. **TX**: Traffic bursts are sent towards the outdoor unit (ODU).
2. **RX**: Traffic is received from the forward link.
3. **ON**: The 10 MHz reference signal from block up converter in the ODU is received by the IDU.
4. **Ethernet TX**: Traffic is sent towards the POP router.
5. **Ethernet RX**: Traffic is received from the POP router.

8 Front control buttons



On the front of the IDU the user has access to two buttons:

1. The power button to switch the IDU on and off. Bare in mind that during normal operational conditions, the IDU will not be switched on and off.
2. The reset button, used to reboot the IDU.

9 Rear panel connections



At the rear of the IDU equipment, the following connectors are available:

1. Power supply
2. Test 1: This DB-9 connector is used for lab testing purposes only. It is not accessed by the end user.
3. Test 2: To be accessed by Newtec certified installer only. Used for initial installation and configuration of the IDU.
4. LAN: RJ-45 connection used to connect to the POP router with crossed Ethernet cable
5. ODU TX (N) connector: RF traffic from IDU to ODU
6. ODU RX (F) connector: RF traffic from ODU to IDU

10 Configuration

The configuration of the IDU is done via the graphical interface of the POP router.
In case this equipment has to be replaced or removed, the following procedure is applicable:

1. Switch off the unit with the "POWER" button.
2. Remove Ethernet cable.
3. Remove ODU TX (N) cable.
4. Remove ODU RX (F) cable RF.
5. Remove power cable from wall outlet
6. Remove power cable from IDU.


10.1 Description

After installation of the outdoor unit and pointing of the antenna, the installer can start with the configuration of the IDU & POP router by using web interface on the POP router.

10.2 Login


Connect IDU with crossed Ethernet cable to LAN2 of POP router.
Connect POP (LAN1) to PC with crossed Ethernet cable and **put PC on DHCP**.
Open internet explorer and go to <http://192.168.0.1:2097> (web interface POP router)

A login window asks for username and password:
This username and password is provided by your ISP.




10.3 User Interface start up

After introducing the right user name and password, the user interface of the Pop Router is shown:



On the left the different configuration and monitoring pages can be selected. These pages will all be displayed in the main window.

10.4 General IDU set up



- **ISP ID:** Identifier given to the ISP by the Satellite Access Provider (SAP).
- **SIT ID:** identification given to the SIT (identical to the CCMT SIT ID).
- **Network ID:** fixed value, given by the SAP.
- **Interactive Network ID:** fixed value, given by the SAP.
- **Population ID base:** Value given by the SAP, depending on the used RLP.
- **Population ID Mask:** fixed value, given by the SAP.
- **Forward Link RF-Frequency (GHz):** forward frequency.
- **Forward Link Symbolrate (MBaud):** forward symbolrate.
- **Forward Link Modulation and FEC:** forward modulation type.
- **Return Link RF-Output Attenuator (dB):** attenuation on the return link.
- **LNB Low-Band LO-Frequency (GHz):** the LO frequency of the outdoor unit.
- **LNB High-Band LO-Frequency (GHz):** the LO frequency of the outdoor unit.
- **Return Link 128kBaud PRBS Frequency (GHz):** the frequency of the PRBS tone.
- **GPS Position Tracking (NMEA-0183 GGA):** Switch on, for non static SIT.

After modifying the parameters, click on the “Update Values” button to acknowledge the change. The installer can continue modifying other parameters in other windows and commission the SIT afterwards, via the “SIT Commissioning” window.


10.5 Entering correct GPS coordinates with GUI

First write down longitude, latitude and elevation from GPS receiver on the antenna site.
For example:

Longitude = E 49° 48' 01.0"
Latitude = N 40° 24' 16.9"
Elevation = 125m

Introduce these figures in the appropriate fields in the next window:

By clicking on the button "Update Values", the correct "X,Y,Z" coordinates of the SIT are calculated and introduced in the configuration file of the POP router. The installer can continue modifying other parameters in other windows and commission the SIT afterwards, via the "SIT Commissioning" window.



10.6 IP - Configuration

NTC/2097/AA Newtec SIT Router - Microsoft Internet Explorer

Newtec Satellite Interactive Terminal

A DVB-RCS compliant Solution for 2 Way-Sat Terminals SIT-0-1 Updated: 3:00:35 PM Mon 8 Nov 2004

IP CONFIGURATION

Define WAN/LAN/DMZ IP-addresses...

Installation Task List | Next Task | Commission SIT

Client Terminal IP-Configuration				
	Device	Interface	IP Address	IP Netmask
🔒	POP	Ethernet WAN	172.24.0.1	255.255.255.252
🔒	POP	Ethernet LAN	192.168.2.161	255.255.255.0
🔒	POP	Ethernet DMZ	1.1.1.1	255.255.255.255
🔒	IDU	Wireless Network	172.19.255.254	255.255.255.248

POP-Router backpanel view. (100 Base-T Ethernet interfaces)

Ethernet-port 'LAN1' = Client LAN (Local Area Network)
Ethernet-port 'LAN2' = Satellite WAN (Wide Area Network)
Ethernet-port 'LAN3' = Client DMZ (Demilitarized Zone)

To update an IP address just click on it, a window will be opened where the new address can be introduced. Click on the “OK” button to accept the changes:





To update a netmask, just click on it, a window will be opened where the new address can be introduced:



The installer can continue modifying other parameters in other windows and commission the SIT afterwards, via the "SIT Commissioning" window.


10.7 Port Forwarding

Port Forwarding is the technique of taking packets destined for a specific TCP or UDP port and machine, and 'forwards' them to a different port and/or machine. This is done 'transparently', meaning that network clients can not see that Port Forwarding is being done. They connect to a port on a machine when in fact the packets are being redirected elsewhere.

Prerequisites:

To be able to configure the port forwarding, the firewall has to be disabled. ([See section: value added services](#))

By clicking on the button "Port-Forwarding" in the Configuration menu, the next window is displayed:



10.7.1 Port forwarding configuration

To configure the port forwarding, click on “Add Ports”.


3 consecutive settings have to be made:

Specify target protocol: Provide a protocol for the port forwarding entry:




The dialog box titled "Explorer User Prompt" has a blue header bar with a close button (X) in the top right corner. The main area contains the text "Script Prompt:" followed by "Please specify the target protocol:" and three options: "1=[UDP + TCP] 2=[UDP] 3=[TCP]". Below this is a text input field containing the number "1". On the right side, there are two buttons: "OK" and "Cancel".

Destination IP address: IP address of the server to which the traffic is forwarded.



The dialog box titled "Explorer User Prompt" has a blue header bar with a close button (X) in the top right corner. The main area contains the text "Script Prompt:" followed by "Please enter the destination IP-address:". Below this is a text input field containing the IP address "192.168.10.10". On the right side, there are two buttons: "OK" and "Cancel".

Port: enter the port or port range.




The dialog box titled "Explorer User Prompt" has a blue header bar with a close button (X) in the top right corner. The main area contains the text "Script Prompt:" followed by "Please enter the port or port-range:" and a note "(Use dash to specify a range, example '1000-1100')". Below this is a text input field containing the port number "5050". On the right side, there are two buttons: "OK" and "Cancel".

The installer can continue modifying other parameters in other windows and commission the SIT afterwards, via the “SIT Commissioning” window.

10.7.2 Configured servers

After configuring the port forwarding, the next window displays all entries:



The screenshot shows a web browser window titled "NTC/2097/AA Newtec SiT Router - Microsoft Internet Explorer". The main content area is titled "Newtec Satellite Interactive Terminal" and displays the "TCP/IP Port Forwarding" configuration page. The page includes a navigation menu on the left with sections for CONFIGURATION, MONITORING, and FAULTS & ALARMS. The main content area shows a table of "Port-Forwarding Entries" with two entries: one for TCP and one for UDP, both pointing to the destination IP address 192.168.10.10. Below the table are buttons for "Add Ports" and "Delete Ports".

Port-Forwarding Entries

	Protocol	Destination IP-Address	IP-Port(s)
<input type="radio"/>	TCP	192.168.10.10	5050
<input type="radio"/>	UDP	192.168.10.10	5050

A rule can easily be removed by selected the desired rule and clicking on the “Delete Ports” button.

10.8 VPN configuration

A Virtual Private Network, or VPN, is a private communications network usually used within a company, or by several different companies or organisations, communicating over a public network.

The screenshot shows the 'TelliCrypt VPN Configuration' page in a web browser. The page title is 'Newtec Satellite Interactive Terminal' and the subtitle is 'A DVB-RCS compliant Solution for 2 Way-Sat Terminals'. The page is updated on Mon 8 Nov 2004 at 3:02:40 PM. The page is titled 'TelliCrypt VPN Configuration' and includes a navigation bar with 'Installation Task List | Next Task | Commission SIT'. The page is divided into three main sections: 'Local Setup', 'Remote Connection Setup', and 'Existing Connections'. The 'Local Setup' section has fields for 'Local' VPN ID, Password, and Confirm Password, with a 'Commit' button. The 'Remote Connection Setup' section has fields for 'Remote' VPN ID, Password, Confirm Password, Remote (public) VPN IP-Address, Network IP-Address Remote LAN, and IP-Netmask Remote LAN, with a 'Commit' button. The 'Existing Connections' section has a table with columns for Remote VPN ID, Remote Network IP-Address, and Remote VPN IP-Address, and a 'Remove Connection' button.

To enable this VPN service, the VPN client service must be activated. ([See section: value added services](#))

Local VPN ID: The identification which was given to the Local SIT during the VPN topology design.
Password: Password of the local VPN SIT.

Remote VPN ID: The id which was given to the Remote SIT during the VPN topology design.
Password: Password of the remote VPN SIT.

Remote VPN IP-Address: IP address of the remote SIT

Network IP address Remote LAN: Network IP address of the LAN connected to the remote SIT.

IP netmask Remote LAN: Netmask of the LAN connected to the remote SIT.

10.9 Value added services

To configure the value added services of the POP Router, click on “Device Services”
 This allows the user to enable DHCP server and Firewall of the POP Router.




To switch a service “on” or “off”, click on the “ON/OFF” action button.

After changing the ON/OFF status of a service, commission the SIT via the “SIT Commissioning” window.

10.10 IDU Firmware

This window allows the management of the IDU bootimage. It displays the Primary and Secondary Bootimage, currently installed on the IDU. All available bootimages on the POP and on a USB storage media (when available) are listed and can be selected for uploading to the IDU.




10.11 Pointing Procedure



!WHEN INSTALLING A TEST SIT ALWAYS CONTACT YOUR SAP

This command will be used for adjusting the cross-polar of the antenna together with your SAP.

Go to the menu “Antenna Pointing” in the configuration menu.
The PRBS frequency and the timeout of the carrier are retrieved from the IDU.
To change the PRBS settings, go to the “General IDU Setup” page.



Click on the “Start” button to activate the PRBS tone.



Click on the “OK” button to acknowledge.

The IDU will reboot and start transmitting the PRBS tone at the programmed frequency and during the programmed number of seconds.

The next window is shown:

NTC/2097/AA Newtec SIT Router - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Newtec Satellite Interactive Terminal

A DVB-RCS compliant Solution for 2 Way-Sat Terminals SIT-0-1 Updated: 3:05:53 PM Mon 8 Nov 2004

128 kBaud PRBS tone feature...

Installation Task List | Next Task | Commission SIT

128 kBaud PRBS activated!

The IDU will now automatically reboot and transmit a PRBS for cross polar adjustment...

>> Clear this message

Pointing Procedure (128 kBaud PRBS):

Return Link PRBS Frequency (GHz)

Return Link PRBS Timeout (sec)


⚠ Values shown are directly retrieved from the IDU!

Wait until the IDU has rebooted. This will take about 2 min.


Then check with the HUB station if the return is ok.

If the return is ok, wait until the PRBS times out or reboot the IDU to disable the PRBS tone.

10.12 SIT Commissioning




This window allows the installer to commission the SIT with all modified settings.



Click on the "OK" button to acknowledge.

10.13 Terminal Status



This window displays the status and the monitored parameters of the SIT.

10.14 TCP Acceleration


Under development

10.15 VPN Connections

Under development

10.16 DHCP Leases

This window displays the active and expired DHCP leases which have been issued by the POP router.




The screenshot shows a web browser window titled "NTC/2097/AA Newtec SIT Router - Microsoft Internet Explorer". The main content area is titled "Newtec Satellite Interactive Terminal" and displays "DHCP Leases (Dynamic Host Configuration Protocol) Active IP-Address leases...". A table lists the following lease information:

IP Address	Ethernet	Hostname	Start Date	End Date
192.168.2.254	00:00:39:34:04:b1	INV-544-02	2004/11/08 14:00:05	2004/11/08 17:20:05

Below the table, there is a text prompt: "Click on a lease IP Address from the list above to delete it...". A button labeled "Show all Active and Expired Leases" is positioned below the prompt. The left sidebar contains a navigation menu with sections: CONFIGURATION (GENERAL IDU SETUP, XYZ COORDINATES, IP CONFIGURATION, PORT FORWARDING, VPN CONFIGURATION, DEVICE SERVICES, IDU FIRMWARE, ANTENNA POINTING, SIT COMMISSIONING), MONITORING (TERMINAL STATUS, TCP ACCELERATION, VPN CONNECTIONS, DHCP LEASES), and FAULTS & ALARMS (EVENTS LOG, PEP SERVICE, VPN SERVICE). The user is identified as "User: installer".

A DHCP lease can be deleted by selecting the appropriate address in the IP address list.



10.17 Event log

All activity done in the user interface of the POP router is logged in a log file and is displayed in the Activity log window:

The screenshot shows the 'Newtec Satellite Interactive Terminal' web interface. The main content area is titled 'Activity Log' and includes a filter dropdown set to 'ALL'. Below the filter is a table with 6 logged events. The left sidebar contains a navigation menu with categories: CONFIGURATION (GENERAL IDU SETUP, XYZ COORDINATES, IP CONFIGURATION, PORT-FORWARDING, VPN CONFIGURATION, DEVICE SERVICES, IDU FIRMWARE, ANTENNA POINTING, SIT COMMISSIONING), MONITORING (TERMINAL STATUS, TCP ACCELERATION, VPN CONNECTIONS, DHCP LEASES), and FAULTS & ALARMS (EVENTS LOG, PEP SERVICE, VPN SERVICE). At the bottom of the sidebar, it shows 'User: root'.

Date	Time	User	6 Logged Events
Mon 08 Nov 2004	02:07:21 PM	root	popbox -c sit
Mon 8 Nov 2004	2:06:27 PM	root	Service dhcpd switched ON
Mon 8 Nov 2004	2:01:54 PM	root	General parameters updated
Mon 8 Nov 2004	2:01:41 PM	root	Service cryptd switched OFF
Mon 08 Nov 2004	01:51:57 PM	root	popbox -c sit
Mon 08 Nov 2004	07:20:45 AM	root	New Pop-Router Web-Interface v2.1.0 installed

10.18 PEP Service

The screenshot shows a web browser window titled "NTC/2097/AA Newtec SIT Router - Microsoft Internet Explorer". The page header reads "Newtec Satellite Interactive Terminal" and "A DVB-RCS compliant Solution for 2 Way-Sat Terminals". The "Tellinet Log" section is active, showing a "Log File:" with a "Level:" dropdown set to "Verbose". The log entries are as follows:

```

Lvl:Date      Time (UTC)  :Message
MSG:2004-11-08 12:22:32.206:Program started =====
MSG:2004-11-08 12:22:32.206:Watchdog starting... [185]
MSG:2004-11-08 12:22:32.206:Watchdog started [185].
MSG:2004-11-08 12:22:32.372:Starting new child...
MSG:2004-11-08 12:22:32.372:Started new child [221].
VRB:2004-11-08 12:22:32.447:Child connecting to watchdog on port 1024...
ERR:2004-11-08 12:22:32.447:Connecting to watchdog failed (1075094653).
MSG:2004-11-08 12:22:32.889:tc-recv starting... [221]
MSG:2004-11-08 12:22:32.889:tc-recv version is 2.4.0 (200405241052200) linux2.4_rh7.3
MSG:2004-11-08 12:22:32.889:Log level is "verbose".
WRN:2004-11-08 12:22:32.899:File /usr/local/tellinet/tcrecv/recv.ini, line 386: Unexp
WRN:2004-11-08 12:22:32.899:File /usr/local/tellinet/tcrecv/recv.ini, line 410: Unexp
ERR:2004-11-08 12:22:32.899:Cannot create UDP socket for ETCP on interface 10.2.0.2
ERR:2004-11-08 12:22:32.899:Could not start Enhanced-TCP (No such device)
ERR:2004-11-08 12:22:32.899:An error occurred while starting tc-recv. Shutting down!
MSG:2004-11-08 12:22:32.899:tc-recv shutting down... [221]
MSG:2004-11-08 12:22:33.160:tc-recv stopped [221].
MSG:2004-11-08 12:23:32.386:Child did not connect: Restarting child.
MSG:2004-11-08 12:23:32.386:Starting new child...
MSG:2004-11-08 12:23:32.386:Started new child [805].
VRB:2004-11-08 12:23:32.411:Child connecting to watchdog on port 1024...
MSG:2004-11-08 12:23:32.424:tc-recv starting... [805]
MSG:2004-11-08 12:23:32.424:tc-recv version is 2.4.0 (200405241052200) linux2.4_rh7.3
ERR:2004-11-08 12:23:32.424:Log level is "verbose".
WRN:2004-11-08 12:23:32.433:File /usr/local/tellinet/tcrecv/recv.ini, line 386: Unexp

```


The Log file of the Tellinet software is displayed. This log can be used whenever troubleshooting is needed.

10.19 VPN Service

Under development

10.20 User manager

It is possible to create new users for the graphical user interface, by adding them in the next window. Be aware that users can only be created with the same or less privileges as the logged in user.



11 Data summary

The exposed wiring between IDU and ODU is limited to less than or equal to 140 feet and instructions are provided to avoid exposure of wiring to accidental contact with lightning and power. The ODU circuitry is treated, in this case, as SELV. So, no primary protector is needed in accordance with NEC Sections 725-54 (c); NEC Section 800-30 and NEC article 810. For Canada: CEC Rule 16-224;CEC Rule 60-200, 60-202 and CEC Section 60.

ETHERNET 10 BASE-T USER INTERFACE

connector: RJ-45

SATELLITE INTERFACE

RF IN (RX) :

connector: F(f)
 impedance: 75 Ohm
 frequency: 950 – 2150 MHz
 acquisition range : +/- 3 MHz
 LNB power: 13/17 Volt & 22 kHz tone / 0.35 A max
 Input level: -65dBm to -25dBm

RF OUT (TX) :

connector: N(f)
 impedance: 50 Ohm
 frequency: 2500 -3000 MHz
 Signalling: 10 MHz tone from ODU @ -10 dBm typ.
 ODU-power: +24 Volt / 35 Watt max.
 TX level: -9dBm typically

CONFIGURATION & MANAGEMENT INTERFACE

SNMP MIB access through RJ-45
 Command Line Interface via RS-232

POWER SUPPLY :

110/230V & 60/50 Hz (select switch on the back)

MECHANICAL :

Small Form Factor Housing (SFF),399mm(D)x324mm(W)x95mm(H), weight 5.5 kg

12 Performance

Tx & Rx SYMBOL RATES

Rx rate: 4 to 30 Mbaud
 Tx rate: up to 1 Mbaud

Tx & Rx TRAFFIC RATES

Rx rate: 2 Mbps
 Tx rate: up to 1 Mbps

PROTOCOL SUPPORT

IPv4, TCP, UDP
 SNMP, ICMP, IGMP, TELNET, PACKET FILTER

ARP

ENVIRONMENTAL :

operating temp.: 0° to +50°C
 storage temp.: -20° to +70°C
 up to 95% condensing