



# ***OPERATIONAL MANUAL***

## ***LABORATORY TYPE FURNACES***

### ***MAGMATHERM SERIES***

#### **950°C PRIMARY**

**1100°C BASIC-EXTENDED-ULTIMATE-SUPERIOR**

**1200°C BASIC-EXTENDED-ULTIMATE-SUPERIOR**

**1300°C BASIC-EXTENDED-ULTIMATE-SUPERIOR**



***Machine Serial No :***

*-All rights reserved, belongs to TETRA ISI SİSTEMLERİ SAN. TİC. LTD. / İSTANBUL.  
Any part of this publication can not be reproduced, copied without permission of  
Tetra İsi Sistemleri San Tic. LTD / Istanbul*

\*You can download the operational manual by [http://tetraisi.com/en/?page\\_id=63](http://tetraisi.com/en/?page_id=63)



## Contents

<b>1-DEFINITION:</b> .....	<b>3</b>
<b>2-SAFETY:</b> .....	<b>3</b>
2.1- PROPER OPERATION.....	3
2.2 OPERATION IN SAFE CONDITIONS .....	5
<b>3- PID CONTORL UNIT PROPERTIES</b> .....	<b>6</b>
<b>4-DISPLAY &amp; MENU</b> .....	<b>1</b>
<b>5-MENU STRUCTURE</b> .....	<b>7</b>
<b>6- OPERATING BY MENU AND STARTING THE FURNACE</b> .....	<b>8</b>
6.1 ENTERING MENU .....	8
6.2 TO ENTER & TO CHANGE VALUES .....	8
<i>STARTING</i> .....	9
<i>10 AUTOMATIC START</i> .....	9
<i>20 SYSTEM STATUS</i> .....	10
<i>30 PROGRAMS</i> .....	11
<i>90 ALARM LIST</i> .....	13
<b>7- START AND STOP PROGRAM</b> .....	<b>15</b>
<b>8- FIRST HEATING</b> .....	<b>17</b>
<b>APPENDIX – 1 TECHNICAL SPECIFICATIONS</b> .....	<b>18</b>
<b>APPENDIX – 2 PRIMARY, BASIC, EXTENDED DIFFERENCES</b> .....	<b>21</b>



**IMPORTANT : BEFORE OPERATING THE FURNACE, OPERATING MANUAL MUST BE READ CAREFULLY.**

**IMPORTANT : AFTER READING OPERATING MANUAL, DIRECTIONS THAT ARE EXPLAINED IN THE SECTION 8 (FIRST HEATING) SHOULD BE FOLLOWED VERY CAREFULLY, DURING FIRST HEATING/OPERATING PROCESS.**

## **1-DEFINITION:**

Magmatherm is a laboratory type heating furnace. Heating is performed up to 1100°C (Magmatherm MT 1100 series) and 1200°C (Magmatherm MT 1200 series) directly and/or by stepped control procedure.

## **2-SAFETY:**

Magmatherm heating furnace may harm operating people or surrounding any other materials, unless this operating manual is applied during operating process. Thus;

- Periodical maintenance should be applied.
- Cautions against accidents should be main concern of operators.
- All operating directives, warnings and recommendations in this operating manual have to be followed and applied carefully.

Unless operating directives, warnings and recommendations in this operating manual is followed and applied, company TETRA ISI SİSTEMLERİ LTD. ŞTİ. is not dedicated for the accidents that may occur.

### **2.1- PROPER OPERATION**

- Magmatherm, can reach up to 1100°C and 1200°C ( Depending on MT100 and MT1200 series.) Thus materials that can stand up to 1100°C and 1200°C can be heated in the chamber. The conditions that should be considered during operating or the points which are the reason no to start operational process are as follows



- -Furnace is not started, if there is any living thing in the chamber
- -Any burning, flammable, exploding, poisoning, (Benzene, LPG, Acetylene etc.) material that may harm when it is heated etc is not stored or put inside the chamber. These types of materials should be kept away from the furnace.
- -Outside case of the furnace may be hot. It should be considered. Especially, when the furnace is heated above 1000°C and if it is kept above this temperature 30 minutes or more, you shouldn't touch to outside case/surfaces without using gloves.
- -Instant high heat should be considered, when the front door is open.
- -Electronic and/or Electrical components may create induction current or magnetic field. It may harm any electronic equipment surrounding the furnace. Especially cardiac pacemaker users should be away from the furnace...
- -It should not be operated in closed environments such as in cupboard etc.
- -Furnace should not be operated by multi plug in tools. It should be operated by stationary plugs which are mounted on the wall.



-Explosive, flammable, burning, poisonous materials, don't heat up

**DANGER**



-Hot Surface

**WARNING**



-Instant high temperature, when the front door is opened.

**DANGER**



## 2.2 OPERATION IN SAFE CONDITIONS

“Contribute in to SAFETY CAUTIONS in the work shop.”

Please obey to safety rules.

Please inform responsible person, as soon as you notice any abnormal condition for the furnace.



Please use protective glass or protective gloves, when you are working.



Don't let non-permitted person contact to any electrically alive parts. Possible electrically alive parts should be processed by responsible persons and by experts.

Cables should be protected against/away from any heat, oil, oily material, sharp tools and materials. Cables should be kept away from furnace surface. Any cable may kill, if any parts of the cable are broken/damaged or cable touches on to the furnace surface. Any broken cable should be replaced by the new one.



**DANGER**

-Danger of life due to electrical shock.



**Danger of life due to electrical shock.**

-To touch in to the electrically alive parts may kill, if cable is broken or damaged. Be aware of the environmental affects: Don't use electrical tools, equipments and machines in wet circumstances. Keep light intensity enough to make easier for the working people.

Plug off the machine, before any cleaning, repair and maintenance process.




### 3- PID CONTORL UNIT PROPERTIES

Following properties are included in EXTENDED model. Please check the differences between PRIMARY – BASIC –EXTENDED models at the page appendix 2.

- PID control
- 4 stepped heating control
- 1oC/min-40oC/min heat acceleration control
- 4 memory, easy working via saved process
- Sound warning during step changes
- Sound warning at the end of process.
- Remaining time indicator which may be required during the step where temperature is kept at the same level.
- Date and time
- Total working time indicator.
- Auto start by setting date and time
- Indicator for the temperature of control PCB and warning for the overheating of control PCB
- User friendly control menu by only 6 buttons
- User friendly 4 line display
- First start-warranty time saving mode
- Thermocouple failure warning
- Automatic stop control over 1100 °C. ( MT-1105 )
- Automatic stop control over 1200 °C. ( MT-1205 )
- Door switch ( Heating is cut off, when the door is open. Optional )



## 4-DISPLAY & MENU



- 1-On / off button
- 2-Led indicating on going heating process
- 3-Led indicates that furnace works
- 4-Display
- 5-Heating start
- 6-Heating stop
- 7-Menu process input/enter/change
- 8-Menu process selection
- 9-Menu process selection
- 10-Menu options

## 5-MENU STRUCTURE

- START**
- 10 AUTO START
- 20 SYSTEM STATUS
- 30 PROGRAMS
  - Heating Program -1
- 40 PROGRAMS
  - Heating Program -2
- 50 PROGRAMS
  - Heating Program -3
- 60 PROGRAMS
  - Heating Program -4
- 90 ERROR LIST




## 6- OPERATING BY MENU AND STARTING THE FURNACE

### 6.1 ENTERING MENU

After the furnace is started, if “MENU/BACK” button is pressed, it is possible to reach menu options. “▲” ve “▼” buttons are used to change menu options.



Main Menu



Display for Menu Options

If you see “ENTER” at the right hand corner, it is possible to reach sub menu options via pressing “ENTER” and “▲” ve “▼” buttons are used to change options and “MENU/BACK” button is used come back to top menu.

### 6.2 TO ENTER & TO CHANGE VALUES

If you see “ENT” at the corner of present menu, value is entered & changed by “ENTER” button.

Changing value is between “> <” signs. “▲” ve “▼” buttons are used to increase and decrease the values. “ENTER” button enables the user to reach options which can be altered.

Altered values are saved, when “> <” signs disappear via pressing “ENTER”

You may come out the present menu and you can reach to top menu by “MENU/BACK” button.





## STARTING


When START/STOP button is pressed, following display appears together with 'Bip' sound.



Menu below is traced to change furnace language as soon as the Furnace starts following display appears on the screen.




Changing furnace language is enabled by pressing “▲” ve “▼” and ENTER” buttons. Than, main menu here below appears at the display




his is main display to follow menu options and change the values. “MENU/BACK” button enables to enter menu.


## 10 AUTOMATIC START



AUTOMATIC START is first page on the menu. This option enables the end user to start furnace automatically at the set value of the date and time.




This display is simulation of auto start option which indicates set of the date, time and program including heating receipt of end user.



Value between “< >” signs can be changed and values are saved via “ENTER” button. As soon as “< >” signs disappear on the display, furnace is ready to start heating. If ‘START’ button is pressed, heating program starts to heat up the furnace.


## 20 SYSTEM STATUS



It is an informative display. You can get short info which explain the status and conditions of furnace. You can see sub menus included in SYSTEM STATUS menu respectively as follows;




Indicating furnace chamber instantaneous temperature and temperature of control PCB.




Menu 22 lets see the date, hour information and enables to change these values.



Furnace language is altered by using “ENTER” button. “▲” ve “▼” buttons enable to change the language and “ENTER” button enables to continue furnace process by set language.



MENU 24 is to see serial number of furnace and total heating time of the furnace from the first operation of the furnace.




MENU 25 indicates average temperature of cumulative working of furnace life. This data is used to determine extra warranty period.



DOOR OPEN sensor is optional for Magmatherm furnaces. In quartz tubes placed resistances are not a cause of short circuit or electrical

danger as bare resistances do. If your furnace includes this optional sensor, MENU 26 is displayed in SYSTEM STATUS title. If you set this alarm as ' ON 'and if the door is open, heating resistances are shut down. Red heater led is turned off. You are warned by a sound sensor, if the door is open more than 120 seconds. When the door is closed, heating program continuous.



Precision Thermocouple Calibrator. But if you need to calibrate your furnace by a certified calibrator, MENU 27 enables you to correct any temperature diffraction between +-10°C. And you can keep absolute temperatures which you want to work.

Magmatherm Furnaces are calibrated by Martel TC 100

### 30 PROGRAMS


#### HEATING PROGRAM – 1

Chamber temperature, temperature heating rate , temperetaure witing steps, waiting times can be set by this menu option. Programs which are called 40,50,60 are similar options for other program settings.



MENU ‘ . ‘ MOD’ is character of heating process that means ‘DIRECT’ or ‘STEPPED’ heating. ‘RAMP’ is to determine the heating rate which specify the time to let your furnace reach to set maximum temperature of the steps of the heating programs.


Values can be set, as it was explained in title; ‘ OPERATING BY





Heating rate can be selected between 10°C/min-25°C/min. If you tend to choose higher value than 25°C/min, ‘Maximum’ appears on the display. On this mode, furnace heating rate is set maximum value automatically.



“Temp-1” indicates the first step where temperature is kept stable/constant for the stepped program. If “Direct heating” is set, “Temp-1” is target temperature for a continuous heating without any waiting step. “Waiting Time” is time to keep the temperature of furnace stable at the set value. Depending on the set values, furnace heating continues to reach the next target temperature, after the step temperatures time is ended.




If “Direct Heating” program is chosen, “Temp-1” is the value to keep the furnace stable at the set temperature, as soon as target temperature is reached for the program. If waiting temperature is tended to be decreased after value 1 is reached, waiting temperature is set as ‘Infinite’. In this mode, heating program can be stopped manually.



Menu 33, 34 ve 35 options can be processed, if stepped program is chosen. If you would like to skip any step, step temperature should be set as ‘0’. For example, if you need to use 3 step program ending at 965°C, you should set your third step temperature as 965°C and fourth step temperature as 0. When the third step is over, fourth step is not considered and all heating program is ended after the third step.

## 90 ALARM LIST



It is informative menu if some failure occurs such as thermocouple failure, PCB over heating.



Temperature sensing system has problem. Most probably thermocouple has a defect. If you have this message, please get in touch with your distributor or TETRA ISI directly.



cut off. This automatic system is directed by control board sensor. You get this message, If this sensor has a defect and If you have this message on the display, please get in touch with your distributor or TETRA ISI directly.

Control unit protected against over heating by a sensor. If the control unit is overheated, heating power is



This message is displayed, if actual time ( Date and time ) circuit has any problem.



If the heating chamber exceeds continious working temperature of the furnace.



If the heating chamber exceeds maximum temperature of the furnace. Menu 95 is displayed and sound warning starts to warn you.



If the PCB temperature exceeds 65°C, this message is followed by sound warning and heating power is cut off. When the PCB is cooled down and if 55°C is kept, heating program starts to continue.




If the furnace is heated up faster than set value, this message is displayed and sound warning starts to work.




The furnace time is powered by a battery in the control unit. If you see this message on the display, battery should be replaced.

## 7- START AND STOP PROGRAM



You should reach this menu to be able to start heating. If "ENTER" button is pressed, 'HEATING' option is activated and heating program selection appears on the display





START' button and heating is activated.

Any heating program can be selected by "▲" ve "▼" buttons and program starts by pressin green colour '



When heating is activated, the proces can be followed by this screen. Continuing program, chamber temperature, waiting time (if the process is at the waiting level) can be observed by this screen .

While furnace is working, program can be stopped by pressing ' STOP ' button. You should press ' START' to continue Double pressing ' STOP ' lets you come out from the program.





## 8- FIRST HEATING

Following conditions should be considered, directions must be applied step by step, and the importance of the first heating process should be kept in mind, when Magmatherm Furnace is operated and heated up for the first time.

8.1- Enough free field, surrounding the furnace should be kept. Recommended distance is minimum 30 cm. This free space will increase the furnace performance because of air circulation. At the same time, any fire or explosion danger which may occur due to any material left around the furnace. **Please don' t forget**, when the furnace reaches to high temperatures, the surface of the furnace reaches to high temperatures too. Any flammable and explosive material which is close to furnace can be a reason for the fire or explosion danger.

8.2- Some gas and fumes due to some chemicals which is used on the electronic parts, in the isolation materials and due to outer furnace surface paint can be harmful if it is breathed directly, during the first heating process. Protective glasses and breathing masks should be definitely used, during first heating and very good air circulation in the working room should be kept.

8.3- During the first heating up process, furnace should be heated up according to following temperature-time table

Heating up to 1000 °C  
Waiting for 2 hours  
Heating up to 1100 °C  
Waiting for 30 minutes.

This procedure can be completed by Magmatherm Programs easily.

**Please don' t touch furnace without gloves, especially during first heating process, due to hot surfaces.**



## APPENDIX – 1 Technical Specifications

### 1100°C BASIC / EXTENDED / ULTIMATE / SUPERIOR 5 Liter / 7 Liter / 10 Liter

PRODUCT	MT1105-B2 MT1105-E4 MT1105-U8 MT1105-S16	MT1107-B2 MT1107-E4 MT1107-U8 MT1107-S16	MT1110-B2 MT1110-E4 MT1110-U8 MT1110-S16
Maximum Working T*	1100°C	1100°C	1100°C
Continues Working T	1075°C	1075°C	1075°C
Maximum Power	2000W	2000W	3000W
Maximum Amper (I max)	10A	10A	14A
Main Voltage / Frequency	220V / 50Hz	220V / 50Hz	220V / 50Hz
Heating Chamber Volume	5 Liter	7 Liter	10 Liter
Heating Chamber Dim. (WxDxH)	15x23x15 [cm]	20x23x16cm	25x23x18 [cm]
Outer Dimension (WxDxH)	48x67x64 [cm]	58x67x67 [cm]	58x67x67 [cm]
Package Dimension	50x69x66 [cm]	60x69x69 [cm]	60x69x69 [cm]
Net Weight	27 kg	?	46 kg
Gross Weight	28,8 kg	?	47,8 kg
GUARANTY PERIOD**			
Heating Resistance	2 Years	2 Years	2 Years
PID Control Unit	2 Years	2 Years	2 Years
Certificates	CE ISO 9001:2008	CE ISO 9001:2008	CE ISO 9001:2008

\*Furnace is durable at this temperature, but control unit does not enable to set this value. If the inner chamber exceeds this temperature, deformation starts to occur and guaranty period is not valid any longer.

\*\* Guaranty Period of PID Control Unit for EXTENDED-ULTIMATE-SUPERIRO models is 3 years.

### 1200°C BASIC / EXTENDED / ULTIMATE / SUPERIOR 5 Liter / 7 Liter / 10 Liter

PRODUCT	MT1205-B2 MT1205-E4 MT1205-U8 MT1205-S16	MT1207-B2 MT1207-E4 MT1207-U8 MT1207-S16	MT1210-B2 MT1210-E4 MT1210-U8 MT1210-S16
Maximum Working T*	1200°C	1200°C	1200°C
Continues Working T	1175°C	1175°C	1175°C
Maximum Power	2000W	2000W	3000W
Maximum Amper (I max)	10A	10A	14A
Main Voltage / Frequency	220V / 50Hz	220V / 50Hz	220V / 50Hz
Heating Chamber Volume	5 Liter	7 Liter	10 Liter
Heating Chamber Dim. (WxDxH)	15x23x15 [cm]	20x23x16cm	25x23x18 [cm]
Outer Dimension (WxDxH)	48x67x64 [cm]	58x67x67 [cm]	58x67x67 [cm]



Package Dimension	50x69x66 [cm]	60x69x69 [cm]	60x69x69 [cm]
Net Weight	27 kg	?	46 kg
Gross Weight	28,8 kg	?	47,8 kg
GUARANTY PERIOD**			
Heating Resistance	2 Years	2 Years	2 Years
PID Control Unit	2 Years	2 Years	2 Years
Certificates	CE ISO 9001:2008	CE ISO 9001:2008	CE ISO 9001:2008

\*Furnace is durable at this temperature, but control unit does not enable to set this value. If the inner chamber exceeds this temperature, deformation starts to occur and guaranty period is not valid any longer.

\*\* Guaranty Period of PID Control Unit for EXTENDED-ULTIMATE-SUPERIRO models is 3 years.

### 1300°C BASIC / EXTENDED / ULTIMATE / SUPERIOR 7 Liter / 10 Liter

PRODUCT	MT1307-B2 MT1307-E4 MT1307-U8 MT1307-S16	MT1310-B2 MT1310-E4 MT1310-U8 MT1310-S16
Maximum Working T*	1300°C	1300°C
Continues Working T	1250°C	1250°C
Maximum Power	2000W	3000W
Maximum Amper (I max)	10A	14A
Main Voltage / Frequency	220V / 50Hz	220V / 50Hz
Heating Chamber Volume	7 Liter	10 Liter
Heating Chamber Dim. (WxDxH)	20x23x16cm	25x23x18 [cm]
Outer Dimension (WxDxH)	58x67x67 [cm]	58x67x67 [cm]
Package Dimension	60x69x69 [cm]	60x69x69 [cm]
Net Weight	?	46 kg
Gross Weight	?	47,8 kg
GUARANTY PERIOD**		
Heating Resistance	2 Years	2 Years
PID Control Unit	2 Years	2 Years
Certificates	CE ISO 9001:2008	CE ISO 9001:2008

\*Furnace is durable at this temperature, but control unit does not enable to set this value. If the inner chamber exceeds this temperature, deformation starts to occur and guaranty period is not valid any longer.

\*\* Guaranty Period of PID Control Unit for EXTENDED-ULTIMATE-SUPERIRO models is 3 years.



## 950°C PRIMARY 3 Liter / 5 Liter Technical Data

<b>PRODUCT</b>	<b>MT9503-P</b>	<b>MT9505-P</b>
Maximum Working T	950°C	950°C
Continues Working T	950°C	950°C
Maximum Power	1500W	1500W
Maximum Amper (I max)	8A	8A
Main Voltage / Frequency	220V / 50Hz	220V / 50Hz
Heating Chamber Volume	3 Litre	5 Liter
Heating Chamber Dim. (WxDxH)	11,5x23x11,5 [cm]	15x23x15cm
Outer Dimension (WxDxH)	40x60x55 [cm]	40x60x55 [cm]
Package Dimension	50x69x66 [cm]	50x69x66 [cm]
Net Weight	18 kg	21 kg
Gross Weight	19,5 kg	22,5 kg
<b>GUARANTY PERIOD</b>		
Heating Resistance	2 Years	2 Years
PID Control Unit	2 Years	2 Years
Certificates	CE ISO 9001:2008	CE ISO 9001:2008



APPENDIX – 2 Primary, Basic, Extended, Ultimate, Superior Differences

	<b>PRIMARY</b>	<b>BASIC</b>	<b>EXTENDED</b>
Working Temperature	950C	1075C-1175C-1250C	1075C-1175C-1250C
Heating Rate	5-25C/min.	5-20C/min.	5-20C/min.
Display	7 segment	4 line	4 line
Heating Program	2 level	2 level	4 level
Memory	2	2	4
Automatic Start Program	NO	NO	YES
Follow up for the waiting level remaining time	NO	NO	YES
Skip the waiting level	NO	NO	YES
Cumulative Heating Time	YES	YES	YES
Cumulative Average Working Temperature	NO	YES	YES
Temperature Calibration Via Menu	NO	NO	YES
Guaranty Period			
<i>RESISTANCE WIRE</i>	2 YEAR	2 YEAR	2 YEAR
<i>CONTROL UNIT</i>	2 YEAR	3 YEAR	3 YEAR

	<b>ULTIMATE</b>	<b>SUPERIOR</b>
Working Temperature	1075C-1175C-1250C	1075C-1175C-1250C
Heating Rate	5-20C/min.	Adjustable independently for each level 5-20C/min.
Display	4 line	4 line
Heating Program	8 level	8 level 5 <sup>th</sup> Memory 16 level
Memory	6	5
Automatic Start Program	YES	YES
Follow up for the waiting level remaining time	YES	YES



Skip the waiting level	YES	YES
Cumulative Heating Time	YES	YES
Cumulative Average Working Temperature	YES	YES
Temperature Calibration Via Menu	YES	YES
Guaranty Period		
<i>RESISTANCE WIRE</i>	2 YEAR	2 YEAR
<i>CONTROL UNIT</i>	3 YEAR	3 YEAR